

Versatec® VS

VARIABLE SPEED

Commercial

Water Source/Geothermal Heat Pump

- R-410A Refrigerant
- 10-15 Tons

Installation Information

Water Piping Connections

Electrical

Startup Procedures

Troubleshooting

Preventive Maintenance




Versatec Variable Speed 10-15 Ton Installation Manual



Table of Contents

Model Nomenclature	4
Electrical Availability	4
General Installation Information	5
Dimensional Data	6
Installation Notes	13
Duct System, Water Piping, and Condensate Drain.	16
Water Quality	17
System Cleaning and Flushing.	18
Open Loop Ground Water Systems	19
Freeze Detection	19
Electrical Connections.	20
Electrical Data.	21
Blower Performance Data.	22
Wiring Schematics	24
Controls - Aurora Advanced Variable Speed Control	29
Controls - UPC DDC Control (optional)	38
Unit Startup	47
Operating Limits.	48
Operating Parameters	49
Pressure Drop	49
Reference Calculations and Legend	50
Refrigerant Circuit Guideline	51
Compressor and Thermistor Resistance	52
Troubleshooting	53
Startup/Troubleshooting Form	54
Preventive Maintenance	56
Replacement Procedures	56
Revision Guide.	59

Model Nomenclature



Notes:
 1 – 575V includes factory installed step down transformer on plenum fan.
 2 – not available on UVV/UVH180 with 208-230V/60/3 .
 3 – Only available on controls option.

Rev.: 19 November 2019

Electrical Availability

VS ECM

Voltage	Model	
	120	180
208-230/60/3	•	•
460/60/3	•	•
575/60/3	*	*

Legend: 08/01/2019
 NA = Not Available
 • = Voltage available in this size
 * = With step down transformer on fan motor

General Installation Information

Safety Considerations



WARNING: Before performing service or maintenance operations on a system, turn off main power switches to the indoor unit. If applicable, turn off the accessory heater power switch. Electrical shock could cause personal injury.

Installing and servicing heating and air conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair or service heating and air conditioning equipment. Untrained personnel can perform the basic maintenance functions of cleaning coils and cleaning and replacing filters. All other operations should be performed by trained service personnel. When working on heating and air conditioning equipment, observe precautions in the literature, tags and labels attached to the unit and other safety precautions that may apply.

Follow all safety codes. Wear safety glasses and work gloves. Use a quenching cloth for brazing operations and have a fire extinguisher available.

Moving and Storage

Move units in the normal “up” orientation. Horizontal units may be moved and stored per the information on the packaging. Do not stack more than three units in total height. When the equipment is received, all items should be carefully checked against the bill of lading to be sure all crates and cartons have been received. Examine units for shipping damage, removing the units from the packaging if necessary. Units in question should also be internally inspected. If any damage is noted, the carrier should make the proper notation on the delivery receipt, acknowledging the damage.

Unit Location

Locate the unit in an indoor area that allows for easy removal of the filter and access panels. Location should have enough space for service personnel to perform maintenance or repair. Provide sufficient room to make water, electrical and duct connection(s). If the unit is located in a confined space, such as a closet, provisions must be made for return air to freely enter the space by means of a louvered door, etc. Any access panel screws that would be difficult to remove after the unit is installed should be removed prior to setting the unit. On horizontal units, allow adequate room below the unit for a condensate drain trap and do not locate the unit above supply piping. **Care should be taken when units are located in unconditioned spaces to prevent damage from frozen water lines and excessive heat that could damage electrical components.**




WARNING: To avoid equipment damage and possible voiding of warranty, be sure that properly sized strainers are installed upstream of both brazed plate heat exchangers to protect them against particles in the fluid.

Installing Vertical Units

Prior to setting the unit in place, remove and discard the compressor hold down shipping bolt located at the front of the compressor mounting bracket.


Vertical units are available in left or right air return configurations. Top flow vertical units should be mounted level on a vibration absorbing pad slightly larger than the base to provide isolation between the unit and the floor. It is not necessary to anchor the unit to the floor (see figure below).

Vertical Unit Mounting



Dimensional Data

LEFT RETURN SHOWN




Large Variable Speed - Horizontal Dimensional Data

Horizontal Models	Overall Cabinet			Water Connections				Discharge Connection				Return Connection*			Electrical Connections		Unistrut Hanging			
	A	B	C	1	2	5	Loop	G	H	J	K	L	M	N	P	R	T	U	V	
	Width	Depth	Height	In	Out	Condensate	Water FPT	Filter Rack Width	From Edge	Supply Height	Supply Width	From Edge	Return Depth	Return Height	From Edge	Height	From Edge	Unistrut/Unistrut	Unistrut/Unistrut	
120	in.	34.0	89.0	29.9	8.1	15.1	3.2	2"	3.1	5.0	24.0	24.0	4.3	47.6	23.5	3.9	25.9	1.7	24.6	61.0
	cm.	86.4	226.1	75.9	20.6	38.4	8.1	50.8 mm	7.9	12.7	61.0	61.0	10.9	120.9	59.7	9.9	65.8	4.3	62.5	154.9
180	in.	34.0	110.0	29.9	8.1	15.1	3.2	2"	3.1	5.0	24.0	24.0	4.3	65.6	23.5	3.9	25.9	1.7	35.1	71.5
	cm.	86.4	279.4	75.9	20.6	38.4	8.1	50.8 mm	7.9	12.7	61.0	61.0	10.9	166.6	59.7	9.8	65.8	4.3	89.2	181.6

*Dimensions for return connections are for the deluxe filter rack that is suitable for ducted return applications.

Dimensional Data cont.

LEFT RETURN SHOWN




Large Variable Speed - Vertical Dimensional Data

Vertical Models	Overall Cabinet			Water Connections				Return Connection*				Discharge Connection			Electrical Connections		
	A	B	C	1	2	3	Loop	G	H	J	K	L	M	N	P	R	
	Width	Depth	Height	In	Out	Condensate	Water FPT	Filter Rack	From Edge	Return Depth	Return Height	From Edge	Supply Width	Supply Height	From Edge	Height	
120	in.	34.0	36.3	72.5	8.1	15.1	22.1	2"	3.1	3.2	29.9	37.8	4.1	28.0	16.0	3.9	27.4
	cm.	86.4	92.2	184.2	20.6	38.4	56.1	50.8 mm	7.9	8.1	75.9	96.0	10.4	71.1	40.6	9.9	69.6
180	in.	34.0	46.3	72.5	8.1	15.1	22.1	2"	3.1	3.2	39.9	37.8	4.1	38.0	16.0	3.9	27.4
	cm.	86.4	117.5	184.2	20.6	38.4	56.1	50.8 mm	7.9	8.1	101.3	96.0	10.4	96.5	40.6	9.9	69.6

*Dimensions for return connections are for the deluxe filter rack that is suitable for ducted return applications

Dimensional Data cont.

LEFT RETURN SHOWN




Large Variable Speed - Vertical Bottom Flow Dimensional Data

Vertical Bottom Flow Models	Overall Cabinet			Water Connections				Return Connection*				Discharge Opening			Electrical Connections		
	A	B	C	1	2	3	Loop	G	H	J	K	L	M	N	P	R	
	Width	Depth	Height	In	Out	Condensate		Water FPT	Filter Rack	From Edge	Return Depth	Return Height	From Edge	Supply Width	Supply Height	From Edge	Height
	using deluxe filter rack																
120	in.	34.0	36.3	72.5	23.4	16.4	4.5	2"	3.1	3.2	29.9	37.8	4.1	28.0	15.0	3.9	4.0
	cm.	86.4	92.2	184.2	59.4	41.7	11.4	50.8 mm	7.9	8.1	75.9	96.0	10.4	71.1	38.1	9.9	10.2
180	in.	34.0	46.3	72.5	23.4	16.4	4.5	2"	3.1	3.2	39.9	37.8	4.1	38.0	15.0	3.9	4.0
	cm.	86.4	117.5	184.2	59.4	41.7	11.4	50.8 mm	7.9	8.1	101.3	96.0	10.4	96.5	38.1	9.9	10.2


*Dimensions for return connections are for the deluxe filter rack that is suitable for ducted return applications

Dimensional Data cont.




FRONT

LEFT RETURN




FRONT



FRONT

RIGHT RETURN



FRONT

Vertical Bottom Flow Models	Overall			Discharge Opening				
	A	B	C	D	E	F	G	
	Width	Depth	Height	From Edge	Supply Width	Supply Height	From Edge	
120	in.	34.0	36.3	4.0	4.1	28.0	15.0	3.0
	cm.	86.4	92.2	10.2	10.4	71.1	38.1	7.6
180	in.	34.0	46.3	4.0	4.1	38.0	15.0	3.0
	cm.	86.4	117.5	10.2	10.4	96.5	38.1	7.6

Weight Distribution Table


Model	Vertical Shipping Weight	Horizontal Shipping Weight	Horizontal Weight Distribution			
			Front		Back	
			D	E	F	G
120	792	807	193	203	188	194
	(359)	(366)	(88)	(92)	(85)	(88)
180	926	1308	331	330	309	303
	(420)	(593)	(150)	(150)	(140)	(137)

Weights are listed in lbs. (kg).
Distributed weights for left return units

7/25/18

Dimensional Data cont.


Waterside Economizer Option



Vertical Economizers- Top Flow	Overall Cabinet			Water Lines							Filter Rack			
	A	B	C	D	E	F	G	H	J	Loop	K	L	M	
	Width	Depth	Height	From TOP	Length LR	Length RR	Width	From Edge	Depth	Water FPT	From Top	Return Depth	Return Height	
120	in.	7.2	36.0	42.0	49.0	9.5	6.6	2.6	1.6	8.0	1 1/2"	2.1	29.9	37.8
	cm.	18.3	91.4	106.7	124.5	24.1	16.8	6.6	4.1	20.3	38.1 mm	5.3	75.9	96.0
180	in.	7.2	46.0	42.0	48.5	9.5	6.6	2.6	1.6	8.0	1 1/2"	2.1	39.9	37.8
	cm.	18.3	116.8	106.7	123.2	24.1	16.8	6.6	4.1	20.3	38.1 mm	5.3	101.3	96.0

Dimensional Data cont.


Waterside Economizer Option



Vertical Economizers- Bottom Flow	Overall Cabinet			Water Lines							Drain Pan		Filter Rack			
	A	B	C	D	E	F	G	H	J	Loop	K	L	M	N	O	
	Width	Depth	Height	From BTM	Length LR	Length RR	Width	From Edge	Depth	Water FPT	From Edge	From Bottom	From Bottom	Return Depth	Return Height	
120	in.	7.1	36.0	42.0	52.3	6.6	9.5	2.6	1.5	8.0	1 1/2"	2.5	4.6	5.1	29.9	37.8
	cm.	18.0	91.4	106.7	132.8	16.8	24.1	6.6	3.8	20.3	38.1 mm	6.4	11.7	13.0	75.9	96.0
180	in.	7.2	46.1	42.0	52.3	6.6	9.5	2.6	1.5	8.0	1 1/2"	2.5	4.6	5.1	39.9	37.8
	cm.	18.3	117.1	106.7	132.8	16.8	24.1	6.6	3.8	20.3	38.1 mm	6.4	11.7	13.0	101.3	96.0

Dimensional Data cont.

Waterside Economizer Option



Horizontal Economizers	Overall Cabinet			Water Lines							Filter Rack			Base Railing			
	A	B	C	D	E	F	G	H	J	Loop	K	L	M	T	U	V	
	Width	Depth	Height	Depth	Width	From Edge	From Top	Length	Drain Pan	Water FPT	From Edge	Return Depth	Return Height	From Edge	Comp. Sect.	A.H. Sect.	
120	in.	7.1	56.5	27.4	17.2	2.0	1.6	4.8	18.2	5.0	1 1/2"	4.7	47.6	23.5	1.7	24.5	61.1
	cm.	18.0	143.5	69.6	43.7	5.1	4.1	12.2	46.2	12.7	38.1 mm	11.9	120.9	59.7	4.3	62.2	155.2
180	in.	7.1	72.5	27.4	17.2	2.0	1.6	4.8	18.2	5.0	1 1/2"	3.3	65.6	23.5	1.7	35.1	71.5
	cm.	18.0	184.2	69.6	43.7	5.1	4.1	12.2	46.2	12.7	38.1 mm	8.4	166.6	59.7	4.3	89.2	181.6

Installation Notes

Typical Unit Installation

Unit Location


Locate the unit in an indoor area that allows for easy removal of the filter and access panels. Location should have enough space for service personnel to perform maintenance or repair. Provide sufficient room to make water, electrical and duct connection(s). If the unit is located in a confined space, such as a closet, provisions must be made for return air to freely enter the space by means of a louvered door, etc. Any access panel screws that would be difficult to remove after the unit is installed should be removed prior to setting the unit. On horizontal units, allow adequate room below the unit for a condensate drain trap and do not locate the unit above supply piping. Care should be taken when units are located in unconditioned spaces to prevent damage from frozen water lines and excessive heat that could damage electrical components.

Water Piping

Piping is usually design as 'reverse return' to equalize flow paths through each unit. A short flexible pressure rated hose is used to make connection to the fixed building

piping system. This hose is typically stainless steel braid and includes a swivel fitting on one end for easy removal and is flexible to help isolate the unit for quieter operation. Isolation valves for servicing, y-strainers for filtering and memory-stop flow valve or a balancing valve can be provided for consistent water flow through the unit.

All unit source water connections are fittings that accept a male pipe thread (MPT). Insert the connectors by hand, then tighten the fitting with a wrench to provide a leakproof joint. The open and closed loop piping system should include pressure/temperature ports for serviceability. The proper water flow must be provided to each unit whenever the unit operates. To assure proper flow, use pressure/temperature ports to determine the flow rate. These ports should be located at the supply and return water connections on the unit. The proper flow rate cannot be accurately set without measuring the water pressure drop through the refrigerant-to-water heat exchanger. Never use flexible hoses smaller than the inside diameter of the water connection at the unit. Limit hose length to 10 feet per connection. Check carefully for water leaks.



Installation Notes cont.

Installing Horizontal Units

Remove and discard the compressor hold down shipping bolt located at the front of the compressor mounting bracket prior to setting the unit in place. Horizontal units are available with side or end discharge.


NOTE: Left (Right) Return Side Discharge can be converted to Left (Right) Return End Discharge or vice versa, without additional custom sheet metal parts. Horizontal units are normally suspended from a ceiling by six 1/2 in. diameter threaded rods. The rods are usually attached to the unit by hanger bracket kits furnished with each unit.

Lay out and install the threaded rods and 1 5/8" strut

channel as shown in the Horizontal Dimensional Data. The unit should be pitched approximately 1/4 in. toward the drain in both directions to facilitate the removal of condensate.

Some applications require the installation of horizontal units on an attic floor. In this case, the unit should be set in a full size secondary drain pan on top of a vibration absorbing pad. The secondary drain pan prevents possible condensate overflow or water leakage damage to the ceiling. The secondary drain pan is usually placed on a plywood base isolated from the ceiling joists by additional layers of vibration absorbing material.

CAUTION: Do not use rods smaller than 1/2 in. diameter since they may not be strong enough to support the unit. The rods must be securely anchored to the ceiling.



Installation Notes cont.

Acoustical Considerations and Equipment Sound Performance

Sound Performance

The Versatec Variable Speed is third party sound rated in accordance with ARI 260. Please consult WaterFurnace Sound Performance Data Catalog for details on the AHRI standard and sound performance data.

Recommendations for Noise Reduction

Horizontal Unit Location


- Specify equipment with quietest sound power ratings
- Do not locate units above areas with a required NC 40 or less
- Space WSHP at least 10 ft (3m) apart to avoid noise summing of multiple units in a space.
- Maximize the height of the unit above the ceiling (horizontal).
- Suspend unit with isolation grommets that are appropriately rated to reduce vibrations (horizontal).

Vertical Unit Location

- Specify equipment with quietest sound power ratings
- Space WSHP at least 10 ft (3m) apart to avoid noise summing of multiple units in a space.
- Acoustic ceiling coatings can greatly reduce noise levels in mechanical rooms.
- Mount unit on a sound absorbing pad, extruded polystyrene, rubber or cork pad.

Ductwork

- Ensure return air grilles will not allow line of site noise to transfer to adjacent space. Use a sound barrier or some other material to isolate the grille from the unit. A supply grille, boot and short piece of flex duct pointed away from the unit can greatly attenuate equipment noise.
- Use a canvas isolation duct connector at the supply and return duct connection of the unit.
- Internally line the discharge and return duct within the first 4-8 feet of unit with acoustic insulation. Install an internally lined 'L' shaped return duct elbow at return grille. Face the elbow away from adjacent units.
- Always install at least one 90° elbow in the discharge duct to eliminate line of sight noise transmission of the blower.
- Use turning vanes at all elbows and tees to reduce turbulence.
- Limit supply duct velocities to less than 1,000 fpm
- Design and install ductwork as stiff as possible
- Allow 3 duct diameters both up and down stream of the unit before any fittings or transitions are installed.
- Use duct sealant on all duct joints.
- Install a short (2-4') of flex duct on all branch ducts just prior to discharge boot or diffuser to reduce vibration and duct sound prior to delivery in the room.
- Locate the branch duct balancing damper as far away from the diffuser as possible.
- In ceiling plenum systems, install an internally lined 'L' shaped return duct elbow at unit. Face the elbow away from adjacent units (horizontal).



Duct System

An air outlet collar is provided on vertical top flow units and all horizontal units to facilitate a duct connection. A flexible connector is recommended for discharge and return air duct connections on metal duct systems. Uninsulated duct should be insulated with a minimum of 1-inch duct insulation. Application of the unit to uninsulated ductwork in an unconditioned space is not recommended as the unit's performance will be adversely affected.

If the unit is connected to existing ductwork, check the duct system to ensure that it has the capacity to accommodate the air required for the unit application. If the duct is too small, as in the replacement of heating only systems, larger ductwork should be installed. All existing ductwork should be checked for leaks and repaired if necessary.

The duct system should be sized to handle the design airflow quietly and efficiently. To maximize sound attenuation of the unit blower, the supply and return plenums should include an internal duct liner of fiberglass or constructed of ductboard for the first few feet. On systems employing a sheet metal duct system, canvas connectors should be used between the unit and the ductwork. If air noise or excessive airflow is a problem, the blower speed can be changed.

Water Piping

The proper water flow must be provided to each unit whenever the unit operates. To assure proper flow, use pressure/temperature ports to determine the flow rate. These ports should be located at the supply and return water connections on the unit. The proper flow rate cannot be accurately set without measuring the water pressure drop through the refrigerant-to-water heat exchanger.


All source water connections on commercial units are fittings that accept a male pipe thread (MPT). Insert the connectors by hand, then tighten the fitting with a wrench to provide a leakproof joint. When connecting to an open loop (groundwater) system, thread any copper MPT fitting into the connector and tighten in the same manner as described above.

Condensate Drain


On vertical units, the internal condensate drain assembly consists of a drain tube which is connected to the drain pan, a 3/4 in. PVC female adapter and a flexible connecting hose. The female adapter may exit either the front or the side of the cabinet. The adapter should be glued to the field-installed PVC condensate piping. On vertical units, a condensate hose is inside all cabinets as a trapping loop; therefore, an external trap is not necessary.

On horizontal and bottom flow units, a PVC stub or stainless steel tube is provided for condensate drain piping connection. An external trap is required (see below). If a vent is necessary, an open stand pipe may be applied to a tee in the field-installed condensate piping.

Horizontal Drain Connection (Composite Drain Pan)



Unit Pitch for Drain



Water Quality

In ground water situations where scaling could be heavy or where biological growth such as iron bacteria will be present, a closed loop system is recommended. The heat exchanger coils in ground water systems may, over a period of time, lose heat exchange capabilities due to a buildup of mineral deposits inside. These can be cleaned, but only by a qualified service mechanic, as special solutions and pumping equipment are required. Hot water generator coils can likewise become scaled and possibly plugged. In areas

with extremely hard water, the owner should be informed that the heat exchanger may require occasional flushing. Failure to adhere to the guidelines in the water quality table could result in loss of warranty.

Units with cupronickel heat exchangers are recommended for open loop applications due to the increased resistance to build-up and corrosion, along with reduced wear caused by acid cleaning.

Material		Copper	90/10 Cupronickel	316 Stainless Steel
pH	Acidity/Alkalinity	7 - 9	7 - 9	7 - 9
Scaling	Calcium and Magnesium Carbonate	(Total Hardness) less than 350 ppm	(Total Hardness) less than 350 ppm	(Total Hardness) less than 350 ppm
Corrosion	Hydrogen Sulfide	Less than 0.5 ppm (rotten egg smell appears at 0.5 ppm)	10 - 50 ppm	Less than 1 ppm
	Sulfates	Less than 125 ppm	Less than 125 ppm	Less than 200 ppm
	Chlorine	Less than 0.5 ppm	Less than 0.5 ppm	Less than 0.5 ppm
	Chlorides	Less than 20 ppm	Less than 125 ppm	Less than 300 ppm
	Carbon Dioxide	Less than 50 ppm	10 - 50 ppm	10 - 50 ppm
	Ammonia	Less than 2 ppm	Less than 2 ppm	Less than 20 ppm
	Ammonia Chloride	Less than 0.5 ppm	Less than 0.5 ppm	Less than 0.5 ppm
	Ammonia Nitrate	Less than 0.5 ppm	Less than 0.5 ppm	Less than 0.5 ppm
	Ammonia Hydroxide	Less than 0.5 ppm	Less than 0.5 ppm	Less than 0.5 ppm
	Ammonia Sulfate	Less than 0.5 ppm	Less than 0.5 ppm	Less than 0.5 ppm
Iron Fouling (Biological Growth)	Total Dissolved Solids (TDS)	Less than 1000 ppm	1000 - 1500 ppm	1000 - 1500 ppm
	LSI Index	+0.5 to -0.5	+0.5 to -0.5	+0.5 to -0.5
	Iron, FE ²⁺ (Ferrous) Bacterial Iron Potential	< 0.2 ppm	< 0.2 ppm	< 0.2 ppm
Erosion	Iron Oxide	Less than 1 ppm, above this level deposition will occur	Less than 1 ppm, above this level deposition will occur	Less than 1 ppm, above this level deposition will occur
	Suspended Solids	Less than 10 ppm and filtered for max. of 600 micron size	Less than 10 ppm and filtered for max. of 600 micron size	Less than 10 ppm and filtered for max. of 600 micron size
	Threshold Velocity (Fresh Water)	< 6 ft/sec	< 6 ft/sec	< 6 ft/sec

NOTES: Grains = ppm divided by 17
mg/L is equivalent to ppm

2/22/12


System Cleaning and Flushing

Cleaning and Flushing

Prior to start up of any heat pump, the water circulating system must be cleaned and flushed of all dirt and debris.

If the system is equipped with water shutoff valves, the supply and return runouts must be connected together at each unit location (This will prevent the introduction of dirt into the unit, see Flushing with Water Shutoff Valve Equipped Systems illustration). The system should be filled at the water make-up connection with all air vents open. After filling, vents should be closed.

Flushing with Water Shutoff Valve Equipped Systems



The contractor should start the main circulator with the pressure reducing valve makeup open. Vents should be checked in sequence to bleed off any trapped air and to verify circulation through all components of the system.

As water circulates through the system, the contractor should check and repair any leaks found in the piping system. Drain(s) at the lowest point(s) in the system should be opened for initial flush and blowdown, making sure water fill valves are set at the same rate. Check the pressure gauge at the pump suction and manually adjust the make-up water valve to hold the same positive pressure both before and after opening the drain valves. Flushing should continue for at least two hours, or longer if required, until drain water is clean and clear.

The supplemental heater and/or circulator pump, if used, should be shut off. All drains and vents should be opened to completely drain the system. Short-circuited supply and return runouts should now be connected to the unit supply and return connections.

Refill the system with clean water. Test the system water for acidity and treat as required to leave the water slightly alkaline (pH 7.5 to 8.5). The specified percentage of antifreeze may also be added at this time. Use commercial grade antifreeze designed for HVAC systems only. Environol™ brand antifreeze is recommended.

Once the system has been filled with clean water and antifreeze (if used), precautions should be taken to protect the system from dirty water conditions. Dirty water will result in system-wide degradation of performance, and solids may clog valves, strainers, flow regulators, etc. Additionally, the heat exchanger may become clogged which reduces compressor service life and can cause premature unit failure.

In boiler/tower application, set the loop control panel set points to desired temperatures. Supply power to all motors and start the circulating pumps. After full flow has been established through all components including the heat rejector (regardless of season), air vented and loop temperatures stabilized, each of the units will be ready for check, test and start up and for air and water balancing.

Ground Source Loop System Checkout

Once piping is completed between the unit pumping system and ground loop, final purging and charging of the loop is needed. A high pressure pump is needed to achieve adequate flow velocity in the loop to purge air and dirt particles from the loop itself. Antifreeze solution is used in most areas to prevent freezing. Flush the system adequately to remove as much air as possible; then pressurize the loop to a static pressure of 40-50 PSI (summer) or 50-75 PSI (winter). This is normally adequate for good system operation. Loop static pressure may decrease soon after initial installation, due to pipe expansion and loop temperature change. Running the unit for at least 30 minutes after the system has been completely purged of air will allow for the “break-in” period. It may be necessary to adjust static loop pressure (by adding water) after the unit has run for the first time. Loop static pressure will also fluctuate with the seasons. Pressures will be higher in the winter months than during the cooling season. This fluctuation is normal and should be considered when charging the system initially.


Ensure the pump provides adequate flow through the unit by checking pressure drop across the heat exchanger. Usually 2.25-3.0 gpm of flow per ton of cooling capacity is recommended in earth loop applications.

Open Loop Ground Water Systems

Typical open loop piping is shown below. Always maintain water pressure in the heat exchanger by placing water control valves at the outlet of the unit to prevent mineral precipitation. Use a closed, bladder-type expansion tank to minimize mineral formation due to air exposure. Insure proper water flow through the unit by checking pressure drop across the heat exchanger and comparing it to the figures in unit capacity data tables in the specification catalog. 1.5-2 gpm of flow per ton of cooling capacity is recommended in open loop applications. Due to only minor differences in flow rate from low to high, only one solenoid valve should be used. The valve should be sized for full flow.

Discharge water from the unit is not contaminated in any manner and can be disposed of in various ways, depending on local codes, i.e. recharge well, storm sewer, drain field, adjacent stream or pond, etc. Most local codes forbid the use of sanitary sewer for disposal. Consult your local building and zoning departments to assure compliance in your area.

Open System - Groundwater Application



Freeze Detection

For Aurora Base Control, set SW2-1, FP1, on the printed circuit board for applications using a closed loop antifreeze solution to 15°F [-9.4°C]. On applications using an open loop/ground water system (or closed loop no antifreeze), set this dip switch to 30°F [-1.1°C], the factory default setting. (Refer to the Dip Switch Field Selection table).

Electrical Connections


General

Be sure the available power is the same voltage and phase as that shown on the unit serial plate. Line and low voltage wiring must be done in accordance with local codes or the National Electric Code, whichever is applicable.

208 Volt Operation

All 208/230 volt units are factory wired for 230 volt operation. For 208 volt operation, the red and blue transformer wires must be switched on terminal strip PS.

Aurora Base Control Box



Electrical Data

ECM Motor

Model	Rated Voltage	Voltage Min/Max	Compressor			Blower Motor FLA	Total Unit FLA	Min Circ Amp	Max Fuse/HACR Breaker
			MCC**	RLA	LRA*				
120	208-230/60/3	187/253	56.0	33.1	60.0	9.2	42.3	50.6	80
	460/60/3	414/506	30.0	17.7	35.0	6.8	24.5	28.9	45
180	208-230/60/3	187/253	84.0	49.6	100.0	9.2	58.8	71.2	110
	460/60/3	414/506	60.0	35.5	60.0	6.8	47.1	56.7	80

HACR circuit breaker in USA only

* - Based on AC input current protection to compressor drive.

** Max Continuous Input Current

8/26/19

Blower Performance Data

MODEL 12U

Fan Speed	Fan RPM	Airflow [scfm] at External Static Pressure [in. wg.]																				
		0.0	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1.0	1.1	1.2	1.3	1.4	1.5	1.6	1.7	1.8	1.9	2.0
1	600	1526	1349	1166	978	786	588															
2	700	1835	1711	1566	1400	1214	1008	781														
3	800	2145	2030	1895	1740	1564	1368	1151	934	718	501											
4	900	2454	2341	2214	2075	1923	1758	1580	1389	1198	1007	817	626									
5	1000	3008	2903	2791	2670	2542	2405	2260	2107	1946	1777	1607	1438	1269	1100	930	761					
6	1100	3323	3229	3129	3022	2909	2788	2662	2528	2388	2241	2087	2007	1926	1846	1766	1685	1605				
7	1250	3773	3684	3594	3502	3408	3311	3210	3106	2997	2882	2762	2636	2737	2613	2490	2366	2242	2119			
8	1400	4270	4180	4093	4007	3921	3835	3748	3658	3566	3471	3370	3265	3153	3034	2923	2812	2701	2590	2479		
9	1500	4582	4499	4419	4342	4265	4189	4112	4033	3951	3865	3773	3674	3569	3454	3330	3206	3082	2957	2833		
10	1600	4877	4801	4737	4673	4604	4528	4446	4361	4277	4198	4123	4050	3972	3875	3737	3530	3322	3114	2907	2699	2492
11	1700	5200	5121	5058	5000	4939	4872	4799	4722	4644	4567	4495	4427	4362	4294	4213	4102	3942	3781	3620	3350	3080
12	1800	5531	5462	5393	5318	5243	5152	5061	4981	4901	4823	4745	4680	4615	4538	4460	4374	4288	4045	3801	3558	3314

Fan selection is accomplished through the Aurora Controls and allows four online selections of continuous fan (G), stage 1 (Lo), stage 2 (Hi), and with electric heat (AUX). 11/16/17

Continuous Fan (G) can be set at any airflow.

Stage 1 (Lo) setting can be located anywhere other than BOLD highlighted points.

Stage 2 (Hi) setting should be located in shaded portion.

Elect heat Airflow (AUX) airflow setting should be configured for the minimum airflow needed to support the heater. Please consult heater manual.

Factory settings for UV*120 are continuous fan (G) speed 1, Minimum Load Stage 1(Lo)= Speed 3, Full Load Stage 2 (Hi) = Speed 8 and with Electric Heat Operation (AUX) = Speed 11.

Model 180

Fan Speed	Fan RPM	Airflow [cfm] at External Static Pressure [in. wg.]																				
		0.0	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1.0	1.1	1.2	1.3	1.4	1.5	1.6	1.7	1.8	1.9	2.0
1	900	2454	2341	2214	2075	1923	1758	1580	1389													
2	1000	2978	2881	2773	2669	2531	2407	2253	2087	1908	1679	1432										
3	1100	3288	3202	3121	3012	2908	2800	2679	2521	2385	2230	2050	1839	1617	1281							
4	1200	3587	3507	3433	3343	3249	3145	3037	2926	2791	2659	2490	2364	2218	2037	1825	1568					
5	1300	3901	3835	3761	3664	3594	3507	3418	3319	3202	3104	2969	2864	2735	2581	2417	2230	2098	1928			
6	1400	4244	4182	4120	4057	3974	3896	3809	3727	3629	3536	3455	3326	3224	3110	2983	2833	2718	2581	2440	2293	
7	1550	4812	4738	4664	4587	4504	4438	4372	4291	4226	4134	4046	3962	3870	3780	3707	3579	3501	3404	3305	3204	3101
8	1700	5329	5262	5195	5139	5082	5020	4958	4895	4831	4752	4673	4601	4529	4455	4380	4294	4222	4145	4068	3990	3911
9	1800	5666	5607	5548	5481	5414	5353	5291	5221	5151	5086	5020	4953	4886	4811	4735	4671	4596	4523	4450	4375	4300
10	1900	6018	5957	5895	5833	5770	5712	5654	5589	5524	5463	5402	5340	5278	5208	5138	5047	4976	4907	4837	4766	4695
11	2000	6350	6287	6224	6165	6105	6045	5985	5923	5861	5799	5736	5672	5607	5541	5475	5414	5347	5281	5214	5148	5080
12	2160	6862	6805	6748	6698	6647	6588	6529	6477	6425	6364	6303	6249	6194	6131	6068	5987	5920	5854	5787	5721	5653

Fan selection is accomplished through the Aurora Controls and allows four online selections of continuous fan (G), stage 1 (Lo), stage 2 (Hi), and with electric heat (AUX). 11/12/17

Continuous Fan (G) can be set at any airflow.

Stage 1 (Lo) setting can be located anywhere other than BOLD highlighted points.

Stage 2 (Hi) setting should be located in shaded portion.

Elect heat Airflow (AUX) airflow setting should be configured for the minimum airflow needed to support the heater. Please consult heater manual.

Factory settings for UV*180 are continuous fan (G) speed 1, Part Load Stage 1(Lo)= Speed 3, Full Load Stage 2 (Hi) = Speed 10 and with Electric Heat Operation (AUX) = Speed 11.

Blower Performance Data cont.

Setting Blower Speed - Variable Speed ECM


The ABC board's Yellow Config LED will flash the current ECM blower speed selections for G, low, and high continuously with a short pause in between. The speeds can also be confirmed with the AID Tool under the Setup/ECM Setup screen. The Aux will not be flashed but can be viewed in the AID Tool. The ECM blower motor speeds can be field adjusted with or without using an AID Tool.

Variable speed ECM Setup without an AID Tool

The blower speeds for G only, Low (Y1), and High (Y2/Aux) can be adjusted directly at the Aurora ABC board which utilizes the push button (SW1) on the ABC board. This procedure is outlined in the ECM Configuration Mode portion of the Aurora 'Base' Control System section. The Aux cannot be set manually without an AID Tool.

Variable speed ECM Setup with an AID Tool


A much easier method utilizes the AID Tool to change the airflow using the procedure below. First navigate to the Setup screen and then select ECM Setup. This screen displays the current ECM settings. It allows the technician to enter the setup screens to change the ECM settings.



Change the highlighted item using the ◀ and ▶ buttons and then press the ■ button to select the item.


Selecting YES will enter ECM speed setup, while selecting NO will return to the previous screen.

ECM Speed Setup - These screens allow the technician to select the G, low, high, and auxiliary heat blower speed for the ECM blower motor. Change the highlighted item using the ▲ and ▼ buttons. Press the ■ button to select the speed.



After the auxiliary heat speed setting is selected the AID Tool will automatically transfer back to the ECM Setup screen.

Cooling Airflow Setup - These screens allow the technician to select -15%, -10%, -5%, None or +5% change from the heating airflow. Change the adjustment percentage using the ▲ and ▼ buttons. Press the ■ button to save the change.



Setting Blower Speed - Variable Speed ECM - UPC Controls

Variable speed ECM blower motors have 12 selectable speeds and are factory set for optimum performance. When applicable, the speed settings may also be adjusted through the Building Automation System (BAS).



CAUTION: Disconnect all power before performing this operation.

Wiring Schematics


Commercial Variable Speed - 120-180 Series

AXB Accessory 2 DIP Settings		
SW1-4	SW1-5	DESCRIPTION
ON	ON	Cycles with Blower
OFF	ON	Cycles with CC first stage compressor or compressor spd 1-12
ON	OFF	Cycles with CC2 second stage of compressor or comp spd 7-12
OFF	OFF	Cycles with DH from ABC board

ABC SW2 Accessory Relay		
DESCRIPTION	SW2-4	SW2-5
Cycle with Blower	ON	ON
Cycle with Compressor	OFF	OFF
Water Valve Slow Opening	ON	OFF
Cycle with Comm. T-stat Hum Cmd	OFF	ON


Notes:

- 1- Optional, factory installed modulating water valve.
- 2- Optional, factory installed modulating reheat.
- 3- Optional, factory installed UPC.
- 4- Optional, factory installed water side economizer.



Wiring Schematics cont.

Commercial Variable Speed



ZS Sensor Information

Zone Sensors can be wired in daisy chain as show or in a star or hybrid configuration. Maximum of 5 sensors per UPC. Maximum allowable load 210mA. See the UPC install manual for possible sensor combinations.

DIP Switch Value	Value
1	0
2	1
4	2
8	3

Each ZS sensor must have a unique address, but the addresses do not need to be sequential. Use the DIP switches on the back of the ZS sensor to set an address from 0 to 4. (0 is the factory default.) Each DIP switch has the value shown in the figure to the left. Turn on as many DIP switches as you need so that their total value equals the address.

Notes


1. Use DIP Switches 5 – 8 to change communication protocol and DIP switches 1 – 2 to change BACnet baud rate

Legend


- Factory Low Voltage Wiring
- - - Field Low Voltage Wiring
- 12345678 RJ45 Connector

Wiring Schematics cont.

Commercial Variable Speed





Aurora LED Flash Codes		
Slow Flash	1 second on and 1 second off	
Fast Flash	100 milliseconds on and 100 milliseconds off	
Flash Code	100 milliseconds on and 400 milliseconds off with a 2 second pause before repeating	
Fault LED (LED 1, Red)		Random Start Delay (Alternating Colors)
Normal Mode	OFF	Status LED (LED 1, Green)
Input Fault Lockout	Flash Code 1	Configuration LED (LED 2, Yellow)
High Pressure Lockout	Flash Code 2	Fault LED (LED 3, Red)
Low Pressure Lockout	Flash Code 3	Configuration LED (LED 2, Yellow)
Freeze Detection - FP2	Flash Code 4	No Software Override
Freeze Detection - FP1	Flash Code 5	DIP Switch Override
Reserved	Flash Code 6	Status LED (LED 3, Green)
Condensate Overflow Lockout	Flash Code 7	Normal Mode
Over/Under Voltage Shutdown	Flash Code 8	Control is Non - Functional
Future Use	Flash Code 9	Test Mode
Compressor Monitoring	Flash Code 10	Lockout Active
Fault: FP1 and FP2 Sensor Error	Flash Code 11	Dehumidification Mode
Future Use	Flash Code 12	Future Use
Non-Critical AXB Sensor Error	Flash Code 13	Future Use
Critical AXB Sensor Error	Flash Code 14	Load Shed
Alarm - Hot Water	Flash Code 15	ESD
Fault Variable Speed Pump	Flash Code 16	Future Use
Future Use	Flash Code 17	Fault LED (LED 1, Red) Cont.
Non-Critical Communication Error	Flash Code 18	Safe Mode - Ambient Temperature Sensor
Fault - Critical Communication Error	Flash Code 19	Fault - Discharge Temperature Sensor
Alarm - Low Loop Pressure	Flash Code 21	Fault - Suction Pressure Sensor
Fault - Communication ECM Fan Motor Error	Flash Code 22	Fault - Condensing Pressure Sensor
Alarm - Home Automation 1	Flash Code 23	Fault - Low Supply Voltage
Alarm - Home Automation 2	Flash Code 24	Fault - Compressor Out of Envelope
Fault - EEV Error	Flash Code 25	Fault - Over Current
Derate - Drive Temperature	Flash Code 41	Fault - Over/Under Voltage
Derate - High Discharge Temperature	Flash Code 42	Fault - High Drive Temperature
Derate - Low Suction Temperature	Flash Code 43	Fault - Drive Internal Error MOC/AOC
Derate - Low Condensing Pressure	Flash Code 44	Fault - Multiple Safe Modes
Derate - High Condensing Pressure	Flash Code 45	Fault - Loss of Charge
Derate - Outer Power Limit	Flash Code 46	Safe Mode - Suction Temperature Sensor
Safe Mode - EEV (Indoor) Communication	Flash Code 47	Safe Mode - LAT Temperature Sensor
Safe Mode - EEV (Outdoor) Communication	Flash Code 48	Safe Mode - Max Operating Pressure



Wiring Schematics cont.

Commercial Variable Speed



AXB Accessory 2 DIP Settings		
SW1-4	SW1-5	DESCRIPTION
ON	ON	Cycles with Blower
OFF	ON	Cycles with CC first stage compressor or compressor spd 1-12
ON	OFF	Cycles with CC2 second stage of compressor or comp spd 7-12
OFF	OFF	Cycles with DH from ABC board

ABC SW2 Accessory Relay		
DESCRIPTION	SW2-4	SW2-5
Cycle with Blower	ON	ON
Cycle with Compressor	OFF	OFF
Water Valve Slow Opening	ON	OFF
Cycle with Comm. T-stat Hum Cmd	OFF	ON

Legend

<p>— Factory Low Voltage Wiring</p> <p>— Factory Line Voltage Wiring</p> <p>— Field Line Voltage Wiring</p> <p>— Optional Block</p> <p>— DC Voltage PCB Traces</p> <p>— Field Zone Sensor Wiring</p> <p>— Internal Junction</p> <p>— Quick Connect Terminal</p> <p>[L1] Field Wiring Lug</p> <p>⊥ Ground</p> <p>— — Relay Contacts - N.O., N.C.</p> <p>⊕ Capacitor</p> <p>⊖ Fuse</p>	<p>⊕ Thermistor</p> <p>⊖ Relay Coil</p> <p>⊕ Switch - Condensate Overflow</p> <p>⊖ Switch - High pressure</p> <p>⊕ Switch - Low pressure</p> <p>[+ -] Polarized connector</p> <p>⊕ Light Emitting Diode - Green</p> <p>⊖ Light Emitting Diode - Yellow</p> <p>⊕ Light Emitting Diode - Red</p>
---	--





CC - Compressor Contactor
 CO - Condensate Over/low Sensor
 ES - Emergency Shutdown
 HP - High Pressure Switch
 LP - Low Pressure Switch
 FD - Freeze Detect on Sensor
 F1 - Fuse

SW1 - Push button
 SW2 - DIP package 8 position
 RS - Blower Relay
 RV - Reversing Valve Coil
 PGM - Phase Guard Monitor
 RH - Reheat Valve Coil

Controls - Aurora Advanced Variable Speed Control

Aurora Controls

The Aurora Control System is a complete commercial comfort system that can bring all aspects of the HVAC system into one cohesive module network. The Aurora System is available in two configurations: Aurora Base Control and Aurora Advanced Control both with optional Aurora UPC for DDC applications.

Control	General Description	Application	Display/Interface	Protocol
<p>Aurora Base Control</p> 	<p>The ABC microprocessor provides all the features necessary to operate today's standard WSHPs that utilize dual capacity compressors and variable speed ECM/5 speed ECM blower motors. This control can communicate to a handheld diagnostic tool to help the installing contractor or service technician with equipment setup and service. By utilizing Modbus RTU communication protocol, the ABC board can communicate with additional devices on the Aurora network</p>	<p>Used for residential and commercial applications that use single or dual capacity compressors with PSC, 5-speed ECM, or variable speed ECM blower motors. This base control can also communicate to the AID Tool to display faults, inputs/outputs, and software revision. Commercial features such as slow opening water valve and random start are also capable with the ABC board.</p>	<p>Optional AID tool can be used for field service.</p>	<p>Standalone</p>
<p>Aurora Advanced Control (ABC/AXB)</p> 	<p>Aurora Advanced Control adds the Aurora AXB expansion board and provides added I/O and standard features such as refrigerant, performance or energy monitoring.</p>	<ul style="list-style-type: none"> • Refrigeration Monitoring - provides Suction and discharge pressure, Suction, liquid line temps and superheat and subcooling. • Performance Monitoring - provides entering and leaving loop water temperatures, loop flow rate as well as heat of extraction or rejection rate into the loop. • Energy Monitoring - provides real-time power measurement (Watt) of compressor, fan, auxiliary heat and zone pump. • Plus many more I/O options 	<p>Optional AID tool can be used for field service.</p>	<p>Standalone</p>
<p>Aurora Base/Aurora Advanced Control w/UPC BACnet or N2</p> 	<p>The Aurora Unitary Protocol Converter (UPC) is an integrated solution and communicates directly with the Aurora Heat Pump Controls and allows access/control of a variety of internal Aurora heat pump operations such as sensors, relay operation, faults and other information. In turn, the UPC then converts internal Aurora Modbus protocol to BACnet MS/TP, or N2 protocols and communicates to the BAS system. This provides the great benefit of complete control integration and a myriad of information available to the BAS from the heat pump control. Plus it also allows individual unit configuration such as ECM fan speeds or freeze protection setting directly over the BAS without the need for access to the actual heat pump.</p>	<p>The Aurora UPC is implemented with the Aurora heat pump control into our latest water source heat pumps. All Internal Aurora points are accessible to the UPC via firmware providing an integrated solution. All zone temperatures and zone sensors are connected to the UPC on an RNet bus, simplifying hook up at the unit. RNet sensors can include a combination of zone temperature and humidity, CO2, and VOC sensors. The UPC includes built-in support for a custom configurable keypad/display unit.</p>	<p>Optional Aurora Touch Interface</p>	<p>BACnet MS/TP or N2 Open (DIP selectable)</p>
<p>Aurora Base/Aurora Advanced Control w/UPC LonWorks</p> 	<p>The Aurora Unitary Protocol Converter (UPC) is an integrated solution and communicates directly with the Aurora Heat Pump Controls and allows access/control of a variety of internal Aurora heat pump operations such as sensors, relay operation, faults and other information. In turn, the UPC then converts internal Aurora Modbus protocol to LONWorks protocol and communicates to the BAS system.</p>	<p>The Aurora UPC is implemented with the heat pump control into our latest water source heat pumps. All Internal Aurora points are accessible to the UPC via firmware providing an integrated solution. All zone temperatures and zone sensors are connected to the UPC on an RNet bus, simplifying hook up at the unit. RNet sensors can include a combination of zone temperature and humidity, CO2, and VOC sensors. The UPC includes built-in support for a custom configurable keypad/display unit.</p>	<p>Optional Aurora Touch Interface</p>	<p>LonWorks</p>

Controls - Aurora Advanced Variable Speed Control cont.

Aurora 'Advanced Variable Speed' Control



NOTE: Refer to the Aurora Base Control Application and Troubleshooting Guide and the Instruction Guide: Aurora Interface and Diagnostics (AID) Tool for additional information.


The Aurora Advanced VS Control provides all baseline operation of 7 faults (HP, LP, and LOC, coax freeze protection, air coil freeze protection, over/under voltage, and condensate overflow), as well as compressor speed, fan speed, and lockout management through a single Aurora Base Control board (ABC). The control features all heat pump operational timings, configurations, sensors, and fault history that can be viewed using the AID tool.

In addition to the baseline operation, Aurora Advanced VS Control adds the extended I/O of the Aurora Expansion Board (AXB) to the mix. This extended I/O includes energy monitoring as a standard feature where current transducers measure current and power of the fan motor. Compressor power is monitored by the compressor drive and communicated to the Aurora Controls. Refrigerant monitoring is standard on all variable speed models and reports refrigerant temperatures and pressures in order to calculate superheat and subcooling. The optional performance monitoring kit includes entering and leaving water temperatures along with source water flow rate via a vortex shedding flow meter.

The Aurora Advanced VS Control uses an internal PID control and communicates via Modbus to the variable speed compressor drive and electronic expansion valve to provide capacity and superheat control of the system. All faults codes from the compressor drive are mapped to the Aurora system which are then displayed through the AID tool.

Optional Aurora UPC

When coupled with the optional Aurora UPC, the system can communicate all of these same heat pump parameters to the BAS as network points using either BACnet, N2 or Lon protocols. This means that not only are heat pump parameters visible by the BAS, many configuration settings, such as airflow and freeze detection settings, can also be changed from the BAS system saving commissioning costs. This provides both cost advantages and features not typically found on WSHP controls. All configuration, sensor and servicing can be accessed thru the AuroraTouch color service tool. This integration allows heat pump monitoring sensors, status and service diagnosis faults to be communicated thru the DDC direct to the building automation system (BAS), giving building supervisors detailed and accurate information on every piece of equipment without removing an access panel!



Control Features

Software ABC Standard Version 3.0 Variable Speed Compressors

Only Copeland EV2 Variable Speed compressors can be operated.

Aurora Advanced VS Control Features

NOTE: Refer to the Aurora Advanced VS Control Application and Troubleshooting Guide and the Instruction Guide: Aurora Interface and Diagnostics (AID) Tool for additional information.

Control Features

Software ABC VS Version 3.0 Variable Capacity Compressors

- Random start at power up
- Anti-short cycle protection
- High and low pressure cutouts
- Loss of charge
- Water coil freeze detection
- Air coil freeze detection
- Over/under voltage protection
- Condensate overflow sensor
- Load shed
- Dehumidification (where applicable)
- Emergency shutdown
- Diagnostic LED
- Test mode push button switch
- Two auxiliary electric heat outputs
- Alarm output
- Accessory output with N.O. and N.C.
- Modbus communication

Controls - Aurora Advanced Variable Speed Control cont.

Variable Speed ECM Blower Motor

A variable speed ECM blower motor is driven directly using the onboard PWM output. Multiple blower speeds are available based upon requirements of the compressor and electric heat. The blower speeds can be changed either by the variable speed ECM manual configurations mode method or by using the Aurora AID Tool directly, or with the Aurora/UPC via BAS.

Advanced Hot Water Generator Control (Domestic Hot Water Option)

An AID Tool selectable temperature limit and microprocessor control of the process is featured. This will maximize hot water generation and prevent undesirable energy use. An alert will occur when the hot water input temperature is at or above the set point (130°F default) for 30 continuous seconds. This alert will appear as an E15 on the AID Tool and the hot water pump de-energizes. Hot water pump operations resume on the next compressor cycle or after 15 minutes of continuous compressor operation during the current thermostat demand cycle. Since compressor hot gas temperature is dependent on loop temperature in cooling mode, loop temperatures may be too low to allow proper heating of water. The control will monitor water and refrigerant temperatures to determine if conditions are satisfactory for heating water.

VS Drive and Envelope Control

The VS drive operates the compressor between 25 and 100% capacity. The VS drive communicates any out of refrigerant envelope conditions to the Aurora and will attempt to adjust the compressor speed to keep within the envelope. These conditions are measured using discharge temperature and current sensors of the drive.

Electronic Expansion Valve (EEV)

The electronic expansion valve (EEV) is operated by the AXB board and is set to maintain optimal superheat setting for maximum efficiency. All operation parameters are communicated to the Aurora system.

Variable Speed Pump

This input and output are provided to drive and monitor a variable speed pump. The VS pump output is a PWM signal to drive the variable speed pump. The minimum and maximum level are set using the AID Tool. 50% and 100% are the default settings respectively. The VS data input allows a separate PWM signal to return from the pump giving fault and performance information. Fault received from the variable speed pump will be displayed as E16.

Modulating Water Valve

This output is provided to drive a modulating water valve. Through advanced design the 0-10VDC valve can be driven directly from the VS Pump output. The minimum and maximum level are set in the same way as the VS pump using the AID Tool. 50% and 100% are the default settings respectively.

Loop Pump Linking

This input and output are provided so that two units can be linked together with a common flow center. When either unit has a call for loop outputs, both unit's loop pump relays and variable speed pumps are energized. The flow center then can simply be wired to either unit. The output from one unit should be routed to the input of the other. If daisy chained, up to 16 heat pumps can be wired and linked together in this fashion.

Advanced Communication Ports

AXB Communication ports P6 and P8 will provide future expansion via dedicated protocols. These are for future use.

Monitoring Sensors

Energy Monitoring

Energy Monitoring is standard in all models and includes two current transducers (blower and electric heat) so that the complete power usage of the heat pump can be measured. Compressor power is measured by the variable speed drive. The AID Tool provides configuration detail for the type of blower motor and a line voltage calibration procedure to improve the accuracy. This information can be displayed on the AID Tool, selected communicating thermostats or communicated thru the optional Aurora UPC BAS communications board.

Refrigerant Monitoring

Refrigerant Monitoring is standard in all models includes two pressure transducers, and three temperature sensors, heating liquid line, suction temperature and existing cooling liquid line (FP1). These sensors allow the measurement of discharge and suction pressures, suction and liquid line temperatures as well as superheat and subcooling. This information can be displayed on the AID Tool or communicated thru the optional Aurora UPC BAS communications board.

Performance Monitoring (Requires Flow Meter)

The optional Performance Monitoring includes three temperature sensors, entering and leaving water, leaving air temperature and a water flow rate sensor. Heat of extraction and rejection will be calculated. This requires configuration using the AID Tool for selection of water or antifreeze and is displayed on the AID tool or communicated thru the optional Aurora UPC BAS communications board.

Controls - Aurora Advanced Variable Speed Control cont.

Special Modes and Applications

Communicating Digital Thermostats

The Aurora Advanced VS controls system also requires either the monochromatic or color touch screen graphic display thermostats for user interface. These displays not only feature easy to use graphical interface but display alerts and faults in plain English.

Dehumidification - Active

Active dehumidification will only activate during cooling operation and is based upon the humidity setpoint of the thermostat being at least 5% below the actual relative humidity and being within the temperature parameters described here. The green status LED will flash code 2 when active. The unit can operate a maximum of 2°F below the cooling setpoint. The compressor will ramp up and airflow will begin at a low level. Airflow is then reduced periodically until air coil temperature setpoint is reached. If coil temperature continues to drop, the airflow is increased until air coil setpoint is maintained. After 20 minutes of operation in the Active Dehumidification mode, normal cooling operation will resume for 5 minutes. This cycle continues until the dehumidification setpoint is reached, room temperature is more than 2°F below cooling setpoint, or more than 1°F above cooling setpoint (normal cooling takes over). In IntelliZone2 systems, active dehumidification is only enabled when system is operating on compressor speeds 4 or lower. Once active dehumidification is activated the main zone and any other active cooling zone will remain open.

Field Hardware Selectable Options

ABC Field Selectable Options via Button (SW1)

Test/Configuration Button (See SW1 Operation Table)

Test Mode

The control is placed in the test mode by holding the push button switch on the ABC SW1 for 2 - 5 seconds. In test mode most of the control timings will be shortened by a factor of sixteen (16). LED3 (green) will flash at 1 second on and 1 second off. Additionally, when entering test mode LED1 (red) will flash the last lockout one time. Test mode will automatically time out after 30 minutes. Test mode can be exited by pressing and holding the SW1 button for 2 to 5 seconds or by cycling the power. **NOTE:** Test mode will automatically be exited after 30 minutes.

Variable Speed ECM Configuration Mode

The control is placed in the variable speed ECM configuration mode by holding the push-button switch SW1 for 5 to 10 seconds, the high, low, and G variable speed ECM speeds can be selected by following the LED display lights. LED2 (yellow) will fast flash when entering the variable speed ECM configuration. When setting G speed LED3 (green) will be continuously lit, for low speed LED1 (red) will be continuously lit, and for high speed both LED3 (green)

and LED1 (red) will be continuously lit. During the variable speed ECM configuration mode LED2 (yellow) will flash each of the 12 possible blower speeds 3 times. When the desired speed is flashed press SW1, LED2 will fast flash until SW1 is released. G speed has now been selected. Next select low speed, and high speed blower selections following the same process above. After third selection has been made, the control will exit the variable speed ECM configuration mode. Aux blower speed will remain at default or current setting and requires the AID Tool for adjustment.

Reset Configuration Mode

The control is placed in reset configuration mode by holding the push button switch SW1 on the ABC for 50 to 60 seconds. This will reset all configuration settings and the EEPROM back to the factory default settings. LED3 (green) will turn off when entering reset configuration mode. Once LED3 (green) turns off, release SW1 and the control will reset.

ABC DIP Switch (SW2)

- SW2-1** FP1 Selection - Low water coil temperature limit setting for freeze detection. On = 30°F; Off = 15°F.
- SW2-2** FP2 Selection - Low air coil temperature limit setting for freeze detection. On = 30°F; Off = Not Used
- SW2-3** RV - O/B - thermostat type. Heat pump thermostats with "O" output in cooling or "B" output in Heating can be selected. On = O; Off = B.
- SW2-4** Access Relay Operation (P2) and 2-5

Access Relay Operation	SW2-4	SW2-5
Cycle with Blower	ON	ON
Cycle with Compressor	OFF	OFF
Water Valve Slow Opening	ON	OFF
Cycle with Comm. T-stat Hum Cmd	OFF	ON

- SW2-6** CC Operation - selection of single or dual capacity compressor. On = Single Stage; Off = Dual Capacity **NOTE:** SW2-6 is not applicable to the 7 Series
- SW2-7** Lockout and Alarm Outputs (P2) - selection of a continuous or pulsed output for both the LO and ALM Outputs. On = Continuous; Off = Pulsed **NOTE:** SW2-7 is not applicable to the 7 Series
- SW2-8** Future Use

Alarm Jumper Clip Selection

From the factory, ALM is connected to 24 VAC via JW2. By cutting JW2, ALM becomes a dry contact connected to ALG.

Controls - Aurora Advanced Variable Speed Control cont.

Variable Speed ECM Blower Speeds

The blower speeds can be changed either by using the variable speed ECM manual configurations mode method or by using the Aurora AID Tool directly (see Instruction Guide: Aurora Interface and Diagnostics (AID) Tool topic).

AXB DIP Switch (SW1)

DIP 1 - ID: This is the AXB ModBus ID and should always read On.

DIP 2 & 3 - Future Use

DIP 4 & 5 - Accessory Relay2: A second, DIP configurable, accessory relay is provided that can be cycled with the compressor 1 or 2, blower, or the Dehumidifier (DH) input. This is to complement the Accessory 1 Relay on the ABC board.

Position	DIP 4	DIP 5	Description
1	ON	ON	Cycles with blower or ECM (or G)
2	OFF	ON	Cycles with CC1 first stage of compressor or compressor spd 1-12
3	ON	OFF	Cycles with CC2 second stage of compressor or compressor spd 7-12
4	OFF	OFF	Cycles with DH input from ABC board

Field Selectable Options via Software (Selectable via the Aurora AID Tool)

Many options are field selectable and configurable in Aurora software via the AID Tool. Consult the installation manual or Aurora documentation for further details.

Basic Aurora Safety Features

The following safety features are provided to protect the compressor, heat exchangers, wiring and other components from damage caused by operation outside of design conditions.

Fuse - a 3 amp automotive type plug-in fuse provides protection against short circuit or overload conditions. Anti-Short Cycle Protection - 4 minute anti-short cycle protection for the compressor.

Random Start - 5 to 80 second random start upon power up.

Fault Retry - in the fault condition, the control will stage off the outputs and then “try again” to satisfy the thermostat VS call. Once the thermostat input calls are satisfied, the control will continue on as if no fault occurred. If 3 consecutive faults occur without satisfying the thermostat VS call, then the control will go to Lockout mode.

Lockout - when locked out, the blower will operate continuously in “G” blower speed setting. The Alarm output (ALM) and Lockout output (L) will be turned on. The fault type identification display LED1 (Red) shall flash the fault code. To reset lockout conditions with SW2-8 On, the demand call must be removed for at least 30 seconds. To reset lockout conditions with SW2-8 Off, the demand call must be removed for at least 30 seconds. Lockout may also be reset by turning power off for at least 30 seconds or by enabling the emergency shutdown input for at least 30 seconds.



CAUTION: Frequent cycling of power to the drive can damage the drive! Wait at least 5 minutes between cycles (connecting and disconnecting power to the drive).

Lockout With Emergency Heat - if the control is locked out in the heating mode, and a call for emergency heat is received, the control will operate in the emergency heat mode while the compressor is locked out. The first emergency heat output will be energized 10 seconds after the W input is received, and the blower will shift to high speed. If the control remains locked out, and the W input is present, additional stage of emergency heat will stage on after 2 minutes. When the W input is removed, all of the emergency heat outputs will turn off, and the variable speed ECM blower will shift to low speed.

High Pressure - fault is recognized when the Normally Closed High Pressure Switch, P4-9/10 opens, no matter how momentarily. The High Pressure Switch is electrically in series with the Compressor Contactor and serves as a hardwired limit switch if an overpressure condition should occur.

Low Pressure - fault is recognized when the Normally Closed Low Pressure Switch, P4-7/8 is continuously open for 30 seconds. Closure of the LPS any time during the 30 second recognition time restarts the 30 second continuous open requirement. A continuously open LPS shall not be recognized during the 2 minute startup bypass time.

Loss of Charge - fault is recognized when the Normally Closed Low Pressure Switch, P4-7/8 is open prior to the compressor starting.

Condensate Overflow - fault is recognized when the impedance between this line and 24 VAC common or chassis ground drops below 100K ohms for 30 seconds continuously.

Controls - Aurora Advanced Variable Speed Control cont.

Freeze Detection-(Coax) - set points shall be either 30°F or 15°F. When the thermistor temperature drops below the selected set point, the control shall begin counting down the 30 seconds delay. If the thermistor value rises above the selected set point, then the count should reset. The resistance value must remain below the selected set point for the entire length of the appropriate delay to be recognized as a fault. This fault will be ignored for the initial 2 minutes of the compressor run time.

Freeze Detection-(Air Coil) - Air Coil Freeze Detection will use the FP2 input to protect against ice formation on the air coil. The FP2 input will operate exactly like FP1 except that the set point is 30 degrees and is not field adjustable.

Over/Under Voltage Shutdown - An over/under voltage condition exists when the control voltage is outside the range of 18 VAC to 30 VAC. If the over/under voltage shutdown lasts for 15 minutes, the lockout and alarm relay will be energized. Over/under voltage shutdown is self-resetting in that if the voltage comes back within range of 18 VAC to 30 VAC for at least 0.5 seconds, then normal operation is restored.

Other Lockouts and Alarms

Several other lockouts and alarms are shown in the Status LED1 (LED1, Red) table with the associated codes visible on the thermostat, ABC Fault LED, and in text in the AID Tool.

Operation Description

Power Up - The unit will not operate until all the inputs and safety controls are checked for normal conditions. The unit has a 5 to 80 second random start delay at power up. Then the compressor has a 4 minute anti-short cycle delay after the random start delay.

Standby - In standby mode the compressor, pump, and blower motor are not active. The RV may be active. The blower and compressor will be off.

Heating Operation - The unit will operate based upon demand as calculated by the room setpoint algorithm. The resulting compressor speed (1-12) will also select an appropriate blower speed for the selected compressor speed. Aux Heat will not be available (on IntelliZone2 Aux Heat is available on compressor speeds 10-12) until after the 12th compressor speed has been operational and still is not satisfying the thermostat, then auxiliary electric heat will be activated.

Emergency Heat (W) - The blower will be started on G speed, 10 seconds later the first stage of electric heat will be turned on. 5 seconds after the first stage of electric heat is energized the blower will shift to Aux speed. If the emergency heat demand is not satisfied after 2 minutes the second electric heat stage will be energized.

Cooling Operation - The unit will operate based upon demand as calculated by the room setpoint algorithm. The resulting compressor speed, speeds 1-12, will also select an appropriate blower speed. The blower mode will also have the cooling airflow adjustment applied. In all cooling operations, the reversing valve directly tracks the O input. Thus, anytime the O input is present, the reversing valve will be energized.

Controls - Aurora Advanced Variable Speed Control cont.

Blower (G) - The blower will start immediately upon receiving a thermostat G command. If there are no other commands from the thermostat the variable speed ECM will run on low speed until the G command is removed. Regardless of blower input (G) from the thermostat, the blower will remain on low speed for 30 seconds at the end of each heating, cooling, and emergency heat cycle.

Emergency Shutdown - Four (4) seconds after a valid ES input, P2-7 is present, all control outputs will be turned off and remain off until the emergency shutdown input is no longer present. The first time that the compressor is started after the control exits the emergency shutdown mode, there will be an anti-short cycle delay followed by a random start delay. Input must be tied to common to activate.

Continuous Blower Operation - The blower output will be energized any time the control has a G input present, unless the control has an emergency shutdown input present. The blower output will be turned off when G input is removed.

Load Shed - The LS input disables all outputs with the exception of the blower output. When the LS input has been cleared, the anti-short cycle timer and random start timer will be initiated. Input must be tied to common to activate.

Aurora Advanced VS Control LED Displays

These three LEDs display the status, configuration, and fault codes for the control. These can also be read in plain English via the Aurora AID Tool. See the LED tables for further explanation.

Aurora Interface and Diagnostics (AID) Tool

The Aurora Interface and Diagnostics (AID) Tool is a device that is a member of the Aurora network. The AID Tool is used to troubleshoot equipment which uses the Aurora control via Modbus RTU communication. The AID Tool provides diagnostics, fault management, variable speed ECM setup, and system configuration capabilities to the Aurora family of controls. An AID Tool is recommended, although not required, for variable speed ECM airflow settings. The AID Tool simply plugs into the exterior of the cabinet in the AID Tool port.



Status LED (LED3, Green)

Description of Operation	Fault LED, Green
Normal Mode	ON
Control is Non-functional	OFF
Test Mode	Slow Flash
Lockout Active	Fast Flash
Dehumidification Mode	Flash Code 2
Load Shed	Flash Code 5
Emergency Shutdown	Flash Code 6
On Peak Mode	Flash Code 7
Warning! VS Derated	Flash Code 8
Warning! VS SafeMode	Flash Code 9

Configuration LED (LED2, Yellow)

Description of Operation	Configuration LED, Yellow
No Software Overwritten	ECM Setting
DIP Switch Overwritten	Slow Flash
ECM Configuration Mode	Fast Flash
Reset Configuration Mode	OFF


Controls - Aurora Advanced Variable Speed Control cont.

ABC & XRB Basic Faults	Fault	Fault LED Code	Flash Code	Lockout	Reset/Remove	Fault Condition Summary	ABC Action	ABC Green Status LED	AID Tool	Display and History	I2Z and Stat Display
ABC & XRB Basic Faults	Normal - No Faults	Off	Off	-	-	-	-	-	-	-	-
	Fault-High Pressure	2	1	No	Auto	Total input error. Autoreset upon condition removal.	Code 1	Normal	Lockout	Lockout - E2 High Press	Lockout - E2 High Press
	Fault-Low Pressure	3	2	Yes	Hard or Soft	HP switch has tripped (<60 psi)	Code 2	Lockout	Lockout	Lockout - E3 Low Press	Lockout - E3 Low Press
	Fault-Freeze Detection FP1	4	3	Yes	Hard or Soft	Low Pressure Switch has tripped (<40 psi for 30 continuous sec.)	Code 3	Lockout	Lockout	Lockout - E4 Freeze Detection FP1	Lockout - E4 Freeze Detection FP1
	Fault-Freeze Detection FP2	5	4	Yes	Hard or Soft	Freeze protection sensor has tripped (<15 or 30 deF for 30 continuous sec.)	Code 4	Lockout	Lockout	Lockout - E5 Freeze Detection FP2	Lockout - E5 Freeze Detection FP2
	Fault-Loss of Charge	6	5	Yes	Hard or Soft	Low Pressure Switch open prior to compressor start (UPC Only)	Code 5	Lockout	Lockout	Lockout - E6	Lockout - E6
	Fault-Condensate Overflow	7	6	Yes	Hard or Soft	Condensate switch has shown continuity for 30 continuous sec.	Code 6	Lockout	Lockout	Lockout - E7 Condensate	Lockout - E7 Condensate
	Fault-Over/Under Voltage	8	7	No**	Auto	Instantaneous Voltage is out of range. - Controls shut down until resolved.	Code 8	Lockout	Lockout	Lockout - E8 Over/Under Voltage	Lockout - E8 Over/Under Voltage
	Fault-Compressor Monitor	10	8	Yes	Hard or Soft	Open Ckt. Run, Start or welded cont.	Code 10	Lockout	Lockout	Lockout - E10 Compress Monitor	Lockout - E10 Compress Monitor
	Fault-FPI & 2 Snsr Error	11	9	Yes	Hard or Soft	If FPI or 2 Snsr Err	Code 11	Lockout	Lockout	Lockout - E11 FPI/FP2 Sensor Error	Lockout - E11 FPI/FP2 Sensor Error
ABC & XRB Advanced Faults	Error-Refrig Perform	12	12	-	-	Not Used	Code 12	-	-	-	-
	Non-Critical AXB Snsr Err	13	13	Yes	Auto	Any Other Sensor Err	Code 13	Normal	Lockout	Alert - E13 Non-Critical AXB Sensor Error	Alert - E13 Non-Critical AXB Sensor Error
	Critical AXB Snsr Err	14	14	Yes	Hard or Soft	Sensor Err for EEV or HW	Code 14	Lockout	Lockout	Alert - E14 Critical AXB Sensor Error	Alert - E14 Critical AXB Sensor Error
	Alarm-Hot Water	15	15	No	Auto	HW over limit or logic lockout. HW pump deactivated.	Code 15	Normal	Normal	Alert - E15 Hot Water Temp Limit	Alert - E15 Hot Water Temp Limit
	Fault-Vapour Pump	17	17	No	Auto	Alert is read from P/PI feedback	Code 17	Normal	Normal	Alert - E17 Vap Pump Err	Alert - E17 Vap Pump Err
	Non-Critical Com Error	18	18	No	Auto	Alert is read from P/PI feedback (Not Implemented)	Code 18	Normal	Normal	Alert - E18 Non-Critical Communication Error	Alert - E18 Non-Critical Communication Error
	Fault-Critical Com Err	19	19	No	Auto	Any non-critical com error	Code 19	Normal	Normal	Alert - E19 Critical Communication Error	Alert - E19 Critical Communication Error
	UPC Communication Loss	20	-	Yes	Auto	Any critical com error. Auto reset upon condition removal	Code 20	Normal	Normal	Alert - E19 Critical Communication Error	Alert - E19 Critical Communication Error
	Alarm - Low Loop Pressure	21	21	No	Auto	Loop pressure is below 3 psi for more than 3 minutes	Code 21	Normal	Alert - E51 Low Loop Pressure	Alert - E51 Low Loop Pressure	-
	Com ECM Fan Motor	22	22	-	-	Not used	Code 22	-	-	-	-
ABC & XRB Advanced Faults	Alarm - Home Automation 1	23	23	No	Auto	Closed contact input is present on Dig 2 input - Text is configurable	Code 23	Normal	Alert - E23 Selected choice	Alert - E23 Selected choice	Alert - E23 Selected choice
	Alarm - Home Automation 2	24	24	No	Auto	Closed contact input is present on Dig 3 input - Text is configurable	Code 24	Normal	Alert - E24 Selected choice	Alert - E24 Selected choice	Alert - E24 Selected choice
	Fault - AXB EEV Error	25	25	Yes	Auto	AXB EEV Error (below Fault Limit)	Code 25	Lockout	Lockout	Lockout - E25 AXB EEV Error	Lockout - E25 AXB EEV Error
	Fault - High Entering Water	26	26	No	Auto	Entering Water Temperature Above Fault Limit	Code 26	Lockout	Lockout	-	-
	Fault - Low Leaving Water	27	27	No	Auto	Entering Water Temperature Below Fault Limit	Code 27	Lockout	Lockout	-	-
	Fault - High Leaving Water	28	28	No	Auto	Leaving Water Temperature Above Fault Limit	Code 28	Lockout	Lockout	-	-
	Fault - High Leaving Water	29	29	No	Auto	Leaving Water Temperature Below Fault Limit	Code 29	Lockout	Lockout	-	-
	Fault - High Leaving Water	30	-	No	Auto	Zone Temperature Sensor Unreliable (UPC Only)	Code 30	Normal	Alert - E51 Low Loop Pressure	Alert - E51 Low Loop Pressure	-
	Fault - Source Flow Switch	31	31	No	Auto	Source Flow Switch Open	Code 31	Lockout	Lockout	-	-
	Fault - Load Flow Switch	32	32	No	Auto	Load Flow Switch Open	Code 32	Lockout	Lockout	-	-
Dual Compressor	Reserved	33	33	-	-	Not Used	-	-	-	-	-
	Reserved	34	34	-	-	Not Used	-	-	-	-	-
	Reserved	35	35	-	-	Not Used	-	-	-	-	-
	Reserved	36	36	-	-	Not Used	-	-	-	-	-
	Reserved	37	37	-	-	Not Used	-	-	-	-	-
	Reserved	38	38	-	-	Not Used	-	-	-	-	-
	Reserved	39	39	-	-	Not Used	-	-	-	-	-
	Reserved	40	40	-	-	Not Used	-	-	-	-	-
	Reserved	41	41	-	-	Not Used	-	-	-	-	-
	Reserved	42	42	-	-	Not Used	-	-	-	-	-
Dual Compressor	Derate-HiCnTemp	43	43	No	Auto	Drive Temp has exceeded critical High Temp	Code 41	Derated	Warning Derated - E41 Drive Temp	Warning Derated - E41 Drive Temp	Warning Derated - E41 Drive Temp
	Derate-HiCnTemp	44	44	No	Auto	Compressor Discharge is exceeded limit for 90 continuous sec.	Code 42	Derated	Warning Derated - E42 HiCnTemp	Warning Derated - E42 HiCnTemp	Warning Derated - E42 HiCnTemp
	Derate-LoCnTemp	45	45	No	Auto	Suction Pressure is critically low	Code 43	Derated	Warning Derated - E43 LoCnTemp	Warning Derated - E43 LoCnTemp	Warning Derated - E43 LoCnTemp
	Derate-HiCnTemp	46	46	No	Auto	Condensing pressure is critically high	Code 44	Derated	Warning Derated - E44 LoCnTemp	Warning Derated - E44 LoCnTemp	Warning Derated - E44 LoCnTemp
	Derate-HiCnTemp	47	47	No	Auto	Condensing pressure is critically high	Code 45	Derated	Warning Derated - E45 HiCnTemp	Warning Derated - E45 HiCnTemp	Warning Derated - E45 HiCnTemp
	Derate-OverPwrLmt	48	48	No	Auto	Supply Voltage is <208V or Max Pwr is reached due to high pressure	Code 46	Derated	Warning Derated - E46 OverPwrLmt	Warning Derated - E46 OverPwrLmt	Warning Derated - E46 OverPwrLmt
	Derate-OverPwrLmt	49	49	No	Auto	Com with EEV is interrupted EEV has some independent mode	Code 47	Derated	Warning Derated - E47 EEVIntCom	Warning Derated - E47 EEVIntCom	Warning Derated - E47 EEVIntCom
	Derate-OverPwrLmt	50	50	No	Auto	Com with EEV is interrupted EEV has some independent mode	Code 48	Derated	Warning Derated - E48 EEVOutCom	Warning Derated - E48 EEVOutCom	Warning Derated - E48 EEVOutCom
	Derate-OverPwrLmt	51	51	Yes	Hard or Soft	Ambient Discharge Sensor (SD) is > 280 F or invalid (<76 to 392 F)	Code 49	Derated	Warning Derated - E49 Ambient Discharge Sensor Error	Warning Derated - E49 Ambient Discharge Sensor Error	Warning Derated - E49 Ambient Discharge Sensor Error
	Derate-OverPwrLmt	52	52	Yes	Hard or Soft	Suction Pressure (PD) is invalid (0 to 232 psi)	Code 50	Derated	Warning Derated - E50 Suction Pressure Error	Warning Derated - E50 Suction Pressure Error	Warning Derated - E50 Suction Pressure Error
V5 Drive	Fault-ComPrsSnr	53	53	10x	Hard or Soft	Low condensing pressure (PD) or invalid (0 to 870 psi) Retry 10x.	Code 51	Lockout	Lockout - E51 DisTmSnr	Lockout - E51 DisTmSnr	Lockout - E51 DisTmSnr
	Fault-LowSupVolt	54	54	Yes	Hard or Soft	Supply Voltage is <175 V (190V to reset) or powered off/on too quickly (<30 sec.)	Code 53	Lockout	Lockout - E53 ComPrsSnr	Lockout - E53 ComPrsSnr	Lockout - E53 ComPrsSnr
	Fault-OutEnvelope	55	55	10x then	Hard or Soft	Comp Operating out of envelope (PO) more than 90 sec. Retry 10x.	Code 54	Lockout	Lockout - E54 LowSupVolt	Lockout - E54 LowSupVolt	Lockout - E54 LowSupVolt
	Fault-OverCurrent	56	56	Yes	Hard or Soft	Over current tripped by phase loss, earth fault, short circuit or major drive fault.	Code 55	Lockout	Lockout - E55 OutEnvelope	Lockout - E55 OutEnvelope	Lockout - E55 OutEnvelope
	Fault-HiDrivTemp	57	57	Yes	Hard or Soft	DC Link Voltage to compressor is >253V or at minimum drive.	Code 56	Lockout	Lockout - E56 OverCurrent	Lockout - E56 OverCurrent	Lockout - E56 OverCurrent
	Fault-DriveErr MOC/AGC	58	58	Yes	Hard or Soft	Drive Temp has exceeded critical High Temp >239 F	Code 57	Lockout	Lockout - E57 Over/Under Volt	Lockout - E57 Over/Under Volt	Lockout - E57 Over/Under Volt
	Fault-MultiSnsrMtd	59	59	Yes	Hard or Soft	The MOC has encountered an internal fault or an internal error. Probably fatal.	Code 58	Lockout	Lockout - E58 HiDrivTemp	Lockout - E58 HiDrivTemp	Lockout - E58 HiDrivTemp
	Fault-LowTemp	60	60	Yes	Hard or Soft	More than one SafeMode condition is present requiring lockout.	Code 59	Lockout	Lockout - E59 DriveErr	Lockout - E59 DriveErr	Lockout - E59 DriveErr
	Fault-HighTemp	61	61	Yes	Auto	V5 Drive Temperature Low	Code 60	Lockout	Lockout - E61 MultiSnsrMtd	Lockout - E61 MultiSnsrMtd	Lockout - E61 MultiSnsrMtd
	Fault-Drive Soft-Start	62	62	Yes	Auto	V5 Drive Temperature High	Code 61	Lockout	Lockout - E62	Lockout - E62	Lockout - E62
Outdoor In/Pkg	Fault-Drive Soft-Start	63	63	Yes	Auto	V5 Drive Temperature High	Code 62	Lockout	Lockout - E63	Lockout - E63	Lockout - E63
	Fault-Drive Soft-Start	64	64	Yes	Auto	Soft-Start did not succeed	Code 63	Lockout	Lockout - E64	Lockout - E64	Lockout - E64
	Fault-Drive Soft-Start	65	65	Yes	Auto	Soft-Start did not succeed	Code 64	Lockout	Lockout - E65	Lockout - E65	Lockout - E65
	Fault-Drive Soft-Start	66	66	Yes	Hard or Soft	Locked Rotor or phasing error	Code 65	Lockout	Lockout - E66	Lockout - E66	Lockout - E66
	Fault-Drive Soft-Start	67	67	Yes	Hard	Drive Microprocessor Fault	Code 66	Lockout	Lockout - E67	Lockout - E67	Lockout - E67
	Fault-Drive Soft-Start	68	68	-	-	Not Used	Code 67	-	-	-	-
	Fault-Drive Soft-Start	69	69	-	-	Not Used	Code 68	-	-	-	-
	Fault-Drive Soft-Start	70	70	-	-	Not Used	Code 69	-	-	-	-
	Fault-Drive Soft-Start	71	71	Yes	Hard or Soft	High superheat and high EEV opening. High superheat will trigger a loss of charge fault	Code 70	Lockout	Lockout - E71 LossCharge	Lockout - E71 LossCharge	Lockout - E71 LossCharge
	Fault-Drive Soft-Start	72	72	Yes	Auto	Suction Temperature Sensor (T2) is invalid (<76 to 392 F)	Code 71	Lockout	Lockout - E72 SuctTmSnr	Lockout - E72 SuctTmSnr	Lockout - E72 SuctTmSnr
Outdoor In/Pkg	Fault-Drive Soft-Start	73	73	No	Auto	Leaving Air Temperature Sensor (T2) is invalid (<76 to 392 F)	Code 72	Normal	Alert - E73 LAT Sensor	Alert - E73 LAT Sensor	Alert - E73 LAT Sensor
	Fault-Drive Soft-Start	74	74	No	Auto	Suction pressure has exceeded that maximum operating level for 90 sec.	Code 73	Normal	Warning SafeMode - E74 MaxOppPress	Warning SafeMode - E74 MaxOppPress	Warning SafeMode - E74 MaxOppPress
	Fault-Drive Soft-Start	75	75	Yes	Hard or Soft	High superheat and high EEV opening % for a long time will trigger a loss of charge fault.	Code 74	Lockout	Lockout - E75 Loss Charge	Lockout - E75 Loss Charge	Lockout - E75 Loss Charge
	Fault-Drive Soft-Start	76	76	No	Auto	Suction Temperature Sensor (T2) is invalid (<76 to 392 F)	Code 75	Normal	Warning SafeMode - E76 SuctTmSnr	Warning SafeMode - E76 SuctTmSnr	Warning SafeMode - E76 SuctTmSnr
	Fault-Drive Soft-Start	77	77	No	Auto	Leaving Air Temperature Sensor (T2) is invalid (<76 to 392 F)	Code 76	Normal	Alert - E77 LAT Sensor	Alert - E77 LAT Sensor	Alert - E77 LAT Sensor
	Fault-Drive Soft-Start	78	78	No	Auto	Suction pressure has exceeded that maximum operating level for 90 sec.	Code 77	Normal	Warning SafeMode - E78 MaxOppPress	Warning SafeMode - E78 MaxOppPress	Warning SafeMode - E78 MaxOppPress
	Fault-Drive Soft-Start	79-98	79-98	-	-	Count will increase each time power is applied to ABC	-	-	-	-	-
	Fault-Drive Soft-Start	99	99	-	-	Outdoor Air Temperature Sensor reading invalid	-	-	-	-	-
	Fault-Drive Soft-Start	100	100	-	-	Outdoor Air Temperature Sensor not communicating	-	-	-	-	-
	Fault-Drive Soft-Start	101	101	-	-	Outdoor Air Humidity Sensor reading invalid	-	-	-	-	-
UPC Rooftop	Fault-Drive Soft-Start	102	102	-	-	Outdoor Air Humidity Sensor not communicating	-	-	-	-	-
	Fault-Drive Soft-Start	103	103	-	-	Return Air temperature sensor reading invalid	-	-	-	-	-
	Fault-Drive Soft-Start	104	104	-	-	Return Air temperature sensor not communicating	-	-	-	-	-
	Fault-Drive Soft-Start	105	105	-	-	Return Air Humidity sensor reading invalid	-	-	-	-	-
	Fault-Drive Soft-Start	106	106	-	-	Return Air Humidity sensor not communicating	-	-	-	-	-
	Fault-Drive Soft-Start	107	107	-	-	Return Air Humidity sensor not communicating	-	-	-	-	-
	Fault-Drive Soft-Start	108	108	-	-	Return Air Humidity sensor not communicating	-	-	-	-	-
	Fault-Drive Soft-Start	109	109	-	-	Return Air Humidity sensor not communicating	-	-	-	-	-
	Fault-Drive Soft-Start	110	110	-	-	Return Air Humidity sensor not communicating	-	-	-	-	-
	Fault-Drive Soft-Start	111	111	-	-	Return Air Humidity sensor not communicating	-	-	-	-	-
Software Support	Compressor Support Fault	120	-	-	-	Incorrect ABC/AXB software for HydroLink Control of compressors	Normal	Normal	-	-	-
	Blower Support Fault	121	-	-	-	Incorrect ABC/AXB software for HydroLink Control of blower	Normal	Normal	-	-	-
	Pump Support Fault	122	-	-	-	Incorrect ABC/AXB software for HydroLink Control of pump	Normal	Normal	-	-	-
	Pump Support Fault	123	-	-	-	Incorrect ABC/AXB software for HydroLink Control of pump	Normal	Normal	-	-	-
	Pump Support Fault	124	-	-	-	Incorrect ABC/AXB software for HydroLink Control of pump	Normal	Normal	-	-	-
	Pump Support Fault	125	-	-	-	Incorrect ABC/AXB software for HydroLink Control of pump	Normal	Normal	-	-	-
	Pump Support Fault	126	-	-	-	Incorrect ABC/AXB software for HydroLink Control of pump	Normal	Normal	-	-	-
	Pump Support Fault	127	-	-	-	Incorrect ABC/AXB software for HydroLink Control of pump	Normal	Normal	-	-	-
	Pump Support Fault	128	-	-	-	Incorrect ABC/AXB software for HydroLink Control of pump	Normal	Normal	-	-	-
	Pump Support Fault	129	-	-	-	Incorrect ABC/AXB software for HydroLink Control of pump	Normal	Normal	-	-	-


Note: *All codes >11 use long flash for tens digit and short flash for the ones digit. 20, 30, 40, 50 etc. will be skipped! Alert is a noncritical sensor or function that has failed. Normal operation of the heat pump is maintained but service is desired at some point.

Controls - Aurora Advanced Variable Speed Control cont.

ABC Control Board Layout




AXB Control Board Layout




Compressor Drive



EEV Board Layout




Controls - UPC DDC Control (optional)



Aurora UPC Controller

The Aurora Unitary Protocol Converter (UPC) is designed to add-on to any Aurora based heat pump control. The Aurora Unitary Protocol Converter (UPC) is designed to allow water source heat pumps to be integrated into Building Automation Systems (BAS) with ease. The Aurora UPC is an integrated solution and communicates directly with the Aurora Heat Pump Controls and allows access/control of a variety of internal Aurora heat pump operations such as sensors, relay operation, faults and other information. In turn, the UPC then converts internal Aurora Modbus protocol to BACnet MS/TP, LON, or N2 protocols and communicates to the BAS system. This provides the great benefit of complete control integration and a myriad of information available to the BAS from the heat pump control. Plus it also allows individual unit configuration such as ECM fan speeds or freeze protection setting directly over the BAS without the need for access to the actual heat pump. The Aurora UPC is programmed using the powerful Eikon object oriented.

The Aurora UPC is implemented with the Aurora Base Controller (ABC) heat pump control into our latest water source heat pumps. This will allow for a BAS to integrate



Aurora Touch Interface




ZS Series Sensors

and communicate to the heat pump thru a choice of 3 different communication protocols. The Aurora UPC has the ability to communicate BACnet MS/TP, N2 open, or LonWorks (requires LON Plugin card). This flexibility is possible due to the onboard dipswitches which allow for the desired protocol and baud rate to be selected in the field. All zone temperatures and zone sensors are connected to the UPC on an RNet bus, simplifying hook up at the unit. RNet sensors can include a combination of zone temperature and humidity, CO₂, and VOC sensors. The UPC includes built-in support for a custom configurable keypad/display unit - BACview6 (4-line by 40 character per line display) or BACview5 (2-line by 16 character per line display). Up to 2 Keypad/display units can be mounted remotely for configuration and troubleshooting.

There are an extensive number of points that the UPC has available over the network for integration into the BAS. Control programmers need to carefully determine which points they want to add into the BAS database. A list of the BACnet points, N2 points, and LON SNVTs are available along with their individual point descriptions by contacting a factory service representative.

Controls - UPC DDC Control (optional) cont.




Aurora UPC Features

- Rugged enclosure made of GE C2950 Cycloy plastic
- Built-in surge transient protection circuitry
- Operating range of -20° to 140°F; 10 to 95% relative humidity, non-condensing
- Onboard CR123A battery has a life of 10 years with 720 hours of cumulative power outage
- Multi-Protocol field selectable communication port that supports:
 - EIA-485 BACnet MS/TP @ 9600, 19.2k, 38.4k, 76.8k baud
 - Metasys N2 Open
 - LonWorks TP/FT-10 (Requires optional LON plug-in communication card)
- Status of all unit operating conditions and fault lockouts
- Visual LED's for status of power, network communication, processor operation, and errors
- Provides gateway into Aurora heat pump controls for unsurpassed control flexibility
 - Network point for commanding unit into load shed
 - Network point for commanding unit into emergency shutdown
 - Network points to assist in fan speed selection
 - Network points for freeze protection settings
- Heating and cooling control from a remotely located zone sensor
- Rnet communication port which allows for multiple Rnet zone sensors (5) to be connected for space temperature averaging if desired.
- Local laptop or BACview connection for field service
- FCC, UL and CE listed. BTL Certification is pending

Aurora UPC Optional Features

- BACview handheld display, needed for field configuration of fan speeds, set points, etc.
- AID Tool for Aurora ABC configuration and troubleshooting.
- Aurora Advanced Control adds the Aurora AXB expansion board and provides added I/O and standard features
 - **Refrigeration Monitoring** - provides Suction and discharge pressure, Suction, liquid line temps and superheat and subcooling.
 - **Performance Monitoring** - provides entering and leaving loop water temperatures, loop flow rate as well as heat of extraction or rejection rate into the loop.
 - **Energy Monitoring** - provides real-time power measurement (Watt) of compressor, fan, auxiliary heat and zone pump.
- Graphics packages available in the future

Controls - UPC DDC Control (optional) cont.



Controls - UPC DDC Control (optional) cont.

1. **Leaving Air Temperature (LAT) Sensor** - This 10 kOhm NTC sensor is factory installed on all UPC equipped heat pumps. It typically is attached to wiring inside the blower cabinet on the suction side of the blower. This sensor is attached on ABC FP2 pins available as LAT AU-30.
2. **Valve End Switch** - This optional input is setup for a field installed flow valve end switch. This end switch input is attached at ABC Y2 and available at point BV-67.
3. **Fan Proving Sensors** - This optional factory installed current sensor is connected to confirm fan operation via the power wires. The sensor is attached at ABC G and available at point BV-33.
4. **Occupancy Sensor** - This standard feature includes a field installed and wired room sensor with occupancy sensor typically found in DDC systems. The RNet room sensors can be found thru your commercial representative. The occupancy Sensors are attached at ABC O and can be found at point BV-49.
5. **Dirty Filter Switch** - This optional field installed switch is connected to confirm dirty filter operation. The dirty filter switch can be found thru your commercial representative. The sensor is attached at ABC W and available at point BV-63.
6. **Fault, Configuration, and Status Codes** - The codes can be visible to the BAS if desired

Aurora Advanced Fault Codes (ABC + AXB Expansion Board) Variable Speed

Variable Speed Drive Additions

	Red Fault LED	LED Flash Code *	Lockout	Reset/Remove	Fault Condition Summary
ABC & AXB Basic Faults	Normal - No Faults	Off	-		
	Fault-Input	1	No	Auto	Tstat input error. Autoreset upon condition removal.
	Fault-High Pressure	2	Yes	Hard or Soft	HP switch has tripped (>600 psi)
	Fault-Low Pressure	3	Yes	Hard or Soft	Low Pressure Switch has tripped (<40 psi for 30 continuous sec.)
	Fault-Freeze Detection FP2	4	Yes	Hard or Soft	Freeze protection sensor has tripped (<30 degF for 30 continuous sec.)
	Fault-Freeze Detection FP1	5	Yes	Hard or Soft	Freeze protection sensor has tripped (<15 or 30 degF for 30 continuous sec.)
	Fault-Condensate Overflow	7	Yes	Hard or Soft	Condensate switch has shown continuity for 30 continuous sec.
	Fault-Over/Under Voltage	8	No**	Auto	Instantaneous Voltage is out of range. **Controls shut down until resolved.
	Fault-FP1 & 2 Snsr Error	11	Yes	Hard or Soft	If FP1 or 2 Sensor Err

Note: *All codes >11 use long flash for tens digit and short flash for the ones digit. 20, 30, 40, 50 etc. are skipped!
Alert' is a noncritical sensor or function that has failed. Normal operation of the heat pump is maintained but service is desired at some point.

Controls - UPC DDC Control (optional) cont.

Aurora Base or Advanced Control Configuration and Status Codes

Status LED (LED3, Green)

Description of Operation	Fault LED, Green
Normal Mode	ON
Control is Non-functional	OFF
Test Mode	Slow Flash
Lockout Active	Fast Flash
Dehumidification Mode	Flash Code 2
Load Shed	Flash Code 5
Emergency Shutdown	Flash Code 6
On Peak Mode	Flash Code 7
(Future Use)	Flash Code 8
(Future Use)	Flash Code 9

Configuration LED (LED2, Yellow)

Description of Operation	Configuration LED, Yellow
No Software Overwritten	ECM Setting
DIP Switch Overwritten	Slow Flash
ECM Configuration Mode	Fast Flash
Reset Configuration Mode	OFF

9. Alarm Relay - The Alarm relay (ALM) is factory connected to 24 VAC via jumper JW2. By cutting JW2, ABC ALM becomes a dry contact connected to ABC ALG. The Relay is field switchable between Factory setting as an Alarm output or available for other uses.

10. Accessory Relay1 - A configurable, accessory relay on the ABC is provided that can be cycled with the compressor, blower, or the Dehumidifier (DH) input. A third (factory) setting cycles the relay with the compressor but delays the compressor and blower output for 90 sec. Source pump or slow opening solenoid valves in well systems or variable speed primary pumping systems would be a prime use of this feature.

Access Relay Operation	SW2-4	SW2-5
Cycle with Blower	ON	ON
Cycle with Compressor	OFF	OFF
Water Valve Slow Opening	ON	OFF
Cycle with Comm. T-stat Hum Cmd	OFF	ON

11. Electric Heat EH1 - A digital 24VDC output is provided for electric heat powering. UPC's Default programming has EH1 set for AUX/ELEC Heat operation and will be controlled using the UPC's internal P.I.D. logic. However it can be changed by the BAS to be network controlled.

12. Electric Heat EH2 - A digital VDC output is provided for field options converted from the original EH2 output. Default UPC program has the EH2 output set for Network Control but can be changed by the BAS to be controlled by the UPC's internal P.I.D. logic.

Controls - UPC DDC Control (optional) cont.

Aurora Advanced Control Configuration and Options

1. **Accessory Relay2** - A second, configurable, accessory relay on the AXB is provided that can be cycled with the compressor 1 or 2, blower, or the Dehumidifier (DH) input. This is to complement the Accessory 1 Relay on the ABC board.

Position	DIP 4	DIP 5	Description
1	ON	ON	Cycles with Fan or ECM (or G)
2	OFF	ON	Cycles with CC1 first stage of compressor or compressor spd 1-12
3	ON	OFF	Cycles with CC2 second stage of compressor or compressor spd 7-12
4	OFF	OFF	Cycles with DH input from ABC board

2. **Analog Out** - A standard 0-10VDC analog output is provided. This output can be used to drive modulating dampers etc.
3. **Variable Speed Pump or Modulating Water Valve (If applicable)** - This input and output are provided to drive and monitor a variable speed pump. The VS pump output is a PWM signal to drive the variable speed pump. The minimum and maximum level are set using the AID Tool. 75% and 100% are the default settings respectively. The VS data input allows a separate PWM signal to return from the pump giving fault and performance information. Fault received from the variable speed pump will be displayed as E16. **Modulating Water Valve** - This Variable speed PWM output is provided to optionally drive a modulating water valve. Through advanced design a 0-10VDC valve can be driven directly from the VS pump output. The minimum and maximum level are set in the same way as the VS pump using the AID Tool. 75% and 100% are the default settings respectively.
4. **Loop Pump Linking (If applicable)** - This input and output are provided so that two units can be linked together with a common flow center. When either unit has a call for loop pump, both unit's loop pump relays and variable speed pumps are energized. The flow center then can simply be wired to either unit. The output from one unit should be routed to the input of the other. If daisy chained up to 16 heat pumps can be wired and linked together in this fashion.

Controls - UPC DDC Control (optional) cont.

Aurora Advanced Control Optional Sensor Kits

- 1. Energy Monitoring (Standard)** - Energy Monitoring includes two current transducers (blower and electric heat). The BACview Tool provides configuration detail for the type of blower motor and a line voltage calibration procedure to improve the accuracy. This real time power usage information can be displayed on the AID Tool and is available thru network points when using BACnet or N2 Open.
 - Compressor Current
 - Fan Current
 - Aux Heat Current
 - Pump Selection
 - Voltage
 - Compressor Watts
 - Fan Watts
 - Aux Heat Watts
 - Pump Watts (VS Only)

- 2. Refrigerant Monitoring (Standard)** - The Refrigerant Monitoring Kit includes two pressure transducers, and three temperature sensors, heating liquid line, suction temperature and existing cooling liquid line (FP1). These sensors allow the measurement of discharge and suction pressures, suction and liquid line temperatures as well as superheat and subcooling. This information can be displayed on the BACview Tool, or the network when using BACnet and N2.
 - Htg Liquid Line
 - Clg Liquid Line
 - Discharge pressure
 - Suction Pressure
 - Discharge Saturated Temp
 - Suction Saturated Temperature
 - Superheat
 - SubCooling

- 3. Performance Monitoring (Requires flow meter)** - Performance Monitoring includes: three temperature sensors, entering and leaving water, leaving air temperature and a water flow rate sensor. With this kit, heat of extraction and rejection will be calculated. This requires configuration using the BACview Tool for selection of water or antifreeze.
 - Leaving Air Temperature (supply)
 - Alt Leaving Air Temperature (Supply)
 - Entering Water Temperature
 - Leaving Water Temperature
 - Water Flow Meter
 - Entering Air Temperature (from zone sensor)
 - Brine Selection (water/antifreeze)
 - Heat of Extraction/Rejection

Controls - UPC DDC Control (optional) cont.

ZS Series RNet Sensor Overview

The ZS Series line of intelligent zone sensors provides the function and flexibility you need to manage the conditions important to the comfort and productivity of the zone occupants. The ZS sensors are available in a variety of zone sensing combinations to address your application needs. These combinations include temperature, relative humidity, and indoor air quality (carbon dioxide or VOCs (Volatile Organic Compounds)). They are built to be flexible allowing for easy customization of what the user/technician sees. Designed to work with the Aurora UPC controllers the ZS sensor line includes the ZS Base, ZS Plus, ZS Pro and ZS Pro-F.

The UPC uses a proprietary communication called Rnet to receive the space temperature from the zone sensor.

This is done using (2) 18 AWG twisted pair unshielded cables for a total of 4 wires connected to the Rnet port. The sensor gets its power from the UPC controller and connecting multiple sensors to one UPC will allow for space temperature averaging. The UPC can support one ZS Pro or ZS Pro F with up to four ZS standard sensors wired to the Rnet port on the UPC for a total of 5 zone sensors. The sensors use a precise 10k ohm thermistor with less than 0.18°F drift over a ten year span, this allows for less maintenance or re-calibration after installation. The sensors also have a hidden communication port for connecting a BACview or local laptop that provides access to the equipment for commissioning and maintenance. The table below shows the features of each of the four sensors that are currently available.







Features	ZS Base	ZS Plus	ZS Pro	ZS Pro-F
Temp, CO ² , Humidity, and VOC Options	✓	✓	✓	✓
Neutral Color	✓	✓	✓	✓
Addressable/supports daisy chaining	✓	✓	✓	✓
Hidden communication port	✓	✓	✓	✓
Mounts on a standard 2" by 4" electrical box	✓	✓	✓	✓
Occupancy Status indicator LED		✓	✓	✓
Push button occupancy override		✓	✓	✓
Setpoint adjust		✓	✓	✓
Large, easy to read LCD			✓	✓
Alarm indicator			✓	✓
°F to °C conversion button				✓

Options	Part Number	Part Number	Part Number	Part Number
Temperature Only	ZSU	ZSUPL	ZSUP	ZSUPF
Temp with CO ²	ZSU-C	ZSUPL-C	ZSUP-C	ZSUPF-C
Temp with Humidity	ZSU-H	ZSUPL-H	ZSUP-H	ZSUPF-H
Temp with Humidity, CO ²	ZSU-HC	ZSUPL-HC	ZSUP-HC	ZSUPF-HC
Temp, Humidity, VOC	ZSU-HV	ZSUPL-HV	ZSUP-HV	ZSUPF-HV
Temp with VOC	ZSU-V	ZSUPL-V	ZSUP-V	ZSUPF-V


Controls - UPC DDC Control (optional) cont.

RNet Sensor Physical and Electrical Data


Sensing Element	Range	Accuracy
Temperature (on non-Humidity models)	-4° to 122° F (-20° C to 50° C)	30.35° F (0.2° C)
Temperature (on Humidity models)	50° F to 104° F (10° C to 40° C)	30.5° F (0.3° C)
Humidity	10% to 90%	31.8% typical
CO2	400 to 1250 PPM 1250 to 2000 PPM	330PPM or +/-3% of reading (greater of two) 35% of reading plus 30 PPM
VOC	0 to 2,000 PPM	3100 PPM
Power Requirements	Sensor Type	Power Required
Temperature Only	All Models	12 Vdc @ 8 mA
Temperature with Humidity	All Models	12 Vdc @ 15 mA (idle) to 190 mA (CO2 measurement cycle)
Temp with VOC, or Temp/VOC/Humidity	All Models	12 Vdc @ 60 mA
Temp with CO2 , or Temp/ CO2/Humidity	All Models	12 Vdc @ 15 mA (idle) to 190 mA (CO2 measurement cycle)
Power Supply	A controller supplies the Rnet sensor network with 12 Vdc @ 210 mA. Additional power may be required for your application. See sensor ZS Installation Guide	
Communication	115 kbps Rnet connection between sensor(s) and controller 15 sensors max per Rnet network; 5 sensors max per control program	
Local Access Port	For connecting a laptop computer to the local equipment for maintenance and commissioning	
Environmental Operating Range	32° to 122° F (0° - 50° C), 10% to 90% relative humidity, non-condensing	
Mounting Dimensions	Standard 4"x 2" electrical box using provided 6/32" x 1/2" mounting screws	



Temperature Only or Temperature with Humidity



Sensor with CO2 or VOC



Unit Startup

Before Powering Unit, Check The Following:

- Power supply matches nameplate specifications.
- Power supply fuses, breakers and wires are sized correctly.
- Switch the Transformer to 208V if applicable.
- Low voltage wiring complete.
- Piping completed and water system cleaned and flushed.
- Air is purged from closed loop system.
- Isolation valves are open, water control valves or loop pumps wired.
- Condensate line open and correctly pitched.
- Dip switches are set correctly.
- Blower wheel rotates freely and turns in the correct direction.
- Air filter/cleaner is clean and in position.
- Service/access panels are in place.
- Return air temperature is between 50-80oF heating and 60-95oF cooling.
- Evaluate air coil cleanliness to insure optimum performance. Clean as needed according to maintenance guidelines.

Startup Steps

NOTE: Complete the Equipment Start-Up/Commissioning Check Sheet during this procedure. Refer to thermostat operating instructions and complete the startup procedure.

1. Initiate a control signal to energize the blower motor. Check the blower operation.
2. Be sure the water control valve or loop pump(s) are activated.
3. Initiate a control signal to place the unit in the cooling mode. Cooling set point must be set below room temperature.
4. Cooling will energize after time delay. Check for correct rotation of scroll compressor in three (3) phase applications. Incorrect rotation will cause low refrigerant pressures and possibly unusual noise. Switch any two power leads at the compressor or contactor to reverse rotation.
5. Verify that the water flow rate is correct by measuring the pressure drop through the heat exchanger using the P/T plugs and comparing to the pressure drop table.
6. Check the temperature of both the supply and discharge water (Refer to Operating Parameters tables).
7. Check for an air temperature drop of 15oF to 25oF across the air coil, depending on the blower speed and entering water temperature.
8. Decrease the cooling set point several degrees and verify variable speed blower operation.
9. Adjust the cooling set point above the room temperature and verify that the compressor and water valve or loop pumps deactivate.
10. Initiate a control signal to place the unit in heating mode. Heating set point must be set above room temperature.
11. Heating will energize after a time delay.
12. Check the temperature of both the supply and discharge water (Refer to Unit Operating Parameters tables).
13. Check for an air temperature rise of 20oF to 35oF across the air coil, depending on the blower speed and entering water temperature.
14. If auxiliary electric heaters are installed, increase the heating set point until the electric heat banks are sequenced on. All stages of the auxiliary heater should be sequenced on when the thermostat is in the Emergency Heat mode. Check amperage of each element.
15. Adjust the heating set point below room temperature and verify that the compressor and water valve or loop pumps deactivate.
16. During the testing, check for excessive vibration, noise or water leaks. Correct or repair as required.
17. Set system to desired normal operation mode and set temperature to maintain desired comfort level.
18. Instruct the owner/operator in the proper operation of the thermostat and system maintenance.

NOTE: Be certain to fill out and forward all warranty registration papers.

Operating Limits

Operating Limits	Cooling		Heating	
	(°F)	(°C)	(°F)	(°C)
Air Limits				
Min. Ambient Air	45	7.2	45	7.2
Rated Ambient Air	80	26.7	70	21.1
Max. Ambient Air	100	37.8	85	29.4
Min. Entering Air	50	10.0	40	4.4
Rated Entering Air db/wb	80.6/66.2	27/19	68	20.0
Max. Entering Air db/wb	110/83	43/28.3	80	26.7
Water Limits				
Min. Entering Water	30	-1.1	20	-6.7
Normal Entering Water	50-110	10-43.3	30-70	-1.1
Max. Entering Water	120	48.9	90	32.2

NOTE: Minimum/maximum limits are only for start-up conditions, and are meant for bringing the space up to occupancy temperature. Units are not designed to operate at the minimum/maximum conditions on a regular basis. The operating limits are dependent upon three primary factors: 1) water temperature, 2) return air temperature, and 3) ambient temperature. When any of the factors are at the minimum or maximum levels, the other two factors must be at the normal level for proper and reliable unit operation.

Operating Parameters

Entering Water Temp °F	Load	Cooling -- No Hot Water Generation					
		Suction Pressure psig	Discharge Pressure psig	Superheat	Subcooling	Water Temp Rise °F	Air Temp Drop °F DB
30	Min	120 - 125	115 - 130	12 - 16	3 - 8	4 - 8	17 - 23
	Max	100 - 115	115 - 130	15 - 20	8 - 12	8 - 12	17 - 23
50	Min	140 - 150	160 - 180	12 - 16	3 - 8	4 - 8	17 - 23
	Max	120 - 135	180 - 200	8 - 12	8 - 14	8 - 12	17 - 23
70	Min	145 - 155	210 - 230	8 - 12	6 - 12	4 - 8	17 - 23
	Max	133 - 143	250 - 260	8 - 12	8 - 14	8 - 12	17 - 23
90	Min	150 - 160	295 - 305	8 - 12	6 - 12	4 - 8	17 - 23
	Max	140 - 150	330 - 340	8 - 12	8 - 14	8 - 12	17 - 23
110	Min	155 - 165	370 - 400	4 - 8	6 - 12	4 - 8	17 - 23
	Max	148 - 153	390 - 420	8 - 12	8 - 14	8 - 12	17 - 23

Entering Water Temp °F	Load	Heating -- No Hot Water Generation					
		Suction Pressure psig	Discharge Pressure psig	Superheat	Subcooling	Water Temp Drop °F	Air Temp Rise °F DB
30	Min	90 - 95	220 - 230	4 - 8	3 - 8	2 - 5	9 - 12
	Max	80 - 88	275 - 290	8 - 12	3 - 10	3 - 7	14 - 18
50	Min	130 - 145	235 - 260	8 - 12	3 - 5	5 - 9	9 - 12
	Max	105 - 120	290 - 315	8 - 12	3 - 10	5 - 9	20 - 24
70	Min	155 - 170	250 - 280	8 - 12	3 - 5	5 - 9	15 - 20
	Max	140 - 155	315 - 330	8 - 12	3 - 10	6 - 10	22 - 30
90	Min	180 - 190	270 - 300	8 - 12	3 - 5	5 - 9	15 - 20
	Max	160 - 170	340 - 380	8 - 12	3 - 10	6 - 10	22 - 30
110	Min						
	Max						

Note: Cooling performance based on entering air temperatures of 80° F DB, 67° F WB.
 Heating performance based on entering air temperature of 70° F DB.

8/25/16

Pressure Drop

Coaxial Heat Exchanger

Model	GPM	Pressure Drop (psid)				
		30oF	50oF	70oF	90oF	110oF
120	15	0.6	0.4	0.3	0.2	0.1
	20	1.3	1.1	0.8	0.6	0.4
	25	2.2	1.8	1.4	1.2	1.0
	30	3.4	2.7	2.2	1.9	1.4
180	22	1.5	1.4	1.2	1.1	0.7
	32	2.9	2.5	2.2	2.0	1.5
	39	3.9	3.4	3.0	2.7	2.1
	45	5.1	4.4	3.8	3.4	2.7

07/12/19

Reference Calculations

Heating Calculations:	Cooling Calculations:
$LWT = EWT - \frac{HE}{gpm \times 500}$	$LWT = EWT + \frac{HR}{gpm \times 500}$
$LAT = EAT + \frac{HC}{cfm \times 1.08}$	$LAT(DB) = EAT(DB) - \frac{SC}{cfm \times 1.08}$
$TH = HC + HWC$	$LC = TC - SC$
	$S/T = \frac{SC}{TC}$

Legend and Notes

ABBREVIATIONS AND DEFINITIONS:

cfm = airflow, cubic feet/minute
 EWT = entering water temperature, Fahrenheit
 gpm = water flow in gallons/minute
 WPD = water pressure drop, psi and feet of water
 EAT = entering air temperature, Fahrenheit
 (dry bulb/wet bulb)
 HC = air heating capacity, MBtu/h
 TC = total cooling capacity, MBtu/h
 SC = sensible cooling capacity, MBtu/h
 kW = total power unit input, kilowatts
 HR = total heat of rejection, MBtu/h

HE = total heat of extraction, MBtu/h
 HWC = hot water generator capacity, MBtu/h
 EER = Energy Efficient Ratio
 = BTU output/Watt input
 COP = Coefficient of Performance
 = Btu output/Btu input
 LWT = leaving water temperature, °F
 LAT = leaving air temperature, °F
 TH = total heating capacity, MBtu/h
 LC = latent cooling capacity, MBtu/h
 S/T = sensible to total cooling ratio

Notes (Refer to Performance Data tables)

- Performance ratings are based on 80°F DB / 67°F WB EAT for cooling and 70°F DB EAT for heating.
- Three flow rates are shown for each unit. The lowest flow rate shown is used for geothermal open loop/well water systems with a minimum of 50°F EWT. The middle flow rate shown is the minimum geothermal closed loop flow rate. The highest flow rate shown is optimum for geothermal closed loop systems and the suggested flow rate for boiler/tower applications.
- Entering water temperatures below 40°F assumes 15% antifreeze solution.
- For non-standard EAT conditions, apply the appropriate correction factors on (Refer to Correction Factor Tables).
- Interpolation between EWT, gpm, and cfm data is permissible.

Refrigerant Circuit Guideline

Symptom	Head Pressure	Suction Pressure	Compressor Amp Draw	Superheat	Subcooling	Air Temp. Differential	Water Temp. Differential
Under Charged System (Possible Leak)	Low	Low	Low	High	Low	Low	Low
Over Charged System	High	High	High	Normal	High	Normal/Low	Normal
Low Air Flow Heating	High	High	High	High/Normal	Low	High	Low
Low Air Flow Cooling	Low	Low	Low	Low/Normal	High	High	Low
Low Water Flow Heating	Low/Normal	Low/Normal	Low	Low	High	Low	High
Low Water Flow Cooling	High	High	High	High	Low	Low	High
High Air Flow Heating	Low	Low	Low	Low	High	Low	Low
High Air Flow Cooling	Low	High	Normal	High	Low	Low	Normal
High Water Flow Heating	Normal	Low	Normal	High	Normal	Normal	Low
High Water Flow Cooling	Low	Low	Low	Low	High	Normal	Low
Low Indoor Air Temperature Heating	Low	Low	Low	Normal	High	Normal	Normal/High
Low Indoor Air Temperature Cooling	Low	Low	Low	Normal/Low	High	Low	Low
High Indoor Air Temperature Heating	High	High	High	Normal/High	Normal/Low	Low	Normal
High Indoor Air Temperature Cooling	High	High	High	High	Low	Low	High
Restricted EEC (Check Service Advisory)	High	Low	Normal/Low	High	High	Low	Low
Insufficient Compressor (Possible Bad Valves)	Low	High	Low	High	Normal/High	Low	Low
Scaled Coaxial Heat Exchanger Heating	Low	Low	Low	Normal/Low	High	Low	Low
Scaled Coaxial Heat Exchanger Cooling	High	High	High	Normal/Low	Low	Low	Low
Restricted Filter Drier	Check temperature difference (delta T) across filter drier.						

8/25/16

Compressor and Thermistor Resistance

Compressor Resistance Chart

Model	208-230/60/3	460/60/3
120	0.681	0.681
180	0.203	0.203

9/23/16

Thermistor Resistance Chart

Thermistor Resistance (10k Ohm) for FP1, FP2, HWL, LWT, LLT, and EWT		Thermistor Resistance (1k Ohm) for compressor discharge line, suction line, LAT, and compressor ambient	
Temperature (°F)	Resistance (Ohms)	Temperature (°F)	Resistance (Ohms)
5	75757-70117	20	974.4-973.4
14	57392-53234	25	985.4-984.4
23	43865-40771	30	996.1-995.1
32	33809-31487	35	1007.0-1006.0
41	26269-24513	40	1017.8-1016.8
50	20570-19230	45	1028.6-1027.6
59	16226-15196	50	1039.5-1038.5
68	12889-12093	55	1050.2-1049.2
77	10310-9688	60	1061.2-1060.2
86	8300-7812	65	1072.9-1071.9
95	6723-6337	70	1082.7-1081.7
104	5480-5172	75	1093.4-1092.4
113	4490-4246	80	1103.0-1102.0
122	3700-3504	85	1115.5-1114.5
131	3067-2907	90	1126.2-1125.2
140	2554-2424	95	1136.6-1135.6
149	2149-2019	100	1147.2-1146.2
		105	1158.1-1157.1
		110	1168.8-1167.8
		115	1179.4-1178.4
		120	1190.1-1189.1
		125	1200.3-1199.3
		130	1212.2-1211.2

8/25/16

Troubleshooting

Should a major problem develop, refer to the following information for possible causes and corrective steps.

If compressor won't run:

1. The fuse may be open or the circuit breaker is tripped. Check electrical circuits and motor windings for shorts or grounds. Investigate for possible overloading. Replace fuse or reset circuit breakers after fault is corrected.
2. Supply voltage may be too low. Check it with a volt meter.
3. Control system may be faulty. Check control for correct wiring of thermostat or aquastat and check the 24 volt transformer for proper voltage.
4. Wires may be loose or broken. Replace or tighten.
5. The low pressure switch may have tripped due to one or more of the following:
 - a) Heating
 - 1) Plugged heat exchanger on source side
 - 2) Water flow source side - (Low)
 - 3) Water too cold source side
 - 4) Low refrigerant
 - b) Cooling
 - 1) Plugged heat exchanger on load side
 - 2) Water flow load side - (Low)
 - 3) Water too cold load side
 - 4) Low refrigerant
6. The high pressure switch may have tripped due to one or more of the following:
 - a) Heating
 - 1) Plugged heat exchanger on load side
 - 2) Low water flow load side
 - 3) Water too warm load side
 - b) Cooling
 - 1) Plugged heat exchanger on source side
 - 2) Low water flow on source side
 - 3) Water too warm source side
7. The compressor overload protection may be open.
8. The internal winding of the compressor motor may be grounded to the compressor shell. If so, replace the compressor.
9. The compressor winding may be open or shorted. Disconnect power. Check continuity with ohm meter. If the winding is open, replace the compressor.

If sufficient cooling or heating is not obtained:

1. Check control for improper location or setting.
2. Check for restriction in water flow.
3. Check refrigerant subcooling and superheat for proper refrigerant charge and expansion valve operation.
4. The reversing valve may be defective and creating a bypass of refrigerant. If the unit will not heat, check the reversing valve coil.

If the unit operation is noisy:

1. Check compressor for loosened mounting bolts. Make sure compressor is floating free on its isolator mounts. Check for tubing contact with the compressor or other surfaces. Readjust it by bending slightly.
2. Check screws on all panels.
3. Check for chattering or humming in the contactor or relays due to low voltage or a defective holding coil. Replace the component.
4. Check for proper installation of vibration absorbing material under the unit.
5. Check for abnormally high discharge pressures.
6. Compressor rotation incorrect

Refrigerant Systems

To maintain sealed circuit integrity, do not install service gauges unless unit operation appears abnormal. Compare the change in temperature on the air side as well as the water side to the Operating Parameters tables. If the unit's performance is not within the ranges listed, and the airflow and water flow are known to be correct, gauges should then be installed and superheat and subcooling numbers calculated. If superheat and subcooling are outside recommended ranges, an adjustment to the refrigerant charge may be necessary.

NOTE: Refrigerant tests must be made with hot water generator turned "OFF". Verify that air and water flow rates are at proper levels before servicing the refrigerant circuit.

Startup and Troubleshooting Form

Company Name: _____ Company Phone No: _____
 Technician Name: _____ Date: _____
 Model No: _____ Serial No: _____
 Owner's Name: _____ Open or Closed Loop: _____
 Installation Address: _____ Installation Date: _____

Check One

Start up/Check-out for new installation Troubleshooting Problem: _____

1. FLOW RATE IN GPM (COAXIAL HEAT EXCHANGER)

Water In Pressure: a. _____ PSI
 Water Out Pressure: b. _____ PSI
 Pressure Drop = a - b c. _____ PSI
 Convert Pressure Drop to Flow Rate
 (refer to *Pressure Drop* table) d. _____ GPM

2. TEMPERATURE RISE OR DROP ACROSS COAXIAL HEAT EXCHANGER

	COOLING	HEATING
Water In Temperature:	e. _____ °F	e. _____ °F
Water Out Temperature:	f. _____ °F	f. _____ °F
Temperature Difference:	g. _____ °F	g. _____ °F

3. TEMPERATURE RISE OR DROP ACROSS AIR COIL

	COOLING	HEATING
Air In Temperature:	h. _____ °F	h. _____ °F
Air Out Temperature:	i. _____ °F	i. _____ °F
Temperature Difference:	j. _____ °F	j. _____ °F

4. HEAT OF REJECTION (HR) / HEAT OF EXTRACTION (HE) CALCULATION

HR or HE = Flow Rate x Temperature Difference x Brine Factor*
 d. (above) x g. (above) x 485 for Methanol or Environol, 500 for water*
 Heat of Extraction (Heating Mode) = _____ btu/hr
 Heat of Rejection (Cooling Mode) = _____ btu/hr
 Compare results to Capacity Data Tables

Note: Steps 5 through 8 need only be completed if a problem is suspected

5. WATTS

	COOLING	HEATING
Volts:	m. _____ VOLTS	m. _____ VOLTS
Total Amps (Comp. + Fan):	n. _____ AMPS	n. _____ AMPS
Watts = m. x n. x 0.85	o. _____ WATTS	o. _____ WATTS

6. CAPACITY

Cooling Capacity = HR. - (o. x 3.413) p. _____ btu/hr
 Heating Capacity = HE. + (o. x 3.413) p. _____ btu/hr

7. EFFICIENCY

Cooling EER = p. / o. q. _____ EER
 Heating COP = p. / (o. x 3.413) q. _____ COP

8. SUPERHEAT (S.H.) / SUBCOOLING (S.C.)

	COOLING	HEATING
Suction Pressure:	r. _____ PSI	r. _____ PSI
Suction Saturation Temperature:	s. _____ °F	s. _____ °F
Suction Line Temperature:	t. _____ °F	t. _____ °F
Superheat = t. - s.	u. _____ °F	u. _____ °F
Head Pressure:	v. _____ PSI	v. _____ PSI
High Pressure Saturation Temp.:	w. _____ °F	w. _____ °F
Liquid Line Temperature*:	x. _____ °F	x. _____ °F
Subcooling = w. - x.	y. _____ °F	y. _____ °F

* Note: Liquid line is between the coaxial heat exchanger and the expansion valve in the cooling mode; between the air coil and the expansion valve in the heating mode.


DEALER: _____
 PHONE #: _____ DATE: _____
 PROBLEM: _____
 MODEL #: _____
 SERIAL #: _____



Commercial Solutions

Startup/Troubleshooting Form


COOLING CYCLE ANALYSIS



Heat of Extraction/Rejection = GPM x 500 (485 for water/antifreeze) x ΔT

Note: DO NOT hook up pressure gauges unless there appears to be a performance problem.

HEATING CYCLE ANALYSIS



Preventive Maintenance

Water Coil Maintenance

1. Keep all air out of the water. An open loop system should be checked to ensure that the well head is not allowing air to infiltrate the water line. Lines should always be airtight.
2. Keep the system under pressure at all times. It is recommended in open loop systems that the water control valve be placed in the discharge line to prevent loss of pressure during off cycles. Closed loop systems must have positive static pressure.

NOTE: On open loop systems, if the installation is in an area with a known high mineral content (125 PPM or greater) in the water, it is best to establish with the owner a periodic maintenance schedule so the coil can be checked regularly. Should periodic coil cleaning be necessary, use standard coil cleaning procedures which are compatible with either the cupronickel or copper water lines. Generally, the more water flowing through the unit the less chance for scaling.

Other Maintenance

Filters

Filters must be clean to obtain maximum performance. They should be inspected monthly under normal operating conditions and be replaced when necessary. Units should never be operated without a filter.

Condensate Drain

In areas where airborne bacteria produce a slime in the drain pan, it may be necessary to treat chemically to minimize the problem. The condensate drain can pick up lint and dirt, especially with dirty filters. Inspect twice a year to avoid the possibility of overflow.

Blower Motors

Blower motors are equipped with sealed ball bearings and require no periodic oiling.

Air Coil

The air coil must be cleaned to obtain maximum performance. Check once a year under normal operating conditions and, if dirty, brush or vacuum (with a brush attachment) clean. Care must be taken not to damage the aluminum fins while cleaning.



CAUTION: Fin edges are sharp.

Replacement Procedures

Obtaining Parts

When ordering service or replacement parts, refer to the model number and serial number of the unit as stamped on the serial plate attached to the unit. If replacement parts are required, mention the date of installation of the unit and the date of failure, along with an explanation of the malfunctions and a description of the replacement parts required.

In-Warranty Material Return

Material may not be returned except by permission of authorized warranty personnel. Contact your local distributor for warranty return authorization and assistance.

Notes

Revision Guide

Pages:	Description:	Date:	By:
Misc.	Updated Waterside Economizer, nomenclature, hot gas reheat.	29 Feb. 2020	JM
9, 21	Add weights table, update electrical data	21 Sept. 2018	JM
All	Document Creation	21 Nov., 2017	JM



Manufactured by
WaterFurnace International, Inc.
9000 Conservation Way
Fort Wayne, IN 46809
www.waterfurnace.com



IM2751AU 02/20

Product:	Versatec Variable Speed Series
Type:	Water Source/Geothermal Heat Pump
Size:	10-15 Tons
Document:	Installation Manual