NEED HELP?

Important Tips

A simple solution to most problems

Reboot your receiver. Press the RESET button next to the smart card slot.

Do not unplug your receiver

- If you unplug it you may miss the most recent updates that improve our service.
- The **DIRECTV** receiver is designed to consume very little energy while not in use.

Do not remove the smart card from the receiver

▶ Make sure you receive all the updates from DIRECTV services by keeping the smart card inserted in the receiver. If you are a customer with Pre-payment and want to recharge your card, you must keep your card in the receiver.

How to get your smart card number

- ▶ Press **INFO** for 3 seconds
- You can also press MENU, then SETTINGS & HELP. Select SETTINGS.

About Billing

Billing cycle

- The **DIRECTV** service is billed monthly in advance. So on the first bill, besides the monthly fee you will receive a prorated amount from the date of service activation.
- Prorated Days + full month = Total price.
- The following months you will pay in advance the monthly fee plus any additional channels (Pay Per View, premium channels, etc). If you need help go to **channel 100**.

IF YOU NEED HELP







37484070



37484070 GUIA RAPIDA Advanced INGLES LH27.indd 1-2 1/13/16 12:13 PM

GETTING FAMILIAR WITH YOUR REMOTE CONTROL

SELECT

0FF

EXIT

Press the **GUIDE** button once for the Program Guide. Press it twice for the guide divided into categories.

RECORDS current program or the one highlighted on the Guide. Press it twice to record the entire series.

SELECTS the highlighted item on the screen.

BACK goes back to previous menu.

MUTES the audio of the channel you're watching.

PLAYS AGAIN the previous seven seconds.

REWINDS at increasing speeds.

POWER turns on and off selected devices and the TV.

Displays the MENU.

LIST displays your recorded programs.

EXITS menu and goes back to the channel you were watching.

INFO displays INFORMATION about the program that is playing or that is highlighted in the Program Guide.

PREV goes back to the previously watched channel.

FORWARDS 30 seconds.

PLAYS & PAUSES current program.

FORWARDS at an increasing speed.

Program your Remote Control

- Press **MENU** on the remote control.
- ▶ Select **SETTINGS & HELP.**
- > SETTINGS.

- ▶ Remote Control.
- Follow the onscreen directions to configure the remote to control vour TV.

USING YOUR PROGRAMMING GUIDE

TV Window

Keep watching your program while using the guide.

Fast Forward on

Schedule Guide

hours.

Highlighted Program's Bar

Use the **ARROW** buttons to highlight a program and read the description. To go to a highlighted program, press the **SELECT** button.

Schedule

To see what programs will be broadcasted later, press the **GUIDE** button on the remote control and browse forward with ▶ **RIGHT ARROW**. Use the **LEFT ARROW** to return.



Programming Guide Options Press the button

to sort programs by category, scroll to specific dates and times and change the favorites

INFORMATION CHANNEL

Channel 100 is DIRECTV's **Information channel** where you can:

- ▶ View featured programming.
- Learn more about your remote control, menu and guide and get information about technical assistance, billing, payments and more.
- Login to your account details.

Go to Channel 100 to watch videos and DIRECTV related information.





PROGRAMMING AND SETTINGS

Program search

Easily find what you want to see.

- Press **MENU** on the remote control.
- Select **SEARCH AND BROWSE.**
- ▶ Select **SMART SEARCH.**
- Use **ARROWS** to select letters.





Mini Guide

 \bigoplus

If you want to know what comes next and still watch your program, use the Single Line Mini Programming Guide. You can also enter here a new channel to see what is being broadcasted.

- Press the **ENTER** button on the remote control
- Scroll through the guide, one line at a time.
- Press **SELECT** on the new program if you want to watch that channel.
- Press the **EXIT** button again to close the Guide.



Customize the guide to display your favorite channels:

- Press **MENU** on the remote control.
- Select **SETTINGS AND HELP.**
- Choose FAVORITE CHANNELS.
- Select PERSONAL SETTINGS 1 or 2.
- Follow the directions to create and specify the name of your list.
- To return to the created list, press the **EXIT** button while in the guide.
- Select **CHANGE FAVORITES LIST** and choose the set list.

Parental Control

Control what your children are watching at all times.

Setting restrictions is easy! With Parental Control lock the channels, limit TV time and set a spending limit for purchases on **DIRECTV Cinema** or **Pay Per View**.

- Press **MENU** on the remote control, select **SETTINGS & HELP.**
- Select PARENTAL CONTROL.
- ▶ Press **LOCK** and create your password. Follow the onscreen instructions.

The value of the preset system is unlocked for all categories.



Features available on all DVR (OPTIONAL):

Pause and record live

- ▶ Press the **RECORD** button once to record the program broadcasting. The progress bar and **RECORD** icon appear next to the program title to indicate recording.
- ▶ You may control live programming with the DVR. Press **PAUSE** to stop what you are watching and **PAUSE** again to resume. Press **PLAY** to return to the program where you left it. If you keep pressing **PLAY**, the image will be played in slow motion.

Recording from the guide

- Select the program in the **Program Guide.**
- Press the **RECORD** button once.
- ▶ The **RECORD** icon appears next to the program title to indicate recording.

Recording a series

You may easily program the recording of complete series (subject to availability).

▶ Press the **RECORD** button twice to record the series.

The **RECORD** icon will repeatedly appear next to the program title to indicate that is recording a series and not a single event.

If you have an HD receiver with no recording capabilities you can go to the site directvla.com/record to find out how a 16GB USB can give your receiver recording capabilities and enjoy these features.

CONTROL Plus


Record your favorite programs without having to be at home.

- Sign in to **DIRECTV** with your cell phone or computer.
- ▶ Login to your MiDIRECTV account.
- Look for **PROGRAMMING GUIDE.**
- ▶ Select the program you want to record.
- Program recording.
- ▶ When you get home you will find the ready to view MY PLAYLIST program.









CUSTOMIZATION AND ADJUSTMENT

View and delete recorded programs

Easy view of recorded programs list.

- Press MENU; RECORDINGS.
- Select **PLAYLIST**.

You can also directly access the list.

- Press **LIST** on the remote control.
- Press **SELECT** on the program you want to view.

Use the arrows to move.

Select **PLAY** to start watching the program.

Delete a program from MY PLAYLIST.

- Select the program you want to delete from MY PLAYLIST.
- Press the **RED** button to delete it.
- Confirm the deletion of the program.





You may extend the time of a live recording

Some special events or sports events broadcasted live go beyond the allotted time. To record do the following:

- Select a recording from the guide.
- Select **ADD THIS EXTENSION** to extend the recording time when the option pops up on the screen.

The default setting extends 30 minutes recording time.

This time extension can go from 1 minute to 3 hours.



Subtitles language

You can activate or change the subtitles language while watching live TV.

- Press the INFO button. Select SUBTIT, then available language.
- ▶ You can also press MENU, then SETTINGS & HELP. Select SETTINGS > DISPLAY > SUBTITLES.



DIRECTV Cinema [Channel 400]

Enjoy the best movies from the comfort of your home. Easily browse and manage the recording of a movie.

- Use **ARROWS** to highlight a movie and see a description.
- Press **RECORD** if you want to schedule the recording of a movie.
- To search for a particular movie, press **MENU** and select SMART SEARCH.



DIRECTV on Demand

View or buy content instantly to enjoy at any time.

- Tune to Channel 1000.
- Select the content you wish to see or buy.
- The content will be available on MY PLAYLIST.

For correct operation, the receiver must be connected to the Internet.



Pay Per View

Enjoy two ways to buy movies and events.

- Through MiDIRECTV in directvla.com/cinema.
- Call our **Customer Service** at 672-8111.





