

The background image shows a man in a light blue shirt from the side, looking at a tablet. He is in a factory or industrial setting with various machines and equipment visible in the background. Overlaid on the image are several digital graphics: a '24/7' icon with a circular arrow, a 'NEWS' icon with a person silhouette, a 'Home' icon, and a 'Industry Online Support' text. There are also binary code (0s and 1s) and network-like icons scattered throughout the digital overlay.

SIEMENS

Ingenuity for life

Sending and Receiving SMS Messages via a SCALANCE M Router

SCALANCE M874/ M876, S7-1200/ S7-1500 CPU,
S7-300/ S7-400/IM151-8 PN CPU / STEP 7 V15.1/ V1.1

<https://support.industry.siemens.com/cs/ww/en/view/54361177>

Siemens
Industry
Online
Support



Legal information

Use of application examples

Application examples illustrate the solution of automation tasks through an interaction of several components in the form of text, graphics and/or software modules. The application examples are a free service by Siemens AG and/or a subsidiary of Siemens AG ("Siemens"). They are non-binding and make no claim to completeness or functionality regarding configuration and equipment. The application examples merely offer help with typical tasks; they do not constitute customer-specific solutions. You yourself are responsible for the proper and safe operation of the products in accordance with applicable regulations and must also check the function of the respective application example and customize it for your system.

Siemens grants you the non-exclusive, non-sublicensable and non-transferable right to have the application examples used by technically trained personnel. Any change to the application examples is your responsibility. Sharing the application examples with third parties or copying the application examples or excerpts thereof is permitted only in combination with your own products. The application examples are not required to undergo the customary tests and quality inspections of a chargeable product; they may have functional and performance defects as well as errors. It is your responsibility to use them in such a manner that any malfunctions that may occur do not result in property damage or injury to persons.

Disclaimer of liability

Siemens shall not assume any liability, for any legal reason whatsoever, including, without limitation, liability for the usability, availability, completeness and freedom from defects of the application examples as well as for related information, configuration and performance data and any damage caused thereby. This shall not apply in cases of mandatory liability, for example under the German Product Liability Act, or in cases of intent, gross negligence, or culpable loss of life, bodily injury or damage to health, non-compliance with a guarantee, fraudulent non-disclosure of a defect, or culpable breach of material contractual obligations. Claims for damages arising from a breach of material contractual obligations shall however be limited to the foreseeable damage typical of the type of agreement, unless liability arises from intent or gross negligence or is based on loss of life, bodily injury or damage to health. The foregoing provisions do not imply any change in the burden of proof to your detriment. You shall indemnify Siemens against existing or future claims of third parties in this connection except where Siemens is mandatorily liable.

By using the application examples you acknowledge that Siemens cannot be held liable for any damage beyond the liability provisions described.

Other information

Siemens reserves the right to make changes to the application examples at any time without notice. In case of discrepancies between the suggestions in the application examples and other Siemens publications such as catalogs, the content of the other documentation shall have precedence.

The Siemens terms of use (<https://support.industry.siemens.com>) shall also apply.

Security information

Siemens provides products and solutions with Industrial Security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the Internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place. For additional information on industrial security measures that may be implemented, please visit <https://www.siemens.com/industrialsecurity>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed at: <https://www.siemens.com/industrialsecurity>.

Table of contents

Legal information	2
1 Library Overview.....	4
1.1 General information	5
1.2 Functions	6
1.3 Hardware and software requirements	8
2 SCALANCE M874/M876 Configuration	9
2.1 Entering the SMS service center.....	9
2.2 Configuring the access details for the cellular network	10
2.3 Configuring SMS Relay (Outgoing)	12
2.4 Configuring SMS Relay (Incoming)	13
3 Function Blocks of the "LSmsSR" Library	15
3.1 The "LSmsSR_SndSms" library block	15
3.1.1 Call and parameter interface	15
3.1.2 Format of an SMS message to the SCALANCE M router	16
3.1.3 Description of the "Send SMS message" function	18
3.1.4 "LSmsSR_typeSmsSnd" PLC data type	19
3.2 The "LSmsSR_RcvSms" library block.....	21
3.2.1 Call and parameter interface	21
3.2.2 Format of an SMS message to the SCALANCE M router	22
3.2.3 Description of the "Receive SMS message" function	24
3.2.4 "LSmsSR_typeSmsRcv" PLC data type	25
3.3 Status and error displays.....	26
4 Working with the Library.....	27
4.1 Integrating the library into STEP 7	27
4.2 Integrating the library block into STEP 7	27
4.3 Updating the "LSmsSR" library	32
5 Appendix	33
5.1 Service and support	33
5.2 Links and literature	34
5.3 Change documentation	34

1 Library Overview

This document describes the "LSmsSR" block library. The block library provides you with tested code and clearly defined interfaces. They can be used as a basis for the task you want to implement.

The Library "LSmsSR" contains:

- The library "LSmsSR_S7_300_S7_400_IM151-8" with the function blocks "LSmsSR_SndSms" and "LSmsSR_RcvSms" for sending and receiving an SMS message to/ from SIMATIC S7-300/ S7-400 und IM151-8 PN CPUs using the SCALANCE M874/M876 router
- The library "LSmsSR_S7_1200_S7_1500" with the library blocks "LSmsSR_SndSms" and "LSmsSR_RcvSms" for sending and receiving an SMS message to/ from SIMATIC S7-1200/ S7-1500 CPUs using the SCALANCE M874/M876 router

The main focus of this document is to describe

- the use of the SMS blocks and
- the functionality implemented.

Furthermore, this documentation shows possible fields of application and helps you integrate the library into your STEP 7 project using step-by-step instructions

Validity of the library


- SIMATIC S7-1200 CPUs V4.0 or higher
- SIMATIC S7-1500 CPUs V2.0 or higher
- SIMATIC S7-300 CPUs
 - CPU 31x-2 PN V3.1 or higher
 - CPU 31x-3 PN V3.2 or higher
- S7-400 CPUs with integrated Ethernet port on CPU
- IM151-8 PN CPUs V3.2 or higher
- SCALANCE M874/ M876 Firmware V4.1.1 or higher
- SIMATIC STEP 7 V15.1, Update 2

1.1 General information

The "LSmsSR" library allows you to execute the following functions:

- send customized messages (e.g., messages regarding your plant status) to a GSM-capable mobile device (SMS Relay Outgoing) via SMS using the SCALANCE M874/M876 router
- receive an SMS message from a GSM-capable mobile device (SMS Relay Incoming) using the SCALANCE M874/M876 router

Figure 1-1



1.2 Functions

Overview

The "LSmsSR_SndSms" and "LSmsSR_RcvSms" function blocks of the "LSmsSR_S7_1200_S7_1500" library are required for data exchange between a SIMATIC S7-1200/ S7-1500 CPU and the SCALANCE M874/M876 router.

The "LSmsSR_SndSms" and "LSmsSR_RcvSms" function blocks of the "LSmsSR_S7_300_S7_400_IM151-8" library are required for data exchange between a SIMATIC S7-300/ S7-400/ IM151-8 PN CPU and the SCALANCE M874/M876 router.

Core functions of the function blocks

- Send SMS message ("LSmsSR_SndSms")
Send SMS message to GSM-capable mobile device via SCALANCE M874/M876.
- Receive SMS message ("LSmsSR_RcvSms")
Receive SMS message from GSM-capable mobile device via SCALANCE M874/M876.

A temporary TCP/IP connection to the partner is established for each function:


- "Send SMS message": Active connection establishment and termination by S7 CPU
- "Receive SMS message": Active connection establishment and termination by router.

"Send SMS message" sequences

For the "Send SMS message" function, the S7 CPU is the active partner. To send the SMS message, it establishes a connection to the router. The S7 CPU sends the SMS message to the router via this connection.

When the SMS message has been sent, the connection to the router is terminated.


Figure 1-2



"Receive SMS message" sequences

For the "Receive SMS message" function, the S7 CPU is the passive partner. It passively waits for connection establishment by the router. When the router receives a command SMS message, it establishes a connection to the S7 CPU and sends the message to the CPU. When the SMS message has been received, the connection to the S7 CPU is terminated.

Figure 1-3

**NOTE**

If a connection between the SCALANCE M router and the S7-CPU cannot be established, all SMS messages received by the router will be deleted.

1.3 Hardware and software requirements

Requirements for this library

To be able to use the functionality of the library described here, the following hardware and software requirements must be met:

Hardware

Table 1-1

Component	Article number	Number	Note
SCALANCE M874-3	6GK5874-3AA00-2AA2	1	Alternatively, you can use any variants of the SCALANCE M874 and M876 series.
SIMATIC S7-1200 CPU 1214C DC/DC/DC	6ES7214-1AG40-0XB0	1	Any S7-1200 CPU V4.0 or higher can be used.
SIMATIC S7-1500 CPU 1513-1PN	6ES7513-1AL01-0AB0		Any S7-1500 CPU can be used.
SIMATIC S7-300 CPU 315-2 PN/DP	6ES7315-2EH14-0AB0		Any S7-300 PN-CPU can be used.
SIMATIC S7-400 CPU 414-3 PN/DP	6ES7414-3EM06-0AB0		Any S7-400 PN-CPU can be used.
IM151-8 PN/DP CPU	6ES7151-8AB01-0AB0		(see Validity of the library)
ANTENNE ANT794-4MR	6NH9860-1AA00	1	GSM quad-band and UMTS and LTE (Europe)
SIMATIC Memory Card	6ES7954-8LF01-0AA0	1	Memory Card for the S7 CPU (S7-1200 optional)
bzw.	Bzw.		
SIMATIC Micro Memory Card	6ES7953-8LP20-0AA0		Memory Card for the S7-300 CPU
SIM card		1	

Software

Component	Article number	Number
STEP 7 Professional V15.1, Update 2	1	6ES7822-1AE05-0YA5

2 SCALANCE M874/M876 Configuration

In order for the router to send/receive SMS messages, make the following settings on the device's Web Based Management page:

- Enter the SMS service center
- Configure the access details for the cellular network
- Configure SMS Relay (Outgoing)
- Configure SMS Relay (Incoming)

NOTE

For a more detailed description of how to configure the SCALANCE M874/M876 router using Web Based Management, please refer to the device manual (see [3](#)).

2.1 Entering the SMS service center

To enable the router to send an SMS message, enter the short message service center (SMSC) of your mobile service provider or service provider.

With the router's WBM page ("System > SMS > General"), you can replace the default SMS service center call number by another one. This depends on your contract.

Figure 2-1

Note

The SMSC number is only required for sending SMS messages. If you only want to receive SMS messages, this number is irrelevant.

2.2 Configuring the access details for the cellular network

Access to the cellular network and the mobile telecommunications services requires the following access parameters:

- SIM card PIN
- APN access data

To configure the access detail for the cellular network, proceed as follows

1. Open the router's WBM page.

Note:

In the address bar of the web browser, enter the IP address or the URL of the device.

2. Enter the name "admin" and the associated password.

Figure 2-2

Note:

When you log in for the first time or after "Restore Factory Defaults and Restart", enter

- the default name "admin"
- the default password "admin".

The password needs to be changed after the first logon or after a "Restore Factory Defaults and Restart".

3. Click the "Login" button or confirm your entries with "Enter".
4. In the "SIM" tab of the WBM page of the SCALANCE M874/M876, enable the mobile network interface, "Interfaces > Mobile > SIM".

Figure 2-3

5. Enter the SIM card PIN.

Figure 2-4

Welcome admin
[Logout](#)

► Wizards
► Information
► System
▼ Interfaces
 ► Ethernet
 ► **Mobile**

Mobile Network Interface Settings

SIM | Operator | Connection Check

☒ Enable Mobile Network Interface

PIN: ●●●●

Radio Mode: Auto

Authentication Method: Auto

☒ Allow Data Roaming

Set Values Refresh

Note:

The PIN can be obtained from your mobile service provider.

6. Open the "Operator" tab: "Interfaces > Mobile > Operator". In "APN" enter the name of the mobile network operator. Check the "Manual APN" check box.

Figure 2-5

SIM | Operator | Connection Check

Country List: -
Provider List: -
PLMNID:
Operator Name:
APN:
User Name:
Password:
Password Confirmation:

Select	PLMNID	Operator Name	APN	User Name	Password	Password	Enabled
<input checked="" type="checkbox"/>	Manual						<input type="checkbox"/>
<input type="checkbox"/>	26203	Eplus	internet.eplus.de	guest	*****	*****	<input type="checkbox"/>
<input type="checkbox"/>	26202	Vodafone	web.vodafone.de	guest	*****	*****	<input checked="" type="checkbox"/>
<input type="checkbox"/>	26201	T-Mobile	internet.t-mobile	guest	*****	*****	<input type="checkbox"/>

5 entries.

Create Delete **Set Values** Refresh

Note:

When the "Manual APN" check box is unchecked, the device automatically selects the appropriate access parameters from the list of mobile network operators. By factory default, the access details of four mobile network operators are set and activated. The manually configured APN will be ignored.

NOTE

These access parameters can be obtained from your mobile network operator.

2.3 Configuring SMS Relay (Outgoing)

To enable the router to send an SMS message, make the following settings on the router's WBM page:

1. On the WBM page of the SCALANCE M874/M876, open the " System > SMS" menu.
2. Open the "SMS Relay (Outgoing)" tab.
3. Enable the sending of SMS messages from the local network.

Figure 2-6

The screenshot shows the 'SMS Relay Settings' page with the 'SMS Relay (Outgoing)' tab selected. The 'Enable SMS Relay' checkbox is checked.

4. Enter the user name and password that must be included before the text is sent by SMS.

The screenshot shows the 'SMS Relay Settings' page with the 'SMS Relay (Outgoing)' tab selected. The 'Enable SMS Relay' checkbox is checked. The 'User' field is set to 'admin' and the 'Password' field is masked with dots.

Note:

The user and password must match the values entered in the "username" and "password" "LSmsSR_typeSmsSnd"- parameters.

5. Enter the port on which the SCALANCE M receives the SMS message.

Figure 2-7

The screenshot shows the 'SMS Relay Settings' page with the 'SMS Relay (Outgoing)' tab selected. The 'Enable SMS Relay' checkbox is checked. The 'User' field is set to 'admin' and the 'Password' field is masked with dots. The 'Server Port Number' field is set to 26864. The 'Set Values' and 'Refresh' buttons are visible.

Note:

This port number must match the port address entered in the "remotePort" "LSmsSR_typeSmsSnd"- parameter (here: 26864).

NOTE

At a given time, only one S7 CPU can establish a connection to the SCALANCE M router and send the SMS message.

If multiple CPUs attempt to establish a connection to the SCALANCE M router at a given time, the escalation block is terminated with error:

16#000180A1: The specified connection or the port is already being used ([Chapter 3.3](#)).

2.4 Configuring SMS Relay (Incoming)

To enable the router to receive an SMS message and send it to the application, make the following settings on the router's WBM page:

1. On the WBM page of the SCALANCE M, open the "System > SMS" menu.
2. Open the "SMS Command" tab.
3. Enable the function "Enable Command SMS".
4. Enter all phone numbers from which the router should receive a command SMS message.

Figure 2-8

The screenshot shows the 'SMS Command' configuration page. The 'SMS Command' tab is active. The 'Enable Command SMS' checkbox is checked. The 'Phone Number / Sender Identifier' field is populated with '+4917123456789'.

For these phone numbers, check "Relay".

5. Open the "SMS Relay (Incoming)" tab "System > SMS > SMS Relay (Incoming)". Create a relay connection with
 - a unique name for the relay connection (Connection Name),
 - the recipient's IP address (IP address of the S7-CPU),
 - the port Number.

Figure 2-9

The screenshot shows the 'SMS Relay (Incoming)' configuration page. The 'SMS Relay (Incoming)' tab is active. The 'Connection Name' field is 'Service', the 'IP Address' field is '192.168.1.2', and the 'Port Number' field is '26864'.

Note:

- The connection name is entered in the command SMS message on the cellular device: **RLY Connection Name smsText**. In this way, you define to which recipient (CPU) the message will be relayed.
- The port number must match the port address entered in the "localPort" "LSmsSR_typeRcvSnd"- parameter (here: 26864).

- Enter the username to check the reception of the message. The username is entered in the frame.

Figure 2-10

SMS Relay (Incoming)

General | Event SMS | SMS Command | SMS Relay (Outgoing) | SMS Relay (Incoming)

Connection Name: Service

IP Address: 192.168.1.2

Port Number: 26864

Username: admin

Password:

- Enter the password associated with the username.

Figure 2-11

SMS Relay (Incoming)

General | Event SMS | SMS Command | SMS Relay (Outgoing) | SMS Relay (Incoming)

Connection Name: Service

IP Address: 192.168.1.2

Port Number: 26864

Username: admin

Password:

- Repeat the password to confirm it.

Figure 2-12

SMS Relay (Incoming)

General | Event SMS | SMS Command | SMS Relay (Outgoing) | SMS Relay (Incoming)

Connection Name: Service

IP Address: 192.168.1.2

Port Number: 26864

Username: admin

Password:

Password (Confirmation):

- Use "Create" to create the new relay connection.

Figure 2-13

SMS Relay (Incoming)

General | Event SMS | SMS Command | SMS Relay (Outgoing) | SMS Relay (Incoming)

Connection Name: Service

IP Address: 192.168.1.2

Port Number: 26864

Username: admin

Password:

Password (Confirmation):

Select	Connection Name	IP Address	Port Number	Username
0 entries.				

Create | delete | Refresh

NOTE

For a more detailed description of how to configure the SCALANCE M874/M876 router using Web Based Management, please refer to the device manual (see [3](#)).

3 Function Blocks of the "LSmsSR" Library

Introduction

The Library "LSmsSR" contains the function blocks and the data types for sending and receiving an SMS message to/ from S7-CPU:

- S7-300, S7-400, IM151-8 PN CPUs:
use the function blocks and the data types from the "LSmsSR_S7_300_S7_400_IM151-8" folder
- S7-1200, S7-1500 CPUs:
use the function blocks and the data types from the "LSmsSR_S7_1200_S7_1500" folder.

3.1 The "LSmsSR_SndSms" library block

Introduction

The "LSmsSR_SndSms" FB is used for sending an SMS message via the SCALANCE M routers.

3.1.1 Call and parameter interface

The following figure shows the call interface of the "LSmsSR_SndSms" library block.

Figure 3-1




Table 3-1

	Name	Data type	Description
Input	sndSms	Bool	Starts the send process. Reacts only to a positive edge.
InOut	smsParam	"LSmsSR_typeSmsSnd" PLC data type	Parameters required for sending an SMS message (see Chapter 3.1.4).

Output	done	Bool	Set when sending has successfully completed. Only valid for one cycle. Default value: FALSE.
	busy	Bool	If the "LSmsSR_SndSms" block is busy sending, busy=TRUE. busy is set to FALSE as soon as the above sending has completed successfully or with an error.
	error	Bool	Provides feedback if an error occurs while executing a routine. Only valid for one cycle. Default value: FALSE
	status	Dword	When error = TRUE: Returns the status to narrow down the cause of the error (see Chapter 3.3). Only valid for one cycle.

3.1.2 Format of an SMS message to the SCALANCE M router

The router receives an SMS message from an S7 CPU that is transmitted in a frame via the TCP/IP connection. The frame matches the following format:

```
Username#Password#CommandCode#Seq-Num;Phone number;smsText:
```

1. Username

User name to check the send permission of an SMS message.

Maximum of 10 characters.

Note:

This user name must match the user name entered in WBM.

Figure 3-2

SMS Relay Settings

General | Event SMS | SMS Command | **SMS Relay (Outgoing)** | SMS Relay (Incoming)

☒ Enable SMS Relay

User: admin

Password: •••••

2. Password


Password associated with the user name.

Maximum of 10 characters.

Note:

This password must match the password entered in WBM.

Figure 3-3



3. CommandCode

Command for sending SMS messages from the local network. The default value "105" must not be changed.

4. Seq-Num

The sequence number is used to assign multiple requests at the same time. The function is currently not supported.

5. Phone number

SMS message recipient's phone number with a maximum of 40 characters.

6. smsText

SMS message text with a maximum of 160 characters.

NOTE

For a more detailed description of how to configure the SCALANCE M874/M876 router using Web Based Management, please refer to the device manual (see [3](#)).


3.1.3 Description of the "Send SMS message" function

To send an SMS message, the application has to establish a TCP/IP connection to the router via the Ethernet interface.

Via this TCP/IP connection, the application sends the target parameters and the message text to the router, which then sends the information as an SMS message (see [Chapter 3.1.2](#)).

For TCP/IP communication, the "LSmsSR_SndSms" library block internally uses the "TCON", "TSEND" and "TDISCON" instructions.

Figure 3-4



3.1.4 "LSmsSR_typeSmsSnd" PLC data type

The "LSmsSR_typeSmsSnd" PLC data type contains the parameters for 'Send SMS message'.

To start up the application, this data type is used in a global data block that is linked to the "smsParam" InOut parameter of the function block.

Figure 3-5

S7-300/ S7-400/ IM151-8 PN/DP CPUs			S7-1200/ S7-1500 CPUs		
LSmsSR_typeSmsSnd			LSmsSR_typeSmsSnd		
	Name	Data type		Name	Data type
1	ipAddress	DWord	1	ipAddress	DWord
2	deviceId	Byte	2	interfaceld	HW_ANY
3	remotePort	Int	3	remotePort	UInt
4	username	String[10]	4	username	String[10]
5	password	String[10]	5	password	String[10]
6	telNo	String[40]	6	telNo	String[40]
7	smsText	String[160]	7	smsText	String[160]

1. ipAddress
IP address of the partner (SCALANCE M).
2. deviceId (S7-300/ S7-400/ IM151-8 PN CPUs) (see [4](#))/ interfaceld (S7-1200/ S7-1500 CPUs)
Local_device_id/ Hardware identifier of the local Ethernet interface of the S7-CPU.
3. remotePort
Port number of the remote connection partner (here: of the SCALANCE M874/M876 router).

Note:

This number must match the address entered in WBM (SMS Relay Outgoing).

Figure 3-6

SMS Relay Settings

General | Event SMS | SMS Command | **SMS Relay (Outgoing)** | SMS Relay (Incoming)

☒ Enable SMS Relay

User: admin

Password:

Server Port Number: 26864

Set Values Refresh

4. Username

User name to check the send permission of an SMS message.

Note:

This user name must match the user name entered in WBM (SMS Relay Outgoing).

Figure 3-7

The screenshot shows the 'SMS Relay Settings' window with tabs for 'General', 'Event SMS', 'SMS Command', 'SMS Relay (Outgoing)', and 'SMS Relay (Incoming)'. The 'SMS Relay (Outgoing)' tab is selected. Under the 'Enable SMS Relay' checkbox, the 'User:' field is highlighted with a red box and contains the text 'admin'. The 'Password:' field is visible below it with masked characters.

5. Password

Password associated with the user name.

Note:

This password must match the password entered in WBM (SMS Relay Outgoing).

Figure 3-8

The screenshot shows the 'SMS Relay Settings' window with the 'SMS Relay (Outgoing)' tab selected. The 'User:' field contains 'admin'. The 'Password:' field is highlighted with a red box and contains masked characters. The 'Enable SMS Relay' checkbox is checked.

6. telNo

SMS message recipient's phone number.

7. smsText

SMS message text

3.2 The "LSmsSR_RcvSms" library block

Introduction

The "LSmsSR_RcvSms" FB is used for receiving an SMS message via the SCALANCE M routers.

3.2.1 Call and parameter interface

The following figure and table show the call interface of the "LSmsSR_RcvSms" library block.

Figure 3-9




Table 3-2

Name		Data type	Description
Input	activateRcvSms	Bool	TRUE: Activates the reception of SMS messages. FALSE: Deactivates the reception of SMS messages.
	smsParam	"LSmsSR_typeSmsRcv" PLC data type	Parameters required for receiving an SMS message (see Chapter 3.2.4).
Output	ndr	Bool	Signals that a new SMS message has been received. Only valid for one cycle.
	busy	Bool	If the "LSmsSR_RcvSms" block is busy receiving, busy=TRUE. busy is set to FALSE as soon as the above receiving has completed successfully or with an error.
	error	Bool	Provides feedback if an error occurs while executing a routine. Only valid for one cycle. Default value: FALSE
	status	Dword	When error = TRUE: Returns the status to narrow down the cause of the error (see Chapter 3.3). Only valid for one cycle.

3.2.2 Format of an SMS message to the SCALANCE M router

The router receives an SMS message from a cellular device in the following format:

RLY Connection Name smsText

- RLY: SMS relay command
- Connection Name: variable, according to the configuration
- smsText: SMS message text

NOTE

Only one space is required between the words.

The message is sent to the S7-CPU in a frame via the TCP/IP connection with this connection name in the following format:

Username#Password#CommandCode#Seq-Num;Phone number;smsText:

1. Username

User name to check the reception of the message.

Maximum of 10 characters.

Figure 3-10

SMS Relay (Incoming)

General	Event SMS	SMS Command	SMS Relay (Outgoing)	SMS Relay (Incoming)
<p>Connection Name: Service</p> <p>IP Address: 192.168.1.2</p> <p>Port Number: 26864</p> <p>Username: admin</p>				

2. Password

Password associated with the user name.

Maximum of 10 characters.

Figure 3-11

SMS Relay (Incoming)

General	Event SMS	SMS Command	SMS Relay (Outgoing)	SMS Relay (Incoming)
<p>Connection Name: Service</p> <p>IP Address: 192.168.1.2</p> <p>Port Number: 26864</p> <p>Password: *****</p>				

3. CommandCode

4. Command for receiving SMS messages from the local network. The default value "105" must not be changed.

5. Seq-Num

The sequence number is used to assign multiple requests at the same time. The function is currently not supported.

6. Connection Name
SMS message recipient's connection name with a maximum of 40 characters.
7. Phone number
SMS message sender's phone number.
8. smsText
SMS message text with a maximum of 160 characters.


NOTE

For a more detailed description of how to configure the SCALANCE M874/M876 router using Web Based Management, please refer to the device manual (see [3](#)).

3.2.3 Description of the "Receive SMS message" function

Applications can also receive SMS messages via the router's Ethernet interface. To do this, the router must establish a TCP/IP connection to the application on the Ethernet interface. The router receives a command SMS message (**RLY Connection Name smsText**) and sends the received message (see [Chapter 3.2.2](#)) to the application. For TCP/IP communication, the "LSmsSR_RcvSms" library block internally uses the "TCON", "TRCV" instructions.

Figure 3-12



3.2.4 "LSmsSR_typeSmsRcv" PLC data type

The "LSmsSR_typeSmsRcv" PLC data type contains the receive data.

To start up the application, this data type is used in a global data block that is linked to the "smsParam" InOut parameter of the function block.

Figure 3-13

S7-300/ S7-400/ IM151-8 PN/DP CPUs			S7-1200/ S7-1500 CPUs		
LSmsSR_typeSmsRcv			LSmsSR_typeSmsRcv		
	Name	Data type		Name	Data type
1	deviceId	Byte	1	interfacId	HW_ANY
2	localPort	Int	2	localPort	UInt
3	rcvTelNo	String[40]	3	rcvTelNo	String[40]
4	rcvMessage	String[160]	4	rcvMessage	String[160]

1. deviceId (S7-300/ S7-400/ IM151-8 PN CPUs) (see [4](#)) / interfacId (S7-1200/ S7-1500 CPUs)

Local_device_id/ Hardware identifier of the local Ethernet interface of the S7-CPU.

2. localPort

Port number of the local connection partner (here: of the S7-CPU).

Note:

This number must match the address entered in WBM (SMS Relay Incoming).

Figure 3-14

SMS Relay (Incoming)				
General	Event SMS	SMS Command	SMS Relay (Outgoing)	SMS Relay (Incoming)
Connection Name: Service IP Address: 192.168.1.2 Port Number: 26864 Username: admin				

3. rcvTelNo
SMS message sender's phone number.
4. rcvMessage
SMS message text received.

3.3 Status and error displays

For error diagnostics, evaluate the "LSmsSR_SndSms" and "LSmsSR_RcvSms" "status" output. By reading the "status" output of the function block, you are provided with information on logical errors and error messages that may occur during the communication between the controller and the router.

The error message structure is such that the first word indicates the block that triggered this message. For example, error message 16#000180A3 was triggered by "TCON" instruction. The following tables provide a list of possible error messages.

"LSmsSR_SndSms" errors

Figure 3-15

Status	Meaning	Remedy / notes
16#0001xyzx	"TCON" error message (active)	For a description of the communication errors, please refer to the STEP 7 Online Help.
16#0011xyzx	"TSEND" error message	
16#0111xyzx	"TDISCON" error message	
16#00008101	Previous job not yet complete. (You have started a new send operation, although busy was still active.)	
16#00008102	Watchdog timer alarm.	Make sure that <ul style="list-style-type: none"> the IP address entered in the "ipAddress" parameter is identical to the IP address of the SCALANCE M874/M876. the S7-1200/S7-1500 CPU is physically connected to the SCALANCE M874/M876.
16#00008103	"smsText" contains the forbidden character ".".	Change "smsText"
16#00008104	"smsText" contains the forbidden character ",".	
16#00008105	"smsText" contains the forbidden character "#".	
16#00008106	"telNo" contains the forbidden character "x".	Change "telNo"

"LSmsSR_RcvSms" errors

Table 3-3

Status	Meaning	Remedy / notes
16#0010xyzx	"TCON" error message (passive)	For a description of the communication errors, please refer to the STEP 7 Online Help.
16#0110xyzx	"TRCV" error message	

4 Working with the Library

This chapter consists of instructions for integrating the "LSmsSR" library into your STEP 7 V15.1 project and instructions for using the library block.

4.1 Integrating the library into STEP 7

The following table shows the steps required to integrate the "LSmsSR" library into your STEP 7 V15.1 project. After integrating the library, you can use the blocks of the "LSmsSR" library.

NOTE The following section assumes that a STEP 7 project exists.


1. The library is available on the HTML page from which you downloaded this document ([\2](#)). Save the "54361177_SMS_SCALANCE_M_LIB_V15_V11.zip" library to your hard drive.
2. Unzip the library.

4.2 Integrating the library block into STEP 7

The following table shows the steps required to integrate the elements of the "LSmsSR" library into your STEP 7 V15.1 project. After integrating these elements, you can use the blocks of library.

1. Open the existing STEP 7 V15.1 project.
2. In the toolbar of the "Global libraries" palette, click "Open global libraries" or, in the "Options" menu, select "Global libraries > Open global library".


Figure 4-1



3. The "Open global library" dialog box opens.


4. Select the following global library: "LSmsSR.al15_1"

Figure 4-2



5. The "LSmsSR" library opens.
6. Use drag and drop to move the "LSmsSR_SndSms" and "LSmsSR_RcvSms" function blocks to the "Program blocks" folder of the S7-CPU.

Figure 4-3



7. The "LSmsSR_typeSmsSnd" and "LSmsSR_typeSmsRcv" PLC data types are automatically copied to the "PLC data types" folder.

8. Create a new global data block with the following parameters:
 - the "LSmsSR_typeSmsSnd" or "LSmsSR_typeSmsRcv" PLC data type
 - the input parameters for the call in OB1
 - the output parameters for the call in OB1

Figure 4-4

SmsData					
	Name	Data type	Offset	Start value	Retain
1	Static				
2	SmsSend	"LSmsSR_typeSmsSnd"	0.0		
3	SmsRcv	"LSmsSR_typeSmsRcv"	236.0		

9. Assign values to all parameters necessary for sending/receiving (see Chapter 3.1.4 / Chapter 3.2.4):
 - ipAddress
 - interfaceld
 - remotePort
 - username
 - password
 - telNo
 - smsText


Figure 4-5

SmsData					
	Name	Data type	Offset	Start value	
1	Static				
2	SmsSend	"LSmsSR_typeSmsSnd"	0.0		
3	ipAddress	DWord	0.0	16#c0a80101	
4	deviceld	Byte	4.0	16#2	
5	remotePort	Int	6.0	26864	
6	username	String[10]	8.0	'admin'	
7	password	String[10]	20.0	'admin'	
8	telNo	String[40]	32.0	'+49123456789'	
9	smsText	String[160]	74.0	'Alarm'	
10	SmsRcv	"LSmsSR_typeSmsRcv"	236.0		
11	deviceld	Byte	236.0	16#2	
12	localPort	Int	238.0	26864	
13	rcvTelNo	String[40]	240.0	"	
14	rcvMessage	String[160]	282.0	"	

10. Save and compile the newly created data block.


11. In the "Program blocks" folder of your device, open the OB1 organization block and use drag and drop to move the "LSmsSR_SndSms" or "LSmsSR_RcvSms" function block to any network.

Figure 4-6




12. Specify the name of the associated instance data block. Click "OK" to exit the dialog box.

Figure 4-7




13. Assign values to all necessary parameters. Use values from the newly created data block.

Figure 4-8




14. Compile the hardware and software of the S7 station: In the Project tree, right-click the device and select the "Compile > Hardware and software (only changes)" menu.

Figure 4-9



15. Download the new project to your controller.




4.3 Updating the "LSmsSR" library

The following guide shows you


- how to check whether the library is up to date and
 - how to integrate a newer version of the "LSmsSR" library into your
 - STEP 7 project.
1. Open TIA Portal and compare the current version number of each element of the library with the latest version from the Industry Online Support portal.
 2. In the Project tree, right-click the blocks of the library. In the context menu, select the "Properties" option.
 3. In the "Properties" window that is displayed, select the "Information" tab.

Figure 4-10




4. If you want to update the library, integrate the latest library as described in [Chapter 4.2](#).
5. Open the new library as described in [Chapter 4.2](#), Steps 1 through 3.
6. In the Project tree, right-click the blocks of the library.
Update the elements of the project
"LSmsSR" > Update types > Project".

Figure 4-11



7. The blocks have been updated. In the toolbar in OB1, click "Update inconsistent block calls" to update or regenerate the instance DBs.

Figure 4-12



8. When you have inserted the updated blocks into your STEP 7 project, compile the software and save the project.
9. The library update is now complete.

5 Appendix

5.1 Service and support

Industry Online Support

Do you have any questions or need assistance?

Siemens Industry Online Support offers round the clock access to our entire service and support know-how and portfolio.

The Industry Online Support is the central address for information about our products, solutions and services.

Product information, manuals, downloads, FAQs, application examples and videos – all information is accessible with just a few mouse clicks:

support.industry.siemens.com

Technical Support

The Technical Support of Siemens Industry provides you fast and competent support regarding all technical queries with numerous tailor-made offers – ranging from basic support to individual support contracts. Please send queries to Technical Support via Web form:

www.siemens.com/industry/supportrequest

SITRAIN – Training for Industry

We support you with our globally available training courses for industry with practical experience, innovative learning methods and a concept that's tailored to the customer's specific needs.

For more information on our offered trainings and courses, as well as their locations and dates, refer to our web page:

www.siemens.com/sitrain

Service offer

Our range of services includes the following:

- Plant data services
- Spare parts services
- Repair services
- On-site and maintenance services
- Retrofitting and modernization services
- Service programs and contracts

You can find detailed information on our range of services in the service catalog web page:

support.industry.siemens.com/cs/sc

Industry Online Support app

You will receive optimum support wherever you are with the "Siemens Industry Online Support" app. The app is available for Apple iOS, Android and Windows Phone:

support.industry.siemens.com/cs/ww/en/sc/2067

5.2 Links and literature

Table 5-1

No.	Topic
\1\	Siemens Industry Online Support https://support.industry.siemens.com
\2\	Link to this entry page of this application example https://support.industry.siemens.com/cs/ww/en/view/54361177
\3\	SIMATIC NET: Industrial Remote Communication Remote Networks SCALANCE M-800 Web Based Management https://support.industry.siemens.com/cs/ww/en/view/109751635
\4\	Which "local_device_id" do you parameterize in order to establish a connection with FB65 "TCON" for Open User Communication (OUC) via Industrial Ethernet? https://support.industry.siemens.com/cs/ww/en/view/51339682

5.3 Change documentation

Table 5-2

Version	Date	Modifications
V1.0	06/2016	First version
V1.1	09/2019	Complete revision.