



Cisco NX-OS Licensing Guide

First Published: 2011-11-23 **Last Modified:** 2021-09-29

Americas Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA http://www.cisco.com Tel: 408 526-4000

800 553-NETS (6387) Fax: 408 527-0883 THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: https://www.cisco.com/c/en/us/about/legal/trademarks.html. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2011-2022 Cisco Systems, Inc. All rights reserved.



CONTENTS

CHAPTER 1 Licensing Cisco NX-OS Software Features 1

Information About Licensing 1

Tier-Based Licenses 3

Cisco Nexus 9000 Series Tier-Based Licenses 7

Cisco Nexus 3000 Series Tier-Based Licenses 12

Feature-Based Licenses 14

Module-based Licenses 30

Bundle/Chassis-based Licenses 31

Honor Mode Licensing 33

Licensing Terminology 33

Licensing Virtualization Support 34

Licensing High Availability 34

License Installation 35

Obtaining a Factory-Installed License 35

Performing a Manual Installation 36

Obtaining the License Key File 36

Installing the License Key File 38

Backing Up Licenses 40

Backing Up the License Key File 41

Backing Up an Installed License 41

Enabling Licensed Features 41

Identifying License Features in Use 41

Uninstalling Licenses 43

Updating Licenses 44

Configuring the Grace Period Feature 46

Grace Period Alerts 46

CHAPTER 2

Enabling the License Grace Period 49
Disabling the License Grace Period 49
Associating a License with a Module 50
License Transfers Between Devices 51
Verifying the License Configuration 51
Additional References 52
Release History for Licensing 52
Smart Software Licensing for Cisco Nexus 7000 Series Switches 59
Finding Feature Information 59
Information About Smart Software Licensing 60
Smart Software Licensing Overview 60
Traditional Licensing Overview 60
Comparing Licensing Models 60
Guidelines and Limitations for Smart Software Licensing 61
Smart Accounts and Virtual Accounts 61
Smart Software Manager Overview 61
Smart Call Home Overview 62
Smart Software Manager Satellite 62
Requesting a Smart Account 63
Adding a User to a Smart Account 64
Converting a Traditional License to a Smart License 64
Converting a Traditional License to a Smart License—CLI Version 65
Configuring Smart Software Licensing 66
Configuring a DNS Client 66
Configuring a VRF To Send a Message Using HTTP 67
Enabling Smart Software Licensing 67
Disabling Smart Software Licensing 67
Registering a Device 68
Renewing Device Registration 68
Renewing Device Authorization 68
Unregistering a Device 68
Configuring Smart Call Home for Smart Software Licensing 69
Viewing a Smart Call Home Profile 69

```
Enabling Smart Call Home Data Privacy 69
      Verifying Smart Software Licensing 69
     Configuration Examples for Smart Software Licensing 70
      Verification Examples for Smart Software Licensing 70
     Use Cases for Smart Software Licensing 74
      Additional References for Smart Software Licensing 76
      Feature History for Smart Software Licensing 77
Smart Software Licensing for Cisco Nexus 3000 and 9000 Series Switches 79
     Smart Software Licensing Overview 79
        Smart Software Manager 80
        Smart Software Manager On-Prem 80
        Smart Accounts and Virtual Accounts 80
        Smart License Workflow and States 81
        Smart Call Home Overview 82
     Traditional Licensing Overview 83
      Comparing Licensing Models 83
      Guidelines and Limitations for Smart Software Licensing 84
     Setting Up Smart Accounts 84
        Requesting a Smart Account 85
        Adding a User to a Smart Account 86
     Converting a Traditional License to a Smart License 86
     Converting a Traditional License to a Smart License—DLC (Device Led Conversion) 87
     Configuring Smart Call Home for Smart Software Licensing 88
        Configuring a DNS Client 88
        Configuring a VRF To Send a Message Using HTTP
        Viewing a Smart Call Home Profile 89
     Configuring Smart Software Licensing 90
        Enabling or Disabling Smart Software Licensing
        Registering a Device 90
        Renewing Device Registration and Authorization
      Verifying Smart Software Licensing 91
      Verification Examples for Smart Software Licensing
      Configuration Examples for Smart Software Licensing 95
```

CHAPTER 3

Use Cases for Smart Software Licensing 96

Additional References for Smart Software Licensing 98

Feature History for Smart Software Licensing 98



Licensing Cisco NX-OS Software Features

This chapter contains information related to feature and module-based licensing for Cisco Nexus switches that run Cisco NX-OS software.



Note

Cisco Data Center Network Manager (DCNM) is a GUI that you can use to manage your data center infrastructure. See the Cisco DCNM Installation and Licensing Guide for details about installing and licensing Cisco DCNM.

- Information About Licensing, on page 1
- Licensing Terminology, on page 33
- Licensing Virtualization Support, on page 34
- Licensing High Availability, on page 34
- License Installation, on page 35
- Obtaining the License Key File, on page 36
- Installing the License Key File, on page 38
- Backing Up Licenses, on page 40
- Enabling Licensed Features, on page 41
- Identifying License Features in Use, on page 41
- Uninstalling Licenses, on page 43
- Updating Licenses, on page 44
- Configuring the Grace Period Feature, on page 46
- Associating a License with a Module, on page 50
- License Transfers Between Devices, on page 51
- Verifying the License Configuration, on page 51
- Additional References, on page 52
- Release History for Licensing, on page 52

Information About Licensing

Licensing allows you to access specified premium features on your device after you install the appropriate license for that feature.

The following table compares licensing support between Cisco Nexus 5000/7000 Series switches and Cisco Nexus 3000/9000 Series switches.

Table 1: Licensing Support for Cisco NX-OS Switches

Licensing Feature	Cisco Nexus 5000 Series Switches	Cisco Nexus 7000 Series Switches	Cisco Nexus 3000 and 9000 Series Switches
Enforcement	Enforced	Enforced, on Cisco NX-OS Release 8.3(2) and earlier 8.3(x) releases. From Cisco NX-OS Release 8.4(1), Honor-based licensing is introduced on Cisco Nexus 7000 Series switches.	Honor-based ¹
		Enforced, on Cisco NX-OS Release 8.2(3) and earlier 8.x releases. From Cisco NX-OS Release 8.2(4), Honor-based licensing is introduced on Cisco Nexus 7000 Series switches.	
Perpetual	Supported	Supported	Supported
Term			
Subscription	Not supported	From Cisco NX-OS Release 8.2(1), subscription-based licensing is available on Cisco Nexus 7000 Series switches.	Supported
Evaluation ²	Supported	Supported	Not supported

Licensing Feature	Cisco Nexus 5000 Series	Cisco Nexus 7000 Series	Cisco Nexus 3000 and
	Switches	Switches	9000 Series Switches
Grace period	Supported	Supported, on Cisco NX-OS Release 8.3(2) and earlier 8.3(x) releases. From Cisco NX-OS Release 8.4(1), Grace period is not supported on Cisco Nexus 7000 Series switches. Supported, on Cisco NX-OS Release 8.2(3) and earlier 8.x releases. From Cisco NX-OS Release 8.2(4), Grace period is not supported on Cisco Nexus 7000 Series switches.	Not applicable

- The following warning might display when installing the honor-based license. Please ignore this warning and continue with the install. !!!!!! WARNING: 'LAN_ENTERPRISE_SERVICES_PKG' LICENSE NOT FOUND ON THE SYSTEM !!!!!!. You have tried to enable a licensed feature [ospf] without installing the 'LAN ENTERPRISE SERVICES PKG' license, which has not been found on the system.
- ² Temporary licenses with an expiry date are available for evaluation and lab use purposes. They are strictly not allowed to be used in production. Please use a permanent or subscription license that has been purchased through Cisco for production purposes. Evaluation license is supported with Smart Software License but not with Traditional license in Cisco Nexus 9000 series switches.

Tier-Based Licenses

Tier-based licensing is available for some Cisco Nexus 3000 and 9000 Series switches. This licensing model applies to both Cisco Application Centric Infrastructure (ACI) and NX-OS standalone architectures where these switches can be deployed. For Cisco Nexus platforms that do not support tier-based licensing, we offer only the NX-OS standalone feature-based licenses. For these switches, see Feature-Based Licenses, on page 14.



Note

The Release History for Licensing, on page 52 section lists the platforms that support tier-based licensing and the release in which support was introduced.

Tier-based licensing offers the following benefits:

- Consistency across ACI and NX-OS licensing (for Cisco Nexus 9000 Series switches).
- The simplicity of being able to purchase a group of feature licenses as packages: Essentials, Advantage, Premier.
- Subscription-based or perpetual licenses

 A subscription-based license enables you to purchase a license for a specific period of time based on your requirement. A subscription-based license is offered as an Essentials, Advantage, or Premier license package.

Purchasing a subscription-based license gives you the opportunity to adjust/upgrade the terms of the license (such as moving from Advantage to Premier) at the time of license renewal.

• A perpetual license enables you to make a one-time purchase of a license that does not expire. A perpetual license is offered as an Essentials or Advantage license package but is not available as a Premium license.



Note

Several add-on licenses are also available, which can be added to either tier or purchased independently.

Along with the infographic below, the Cisco Nexus 9000 and 3000 Series NX-OS Switch License Navigator (https://www.cisco.com/c/dam/en/us/td/docs/Website/datacenter/license/index.html) is available to help you select the appropriate license for your needs.

Figure 1: Cisco Nexus 9000 and 3000 Series NX-OS Switch License Navigator Infographic

For the best value, Cisco recommends option #1, which supports ACI + NX-OS + Day 2 Ops.




Table 2: NX-OS License Package features Included in Tier-Based Licenses for Cisco Nexus 9000 and 3000 Series Switches

License Package	Features Included*
Essentials	• Fabric management features (DCNM LAN ³ and PTP)
	• Fabric services features (iCAM, ITD, IP fabric for media non-blocking multicast, and smart channel)
	• Routing and switching features (BGP, EIGRP, GRE, IS-IS, MSDP, OSPF, PBR, PIM, SSM, VRF, VXLAN BGP EVPN, SRv6 (no EVPN), and SR-MPLS (no EVPN))
	• Telemetry features (NetFlow, FT, FTE, SSX)
Advantage	All features included in the Essentials package plus the following features:
	Advanced fabric features (Pervasive Load Balancing and Tenant Routed Multicast)
	• DCI overlay features (Inter AS option B, segment routing SR-MPLS, Layer 3 EVPN over segment routing SRv6, MPLS Layer 3 VPN, and VXLAN EVPN Multi-Site)
	• Fabric services features (Enhanced PBR (EPBR))
	RTP Flow Monitoring (Media Flow Analytics), PTP Monitoring, Multicast NAT
Premier	All features included in the Essentials and Advantage packages plus support for the Cisco Network Insights Advisor, Cisco Network Insights for Resources, and Cisco Network Assurance Engine.

³ DCNM LAN Adv license enabled on the Nexus device through DCNM server or via hidden cli (license dcnm-lan enable) is not persistent across ASCII reload on device. DCNM server has to do a rediscovery to enable the license again.

Table 3: NX-OS License Package features Included in Add-On Licenses for Cisco Nexus 9000 and 3000 Series Switches

Security add-on license	MACsec, Secure VXLAN EVPN Multi-Site using CloudSec ⁴
Storage add-on license	FCoE, FC, and DCNM SAN
SyncE add-on license	Synchronous Ethernet (SyncE) support
NDB add-on license	Nexus Data Broker

⁴ Beginning with Cisco Nexus Release 9.3(5), Secure VXLAN EVPN Multi-Site using CloudSec is supported only on Cisco Nexus 9300-FX2 platform switches,



Note

Feature support varies by platform and release. See the Nexus Switch Platform Support Matrix to determine which features are supported for your platform.

The following options are available when you order an Essentials or Advantage package:

- Cisco Nexus 9000 Series switches
 - Cisco ONE subscription license for DCN (ACI+NX-OS) for 3, 5, or 7 years
 - Non-Cisco ONE perpetual license for DCN (ACI+NX-OS)
 - Non-Cisco ONE perpetual license for NX-OS
 - NX-OS upgrade licenses
- Cisco Nexus 3000 Series switches
 - Cisco ONE subscription license for NX-OS for 3, 5, or 7 years
 - Non-Cisco ONE perpetual license for NX-OS

If you install a subscription-based license, you will be notified 90 days before your licensing contract expires.



Note

If the Essentials license expires after the Advantage license is installed, the following message appears: "LIC_LICENSE_EXPIRED: License expired for feature NXOS_ESSENTIALS_XF. Feature will run in honor mode." You can ignore this message because the license is no longer in use.

Cisco Nexus 9000 Series Tier-Based Licenses

The DCN (ACI+NX-OS) Essentials, Advantage, and add-on licenses are supported for Cisco Nexus 9300 platform switches beginning with Cisco NX-OS Release 9.2(3). Beginning with Cisco NX-OS Release 7.0(3)I7(7) and 9.3(2), the ACI Premier licenses are supported for Cisco Nexus 9300 platform switches. These licenses support license migration from Cisco NX-OS to ACI. Any attempt to install these licenses for a prior release will fail.

When you downgrade from Cisco NX-OS Release 9.2(3) to an earlier release, the features that use the DCN (ACI+NX-OS) Essentials, Advantage, and add-on licenses continue to work in honor mode in the downgraded version. In addition, the output of the **show license usage** command continues to include entries for these unsupported licenses.

The -XM licenses apply to modular switches; the -GF licenses apply to switches with less than 3.6 Tbps; the -XF licenses apply to switches with more than 3.6 Tbps and less than 6.4 Tbps; and the -XF2 licenses apply to switches with more than 6.4 Tbps.

Table 4: License Categories and Associated Supported Platforms (Cisco Nexus 9000 Series Switches)

1G Fixed Platform (GF) License	10G/25G/40G/100G Fixed Platform (XF) License	10G/25G/40G/100G Fixed Platform (XF2) License	4-Slot Modular Platform License	8-Slot, 16-Slot Modular Platform License
N9K-C9348GC-FXP	N9K-C93180YC-EX	N9K-C9364C	N9K-C9504	N9K-C9508
	N9K-C93108TC-EX	N9K-C9316D-GX		N9K-C9516
	N9K-C93180LC-EX	N9K-C93600CD-GX		
	N9K-C93180YC-FX	N9K-C9364C-GX		
	N9K-C93108TC-FX			
	N9K-C93240YC-FX2			
	N9K-C93216TC-FX2			
	N9K-C93360YC-FX2			
	N9K-C9336C-FX2			
	N9K-C93180YC-EX-24			
	N9K-C93108TC-EX-24			
	N9K-C93180YC-FX-24			
	N9K-C93108TC-FX-24			

Table 5: PIDs for Cisco ONE Subscription Tier-Based Licenses for DCN (ACI+NX-OS) (Cisco Nexus 9000 Series Switches - Fixed Platforms)

License	1G Fixed Platforms (GF)	10G/25G/40G/100G Fixed Platforms (XF)	Cisco Nexus 9364C and 9300-GX Platforms (XF2)
Essentials package	C1E1TN9300GF-3Y	C1E1TN9300XF-3Y	C1E1TN9300XF2-3Y
	C1E1TN9300GF-5Y	C1E1TN9300XF-5Y	C1E1TN9300XF2-5Y
	C1E1TN9300GF-7Y	C1E1TN9300XF-7Y	C1E1TN9300XF2-7Y
Advantage package	C1A1TN9300GF-3Y	C1A1TN9300XF-3Y	C1A1TN9300XF2-3Y
	C1A1TN9300GF-5Y	C1A1TN9300XF-5Y	C1A1TN9300XF2-5Y
	C1A1TN9300GF-7Y	C1A1TN9300XF-7Y	C1A1TN9300XF2-7Y
Premier package ⁵	C1P1TN9300GF-3Y	C1P1TN9300XF-3Y	C1P1TN9300XF2-3Y
	C1P1TN9300GF-5Y	C1P1TN9300XF-5Y	C1P1TN9300XF2-5Y
	C1P1TN9300GF-7Y	C1P1TN9300XF-7Y	C1P1TN9300XF2-7Y
Add-On Licenses			

License	1G Fixed Platforms (GF)	10G/25G/40G/100G Fixed Platforms (XF)	Cisco Nexus 9364C and 9300-GX Platforms (XF2)
NDB	C1-N9K-NDB-3Y	C1-N9K-NDB-3Y	C1-N9K-NDB-3Y
	C1-N9K-NDB-5Y	C1-N9K-NDB-5Y	C1-N9K-NDB-5Y
	C1-N9K-NDB-7Y	C1-N9K-NDB-7Y	<u>6</u>
			C1-N9K-NDB-7Y
Security	C1-N9K-SEC-XF-3Y	C1-N9K-SEC-XF-3Y	C1-N9K-SEC-XF-3Y
	C1-N9K-SEC-XF-5Y	C1-N9K-SEC-XF-5Y	C1-N9K-SEC-XF-5Y
	C1-N9K-SEC-XF-7Y	C1-N9K-SEC-XF-7Y	C1-N9K-SEC-XF-7Y
Storage	Not supported	C1-N9K-STRG-XF-3Y	Not supported
		C1-N9K-STRG-XF-5Y	
		C1-N9K-STRG-XF-7Y	

The ACI Premier license package includes the ACI Essentials and ACI Advantage license packages.
 The Cisco Nexus 9300-GX switches do not support NDB.

Table 6: PIDs for Cisco ONE Subscription Tier-Based Licenses for DCN (ACI+NX-OS) (Cisco Nexus 9000 Series Switches - Modular Platforms)

License	4-Slot Modular Platforms	8- to 16-Slot Modular Platforms
Essentials package	C1E1TN9500M4-3Y	C1E1TN9500M816-3Y
	C1E1TN9500M4-5Y	C1E1TN9500M816-5Y
	C1E1TN9500M4-7Y	C1E1TN9500M816-7Y
Advantage package	C1A1TN9500M4-3Y	C1A1TN9500M816-3Y
	C1A1TN9500M4-5Y	C1A1TN9500M816-5Y
	C1A1TN9500M4-7Y	C1A1TN9500M816-7Y
Premier package ⁷	C1P1TN9500M4-3Y	C1P1TN9500M816-3Y
	C1P1TN9500M4-5Y	C1P1TN9500M816-5Y
	8	2
	C1P1TN9500M4-7Y	C1P1TN9500M816-7Y
Add-On Licenses		
NDB	C1-N9K-NDB-M4-3Y	C1-N9K-NDB-M816-3Y
	C1-N9K-NDB-M4-5Y	C1-N9K-NDB-M816-5Y
	C1-N9K-NDB-M4-7Y	C1-N9K-NDB-M816-7Y

License	4-Slot Modular Platforms	8- to 16-Slot Modular Platforms
Security	C1-N9K-SEC-M-3Y	C1-N9K-SEC-M-3Y
	C1-N9K-SEC-M-5Y	C1-N9K-SEC-M-5Y
	C1-N9K-SEC-M-7Y	C1-N9K-SEC-M-7Y
Storage	C1-N9K-STRG-M-3Y	C1-N9K-STRG-M-3Y
	C1-N9K-STRG-M-5Y	C1-N9K-STRG-M-5Y
	C1-N9K-STRG-M-7Y	C1-N9K-STRG-M-7Y

⁷ The ACI Premier license package includes the ACI Essentials and ACI Advantage license packages.

Table 7: PIDs for Non-Cisco ONE Perpetual Tier-Based Licenses for DCN (ACI+NX-OS) (Cisco Nexus 9000 Series Switches)

License	1G Fixed Platforms (GF)	10G/25G/40G/100G Fixed Platforms (XF)	Cisco Nexus 9364C and 9300-GX Platforms (XF2) ¹⁰¹¹		
Essentials package	ACI-ES-GF	ACI-ES-XF	ACI-ES-XF2		
Advantage package	ACI-AD-GF	ACI-AD-XF	ACI-AD-XF2		
Add-On Licenses	Add-On Licenses				
Security	Not supported	ACI-SEC-XF	ACI-SEC-XF2		
Storage (FC NPV, FCoE NPV, and SAN switching)	Not supported	ACI-STRG	Not supported		

The licenses for the Cisco Nexus 9364C switch are supported beginning with Cisco NX-OS Release 7.0(3)17(6). The licenses for the Cisco Nexus 9300-GX switches are supported beginning with Cisco NX-OS Release 9.3(3).

This license includes DCNM SAN Advanced and is available for Cisco Nexus 93180YC-FX and 93360YC-FX2 platform switches.



Note

Cisco NX-OS Release 9.2(3) does not support ACI licenses for the Cisco Nexus 9336C-FX2, 93108TC-FX, 93180YC-FX, and 93240YC-FX2 platform switches.

The NX-OS Essentials, Advantage, and add-on licenses are supported for Cisco Nexus 9000 Series switches beginning with Cisco NX-OS Release 7.0(3)I7(3).

⁸ NAE support available in future NX-OS releases.

⁹ NAE support available in future NX-OS releases.

Beginning with Cisco NX-OS Releases 7.0(3)I7(6) and 9.3(1), the -XF2 Essentials and Advantage licenses have priority over the -XF licenses. If an -XF license is installed and features are checked out from this license and then you later install the -XF2 license, the -XF license shows as unused (in the output of the **show license usage** command), and the features become checked out from the -XF2 license. The Advantage licenses continue to have priority over the Essentials licenses.

Table 8: PIDs for Non-Cisco ONE Perpetual Tier-Based Licenses for NX-OS (Cisco Nexus 9000 Series Switches - Fixed Platforms)

License	1G Fixed Platforms (GF)	10G/25G/40G/100G Fixed Platforms (XF)	Cisco Nexus 9364C and 9300-GX Platforms (XF2) ¹³¹⁴		
Essentials package	NXOS-ES-GF	NXOS-ES-XF	NXOS-ES-XF2		
Advantage package	NXOS-AD-GF	NXOS-AD-XF	NXOS-AD-XF2		
Add-On Licenses	Add-On Licenses				
NDB	NXOS-NDB	NXOS-NDB	NXOS-NDB ¹⁵		
Security	ACI-SEC-XF	ACI-SEC-XF	ACI-SEC-XF		
Storage	Not supported	ACI-STRG	Not supported		

The licenses for the Cisco Nexus 9364C switch are supported beginning with Cisco NX-OS Release 7.0(3)I7(6). The licenses for the Cisco Nexus 9300-GX switches are supported beginning with Cisco NX-OS Release 9.3(3).

Table 9: PIDs for Non-Cisco ONE Perpetual Tier-Based Licenses for NX-OS (Cisco Nexus 9000 Series Switches - Modular Platforms)

License	4-Slot Modular Platforms	8- to 16-Slot Modular Platforms	
Essentials package	NXOS-ES-M4	NXOS-ES-M8-16	
Advantage package	NXOS-AD-M4	NXOS-AD-M8-16	
Add-On Licenses			
NDB	NDB-MODM-SWT-K9	NDB-NDB-MODL-SWT-K9	
Security	NXOS-SEC-XM	NXOS-SEC-XM	
Storage	NXOS-STRG-M	NXOS-STRG-M	

You can use the following licenses to upgrade from an NX-OS LAN Enterprise Services license to an NX-OS Essentials or Advantage license.

Beginning with Cisco NX-OS Releases 7.0(3)I7(6) and 9.3(1), the -XF2 Essentials and Advantage licenses have priority over the -XF licenses. If an -XF license is installed and features are checked out from this license and then you later install the -XF2 license, the -XF license shows as unused (in the output of the **show license usage** command), and the features become checked out from the -XF2 license. The Advantage licenses continue to have priority over the Essentials licenses.

The Cisco Nexus 9300-GX switches do not support NDB.

¹⁶ ACI-SEC-XF is required only for supporting the uplink ports on the 1G Fixed Platforms.

¹⁷ ACI-SEC-XF replaces NXOS-SEC-XF. NXOS-SEC-XF is no longer orderable.

¹⁸ This license includes DCNM SAN Advanced. NXOS-STRG is no longer orderable.

Table 10: NX-OS Upgrade Licenses (Cisco Nexus 9000 Series Switches)

Upgrade License	Description
NXOS-UPG-L-ES-GF=	NX-OS Upgrade License: LAN to Essentials (1G platforms)
NXOS-UPG-L-AD-GF=	NX-OS Upgrade License: LAN to Advantage (1G platforms)
NXOS-UPG-ES-AD-GF=	NX-OS Upgrade License: Essentials to Advantage (1G platforms)
NXOS-UPG-L-ES-XF=	NX-OS Upgrade License: LAN to Essentials (10G+ platforms)
NXOS-UPG-L-AD-XF=	NX-OS Upgrade License: LAN to Advantage (10G+ platforms)
NXOS-UPG-ES-AD-XF=	NX-OS Upgrade License: Essentials to Advantage (10G+ platforms)
NXOS-UPG-L-ES-XF2=	NX-OS Upgrade License: LAN to Essentials (XF2 platforms)
NXOS-UPG-L-AD-XF2=	NX-OS Upgrade License: LAN to Advantage (XF2 platforms)
NXOS-UPG-ES-ADXF2=	NX-OS Upgrade License: Essentials to Advantage (XF2 platforms)
NXOS-UPG-L-ES-M4=	NX-OS Upgrade License: LAN to Essentials (modular 4-slot)
NXOS-UPG-L-AD-M4=	NX-OS Upgrade License: LAN to Advantage (modular 4-slot)
NXOS-UPG-ES-AD-M4=	NX-OS Upgrade License: Essentials to Advantage (modular 4-slot)
NXOS-UPG-L-ES-M8=	NX-OS Upgrade License: LAN to Essentials (modular 8- to 16-slot)
NXOS-UPG-L-AD-M8=	NX-OS Upgrade License: LAN to Advantage (modular 8- to 16-slot)
NXOS-UPG-ES-AD-M8=	NX-OS Upgrade License: Essentials to Advantage (modular 8- to 16-slot)

Cisco Nexus 3000 Series Tier-Based Licenses

The NX-OS Essentials, Advantage, and add-on licenses are supported for some Cisco Nexus 3000 Series switches.



Note

The Release History for Licensing, on page 52 section lists the platforms that support tier-based licensing and the release in which support was introduced.

The -XM licenses apply to modular switches, the -XF licenses apply to switches with less than 6.4 Tbps, and the -XF2 licenses apply to switches with more than 6.4 Tbps.

The -XF2 Essentials and Advantage licenses have priority over the -XF licenses. If an -XF license is installed and features are checked out from this license and then you later install the -XF2 license, the -XF license shows as unused (in the output of the **show license usage** command), and the features become checked out from the -XF2 license. The Advantage licenses to have priority over the Essentials licenses.

Table 11: PIDs for Cisco ONE Subscription Tier-Based Licenses for NX-OS (Cisco Nexus 3000 Series Switches)

License	PID		
Essentials package ¹⁹	N3K-ES-XF-3Y		
	N3K-ES-XF-5Y		
	N3K-ES-XF-7Y		
	N3K-ES-XF2-3Y		
	N3K-ES-XF2-5Y		
	N3K-ES-XF2-7Y		
	N3K-ES-XM-3Y		
	N3K-ES-XM-5Y		
	N3K-ES-XM-7Y		
Advantage package	N3K-AD-XF-3Y		
	N3K-AD-XF-5Y		
	N3K-AD-XF-7Y		
Add-On Licenses			
NDB	N3K-NDB-3Y		
	N3K-NDB-5Y		
	N3K-NDB-7Y		
Security	N3K-SEC-3Y		
	N3K-SEC-5Y		
	N3K-SEC-7Y		

¹⁹ License support for Cisco Nexus 3400-S switches:

- N3K-C3408-S: N3K-ES-XM-3Y, N3K-ES-XM-5Y, and N3K-ES-XM-7Y
- N3K-C3432D-S: N3K-ES-XF2-3Y, N3K-ES-XF2-5Y, and N3K-ES-XF2-7Y

Table 12: PIDs for Non-Cisco ONE Perpetual Tier-Based Licenses for NX-OS (Cisco Nexus 3000 Series Switches)

License	PID
Essentials package	N3K-ES-XF
	N3K-ES-XF2
	N3K-ES-XM
Advantage package	N3K-AD-XF
	N3K-AD-XF2

License	PID
Add-On Licenses	
NDB	N3K-NDB
Security	N3K-SEC

Feature-Based Licenses

Feature-based licenses make features available to the entire physical device. Therefore, you only require one copy of the license for a device. A license only supports the listed features. Licenses may be specific to a particular hardware platform.

Any feature that is not included in a license package is bundled with the Cisco NX-OS software and is provided at no extra charge to you.



Tip

For specific implementation of features, see the Release Notes document and configuration guides for the Cisco Nexus 9000 Series switches.



Note

The Cisco Nexus 9000 Series switches support static routes, switch virtual interfaces (SVIs), Hot Standby Router Protocol (HSRP), and Routing Information Protocol (RIP) by default (without any license).

The licenses are independent of each other. If you want to use features that are covered by different licenses, you must install all the appropriate licenses.

The following table lists the feature-based license packages for the Cisco Nexus 9000 Series (which includes Cisco Nexus 9200, 9300, 9300-EX, 9300-FX/FX2/FX3/FXP, and 9500 switches) in Cisco NX-OS mode.

Note In the CCW tool, these licenses are described as legacy NX-OS software licenses.

Table 13: Feature-Based Licenses for the Cisco Nexus 9000 Series in Cisco NX-OS Mode

Feature License	Product ID	Feature Name
LAN_ENTERPRISE_SERVICES_PKG	N95-LAN1K9 (for Cisco Nexus 9500 Series switches) N93-1G-LAN1K9 (for the Cisco Nexus N9K-C9348GC-FXP switch) N93-LAN1K9 (for Cisco Nexus 9200, 9300, 9300-EX, and 9300-FX/FX2 Series switches, except the Cisco Nexus N9K-C9348GC-FXP switch) N93-LAN1K9-XF2 (for the Cisco Nexus 9364C and 9300-GX switches)	Open Shortest Path First (OSPF) Protocol Border Gateway Protocol (BGP) Intermediate System (IS-IS) Protocol (Layer 3 only) Protocol Independent Multicast (PIM), which includes sparse mode, bidirectional mode, and Source Specific Multicast (SSM) mode Multicast Source Discovery Protocol (MSDP) Policy-Based Routing Generic Routing Encapsulation (GRE) Tunnels Enhanced Interior Gateway Routing Protocol (EIGRP) VRF route leaking VXLAN BGP EVPN Non-blocking multicast (NBM) - for the IP fabric for media solution. Note The IP fabric for media solution. Note The IP fabric for media solution also requires the N93-LAN1K9 or N95-LAN1K9 license for multicast.

Feature License	Product ID	Feature Name
VPN Fabric License	N95-FAB1K9	• InterAS option B
	N93-FAB1K9	• Layer 3 EVPN over segment routing MPLS
		• MPLS Layer 3 VPN
		Pervasive Load Balancing (PLB)
		Tenant Routed Multicast
		VXLAN EVPN Multi-Site
		• Enhanced PBR (EPBR)
Network Services Package	N95-SERVICES1K9	• iCAM
NETWORK_SERVICES_PKG	N93-SERVICES1K9	Intelligent Traffic Director (ITD)
		• Non-blocking multicast (NBM) - for the IP fabric for media solution.
		Note The IP fabric for media solution also requires the N93-LAN1K9 or N95-LAN1K9 license for multicast.
		Smart channel
		Note Beginning with Cisco Nexus NX-OS 9.3(5), Catena is no longer available. However, Catena is available with the Essentials license package of earlier releaes.
FCoE NPV Package	N95-FNPV1K9	FCoE NPV
FCOE_NPV_PKG	N93-FNPV1K9	Note The N93-16Y-SSK9 and N93-48Y-SSK9 licenses also support FCoE NPV. If you install one of these licenses (rather than N95-FNPV1K9 or N93-FNPV1K9), the show license command does not show FCoE NPV in the output. For more information, see the Cisco Nexus 9000 Series NX-OS FC-NPV and FCoE-NPV Configuration Guide.

Feature License	Product ID	Feature Name
SAN Switching Package SAN_ENTERPRISE_PKG and FC Port Package FC_PORT_ACTIVATION_PKG	N93-16Y-SSK9 (up to 16 ports) N93-48Y-SSK9 (all 48 ports)	SAN switching, FC NPV, or FCoE NPV Note SAN switching, FC NPV, and FCoE NPV require both the FC_PORT_ACTIVATION_PKG and SAN_ENTERPRISE_PKG licenses. For more information, see the Cisco Nexus 9000 Series NX-OS SAN Switching Configuration Guide and the Cisco Nexus 9000 Series NX-OS FC-NPV and FCoE-NPV Configuration Guide.
Security License	ACI-SEC-XM*** or ACI-SEC-XF**	Note Cisco Nexus 9000 Series ToR switches that support this feature require the ACI-SEC-XF** license, and Cisco Nexus 9000 Series EoR switches that support this feature require the ACI-SEC-XM*** license. Secure VXLAN EVPN Multi-Site using CloudSec Note Secure VXLAN EVPN Multi-Site using CloudSec licensing support is available with the ACI-SEC-XF license. Secure VXLAN EVPN Multi-Site using CloudSec licensing support is not available with the ACI-SEC-XM license.
24 Port License Upgrade Package* NEXUS_24PORTEX_UPGRADE	N9K-EX-24P-UPG=	24-port upgrade license for Cisco Nexus 93108TC-EX-24 and 93180YC-EX-24 switches.
24 Port License Upgrade Package* NEXUS_24PORTFX_UPGRADE	N9K-FX-24P-UPG=	24-port upgrade license for Cisco Nexus 93108TC-FX-24 and 93180YC-FX-24 switches.

The following table lists the feature-based license packages for the Cisco Nexus 7000 Series, which includes Cisco Nexus 7000 switches and Cisco Nexus 7700 switches.

Table 14: Feature-Based Licenses for the Cisco Nexus 7000 Series

Feature License	Product ID	Feature Name
Enterprise Services Package LAN_ENTERPRISE_SERVICES_PKG	Product ID N7K-LAN1K9 N77-LAN1K9	Open Shortest Path First (OSPF) Protocol Border Gateway Protocol (BGP) Intermediate System-to-Intermediate System (IS-IS) Protocol (Layer 3 only) Protocol Independent Multicast (PIM), which includes sparse mode, bidirectional mode, and source-specific mode (SSM).
		 Multicast Source Discovery Protocol (MSDP) Policy-Based Routing Generic routing encapsulation (GRE) Tunnels Enhanced Interior Gateway Routing Protocol (EIGRP)
		 VXLAN BGP eVPN Control Plane over VXLAN ACI WAN Interconnect Locator/ID Separation Protocol (LISP)
Advanced Services Package LAN_ADVANCED_SERVICES_PKG	N7K-ADV1K9	Virtual Device Contexts (VDCs)

^{*}The 24-port licenses are hardware licenses. They are independent of any Cisco NX-OS or ACI software feature sets or software licenses.

^{**}ACI-SEC-XF replaces NXOS-SEC-XF. NXOS-SEC-XF is no longer orderable.

^{***}ACI-SEC-XM replaces NXOS-SEC-XM. NXOS-SEC-XM is no longer orderable.

Feature License	Product ID	Feature Name
VDC Licenses	N7K-VDC1K9	For Nexus 7000 Series, a single ADV
VDC_LICENSES	N77-VDC1K9	license provides five non-admin VDCs and one admin VDC. If you require an additional VDC, buy another license (N7K-VDC1K9) which in turn, provides another four VDCs.
		• For Nexus 7700 Series, a single ADV license provides five non-admin VDCs and one admin VDC. If you require an additional VDC, buy another license (N77-VDC1K9) which in turn, provides another four VDCs.
Transport Services Package	N7K-TRS1K9	Overlay Transport Virtualization (OTV)
LAN_TRANSPORT_SERVICES_PKG	N77-TRS1K9	
Scalable Services Package	N7K-C7004-XL	A single license per system enables all
SCALABLE_SERVICES_PKG	N7K-C7009-XL	XL-capable I/O modules to operate in XL mode. The license increases the performance
	N7K-C7010-XL	of the following features:
	N7K-C7018-XL	• IPv4 routes
		• IPv6 routes
		• ACL entries
Enhanced Layer 2 Package	N7K-EL21K9	FabricPath support on the F Series
ENHANCED_LAYER2_PKG	N77-EL21K9	module
		Remote Integrated Service Engine (RISE)
		Intelligent Traffic Director (ITD)
		Intelligent CAM Analytics and Machine Learning (iCAM)
MPLS Services Package	N7K-MPLS1K9	Multiprotocol Label Switching (MPLS)
MPLS_PKG	N77-MPLS1K9	• Layer 3 Virtual Private Network (VPN)
		• Layer 2 Ethernet over MPLS (EoMPLS)
		Layer 2 Virtual Private LAN Services (VPLS)
		ACI WAN Interconnect

Feature License	Product ID	Feature Name
Storage Enterprise Package STORAGE-ENT	N7K-SAN1K9 N77-SAN1K9	 Inter-VSAN routing (IVR) over Fibre Channel and FCoE IVR Network Address Translation (NAT) over Fibre Channel VSAN-based Access Control Fabric Binding for Open Systems



Note

From Cisco NX-OS Release 6.1, Cisco TrustSec (CTS) does not require a feature license. CTS is included with the Cisco NX-OS software.

The following table lists the feature-based license packages for the Cisco Nexus 6000 Series switches.

Table 15: Feature-Based Licenses for the Cisco Nexus 6000 Series

Feature License	Product ID	Feature Name
FabricPath Services Package	N6001-EL2-SSK9	FabricPath
ENHANCED_LAYER2_PKG	N6004-EL2-SSK9	
FCoE NPV Package	N6K-FNPV-SSK9	FCoE NPV
FCOE_NPV_PKG		
Layer 3 Base Services Package LAN_BASE_SERVICES_PKG 20 21	N6K-BAS1K9	Unlimited static routes and a maximum of 256 dynamic routes. • Static routes • RIPv2 • OSPFv2 and OSPFv3 • EIGRP Stub • HSRP 22 • VRRP 23 • IGMP v2/v3 • PIMv2 (sparse mode) • VRF Lite
		• Routed ACL
		• NAT

Feature License	Product ID	Feature Name
Layer 3 Enterprise Services Package LAN_ENTERPRISE_SERVICES_PKG 24 25	N6001-LAN1K9 N6004-LAN1K9	N6001-LAN1K9 / N6004-LAN1K9 (includes the following features in addition to the ones under N6K-BAS1K9 license). • BGP • PBR • Full EIGRP • PIMv2 (all modes) • L3 IS-IS ²⁶ • uRPF • MSDP • Sampled NetFlow • Intelligent Traffic Director (ITD)
Network Services Package NETWORK_SERVICES_PKG	N6K-SERVICES1K9 ²⁷	Remote Integrated Services Engine (RISE) Intelligent Traffic Director (ITD)
Storage Protocols Services Package	N6001-16P-SSK9	Native Fibre Channel
FC_FEATURES_PKG	N6004-4Q-SSK9	• FCoE
ENTERPRISE_PKG	N6004-12Q-SSK9	• FC NPV
	N6K-16P-SSK9 ²⁸ N6K-20P-SSK9 ²⁹ N6001-64P-SSK9 N6004-96Q-SSK9	 FC Port Security Fabric Binding Fibre Channel Security Protocol (FC-SP) Authentication
VM-FEX Package	N6K-VMFEXK9	VM-FEX

The LAN_BASE_SERVICES_PKG gives unlimited static routes and a maximum of 256 dynamic routes across all the protocols.

21 Routes above 256 for all protocols are included in the LAN_ENTERPRISE_SERVICES_PKG license.

Although this feature can be enabled and configured in the CLI without this license, it will not function until the license is installed.

Although this feature can be enabled and configured in the CLI without this license, it will not function until the license is installed. When you configure HSRP in a virtual port channel (vPC) on the Cisco Nexus 6000 platform without installing the LAN_BASE_SERVICES_PKG license, it sends an HSRP hello message to the link-local multicast address and enables the Active-Active state.

25 Routes above 256 for all the protocols included in the LAN_ENTERPRISE_SERVICES_PKG license.

²⁶ L3 IS-IS will be available starting with the Cisco NX-OS Release 7.0(1)N1(1).

- N6K-SERVICES1K9 is available from Cisco NX-OS Release 7.2(0)N1(1). To use RISE and ITD features with Cisco NX-OS Release 7.1(1)N1(1), use the ENHANCED_LAYER2_PKG license.
- ²⁸ These licenses are applicable to Cisco Nexus 6004 20 UP LEM only.
- These licenses are applicable to Cisco Nexus 6004 20 UP LEM only.

The following table lists the feature-based license packages for the Cisco Nexus 5600 Series switches.

Table 16: Feature-Based Licenses for the Cisco Nexus 5600 Series

Feature License	Product ID	Feature Name
FabricPath Services Package	N5672-EL2-SSK9	FabricPath
ENHANCED_LAYER2_PKG	N56128-EL2-SSK9	
	N5696-EL2-SSK9	
	N5624Q-EL2-SSK9	
	N5648Q-EL2-SSK9	
FCoE NPV Package	N56-FNPV-SSK9	FCoE NPV
FCOE_NPV_PKG		
Layer 3 Base Services Package	N56-BAS1K9	Layer 3 Base Services Package
LAN_BASE_SERVICES_PKG 30		Unlimited static routes and maximum of 256 dynamic routes
		Static Routes
		• RIPv2
		• OSPFv2 and OSPFv3
		• EIGRP Stub
		• HSRP <u>31</u>
		• VRRP ³²
		• IGMP v2/v3
		• PIMv2 (sparse mode)
		• VRF Lite
		• Routed ACL
		• NAT

The LAN_BASE_SERVICES_PKG license should be installed in order to use the LAN_ENTERPRISE_SERVICES_PKG license.

Feature License	Product ID	Feature Name
Layer 3 Enterprise Services Package	N56-LAN1K9	Layer 3 Enterprise Services Package
LAN_ENTERPRISE_SERVICES_PKG3334		The N56-LAN1K9 license includes the following features in addition to the ones under the N56-BAS1K9 license.
		• BGP
		• PBR
		• Full EIGRP
		• PIMv2 (all modes)
		• L3 IS-IS ³⁵
		• uRPF
		• MSDP
		Sampled NetFlow
		• VxLAN Flood and Learn ³⁶
		• VxLAN EVPN ³⁷
		Intelligent Traffic Director (ITD)
Network Services Package NETWORK SERVICES PKG	N56-SERVICES1K9 ³⁸	Remote Integrated Services Engine (RISE)
THE TWO THE SERVICES INC		Intelligent Traffic Director (ITD)
Storage Protocols Services Package	N56-16p-SSK9	Native Fibre Channel
FC_FEATURES_PKG	N56-12P-SSK9 ³⁹	• FCoE
ENTERPRISE_PKG	N5672-72P-SSK9	• NPV
	N56128-128P-SSK9	• FC Port Security
	N56-20P-SSK9 ⁴⁰	Fabric Binding
	N56-12Q-SSK9	Fibre Channel Security
	N56-4Q-SSK9	Protocol (FC-SP) Authentication
	N56-48Q-SSK9	Aumentication
VM-FEX Package	N56-VMFEX9	VM-FEX

 $^{^{30}~{\}rm The~LAN_BASE_SERVICES_PKG}$ gives unlimited static routes and a maximum of 256 dynamic routes across all the protocols.

Although this feature can be enabled and configured in the CLI without this license, it will not function until the license is installed.

- Although this feature can be enabled and configured in the CLI without this license, it will not function until the license is installed.
- The LAN_BASE_SERVICES_PKG license should be installed in order to use the LAN_ENTERPRISE_SERVICES_PKG license.
- Routes above 256 for all the protocols included in the LAN ENTERPRISE SERVICES PKG license.
- ³⁵ L3 IS-IS will be available starting with the Cisco NX-OS Release 7.0(1)N1(1).
- VXLAN Flood and Learn is supported from Cisco NX-OS Release 7.1(0)N1(1) and requires the LAN_BASE_SERVICES_PKG license and the ENHANCED_LAYER2_PKG license. From Cisco NX-OS Release 7.2(1)N1(1), VXLAN Flood and Learn will require the LAN_BASE_SERVICES_PKG license and the LAN_ENTERPRISE_SERVICES_PKG license only.
- VXLAN EVPN is supported from Cisco NX-OS Release 7.3(0)N1(1) and will require the LAN BASE SERVICES PKG license and the LAN ENTERPRISE SERVICES PKG license.
- N56-SERVICES1K9 is available from Cisco NX-OS Release 7.2(0)N1(1). To use RISE and ITD features with Cisco NX-OS Release 7.1(1)N1(1), use the ENHANCED LAYER2 PKG license.
- This license is applicable to Cisco Nexus 5672UP-16G only.
- ⁴⁰ This license is applicable to Cisco Nexus 5696 20 Port UP LEM only.

The prefix of the Product ID number indicates the platform for which the license applies. For example, N5548 indicates that the license is for the Cisco Nexus 5548 switch only, and N5K indicates that the license is for all Cisco Nexus 5000 Series switches.

The following table lists the feature-based license packages for the Cisco Nexus 5000 Series and Cisco 5500 Series Platform.

Table 17: Feature-Based Licenses for the Cisco Nexus 5000 and Nexus 5500 Series

Feature License	Product ID	Features
FabricPath Services Package	N5548-EL2-SSK9	FabricPath
ENHANCED_LAYER2_PKG	N5596-EL2-SSK9	
FCoE NPV Package	N5010-FNPV-SSK9	FCoE NPV
FCOE_NPV_PKG	N5020-FNPV-SSK9	
	N5548-FNPVSSK9	
	N5596-FNPV-SSK9	

Feature License	Product ID	Features
Layer 3 Base Services Package LAN_BASE_SERVICES_PKG	N55-BAS1K9	Layer 3 Base Services Package
4 <u>1</u>		Unlimited static routes and a maximum of 256 dynamic routes
		Static Routes
		• RIPv2
		OSPFv2 and OSPFv3
		• EIGRP Stub
		• HSRP ⁴²
		• VRRP <u>43</u>
		• IGMP v2/v3
		• PIMv2 (sparse mode)
		• VRF Lite
		• Routed ACL
Layer 3 Enterprise Services Package LAN_ENTERPRISE_SERVICES_PKG	N55-LAN1K9	Layer 3 Enterprise Services Package
4445		N55-LAN1K9 includes the following features in addition to the ones under the N55-BAS1K9 license.
		• BGP
		• PBR
		• PIMv2 (all modes)
		• Full EIGRP
		• uRPF
		• MSDP
		• Intelligent Traffic Director (ITD)
Network Services Package	N55-SERVICES1K9 ⁴⁶	Remote Integrated Services
NETWORK_SERVICES_PKG		Engine (RISE) Intelligent Traffic Director (ITD) ⁴⁷

Feature License	Product ID	Features
Storage Protocols Services Package	N5010-SSK9	Native Fibre Channel
FC_FEATURES_PKG	N5020-SSK9	• FCoE
ENTERPRISE_PKG	N55-8P-SSK9	• NPV
	N55-48P-SSK9	• FC Port Security
		Fabric Binding
		• Fibre Channel Security Protocol (FC-SP) Authentication
VM-FEX Package	N55-VMFEXK9	VM-FEX

The LAN_BASE_SERVICES_PKG gives unlimited static routes and a maximum of 256 dynamic routes across all the protocols.

The following table lists the feature-based license packages for the Cisco Nexus 4000 Series.

Table 18: Feature-Based Licenses for the Cisco Nexus 4000 Series

Feature License	Product ID	Features
Basic Storage Services Package	N4K-4005I-SSK9	FIP Snooping
BASIC_STORAGE_SERVICES_PKG		

⁴² Although this feature can be enabled and configured in the CLI without this license, it will not function until the license is installed.

Although this feature can be enabled and configured in the CLI without this license, it will not function until the license is installed.

The LAN_BASE_SERVICES_PKG license should be installed to use the LAN_ENTERPRISE_SERVICES_PKG license.

⁴⁵ Routes above 256 for all the protocols are included in the LAN_ENTERPRISE_SERVICES_PKG license.

N55-SERVICES1K9 is available from Cisco NX-OS Release 7.2(0)N1(1). To use RISE and ITD features with the Cisco NX-OS Release 7.1(1)N1(1), use the LAN ENTERPRISE SERVICES PKG license.

Starting NXOS 7.2(0)N1(1), LAN_ENTERPRISE_SERVICES_PKG package does not contain ITD license. You need to install NETWORK SERVICES PKG package for ITD.

The following table lists the feature-based license packages for the Cisco Nexus 3600 platform switches.

Table 19: Feature-Based Licenses for the Cisco Nexus 3600 Platform Switches

Feature License	Product ID	Features
Layer 3 Enterprise Services Package	N3K-LAN1K9	• BGP
LAN_ENTERPRISE_SERVICES_PKG		• EIGRP
		• IS-IS
		OSPFv2 and OSPFv3
		• PIM
		• VRF-lite
		• VXLAN
VDN Edwin Linner	NOW FADINO	Lutan A.C. antian D
VPN Fabric License	N3K-FAB1K9	• InterAS option B
		• MPLS Layer 3 VPN

The following table lists the feature-based license packages for the Cisco Nexus 3500 Series switches.

Table 20: Feature-Based Licenses for the Cisco Nexus 3500 Series Switches

Feature License	Product ID	Features
24 Port License Package 24P_LIC_PKG	N3548-24P-LIC	24-port license for the Cisco Nexus 3548 Series switch.
24 Port Upgrade License Package 24P_UPG_PKG	N3548-24P-UPG	24-port upgrade license for the Cisco Nexus 3548 Series switch.
Cisco Nexus 3500 Algo Boost License ALGO_BOOST_SERVICES_PKG	N3548-ALGK9	Cisco Nexus 3500 Algo Boost License • Warp Mode • Warp SPAN • NAT
Layer 3 Base Services Package LAN_BASE_SERVICES_PKG	N3548-BAS1K9	Layer 3 Base Services Package • EIGRP stub • OSPFv2 (limited routes) • PIMv2 (sparse mode)

Feature License	Product ID	Features
Layer 3 Enterprise Services Package LAN1K9_ENT_SERVICES_PKG 48	N3524-LAN1K9	Layer 3 Enterprise Services Package for Cisco Nexus 3524 Series switches • BGP • PBR • VRF-Lite (IP-VPN) This license requires the Base Services Package.
Layer 3 Enterprise Services Package LAN_ENTERPRISE_SERVICES_PKG 49	N3548-LAN1K9	Layer 3 Enterprise Services Package for Cisco Nexus 3548 Series switches • BGP • PBR • VRF-Lite (IP-VPN) This license requires the Base Services Package.

⁴⁸ For Cisco NX-OS releases prior to 9.3(3), the BGP feature is checked out from the LAN1K9_ENT_SERVICES_PKG for both Cisco Nexus 3524 and 3548 platform switches.

For Cisco NX-OS releases prior to 9.3(3), the PBR feature is checked out from the LAN ENTERPRISE SERVICES PKG for both Cisco Nexus 3524 and 3548 platform switches.



Note

After upgrading to Cisco NX-OS Release 7.0(3)I7(7), the **show license usage** command might display license mismatches that do not apply to Cisco Nexus 3500 Series switches. A "License Missing" warning in the comments section may also be displayed. Issue the **clear license sprom** command to recover from this state.

The following table lists the feature-based license packages for the Cisco Nexus 3000 Series.

Table 21: Feature-Based Licenses for the Cisco Nexus 3000 Series

Feature License	Product ID	Features
16 Port License Upgrade Package 16P_UPG_PKG	N3K-16T-UPG	16-port upgrade license for Cisco Nexus 3172TQ switches. This is the upgrade license to enable 16 ports, and it can only be applied to N3K-C3172TQ-32T.
32 Port License Package 32P_LIC_PKG	N3K-32X-LIC	Default 32-port license for the Cisco Nexus 3172TQ switches.

Feature License	Product ID	Features
16 Port License Upgrade Package 16P_UPG_PKG	N3064T-16T-UPG	16-port upgrade license for Cisco Nexus 3164T switch.
32 Port License Package 32P_LIC_PKG	N3064T-32T-LIC	32-port license for Cisco Nexus 3164T switch.
Layer 3 Base Services Package LAN_BASE_SERVICES_PKG	N3K-BAS1K9	• EIGRP stub • OSPFv2 (limited routes) • PIMv2 (sparse mode) Note Only the Cisco Nexus 3016, 3048, 3064, 3132Q, 3132Q-XL, and 3172 switches require the Layer 3 Base Services Package. The Cisco Nexus 3132C-Z, 3164Q, 31128PQ, 3100-V, 32xx, and 34xx switches require the Layer 3 Enterprise Services Package (rather than the Layer 3 Base Services Package) to support these routing protocols.
Layer 3 Enterprise Services Package LAN_ENTERPRISE_SERVICES_PKG	N3K-LAN1K9 N3K-LAN2K9 (for Cisco Nexus 3264C-E, 3408-S, 3432D-S, and 3464C switches)	BGP Policy-Based Routing Generic routing encapsulation (GRE) tunnels

Feature License	Product ID	Features
Hardware Streaming Telemetry Package HW_STREAMING_TELEMETRY_PKG	N3K-STR1K9 (for Cisco Nexus 34180YC switches) N3K-STR2K9 (for the Cisco Nexus 3464C, 3408-S, and 3432D-S switches)	Note This license is available beginning with Cisco NX-OS Release 9.2(3). Any attempt to install this license for a prior release will fail. When you downgrade from Cisco NX-OS Release 9.2(3) to an earlier release, the features that use the hardware streaming telemetry license continue to work in honor mode in the downgraded version. In addition, the output of the show license usage command continues to include entries for these unsupported licenses.

Module-based Licenses

Module-based licenses make features available to one module on the physical device, so you need one copy of the license for each module that you want to enable the features on. Each license only supports the listed features. Licenses may be specific to a particular hardware platform or module.



Note

Any feature not included in a license package is bundled with the Cisco NX-OS software and is provided at no extra charge to you.

This table lists the module license packages for the Cisco Nexus 7000 Series, which includes Cisco Nexus 7000 switches and Cisco Nexus 7700 switches.

Table 22: Module-Based Licenses for the Cisco Nexus 7000 Series

Module License	Product ID	Features
FCoE Services Package (FCOE_PKG)	N7K-FCOE-F132XP=	Fibre Channel over Ethernet (FCoE) Note You do not need the Advanced Services Package to enable the storage VDC required for FCoE.

Module License	Product ID	Features
FCoE F2-Series (FCoE_F2)	N7K-FCOE-F248XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7000 48-port 10G SFP+ (F2)
	N77-FCOE-F248XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7700 Enhanced F2E Series 48 Port 10G (SFP+)
FCoE F3-Series (FCoE_F3)	N7K-FCOE-F312FQ	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7000 F3 Series 12-port 40-Gigabit Ethernet QSFP+ module
	N7K-FCOE-F348XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7000 F3 Series 48-port 10-Gigabit Ethernet SFP+ module
	N77-FCOE-F324FQ	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7700 F3 Series 24-port 40-Gigabit Ethernet QSFP+ module
	N77-FCOE-F348XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7700 F3 Series 48-port 10-Gigabit Ethernet SFP+ module



Note

The licenses are independent of each other. If you want to use features that are covered by different licenses, you must install all appropriate licenses. For example, if you want to use EIGRP and VDCs on the Cisco Nexus 7000 Series, you must install both the Enterprise Services Package license and the Advanced Services Package license.

Related Topics

Associating a License with a Module, on page 50

Bundle/Chassis-based Licenses

Bundle/Chassis-based licensing makes the Fibre Channel over Ethernet (FCoE) feature available for all supported line card modules such as F2 and F3 for that particular chassis with max counts supported by that chassis.



Note

Bundle/Chassis-based licensing is not supported for the Cisco Nexus 7000 series.

This table lists the bundle/chassis-based licenses for the Cisco Nexus 7700 Series.

Table 23: Bundle/Chassis-Based Licenses for the Cisco Nexus 7700 Series

Bundle/Chassis	Product ID	Features	
N7706-FCOE-10G=	N77-FCOE-F248XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7706 F2 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 4 modules)	
	N77-FCOE-F348XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7706 F3 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 4 modules)	
N7710-FCOE-10G=	N77-FCOE-F248XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7710 F2 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 8 modules)	
	N77-FCOE-F348XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7710 F3 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 8 modules)	
7718		Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7718 F2 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 16 modules)	
	N77-FCOE-F348XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7718 F3 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 16 modules)	
N7706-FCOE-40G=	N77-FCOE-F248XP	Fibre Channel over Ethernet (FCoE) for Cisco Next 7706 F2 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 4 modules)	
	N77-FCOE-F348XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7706 F3 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 4 modules)	
	N77-FCOE-F324FQ	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7706 F3 Series 24-port 40-Gigabit Ethernet QSFP+ Module (Maximum of 4 modules)	
N7710-FCOE-40G=	N77-FCOE-F248XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7710 F2 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 8 modules)	
	N77-FCOE-F348XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7710 F3 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 8 modules)	
	N77-FCOE-F324FQ	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7710 F3 Series 24-port 40-Gigabit Ethernet QSFP+ Module (Maximum of 8 modules)	

Bundle/Chassis	Product ID	Features
N7718-FCOE-40G=	N77-FCOE-F248XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7718 F2 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 16 modules)
	N77-FCOE-F348XP	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7718 F3 Series 48-port 10-Gigabit Ethernet SFP+ Module (Maximum of 16 modules)
	N77-FCOE-F324FQ	Fibre Channel over Ethernet (FCoE) for Cisco Nexus 7718 F3 Series 24-port 40-Gigabit Ethernet QSFP+ Module (Maximum of 16 modules)

Honor Mode Licensing

Starting from Cisco NX-OS Releases 8.2(4) and 8.4(1), Honor Mode Licensing is supported on Cisco Nexus 7000 Series switches. Honor mode licensing allows you to enable or continue using a feature without having a valid license for that feature. In such a scenario, a syslog is generated once every 7 days until you acquire the required license. An example of such a syslog is given below.

%LICMGR-2-LOG_LIC_MISSING_WARNING: A feature that requires LAN_ENTERPRISE_SERVICES_PKG license is not installed. System supports honor based licensing so feature will continue to be fully functional. Use 'show license usage <package-name>' to find features using missing license.

Licensing Terminology

The following terms are used in this document:

Licensed feature

Permission to use a particular feature through a license file, a hardware object, or a legal contract. This permission is limited to the number of users, number of instances, time span, and the implemented device.

Licensed application

A software feature that requires a license to be used.

License enforcement

A mechanism that prevents a feature from being used without first obtaining a license.

Node-locked license

A license that can only be used on a particular device using the device's unique host ID.

Host IDs

A unique chassis serial number that is specific to each device.

Software license claim certificate

A document entitling its rightful owner to use licensed features on one device as described in that document.

Product Authorization Key (PAK)

The PAK allows you to obtain a license key from one of the sites listed in the software license claim certificate document. After registering at the specified website, you will receive your license key file and installation instructions through e-mail.

License key file

A device-specific unique file that specifies the licensed features. Each file contains digital signatures to prevent tampering and modification. License keys are required to use a licensed feature. License keys are enforced within a specified time span.

Missing license

Once a license is installed, the license file can be deleted from bootflash as the license is copied to the internal file system. If the internal file system becomes corrupted or a supervisor module is replaced after you have installed a license, the license shows as missing although the feature continues to work. In this case, copy the license file (.lic) into bootflash and reinstall it as soon as possible.

Evaluation license

A temporary license. Evaluation licenses are time bound (valid for a specified number of days) and are tied to a host ID (device serial number).



Note

Temporary licenses with an expiry date are available for evaluation and lab use purposes. They are strictly not allowed to be used in production. Please use a permanent or subscription license that has been purchased through Cisco for production purposes.

Permanent license

A license that is not time bound is called a permanent license.

Grace period

The amount of time the features in a license package can continue functioning without a license.

Support

If you purchased Cisco support through a Cisco reseller, contact the reseller directly. If you purchased support directly from Cisco, contact Cisco Technical Support at this URL: http://www.cisco.com/en/US/support/tsd_cisco_worldwide_contacts.html

Licensing Virtualization Support

On the Cisco Nexus 7000 Series, you install and manage licenses on the physical device in the default virtual device context (VDC 1). Licenses apply to features in all VDCs and Virtual Routing and Forwarding instances (VRFs) on the physical device. You do not need to obtain a separate license for each VDC or VRF. For more information on VDCs, see the *Cisco Nexus 7000 Series NX-OS Virtual Device Context Configuration Guide*.

Licensing High Availability

As with other Cisco NX-OS features, the licensing feature also maintains the following high-availability standards:

- Installing any license in the device is a nondisruptive process.
- Installing a license automatically saves a copy of permanent licenses to the chassis.
- If you have enabled the grace period feature, enabling a licensed feature that does not have a license key starts a counter on the grace period. You then have 120 days to install the appropriate license keys, disable the use of that feature, or disable the grace period feature. If at the end of the 120-day grace period the device does not have a valid license key for the feature, the Cisco NX-OS software automatically disables the feature and removes the configuration from the device.



Note

The Cisco Nexus 9000 Series and Cisco Nexus 3000 Series do not support the grace period feature.



Note

The Cisco Nexus 7000 Series switches support grace period on Cisco NX-OS Release 8.2(3) and earlier 8.x releases. From Cisco NX-OS Releases 8.2(4) and 8.4(1), Grace period is not supported on Cisco Nexus 7000 Series switches.



Note

Some licenses, for example Cisco TrustSec for the Cisco Nexus 7000 Series or Layer 3 Enterprise Services for the Cisco Nexus 5000 Series, do not have a grace period.

Devices with dual supervisors have the following additional high-availability features:

- The license software runs on both supervisor modules and provides failover protection.
- The license key file is mirrored on both supervisor modules. Even if both supervisor modules fail, the license file continues to function from the version that is available on the chassis.

License Installation

You can either obtain a factory-installed license (only applies to new device orders) or perform a manual license installation of the license (applies to existing devices in your network).



Note

Only users with the network-admin role can install licenses on Cisco NX-OS devices. For information on user accounts and roles, see the *Security Configuration Guide* for your platform.

Obtaining a Factory-Installed License

You can obtain factory-installed licenses for a new Cisco NX-OS device.

SUMMARY STEPS

- 1. Contact your reseller or Cisco representative and request this service.
- 2. Start using the device and the licensed features.

DETAILED STEPS

Step 1 Contact your reseller or Cisco representative and request this service.

Note

If you purchased Cisco support through a Cisco reseller, contact the reseller directly. If you purchased support directly from Cisco, contact Cisco Technical Support at http://www.cisco.com/en/US/support/tsd_cisco_worldwide_contacts.html.

Your device is shipped with the required licenses installed in the system.

Step 2 Start using the device and the licensed features.

Performing a Manual Installation

If you have existing devices or if you wish to install the licenses on your own, you must first obtain the license key file and then install that file in the device.




Note

All licenses for the Cisco Nexus 5000 Series and the Cisco Nexus 4000 Series are factory-installed. Manual installation is not required.

Figure 2: Obtaining a License Key File

This figure shows how to obtain a license key file.



Obtaining the License Key File

You can obtain new or updated license key files.

SUMMARY STEPS

- **1.** Obtain the serial number for your device by entering the **show license host-id** command. The host ID is also referred to as the device serial number.
- 2. Obtain your software license claim certificate document. If you cannot locate your software license claim certificate, contact Cisco Technical Support at http://www.cisco.com/en/US/support/tsd_cisco_worldwide_contacts.html.
- 3. Locate the product authorization key (PAK) from the software license claim certificate document.
- **4.** Locate the website URL from the software license claim certificate document. You can access the Product License Registration website https://tools.cisco.com/SWIFT/LicensingUI/Home.
- 5. Follow the instructions on the Product License Registration website to register the license for your device.
- **6.** For the Cisco Nexus 9000 Series switches, Cisco Nexus 3164Q switches, and Cisco Nexus 31128PQ switches, use the **copy licenses** command to save your license file to one of three locations—the bootflash: directory, the usb1: device, or the usb2: device. For the Cisco Nexus 7000 Series, use the **copy licenses** command from the default VDC to save your license file to one of four locations—the bootflash: directory, the slot0: device, the usb1: device, or the usb2: device. For all other platforms, use the **copy licenses** command to save your license file to one of two locations—the bootflash: directory or the volatile: directory.

DETAILED STEPS

	Command or Action	Purpose	
Step 1	Obtain the serial number for your device by entering the show license host-id command. The host ID is also referred to as the device serial number.	switch# show license host-id License hostid: VDH=FOX064317SQ	
		Use the entire ID that appears after the equal sign (=). In this example, the host ID is FOX064317SQ.	
Step 2	Obtain your software license claim certificate document. If you cannot locate your software license claim certificate, contact Cisco Technical Support at http://www.cisco.com/en/US/support/tsd_cisco_worldwide_contacts.html.		
Step 3	Locate the product authorization key (PAK) from the software license claim certificate document.		
Step 4	Locate the website URL from the software license claim certificate document. You can access the Product License Registration website https://tools.cisco.com/SWIFT/LicensingUI/Home.		
Step 5	Follow the instructions on the Product License Registration website to register the license for your device.	The license key file is sent to you by e-mail and is digital signed to only authorize use on the requested device. The requested features are also enabled once the Cisco NX-software on the specified device accesses the license key file.	
		Caution Do not make any modifications to the license key file. It will alter the digital signature and render the license invalid.	

	Command or Action	Purpose	Purpose	
		A license is permanent. If you do not have a license, the grace period for using a feature starts from the first time you start using a feature offered by a license.		
		Note	Cisco TrustSec for the Cisco Nexus 7000 Series and Layer 3 Enterprise for the Cisco Nexus 5000 Series do not have a grace period. You must obtain an Advanced Services license to use Cisco TrustSec.	
Step 6	For the Cisco Nexus 9000 Series switches, Cisco Nexus 3164Q switches, and Cisco Nexus 31128PQ switches, use the copy licenses command to save your license file to one of three locations—the bootflash: directory, the usb1: device, or the usb2: device. For the Cisco Nexus 7000 Series, use the copy licenses command from the default VDC to save your license file to one of four locations—the bootflash: directory, the slot0: device, the usb1: device, or the usb2: device. For all other platforms, use the copy licenses command to save your license file to one of two locations—the bootflash: directory or the volatile: directory.		Only users with the network-admin role can copy licenses on Cisco NX-OS devices. For information on user accounts and roles, see the <i>Security Configuration Guide</i> for your platform.	

Related Topics

Backing Up Licenses, on page 40
Backing Up the License Key File, on page 41
Backing Up an Installed License, on page 41
Configuring the Grace Period Feature, on page 46
Grace Period Alerts, on page 46
Enabling the License Grace Period, on page 49
Disabling the License Grace Period, on page 49

Installing the License Key File

You can install the license to enable features on your device. For the Cisco Nexus 7000 Series, the license must be installed in the default VDC or admin VDC. A license applies to features in all VDCs and VRFs on the physical device.



Tip

If you need to install multiple licenses in any device, be sure to provide unique filenames for each license key file.



Note

If you have a single supervisor module on your Cisco NX-OS device and you replace the supervisor module, you must reinstall the license key file.

If you are currently running with a grace period license to avoid service disruptions when you install your permanent license, do not disable the grace period by using the **no license grace-period** command. Instead, just install your new license. The license manager will automatically transition from grace licensing to the installed license.

SUMMARY STEPS

- 1. Log into the device through the console port of the active supervisor.
- **2.** Perform the installation by using the **install license** command on the active supervisor module from the device console.
- **3.** (Optional) Back up the license key file.
- **4.** Exit the device console and open a new terminal session to view all license files installed on the device using the **show license** command.
- **5.** (Optional) Enable licensed features, if necessary, by using the **feature** *feature-name* command in global configuration mode. For example, you can enable the BGP feature as follows:

DETAILED STEPS

Step 1 Log into the device through the console port of the active supervisor.

Note Only users with the network-admin role can install licenses on Cisco NX-OS devices. For information on user accounts and roles, see the *Security Configuration Guide* for your platform.

Step 2 Perform the installation by using the **install license** command on the active supervisor module from the device console.

```
switch# install license bootflash:license_file.lic
Installing license ..done
```

Note If you provide a target name for the license key file, the file is installed with the specified name. Otherwise, the filename specified in the license key file is used to install the license.

- **Step 3** (Optional) Back up the license key file.
- **Step 4** Exit the device console and open a new terminal session to view all license files installed on the device using the **show** license command.

Note If the license meets all guidelines when the **install license** command is used, all features and modules continue functioning as configured.

You can use the **show license brief** command to display a list of license files installed on the device.

```
switch# show license brief
Enterprise.lic
```

You can use the **show license file** command to display information about a specific license file installed on the device.

Step 5 (Optional) Enable licensed features, if necessary, by using the **feature** *feature-name* command in global configuration mode. For example, you can enable the BGP feature as follows:

```
swtich# configure terminal
switch(config)# feature bgp
```

Related Topics

Feature-Based Licenses, on page 14
Module-based Licenses, on page 30
Backing Up Licenses, on page 40
Backing Up the License Key File, on page 41
Backing Up an Installed License, on page 41

Backing Up Licenses

If the configuration or bootflash memory on your device becomes corrupted, you might need to reinstall your license. You can do a reinstallation from a backed-up copy of the license key file. If you do not have a license key file, you can create a copy of the license key file from your installed license.



Note

If you have a single supervisor module on your Cisco NX-OS device and you replace the supervisor module, you must reinstall the license key file. You cannot reinstall the license key file from the backed-up copy.



Caution

If you erase any existing licenses installed on your device, you can reinstall them only by using the **install license** command using the license key file.



Note

Only users with the network-admin role can back up licenses on Cisco NX-OS devices. On the Cisco Nexus 7000 Series, licenses must be backed up from the default VDC (VDC 1). For information on user accounts and roles, see the *Security Configuration Guide* for your platform.

Backing Up the License Key File

You can back up your license key file to a remote server or to an external device by using the **copy** command.

This example shows how to save a license key file to a remote server:

```
switch# copy bootflash:license file.lic tftp://10.10.1.1//license file.lic
```

Some Cisco NX-OS platforms support external flash devices. This example shows how to save a license key file to an external Flash device:

```
switch# copy bootflash: license file.lic slot0: license file.lic
```

Backing Up an Installed License

You can back up your license key file to a remote server or to an external device by using the **copy** command.

This example saves all licenses installed on your device to a .tar file and copies it to a remote UNIX-based server:

```
switch# copy licenses bootflash:Enterprise.tar
Backing up license done
switch# copy bootflash:Enterprise.tar tftp://10.10.1.1//Enterprise.tar
```

You can uncompress the .tar file on the remote UNIX-based server to create one or more backup license key files, depending on how many licenses you have installed. You can also extract the license files on your Cisco NX-OS device by using the **tar extract** command.

This example shows how to extract license files from a .tar file:

```
switch# tar extract bootflash:Enterprise.tar
```

Enabling Licensed Features

You might have to enable a licensed feature to configure it. To enable a licensed feature, use the **feature** *feature-name* command in global configuration mode. For example, you can enable the BGP feature as follows:

```
switch# configure terminal
switch(config)# feature bgp
```

Identifying License Features in Use

Use the **show license usage** [package-name] command to identify all of the active features.

switch# show license usage			
Feature	Ins Lic Count	Status Expiry	Date Comments
LAN_ENTERPRISE_SERVICES_PKG	Yes -	In use Never	-
switch# show license usage L Application	AN_ENTERPRI	SE_SERVICES_PK	G
bqp			
msdp			
ospf			



Licenses are disabled if the system clock is reset. The show license usage command shows that the licensed feature is not enabled. To work around this behavior, reboot the device.

For Cisco Nexus 3000, 3500, 3600, and 9000 Series switches, the Comments field displays the time elapsed (in minutes and seconds) from when honor mode is enabled for a license package. This field is populated when a feature is enabled but the corresponding license is not installed.

switch# show license usage Feature	Ins	Lic Count		Expiry Date	Comments
FC_PORT_ACTIVATION_PKG LAN_ENTERPRISE_SERVICES_PKG	No No	0 –	Unused In use		- Honor Start 0M 33S

For Cisco Nexus 7000 or 9000 Series switches, if "license missing" appears in the output of the **show license** usage command, the license file for your device is either not installed on the internal directory of the device or contains incorrect information. Complete these steps to resolve the issue:

Validate that the license host ID and file match the chassis serial number.



Note If these do not match and you see the log on two devices, the license files are most likely swapped between the chassis. Compare the host ID and serial numbers between each chassis and move the appropriate file to the correct chassis.

- **2.** Update the license file (.lic) with the file from the bootflash.
- 3. If these steps do not work, clear the license SPROM with the clear license sprom command and reinstall the license.

For the Cisco Nexus 7000 Series, use the show license usage vdc-all license-name command to identify the features active in a VDC for a specific license.

switch# show license usage vdc-all LAN ADVANCED SERVICES PKG

Application
----bgp
ospf
bgp@2
ospf@2



Note

The "@2" after the feature name in the **show license usage vdc-all** command output indicates that the feature is enabled in VDC 2.

For the Cisco Nexus 7000 Series, use the **show license usage vdc-all** command from the default VDC to identify all of the active features in all VDCs.

switch# show license usage vdc-all

Uninstalling Licenses

You can only uninstall a permanent license that is not in use. If you try to delete a permanent license that is currently being used, the software rejects the request and issues an error message.

When you enable a Cisco NX-OS software feature, it can activate a license grace period. Uninstalling an unused license causes the grace period to come into effect. The grace period is counted from the first use of the feature without a license and is reset when a valid license file is installed.

For the Cisco Nexus 7000 Series, you can uninstall a license only from the default VDC (VDC 1).



Note

Only users with the network-admin role can uninstall licenses on Cisco NX-OS devices. For information on user accounts and roles, see the *Security Configuration Guide* for your platform.



Note

Permanent licenses cannot be uninstalled if they are currently being used. Features turned on by permanent licenses must be disabled before that license is uninstalled.



Tip

If you are using an evaluation license and would like to install a new permanent license, you can do so without service disruption and before the evaluation license expires. Removing an evaluation license immediately triggers a grace period without service disruption.



Caution

You must disable the features that are related to the feature before uninstalling a license. The delete procedure fails if the license is in use.

Step 1 Save your running configuration to a remote server by using the **copy** command.

```
switch# copy running-config tftp://server/path/filename
```

Step 2 Display a list of all installed license key files and identify the file to be uninstalled by using the **show license brief** command. In this example, the file to be uninstalled is the Enterprise.lic file.

```
switch# show license brief
Enterprise.lic
```

Step 3 Disable the features provided by the license to be uninstalled. Use the **show license usage vdc-all** *package-name* command to view the enabled features for a specified package.

```
switch# show license usage vdc-all LAN_ENTERPRISE_SERVICES_PKG
Application
-----
bgp
ospf
bgp@2
ospf@2
```

Note

For the Cisco Nexus 7000 Series, if the feature names in the **show license usage vdc-all** command output are followed by "@" and a number, that means that the feature is enabled in a nondefault VDC and must be disabled from that VDC. The number after the feature name is the nondefault VDC identifier number. Use the **show vdc** command and **switchto vdc** command to reach the nondefault VDC where you can disable the features.

Step 4 Uninstall the Enterprise lic file by using the **clear license** *filename* command, where *filename* is the name of the installed license key file.

```
switch# clear license Enterprise.lic
Clearing license Enterprise.lic:
SERVER this_host ANY
VENDOR cisco
```

Step 5 Continue uninstalling the license by entering y for yes.

```
Do you want to continue? (y/n) \boldsymbol{y} Clearing license ..done
```

The Enterprise.lic license key file is now uninstalled.

Updating Licenses

If your license is time bound, you must obtain and install an updated license. Contact technical support to request an updated license.

For the Cisco Nexus 7000 Series, you can update the license only from the default VDC (VDC 1).



Note

If you purchased Cisco support through a Cisco reseller, contact the reseller directly. If you purchased support directly from Cisco, contact Cisco Technical Support at http://www.cisco.com/en/US/support/tsd_cisco_worldwide_contacts.html.



Note

Only users with the network-admin role can update licenses on Cisco NX-OS devices. For information on user accounts and roles, see the *Security Configuration Guide* for your platform.

SUMMARY STEPS

- **1.** Obtain the updated license file.
- **2.** Save your running configuration to a remote server by using the **copy** command.
- 3. Verify the name of the file to be updated by using the **show license brief** command.
- **4.** Update the license file by using the **update license** {**bootflash:** | **slot0:** | **usb0:** | **usb1:**} *new-license-filename old-license-filename* command.
- **5.** Continue with the license update by entering \mathbf{y} (yes is the default).
- **6.** (Optional) Enable licensed features, if necessary, by using the **feature** *feature-name* command in global configuration mode. For example, you can enable the BGP feature as follows:

DETAILED STEPS

- **Step 1** Obtain the updated license file.
- **Step 2** Save your running configuration to a remote server by using the **copy** command.
- **Step 3** Verify the name of the file to be updated by using the **show license brief** command.

```
switch# show license brief
Enterprise1.lic
```

Step 4 Update the license file by using the **update license** {**bootflash:** | **slot0:** | **usb0:** | **usb1:**} *new-license-filename old-license-filename* command.

```
switch# update license bootflash:Enterprise2.lic Enterprise1.lic
```

Note Make sure to use the **install** command to install a new license and the **update** command to update a license.

Step 5 Continue with the license update by entering **y** (yes is the default).

```
Do you want to continue? (y/n) y Updating license ..done switch#
```

The Enterprise 1.lic license key file is now updated.

Step 6

(Optional) Enable licensed features, if necessary, by using the **feature** *feature-name* command in global configuration mode. For example, you can enable the BGP feature as follows:

switch# configure terminal
switch(config)# feature bgp
switch#

Related Topics

Feature-Based Licenses, on page 14 Module-based Licenses, on page 30 Obtaining the License Key File, on page 36

Configuring the Grace Period Feature

The grace period feature allows you to use licensed features that do not have a license key. By default, the license period feature is disabled. While the grace period feature is disabled, users cannot accidentally enable licensed features.



Note

The Cisco Nexus 9000 Series and Cisco Nexus 3000 Series do not support the grace period feature.

For the Cisco Nexus 7000 Series, you can enable and disable the grace period only from the default VDC (VDC 1).

On a Cisco Nexus 7000 Series switch, the grace period gets automatically started for features that do not have a license key installed (even when the **no license grace-period** command is enabled).



Note

Starting from Cisco NX-OS Releases 8.2(4) and 8.4(1), Grace period is not supported on Cisco Nexus 7000 Series switches.

For the Cisco Nexus 5000 Series, the license grace-period command is enabled by default.



Note

Only users with the network-admin role can enable the grace period on Cisco NX-OS devices. For information on user accounts and roles, see the *Security Configuration Guide* for your platform.

Grace Period Alerts

The Cisco NX-OS software gives you a 120-day grace period. This grace period starts or continues when you are evaluating a feature for which you have not installed a license. For the Cisco Nexus 7000 Series, the grace period applies to all VDCs on the physical device. If you start the grace period by enabling a licensed feature in one VDC, the grace period starts for all VDCs.

The grace period stops if you disable a feature that you are evaluating, but if you enable that feature again without a valid license, the grace period countdown continues where it left off.



Note

Starting from Cisco NX-OS Releases 8.2(4) and 8.4(1), Grace period is not supported on Cisco Nexus 7000 Series switches.



Note

To avoid service disruptions when you install the permanent license, do not disable the grace period by using the **no license grace-period** command. Instead, just install your new license. The license manager will automatically transition from grace licensing to the installed license.

Once the license manager is using your installed license, the grace period alerts will cease.

The grace period operates across all features in a license package. License packages can contain several features. If you disable a feature during the grace period and there are other features in that license package that are still enabled, the countdown does not stop for that license package. To suspend the grace period countdown for a license package, you must disable every feature in that license package. For the Cisco Nexus 7000 Series, you must disable the licensed features in all VDCs on the physical device. Use the **show license usage vdc-all** *license-name* command in the default VDC to determine which features to disable.

```
switch# show license usage vdc-all LAN_ENTERPRISE_SERVICES_PKG
Application
-----
bgp
ospf
bgp@2
ospf@2
```



Note

For the Cisco Nexus 7000 Series, if a feature name in the **show license usage vdc-all** command output is followed by "@" and a number, that means that the feature is enabled in a nondefault VDC and you must disable it from that VDC. The number after the feature name is the nondefault VDC identifier number. Use the **show vdc** command and **switchto vdc** command to reach the nondefault VDC where you can disable the feature.



Note

When you disable a feature or when the license grace period expires, the Cisco NX-OS software generates a checkpoint containing the feature configuration that you can use to reconfigure the feature when you reenable the license after you install the license or resume the grace period countdown. For more information on checkpoints, see the *System Management Configuration Guide* for your platform.

The Cisco NX-OS license counter keeps track of all licenses on a device. If you are evaluating a feature and the grace period has started, you will receive console messages, SNMP traps, system messages, and Call Home messages on a daily basis. The frequency of the messages becomes hourly during the last seven days of the grace period.

In addition to the grace period alerts, Cisco NX-OS will display a banner at login in the last 15 days of the grace period:

NOTICE: NX-OS LICENSED FEATURES NEED ATTENTION

Feature Ins Lic Status Expiry Date Comments
Count

LAN_ENTERPRISE_SERVICES_PKG No - In use Grace 14D 6H

**** WARNING: License(s) about to expire. When license(s) expire,
all licensed conditional features will be disabled ****

During the last seven days of the grace period, the banner will include a prompt which you must dismiss before you can complete login:

NOTICE: NX-OS LICENSED FEATURES NEED ATTENTION

Feature Ins Lic Status Expiry Date Comments
Count

LAN_ENTERPRISE_SERVICES_PKG No - In use Grace 3D 23H

***** WARNING: License(s) about to expire. When license(s) expire,
all licensed conditional features will be disabled ****

CISCO TAC must be contacted asap for required licenses to prevent imminent
downtime/service disruption.
Please press Enter to confirm you understand this risk and wish to continue: [ENTER]

For example, if you enabled a licensed feature on January 30, you will receive grace period ending messages as follows:

- Daily alerts from January 30 to May 21. Starting from May 15, Cisco NX-OS would display the banner at login.
- Hourly alerts from May 22 to May 30. The login banner would require you to dismiss its prompt before you can complete login.

On May 31, the grace period ends, and the licensed feature is automatically disabled. You will not be allowed to use the licensed feature until you purchase a valid license.



Note

You cannot modify the frequency of the grace period messages.



Caution

After the final seven days of the grace period, the feature is turned off and your network traffic may be disrupted. Any future upgrade to Cisco NX-OS will enforce license requirements and the 120-day grace period.

Use the **show license usage** command to display grace period information for a device.

```
switch# show license usage

Feature Ins Lic Status Expiry Date Comments

Count

LAN_ADVANCED_SERVICES_PKG Yes - In use Never -

LAN_ENTERPRISE_SERVICES_PKG No - In use Grace 119D 22H
```

Enabling the License Grace Period

Enable the grace period feature by using the **license grace-period** command:

```
switch# configure terminal
switch(config)# license grace-period
```

For the Cisco Nexus 7000 Series, you can only enable the grace period feature from the default VDC.

Related Topics

```
Feature-Based Licenses, on page 14 Module-based Licenses, on page 30
```

Disabling the License Grace Period

To disable the grace period, you must disable all features that use the license grace period. Otherwise, the Cisco NX-OS software rejects the request and issues an error message.



Note

To avoid service disruptions, you should not disable the grace period before you install a permanent license.

SUMMARY STEPS

- **1.** Display the licenses using the grace period by using the **show license usage** command. For the Cisco Nexus 7000 Series, you must work in the default VDC.
- 2. Disable the features provided by the license using the grace period. Display the enabled features for a specified package by using the **show license usage** *package-name* command. For the Cisco Nexus 7000 Series, use the **show license usagevdc-all** *package_name* in the default VDC to view the enabled features in all VDCs.
- **3.** Disable the grace period.

DETAILED STEPS

Step 1 Display the licenses using the grace period by using the **show license usage** command. For the Cisco Nexus 7000 Series, you must work in the default VDC.

```
switch# show license usage

Feature Ins Lic Count

LAN_ADVANCED_SERVICES_PKG Yes - In use Never - LAN_ENTERPRISE_SERVICES_PKG No - In use Grace 119D 22H
```

Step 2 Disable the features provided by the license using the grace period. Display the enabled features for a specified package by using the **show license usage** package-name command. For the Cisco Nexus 7000 Series, use the **show license usagevdc-all** package_name in the default VDC to view the enabled features in all VDCs.

```
switch# show license usage vdc-all LAN_ENTERPRISE_SERVICES_PKG
Application
-----
bgp
ospf
bgp@2
ospf@2
```

Note

For the Cisco Nexus 7000 Series, if a feature name in the **show license usage vdc-all** command output is followed by "@" and a number, that means that the feature is enabled in a nondefault VDC and you must disable it from that VDC. The number after the feature name is the nondefault VDC identifier number. Use the **show vdc** command and **switchto vdc** command to reach the nondefault VDC where you can disable the feature.

When you disable a feature or when the license grace period expires, the Cisco NX-OS software generates a checkpoint containing the feature configuration that you can use to reconfigure the feature when you reenable the license after you install the license or reenable the grace period. For more information on checkpoints, see the *System Management Configuration Guide* for your platform.

Step 3 Disable the grace period.

```
switch# configure terminal
switch(config)# no license grace-period
```

Associating a License with a Module

You must associate a module-based license with a module to enable the licensed features on that module.

Before you begin

- Ensure you have installed the correct license.
- Ensure you are in the correct VDC.
- Ensure you have met all required prerequisites for the feature. See the appropriate feature documentation for details.

SUMMARY STEPS

1. license fcoe module module-number

DETAILED STEPS

	Command or Action	Purpose
Step 1	license fcoe module module-number	Associates the module-based license with the module.
	Example:	
	switch(config)# license fcoe module 2	

License Transfers Between Devices

A license is specific to the physical device for which it is issued and is not valid on any other physical device. If you need to transfer a license from one physical device to another, contact your customer service representative.



Note

If you have a single supervisor module on your Cisco NX-OS device and you replace the supervisor module, you must reinstall the license key file.

If you are evaluating a license when you replace the supervisor module, the grace period of the license is usually set to 120 days. On a dual supervisor system, the grace period of the license will be overwritten from the existing active supervisor module to the new standby supervisor module.



Note

If you purchased Cisco support through a Cisco reseller, contact the reseller directly. If you purchased support directly from Cisco, contact Cisco Technical Support at this URL: http://www.cisco.com/en/US/support/tsd_cisco_worldwide_contacts.html

Verifying the License Configuration

To display the license configuration information, perform one of the following tasks:

Command	Purpose	
show license [brief]	Displays information for all installed license files.	
show license feature package mapping	Displays information about features available in installed license packages.	
	Note The Cisco Nexus 9000 Series and the Cisco Nexus 3164Q switches do not support this command.	

Command	Purpose
show license file	Displays information for a specific license file.
show license host-id	Displays the host ID for the physical device.
show license usage [license-package]	Displays the usage information for installed licenses.

Additional References

This section includes additional information related to licensing the Cisco NX-OS software.

Table 24: Applicable MIBs

MIBs	MIBs Link
CISCO-LICENSE_MGR-MIB	To locate and download MIBs, go to ftp://ftp.cisco.com/pub/mibs/supportlists/
	•

Release History for Licensing

This table lists the release history for this feature.

Table 25: Release History for Licensing

License	Release	Notes
Synchronous Ethernet (SyncE) add-on license	Cisco Nexus NX-OS Release 10.1(2)	Support for the SyncE add-on license.
C1P1TN9500M4-3Y C1P1TN9500M4-5Y C1P1TN9500M816-3Y C1P1TN9500M816-5Y (not ACI)	Cisco Nexus NX-OS Release 9.3(5)	Introduced for the Cisco Nexus 9500 Series switches.
SyncE add-on license	Cisco Nexus NX-OS Release 9.3(5)	Introduced Synchronous Ethernet (SyncE) add-on license for the Cisco Nexus 93180YC-FX3S platform switch.

License	Release	Notes
ACI-SEC-XF license	Cisco Nexus NX-OS Release 9.3(5)	Added support for Secure VXLAN EVPN Multi-Site using CloudSec licensing.
		Note Secure VXLAN EVPN Multi-Site using CloudSec licensing support is available with the ACI-SEC-XF license.
		Note For Cisco Nexus NX-OS Release 9.3(5), Secure VXLAN EVPN Multi-Site using CloudSec is supported only on Cisco Nexus 9300-FX2 platform switches,
ACI-STRG, C1-N9K-STRG-XF-3Y, and C1-N9K-STRG-XF-5Y licenses	Cisco Nexus NX-OS Release 9.3(3)	Introduced for the Cisco Nexus 93180YC-FX platform switch.
N3K-STR2K9 license	Cisco Nexus NX-OS Release 9.3(3)	Added support for the Cisco Nexus 3408-S and 3432D-S switches.
N93-LAN1K9-XF2 license	Cisco Nexus NX-OS Release 9.3(3)	Introduced for the Cisco Nexus 9300-GX switches.
NX-OS Advantage license	Cisco Nexus NX-OS Release 9.3(3)	Added support for the Cisco Nexus 3132Q (excluding the 3132Q-40GE), 3172, 3172PQ, 3172TQ, 31128PQ, 3100-V, 3232C, 3264Q, and 3500 switches.
		Note The Cisco Nexus 3132Q, 3172, 3172PQ, and 3172TQ platform switches support the NX-OS Advantage license only when running in N9K mode. You can view the switch mode using the show system switch-mode command.
NXOS-ES-XF2 and NXOS-AD-XF2 licenses	Cisco Nexus NX-OS Release 9.3(3)	Introduced for the Cisco Nexus 9300-GX switches.

License	Release	Notes
NXOS-SEC-XF license	Cisco Nexus NX-OS Release 9.3(3)	Added support for the Cisco Nexus 93216TC-FX2 and 93360YC-FX2 platform switches.
C1P1TN9300GF-3Y	Cisco Nexus NX-OS Release 9.3(2)	Introduced for the Cisco Nexus 9300
C1P1TN9300GF-5Y		Series switches.
C1P1TN9300XF-3Y		
C1P1TN9300XF-5Y		
C1P1TN9300XF2-3Y		
C1P1TN9300XF2-5Y		
Honor mode syslog in the output of the show license usage command	Cisco Nexus NX-OS Release 9.3(1)	Introduced for the Cisco Nexus 3000, 3500, 3600, and 9000 Series switches.
NX-OS Advantage license	Cisco Nexus NX-OS Release 9.3(1)	Introduced for the Cisco Nexus 3132C-Z, 3264C-E, 3636C-R, and 36180YC-R switches.
NX-OS Essentials license	Cisco Nexus NX-OS Release 9.3(1)	Introduced for the Cisco Nexus 3132C-Z, 3132Q (excluding the 3132Q-40GE), 3172, 3172PQ, 3172TQ, 31128PQ, 3100-V, 3232C, 3264C-E, 3264Q, 3464C, 34180YC, 3500, 3636C-R, and 36180YC-R switches.
NX-OS Essentials and Advantage licenses	Cisco Nexus NX-OS Release 9.3(1)	Recommended that the -XF2 licenses be purchased for Cisco Nexus 3000 Series switches and Cisco Nexus 9364C switches.
NXOS-SEC-XF license	Cisco Nexus NX-OS Release 9.3(1)	Added support for the Cisco Nexus 9332C, 9348C-FXP, and 9364C platform switches.
DCN (ACI+NX-OS) Essentials and Advantage license packages and add-on licenses	Cisco Nexus NX-OS Release 9.2(3)	Introduced for the Cisco Nexus 9300 platform switches.
N3K-LAN2K9 license	Cisco Nexus NX-OS Release 9.2(3)	Added support for the Cisco Nexus 3264C-E and 3464C switches.
N3K-STR1K9 license	Cisco Nexus NX-OS Release 9.2(3)	Added support for the Cisco Nexus 34180YC switch.
N3K-STR2K9 license	Cisco Nexus NX-OS Release 9.2(3)	Added support for the Cisco Nexus 3464C switch.

License	Release	Notes
N9K-LIC1-24P, N9K-EX-24P-UPG=, and N9K-FX-24P-UPG= licenses	Cisco Nexus NX-OS Release 9.2(3)	Added these 24-port licenses for the Cisco Nexus 93108TC-EX, 93108TC-FX, 93180YC-EX, and 93180YC-FX switches.
N3K-LAN2K9 license	Cisco Nexus NX-OS Release 9.2(2v)	Added support for the Cisco Nexus 3432D-S switch.
N3K-LAN2K9 license	Cisco Nexus NX-OS Release 9.2(2t)	Added support for the Cisco Nexus 3408-S switch.
NXOS-SEC-XF license	Cisco Nexus NX-OS Release 9.2(1)	Added this license for Cisco Nexus 9000 Series ToR switches that support MACsec.
Honor Mode Licensing	Cisco Nexus NX-OS Release 8.4(1)	Introduced for the Cisco Nexus 7000
	Cisco Nexus NX-OS Release 8.2(4)	Series switches.
ENHANCED_LAYER2_PKG license	Cisco NX-OS Release 8.2(1)	iCAM feature is available under the ENHANCED_LAYER2_PKG license on Cisco Nexus 7000 Series switches.
N95-FAB1K9 and N3K-FAB1K9 licenses	Cisco NX-OS Release 7.0(3)F3(3)	Added support for the InterAS option B and MPLS Layer 3 VPN features.
N3K-LAN1K9 license	Cisco NX-OS Release 7.0(3)F3(1)	Added support for the Cisco Nexus 3600 platform switches.
ACI Premier license packages	Cisco Nexus NX-OS Release 7.0(3)I7(7)	Introduced for the Cisco Nexus 9300 Series switches.
NX-OS Essentials and Advantage licenses	Cisco Nexus NX-OS Release 7.0(3)I7(7)	The -XF2 licenses now have priority over the -XF licenses for Cisco Nexus 3000 and 3600 Series switches and Cisco Nexus 9364C switches.
NXOS-ES-XF2, NXOS-AD-XF2, and NXOS-NDB licenses	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I7(6)	Introduced for the Cisco Nexus 9364C switch.
N93-LAN1K9-XF2 license	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I7(6)	Introduced for the Cisco Nexus 9364C switch.
NX-OS Essentials and Advantage license packages and NX-OS upgrade licenses	Cisco Nexus 9000 Series NX-OS Release 7.0(3)17(3)	Introduced for the Cisco Nexus 9000 Series switches.
NXOS-SEC-XM license	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I7(2)	Added support for the MACsec feature for Cisco EoR switches.

License	Release	Notes
FC NPV and FCoE NPV licenses	Cisco Nexus 9000 Series NX-OS Release 7.0(3)17(2)	Added support for FC and FCoE NPV.
N95-FAB1K9 and N93-FAB1K9 licenses	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I7(1)	Added support for the Pervasive Load Balancing, Tenant Routed Multicast, and VXLAN EVPN Multi-Site features.
N93-1G-LAN1K9 license	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I7(1)	Introduced this license for the Cisco Nexus N9K-C9348GC-FXP switch.
N95-SERVICES1K9 and N93-SERVICES1K9	Cisco Nexus 9000 Series NX-OS Release 7.0(3)17(1)	Added support for the iCAM feature.
N3K-FAB1K9, N95-FAB1K9, and N93-FAB1K9 licenses	Cisco Nexus 3000 and 9000 Series NX-OS Release 7.0(3)I6(1)	Added support for the Layer 3 EVPN over segment routing MPLS feature.
N95-SERVICES1K9 and N93-SERVICES1K9 licenses	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I6(1)	Added support for the catena and smart channel features.
N93-LAN1K9 license	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I4(2)	Added support for the non-blocking multicast (NMB) feature on Cisco Nexus 9236C, 9272Q, and 92160YC-X switches.
N3K-LAN1K9 license	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I4(1)	Added support for the Cisco Nexus 3100-V switches.
N95-FNPV1K9 license and N93-FNPV1K9 license	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I3(1)	Added these licenses to support FCoE NPV on Cisco Nexus 9500 and 9300 Series switches.
N93-LAN1K9 license	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I3(1)	Added support for the Cisco Nexus 9200 Series switches.
N3K-LAN1K9 license	Cisco Nexus 3232C and 3264Q NX-OS Release 7.0(3)IX1(2)	Added support for the Cisco Nexus 3232C and 3264Q switches.
N3172T-32T-LIC, N3172T-16T-UPG	Cisco Nexus 3000 Series NX-OS Release 7.0(3)I2(1)	N3172T-32T-LIC is the default 32-port license for Cisco Nexus 3172TQ switches. N3172T-16T-UPG is the 16-port upgrade license for Cisco Nexus 3172TQ switches. This is the upgrade license to enable 16 ports and it can only be applied to N3K-C3172TQ-32T.
N3K-LAN1K9 license	Cisco Nexus 3000 Series NX-OS Release 7.0(3)I2(1)	Added support for the Cisco Nexus 31128PQ switch and the Cisco Nexus 3100 Series switches in N9K mode.

License	Release	Notes
N95-LAN1K9 and N93-LAN1K9 licenses	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I2(1)	Added support for PIM bidirectional mode and Source-Specific Multicast (SSM) mode.
N6K-SERVICES1K9, N56-SERVICES1K9, and N55-SERVICES1K9	Cisco Nexus 5500, 5600, and 6000 Series NX-OS Release 7.2(0)N1(1)	Added these licenses to support the Intelligent Traffic Director (ITD) and Remote Integrated Services Engine (RISE) on the Cisco Nexus 5500, 5600 and 6000 Series switches.
N95-SERVICES1K9 license and N93-SERVICES1K9 license	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I1(2)	Added these licenses to support the Intelligent Traffic Director (ITD) on the Cisco Nexus 9500 and 9300 Series switches.
N95-LAN1K9 license	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I1(2)	Added VXLAN and BGP eVPN control plane support for the Cisco Nexus 9500 Series switches.
FCoE F3 Series	Cisco Nexus 7000 Series NX-OS Release 7.2(0)D1(1)	Added licenses for FCoE on F3 Series modules.
MPLS	Cisco Nexus 7000 Series NX-OS Release 7.2(0)D1(1)	Added license for MPLS on Cisco Nexus 7700 switches.
N93-LAN1K9 license and N3K-LAN1K9 license	Cisco Nexus 9000 Series NX-OS Release 7.0(3)I1(1)	Added support for the BGP eVPN control plane for the Cisco Nexus 9300 Series switches and the Cisco Nexus 3164Q switch.
N95-LAN1K9 license, N93-LAN1K9 license, and N3K-LAN1K9 license	Cisco Nexus 9000 Series NX-OS Release 6.1(2)I3(1)	Added support for policy-based routing.
N3K-LAN1K9 license	Cisco Nexus 9000 Series NX-OS Release 6.1(2)I2(2a)	Added support for the Cisco Nexus 3164Q switch.
N93-LAN1K9 license	Cisco Nexus 9000 Series NX-OS Release 6.1(2)I2(1)	Added the license for the Cisco Nexus 9300 Series switches.
N95-LAN1K9 license	Cisco Nexus 9000 Series NX-OS Release 6.1(2)I1(1)	Added the license for the Cisco Nexus 9500 Series switches.
N77-LAN1K9 license	Cisco Nexus 7000 Series NX-OS Release	Added licenses for the Cisco Nexus
N77-VDC1K9 license	6.2(2)	7718 switch and the Cisco Nexus 7710 switch.
N77-EL21K9 license		
N77-SAN1K9 license		
Layer 3 Base Services Package	Cisco Nexus 3548 Switch NX-OS Release 5.0(3)A1(1)	Added the Cisco Nexus 3548 Layer 3 Base License.

License	Release	Notes
Layer 3 Enterprise Services Package	Cisco Nexus 3548 Switch NX-OS Release 5.0(3)A1(1)	Added the Cisco Nexus 3548 Layer 3 Enterprise License.
NAT, Warp Mode, Warp SPAN	Cisco Nexus 3548 Switch NX-OS Release 5.0(3)A1(1)	Added the new 3500 Algo Boost License.
N7K-C7004-XL license	Cisco Nexus 7000 Series NX-OS Release 6.1(2)	Added the Cisco Nexus 7004 Scalable Feature License.
VDC and FCoE F2 Series	Cisco Nexus 7000 Series NX-OS Release 6.1(1)	Added licenses for VDCs and FCoE on F2 Series modules. Removed Cisco TrustSec from the
		Advanced Services Package.
MPLS, LISP, and FCoE	Cisco Nexus 7000 Series NX-OS Release 5.2(1)	Added licenses for the MPLS, LISP, and FCoE features.
Grace period	Cisco Nexus 7000 Series NX-OS Release 4.2(1)	Automatic checkpoints are created for configured licensed features when the grace period expires.



Smart Software Licensing for Cisco Nexus 7000 Series Switches

This chapter provides an overview of Smart Software Licensing and describes the tools and processes required to complete the registration and authorization for Cisco Nexus 7000 Series Switches.

- Finding Feature Information, on page 59
- Information About Smart Software Licensing, on page 60
- Guidelines and Limitations for Smart Software Licensing, on page 61
- Smart Accounts and Virtual Accounts, on page 61
- Smart Software Manager Overview, on page 61
- Smart Call Home Overview, on page 62
- Smart Software Manager Satellite, on page 62
- Requesting a Smart Account, on page 63
- Adding a User to a Smart Account, on page 64
- Converting a Traditional License to a Smart License, on page 64
- Converting a Traditional License to a Smart License—CLI Version, on page 65
- Configuring Smart Software Licensing, on page 66
- Configuring Smart Call Home for Smart Software Licensing, on page 69
- Verifying Smart Software Licensing, on page 69
- Configuration Examples for Smart Software Licensing, on page 70
- Verification Examples for Smart Software Licensing, on page 70
- Use Cases for Smart Software Licensing, on page 74
- Additional References for Smart Software Licensing, on page 76
- Feature History for Smart Software Licensing, on page 77

Finding Feature Information

Your software release might not support all the features documented in this module. For the latest caveats and feature information, see the Bug Search Tool at https://tools.cisco.com/bugsearch/ and the release notes for your software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature History for Smart Software Licensing table.

Information About Smart Software Licensing

Smart Software Licensing Overview

Introduction to Smart Licensing

Cisco Smart Licensing is a flexible licensing model that provides you with an easier, faster, and more consistent way to purchase and manage software across the Cisco portfolio and across your organization. And it's secure – you control what users can access. With Smart Licensing you get:

- Easy Activation: Smart Licensing establishes a pool of software licenses that can be used across the entire organization—no more PAKs (Product Activation Keys).
- Unified Management: My Cisco Entitlements (MCE) provides a complete view into all of your Cisco products and services in an easy-to-use portal, so you always know what you have and what you are using.
- License Flexibility: Your software is not node-locked to your hardware, so you can easily use and transfer licenses as needed.

To use Smart Licensing, you must first set up a Smart Account on Cisco Software Central (software.cisco.com). For a more detailed overview on Cisco Licensing, go to cisco.com/go/licensingguide.

Traditional Licensing Overview

Traditional licensing at Cisco is a legacy licensing model based on Product Activation Keys (PAK) and Unique Device Identifiers (UDI). On most Cisco NX-OS 7000 Series Switches, capacity needs are assessed prior to obtaining and installing a .tar file on switches to retrieve the UDI. Customers place an order for a PAK, and the PAK is emailed to the user. A combination of them. UDI and PAK is used to receive a license file that is installed in the boot directory of the switch to complete the installation of the Cisco NX-OS software.

The License Registration Portal (LRP) is available to help migrate traditional licenses to smart licenses. To access the LRP, obtain training, and manage licenses, go to http://tools.cisco.com/SWIFT/LicensingUI/Home.

You can convert the traditional license to a smart license in the following ways:

- Converting a Traditional License to a Smart License, on page 64
- Converting a Traditional License to a Smart License—CLI Version, on page 65

Comparing Licensing Models

Two types of licensing models are used for the Cisco Nexus 7000 Series Switches—traditional licensing and Smart Software Licensing.

Table 26: Comparison Between Traditional Licensing and Smart Software Licensing

Description Traditional Licensing Smart Software Licensing	
--	--

License instance node locked to the product instance	Yes	No
Product registration upon configuration	No	Yes
Offers tools to report, monitor, own, and consume	No	Yes
Requires Smart Call Home	No	Yes

Guidelines and Limitations for Smart Software Licensing

- You cannot use both traditional licensing and Smart Software Licensing at the same time on the Cisco Nexus 7000 Series Switches.
- Smart Software Licensing is not supported on Cisco N-Port Virtualizer (Cisco NPV) devices.
- Port licenses will be in out-of-compliance state when you move from a traditional license to a Smart Software License.

Smart Accounts and Virtual Accounts

• A Smart account provides you with a single location for all smart-account enabled products and licenses. It assists you in speedy procurement, deployment, and maintenance of your Cisco software.

If you are requesting a Smart account on behalf of an organization, you must have the authority to represent the requesting organization when creating a Smart account. After submitting the request, the request goes through an approval process before you are provided with access to your Smart account.

Go to http://software.cisco.com to learn about, set up, and manage a Smart account.

• A virtual account is a subaccount within a Smart account. You can define the virtual account's structure based on organizational layout, business function, geography, or any defined hierarchy. Virtual accounts can be created and maintained only by Smart account administrators.

Smart Software Manager Overview

Smart Software Manager enables the management of software licenses and Smart accounts from a single portal. The interface allows you to activate your product, manage entitlements, renew, and upgrade software. An active Smart account is required to complete the registration process. To access the Smart Software Manager, go to http://www.cisco.com/web/ordering/smart-software-manager/index.html.

You must add the following information in the Smart Software Manager:

• Trusted Unique Identifier—This is the device ID (Secure Unique Device Identifier (SUDI)).

- Organizational Identifier—This is a numerical format to associate a product with a Smart account or Virtual account.
- Licenses consumed—Allows the Smart Software Manager to understand the license type and the level
 of consumption.

Smart Call Home Overview



Note

You must configure the DNS client and virtual routing and forwarding (VRF) before using Smart Call Home. For more information, see Configuring a DNS Client and Configuring a VRF To Send a Message Using HTTP.

Use the Smart Call Home feature to communicate with the Smart Software Manager. Smart Call Home is enabled automatically when you configure Smart Software Licensing. On Cisco Nexus 7000 Series Switches, Smart Software Licensing is not enabled by default.

The Smart Call Home (SCH) server runs on the Cisco Smart Software Manager (CSSM) satellite by default. You can access this service using the following URL:

https://<CSSM satllite IP>/Transportgateway/services/DeviceRequestHandler

Provide this URL as part of Smart Call Home configuration so that the device registration works with the CSSM satellite. For a sample configuration, see Configuration Examples for Smart Software Licensing.

Smart Call Home creates a CiscoTAC-1 profile. The associated Smart Call Home messages are sent to the Smart Software Manager only after enabling Smart Call Home. For switches in which Smart Software Licensing is enabled by default, Smart Call Home is also enabled by default, along with the associated messages.

To disable Smart Software Licensing, see Disabling Smart Software Licensing.

Smart Software Manager Satellite

Smart Software Manager satellite is a component of Smart Software Licensing and works in conjunction with the Smart Software Manager to manage software licenses. You can intelligently manage product licenses and get near real-time visibility and reports pertaining to the Cisco licenses you purchased and consumed.

If you do not want to manage your installed base using a direct Internet connection, the Smart Software Manager satellite will be installed on your premises to provide a subset of the Smart Software Manager functionality. You can download the satellite application, deploy it, and register it with the Smart Software Manager.

You can perform the following functions using the satellite application on your premises:

- · Activate or register a license
- Get visibility to your company's licenses
- Transfer licenses between company entities

To learn more about the Smart Software Manager satellite, go to http://www.cisco.com/go/smartsatellite.

Requesting a Smart Account

Requesting a Smart account is a one-time process. Subsequent management of users is a capability provided through the tool.

Before you begin

Ensure that you have a Cisco Employee Connection (CEC) ID.

- **Step 1** Go to http://software.cisco.com, and log in to your account.
- Step 2 Click the Request a Smart Account link in the Administration section.
- **Step 3** Perform one of the following tasks to select the Account Approver:
 - To select yourself as the approver, click Yes, I will be the Approver for the account option.
 - To select a different person as the approver, click **No, the person specified below will be the Approver for the account** option and specify the person's email ID.

Note The specified approver must have the authority to enter legal agreements. The approver serves as the primary owner and nominates account administrators.

- **Step 4** Depending on the approver type, perform one of the following procedures:
 - If you are the approver, perform the following tasks:
 - a. Enter Account Name, Company/Organization Name, Country, and State/Province/Region information.
 - **b.** (Optional) Click **Edit**.
 - c. In the Edit Account Identifier window, enter a valid Proposed Domain Identifier and Contact Phone Number, and click OK.

Note The default domain identifier is the approver's email domain. If you edit the domain identifier, the change goes through a manual approval process.

- d. Click Continue to select the legal address to be linked to your Smart account.
- If you are not the approver, perform the following procedure:
- a. Enter the Account Name and an optional Message to the approver.
- **b.** (Optional) Click **Edit**.
- c. In the Edit Account Identifier window, enter a valid Proposed Domain Identifier, and click OK.

Note The default domain identifier is the approver's email domain. If you edit the domain identifier, the change goes through a manual approval process.

- d. Click Continue.
- e. Follow the instructions in the email that is sent to you to complete the request.

Adding a User to a Smart Account

Smart account user management is available in the **Administration** section of Cisco Software Central.

- Step 1 Go to http://software.cisco.com, and log in to your account.Step 2 Click the Manage Smart Account link in the Administration section.
- Step 3 Click the Users tab.
- Step 4 Click New User.
- **Step 5** Provide the required information in the **New User** section.
 - (Define roles to manage the entire Smart account or specific virtual accounts.)
- Step 6 Click Continue.

Converting a Traditional License to a Smart License

Traditional licenses associated with Product Activation Keys (PAK) can be converted to Smart Licenses. Access Traditional licenses through the License Registration Portal by clicking the **PAKs/Tokens** tab, and then use the information provided in this section to convert PAKs to smart licenses.

- **Step 1** Go to http://software.cisco.com, and log in to your account.
- **Step 2** Click the **Traditional Licensing** link in the **License** section.

You will be redirected to the LRP window.

- **Step 3** Click the **PAKs/Tokens** tab under **Manage**, if it is not already selected.
- **Step 4** Check the **PAK/Token ID** check box.
- Step 5 Select Convert to Smart Entitlements from the Actions drop-down menu.
- **Step 6** Select a smart account from the **Smart Account** drop-down list.

Note You can view only the smart accounts that are assigned to you.

- **Step 7** Select a virtual account from the **Virtual Account** drop-down list.
 - **Note** You can view only the virtual accounts that are assigned to you.
- Step 8 Click Assign.

The selected PAK will be converted to a smart license.

Converting a Traditional License to a Smart License—CLI Version

Traditional licenses associated with Product Activation Keys (PAK) can be converted to smart licenses using CLI.

Before you begin

- Ensure that Smart Software Licensing is enabled.
- Ensure that you have a valid smart account.
- Ensure that you have valid user rights for the smart account.

Step 1 switch# license smart conversion start

Starts a manual conversion of a traditional license to a smart license. The conversion takes place in the background. After the conversion succeeds or fails, a system log message is displayed on the switch console.

Step 2 (Optional) switch# license smart conversion stop

Stops the manual conversion.

Step 3 (Optional) switch# show license status

Displays the license conversion status. If you run this command from an active device in an high availability (HA) configuration, this will display the status of all the devices in the HA configuration.

Converting a Traditional License to a Smart License—CLI Version

The following example shows how to convert a traditional license to a smart license using the CLI:

```
switch# license smart conversion start
```

Smart License Conversion process is in progress. Use the 'show license status' command to check the progress and result.

The following example shows how to stop the process of converting a traditional license to smart license using the CLI:

The following example shows the status of the license conversion for a standalone device:

```
switch# license smart conversion stop
stop manual conversion failed:
Some Smart Licensing Conversion jobs stopped successfully.
```

The following example shows the status of line conversion for a standalone device:

```
switch# show license status
```

Smart Licensing is ENABLED. Registration: Status: REGISTERED Smart Account: Big-U University

Virtual Account: Physics

Export-Controlled Functionality: Not Allowed

Initial Registration: SUCCEEDED on Feb 24 23:30:12 2014 PST
Last Renewal Attempt: SUCCEEDED on Feb 24 23:30:12 2014 PST

Next Renewal Attempt: Aug 24 23:30:12 2014 PST Registration Expires: Feb 24 23:30:12 2015 PST

!The following show output is applicable from Cisco NX-OS Release 8.2(1) onwards!

Smart License Conversion:

Automatic Conversion Enabled: False

Status: SUCCEEDED on Jan 1 00:00:00 1970 UTC

License Authorization:

Status: AUTHORIZED on Aug 31 17:04:56 2017 UTC

Last Communication Attempt: SUCCEEDED on Aug 31 17:04:56 2017 UTC

Next Communication Attempt: Sep 30 17:04:56 2017 UTC

Communication Deadline: Nov 29 16:58:31 2017 UTC

Configuring Smart Software Licensing

Configuring a DNS Client

Procedure

	Command or Action	Purpose
Step 1	switch# configure terminal	Enters global configuration mode.
Step 2	switch(config)# ip domain-lookup	Enables DNS-based address translation.
Step 3	switch(config)# ip domain-name name [use-vrf vrf-name]	Defines the default domain name that Cisco NX-OS uses to resolve unqualified host names. You can also define a virtual routing and forwarding (VRF) that Cisco NX-OS uses to resolve this domain name if it cannot be resolved in the VRF that you configured this domain name under. Cisco NX-OS appends the default domain name to any hostname that does not contain a complete domain name before starting a domain-name lookup.
Step 4	switch(config)# ip name-server address1 [address2 address6] [use-vrf vrf-name]	Defines up to six name servers. The address can be either an IPv4 address or an IPv6 address. You can optionally define a VRF that Cisco NX-OS uses to reach this name server if it cannot be reached in the VRF that you configured this name server under.
Step 5	switch(config)# vrf context vrf-name	Creates a VRF and enters VRF configuration mode.
Step 6	switch(config-vrf)# ip domain-name name [use-vrf vrf-name]	Defines the default domain name that Cisco NX-OS uses to complete unqualified host names. You can optionally define a VRF that Cisco NX-OS uses to resolve this domain

	Command or Action	Purpose
		name if it cannot be resolved in the VRF that you configured this domain name under.
		Cisco NX-OS appends the default domain name to any hostname that does not contain a complete domain name before starting a domain-name lookup.
Step 7	switch(config-vrf)# ip name-server address1 [address2 address6] [use-vrf vrf-name]	Defines up to six name servers. The address can be either an IPv4 address or an IPv6 address.
		You can also define a VRF that Cisco NX-OS uses to reach this name server if it cannot be reached in the VRF that you configured this name server under.

Configuring a VRF To Send a Message Using HTTP

Procedure

	Command or Action	Purpose
Step 1	switch# configure terminal	Enters global configuration mode.
Step 2	switch(config)# callhome	Enters Call Home configuration mode.
Step 3	switch(config-callhome)# transport http use-vrf vrf-name	Configures the VRF used to send email and other Smart Call Home messages over HTTP.

Enabling Smart Software Licensing

Step 1 switch# configure terminal.

Enters global configuration mode.

- **Step 2** Use one of the following commands to enable Smart Software Licensing:
 - switch(config)# license smart enable
 - switch(config)# feature license smart

Enables Smart Software Licensing.

Disabling Smart Software Licensing

Step 1 switch# **configure terminal**.

Enters global configuration mode.

Step 2 Use one of the following commands to disable Smart Software Licensing:

- switch(config)# no license smart enable
- switch(config)# no feature license smart

Disables Smart Software Licensing.

Registering a Device

Before you begin

- Ensure that Smart Software Licensing is enabled.
- Ensure that you have the token to be used to register your device to the smart account.

switch# license smart register idtoken token [force]

Registers your device to the smart account using the token.

Renewing Device Registration

switch# license smart renew ID

Renews the device registration.

Renewing Device Authorization

switch# license smart renew auth

Renews the device authorization.

Unregistering a Device

switch# license smart deregister

Unregisters a device.

Configuring Smart Call Home for Smart Software Licensing

Viewing a Smart Call Home Profile

switch# show callhome smart-licensing

Displays the Smart Call Home profile.

Enabling Smart Call Home Data Privacy

Step 1 switch# configure terminal

Enters global configuration mode.

Step 2 switch(config)# callhome

Enters Call Home configuration mode.

Step 3 switch(config-callhome)# data-privacy hostname

Enables Call Home data privacy.

Verifying Smart Software Licensing

Verify Smart Software Licensing using the following commands:

Commands	Purpose
show license all	Displays all smart license agent information.
show license status	Displays the smart license agent status.
show license summary	Displays a summary of the smart license agent status.
show license tech support	Gathers information for troubleshooting.
show license udi	Displays device UDI information.
show license usage	Displays show license usage table information.
show tech-support license	Displays licensing technical support information.

Configuration Examples for Smart Software Licensing

This example shows how to register your device with the Cisco portal and enable Smart Software Licensing:



Note

To avoid any issues during registering your device, ensure to check if the name server is reachable before registering your device.

```
switch# configure terminal
switch(config)# ip domain-lookup
switch(config)# ip domain-name cisco.com
switch(config)# ip name-server 171.70.168.183 use-vrf management
switch(config)# vrf context management
switch(config-vrf)# ip domain-name cisco.com
switch(config-vrf)# ip name-server 171.70.168.183
switch(config-vrf)# exit
switch(config)# callhome
switch(config-callhome)# transport http use-vrf management
switch(config-callhome)# exit
switch(config)# feature license smart
```

This example shows how to disable Smart Software Licensing:

```
switch# configure terminal
switch(config)# no feature license smart
```

This example shows how to register a device:

```
switch# configure terminal
switch(config)# license smart register idtoken sampletokenID
register status: Registration process is in progress. Use the 'show license status' command
to check the progress and result
```

This example shows how to unregister a device:

```
switch# license smart deregister
```

This example shows how to provide the URL for CSSM satellite as part of smart call home configuration:

```
switch(config-callhome)# destination-profile CiscoTAC-1 ?
alert-group Add alert group
email-addr Add email addr
http Add http or https url
transport-method Callhome message sending transport-method
destination-profile CiscoTAC-1 http https://10.83.111.51/Transportgateway/
services/DeviceRequestHandler*
```



Note

* The IP address should have the format: https://<CSSM satllite IP>/Transportgateway/services/DeviceRequestHandler

Verification Examples for Smart Software Licensing

These examples show how to verify Smart Software Licensing:

```
switch# show license status
Smart Licensing is ENABLED
Registration:
  Status: REGISTERED
  Smart Account: Cisco Systems, Inc.
 Virtual Account: NexusSmartLicensing Test
  Export-Controlled Functionality: Allowed
  Initial Registration: SUCCEEDED on Dec 14 10:43:33 2016 UTC
  Last Renewal Attempt: None
  Next Renewal Attempt: Jun 12 10:43:32 2017 UTC
  Registration Expires: Dec 14 08:07:20 2017 UTC
License Authorization:
  Status: AUTHORIZED on Dec 14 10:43:48 2016 UTC
  Last Communication Attempt: SUCCEEDED on Dec 14 10:43:48 2016 UTC
  Next Communication Attempt: Jan 13 10:43:47 2017 UTC
  Communication Deadline: Dec 14 08:07:20 2017 UTC
switch# show callhome smart-licensing
Current smart-licensing transport settings:
 Smart-license messages: enabled
Profile: CiscoTAC-1 (status: ACTIVE)
switch# show license summary
Smart Licensing is ENABLED
Registration:
 Status: REGISTERED
  Smart Account: Cisco Systems, Inc.
  Virtual Account: NexusSmartLicensing_Test
  Export-Controlled Functionality: Allowed
License Authorization:
  Status: AUTHORIZED on Dec 14 10:43:48 2016 UTC
  Last Communication Attempt: SUCCEEDED
  Next Communication Attempt: Jan 13 10:43:47 2017 UTC
  Communication Deadline: Dec 14 08:07:20 2017 UTC
switch# show license all
Smart Licensing Status
_____
Smart Licensing is ENABLED
Registration:
 Status: REGISTERED
  Smart Account: Cisco Systems, Inc.
  Virtual Account: NexusSmartLicensing Test
 Export-Controlled Functionality: Allowed
  Initial Registration: SUCCEEDED on Dec 14 10:43:33 2016 UTC
  Last Renewal Attempt: None
  Next Renewal Attempt: Jun 12 10:43:32 2017 UTC
  Registration Expires: Dec 14 08:07:20 2017 UTC
License Authorization:
  Status: AUTHORIZED
```

```
Last Communication Attempt: SUCCEEDED on Dec 14 10:43:48 2016 UTC
 Next Communication Attempt: Jan 13 10:43:48 2017 UTC
 Communication Deadline: Dec 14 08:07:21 2017 UTC
License Usage
_____
Product Information
______
UDT: SN:JAF1428DTAH
Agent Version
_____
Smart Agent for Licensing: 1.6.6 rel/88
switch# show license tech support
Smart Licensing Status
______
Smart Licensing is ENABLED
Registration:
 Status: REGISTERED
 Smart Account: Cisco Systems, Inc.
 Virtual Account: NexusSmartLicensing Test
 Export-Controlled Functionality: Allowed
 Initial Registration: SUCCEEDED on Dec 14 10:43:33 2016 UTC
 Last Renewal Attempt: None
 Next Renewal Attempt: Jun 12 10:43:32 2017 UTC
 Registration Expires: Dec 14 08:07:20 2017 UTC
License Authorization:
 Status: AUTHORIZED on Dec 14 10:43:48 2016 UTC
  Last Communication Attempt: SUCCEEDED on Dec 14 10:43:48 2016 UTC
 Next Communication Attempt: Jan 13 10:43:47 2017 UTC
 Communication Deadline: Dec 14 08:07:20 2017 UTC
Evaluation Period:
  Evaluation Mode: Not In Use
 Evaluation Period Remaining: 89 days, 23 hours, 59 minutes, 7 seconds
License Usage
==========
Product Information
______
UDI: SN:JAF1428DTAH
Agent Version
_____
Smart Agent for Licensing: 1.6.6 rel/88
Upcoming Scheduled Jobs
_____
Current time: Dec 15 08:44:44 2016 UTC
IdCert Expiration Warning: Oct 15 08:07:20 2017 UTC (303 days, 23 hours, 22 minu
tes, 36 seconds remaining)
Daily: Dec 15 10:26:50 2016 UTC (1 hours, 42 minutes, 6 seconds remaining)
Certificate Renewal: Jun 12 10:43:32 2017 UTC (179 days, 1 hours, 58 minutes, 48
seconds remaining)
Reservation configuration mismatch between nodes in HA mode: Not Available
Certificate Expiration Check: Dec 14 08:07:20 2017 UTC (363 days, 23 hours, 22 m
inutes, 36 seconds remaining)
```

```
Authorization Renewal: Jan 13 10:43:47 2017 UTC (29 days, 1 hours, 59 minutes, 3
 seconds remaining)
Authorization Expiration Check: Dec 14 08:07:20 2017 UTC (363 days, 23 hours, 22
minutes, 36 seconds remaining)
Init Flag Check: Not Available
Register Period Expiration Check: Not Available
Ack Expiration Check: Not Available
License Certificates
Production Cert: True
PIID: 27dc6a49-9745-4c7c-86de-d1dbd31e58ac
Licensing Certificated:
    Id certificate Info:
        Start Date: Dec 14 08:07:22 2016 UTC
        Expiry Date: Dec 14 08:07:22 2017 UTC
        Version Number: 3
        Serial Number: 727430
        Common Name: 9c172927d1806d05694c1f434b40ec0fbef93abb::2
    Signing certificate Info:
        Start Date: Sep 11 19:05:34 2013 UTC
        Expiry Date: Dec 7 07:00:15 2069 UTC
        Version Number: 3
        Serial Number: 3
        Common Name: MMI Signer
    Sub CA Info:
        Start Date: Sep 11 19:06:30 2013 UTC
        Expiry Date: Dec 7 07:00:15 2069 UTC
        Version Number: 3
        Serial Number: 2
        Common Name: Smart Licensing CA
    Root Cert Info:
        Start Date: May 30 19:48:47 2013 UTC
        Expiry Date: Dec 7 07:00:15 2069 UTC
        Version Number: 3
        Serial Number: 1
        Common Name: Cisco Licensing Root CA
HA Info
_____
RP Role: Active
Chassis Role: Active
Behavior Role: Active
RMF: True
CF: True
CF State: Stateless
Other Info
_____
Software ID: regid.2015-09.com.cisco.Nexus 7000,1.0 6e2b6ed8-fe9b-48e0-a71f-74ea
Agent State: authorized
TS enable: True
Transport: Callhome
Locale: C
Debug flags: 0x7
Privacy Send Hostname: True
Privacy Send IP: True
Build type:: Production
```

```
sizeof(char) : 1
sizeof(int)
             : 4
sizeof(long) : 4
sizeof(char *): 4
sizeof(time t): 4
sizeof(size t): 4
Endian: Little
Write Erase Occurred: False
XOS version: 0.11.0.0
Reservation enable: False
Reservation in progress: False
Reservation type: None
Reservation request code: <empty>
Reservation authorization code: <empty>
Reservation return code: <empty>
Config Persist Received: True
Message Version: 1.1
switch# show license udi
UDI: SN:JAF1428DTAH
switch# show license usage
License Authorization:
 Status: AUTHORIZED on Dec 15 08:45:50 2016 UTC
(LAN ENTERPRISE SERVICES PKG):
  Description: LAN license for Nexus 7000,7700 Platforms
  Count: 1
  Version: 1.0
  Status: AUTHORIZED
switch# show running-config callhome
!Time: Thu Dec 15 08:55:26 2016
version 8.0(1)
callhome
  email-contact sch-smart-licensing@cisco.com
  destination-profile CiscoTAC-1 transport-method http
  destination-profile CiscoTAC-1 http https://tools.cisco.com/its/service/oddce/
services/DDCEService
  transport http use-vrf management
  enable
```

Use Cases for Smart Software Licensing

Scenario 1

1. Configure and order a Cisco Nexus 7000 Series Switch with licenses and select the Cisco NX-OS release that will be preinstalled on the hardware prior to shipment.



Note

To convert the preinstalled licenses on the hardware to smart licenses, you must have a Smart Account set up, and then convert the licenses by going to the License Registration Portal.

- 2. Click the Devices tab under the Manage section. Click the corresponding Device ID, and choose Convert to Smart Entitlements from the Device ID drop-down list. This will convert all the licenses that are preinstalled on the switch to smart licenses. Note that this task must be performed for each switch that you want to convert to smart license.
- **3.** The service will validate if license Stock Keeping Units (SKUs) on the switch have been mapped to smart licenses before proceeding with the conversion.
- **4.** Enable smart mode on the switch and start using the smart licenses.

Scenario 2

- 1. Configure and order a Cisco Nexus 7000 Series Switch with licenses and select the Cisco NX-OS release that will be preinstalled in the hardware prior to shipment.
- 2. Upgrade the switch to Cisco NX-OS Release 8.0(1).



Note

To convert the preinstalled licenses on the hardware to smart licenses, you must have a Smart account set up and then perform the conversion by going to the License Registration Portal.

- 3. Click the **Devices** tab under the **Manage** section. Click the corresponding Device ID, and choose **Convert to Smart Entitlements** from the Device ID drop-down list. This will convert all the licenses that are preinstalled on the switch to smart licenses. Note that this task must be performed for each switch that you want to convert to smart license.
- **4.** The service will validate if license SKUs on the switch are mapped to smart licenses before proceeding with the conversion.
- 5. You enable smart mode on the switch and start using the smart licenses.

Scenario 3

 Order a spare license SKU and do not associate a Smart account to the order in Cisco Commerce Workspace (CCW).



Note

You must have a Smart account set up before using Smart Software Licensing.

- 2. Get a PAK delivered to yourself and load it to your Smart account.
- 3. License Registration Portal service will validate if a spare license SKU is mapped to a smart license.
- **4.** The Smart Software Manager (SSM) will notify you via email that your Smart Account has licenses that can be fulfilled as traditional licenses or smart licenses.

- **5.** Specify the PAKs as smart licenses in SSM.
- **6.** Ensure that Cisco NX-OS Release 8.0(1) is installed on the switch, enable smart mode, and start using the smart entitlements.

Scenario 4

- 1. Order a spare license SKU and assign a Smart account to the order in CCW.
- 2. The existing License Registration Portal service will auto deposit the PAK to the LRP Smart account.
- **3.** License Registration Portal service will validate if the spare license SKU has been mapped to smart entitlements. If the spare license SKU are mapped to smart entitlements, the service sends out a confirmation notification to CSSM.
- **4.** The Smart Software Manager will notify you via email that your Smart Account has licenses that can be fulfilled as traditional licenses or smart licenses.
- 5. Specify the PAKs as Smart Software Licenses in SSM.
- **6.** Ensure that Cisco NX-OS Release 8.0(1) is installed on the switch, enable smart mode, and start using the smart licenses.

Additional References for Smart Software Licensing

Table 27: Technical Assistance

Description	Link
Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.	http://www.cisco.com/cisco/web/support/index.html
To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.	
Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.	
License Registration Port (LRP) documentation	https://www.cisco.com/web/fw/tools/swift/xui/html/help.html

Feature History for Smart Software Licensing

Feature Name	Release	Feature Information
Smart Software Licensing with Satellite	8.4(2)	This feature was introduced.
Converting a Traditional License to a Smart License—CLI Version	8.2(1)	This feature was introduced.
Subscription-based Licensing	8.2(1)	This feature was introduced.
Smart Software Licensing	8.0(1)	Smart Software Licensing is a standardized licensing platform that simplifies the Cisco software experience and helps you understand how Cisco software is used across your network. Smart Software Licensing is the next generation licensing platform for Cisco Nexus 7000 Series Switches.
		The following commands were introduced in this feature:
		• feature license smart
		• license smart deregister
		• license smart enable
		• license smart register
		• license smart renew
		• show license all
		• show license status
		• show license summary
		• show license tech support
		• show license udi
		• show license usage

Feature History for Smart Software Licensing



Smart Software Licensing for Cisco Nexus 3000 and 9000 Series Switches

This chapter provides an overview of Smart Software Licensing and describes the tools and processes required to complete the registration and authorization for Cisco Nexus 3000 and 9000 Series Switches.

- Smart Software Licensing Overview, on page 79
- Traditional Licensing Overview, on page 83
- Comparing Licensing Models, on page 83
- Guidelines and Limitations for Smart Software Licensing, on page 84
- Setting Up Smart Accounts, on page 84
- Converting a Traditional License to a Smart License, on page 86
- Converting a Traditional License to a Smart License—DLC (Device Led Conversion), on page 87
- Configuring Smart Call Home for Smart Software Licensing, on page 88
- Configuring Smart Software Licensing, on page 90
- Verifying Smart Software Licensing, on page 91
- Verification Examples for Smart Software Licensing, on page 91
- Configuration Examples for Smart Software Licensing, on page 95
- Use Cases for Smart Software Licensing, on page 96
- Additional References for Smart Software Licensing, on page 98
- Feature History for Smart Software Licensing, on page 98

Smart Software Licensing Overview

Introduction to Smart Licensing

Cisco Smart Licensing is a flexible licensing model that provides you with an easier, faster, and more consistent way to purchase and manage software across the Cisco portfolio and across your organization. And it's secure – you control what users can access. With Smart Licensing you get:

- Easy Activation: Smart Licensing establishes a pool of software licenses that can be used across the entire organization—no more PAKs (Product Activation Keys).
- Unified Management: My Cisco Entitlements (MCE) provides a complete view into all of your Cisco products and services in an easy-to-use portal, so you always know what you have and what you are using.

• License Flexibility: Your software is not node-locked to your hardware, so you can easily use and transfer licenses as needed.

To use Smart Licensing, you must first set up a Smart Account on Cisco Software Central (software.cisco.com). For a more detailed overview on Cisco Licensing, go to cisco.com/go/licensingguide.

Smart Software Manager

The Cisco Smart Software Manager (CSSM) enables the management of software licenses and Smart accounts from a single portal. The interface allows you to activate your product and manage entitlements and prevent license violations, expiry of subscription-based licenses, and out-of-compliance licenses. An active Smart account is required to complete the registration process. To access the Smart Software Manager, go to http://www.cisco.com/web/ordering/smart-software-manager/index.html.

You must add the following information in the Smart Software Manager:

- Trusted Unique Identifier—This is the device ID [Secure Unique Device Identifier (SUDI)].
- Organizational Identifier—This is a numerical format to associate a product with a Smart account or Virtual account.
- Licenses consumed—Allows the Smart Software Manager to understand the license type and the level
 of consumption.

Smart Software Manager On-Prem

Smart Software Manager On-Prem is a component of Smart Software Licensing and works in conjunction with the Smart Software Manager to manage software licenses. You can intelligently manage product licenses and get near real-time visibility and reports pertaining to the Cisco licenses you purchased and consumed.

If you do not want to manage your installed base using a direct Internet connection, Smart Software Manager On-Prem will be installed on your premises to provide a subset of the Smart Software Manager functionality. You can download the application, deploy it, and register it with the Smart Software Manager.

You can perform the following functions using the application on your premises:

- · Activate or register a license.
- Get visibility to your company's licenses.
- Transfer licenses between company entities.

To learn more about Smart Software Manager On-Prem, go to https://www.cisco.com/c/en/us/buy/smart-accounts/software-manager.html.

Smart Accounts and Virtual Accounts

A Smart account provides you with a single location for all smart-account enabled products and licenses. It assists you in speedy procurement, deployment, and maintenance of your Cisco software.

If you are requesting a Smart account on behalf of an organization, you must have the authority to represent the requesting organization when creating a Smart account. After submitting the request, the request goes through an approval process before you are provided with access to your Smart account.


Go to http://software.cisco.com to learn about, set up, and manage a Smart account.

A virtual account is a subaccount within a Smart account. You can define the virtual account's structure based on organizational layout, business function, geography, or any defined hierarchy. Virtual accounts can be created and maintained only by Smart account administrators.

Smart License Workflow and States

The following illustration shows the workflow for Smart licenses:

Figure 3: Smart Licensing Workflow



Smart Software Licensing supports the following license states:

Table 28: Smart License States

State	Description
Unregistered	The Smart license is enabled but not connected to the Cisco Smart Software Manager (CSSM). Before you register the switch with the CSSM, Smart Software Licensing automatically enters the evaluation
	period. The switch remains in evaluation mode for 90 days.

State	Description
Registered	The Smart license is enabled and connected to the CSSM.
Authorized	The switch has the required license.
	The CSSM has verified that the reported number of licenses in use do not exceed the total number of licenses purchased for an entitlement.
	The authorization is valid for 90 days. The switch sends the entitlement request again every 30 days to renew the authorization.
Out of Compliance (OOC)	The switch does not have the required license.
	The license can be out of compliance for one of the following reasons:
	The number of licenses in use exceeds the total number of licenses purchased for an entitlement.
	The purchased licenses are subscription-based and have expired.
Authorization Expired	The switch cannot communicate with Cisco for an extended period of time, usually 90 days.
	The authorization could expire for one of the following reasons:
	A network issue prevents the renewal of authorization.
	An issue occurs with license compliance.

Smart Call Home Overview

Use the Smart Call Home feature to communicate with the Smart Software Manager. On Cisco Nexus 3000 and 9000 Series switches, Smart Software Licensing and Smart Call Home are not enabled by default.

The Smart Call Home (SCH) server runs on Cisco Smart Software Manager On-Prem by default. You can access this service using the following URL:

https://CSSM-On-Prem-IP/Transportgateway/services/DeviceRequestHandler

Provide this URL as part of the Smart Call Home configuration so that the device registration works with CSSM On-Prem. For a sample configuration, see the Configuration Examples for Smart Software Licensing.

Smart Call Home creates a CiscoTAC-1 profile. The associated Smart Call Home messages are sent to the Smart Software Manager only after enabling Smart Call Home.



Note

You must configure the DNS client and virtual routing and forwarding (VRF) before using Smart Call Home. For more information, see Configuring a DNS Client and Configuring a VRF To Send a Message Using HTTP.

Traditional Licensing Overview

Traditional licensing at Cisco is a legacy licensing model based on Product Activation Keys (PAKs) and Unique Device Identifiers (UDIs). On most Cisco NX-OS switches, capacity needs are assessed prior to obtaining and installing a .tar file on switches to retrieve the UDI. Customers place an order for a PAK, and the PAK is emailed to the user. The UDI and PAK are used to receive a license file that is installed in the boot directory of the switch to complete the installation of the Cisco NX-OS software.



Note

Traditional license installation via Power On Auto Provisioning (POAP) ends with release 10.2(1).

The License Registration Portal (LRP) is available to help migrate traditional licenses to smart licenses. To access the LRP, obtain training, and manage licenses, go to http://tools.cisco.com/SWIFT/LicensingUI/Home.

Comparing Licensing Models

Two types of licensing models are used for the Cisco Nexus 3000 and 9000 Series Switches: traditional licensing and Smart Software Licensing.

Table 29: Comparison Between Traditional Licensing and Smart Software Licensing

Description	Traditional Licensing	Smart Software Licensing
License instance node locked to the product instance	Yes	No
Product registration upon configuration	No	Yes
Offers tools to report, monitor, own, and consume	No	Yes
Requires Smart Call Home	No	Yes

The licensing mode changes based on the configuration provided. If Smart Software Licensing is enabled, all license requests are passed to the CSSM. If Smart Software Licensing is disabled, all license requests are fulfilled based on the license files installed on the device.

Guidelines and Limitations for Smart Software Licensing

- The smart license reservation command is not supported for Nexus 9000, although the command may still be found in old code.
- If the switch has no connectivity to a CSSM server, the **show running** command may get stuck or may take up to 2 minutes to respond. We suggest that the CSSM server is always reachable when smart-licensing is enabled.
- Beginning with Cisco NX-OS Release 9.3(3), all Cisco Nexus 3000 and 9000 Series switches (except the Cisco Nexus 3016 and 3064 platform switches) support Smart Software Licensing.
- You cannot use both traditional licensing and Smart Software Licensing at the same time.
- The FC_PORT_ACTIVATION_PKG license consumes the FC 48 ports entitlement tag regardless of the number of FC ports acquired (Cisco NX-OS 9.3(4) and earlier releases).
- Beginning with Cisco NX-OS Release 9.3(5), when a term license is reserved and its term has expired, the license is still shown as Authorized with the **show license usage** command. In CSSM, alerts will continue and any new licenses from the same pool added to the virtual account are assigned to the reservation.
- Beginning with Cisco NX-OS Release 9.3(5), disabling and enabling an installed feature when the license is in a "Not Authorized" state, the license no longer appears in the display of the license usage.
- Beginning with Cisco NX-OS Release 9.3(5), the conversion of a traditional license to a Smart License using DLC (Device Led Conversion) on Cisco Nexus 3000 and 9000 Series switches, fails when performing additional subsequent Device Led Conversions.
- Converting a traditional license to a Smart License DLC fails unless licenses are installed in traditional mode (Cisco NX-OS 9.3(5) and later releases)
- After converting a traditional license to a Smart License DLC on a (On-Prem) device, the device does
 not receive a pass/fail response from the On-Prem Server. Manual synchronization of the On-Prem Server
 to CSSM might be required to get the return response to the device. (Cisco NX-OS 9.3(5) and later
 releases)
- Beginning with Cisco NX-OS Release 9.3(5), the conversion of a traditional license to a Smart License using DLC (Device Led Conversion) is not supported on Cisco Nexus 3408-S switches.
- License Borrowing When license borrowing is calculated, compliance is accomplished in the quickest way possible. Typically, this means that license borrowing is from its immediate parent.

An alternative is considered if no licenses are found to be eligible to be borrowed from the immediate parent. If during a subsequent call, a device is found not be in compliance, a recalculation for optimization is done. The trigger for a completely optimized pool is a device that is potentially receiving OOC.

Setting Up Smart Accounts

This section provides information on requesting a Smart account and adding users to the account.

Requesting a Smart Account

Requesting a Smart account is a one-time process. Subsequent management of users is a capability provided through the tool.

Before you begin

Ensure that you have a Cisco login.

- **Step 1** Go to http://software.cisco.com, and log in to your account.
- Step 2 Click the Request a Smart Account link in the Administration section.
- **Step 3** Perform one of the following tasks to select the Account Approver:
 - To select yourself as the approver, click Yes, I will be the Approver for the account option.
 - To select a different person as the approver, click **No, the person specified below will be the Approver for the account** option and specify the person's email ID.

Note The specified approver must have the authority to enter legal agreements. The approver serves as the primary owner and nominates account administrators.

- **Step 4** Depending on the approver type, perform one of the following procedures:
 - If you are the approver, perform the following tasks:
 - a. Enter Account Name, Company/Organization Name, Country, and State/Province/Region information.
 - b. (Optional) Click Edit.
 - c. In the Edit Account Identifier window, enter a valid Proposed Domain Identifier and Contact Phone Number, and click OK.

Note The default domain identifier is the approver's email domain. If you edit the domain identifier, the change goes through a manual approval process.

- **d.** Click **Continue** to select the legal address to be linked to your Smart account.
- If you are not the approver, perform the following procedure:
- **a.** Enter the **Account Name** and an optional **Message** to the approver.
- b. (Optional) Click Edit.
- c. In the Edit Account Identifier window, enter a valid Proposed Domain Identifier, and click OK.

Note The default domain identifier is the approver's email domain. If you edit the domain identifier, the change goes through a manual approval process.

- d. Click Continue.
- **e.** Follow the instructions in the email that is sent to you to complete the request.

Adding a User to a Smart Account

Smart account user management is available in the **Administration** section of Cisco Software Central.

- Step 1 Go to http://software.cisco.com, and log in to your account.
- Step 2 Click the Manage Smart Account link in the Administration section.
- Step 3 Click the Users tab.
- Step 4 Click New User.
- **Step 5** Provide the required information in the **New User** section.

(Define roles to manage the entire Smart account or specific virtual accounts.)

Step 6 Click Continue.

Converting a Traditional License to a Smart License

Traditional licenses associated with Product Activation Keys (PAKs) can be converted to smart licenses using the License Registration Portal (LRP). Access traditional licenses by clicking the **PAKs/Tokens** tab. Then use the information in this section to convert PAKs to smart licenses.



Note

Alternatively, you can convert traditional licenses to smart licenses using one of the following methods:

- Access the Smart Software Manager and follow the instructions in the "Convert to Smart Licensing" section.
- Contact Cisco Global Licensing Operations (GLO) or TAC. You need to provide your PAK and device details as well as the smart account where you want the licenses to be deposited.
- **Step 1** Go to http://software.cisco.com, and log in to your account.
- **Step 2** Click the **Traditional Licensing** link in the **License** section.

You are redirected to the LRP window.

- Step 3 Click the PAKs/Tokens tab under Manage, if it is not already selected.
- **Step 4** Check the **PAK/Token ID** check box.
- **Step 5** Select **Convert to Smart Entitlements** from the **Actions** drop-down menu.
- Step 6 Select a smart account from the Smart Account drop-down list.

Note You can view only the smart accounts that are assigned to you.

Step 7 Select a virtual account from the **Virtual Account** drop-down list.

Note You can view only the virtual accounts that are assigned to you.

Step 8 Click Assign.

The selected PAK is converted to a smart license.

Converting a Traditional License to a Smart License—DLC (Device Led Conversion)

Traditional licenses associated with Product Activation Keys (PAK) can be converted to smart licenses using CLI.

This type of conversion is also known as a Device Led Conversion (DLC).

Before you begin

- Ensure that Smart Software Licensing is enabled.
- Ensure that you have a valid smart account.
- Ensure that you have valid user rights for the smart account.

Step 1 switch# license smart conversion start

Starts a manual conversion of a traditional license to a smart license. The conversion takes place in the background. After the conversion succeeds or fails, a system log message is displayed on the switch console.

Step 2 (Optional) switch# license smart conversion stop

Stops the manual conversion.

Step 3 (Optional) switch# show license status

Displays the license conversion status. If you run this command from an active device in a high availability (HA) configuration, this will display the status of all the devices in the HA configuration.

Converting a Traditional License to a Smart License—DLC

The following example shows how to convert a traditional license to a smart license using the CLI:

```
switch# license smart conversion start
```

Smart License Conversion process is in progress. Use the 'show license status' command to check the progress and result.

The following example shows how to stop the process of converting a traditional license to smart license using the CLI:

The following example shows the status of the license conversion for a standalone device:

```
switch# license smart conversion stop
stop manual conversion failed:
Some Smart Licensing Conversion jobs stopped successfully.
```

The following example shows the status of line conversion for a standalone device:

switch# show license status

```
Smart Licensing is ENABLED.
Registration:
Status: REGISTERED
Smart Account: Big-U University
Virtual Account: Physics
Export-Controlled Functionality: Not Allowed
Initial Registration: SUCCEEDED on Feb 24 23:30:12 2020 PST
Last Renewal Attempt: SUCCEEDED on Feb 24 23:30:12 2020 PST
Next Renewal Attempt: Apr 24 23:30:12 2020 PST
Registration Expires: Dec 24 23:30:12 2020 PST
```

The following show output is applicable from Cisco NX-OS Release 9.3(5) onwards:

```
Smart License Conversion:
Automatic Conversion Enabled: False
Status: SUCCEEDED on Jan 1 00:00:00 2020 UTC

License Authorization:
Status: AUTHORIZED on Mar 31 17:04:56 2020 UTC

Last Communication Attempt: SUCCEEDED on Mar 31 17:04:56 2020 UTC

Next Communication Attempt: Apr 30 17:04:56 2020 UTC

Communication Deadline: Nov 29 16:58:31 2020 UTC
```

Configuring Smart Call Home for Smart Software Licensing

Make sure that Smart Call Home is enabled on the switch before configuring Smart Software Licensing. For more information, see the "Configuring Smart Call Home" chapter of the *System Management Configuration Guide, Release 9.3(x)* for your specific Cisco Nexus 3000 or 9000 Series switch.

Configuring a DNS Client

Before you begin

Make sure that the name server is reachable before you configure a DNS client.

Procedure

	Command or Action	Purpose
Step 1	switch# configure terminal	Enters global configuration mode.
Step 2	switch(config)# ip domain-lookup	Enables DNS-based address translation.
Step 3	switch(config)# ip domain-name name [use-vrf vrf-name]	Defines the default domain name that Cisco NX-OS uses to resolve unqualified host names. You can also define a virtual routing and forwarding (VRF) that Cisco NX-OS uses to resolve this domain name if it cannot be resolved in the VRF under which you configured this domain name. Cisco NX-OS appends the default domain name to any hostname that does not contain a complete domain name before starting a domain-name lookup.

	Command or Action	Purpose
Step 4	switch(config)# ip name-server address1 [address2 address6] [use-vrf vrf-name]	Defines up to six name servers. The address can be either an IPv4 or IPv6 address.
		You can optionally define a VRF that Cisco NX-OS uses to reach this name server if it cannot be reached in the VRF under which you configured this name server.
Step 5	switch(config)# vrf context vrf-name	Creates a VRF and enters VRF configuration mode.
Step 6	switch(config-vrf)# ip domain-name name [use-vrf vrf-name]	Defines the default domain name that Cisco NX-OS uses to complete unqualified host names. You can optionally define a VRF that Cisco NX-OS uses to resolve this domain name if it cannot be resolved in the VRF under which you configured this domain name. Cisco NX-OS appends the default domain name to any
		hostname that does not contain a complete domain name before starting a domain-name lookup.
Step 7	switch(config-vrf)# ip name-server address1 [address2 address6] [use-vrf vrf-name]	Defines up to six name servers. The address can be either an IPv4 or IPv6 address.
		You can also define a VRF that Cisco NX-OS uses to reach this name server if it cannot be reached in the VRF under which you configured this name server.

Configuring a VRF To Send a Message Using HTTP

Procedure

	Command or Action	Purpose
Step 1	switch# configure terminal	Enters global configuration mode.
Step 2	switch(config)# callhome	Enters Call Home configuration mode.
Step 3	switch(config-callhome)# transport http use-vrf vrf-name	Configures the VRF used to send email and other Smart Call Home messages over HTTP.

Viewing a Smart Call Home Profile

Procedure

	Command or Action	Purpose
Step 1	switch# show running-config callhome	Displays the Smart Call Home profile.

Configuring Smart Software Licensing

Follow the instructions in this section to enable Smart Software Licensing, register your device to use a Smart account, and renew device registration and authorization.

Enabling or Disabling Smart Software Licensing

Procedure

	Command or Action	Purpose	
Step 1	switch# configure terminal.	Enters global configuration mode.	
Step 2	Use one of the following commands to enable Smart Software Licensing:	Enables Smart Software Licensing and disables traditional licensing. All license requests now go through the CSSM.	
	• switch(config)# [no] license smart enable	The [no] version of this command disables Smart Software Licensing.	
	• switch(config)# [no] feature license smart	Licensing.	

Registering a Device

You can register your device to use a Smart account. You need to register each device only once.

Before you begin

- Make sure that Smart Software Licensing is enabled.
- Make sure that you have the token to register your device to the Smart account.

Procedure

	Command or Action	Purpose	
Step 1	switch# license smart register idtoken token [force]	Registers your device to the Smart account using the toke The CSSM automatically renews the registration information with Cisco every 30 days.	
		Note To unregister a device deregister command	e, use the license smart

Renewing Device Registration and Authorization

Procedure

	Command or Action	Purpose
Step 1	switch# license smart renew id	Renews the device registration.

	Command or Action	Purpose
Step 2	switch# license smart renew auth	Renews the device authorization.

Verifying Smart Software Licensing

Verify Smart Software Licensing using the following commands:

Commands	Purpose	
show license all	license all Displays all smart licensing information.	
show license status	Displays the smart licensing status.	
show license summary	Displays a summary of the registration, authorization, and entitlement for smart licenses.	
show license tech support	Displays smart licensing technical support information.	
show license udi	Displays the device identifier used by the smart license.	
show license usage	Displays authorization, entitlement, version, and status information for smart licenses.	



Note

System messages for traditional licensing might appear when the device is using Smart Software Licensing. If your device is using Smart Software Licensing, you can ignore messages such as the following: "LIC_MISSING_WARNING: A feature that requires *license-name* license is not installed."

Verification Examples for Smart Software Licensing

These examples show how to verify Smart Software Licensing:

```
Switch# show license status

Smart Licensing is ENABLED

Registration:
   Status: REGISTERED
   Smart Account: Cisco Systems, Inc.
   Virtual Account: NexusSmartLicensing_Test
   Export-Controlled Functionality: Allowed
   Initial Registration: SUCCEEDED on Nov 12 10:43:33 2019 UTC
   Last Renewal Attempt: None
   Next Renewal Attempt: Jun 16 10:43:32 2019 UTC
   Registration Expires: Nov 12 08:07:20 2019 UTC

License Authorization:
   Status: AUTHORIZED on Nov 12 10:43:48 2019 UTC

Last Communication Attempt: SUCCEEDED on Nov 12 10:43:48 2019 UTC
```

```
Next Communication Attempt: Jun 16 10:43:47 2019 UTC
  Communication Deadline: Nov 12 08:07:20 2019 UTC
switch# show license summary
Smart Licensing is ENABLED
Registration:
 Status: REGISTERED
  Smart Account: Cisco Systems, Inc.
 Virtual Account: NexusSmartLicensing Test
 Export-Controlled Functionality: Allowed
License Authorization:
 Status: AUTHORIZED on Dec 14 10:43:48 2019 UTC
 Last Communication Attempt: SUCCEEDED
  Next Communication Attempt: Jun 16 10:43:47 2019 UTC
  Communication Deadline: Nov 12 08:07:20 2019 UTC
switch# show license all
Smart Licensing Status
_____
Smart Licensing is ENABLED
Registration:
 Status: REGISTERED
  Smart Account: Cisco Systems, Inc.
  Virtual Account: NexusSmartLicensing Test
 Export-Controlled Functionality: Allowed
 Initial Registration: SUCCEEDED on Nov 12 10:43:33 2019 UTC
 Last Renewal Attempt: None
 Next Renewal Attempt: Jun 16 10:43:32 2019 UTC
 Registration Expires: Nov 12 08:07:20 2019 UTC
License Authorization:
  Status: AUTHORIZED
  Last Communication Attempt: SUCCEEDED on Nov 12 10:43:48 2019 UTC
 Next Communication Attempt: Jun 16 10:43:48 2019 UTC
  Communication Deadline: Nov 12 08:07:21 2019 UTC
License Usage
_____
Product Information
______
UDI: SN:AB123456789
Agent Version
Smart Agent for Licensing: 1.6.6 rel/88
switch# show license tech support
Smart Licensing Status
Smart Licensing is ENABLED
Registration:
 Status: REGISTERED
  Smart Account: Cisco Systems, Inc.
```

```
Virtual Account: NexusSmartLicensing Test
  Export-Controlled Functionality: Allowed
  Initial Registration: SUCCEEDED on Nov 12 10:43:33 2019 UTC
  Last Renewal Attempt: None
  Next Renewal Attempt: Jun 16 10:43:32 2019 UTC
  Registration Expires: Nov 12 08:07:20 2019 UTC
License Authorization:
  Status: AUTHORIZED on Nov 12 10:43:48 2019 UTC
  Last Communication Attempt: SUCCEEDED on Nov 12 10:43:48 2019 UTC
  Next Communication Attempt: Jun 16 10:43:47 2019 UTC
  Communication Deadline: Nov 12 08:07:20 2019 UTC
Evaluation Period:
 Evaluation Mode: Not In Use
  Evaluation Period Remaining: 89 days, 23 hours, 59 minutes, 7 seconds
License Usage
_____
Product Information
______
UDI: SN:AB123456789
Agent Version
Smart Agent for Licensing: 1.6.6 rel/88
Upcoming Scheduled Jobs
______
Current time: Nov 12 08:44:44 2019 UTC
IdCert Expiration Warning: Oct 15 08:07:20 2019 UTC (303 days, 23 hours, 22 minu
tes, 36 seconds remaining)
Daily: Oct 15 10:26:50 2019 UTC (1 hours, 42 minutes, 6 seconds remaining)
Certificate Renewal: Jun 16 10:43:32 2019 UTC (179 days, 1 hours, 58 minutes, 48
 seconds remaining)
Reservation configuration mismatch between nodes in HA mode: Not Available
Certificate Expiration Check: Nov 12 08:07:20 2019 UTC (363 days, 23 hours, 22 m
inutes, 36 seconds remaining)
Authorization Renewal: Jun 16 10:43:47 2019 UTC (29 days, 1 hours, 59 minutes, 3
seconds remaining)
Authorization Expiration Check: Nov 12 08:07:20 2019 UTC (363 days, 23 hours, 22
minutes, 36 seconds remaining)
Init Flag Check: Not Available
Register Period Expiration Check: Not Available
Ack Expiration Check: Not Available
License Certificates
Production Cert: True
PIID:
Licensing Certificated:
    Id certificate Info:
       Start Date: Nov 12 08:07:22 2019 UTC
       Expiry Date: Nov 12 08:07:22 2019 UTC
       Version Number: 3
        Serial Number: 123456
        Common Name: 9c172927d1806d05694c1f434b40ec0fbef93abb::2
    Signing certificate Info:
        Start Date: Aug 11 19:05:34 2019 UTC
```

```
Expiry Date: Nov 12 07:00:15 2069 UTC
        Version Number: 3
        Serial Number: 3
        Common Name: MMI Signer
    Sub CA Info:
        Start Date: Sep 11 19:06:30 2019 UTC
        Expiry Date: Dec 7 07:00:15 2069 UTC
        Version Number: 3
        Serial Number: 2
        Common Name: Smart Licensing CA
    Root Cert Info:
        Start Date: Jun 30 19:48:47 2019 UTC
        Expiry Date: Dec 7 07:00:15 2069 UTC
        Version Number: 3
        Serial Number: 1
        Common Name: Cisco Licensing Root CA
HA Info
========
RP Role: Active
Chassis Role: Active
Behavior Role: Active
RMF: True
CF: True
CF State: Stateless
Other Info
Software ID: regid.2015-09.com.cisco.Nexus 9000,1.0 6e2b6ed8-fe9b-48e0-a71f-74ea
f1bcc991
Agent State: authorized
TS enable: True
Transport: Callhome
Locale: C
Debug flags: 0x7
Privacy Send Hostname: True
Privacy Send IP: True
Build type:: Production
sizeof(char) : 1
sizeof(int)
sizeof(long) : 4
sizeof(char *): 4
sizeof(time_t): 4
sizeof(size_t): 4
Endian: Little
Write Erase Occurred: False
XOS version: 0.11.0.0
Reservation enable: False
Reservation in progress: False
Reservation type: None
Reservation request code: <empty>
Reservation authorization code: <empty>
Reservation return code: <empty>
Config Persist Received: True
Message Version: 1.1
switch# show license udi
UDI: SN:AB123456789
```

```
switch# show license usage
License Authorization:
  Status: AUTHORIZED on Nov 12 08:45:50 2019 UTC
(LAN ENTERPRISE SERVICES PKG):
  Description: LAN license for Nexus 9000 Platforms
  Count: 1
  Version: 1.0
  Status: AUTHORIZED
switch# show running-config callhome
!Time: Thu Nov 12 08:55:26 2019
version 9.3(3)
callhome
  email-contact sch-smart-licensing@cisco.com
  destination-profile CiscoTAC-1 transport-method http
 destination-profile CiscoTAC-1 http https://tools.cisco.com/its/service/oddce/
services/DDCEService
  transport http use-vrf management
  enable
```

Configuration Examples for Smart Software Licensing

This example shows how to register your device with the Cisco portal and enable Smart Software Licensing:



Note

To avoid any issues when registering your device, make sure that the name server is reachable before registering your device.

```
switch# configure terminal
switch(config)# ip domain-lookup
switch(config) # ip domain-name cisco.com
switch(config)# ip name-server 171.70.168.183 use-vrf management
switch(config)# vrf context management
switch(config-vrf)# ip domain-name cisco.com
switch(config-vrf) # ip name-server 171.70.168.183
switch(config-vrf)# exit
switch(config) # callhome
switch (config-callhome) # transport http use-vrf management
switch(config-callhome)# exit
switch(config)# feature license smart
This example shows how to disable Smart Software Licensing:
switch# configure terminal
switch(config) # no feature license smart
This example shows how to register a device:
switch# configure terminal
switch(config)# license smart register idtoken sampletokenID
register status: Registration process is in progress. Use the 'show license status' command
```

```
to check the progress and result
```

This example shows how to unregister a device:

```
switch# license smart deregister
```

This example shows how to provide the URL for CSSM On-Prem as part of the Smart Call Home configuration:

```
callhome
  contract-id <contract-id>
  customer-id <customer-id>
  site-id <site-id>
  email-contact <email>
  phone-contact <phone>
  streetaddress <street address>
  destination-profile CiscoTAC-1 transport-method http
  destination-profile CiscoTAC-1 index 1 http
https://<CSSM-On-Prem-IP>/Transportgateway/services/DeviceRequestHandler
  transport http use-vrf management
  enable
```

Use Cases for Smart Software Licensing

Scenario 1

1. Configure and order a Cisco Nexus 3000 or 9000 Series switch with licenses and select the Cisco NX-OS release that will be preinstalled on the hardware prior to shipment.



Note

To convert the preinstalled licenses on the hardware to smart licenses, you must have a Smart Account set up and then convert the licenses by going to the License Registration Portal.

- 2. Click the **Devices** tab under the **Manage** section. Click the corresponding Device ID, and choose **Convert to Smart Entitlements** from the Device ID drop-down list. Doing so converts all the licenses that are preinstalled on the switch to smart licenses. This task must be performed for each switch that you want to convert to smart licensing.
- **3.** The service validates if license Stock Keeping Units (SKUs) on the switch have been mapped to smart licenses before proceeding with the conversion.
- **4.** Enable smart mode on the switch and start using the smart licenses.

Scenario 2

- 1. Configure and order a Cisco Nexus 3000 or 9000 Series switch with licenses and select the Cisco NX-OS release that will be preinstalled in the hardware prior to shipment.
- **2.** Upgrade the switch to Cisco NX-OS Release 9.3(3) or a later release.



Note

To convert the preinstalled licenses on the hardware to smart licenses, you must have a Smart account set up and then perform the conversion by going to the License Registration Portal.

- 3. Click the **Devices** tab under the **Manage** section. Click the corresponding Device ID, and choose **Convert** to Smart Entitlements from the Device ID drop-down list. Doing so converts all the licenses that are preinstalled on the switch to smart licenses. This task must be performed for each switch that you want to convert to smart licensing.
- The service validates if license SKUs on the switch are mapped to smart licenses before proceeding with the conversion.
- Enable smart mode on the switch and start using the smart licenses.

Scenario 3

1. Order a spare license SKU and do not associate a Smart account to the order in Cisco Commerce Workspace



Note You must have a Smart account set up before using Smart Software Licensing.

- 2. Order a PAK and load it to your Smart account.
- 3. The License Registration Portal service validates if the spare license SKU is mapped to a smart license.
- The Smart Software Manager (SSM) notifies you through email when your Smart Account has licenses that can be fulfilled as traditional licenses or smart licenses.
- Specify the PAKs as smart licenses in SSM.
- Ensure that Cisco NX-OS Release 9.3(3) or a later release is installed on the switch, enable smart mode, and start using the smart entitlements.

Scenario 4

- 1. Order a spare license SKU and assign a Smart account to the order in CCW.
- 2. The existing License Registration Portal service deposits the PAK to the LRP Smart account.
- The License Registration Portal service validates if the spare license SKU has been mapped to smart entitlements. If the spare license SKUs are mapped to smart entitlements, the service sends out a confirmation notification to CSSM.
- The Smart Software Manager notifies you through email when your Smart Account has licenses that can be fulfilled as traditional licenses or smart licenses.
- **5.** Specify the PAKs as Smart Software Licenses in SSM.
- **6.** Ensure that Cisco NX-OS Release 9.3(3) or a later release is installed on the switch, enable smart mode, and start using the smart licenses.

Additional References for Smart Software Licensing

Table 30: Technical Assistance

Description	Link
License Registration Portal (LRP) documentation	https://www.cisco.com/web/fw/tools/swift/xui/html/help.html
Smart accounts and smart licensing	https://forums.cisco.com/OperationsExchange/s/ Training-Details?L1Category=Training&L2Category=CSE_End_ Customer&L1CategoryPath=training
Training and resources	https://community.cisco.com/t5/smart-licensing-enterprise/software-on-demand-training-resources-for-customers/ta-p/3639797

Feature History for Smart Software Licensing

Feature Name	Release	Feature Information
Converting a Traditional License to a Smart License—DLC (Device Led Conversion)	9.3(5)	Introduced support for Device Device Led Conversion (DLC) to convert a traditional license to a Smart License.
Smart Software Licensing	9.3(3)	Introduced this feature for Cisco Nexus 3000 and 9000 Series switches.