

What methods are available to program my telephone?

Answer


There are two basic methods available to program your phone.

Display Menu Tree Method (Older Model Phones): This method requires pressing the MENU soft key then using the navigation arrows to scroll to the various menus and sub-menus of the phone to select the desired programming feature.


Direct Command Code Method (Newer Model Phones): This method allows access to the desired programming feature by pressing the MENU soft key, the pound sign, and a 3 or 4 digit number code found in the manual.

Below is an example of both of the programming methods:

Display Menu Tree Method:



Direct Command Code Method:



How do I view, add, block, and unblock numbers?

Answer

Scroll down to your answer or click one of the links just below:

1. [Unblock Blocked Numbers](#)
2. [Block Call](#)
3. [View Blocked List](#)
4. [Add Numbers to Blocked List](#)
5. [Block a Range of Numbers](#)

Add numbers to my blocked list of numbers:

To manually block a number:

1. Press the **[MENU] [#] [2] [1] [7]** on the handset
2. Press **[ADD]**
3. Enter the phone number you want blocked
4. Press **[SAVE]**

To store block number from caller list:

1. Press **[MENU] [#] [2] [1] [3]**
2. Scroll to the number to be blocked
3. Press **[SAVE]**

Note: If you do not want the first ring from a phone number on the call block list to sound, turn the first ring setting to "Off". Follow this procedure on the handset:

1. Press the **[MENU] [#] [1] [7] [3]**
2. Select "ON"
3. Press **[SAVE]**

**For additional information, please refer to the Operating Manual.

Question

How do I clear 'New Voicemail' or "Voice mail msg. via phone co" on my handset's display or disable voice mail?

Answer

Your telephone is alerting you that you have a new voice message from your phone company's assigned Voice mailbox. The procedure to access your voice mailbox would vary depending on the instructions of your phone company/service provider. Once you listen to your new messages, "New Voicemail" or "Voice mail msg. via phone co" should be cleared from the handset.

Note: If the handset still indicates there are new messages even after you have listened to all new messages, turn it off by pressing and holding [#] until the handset beeps.

If you do not have voicemail service through your telephone service provider that you are aware of:

Press [MENU] [#] [3] [3] [2] then press [0] to select **OFF** followed by SAVE to disable the Voicemail Tone Detector of the telephone.

How do I use my Answering Machine and/or my Voice Mail?

Answer

Scroll down to your specific question or click one of the links just below:

[Answering Machine:](#)

1. [Record a Greeting](#)
2. [Check a Recorded Greeting](#)
3. [Change a Pre-Recorded Greeting](#)
4. [Set Number of Rings for Answering Machine Pickup](#)
5. [Setup/Change Remote Access Code](#)
6. [How to Use the Remote Access Code](#)
7. [Turn On/Off Call Screening](#)

[Voice Mail \(VM\)](#)

8. [Store Voice Mail Number](#)
9. [Voice Mail Tone Detect Defined](#)
10. [Use Voice Mail and Turn Off or Stop Answering Machine](#)
11. [Clear Handset Voice Mail Message](#)
12. [Check Voice Mail with Handset](#)

How do I record a greeting message?

Answer

To record a greeting message, use one of the following three methods:

A. To record a greeting message or outgoing message, Press [MENU] [#] [3] [0] [2] and select [YES] on the handset, as soon as you hear a beep, start recording your message. To stop recording press [STOP] on the handset. If this method does not apply to your phone, please follow method "B" below.

B. To record a greeting message or outgoing message, Press [MENU] [#] [3] [0] [2] and select your desired line for the greeting, press [SELECT] on the handset, as soon as you hear a beep,

start recording your message. To stop recording press [**STOP**] on the handset. If this method does not apply to your phone, please follow method "C" below.

How do I edit an entry on my speed dial list?

Answer

1. Press and hold the desired dial key
2. Press [**MENU**]
3. Scroll to "Edit"
4. Press [**SELECT**]
5. Edit the name
6. Press [**OK**]
7. Edit the number
8. Press [**OK**]
9. Press [**SELECT**]

Question

How do I deregister a handset which is no longer in use?

Answer

To deregister a handset, you will need to follow the below steps:

1. Press [**MENU**] [#] [1] [3] [1]
2. Press [**▲**]/[**▼**] to select the handset
3. Press [**SELECT**]
4. Press [**▲**]/[**▼**] to select "YES"
5. Press [**SELECT**] to deregister the handset

Enter [3] [3] [5]→[**OK**] Select the handset you want to cancel by pressing the desired handset(s) number Select [**OK**]→[**▲**]/[**▼**]: "YES" →[**SELECT**]