

Installation Manual

AI80 Automatic Identification System

This manual is intended as a reference guide for installing and maintaining the Simrad AI80 Automatic Identification System.

Document revisions

Rev	Date	Written by	Checked by	Approved by
0	17.09.04	ISt	KKr	KKr
1	17.11.04	ISt	KKr	KKr

Document history

Rev. 0 First edition.

Rev. 1 FCC statements included.

To assist us in making improvements to this manual, we would welcome comments and constructive criticism. Please send all such - in writing to:

Kongsberg Seatex AS
Pirsenteret
N-7462 Trondheim, Norway

or by e-mail to:
firmapost@kongsberg-seatex.no

About this manual

This manual is intended as a reference guide for installing and maintaining the Simrad AI80 Automatic Identification System.

In this manual, references to buttons on the control unit are written in boldface, and in a different text style (e.g. **VIEW** button, **SHIFT** button, **ENTER** button).

Important text that requires special attention from the reader is emphasized as follows:

Note! *Used to draw the reader's attention to a comment or some important information.*

Caution! *Used to warn the reader that a risk of damage to the equipment exists if care is not exercised.*

WARNING! **Used when it is necessary to warn personnel that a risk of injury or death exists if care is not exercised.**

FCC part 15 statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a marine and/or commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. The equipment is not intended for operation in a residential area. Operation in such an area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Additional information to the user

Changes or modifications not expressly approved by Kongsberg Seatex AS will void the user's authority to operate the equipment.

This manual is divided in the following sections:

1. Technical specifications

Specifications for the system and for all separate units in the AI80 system..

2. Installation

Reference guide for correct installation of the AI80 system.

3. Connecting and configuring external equipment

Describes how external equipment is connected to the AI80 system.

4. Software setup procedure

Reference guide for correct configuration of the AI80 system.

5. Maintenance

Reference guide for correct configuration of the AI80 system.

6. Troubleshooting

Troubleshooting procedures that could be performed for checking hardware and external interface.

7. Spare parts list

Part numbers for all standard and optional units that may be included in the AI80 system.

8. Appendix A

Vessel identifiers.

9. Appendix B

IEC 61162-1, IEC/PAS 6162-100 sentence description.

10. Appendix C

Software setup procedure using external, optional MKD.

11. Appendix D

AIS troubleshooting form.

12. Appendix E

Optional VHF antenna.

Abbreviations and acronyms

ABK	Addressed and Binary Broadcast Acknowledgement
ABM	Addressed Binary and Safety Related Message
ACA	AIS Regional Channel Assignment
AIS	Universal Ship-borne Automatic Identification System
AIS 1	161.975 MHz (87B – 2087)
AIS 2	162.025 MHz (88B – 2088)
ALR	Alarm
ARPA	Automatic Radar Plotting Aid
ASCII	American Standard Code for Information Interchange
ATN	Aids to Navigation
BIIT	Built In Integrity Tests
COG	Course Over Ground
DGPS	Differential GPS
DGNSS	Differential Global Navigation Satellite System
DSC	Digital Selective Calling
ECDIS	Electronic Chart Display and Information System
ECS	Electronic Chart System
EMC	Electromagnetic Compatibility
ETA	Estimated Time of Arrival
FATDMA	Fixed Allocation TDMA
GNSS	Global Navigation Satellite System
GPS	Global Positioning System
IALA	International Association of Lighthouse Authorities
IEC	International Electrotechnical Commission
IMO	International Maritime Organisation
LR	Long Range
MKD	Minimum Keyboard Display
MMSI	Maritime Mobile Service Identity
MSG	Message
N/A	Not Applicable
NMEA	National Marine Electronics Association

PI	Presentation Interface
PPS	Pulse-per-second
PUR	Polyurethane
PWR	Power
ROT	Rate of Turn
RTCM	Radio Technical Commission of Maritime Service
RX	Receive
SAR	Search and Rescue
SMS	Short Message Service
SOG	Speed Over Ground
SOTDMA	Self Organising TDMA
TBD	To Be Defined
TDMA	Time Division Multiple Access
TX	Transmit
TXT	Text Message
UTC	Universal Co-ordinated Time
VDL	VHF Data Link
VDM	VHF Data Link Message
VDO	VHF Data Link Own Vessel Message
VHF	Very High Frequency

Contents

1	TECHNICAL SPECIFICATIONS.....	1
1.1	Health, environment and safety	1
1.2	Restrictions in guarantee	1
1.3	Power	1
1.4	Data input	1
1.5	Specifications.....	2
	AI80 Mobile Unit	2
	AI80 Minimum Keyboard Display (MKD).....	5
	GPS antenna (GPS4)	7
	Pilot plug.....	8
	Optional, external MKD Unit.....	8
2	INSTALLATION	11
2.1	General.....	11
2.2	Unpacking and handling.....	11
2.3	Installation procedure	11
2.4	Cabling.....	13
2.5	Location of the units	15
	Antenna location.....	15
2.6	MKD unit.....	16
	Mechanical installation.....	16
2.7	Optional MKD unit.....	17
	Mechanical installation.....	17
	The optional MKD cable	18
2.8	AI80 Mobile Unit	19
	Mechanical installation.....	19
	Cable connection	19
	Rear connections.....	19
	Data signals.....	20
2.9	Pilot plug.....	20
2.10	External alarm.....	21

2.11	GPS antenna	22
	Mechanical installation.....	22
	GPS antenna offset arms.....	22
	Checking the antenna cable	23
	Sealing antenna connectors	23
2.12	VHF antenna.....	23
3	CONNECTING AND CONFIGURING EXTERNAL EQUIPMENT	25
3.1	General.....	25
3.2	Presentation interface	26
	Physical location.....	26
	Port configuration	26
	Input sentences	26
	Proprietary input sentences.....	27
	Output sentences.....	27
3.3	Long-Range interface	28
	Physical location.....	28
	Port configuration	28
	Input sentences	28
	Output sentences.....	28
3.4	Sensor input	29
	Physical location.....	29
	Port configuration	29
	Input sentences	29
	Priority of Position.....	30
	Priority of SOG and COG.....	30
	Priority of Heading	30
	Priority of Rate of Turn	30
4	SOFTWARE SETUP PROCEDURE.....	31
4.1	General.....	31
4.2	Security settings AI80	31
4.3	Entering static data	32
4.4	Configuring external serial ports	33

4.5	VHF data link	33
4.6	Configuring radio channels	33
	Viewing a region's settings	33
	Adding a region	34
	Edit current region	35
5	MAINTENANCE	37
5.1	General.....	37
5.2	Periodic maintenance.....	37
	MKD Units	37
	Mobile Unit.....	37
5.3	Repair and modifications.....	38
	Exchanging antenna cables.....	38
	Exchanging GPS or VHF antennas	38
5.4	Software updates.....	39
6	TROUBLESHOOTING	41
6.1	General.....	41
6.2	Hardware problems.....	41
	Power supply failure	42
	GPS and VHF antenna cable connections	42
	GPS and VHF antenna malfunction	42
	GPS receiver failure.....	42
	VHF transceiver failure	43
6.3	External data interface problems	43
	Data input from main GPS/GNSS source.....	43
	Heading from vessel heading sensor	44
	AIS unit restarts	44
7	SPARE PART LIST.....	45
7.1	Simrad AI80.....	45
8	APPENDIX A - VESSEL IDENTIFIERS.....	47
9	APPENDIX B - DIGITAL INTERFACE IEC 61162-1	51
	Hardware	51

	Proprietary 61162-1 sentences.....	52
	New IEC 61162-1 sentences.....	55
	IEC 61162-1, Ed. 2, sentences.....	75
10	APPENDIX C - SOFTWARE SETUP USING OPTIONAL MKD	87
10.1	Security settings optional MKD	87
	Setting the security codes	87
	Changing the security levels.....	88
10.2	Entering static data optional MKD.....	90
10.3	Configuration external serial ports optional MKD.....	91
10.4	Port settings and MAC address optional MKD	92
10.5	Answer mode optional MKD.....	93
10.6	Configuring radio channels optional MKD	94
	Adding a region	95
	Editing current region.....	96
	Viewing a region's settings	96
11	APPENDIX D - TROUBLESHOOTING FORM	97
12	APPENDIX E - OPTIONAL VHF ANTENNA.....	99

1 TECHNICAL SPECIFICATIONS

1.1 Health, environment and safety

Operation or troubleshooting of Simrad AI80 equipment will not imply any risk for high voltages, explosions or exposure to gas. The AI80 is compliant with IEC 60950/EN60950 standards regarding product safety (low voltage) and IEC 60945/EN60945 standards on electromagnetic compatibility (immunity/radiation), vibration and climatic conditions.

1.2 Restrictions in guarantee

The liability of the manufacturer is limited to repair of the AI80 only, and excludes consequential damages such as customer's loss of profit or damage to other systems traceable back to AI80 malfunction. The warranty does not cover malfunctions of the AI80 resulting from the following conditions:

- a) The customer has opened the Mobile Unit
- b) Over-voltage or incorrect power connection

1.3 Power

Voltage input:.....24 V DC (nominal) range 18 – 35 V

Power consumption:.....50 W peak, approx. 30 W continuous

1.4 Data input

Gyro compass:.....NMEA 0183 version 3.0

GPS Main source:NMEA 0183 version 3.0

DGPS corrections:.....RTCM – SC104 version 2.1

1.5 Specifications

AI80 Mobile Unit

Dimensions:..... Refer page 3

Weight:3.4 kg

Colour:..... Black

Enclosure material:..... Varnished aluminium

Environmental protection:..... IP40

Temperature range:

Operating:..... -15 to +55°C (+5° to +131°F)

Storage: -25 to +60°C (-13° to +140°F)

Humidity - operating:..... 0-95% RH

Vibration test:

Displacement:..... 1 mm from 2 Hz to 13 Hz

Acceleration: 7 m/s² from 13 Hz to 100 Hz

Compass safe distance.....0.35 m

VHF radio:

Number of transmitters: 1

Number of receivers:.....3

Channel spacing:12.5 or 25 kHz

Frequency range: 156 - 165 MHz

Transmitter power: 2 W or 12.5 W nominal (selectable)

AIS 1 (Channel 87B):..... 161.975 MHz

AIS 2 (Channel 88B):..... 162.025 MHz


DSC receiver: 156.525 MHz

GPS receiver:


Type:Ashtech A12

Operating frequency


(reception only):..... 1575.42 MHz ± 10 MHz




TOP VIEW




FRONT VIEW




REAR VIEW



SIDE VIEW EXPLODED



BOTTOM VIEW - EXPLODED



AI80 Minimum Keyboard Display (MKD)

Dimensions:..... See below

Weight:.....0.4 kg

Colour:..... Black

Cable length (to Mobile Unit):.....7 m

Enclosure material:..... Plastic


Environmental protection:.....IP56 (when panel-mounted)

Temperature range:


Operating:.....-15 to +55°C (+5 to +131°F)

Storage:-25 to +70°C (-13 to +158°F)

Humidity - operating:..... 0-95% RH



FRONT VIEW



REAR VIEW



GPS antenna (GPS4)

Dimensions:..... Refer figure below

Weight:0.130 kg


Cable adapter set (2 cables):2 x 0.5 m

Voltage input:5 V DC from the AI80 Mobile Unit

Temperature range: -35°C - +70°C (-31° - +158°F)


Humidity:100% (sealed)

Mounting: 1"14 thread (standard US)




Pilot plug

AMP CPC series 2/Receptacle (Square Flanged) Shell size 11, 9-pin.
The pilot plug is located at the rear of the MKD.




Optional, external MKD Unit


Dimensions:..... See below
Weight:..... 0.9 kg (2.0 lbs.)
Colour:..... Black
Cable length (to Mobile Unit):..... 7 m
Enclosed material:..... Epoxy coated aluminium
Environmental protection:..... IP56 (when panel-mounted)
Temperature range - operating: -25 to +55°C (-13 to +131°F)
Temperature range - storage: -30 to +80°C (-22 to +176°F)



FRONT VIEW



VERTICALLY MOUNTED



HORISONTALLY MOUNTED

**THIS PAGE INTENTIONALLY LEFT
BLANK**

2 INSTALLATION

2.1 General

To reduce the installation cost, crew members (Crew) qualified to perform electrical installations can perform part of the installation. However, qualified service personnel (SP) should carry out the final commissioning.

2.2 Unpacking and handling

Care should be taken when unpacking and handling the equipment. A visual inspection should be made to ensure that the equipment has not been damaged during shipment, and that all parts are present.

A standard AI80 delivery includes:

- AI80 Mobile Unit
- AI80 MKD
- GPS4 GPS antenna including mounting kit and cable adapter set
- Documentation, including User and Installation manual

2.3 Installation procedure

The table on the following pages describes a recommended installation procedure. It also describes items that could be performed by the vessel crew and items that must be carried out by qualified personnel. The table also includes page references to the various items' installation description in this manual.

Description	Performed by		Ref page
	Crew	SP	
1. Mount the GPS4 antenna included in the AI80 system and the third party VHF antenna.	x		
2. Connect the adapter cable to the GPS4 antenna.	x		
3. Pull cables from the antennas to the AI80 Mobile Unit.	x		
4. Check the GPS and VHF cables for short circuit between the centre conductors and shield (ground).	x		23
5. Mount the AI80 Mobile Unit - mount the MKD.	x		16 onwards
6. Connect the GPS adapter cable to antenna cable.	x		
7. Connect the GPS4 antenna and the VHF antenna to the plugs on the rear of the Mobile Unit (connectors to be mounted by SP).	x		19
8. Connect the MKD unit to the Mobile Unit using the supplied cables.	x		19
9. Connect the external main GPS sensor to Sensor port 1, 2 or 3 on the Mobile Unit.		x	
10. Connect the vessel's main heading sensor to Sensor port 1, 2 or 3 on the Mobile Unit.		x	
11. Provide other interface from external sensors to the Mobile Unit.		x	
12. Connect the Power to the Mobile Unit. Make sure the power supply is from the vessel's emergency supply.		x	
13. Apply power to the AI80 system.		x	
14. Check that the indication on the LED indicators on the Mobile Unit is as follows: GPS LED: blinks green once each second TX LED: blinks green and amber, at the most 10 seconds between each blink MSG LED: blinks green and amber, at the most 10 seconds between each blink		x	
15. Perform the software setup procedure.		x	

2.4 Cabling

Double shielded coaxial cables equal or better than RG-214 are recommended when connecting the GPS and VHF antennas to the AI80 system.


Coaxial cables should be installed in separate signal cable channels/tubes and at least 10 cm away from power supply cables.

All outdoor installed connectors on the coaxial cables should be fitted with preventive isolation such as shrink-stocking with silicone to protect against water penetration.

Avoid sharp bends of the cables. A bend may change the characteristic impedance of the cable.

CABLE NO.	DESCRIPTION	CABLE LENGTH	PART NO.
1	Interface cable to MKD/Pilot Plug	7 m	A101-13_1
2	Adapter cable GPS	0.5 m	A100-93
3	Interconnection cable GPS4	0.5 m	A101-03
4	Mounting kit, GPS antenna		A101-02

The figure below shows cables and cable length in a standard AI80 system.



Note !

Shaded items and cables are not part of a standard AI80 scope of supply.

Antenna cables

The antenna cables should be as short as possible to minimise attenuation of the signal. The cables should be located at least 10 cm away from power supply cables.

The table below shows the maximum cable length (VHF) for the different antenna cable types.

Cable type	Max. length at 160 MHz
RG58	10 metres
“PUR” 58 *	10 metres
RG213	30 metres
RG214 *	30 metres
LowLoss ½” *	100 metres

* Recommended cable types.

Power cables

Use minimum 2 x 2.5 mm² cables to avoid voltage drop.

2.5 Location of the units


The units included in the AI80 system should be mounted with special regard to the units' environmental protection, temperature range and cable length. Refer Technical specifications, page 1 onwards.

Antenna location

The AIS equipment, like any other ship borne transceiver operating in the VHF maritime band, may cause interference to a ship's VHF radiotelephone. This interference may occur as a periodic (e.g. every 20 s) soft clicking sound on a ship's radiotelephone.

This affect may become more noticeable when the VHF radiotelephone antenna is located near the AIS VHF antenna, and when the radiotelephone is operating on channels near the AIS operating channels (e.g. channels 27, 28 and 86).

The figure below shows recommended location and distance between the different antennas.



2.6 MKD unit

Mechanical installation

The MKD may be panel or bracket (option) mounted. The optional mounting bracket may be ordered separately.

The unit should be mounted with special regard to the operator's need for easy operation.

Avoid mounting the MKD where it is easily exposed to sunlight, as this will shorten the lifetime of the display. If this is not possible, make sure the units are always covered with a protective cover when not in use.

Panel mounting

Make sure that the mounting location includes space for plug and cable bend.

The mounting surface must be flat and even to within 0.5 mm.

1. Remove the 4 front panel corners from the MKD.
2. Drill 4 mounting holes and make a panel cut-out according to dimensional drawing, pages 5 and 6.
3. Fasten the MKD to the panel with the supplied 19 mm screws.
4. Apply the front panel corners.

Note !

Do not over-tighten the mounting screws.

Bracket mounting (option)

When the MKD is bracket mounted (item A100-85), it is not weatherproof from the back. When bracket-mounted, the exposed parts of the plugs should be protected against salt corrosion.

1. Locate the cradle on the mounting site and mark the 4 holes for the screws on the mounting surface.
2. Drill the 4 holes and screw the cradle to the mounting surface.
3. Use the supplied screws to fasten the MKD to the left and right brackets.
4. Apply the front panel corners.

Use the two locking knobs to assemble the cradle with the left and right brackets and adjust the MKD for the best viewing angle.

2.7 Optional MKD unit

Mechanical installation

The optional MKD may be panel or bracket (option) mounted. The optional mounting bracket may be ordered separately.


The unit should be mounted with special regard to the operator's need for easy operation.

Avoid mounting the MKD where it is easily exposed to sunlight, as this will shorten the lifetime of the display. If this is not possible, make sure the units are always covered with the protective cover when not in use.

Panel mounting

Make sure that the mounting location includes space for plug and cable bend.

The mounting surface must be flat and even to within 0.5 mm.




1. Remove the 4 front panel corners from the MKD.
2. Drill 4 mounting holes and make a panel cut-out according to dimensional drawing, page 8.
3. Use the supplied gasket between the panel and the unit.
4. Fasten the MKD to the panel with the supplied 19 mm screws.
5. Apply the front panel corners.

Note !

Do not over-tighten the mounting screws.

Bracket mounting (option)

When the MKD is bracket mounted (item A100-85), it is not weatherproof from the back due to a breathing hole in the back cabinet. When bracket-mounted, the exposed parts of the plugs should be protected against salt corrosion.




1. Locate the cradle on the mounting site and mark the 4 holes for the screws on the mounting surface.
2. Drill the 4 holes and screw the cradle to the mounting surface.
3. Use the supplied screws to fasten the MKD to the left and right brackets.
4. Apply the front panel corners.
5. Use the two locking knobs to assemble the cradle with the left and right brackets and adjust the MKD for the best viewing angle.

The optional MKD cable

The optional MKD is connected to the AI80 Mobile Unit with a 7-metre cable included with the MKD.

The connector may be connected to any of the two inputs on the rear side of the MKD.

The table below gives the pin layout for the MKD connector and the 9-pin D-sub connector that is connected to the Mobile Unit.



Signal name	MKD connector	Wire colour	D-sub 9-pin (Mobile Unit)
Bus-	1	Brown	2
Bus+	2	White	7
V System -	4	Black	1
V System +	5	White	6

Note !

Short circuit on the MKD connector may cause permanent damage to the AI80 Mobile Unit.

2.8 AI80 Mobile Unit

Mechanical installation

The Mobile Unit should be mounted in a place with proper ventilation. The unit is mounted with four bolts, refer dimensional drawing on page 4.

Ensure that there is enough space on the rear side of the unit for installation of plugs and cables. A minimum distance of 220 mm between the unit and the wall is required.

Make sure that unit is properly secured to the deck/bulkhead. Clamps are recommended to secure power and data cables connected to the Mobile Unit.


Cable connection

The rear panel of the Mobile Unit contains connectors for GPS, VHF, external MKD, data signals and power (+24V DC).

The connector types are as shown in the table below:


Type	Connected to:
9 pins D-Sub, male	MKD
TNC connector, Female	GPS antenna
N-connector, Female	VHF antenna
Screw terminals P1, P2	Data I/O
Screw terminals	Power

Rear connections



Data signals

The figure below shows the location of the AI80 data signals on the P1 (left connector row), P2 (right connector row). Refer to chapter 3 for description of signals. For detailed electrical description, see Appendix B - Digital interface IEC 61162-1.



Note ! *RD(A) is low relative to RD(B) when idle. TD(A) is low relative to TD(B) when idle.*

Note ! *All data cables must be twisted pair cables with shield.*

All cables should be terminated to shield using the clamps on the mounting plate.

2.9 Pilot plug

A Pilot plug is included in the AI80 system and is located at the rear of the AI80 MKD. The plug is used for connecting a Personal Pilot Unit (PPU) to the AI80 system.

The pilot plug is an AMP CPC series 2/Receptacle (Square Flanged), Shell size 11, 9-pin.

In case of a panel mounted MKD, an extension cord must be used.


Default baud rate is 38400, N, 8, 1.

Signal name	Seatex notation	Pin on AMP 206486-1
TX(A)	Pilot_TD(A) (TXA)	1
TX(B)	Pilot_TD(B) (TXB)	4
RX(A)	Pilot_RD(A) (RXA)	5
RX(B)	Pilot_RD(B) (RXB)	6
Shield	Shield	9

2.10 External alarm

The Mobile Unit does not include an acoustic alarm, but has a built-in alarm functionality. An alarm will open the alarm relay, which can be used to trigger an external alarm.

The diagram below shows how an external alarm may be connected to the rear of the Mobile Unit.



2.11 GPS antenna

Mechanical installation


The GPS antenna included in the AI80 system is used for time synchronisation and computation of backup position fix. In addition to this GPS antenna, the AI80 should be connected to the vessel's main GPS system at the rear of the Mobile Unit. Sensor input 1-3 may be used.

Optimum location of the GPS antenna is important to ensure continuous track of all visible GPS satellites. The following should be taken into consideration during installation:

- The GPS antenna must be installed where it has a clear view of the sky and thus the objective is to see the horizon freely through 360 degrees with a vertical observation of 5 to 90 degrees above the horizon.
- Small diameter obstructions, such as masts and booms, do not seriously degrade signal reception but such objects must not eclipse more than a few degrees of any given bearing.
- The antenna should be located at least 3 metres away from and out of the transmitting beam of high power transmitters (S-band radar and/or Inmarsat systems). This includes the ship's own AIS VHF antenna if it is located separately.

Refer figure on page 15.

Use the supplied antenna mounting kit when mounting the antenna. Appropriate crimping tools must be used.



GPS antenna offset arms

The mounting location for the internal GPS antenna and for the main GPS antenna connected to the AI80 system, needs to be input to the AI80 as a part of the configuration settings. The figure shows the offset arms that have to be configured.

Refer **Entering static data**, pages 32 and 90.

Checking the antenna cable


After the mechanical and electrical installation is completed, the coaxial cables should be checked for short circuit between centre conductor and shield (ground) with the antenna disconnected. If not short-circuited, the antenna cable could be connected to the Mobile Unit.

Sealing antenna connectors

The outdoor antenna connectors have to be sealed with self-bonding tape and PVC/Vinyl tape for waterproofing.

Coil the self-bonding tape from one cable end to the other. Use at least two layers of tape. After coiling, make a bounding by pressure of fingers.

Coil at least two layers of PVC/Vinyl tape without stretching. After coiling, make a bounding by pressure of fingers.



2.12 VHF antenna

The VHF antenna is not included in a standard AI80 system, but has to be part of the AIS installation. A qualified antenna must cover marine band (156 MHz - 164 MHz), have omni-directional vertical polarization and provide 2 to 5 dB gain.

For installation of this antenna, refer to documentation delivered by the antenna supplier. Refer also to the figure on page 15 for location.

Verify that there is no short circuit between centre conductors and shield (ground) before the cable is connected to the Mobile Unit. Seal the antenna connectors as described for the GPS antenna.

As an option Kongsberg Seatex AS may provide an antenna with part number A100-58, shown in Appendix E - Optional VHF antenna.

**THIS PAGE INTENTIONALLY LEFT
BLANK**


3 CONNECTING AND CONFIGURING EXTERNAL EQUIPMENT

3.1 General

In general, all sensors installed in compliance with other carriage requirements of SOLAS Chapter V should be connected to the AI80 system.

Increased navigational performance can be achieved by interfacing the AI80 to an ECDIS, ECS and/or radar.

All external equipment is connected to the AI80. For termination, refer **Data signals**, page 20.



Note !

Shielded twisted pair cables shall be used for the high-speed serial data ports.

The following sections present the port configuration and IEC 61162-1 sentences that may be used when connecting external equipment to the AI80 system. Detailed description of the IEC 61162-1 sentences are found in **Appendix B - Digital interface IEC 61162-1**, page 51.

For terminal location, refer to the figure on page 20.

3.2 Presentation interface

The presentation interface consists of two physical ports: **PI** and **Pilot** port. Both ports are functionally equivalent.

The **PI** port provides a primary port for connecting onboard equipment such as ECDIS, radar, Long Range AIS etc.

The **Pilot** port is used for the Pilot Plug included in the AI80 system. This plug is intended for the ship's pilot equipment, service equipment, etc.

Physical location

Installed on P1, pins 11 - 15. See figure on page 20.

Port configuration

The PI and Pilot port have the following default settings:

Baud Rate	Parity	Bits	Stop Bit
38400	N	8	1

The baud rate is configurable to either 38400 or 57600. This due to the amount of data. Refer to **Configuring external serial ports**, pages 33 and 91.

Input sentences

Sentence	Content
VSD	Voyage static data
SSD	Ship static data
ABM	Addressed binary message
BBM	Broadcast binary message
AIR	AIS interrogation message
ACA	AIS channel assignment command
ACK	Acknowledgement message
LRF	Long range acknowledge

Proprietary input sentences

Sentence	Content
MMSI	MMSI number
IMO	IMO number
PORT	Serial port configuration parameters

Output sentences

Sentence	Content	Transmission interval
ABK	Acknowledgement message	Upon reception of messages 7 and 13, and when sending message 15
VDO	VHF Data link own message	1 Hz nominal
ALR	Alarm messages	30 seconds/1 min.
TXT	Indication messages	When change of status
ACA	AIS channel assignment command	When change of status
VDM	VHF Data link message	When receiving on VDL
LRI	Long-range interrogation	When LR request received & when LR response sent
LRF	Long-range function identification	When LR request received & when LR response sent
LR1	Long-range response	When LR response sent
LR2	Long-range response	When LR response sent
LR3	Long-range response	When LR response sent

3.3 Long-Range interface

The Long Range interface provides a two-way interface for equipment that provides for long-range communications, such as Inmarsat.

Physical location

Installed on P2, pins 1 - 5, see figure on page 20.

Port configuration

The Long Range port has the following default settings:

Baud Rate	Parity	Bits	Stop Bit
4800	N	8	1

The baud rate is configurable from 1200 to 57600. Refer to **Configuring external serial ports**, pages 33 and 91.

Input sentences

Sentence	Content
LRI	Long-range interrogation
LRF	Long-range function identification

Output sentences

Sentence	Content	Transmission interval
LRF	Long-range function identification	When LR response sent
LR1	Long-range response	When LR response sent
LR2	Long-range response	When LR response sent
LR3	Long-range response	When LR response sent

3.4 Sensor input

Physical location

Sensor1 is installed on P1, pins 16 - 20, Sensor2 is installed on P1, pins 6 - 10 and Sensor3 is installed on P1, pins 1 - 15, see figure on page 20.

These ports are mainly intended to serve as inputs from ships' primary navigation systems such as position sensor data and heading sensor data (the ports are configurable and transmission of two-way data is possible).

Port configuration

The sensor inputs Sensor1, Sensor2 and Sensor3 are equivalent and the default settings are as follows:

Baud Rate	Parity	Bits	Stop Bit
4800	N	8	1

The baud rate is configurable from 1200 to 57600. Refer to **Configuring external serial ports**, pages 33 and 91.

Input sentences

Sentence	Content	From version
GGA	Position, TOD, position quality (diff/non-diff)	1.5 →
GNS	Position, TOD, position quality (diff/non-diff)	3.0 →
GLL	Position, TOD, position quality (diff/non-diff)	2.0 →
DTM	Datum	3.0 →
VBW	SOG, COG (derived from speed components)	3.0 →
VTG	SOG, COG	1.5 →
RMC	Position, TOD, position quality (diff/non-diff), SOG, COG	1.5 →
HDT	Heading	1.5 →
GBS	RAIM indicator	3.0 →
ZDA	TOD and Date	1.5 →
OSD	Position, TOD, SOG, COG, Heading	2.0 →
ROT	Rate of turn	2.0 →

If the sensor inputs are configured with redundant data, the tables below describe the priorities of the redundant data.

Priority of Position

Priority	Sentence
1	RMC
2	GNS
3	GGA
4	GLL

Priority of SOG and COG

Priority	Sentence
1	RMC
2	OSD
3	VBW
4	VTG

Priority of Heading

Priority	Sentence
1	OSD
2	HDT

Priority of Rate of Turn

Priority	Sentence
1	ROT
2	OSD (derived from heading)
3	HDT (derived from heading)

4 SOFTWARE SETUP PROCEDURE

4.1 General

The AI80 system is set up with factory settings during testing. The software setup must be performed as a part of the AI80 installation procedure.

The software setup is performed from sub-menus available from the **Main Menu** page, activated by pressing the **VIEW** button. The respective **Main Menu** pages are shown below.

- MAIN MENU -----	
Alarms and LR	
Dynamic data	
Settings	▼
SMS	
Downperiods	
Chn.Management	
System	

This is the **Main Menu** page for the AI80 with sub-menus. All settings that need to be changed can be found in the **Settings** sub-menu.

For explanation of buttons, manoeuvring in the menus and for entering data, refer to the *Simrad AI80 User Manual*.

Note !

*The software settings may be protected by a security code. When entering parameters defined with a security level other than 0, the access code has to be entered before these settings can be changed. Refer **Security settings AI80** in the next pages and page 87.*

4.2 Security settings AI80

- Settings -----	
Nav.Status	
Voyage related	
Gyro calibration	
Static data	
VHF	▲
LR	
Serial	
PIN	

Security PIN code

All entries on this page are protected by a PIN code.

Initially, a default authorisation code is used for altering data fields in the **Settings** page. The default PIN code is: 1234. We recommend to change to a vessel specific PIN code.

Enter new four digit PIN code by selecting PIN and PIN: **** on the **Settings** menu.

Note! *Based on the MAC address a master PIN code can be handed out from Custom Support.*

4.3 Entering static data

- Static data ----- Name: VANNINA Call: CA122 MMSI: 136547932 IMO: 3334445 Type: 123 Keel: 30.5 DimA: 0 DimB: 0 DimC: 0 DimD: 0 LocDimA: 0 LocDimB: 0 LocDimC: 0 LocDimD: 0

Static data are specific ship data that do not change from one voyage to another. In order to input static data, select parameters by pressing **EDIT** and press **SHIFT** to access text mode.

If MMSI number is changed, the unit should be restarted, see the *Simrad AI80 User Manual*.

Name: The vessel name (text).

Call: The vessel call sign (text).

MMSI: The Maritime Mobile Signal Identifier number.

IMO: The vessel IMO number.

Type: Type of vessel.

Keel: Height over keel. Total height of vessel in metres.

DimA: External GPS antenna location

DimB: External GPS antenna location

DimC: External GPS antenna location


DimD: External GPS antenna location

LocDimA: Internal GPS antenna location

LocDimB: Internal GPS antenna location

LocDimC: Internal GPS antenna location

LocDimD: Internal GPS antenna location



External GPS/GNSS antenna location. Since the vessel's primary GPS receiver is used as reference for the transmitted AIS position, the physical location (horizontal plan only) of the vessel GPS antenna should be input to the AIS in metres.

Setup by entering: DimA, DimB, DimC & DimD.

Internal GPS antenna location. The AIS internal GPS receiver is backup position sensor for the vessel primary GPS receiver. The AIS internal GPS antenna's physical location (horizontal plane only) also needs to be input to the AIS in metres.

Setup by entering: LocDimA, LocDimB, LocDimC & LocDimD.

4.4 Configuring external serial ports

The serial port baud rate must be set up according to external instrumentation. The sensor interfaces comply with the NMEA 0183, version 3. Change the baud rates accordingly.

Enter the **Serial** page by selecting **Settings** in the **Main Menu**, and **Serial** in the **Settings** menu. In the **Serial** page, press **EDIT** to start editing the baud rate. Hold **OK** to save.

4.5 VHF data link

The VHF page includes ON/OFF status for transmitter and VDL answer mode.

ON/OFF status: The transmitter setting is recommended set to TX: ON.

Note !

The transmitter may be turned OFF at Master's discretion should an emergency situation occur. However, the AIS receiver will still be functioning and thus AIS data from other vessels will still be received.

VDL answer mode: VDL answer mode allows the configuration of the AIS unit with regard to how it responds to inquiries by binary messages (messages 6 and 8).

An inquiry of this type could be a request for information regarding number of persons onboard, draught etc. If turned OFF, the AIS will ignore the inquiry.

Note !

The VDL setting "ON" indicates that answer mode to interrogator is enabled when message 6 or 8 containing interrogation functional identification, is received.

4.6 Configuring radio channels

Viewing a region's settings

Under this option a list of all registered regions is displayed. By using the **ARROW** buttons, regions can be individually selected. Selecting a region is done by pressing the **OK** button and region parameters will be shown. This is a read-only page.

Adding a region

- Add region -----
ChnA: 0
ChnB: 0
RxTx: TxA/TxB, RxA/Rx▼
TxPower: LOW
LAT NE: 00°00'00.00N
LON NE: 000°00'00.00E
LAT SW: 00°00'00.00N
LON SW: 000°00'00.00E
BW A: Default
BW B: Default
Zone: 0
Hold [OK] to save

To edit these parameters, use the **ARROW** keys to manoeuvre to the parameter of interest and press **EDIT**. Use the **DEL** button if necessary, and enter the new value. If non-digits are required, press the **SHIFT** button to change to alpha mode. Press the **SHIFT** button again to return to digit mode.

While in alpha mode, letters and special characters can be entered (e.g. the degree symbol °).

Note !

If the user tries to enter a region which parameters locates the region more than 500 nautical miles away from the vessel, the region will automatically be discarded. Also when the vessel position is further than 500 nautical miles from the region, this region is automatically discarded by the AIS unit.

ChA: The radio channel to be used as channel A.

ChB: The radio channel to be used as channel B.

RxTx: Transmission/reception mode. This parameter indicates whether or not the AIS should transmit and receive on both channels, or on only a subset of these.

TxPower: The transmission power of the radio. Low equals 2W, and High equals 12W.

Lat/Lon: The rectangular area to which the radio parameters apply. The area is specified by entering the coordinates for the north-east corner and the south-west corner.

BW A: Bandwidth for the selected channel A.

BW B: Bandwidth for the selected channel B.

Zone: Transition zone for the region. This parameter is given in nautical miles, and provides information about the transition zone of the region in which the AIS should change radio parameters to the ones specified for the region.

Edit current region

This function is used to change the current radio parameters and is similar to **Add Region**, the only difference being that by changing these values the default parameters for the current region are altered and take effect immediately.

Note !

*For software setup procedure using optional MKD see **Appendix C - Software setup using optional MKD** on page 87.*

**THIS PAGE INTENTIONALLY LEFT
BLANK**

5 MAINTENANCE

5.1 General

All units in the AI80 system are “repair by replacement” units, and the operator is therefore required to perform only a limited amount of preventive maintenance on the units.

The service in the field is limited to:

- Replacing damaged GPS or VHF antenna cables
- Replacing failed AI80 system units

A damaged unit that has to be shipped back to the supplier, should be sent in the original transportation box or another appropriate box. The return address is provided in the first pages of this manual.

5.2 Periodic maintenance

The AI80 system should regularly be checked for firm and fixed mounting of the chassis in order to avoid excessive resonances. All connectors should be checked for good mechanical and electrical connections. Cables should not be bent more than the minimum recommended bending radius and there should be no sharp bends on coaxial cables. All cables should be fixed tight and rigid to their supporting structure (bulkhead, mast etc.) and special care should be taken where cables run through holes with sharp edges.

MKD Units

The MKD will under normal use require little maintenance.

If the unit requires any form of cleaning, use fresh water and a mild soap solution (not a detergent). It is important to avoid using chemical cleaners and hydrocarbons such as diesel, petrol etc.

Mobile Unit

A properly operating Mobile Unit will indicate transmitting and receiving messages by short blinks on the **TX** and **MSG** LEDs. Inspecting the LEDs for normal operation gives a good indication of the operating status. Any red LED indication means that further investigation and servicing is necessary, see chapter 6.1.

5.3 Repair and modifications

The units in the AI80 system are not designed for customer repair. All repairs and modifications of the units should be carried out by qualified personnel. A failed unit should be shipped back to the supplier for repair.

Exchanging antenna cables

1. Disconnect the power cable.
2. Dismount the damaged antenna cable. The new antenna cable must be as straight as possible. Do not crush or crimp the cable, as this will affect the electrical properties of the cable.
3. Connect the antenna cable to the antenna.
4. Seale the connection between the antenna and the antenna cable against water penetration as described in page 23.
5. Connect the antenna cable to the AI80 Mobile Unit and reapply power.

Note !

If the GPS antenna cable is attached to the Mobile Unit, do not attach the antenna cable to the antenna when the AI80 is powered. If the antenna cable is short-circuited with power on, the GPS receiver within the unit can be damaged.

Exchanging GPS or VHF antennas

1. Disconnect the power cable.
2. Dismount the failed antenna.
3. Mount the new antenna on the antenna rod.
4. Connect the antenna cable to the antenna.
5. Seale the connection between the antenna and the antenna cable against water penetration as described in page 23.
6. Connect the antenna cable to the AI80 Mobile Unit and reapply power.

Note !

If the GPS antenna cable is attached to the Mobile unit, do not attach the antenna cable to the antenna when the AI80 is powered. If the antenna cable is short-circuited with power on, the GPS receiver within the unit can be damaged.

5.4 Software updates

The software in the AI80 system can be upgraded to the latest version in the field by changing the compact flash inside the Mobile Unit. Do the following:

1. Enter the **System** menu, select **Software upgrade** and **Start upgrade**. Follow on-screen instructions. Power off the unit.
2. Open the front panel.
3. Locate the compact flash and gently remove it.
4. Insert new compact flash and close front panel.
5. Power on the unit.

**THIS PAGE INTENTIONALLY LEFT
BLANK**

6 TROUBLESHOOTING

6.1 General

The LED indicators on the front of the Mobile Unit can be used to monitor status as well as data reception and transmission.

LED	Colour	Description
TX	Off	Transmitter idle
	Amber	Transmitting on AIS channel B
	Green	Transmitting on AIS channel A
	Red	Transmitter turned off
MSG	Off	No message/report being received
	Amber	Message/report received on channel B
	Green	Message/report received on channel A
GPS	Amber	Indirect synchronisation free run
	Green	Internal GPS OK, GPS synch selected
ALM	Off	No alarm
	Red	Alarm - alarm relay activated

Prior to any troubleshooting, the system should be restarted to see if this resolves the problem.

- Restart the Mobile Unit as described in the *Simrad AI80 User Manual*.
- Remove the + 24 V power supply cable and then reapply power.

6.2 Hardware problems

Hardware problems can be divided into the following categories:

- Power supply failure
- GPS receiver failure
- VHF transceiver failure
- GPS and VHF antennas and cables
- Interface cables

If the system outputs an alarm, the alarm condition can be read from the display.

Power supply failure

If the unit periodically restarts approximately every one minute, this could indicate a power supply failure.

Use the following procedure to check for power failure:

1. Check that external power has been connected to the rear connectors.
2. Verify that supplied power is in accordance with technical power specifications, page 1.
3. Verify that power cable dimensions are minimum 2.5 mm².

GPS and VHF antenna cable connections

Typical problems when no GPS signal is received are that the GPS antenna cable and/or connectors are damaged, or that the cables are not properly connected. In order to check for antenna cable problems, ensure that the GPS antenna is disconnected. The Ohm reading between the centre and the screen should normally be infinite if there is no short-circuit in the cable. Make a short-circuit in the opposite end of the cable and measure the resistance. Now the reading should be approximately 0 Ohm.

GPS and VHF antenna malfunction

Disconnect the GPS antenna cable at the rear side of the Mobile Unit. Measure the resistance between the centre pin and shield in the cable (with the antenna connected). The GPS antenna does not have a defined resistance that can be measured. Therefore, before measurements can be carried out, the antenna end of the cable needs to be short-circuited. Measure between centre conductor and shield. Resistance should be close to 0 Ohm.

Caution! *Switch off the power before disconnecting the antenna!*

GPS receiver failure

During normal operation the **GPS** LED blinks green once each second. If the **GPS** LED on the front of the unit blinks amber, the AI80 system computes no position data, the GPS receiver inside the Mobile Unit should be checked.

Disconnect the antenna cable at the rear side of the Mobile Unit. The voltage output on the GPS antenna connector should be approximately 4.8 – 5.0 V if the GPS receiver supplies voltage to the antenna. If not, this indicates problems with the GPS receiver. Disconnect and reconnect power to see if the Mobile Unit starts up as normal. If not, consult Customer Support for advice.

VHF transceiver failure

If there is no activity on the **TX** and/or the **MSG** LED on the front of the unit, this indicates a transmitter or receiver problem. Disconnect and reconnect power to see if the Mobile Unit starts up as expected. If not, consult Customer Support for advice.

6.3 External data interface problems

External data connections may have incorrect:

- Data input from main GPS source
- Data input from vessel heading sensor

Check NMEA version, see table on page 29.

Data input from main GPS/GNSS source

Position data input to the AI80 system is received from the vessel's main GPS/GNSS receiver using an RS-422 serial line communication. If data are not received in the AI80 Mobile Unit, the following steps should be taken in order to check for missing position data:

1. Check that corresponding cable connections are correctly terminated, refer chapter 3.4 and note on page 20.
2. If properly connected, check the serial line communication (baud rate, parity, number of bytes transmitted, number of stop bits) between transmitting (vessel GPS/GNSS receiver) and receiving (parameters to be checked from display) end.
3. If OK, check that the position output format from the GPS/GNSS receiver is in accordance with the expected input position format, see page 29 and Appendix B - Digital interface IEC 61162-1.

If the Mobile Unit still does not receive position data, consult Customer Support for advice.

For details on electrical interface, see page 51.

Heading from vessel heading sensor

Heading data is received from the vessel's gyro. If input data is missing, the following steps should be taken in order to check for missing heading data:

1. Check that corresponding cable connections are correctly terminated, refer chapter 3.4 and note on page 20.
2. If correctly connected, check the serial line communication (baud rate, parity, number of bytes transmitted, number of stop bits) between transmitting (vessel heading sensor) and receiving (parameters to be checked from the MKD unit) end.
3. If OK, check that the heading output format from the compass is in accordance with the expected input heading format, see page 28 and Appendix B - Digital interface IEC 61162-1.

If the Mobile Unit still does not receive heading data, consult Customer Support for advice.

AIS unit restarts

If the AIS unit frequently restarts, please note that the AIS is dependent upon 24 V DC/50 W, see Power supply failure on page 42.

1. Check that external power source has sufficient current rating (recommended 4 A) and that
2. power cables are within specifications for such a power consumption.

7 SPARE PART LIST

7.1 Simrad AI80

A120-14 Simrad AI80 including	
Part No	Description
A101-11_1	Simrad AI80 Class A Mobile Station
A101-12_1	Simrad AI80 MKD, including interface cable to MKD/pilot plug (A101-13_1) length 7 m
A101-01	GPS antenna, GPS4
A101-02	Mounting kit for GPS4
A101-03	Interconnection cable for GPS4
A100-93	Adapter cable set for GPS antenna cable, one cable, length 0.5 m
A101-17	AI80 terminals for data and power
A101-15	AI80 Installation Manual
A101-16	AI80 User's Manual

Optional supplied equipment

Part No	GPS/VHF antenna cables and connectors
A100-59	GPS/VHF antenna cable (RG 214), price per m, max. length 30 m*
A100-61	Connector kit for GPS antenna cable (RG214), two connectors
A100-66	Connector kit for VHF antenna cable (RG214), two connectors
A100-60	GPS/VHF antenna cable (low loss), price per m, max. length 100 m*
A100-71	Connector kit for GPS antenna cable (low loss), two connectors
A100-73	Connector kit for VHF antenna cable (low loss), two connectors
B200-12	Adapter cable set for VHF antenna cable, two cables length 0.5 m

Part No	Optional MKD, MKD bracket, VHF antenna and cables
A101-07_3	Simrad AIS MKD, incl. interface cable to MKD, length 7 m
A100-76	Interface cable to MKD, length 7 m
A100-77	Interface cable to MKD, length 15 m
A101-13_1	Interface cable to AI80 MKD, length 7 m
A101-13_2	Interface cable to AI80 MKD, length 15 m
A100-85	MKD bracket for table, bulkhead or overhead mounting
A101-14	AI80 MKD bracket for table, bulkhead or overhead mounting
A100-58	VHF antenna, AV7N
A100-88	AIS power cable (Belden 8471 NH), price per metre
A100-96	Connection cable (GPS, Gyro, ECDIS), price per metre
Part No	Gyro converter and power supply
A900-60	GI51 Gyro Interface Unit including manual
A900-20	Power Supply (110/230 V AC / 24 V DC)

*) For GPS or VHF antenna cable lengths between 30 and 100 meters, we recommend to select A100-60 with connectors A100-71 and A100-73.

8 APPENDIX A - VESSEL IDENTIFIERS

The table on the following pages holds an overview of all vessel identifiers that should be used in an AIS system.

The following abbreviations are used in the table:

WIG: Wing In Ground

HSC: High Speed Craft

DG: Dangerous Goods

HS: Harmful Substances

MP: Marine Pollutants


No.	First digit	Second digit
10	Reserved for future use	All ships of this type
11	Reserved for future use	Carrying DG, HS or MP, IMO hazard or pollutant category A
12	Reserved for future use	Carrying DG, HS, or MP, IMO hazard or pollutant category B
13	Reserved for future use	Carrying DG, HS, or MP, IMO hazard or pollutant category C
14	Reserved for future use	Carrying DG, HS, or MP, IMO hazard or pollutant category D
15	Reserved for future use	Reserved for future use
16	Reserved for future use	Reserved for future use
17	Reserved for future use	Reserved for future use
18	Reserved for future use	Reserved for future use
19	Reserved for future use	Reserved for future use
20	WIG	All ships of this type
21	WIG	Carrying DG, HS or MP, IMO hazard or pollutant category A
22	WIG	Carrying DG, HS, or MP, IMO hazard or pollutant category B
23	WIG	Carrying DG, HS, or MP, IMO hazard or pollutant category C
24	WIG	Carrying DG, HS, or MP, IMO hazard or pollutant category D
25	WIG	Reserved for future use
26	WIG	Reserved for future use

No.	First digit	Second digit
27	WIG	Reserved for future use
28	WIG	Reserved for future use
29	WIG	Reserved for future use
30	Vessel	Fishing
31	Vessel	Towing
32	Vessel	Towing and length of the tow exceeds 200 m or breadth exceeds 25 m
33	Vessel	Engaged in dredging or underwater operations
34	Vessel	Engaged in diving operations
35	Vessel	Engaged in military operations
36	Vessel	Sailing
37	Vessel	Pleasure craft
38	Vessel	Reserved for future use
39	Vessel	
40	HSC	Reserved for future use
41	HSC	Carrying DG, HS or MP, IMO hazard or pollutant category A
42	HSC	Carrying DG, HS, or MP, IMO hazard or pollutant category B
43	HSC	Carrying DG, HS, or MP, IMO hazard or pollutant category C
44	HSC	Carrying DG, HS, or MP, IMO hazard or pollutant category D
45	HSC	Reserved for future use
46	HSC	Reserved for future use
47	HSC	Reserved for future use
48	HSC	Reserved for future use
49	HSC	Reserved for future use
50	Pilot vessel	
51	Search and rescue vessels	
52	Tugs	
53	Port tenders	
54	Vessels with anti-pollution facilities or equipment	


No.	First digit	Second digit
55	Law enforcement vessels	
56	Spare – for assignments to local vessels	
57	Spare – for assignments to local vessels	
58	Medical transports (as defined in the 1949 Geneva Conventions and Additional Protocols)	
59	Ships according to RR Resolution No. 18 (Mob-83)	
60	Passenger ships	Reserved for future use
61	Passenger ships	Carrying DG, HS or MP, IMO hazard or pollutant category A
62	Passenger ships	Carrying DG, HS, or MP, IMO hazard or pollutant category B
63	Passenger ships	Carrying DG, HS, or MP, IMO hazard or pollutant category C
64	Passenger ships	Carrying DG, HS, or MP, IMO hazard or pollutant category D
65	Passenger ships	Reserved for future use
66	Passenger ships	Reserved for future use
67	Passenger ships	Reserved for future use
68	Passenger ships	Reserved for future use
69	Passenger ships	Reserved for future use
70	Cargo ships	Reserved for future use
71	Cargo ships	Carrying DG, HS or MP, IMO hazard or pollutant category A
72	Cargo ships	Carrying DG, HS, or MP, IMO hazard or pollutant category B
73	Cargo ships	Carrying DG, HS, or MP, IMO hazard or pollutant category C
74	Cargo ships	Carrying DG, HS, or MP, IMO hazard or pollutant category D
75	Cargo ships	Reserved for future use
76	Cargo ships	Reserved for future use
77	Cargo ships	Reserved for future use
78	Cargo ships	Reserved for future use
79	Cargo ships	Reserved for future use
80	Tankers	Reserved for future use

No.	First digit	Second digit
81	Tankers	Carrying DG, HS or MP, IMO hazard or pollutant category A
82	Tankers	Carrying DG, HS, or MP, IMO hazard or pollutant category B
83	Tankers	Carrying DG, HS, or MP, IMO hazard or pollutant category C
84	Tankers	Carrying DG, HS, or MP, IMO hazard or pollutant category D
85	Tankers	Reserved for future use
86	Tankers	Reserved for future use
87	Tankers	Reserved for future use
88	Tankers	Reserved for future use
89	Tankers	Reserved for future use
90	Other types of ship	Reserved for future use
91	Other types of ship	Carrying DG, HS or MP, IMO hazard or pollutant category A
92	Other types of ship	Carrying DG, HS, or MP, IMO hazard or pollutant category B
93	Other types of ship	Carrying DG, HS, or MP, IMO hazard or pollutant category C
94	Other types of ship	Carrying DG, HS, or MP, IMO hazard or pollutant category D
95	Other types of ship	Reserved for future use
96	Other types of ship	Reserved for future use
97	Other types of ship	Reserved for future use
98	Other types of ship	Reserved for future use
99	Other types of ship	Reserved for future use

The recommended wiring (the figures below are excerpts from IEC 61162-2, ed. 1) is as shown on the drawings. The A, B and C designation correspond with the data signals as shown on figure on page 20. There may be several listeners (receivers) but only one talker (transmitter). For long lines we recommend to use a terminating resistor (120 Ohm between A' and B' at the receiving end). Avoid stubs or make them as short as possible. The common wire designated "C" is the signal ground reference and this wire shall be isolated from the outer shielding. The outer cable shield shall be continuous (unbroken) through the installation, but shall not be terminated to any part of the receiver.



Shielded twisted pair cable with third-wire is shown below. The common "C" wire may be one wire of a pair of another port's common connection wire "C", if they have the same destination.



Excerpt from 61162-2, ed. 1 (NMEA 0183 version 3.0, 3.5.2).

Proprietary 61162-1 sentences

General

In order to configure and service the AI80 Mobile Unit there are some proprietary messages that can be used on the PI or Pilot interface. The AIS Mobile Unit uses the NMEA registered "STX" manufacturer's code. When setting parameters in the AIS Mobile Unit use the **\$PSTXS** command. To query the AIS Mobile Unit for information, use the **\$PSTXQ** command. Responses from the AIS Mobile Unit uses the **\$PSTXR** command. The proprietary messages comply with IEC 61162-1 and have the following structure:

\$	P	STX	S	,	<Msg ID>	DATA	*	<FCS>	<CR>	<LF>
----	---	-----	---	---	----------	------	---	-------	------	------

Field	Definition
\$ or !	Hex 24 or Hex 21 - Start of sentence
P	Hex 50 – Proprietary sentence ID
STX	Kongsberg Seatex mnemonic code
S or R or Q	S = Set, R = Response, Q = Query
<Msg ID>	Message ID identifying a specific sentence
DATA	Data portion, unique for each Message ID.
*	Checksum delimiter
<FCS>	Checksum
<CR><LF>	End of message

MSI number

To request the current MMSI number from the AIS Mobile Unit, use the command:

\$PSTXQ,MMSI<FCS><CR><LF>*

The AIS Mobile Unit response message has the format:

\$PSTXR,MMSI,<nnnn><FCS><CR><LF>*

To set or change the MMSI number, use the command:

\$PSTXS,MMSI,<nnnn><FCS><CR><LF>*

Field	Description	Range
MMSI	Message ID identifying this sentence	NA
<nnnn>	MMSI number	0 to 1073741823

All fields are required and used.

IMO number

To request the current IMO number from the AIS Mobile Unit, use the command:

\$PSTXQ,IMO<FCS><CR><LF>*

The AIS Mobile Unit response message has the format:

\$PSTXR,IMO,<nnnn><FCS><CR><LF>*

To set or change the IMO number, use the command:

\$PSTXS,IMO,<nnnn><FCS><CR><LF>*

Field	Description	Range
IMO	Message ID identifying this sentence	NA
<nnnn>	IMO number	0 to 1073741823

All fields are required and used.

Serial port communication parameters

To request the current communication parameters of the serial ports, and to retrieve all available serial ports, use the command:

\$PSTXQ,PORT<FCS><CR><LF>*

The AIS Mobile Unit response message has the format (one message per port):

\$PSTXR,PORT,CCCC,<bbbb>,<p>,<d>,<s><FCS><CR><LF>*

To set or change the communication parameters, use the command:

\$PSTXS,PORT,CCCC,<bbbb>,<p>,<d>,<s><FCS><CR><LF>*

Field	Description	Range
PORT	Message ID identifying this sentence	NA
CCCC	Name of serial port	COM1 to COM32
<bbbb>	Baud rate	1200 to 38400
<p>	Parity, 'N' = None, 'E' = Even, 'O' = Odd	'N', 'E', 'O'
<d>	Data bits	5-8
<s>	Stop bits	1, 2

All fields are required and used.

New IEC 61162-1 sentences

This subchapter contains a description of proposed IEC 61162-1 sentences due to AIS. Reference is made to IEC 61193-2, 2001, annex B2 and IEC/PAS 61162-100.


ABK – Addressed and binary broadcast acknowledgement

The ABK-sentence is generated when a transaction, initiated by reception of an ABM, AIR, or BBM sentence, is completed or terminated.

This sentence provides information about the success or failure of a requested ABM broadcast of either ITU-R M.1371 messages 6 or 12. The ABK process utilises the information received in ITU-R M.1371 messages 7 and 13. Upon reception of either a VHF Data-link message 7 or 13, or the failure of messages 6 or 12, the AIS unit delivers the ABK sentence to the external application.

This sentence is also used to report to the external application the AIS unit's handling of the AIR (ITU-R M.1371 message 15) and BBM (ITU-R M.1371 messages 8 and 14) sentences. The external application initiates an interrogation through the use of the AIR-sentence, or a broadcast through the use of the BBM sentence. The AIS unit generates an ABK sentence to report the outcome of the AIR or BBM broadcast process.

\$--ABK,xxxxxxxx,a,x,x,x,x*hh<CR><LF>



NOTE 1

Identifies the distant addressed AIS unit involved with the acknowledgement. If more than one MMSI are being addressed (ITU-R M.1371 message 15), the MMSI of the first distant AIS unit, identified in the message, is the MMSI reported here. When the Message ID is a general broadcast (ITU-R M.1371 messages 8 or 14), this field is null.

NOTE 2

Indication of VDL channel upon which Message ID 7 or 13 acknowledgement was received. An "A" indicates reception on channel A. A "B" indicates reception on channel B. If not available, field is null.

NOTE 3 This indicates to the external application the type of ITU-R M.1371 message that this ABK sentence is addressing. Also see the message IDs listed in NOTE 4.

NOTE 4 The message sequence number, together with the ITU-R M.1371 message ID and MMSI of the addressed AIS unit, uniquely identifies a previously received ABM, AIR, or BBM sentence. Generation of an ABK-sentence makes a sequential message identifier available for reuse. The ITU-R M.1371 Message ID is used to determine the origin of the message sequence identifier number. The following table lists the origins by message ID:

ITU-R M.1371 Message ID	Message Sequence Number source
6	sequential message identifier from ABM-sentence, IEC 61162-1
7	addressed AIS unit's message 7, sequence number, ITU-R M.1371
8	sequential message identifier from BBM-sentence, IEC 61162-1
12	sequential message identifier from ABM-sentence, IEC 61162-1
13	addressed AIS unit's message 13, sequence number, ITU-R M.1371
14	sequential message identifier from BBM-sentence, IEC 61162-1
15	no source, field shall be null


NOTE 5 Acknowledgements provided are:

0	= message (6 or 12) successfully received by the addressed AIS unit,
1	= message (6 or 12) was broadcast, but no acknowledgement by the distant addressed AIS unit,
3	= message could not be broadcast,
4	= requested broadcast of message (8, 14, or 15) has been successfully completed, late reception of a message 7 or 13 acknowledgement "addressed to own-ship" MMSI – identified by; destination MMSI, acknowledgement source MMSI, message sequence identifier, and message type. Late reception means that the AIS unit did not have an acknowledgement process active for the acknowledgement that was received.

ABM – Addressed Binary and safety related message

This sentence supports ITU-R M.1371 messages 6 and 12. It provides an external application with a means to exchange data using an AIS. The message data is defined by the application only – not the AIS. This message offers great flexibility for implementing system functions that use the AIS like a communications device. After receiving this sentence, the AIS initiates a radio broadcast on the VHF Data Link (VDL) of either message 6 or 12. The AIS will make up to four broadcasts of the message. The actual number will depend on the reception of an acknowledgement from the addressed "destination" AIS. The default time between retries is 4 s. Retries will not be attempted more frequently than 4 s. Retries stop when the appropriate acknowledgement (See ITU-R M.1371 messages 7 and 13.) is received. The AIS will make up to 4 broadcasts, original broadcast plus three retries. This process could take 32 s to complete.

The success or failure of the reception of this broadcast by the intended AIS unit is confirmed through the use of the "Addressed and binary Broadcast Acknowledgement (ABK)" sentence formatter, and the processes that support the generation of an ABK-sentence. The AIS is also limited in the amount of encapsulated data that can be sent in each slot and frame. If the length of the message would exceed five slots, or the AIS broadcast would exceed the limit of 20 RATDMA slot transmissions for the current frame, the AIS will return an ABK-sentence with an acknowledgement of "2" – message could not be broadcast.



NOTE 1

The total number of sentences required to transfer the binary message data to the AIS unit. The first field specifies the total number of sentences used for a message, minimum value 1. The second field identifies the order of this sentence in the message, minimum value 1. All sentences contain the same number of fields. Successive sentences

may use null fields for fields that have not changed, such as fields 4, 5, and 6.


- NOTE 2 This sequential message identifier serves two purposes. It is both an IEC 61162-1 "sequential message identifier field," and it is the "sequence number" utilised by the ITU-R M.1371 in message types 6 and 12. The range of this field is restricted by ITU-R M.1371 to the range of 0 to 3. This sequential message identifier and the destination MMSI uniquely identifies a message. The sequential message identifier may be reused after the "ABK" acknowledgement for that sequence number is provided by the destination AIS unit. (See the ABK-sentence formatter.)
- NOTE 3 The MMSI of the AIS unit which is the destination of the message.
- NOTE 4 The AIS channel that shall be used for the broadcast: 0 = no broadcast channel preference, 1 = Broadcast on AIS channel A, 2 = Broadcast on AIS channel B, 3 = Broadcast two copies of the message – one copy sent on channel A and another copy sent on channel B.
- NOTE 5 This is the content of the "binary data" parameter for ITU-R M.1371 message 6, or the "Safety related Text" parameter for message 12. The first sentence may contain up to 48 "6-bit" symbols (288 bits). Following sentences may contain up to 60 valid "6-bit" symbols (360 bits), if fields 4, 5, and 6 are unchanged from the first sentence and set to null. The actual number of "6-bit" symbols in a sentence must be adjusted so that the total number of characters in a sentence does not exceed the "82-character" limit.
- NOTE 6 To encapsulate, the number of binary bits must be a multiple of six. If it is not, one to five "fill bits" are added. This parameter indicates the number of bits that were added to the last 6-bit coded character. This value shall be set to zero when no "fill bits" have been added. This cannot be a null field.

ACA – AIS regional channel assignment message

An AIS unit can receive regional channel management information four ways: ITU-R M.1371 message 22, DSC telecommand received on channel 70, manual operator input, and an ACA-sentence. The AIS unit may store channel management information for future use. Channel management information is applied based upon the actual location of the AIS unit. An AIS unit is "using" channel management information when the information is being used to manage the operation of the VHF receivers and/or transmitter inside the AIS unit.

This sentence is used to both enter and obtain channel management information. When sent to an AIS unit, the ACA-sentence provides regional information that the unit stores and uses to manage the internal VHF radio. When sent from an AIS unit, the ACA-sentence

provides the current channel management information retained by the AIS unit. The information contained in this sentence is similar to the information contained in an ITU-R M.1371 message 22. The information contained in this sentence directly relates to the "Initialisation Phase" and "Dual Channel operation and Channel management" of the AIS unit as described in ITU-R M.1371.



NOTE 1 This is used to bind the contents of the ACA and ACS sentences together. If provided by the AIS, the ACS sentence shall immediately follow the related ACA sentence, and both sentences shall contain the same sequence number. The AIS generating ACA and ACS sentences shall increment the sequence number by one each time an ACA/ACS pair is created. After "9" is used, the sequence numbering process shall begin again from "0". If the sequence numbers do not match, the information contained in an ACS sentence is not related to the information in an ACA sentence. The ACS sentence may be used to respond to an "ACA Query-sentence" (See IEC 61162-1, § 5.3.2.). The AIS shall respond by providing ACA/ACS pairs for each of the stored regional operating settings. At any given time, the maximum number of pairs is eight. When an ACS sentence is not sent following an ACA sentence, the sequence number may be null.

NOTE 2 Value of 1 nautical mile to a value of 8 nautical miles (with a resolution of 1 nautical mile)

NOTE 3 VHF channel number, see ITU-R M.1084, Annex 4

NOTE 4 Value of 0, bandwidth is specified by channel number, see ITU-R M.1084, Annex 4

Value of 1, bandwidth is 12,5 kHz.


- NOTE 5 Value of 0, transmit on channels A and B, receive on channels A and B
Value of 1, transmit on channel A, receive on channels A and B
Value of 2, transmit on channel B, receive on channels A and B
Value of 3, do not transmit, receive on channels A and B
Value of 4, do not transmit, receive on channel A
Value of 5, do not transmit, receive on channel B
- NOTE 6 Value of 0, high power
Value of 1, low power
- NOTE 7 Source identifiers:
A, ITU-R M.1371 message 22: Channel Management addressed message,
B, ITU-R M.1371 message 22: Channel Management broadcast geographical area message,
C, IEC 61162-1 AIS Channel Assignment sentence,
D, DSC Channel 70 telecommand, and
M, operator manual input.
This field should be null when the sentence is sent to an AIS.
- NOTE 8 This value is set to indicate that the other parameters in the sentence are "in-use" by an AIS unit at the time that the AIS unit sends this sentence. A value of "0" indicates that the parameters are not "in-use," and a value of "1" indicates that the parameters are "in-use." This field should be null when the sentence is sent to an AIS.
- NOTE 9 This is the UTC time that the "in-use" flag changed to the indicated state. This field should be null when the sentence is sent to an AIS.

AIR – AIS interrogation request

This sentence supports ITU-R M.1371 message 15. It provides an external application with the means to initiate a request for specific ITU-R M.1371 messages from distant mobile or base AIS stations. A single sentence can be used to request, as many as, two messages from one AIS unit and one message from a second AIS unit. The message types that can be requested are limited. The complete list of messages that can be requested can be found within the message 15 description in ITU-R M.1371. Improper requests may be ignored.

The external application initiates the interrogation. The external application is responsible for assessing the success or failure of the interrogation. After receiving this sentence, the AIS initiates a radio broadcast (on the VHF Data Link) of a message 15 – Interrogation.

The success or failure of the interrogation broadcast is determined by the external application's assessment of the combined reception of the ABK-sentence and future VDM-sentences provided by the AIS via the Presentation Interface. After receiving this AIR-sentence, the AIS should broadcast a message 15 within 4 s, and the addressed AIS should take no more than an additional 4 s to respond – a total of 8 s.



NOTE 1 Identifies the first distant AIS being interrogated. Two messages can be requested from the first AIS.

NOTE 2 Examples of messages that may be requested from a distant mobile AIS station include:

Message 3, Position Report,

Message 5, Ship Static and Voyage related data,

Message 9, Standard SAR Aircraft Position Report,

Message 18, Standard Class B Equipment Position Report,

Message 19, Extended Class B Equipment Position Report, and

Message 21, Aids-to-Navigation Report.

Examples of messages that may be requested from a distant AIS base station include:

Message 4, Base Station Report,

Message 17, GNSS Broadcast Binary Message, (all available corrections are requested),

Message 20, Data Link Management Message,

Message 22, Channel Management.

NOTE 3 This field is used to request a message that has been further sub-divided into alternative data structures. When requesting messages

with alternative data structures, this message subsection identifier must be provided, so that the correct sub-division of the message data is provided. If the message structure is not sub-divided into different structures, this field should be null.


NOTE 4

This identifies the second distant AIS being interrogated. Only one message may be requested from the second AIS. The MMSI of the second AIS may be the same MMSI as the first AIS. This technique can be used to request a third message from station-1.

BBM – Broadcast binary message

This sentence supports generation of an ITU-R M.1371 Binary Broadcast Message (message 8) or Safety Related Broadcast Message (message 14). It provides an external application with a means to broadcast data, as defined by the application only – not the AIS. This message offers great flexibility for implementing system functions that use the AIS like a digital broadcast device. After receiving this sentence, the AIS initiates a VHF broadcast of either message 8 or 14 within 4 s. (Also, see the ABK-sentence.)

The success or failure of the broadcast confirmed through the use of the "Addressed and binary Broadcast Acknowledgement (ABK)" sentence formatter, and the processes that support the generation of an ABK-sentence. The AIS is limited in the amount of encapsulated data that can be sent in each slot and frame. If the length of the message would exceed five slots, or the AIS broadcast would exceed the limit of 20 RATDMA slot transmissions for the current frame, the AIS will return an ABK-sentence




NOTE 1

The total number of IEC 61162-1 sentences needed to transfer the contents of the binary message to the AIS. The first field specifies the total number of sentences used for a message, minimum value 1. The second field identifies the order of this sentence in the message, minimum value 1. All sentences contain the same number of fields. Successive sentences may use null fields for fields that do not change – such as fields 4 and 5.

- NOTE 2 The Sequential Message Identifier provides a message identification number from 0 to 9 that is sequentially assigned as needed. Note that this is only a sequential message identifier. This is used differently than the "Message sequence identifier" of an ABM sentence. This identifier is incremented for each new multi-sentence message. The count resets to 0, after 9 is used. For the contents of a message 8 or 14 requiring multiple sentences, each sentence of the message contains the same Sequential Message Identification number. This number is used to link the separate sentences containing portions of the same encapsulated data. This allows for the possibility that other sentences might be interleaved with the message sentences that, taken collectively, contain a single message 8 or 14. This number also links a future ABK-sentence acknowledgement to the appropriate BBM-sentence. (See ABK, NOTE 4.)
- NOTE 3 The AIS channel that shall be used for the broadcast: 0 = no broadcast channel preference, 1 = Broadcast on AIS channel A, 2 = Broadcast on AIS channel B, 3 = Broadcast two copies of the message – one on channel A and another sent on channel B.
- NOTE 4 This is the content of the "binary data" parameter for ITU-R M.1371 message 8 or the "Safety related Text" parameter for message 14. The first sentence may contain up to 58 "6-bit" symbols (348 bits). The following sentences may contain up to 60 "6-bit" symbols (360 bits), if fields 4 and 5 are unchanged from the first sentence and set to null. The actual number of "6-bit" symbols in a sentence must be adjusted so that the total number of characters in a sentence does not exceed the "82-character" limit.
- NOTE 5 To encapsulate, the number of binary bits must be a multiple of six. If it is not, one to five "fill bits" are added. This parameter indicates the number of bits that were added to the last 6-bit coded character. This value shall be set to zero when no "fill bits" have been added. This cannot be a null field.

LRI – Long-Range Interrogation

The long-range interrogation of the AIS is accomplished through the use of two sentences. The pair of interrogation sentences, a LRI-sentence followed by a LRF-sentence, provides the information needed by an AIS to determine if it must construct and provide the reply sentences (LRF, LR1, LR2, and LR3). The LRI-sentence contains the information that the AIS needs in order to determine if the reply sentences need to be constructed. The LRF-sentence identifies the information that needs to be in the reply sentences.



NOTE 1 This is used to bind the contents of the LRI and LRF sentences together. The LRF sentence shall immediately follow the LRI sentence and use the same sequence number. The requestor process shall increment the sequence number each time a LRI/LRF pair is created. The sequencing process shall continuously increment. After "9" is used, the process shall begin again at "0". If the LRI and LRF sequence numbers are different, the Long-range interrogation is not valid.

NOTE 2 The control flag is a single character that qualifies the request for information. The control flag affects the AIS unit's reply logic. The control flag cannot be a null field. When the Control Flag is "0", the AIS responds if either:

The AIS is within the geographic rectangle provided, **and**

The AIS has not responded to the requesting MMSI in the last 24 hours, **and**

The MMSI "destination" field is null.

or

The AIS unit's MMSI appears in the MMSI "destination" field in the LRI sentence.

When the Control Flag is "1", the AIS responds if:


The AIS is within the geographic rectangle provided.

NOTE 3 This is the nine-digit number that uniquely identifies the specific AIS that should respond. This field is null when the interrogation is for a geographic region. When addressing a specific AIS, it is not necessary to provide the geographic co-ordinates of the region.

NOTE 4 The geographic region being interrogated is a "rectangular" area defined by the latitude and longitude of the north-east and south-west corners. These fields should be null when interrogating a specific AIS. (See note 2.)

LRF – Long Range Function

This sentence is used in both long-range interrogation requests and long-range interrogation replies. The LRF-sentence is the second sentence of the long-range interrogation request pair, LRI and LRF (See the LRI-sentence.). The LRF-sentence is also the first sentence of the long-range interrogation reply. The minimum reply consists of a LRF-sentence followed by a LR1-sentence. The LR2-sentence and/or the LR3-sentence follow the LR1-sentence, if information provided in these sentences is requested in the interrogation. When the AIS creates the LRF-sentence for the long-range interrogation reply, fields 1, 2, 3, and 4 should remain as received in the interrogation; and field 5 (Function Reply Status) and a new checksum are added to the LRF reply sentence.



NOTE 1 This is used to bind the contents of the LRI and LRF sentences together. The LRF sentence shall immediately follow the LRI sentence and use the same sequence number. The requestor process shall increment the sequence number each time a LRI/LRF pair is created. After 9 is used, the process shall begin again from 0. The Long-range interrogation is not valid if the LRI and LRF sequence numbers are different.

NOTE 2 The Function request field uses alphabetic characters based upon IMO Resolution A.851(20) to request specific information items. Specific information items are requested by including their function identification character in this string of characters. The order in which the characters appear in the string is not important. All characters are upper case. Information items will not be provided if they are not specifically requested – even if available to the AIS. The IMO Resolution defines the use of all characters from A to Z, but not all of the defined information is available from the AIS. The following is a list of the function identification characters with the information they request:

A = Ship's: name, call sign, and IMO number

B = Date and time of message composition

C = Position

E = Course over ground

F = Speed over ground

I = Destination and Estimated Time of Arrival (ETA)

O = Draught

P = Ship/Cargo

U = Ship's: length, breadth, type

W = Persons on board

NOTE 3

The "Function Reply Status" field provides the status characters for the "Function Request" information. When a long-range interrogation request is originated, the "Function Reply Status" field should be null. The "Function Reply Status" characters are organised in the same order as the corresponding function identification characters in the "Function Request" field. The following is a list of the "Function Reply Status" characters with the status they represent:

2 = Information available and provided in the following LR1, LR2, or LR3 sentence,


3 = Information not available from AIS unit,

4 = Information is available but not provided (i.e. restricted access determined by ship's master),

LR1 – Long-range Reply with destination for function request "A"

The LR1-sentence identifies the destination for the reply and contains the information requested by the "A" function identification character. (See the LRF-sentence.)

\$--LR1,x,xxxxxxxx,xxxxxxxx,c--c,c--c,xxxxxxxx*hh<CR><LF>



NOTE 1

The three fields, sequence number, MMSI of responder, and MMSI of requestor are always provided.

NOTE 2

The sequence number should be the same number as the sequence number of the LRI and LRF sentences that initiated this reply.

NOTE 3

The characters that can be used are listed in IEC 61162-1, table 2. Some characters in this table are the reserved characters listed in IEC 61162-1, table 1. Reserved characters may be used, but they must be represented using the "^-method" (See IEC 61162-1, § 5.1.3.). The individual information items shall be a null field, if any one of the following three conditions exist:


The information item was not requested.

The information item was requested, but it is not available.

The information item was requested, but it is not being provided.

LR2 – Long-range Reply for function requests "B, C, E, and F"

The LR2-sentence contains the information requested by the "B, C, E, and F" function identification characters. (See the LRF-sentence.)



NOTE 1

If the sentence is used, the two fields, Sequence Number and MMSI of responder, are always provided.

NOTE 2

The sequence number should be the same number as the sequence number of the LRI and LRF sentences that initiated this reply.

NOTE 3

The individual information items shall be a null field if any of the following three conditions exist:


The information item was not requested.

The information item was requested, but it is not available.

The information item was requested, but it is not being provided.

LR3 – Long-range Reply for function requests "I, O, P, U and W"

The LR3-sentence contains the information requested by the "I, O, P, U, and W" function identification characters (see the LRF-sentence).




- NOTE 1 If the sentence is used, the two fields, Sequence Number and MMSI of responder, are always provided.
- NOTE 2 The sequence number should be the same number as the sequence number of the LRI and LRF sentences that initiated this reply.
- NOTE 3 The individual information items shall be a null field if any of the following three conditions exist:
- The information item was not requested,
 - The information item was requested but is not available, or
 - The information item was requested but is not being provided.
- NOTE 4 Current number of persons on-board, including crew members: 0 to 8191.
- 0 = default (not available), 8191 = 8191 or more people.
- NOTE 5 The characters that can be used are listed in IEC 61162-1, table 2. Some characters in this table are the reserved characters listed in IEC 61162-1, table 1. Reserved characters may be used, but they must be represented using the "^-method" (See IEC 61162-1, § 5.1.3.).
- NOTE 6 See ITU-R M.1371:2000, table 17, parameter "Type of ship and cargo type" for the range of valid values available for this field.

SSD – Ship Static Data

This sentence is used to enter static parameters into a shipboard AIS. The parameters in this sentence support a number of the ITU-R M.1371 messages.

\$--SSD,c--c,c--c,xxx,xxx,xx,xx,c,aa*hh<CR><LF>



NOTE 1 Ship call sign. A null field indicates that the previously entered call sign is unchanged. The string of characters "@@@@@@@" are used to indicate that the call sign is not available.

NOTE 2 The characters that can be used in the name are listed in the ITU-R M.1371, table 14 (6-bit ASCII). Some of the acceptable characters in this 6-bit ASCII table are reserved characters under IEC 61162-1. They must be represented using the "^-method" (See IEC 61162-1, section 5.1.3.). A null field indicates that the previously entered name is unchanged. The string of characters "@@@@@@@@@@@@@@@@@@" are used to indicate that the ship's name is not available.

NOTE 3 These are the four dimensions from the bow, stern, port beam, and starboard beam to the horizontal reference point on the ship for which the current "position reports" are valid. The sum of A + B is the length of the ship in metres, and the sum of C + D is the width of the ship in metres (See ITU-R M.1371, message 5, "Reference Point for reported position and Dimensions of Ship."). If the reference point of "reported position" is not available, but the dimensions of the ship are available: A = C = 0 and B > 0 and D > 0. If neither the reference point for the reported position nor the dimensions of the ship are available: A = B = C = D = 0 (default). Use of a null field for A, B, C, and/or D indicates that the previously entered dimension for that parameter is unchanged. In many cases, the ship's reference point for "reported position" will be the location of the positioning antenna.

NOTE 4 The DTE indicator is an abbreviation for Data Terminal Equipment indicator. The purpose of the DTE indicator is to inform distant

receiving applications that, if set to "available" the transmitting station conforms, at least, to the minimum keyboard and display requirements. The DTE indicator is only used as information provided to the application layer – indicating that the transmitting station is available for communications. On the transmitting side, the DTE indicator may be set by an external application using this sentence. DTE indicator flag values are:

0 = Keyboard and display are a standard configuration, and communication is supported.


1 = Keyboard and display are either unknown or unable to support communication (default setting).

NOTE 5

The source identifier contains the "Talker ID" of the equipment at this location. The AIS may use the "Talker ID" to identify multiple sources of position data and to detect a change to the reference point on the ship.

VDM – VHF Data-link Message

This sentence is used to transfer the entire contents of a received AIS message packet, as defined in ITU-R M.1371 and as received on the VHF Data Link (VDL), using the "6-bit" field type. The structure provides for the transfer of long binary messages by using multiple sentences.



NOTE 1

The length of an ITU-R M.1371 message may be long and may require the use of multiple sentences. The first field specifies the total number of sentences used for a message, minimum value 1. The second field identifies the order of this sentence in the message, minimum value 1. These cannot be null fields.

NOTE 2

The Sequential message identifier provides a message identification number from 0 to 9 that is sequentially assigned and is incremented for each new multi-sentence message. The count resets to 0 after 9 is used. For a message requiring multiple sentences, each sentence of the message contains the same sequential message identification number. It is used to identify the sentences containing portions of the same

message. This allows for the possibility that other sentences might be interleaved with the message sentences that, taken collectively, contain a single message. This field shall be a null field when messages fit into one sentence.

NOTE 3 The AIS message reception channel is indicated as either "A" or "B." This channel indication is relative to the operating conditions of the AIS when the packet is received. This field shall be null when the channel identification is not provided. The VHF channel numbers for channels "A" and "B" are obtained by using an ACA-sentence "query" of the AIS.


NOTE 4 The maximum string length of encapsulation is limited such that the total number of sentence characters does not exceed 82. This field supports a maximum of 62 valid characters for a message transferred using multiple sentences, and 63 valid characters for a message using a single sentence.

NOTE 5 To encapsulate, the number of binary bits must be a multiple of six. If it is not, one to five "fill bits" are added. This parameter indicates the number of bits that were added to the last 6-bit coded character. This value shall be set to zero when no "fill bits" have been added. This cannot be a null field.

VDO – VHF Data-link Own-vessel message

This sentence is used to provide the information assembled for broadcast by the AIS. It uses the six-bit field type for encapsulation. The sentence uses the same structure as the VDM sentence formatter.

!-VDO,x,x,x,a,s--s,x*hh<CR><LF>



NOTE 1 The length of an ITU-R M.1371 message may be long and may require the use of multiple sentences. The first field specifies the total number of sentences used for a message, minimum value 1. The second field identifies the order of this sentence in the message, minimum value 1. These cannot be null fields.

NOTE 2 The Sequential message identifier provides a message identification number from 0 to 9 that is sequentially assigned and is incremented for each new multi-sentence message. The count resets to 0 after 9 is

used. For a message requiring multiple sentences, each sentence of the message contains the same sequential message identification number. It is used to identify the sentences containing portions of the same message. This allows for the possibility that other sentences might be interleaved with the message sentences that, taken collectively, contain a single message. This field shall be a null field when a message fits into one sentence.

NOTE 3 This is the channel used to broadcast the AIS message. The AIS channel field, set to either "A" or "B", indicates that the message was broadcast. If the message is not broadcast, the "AIS Channel" field shall be null. The VHF channel numbers for channels "A" and "B" are obtained by using an ACA-sentence "query" of the AIS.


NOTE 4 The maximum string length of encapsulation is limited such that the total number of sentence characters does not exceed 82. This field supports a maximum of 62 valid characters for a message transferred using multiple sentences, and 63 valid characters for a message using a single sentence.

NOTE 5 To encapsulate, the number of binary bits must be a multiple of six. If it is not, one to five "fill bits" are added. This parameter indicates the number of bits that were added to the last 6-bit coded character. This value shall be set to zero when no "fill bits" have been added. This cannot be a null field.

VSD – Voyage Static Data

This sentence is used to enter information about a ship's voyage. This information remains relatively static during the voyage. However, the information will frequently change from voyage to voyage. The parameters in this sentence support a number of the ITU-R M.1371 messages.

`$--VSD,x.x,x.x,x.x,c--c,hhmmss.ss,xx,xx,x.x,x.x*hh<CR><LF>`



- NOTE 1 Type of ship and cargo category are defined in ITU-R M.1371. The description of ship and cargo are indicated by a number. The values are defined in ITU-R M.1371, message 5. A null field indicates that this is unchanged.
- NOTE 2 Draught is reported in the range of 0 to 25,5 metres. The value 0 = not available (default), and the value 25,5 indicates that the draught is 25,5 metres or more. Only values from 0 to 25,5 shall be accepted by the AIS. A null field indicates that this is unchanged.
- NOTE 3 Number of persons on-board includes the crew. The value 0 = not available (default). The value 8191 = 8191 or more people. Only values from 0 to 8191 shall be accepted by the AIS. A null field indicates that this is unchanged.
- NOTE 4 The characters that can be used in the destination are listed in the ITU-R M.1371, table 14 (6-bit ASCII). Some of the acceptable characters in this 6-bit ASCII table are reserved characters under IEC 61162-1. They must be represented using the "^-method" (See IEC 61162-1, section 5.1.3.). A null field indicates that the previously entered destination is unchanged. The string of characters "@@@@@@@@@@@@@@@@@@@@@@" are used to indicate that the ship's destination is not available.
- NOTE 5 The UTC time of arrival field follows the "TIME" field type described in table 6 (IEC 61162-1). The two fixed digits of seconds are not broadcast by the AIS and should be set to "00". The optional decimal point and associated decimal fraction shall not be provided. The resulting time is a number with six fixed digits, "hhmm00". Leading zeros are always included for the hours and minutes. If the hour of arrival is not available, "hh" shall be set to 24. If the minute of arrival is not available, "mm" shall be set to 60. A null field indicates that this is unchanged.
- NOTE 6 The day and month of arrival are in UTC. The day is a two-digit fixed number requiring leading zeros. The month is a two-digit fixed number requiring leading zeros. If the day of arrival is not available, "00" shall be the number for day. If the month of arrival is not available, "00" shall be the number for the month. A null field indicates that this is unchanged.
- NOTE 7 The Navigational status is indicated using the following values, a null field indicates the status is unchanged (ref. ITU-R M.1371, Message 1, Navigational status parameter):
- 0 = under way using engine
 - 1 = at anchor
 - 2 = not under command
 - 3 = restricted manoeuvrability

- 4 = constrained by draught
- 5 = moored
- 6 = aground
- 7 = engaged in fishing
- 8 = under way sailing
- 9 = reserved for High Speed Craft
- 10 = reserved for Wing In Ground
- 11 to 14 = reserved for future use
- 15 = not defined (default)

NOTE 8

Definition of values 1 to 15 provided by a competent regional authority. Value shall be set to zero (0), if not used for any regional application. Regional applications shall not use zero. A null field indicates that this is unchanged (ref. ITU-R M.1371, Message 1, Reserved for regional applications parameter).


ACK – Acknowledge alarm

Local alarm condition and status. This sentence is used to report an alarm condition on a device and its current state of acknowledgement.

Alarm's description text
Alarm's acknowledge state, A = acknowledged
V = unacknowledged
Alarm condition (A = threshold exceeded, V = not exceeded)
Local alarm number (identifier) [identification number of alarm source]
Time of alarm condition change, UTC

Local geodetic datum and datum offsets from a reference datum. This sentence is used to define the datum to which a position location, and geographic locations in subsequent sentences, are referenced. Latitude, longitude and altitude offsets from the reference datum, and the selection of the reference datum, are also provided.

The datum sentence should be transmitted immediately prior to every positional sentence (e.g. GLL, BWC, WPL) which is referenced to a datum other than WGS84, the datum recommended by IMO.



NOTE 1 Three character alpha code for local datum. If not one of the listed earth-centred datums, or 999 for user defined datums, use IHO datum code from International Hydrographic Organisation Publication S-60, Appendices B and C. Null field if unknown.

NOTE 2 One character subdivision datum code when available or user defined reference character for user defined datums, null field otherwise. Subdivision character from IHO Publication S-60, Appendices B and C.

NOTE 3 Latitude and longitude offsets are positive numbers, the altitude offset may be negative. Offsets change with position: position in the local datum is offset from the position in the reference datum in the directions indicated:


$$P_{local\ datum} = Pref\ datum + offset$$

NOTE 4 Users should be aware that chart transformations based on IHO S60 parameters may result in significant positional errors when applied to chart data.

Only the local datum is required and used by the AIS.

GBS – GNSS satellite fault detection

This message is used for setting the RAIM flag in the position reports sent by the AIS.




- NOTE 1 Expected error in metres due to bias, with noise = 0.
- NOTE 2 Satellite ID numbers. To avoid possible confusion caused by repetition of satellite ID numbers when using multiple satellite systems, the following convention has been adopted:
- GPS satellites are identified by their PRN numbers, which range from 1 to 32.
- The WAAS system has reserved numbers 33 – 64 to identify its satellites.
- The numbers 65 – 96 are reserved for GLONASS satellites. GLONASS satellites are identified by 64+ satellite slot numbers. The slot numbers are 1 through 24 for the full GLONASS constellation of 24 satellites, thus giving a range of 65 through 88. The numbers 89 through 96 are available if slot numbers above 24 are allocated to on-orbit spares.
- Only Expected error in latitude and Expected error in longitude is required and used by the AIS.

GGA – Global positioning system (GPS) fix data

Time, position and fix-related data for a GPS receiver.

\$--GGA, hhmmss.ss, llll.ll, a, yyyy.yy, a, x, xx, x.x, x.x, M, x.x, M, x.x, xxxx*hh<CR><LF>



- NOTE 1 GPS quality indicator:
- 0 = fix not available or invalid
 - 1 = GPS SPS mode, fix valid
 - 2 = differential GPS, SPS mode, fix valid
 - 3 = GPS PPS mode, fix valid
 - 4 = Real Time Kinematic. Satellite system used in RTK mode with fixed integers
 - 5 = Float RTK. Satellite system used in RTK mode with floating integers
 - 6 = Estimated (dead reckoning) mode

7 = Manual input mode

8 = Simulator mode

The GPS Quality Indicator shall not be a null field.

NOTE 2 Time in seconds since last SC104 type 1 or 9 update, null field when DGPS is not used.


NOTE 3 Geoidal separation: the difference between the WGS-84 earth ellipsoid surface and mean sea level (geoid) surface, " - " = mean sea level surface below the WGS-84 ellipsoid surface.

Utc of position, Latitude, Longitude and GPS quality is the only fields that are used by the AIS.

GLL – Geographic position – latitude/longitude

Latitude and longitude of vessel position, time of position fix and status.

\$--GLL, IIII.II, a, yyy.yy, a, hhmmss.ss, A, a *hh<CR><LF>



NOTE 1 Positioning system Mode indicator:

A = Autonomous

D = Differential

E = Estimated (dead reckoning)

M = Manual input

S = Simulator

N = Data not valid

NOTE 2 The Mode Indicator field supplements the Status field (field 6). The Status field shall be set to V = invalid for all values of Operating Mode except for A = Autonomous and D = Differential. The positioning system Mode indicator and Status fields shall not be null fields.


All fields are used by the AIS.

GNS – GNSS fix data

Fix data for single or combined satellite navigation systems (GNSS). This sentence provides fix data for GPS, GLONASS, possible future satellite systems and systems combining these. This sentence could be used with the talker identification of GP for GPS, GL for GLONASS, GN for GNSS combined systems, as well as future identifiers. Some fields may be null fields for certain applications, as described below.

If a GNSS receiver is capable simultaneously of producing a position using combined satellite systems, as well as a position using only one of the satellite systems, then separate \$GPGNS, \$GLGNS, etc. messages may be used to report the data calculated from the individual systems.

If a GNSS receiver is set up to use more than one satellite system, but for some reason one or more of the systems are not available, then it may continue to report the positions using \$GNGNS, and use the mode indicator to show which satellite systems are being used.



NOTE 1

Mode Indicator. A variable length valid character field type with the first two characters currently defined. The first character indicates the use of GPS satellites, the second character indicates the use of GLONASS satellites. If another satellite system is added to the standard, the mode indicator will be extended to three characters; new satellite systems shall always be added to the right, so the order of characters in the Mode Indicator is: GPS, GLONASS, other satellite systems.

The characters shall take one of the following values:

N = No fix. Satellite system not used in position fix, or fix not valid.

A = Autonomous. Satellite system used in non-differential mode in position fix.

D = Differential. Satellite system used in differential mode in position fix.

P = Precise. Satellite system used in precision mode. Precision mode is defined as: no deliberate degradation (such as Selective Availability), and higher resolution code (P-code) is used to compute position fix.

R = Real Time Kinematic. Satellite system used in RTK mode with fixed integers.

F = Float RTK. Satellite system used in real time kinematic mode with floating integers.

E = Estimated (dead reckoning) Mode.

M = Manual Input Mode.

S = Simulator Mode.

The Mode indicator shall not be a null field.

NOTE 2

Age of differential data and Differential reference station ID

When the talker is GN and more than one of the satellite systems are used in differential mode, then the "Age of differential data" and "Differential reference station ID" fields shall be null. In this case, the "Age of differential data" and "Differential reference station ID" fields shall be provided in following GNS messages with talker IDs of GP, GL, etc. These following GNS messages shall have the latitude, N/S, longitude, E/W, altitude, geoidal separation, mode and HDOP fields null. This indicates to the listener that the field is supporting a previous \$GNGNS message with the same time tag. The "Number of satellites" field may be used in these following messages to denote the number of satellites used from that satellite system.

Example: A combined GPS/GLONASS receiver using only GPS differential corrections has the following GNS sentence sent:

```
$GNGNS,122310.2,3722.425671,N,12258.856215,W,DA,14,0.9,1005.543,6.5,5.2,23*59<CR><LF>
```

Example: A combined GPS/GLONASS receiver using both GPS differential corrections and GLONASS differential corrections may have the following three GNS sentences sent in a group:

```
$GNGNS,122310.2,3722.425671,N,12258.856215,W,DD,14,0.9,1005.543,6.5,,*74<CR><LF>
```

```
$GPGNS,122310.2,,,,,7,,,5.2,23*4D<CR><LF>
```

```
$GLGNS,122310.2,,,,,7,,,3.0,23*55<CR><LF>
```

The Differential Reference station ID may be the same or different for the different satellite systems

b) Age of Differential Data

For GPS differential data: This value is the average of the most recent differential corrections in use. When only RTCM SC104 Type 1 corrections are used, the age is that of the most recent Type 1 correction. When RTCM SC104 Type 9 corrections are used solely, or in combination with Type 1 corrections, the age is the average of the most recent corrections for the satellites used. Null field when Differential GPS is not used.

For GLONASS differential data: This value is the average age of the most recent differential corrections in use. When only RTCM SC104 Type 31 corrections are used, the age is that of the most recent Type 31 correction. When RTCM SC104 Type 34 corrections are used solely, or in combination with Type 31 corrections, the age is the average of the most recent corrections for the satellites used. Null field when differential GLONASS is not used.

NOTE 3 HDOP calculated using all the satellites (GPS, GLONASS and any future satellites) used in computing the solution reported in each GNS sentence.

NOTE 4 Geoidal separation is the difference between the earth ellipsoid surface and mean-sea-level (geoid) surface defined by the reference datum used in the position solution, "-" = mean-sea-level surface below ellipsoid surface. The reference datum may be specified in the DTM sentence.

UTC of position, Latitude, Longitude and Mode indicator, are the only fields used by the AIS.

HDT – Heading true

IMO Resolutions A.424 and A.821. Actual vessel heading in degrees true produced by any device or system producing true heading.


\$--HDT, x.x, T*hh<CR><LF>

└──┴─── Heading, degrees true

All fields are used by the AIS.

OSD Own ship data

IMO Resolution A.477 and MSC 64(67), Annex 1 and Annex 3. Heading, course, speed, set and drift summary. Useful for, but not limited to radar/ARPA applications. OSD gives the movement vector of the ship based on the sensors and parameters in use.



NOTE

Reference systems on which the calculation of vessel course and speed is based. The values of course and speed are derived directly from the referenced system and do not additionally include the effects of data in the set and drift fields.

B = bottom tracking log

M = manually entered

W = water referenced

R = radar tracking (of fixed target)


P = positioning system ground reference.

Heading, Heading status, Vessel course, Vessel speed and Speed units, are used by the AIS.

RMC - Recommended minimum specific GNSS data

Time, date, position, course and speed data provided by a GNSS navigation receiver. This sentence is transmitted at intervals not exceeding 2 s and is always accompanied by RMB when a destination waypoint is active. RMC and RMB are the recommended minimum data to be provided by a GNSS receiver. All data fields must be provided null fields used only when data is temporarily unavailable.

\$--RMC, hhmmss.ss, A, llll.ll, a, yyyy.yy, a, x.x, x.x, xxxxxx, x.x, a, a*hh<CR><LF>



NOTE 1 Easterly variation (E) subtracts from true course. Westerly variation (W) adds to true course.

NOTE 2 Positioning system Mode indicator:

A = Autonomous mode

D = Differential mode

E = Estimated (dead reckoning) mode

M = Manual input mode

S = Simulator mode

N = Data not valid


NOTE 3 The positioning system Mode indicator field supplements the positioning system Status field (field No. 2) which shall be set to V = invalid for all values of Mode indicator except for A = Autonomous and D = Differential. The positioning system Mode indicator and Status fields shall not be null fields.

All fields, except Magnetic variation is used by the AIS.

ROT – Rate of turn

IMO Resolution A.526. Rate of turn and direction of turn.

\$--ROT, x.x, A*hh<CR><LF>




All fields are used by the AIS.

TXT – Text transmission

For the transmission of short text messages. Longer text messages may be transmitted by using multiple sentences.

\$--TXT,xx,xx,xx,c--c*hh<CR><LF>



NOTE 1 Text messages may consist of the transmission of multiple messages all containing identical field formats. The first field specifies the total number of messages, minimum value = 1. The second field identifies the order of this message (message number), minimum value = 1. For efficiency, it is recommended that null fields be used in the additional sentences, otherwise data is unchanged from the first sentence.

NOTE 2 The text identifier is a number, 01 to 99, used to identify different text messages.


NOTE 3 ASCII characters, and code delimiters if needed, up to the maximum permitted sentence length (i.e. up to 61 characters including any code delimiters).

All fields are used by the AIS.

VBW – Dual ground/water speed

Water-referenced and ground-referenced speed data.

\$--VBW, x.x, x.x, A, x.x, x.x, A, x.x, A, x.x, A*hh<CR><LF>



NOTE 1 Transverse speed: "-" = port, Longitudinal speed: "-" = astern.


NOTE 2 The status field shall not be a null field.

All fields are used by the AIS except Stern speed.

VTG – Course over ground and ground speed

The actual course and speed relative to the ground.

\$--VTG, x.x, T, x.x, M, x.x, N, x.x, K,a*hh<CR><LF>



NOTE

Positioning system Mode indicator:

A = Autonomous mode

D = Differential mode

E = Estimated (dead reckoning) mode

M = Manual input mode

S = Simulator mode

N = Data not valid


The positioning system Mode indicator field shall not be a null field.

Course over ground, degrees magnetic and Speed over ground km/h are not used by the 'AIS'

ZDA – Time and date

UTC, day, month, year and local time zone.

\$--ZDA, hhmmss.ss, xx, xx, xxxx, xx, xx*hh<CR><LF>



NOTE 1

Local time zone is the magnitude of hours plus the magnitude of minutes added, with the sign of local zone hours, to local time to obtain UTC. Local zone is generally negative for East longitudes with local exceptions near the International Date Line.

Example: At Chatham Is. (New Zealand) at 1230 (noon) local time on June 10, 1995:

\$GPZDA,234500,09,06,1995,-12,45*6C<CR><LF>

In the Cook Islands at 1500 local time on June 10, 1995:

\$GPZDA,013000,11,06,1995,10,30*4A<CR><LF>

All fields except Local zone, are used by the AIS.

10 APPENDIX C - SOFTWARE SETUP USING OPTIONAL MKD

10.1 Security settings optional MKD

To avoid unauthorised input of data in the menus accessed from the **Main** menu, the AI80 system should be set up with security codes and different access levels.

3 different access levels may be defined:

Level 0: No security code required

Level 1: Access controlled by L1 PIN Code or L2 PIN Code

Level 2: Access controlled by L2 PIN Code

Access levels for the different menus are defined in the **Security** submenu, activated from the **Menu** page.

Setting the security codes

When using the external, optional MKD the default security code delivered with the Mobile Unit is “AIS” as for both Level 1 and Level 2. These security codes should be changed when the system is configured for the first time. Use the following procedure to change the security codes:

```

=== Main Menu ===== P1
-----
c.Security
-----

```

1. Press the **MENU** button to activate the **Main** menu, and select **Security**. The **Security** menu will be displayed.

```

=== Security ===== P1c
Authorisation
-----
L1 PIN Code      :*****
L2 PIN Code      :*****
Nav.Status       :1
Voyage Data      :2
Static Data      :0
Chn.Mgmt         :0
VHF Link         :1
Serial Ports     :1
Netw.Settings    :2
Answer Mode      :0

```

2. Press **ENTER** when the **L1 PIN Code** line is highlighted. The keyboard function will be displayed in the lower part of the **Security** menu.

```

=== Security ===== Plc
  Authorisation
-----
L1 PIN Code      :*****
L2 PIN Code      :*****
Nav. Status      :0
Voyage Data      :0
Static Data      :1
=====
Enter authorisation code
PIN:
=====
      ABCDEFGHIJKLMNO
      PQRSTUVWXYZ1234
  
```

3. Enter **AIS** (default security code), and confirm the entry by moving the highlight to the **↵** symbol and pressing the **ENTER** button.
4. Now enter the new security code for Level 1, and confirmed the entry by moving the highlight to the **↵** symbol and pressing the **ENTER** button.

5. Highlight the **L2 PIN Code** and repeat the procedure above to change the security code for Level 2.
6. Record the new codes and keep them in a safe location. If the new codes are lost, a master code can be obtained from Customer Support by supplying the MAC address, see pages 91 and 92.

Changing the security levels

To avoid unauthorised input of data in the menus accessed from the **Main** menu, the AI80 system should be set up with security codes and different access levels.


Note !

All entries on the Security page are protected by L2 security code. This code has to be entered before any parameters can be changed. Refer item 3 below.


1. Activate the **Security** menu from the **Main** menu.


```

=== Security ===== Plc
  Authorisation
-----
L1 PIN Code      :*****
L2 PIN Code      :*****
Nav.Status       : 0
Voyage Data      : 0
Static Data      : 1
Chn.Mgmt         : 2
VHF Link         : 1
Serial Ports     : 1
Netw.Settings    : 2
Answer Mode      : 1
  
```

2. Highlight the parameter group for which the security level is to be changed, and press the **ENTER** button. The lower part of the display will now show the keyboard function.
3. Enter the security code for Level 2, move the highlight to the  symbol and press the **ENTER** button. In the lower part of the display it will now be possible to change security level for the selected parameter.

```

=====
0 1 2 
  
```

4. Select security level, and confirm by highlighting the  symbol and pressing the **ENTER** button.
5. Continue entering security levels for the remaining parameter groups.


Note ! *To ease the operation of the system, all parameters that have to be changed during normal operation should be set to Level 0.*

Note ! *Once authenticated with L1 or L2 PIN code, the authentication is valid until the View page has been displayed for 5 seconds. To protect the AI80 security systems, the MKD returns to the View page when not used for 15 minutes. In high security applications we recommend manually returning to the View page when a change that required authentication is completed.*


10.2 Entering static data optional MKD

All vessel data that do not change from one voyage to another should be entered during installation.

If MMSI number is changed, the unit should be restarted, see the *Simrad AI80 User Manual* for details.



1. Press the **MENU** button to activate the **Main** menu, and select **Static Data**. The **Static Data** menu will be displayed.



The following information should be entered:

Name: Vessel name

Call: Vessel's call signal

MMSI: The vessel's Maritime Mobile Signal Identifier number



IMO: Vessel's IMO number

Type: Type of vessel. Refer Appendix A - vessel identifiers, page 47.

Keel: Vessel height over keel in metres. Total height from keel to mast.



Use the arrow-down button to move to next page where horizontal location for the GPS antenna included in the AI80 system should be entered. Refer page 22.





Page 3 in the **Static Data** menu, entered by pressing the Arrow-down button, is used for entering horizontal location for the vessel's main GPS antenna.

```

=== Static Data ===== P14
GNSS                      3/3
-----
Length A : 20
Length B : 20
Length C : 9
Length D : 5
    
```

10.3 Configuration external serial ports optional MKD

The baud rate for each serial port used for interfacing external equipment has to be configured from the **Serial ports** submenu.

```

=== Main Menu ===== P1
    
```

```

9.Network & Ports
    
```

1. Press the **MENU** button to activate the **Main** menu, and select **Ports**.

```

=== Ports ===== P19
    
```

```

1.Serial Ports
2.MAC adr.
    
```

2. Select **Serial Ports** in the **Ports** menu. The **Serial Ports** page will be displayed.

```

=== Serial Ports === P191
External Ports
-----
PILOT      : 38400
PI         : 38400
LongRange  : 4800
RTCM       : 4800
SENSOR-1   : 4800
SENSOR-2   : 4800
SENSOR-3   : 4800
    
```

3. Highlight the port that is to be configured, and press the **ENTER** button. The lower part of the display will now show baud rates available for the selected port.

Refer chapter 3.

10.4 Port settings and MAC address optional MKD

The **Ports** menu is used by the operator to change serial parameters and view the MAC address.

```

=== Main Menu ===== P1
9.Ports
    
```

1. Press the **MENU** button to activate the **Main** menu, and select **Ports**.

```

=== Ports ===== P19
1.Serial Ports
2.MAC adr.
    
```

2. Select **MAC adr.** in the **Ports** menu. The **MAC adr.** page will be displayed.

```

=== MAC adr. ===== P192
External Ports
-----
MAC MS   :000.005.190
MAC LS   :000.000.206
    
```

10.5 Answer mode optional MKD

The **Answer mode** page configures the polling operation for the AI80 system.

```

=== Main Menu ===== P1
-----
a. Answer Mode
-----

```

1. Press the **MENU** button to activate the **Main** menu, and select **Answer Mode**.

```

=== Answer Mode ===== P1a
Current Settings
-----
LongeRange :Automatic
VDL Response :On

```

The following parameters may be defined:

LongRange Configures the long-range polling. The following selections are available:

Automatic: The AI80 system will automatically reply to a long-range request. The request will however be listed in the **Long Range** view.

Manual: The operator will have to manually reply to a request.

The long-range function is optional and requires additional external equipment. Refer the *Simrad AI80 User Manual* for details.


VDL Response Configures the normal VHF polling. Could be set to **ON** (default) or **OFF**.

Note !

The VDL setting "ON" indicates that answer mode to interrogator is enabled when message 6 or 8 containing interrogation functional identification, is received.


10.6 Configuring radio channels optional MKD

AIS systems normally operate on two AIS channels: channel 2087 and channel 2088. Where these channels are not available regionally, other channels may be configured by using the **Chn.Management** submenu. Maximum 8 regions may be configured.



Press the **MENU** button to activate the **Main** menu, and select **Chn.Management**.

The **Chn.Management** submenu has three options for channel management, described in the next pages.



Adding a region

```

=== Add Region ===== P163
REGION-1
-----
ChnA      : 143
ChnB      : 144
RxTxMode  : TxA/TxB/RxA/RxB
TxPower   : High
LAT NE    : 000°00'00.00N
LON NE    : 000°00'00.00E
LAT SW    : 000°00'00.00N
LON SW    : 000°00'00.00E
BW A      : Default
BW B      : Default
Zone      : 2

```

The **Add regions** option is used for defining new regions.

When regions are defined, the AI80 system will automatically jump to the defined VHF channels when the vessel enters this region.

The following parameters have to be defined:

ChnA/ChnB: VHF channels used for transmitting.

RxTxMode: Channels (A/B) used for transmitting/receiving


TxPower: Transmission power. Selectable options: **High** (12.5 W) and **Low** (2 W).

LAT NE: North-East latitude coordinates for the defined area.

LON NE: North-East longitudinal coordinates for the defined area.

LAT SW: South-West latitude coordinates for the defined area.

LON SW: South-West longitudinal coordinates for the defined area.



BW A/BW B: Bandwidth for the VHF channels used in this area. Selectable options: **Default** (maximum bandwidth allowed in this area) and **Narrow** (12,5 kHz).

Zone: The size of the transition area in nautical miles outside the region.

Editing current region

```

=== Edit Cur.Reg == P161
REGION-1
-----
ChnA      :143
ChnB      :144
RxTxMode:TxA/TxB/RxA/RxB
TxPower   :High
LAT NE    :012°13'23.56N
LON NE    :132°36'14.02E
LAT SW    :034°56'21.06N
LON SW    :125°56'12.21E
BW A      :Default
BW B      :Default
Zone      :2

```

The **Edit Cur.Reg.** option enables the operator to change parameters for the current AIS channels.

Viewing a region's settings

```

=== View Cur.Reg === P162
REGION-1                      2 / 6
-----
ChnA      :143
ChnB      :144
RxTxMode:TxA/TxB/RxA/RxB
TxPower   :High
LAT NE    :012°13'23.56N
LON NE    :132°36'14.02E
LAT SW    :034°56'21.06N
LON SW    :125°56'12.21E
BW A      :Default
BW B      :Default
Zone      :2

```

The **View Regions** option displays all defined regions. This is a read only page and no configuration changes can be made.

The view regions may consist of up to 8 pages, indicated in the upper left corner as e.g. 2/6. The ▲ and ▼-buttons are used for displaying available regions.

11 APPENDIX D - TROUBLESHOOTING FORM

When problems, verify that external cables and connectors are OK.

Disconnect 24 volt power, wait 10 seconds and reconnect.

If AIS is still experiencing problems, proceed by filling out the Troubleshooting form on the next page and sending it to Customer Support.

Fill in shaded fields when relevant, either by X or plain text.

	Vessel name
	Customer name
	MMSI number
	IMO number
	Type/model of AIS (see label at the back of main AIS unit, not the keyboard/display unit)
	Serial no. of AIS (see label at the back of main AIS unit, not the keyboard/display unit)
	Software version in AIS unit (see Simrad AI80 User's Manual for SW version)

Enter X in front of the observation which matches the AIS behaviour.

Light/LED status

4 LEDs on front of AIS main unit (not the keyboard/display unit): TX, MSG, GPS, ALM

	01 Normal operation	TX and MSG will blink (green/orange) occasionally, GPS will blink steady (green) at 1-second intervals, ALM will stay off.
	02 Fault	Like Normal operation except ALM light is red.
		If alarm, write alarm message(s) here, press ALM button to acknowledge alarm.
	03 Fault	Like Normal operation except GPS blinks orange.
	04 Fault	All LEDs constantly orange.
	05 Fault	All LEDs constantly off, except backlight in MKD is on.
	06 Fault	All LEDs constantly off, also backlight in MKD - check 24 volt power supply into AIS: wires, fuses, connections.
	07 Fault	Other LED observations, write explanation below.

MKD (keyboard/display) status

	08 Normal operation	Range, bearing and vessel name in upper part. Buttons work OK.
	09 Fault	Only Kongsberg logo in display, buttons and scroll wheel not working (optional MKD only).
	10 Fault	Other MKD observations, write explanation below.

Other comments

If other observations or problems enter description below:

--

12 APPENDIX E - OPTIONAL VHF ANTENNA

COMROD AV7 Marine VHF Antenna

Application:

AV7 is a high quality dipole antenna designed for the marine VHF radio telephone service. It is a high quality antenna with a durable construction and a beautiful finish for installation on all kinds of vessels.

Electrical specifications:

Frequency range	156-162 MHz, VSWR < 1.5:1 145-165 MHz, VSWR < 2:1
Nominal impedance	50 ohm
Power rating	100 W
Gain	2 dbi
Pattern	Horizontal plane: Omnidirectional Vertical plane: See reverse page
Polarization	Vertical
Connector	UHF female is standard
DC-grounded	Yes


Mechanical specifications:

Design	Centerfed coaxial dipole. Radiating elements completely enclosed in polyurethane foam within a fiberglass tube. Mounting bracket in aluminium.
Height	1.25 m (4 ft)
Weight	1 kg, including U-bolts
Wind rating	55 m/s = 125 mph
Finish	Polyurethane lacquer, white
Temperature range	-55 °C, +71 °C; -67 °F, +160 °F

Mounting:

AV7 is easily mounted to the bulkhead by means of 4 holes in the aluminium bracket, or to a mast or tube with U-bolts. The tube may be horizontal or vertical. The U-bolts in stainless steel, are included.

Suitable cable: RG8, RG213 or similar.



**THIS PAGE INTENTIONALLY LEFT
BLANK**