



Mailbox Client Intel® FPGA IP User Guide

Updated for Intel® Quartus® Prime Design Suite: **22.4**

IP Version: **20.2.1**



Online Version



Send Feedback

ID: **683290**

Version: **2022.12.19**

Contents

1. Mailbox Client Intel FPGA IP User Guide.....	3
1.1. Device Family Support.....	4
1.2. Parameters.....	5
1.3. Mailbox Client Intel FPGA Core Interface Signals.....	6
1.3.1. Clock and Reset Interfaces.....	6
1.3.2. Avalon Memory-Mapped Interface.....	7
1.3.3. AXI Manager Interface.....	7
1.4. Mailbox Client Intel FPGA IP Avalon MM Memory Map	9
1.4.1. Interrupt Enable Register.....	10
1.4.2. Interrupt Status Register	11
1.4.3. Timer Registers.....	13
1.5. Commands and Responses.....	14
1.5.1. Operation Commands.....	15
1.5.2. Error Code Responses.....	24
1.5.3. Error Code Recovery.....	25
1.6. Specifying the Command and Response FIFO Depths.....	26
1.7. Enabling Cryptographic Services.....	27
1.8. Using the Mailbox Client Intel FPGA IP.....	28
1.9. Mailbox Client Intel FPGA IP Core Use Case Examples.....	32
1.10. Nios II and Nios V Processors HAL Driver.....	34
1.10.1. Mailbox Client HAL API.....	34
1.10.2. LibRSU HAL API.....	38
1.11. Mailbox Client Intel FPGA IP User Guide Archives.....	52
1.12. Document Revision History for the Mailbox Client Intel FPGA IP User Guide.....	53
2. Appendix: CONFIG_STATUS and RSU_STATUS Error Code Descriptions.....	59

1. Mailbox Client Intel FPGA IP User Guide


The Mailbox Client Intel FPGA IP is a bridge between a host and the secure device manager (SDM). Available for Intel® Stratix® 10 and Intel Agilex™ devices, you use the Mailbox Client Intel FPGA IP to send commands and receive status from SDM peripheral clients. The Mailbox Client defines functions that the SDM runs.

The following pre-defined functions are available:

- Reading the Chip ID
- Reading temperature sensors
- Reading voltage sensors
- Reading and writing external quad serial peripheral interface (SPI) flash memory
- Performing remote system updates (RSU)
- Enabling cryptographic services⁽¹⁾

The following block diagram shows how to use the Mailbox Client Intel FPGA IP in an interactive session. The diagram also emphasizes different ways of communicating with IP through the Host Controller.

Figure 1. Mailbox Client Intel FPGA IP System Block Diagram



This block diagram includes the following components:

⁽¹⁾ This feature is available for Intel Agilex devices in Intel Quartus® Prime software version 21.3 or later.

- Host Controller: provides possible ways of accessing the Mailbox Client Intel FPGA IP. Use any of the specified ways to communicate with the host controller:
 - System Console with the JTAG to Avalon® Master Bridge Intel FPGA IP. The System Console provides a Tcl Console pane that you can use to run the IP functions. The JTAG to Avalon Master Bridge Intel FPGA IP translates the commands it receives from the System Console to Avalon Memory-Mapped (Avalon MM) format that the Mailbox Client Intel FPGA IP requires.
 - Nios® II processor: sends commands to the Mailbox Client Intel FPGA IP.
 - Custom logic: It sends commands to the Mailbox Client Intel FPGA IP.
 - PCIe* Hard IP
 - Ethernet IP
- Mailbox Client Intel FPGA IP: drives commands and receives responses from the SDM. This component includes FIFOs with a maximum depth of 1024 entries to store commands and responses. The Mailbox Client Intel FPGA IP interrupt indicates when the input FIFO is full and when the output FIFO contains valid data. You can size these FIFOs to accommodate the commands the you intend to send.

Intel provides a reference design that uses the System Console and the JTAG master to drive the Mailbox Client Intel FPGA IP. In the Intel Design Store, search for *Intel Agilex Mailbox Client Intel FPGA IP Core Design Example (QSPI flash Access and Remote System Update)* to view the design.

Related Information

- [Avalon Interface Specifications](#)
- [Secure Device Manager in Intel Stratix 10 Devices](#)
- [Analyzing and Debugging Designs with System Console](#)
- [Mailbox Client Intel FPGA IP Core Design Example \(QSPI flash Access and Remote System Update\)](#)

1.1. Device Family Support

The following lists the device support level definitions for Intel FPGA IPs:

- **Advance support** — The IP is available for simulation and compilation for this device family. Timing models include initial engineering estimates of delays based on early post-layout information. The timing models are subject to change as silicon testing improves the correlation between the actual silicon and the timing models. You can use this IP for system architecture and resource utilization studies, simulation, pinout, system latency assessments, basic timing assessments (pipeline budgeting), and I/O transfer strategy (data-path width, burst depth, I/O standards tradeoffs).
- **Preliminary support** — The IP is verified with preliminary timing models for this device family. The IP meets all functional requirements, but might still be undergoing timing analysis for the device family. It can be used in production designs with caution.
- **Final support** — The IP is verified with final timing models for this device family. The IP meets all functional and timing requirements for the device family and can be used in production designs.

Table 1. Device Family Support

Device Family	Support
Intel Stratix 10	Final
Intel Agilex	Final

Note: You cannot simulate the Mailbox Client Intel FPGA IP because the IP receives the responses from SDM. To validate this IP, Intel recommends that you perform hardware evaluation.

Related Information

- [Mailbox Client Intel FPGA IP Release Notes](#)
- [Mailbox Client with Avalon Streaming Interface Intel FPGA IP Release Notes](#)

1.2. Parameters

Parameter Name	Value	Description
Mailbox Client Parameters		
Command FIFO Depth	1 - 1024	Depth of the command FIFO
Response FIFO Depth	1 - 1024	Depth of the response FIFO
Crypto Memory Timeout Value	0x00002710 - 0x7FFFFFFF	The timeout for the cryptographic service. Specify value within the minimum and maximum timeout value. <ul style="list-style-type: none"> • 0x7FFFFFFF: Maximum memory timeout value • 0x002710: Minimum memory timeout value
Memory AXI Manager Parameters		
Enable Crypto Service⁽²⁾	0, 1	Enables the cryptographic offloading feature. When set, enables the crypto AXI manager interface.

⁽²⁾ This feature is only available for Intel Agilex devices.


1.3. Mailbox Client Intel FPGA Core Interface Signals

The host communicates with the Mailbox Client Intel FPGA over its Avalon Memory-Mapped (Avalon MM) interface. For Intel Agilex devices, the AXI manager interface is available if you enabled **Enable Crypto Service** parameter. Through the AXI manager interface, the crypto service has access to the lowest 1GB of memory, with a maximum data size of 512 MB per each read and write operation.

The following figure illustrates the Mailbox Client Intel FPGA IP interfaces.

Figure 2. Mailbox Client Intel FPGA IP Interfaces

The AXI manager interface is only available in the Intel Agilex devices with enabled **Enable Crypto Service** parameter.



Note: For information about the AXI manager interface, refer to the *AXI Manager Interface* table.

Related Information

- [AXI Manager Interface](#) on page 7
- [Intel Stratix 10 Configuration User Guide](#)
For information about including the Reset Release IP in your design.
- [Intel Agilex Configuration User Guide](#)
For information about including the Reset Release IP in your design.

1.3.1. Clock and Reset Interfaces

Table 2. Clock and Reset Interfaces

Signal Role	Width	Direction	Description
clk	1	Input	Input clock to clock the IP. The maximum frequency is 250 MHz.
reset	1	Input	Reset that resets the IP. To reset the IP, assert the <code>reset</code> signal high for at least 2 <code>clk</code> cycles. To ensure the Mailbox Client Intel FPGA IP functions correctly when the device enters user mode, your design must include the Reset Release Intel FPGA IP to hold the reset until the FPGA fabric entered user mode. Intel recommends using a reset synchronizer when connecting the user

continued...

Signal Role	Width	Direction	Description
			<p>reset or output of the Reset Release IP to the reset port of the Mailbox Client IP. To implement the reset synchronizer, use the Reset Bridge Intel FPGA IP available in the Platform Designer.</p> <p><i>Note:</i> For IP instantiation and connection guidelines in the Platform Designer, refer to the <i>Required Communication and Host Components for the Remote System Update Design Example</i> figure in the <i>Intel Stratix 10 Configuration User Guide</i>.</p> <p><i>Note:</i> For IP instantiation guidelines, refer to the <i>Configuration User Guide</i>.</p>
irq	1	Output	Interrupt signal. Drives the value of the AND of the interrupt status and interrupt enable registers.

1.3.2. Avalon Memory-Mapped Interface

The Avalon MM interface is standard memory-mapped interface. For detailed definitions of these signals, refer to the *Avalon Memory-Mapped Interfaces* chapter in the *Avalon Interface Specifications*.

Table 3. Avalon Memory-Mapped Interface

Signal Role	Width	Direction	Description
avmm_address	4	Input	Avalon MM address.
avmm_write	1	Input	Avalon MM write request.
avmm_read	1	Input	Avalon MM read request.
avmm_writedata	32	Input	Avalon MM write data bus.
avmm_readdata	32	Output	Avalon MM read data bus.
avmm_readdatavalid	1	Output	Avalon MM read data valid.

Related Information

- [Avalon Interface Specifications](#)
- [Avalon Memory-Mapped Interface Signal Roles](#)

1.3.3. AXI Manager Interface

The AXI manager interface is a standard advanced extensible interface (AXI). This interface is accessible when you enabled the crypto services features. The crypto services features are available for the Intel Agilix devices.

Table 4. AXI Manager Interface

The table displays command, response, and urgent interface signals.

Signal Role	Width	Direction	Description
AXI Manager Clock and Reset Signals			
axi_in_clk	1	Input	AXI* interface clock.
axi_in_reset	1	Input	AXI interface reset.
<i>continued...</i>			

Signal Role	Width	Direction	Description
AXI Manager Write Address Channel Signals			
axi_target_awid	4	Output	AXI identification tag for write transaction.
axi_target_awaddr	32	Output	AXI address of the first transfer in a write transaction.
axi_target_awlen	8	Output	AXI length. Identifies the exact number of data transfers in a write transaction.
axi_target_awsz	3	Output	AXI size. Identifies the number of bytes in each data transfer in a write transaction.
axi_target_awburst	2	Output	AXI burst type. Indicates how address changes between each transfer in a write transaction.
axi_target_awlock	1	Output	Provides information about the atomic characteristics of a AXI write transaction.
axi_target_awcache	4	Output	Indicates how a write transaction is required to progress through a system.
axi_target_awprot	3	Output	Protection attributes of a write transaction: privilege, security level, and access type.
axi_target_awqos	4	Output	Quality of Service identifier for a write transaction
axi_target_awvalid	1	Output	AXI valid signal for a write transaction. Indicates that the write address channel signals are valid.
axi_target_awuser	5	Output	User-defined extension for the write address channel.
axi_target_awready	1	Input	AXI ready signal for write address. Indicates that a transfer on the write address channel can be accepted.
AXI Manager Write Data Channel Signals			
axi_target_wdata	64	Output	AXI write data.
axi_target_wlast	1	Output	AXI write transaction last data transfer. Indicates whether the current transfer is the last data transfer in a write transaction.
axi_target_wready	1	Input	AXI ready signal for write data. Indicates that a write data channel transfer can be accepted.
axi_target_wvalid	1	Output	AXI valid signal for write data. Indicates that a write data channel signals are valid.
axi_target_wstrb	8	Output	AXI write strobes. Indicates the byte lane holding valid data.
AXI Manager Write Response Channel Signals			
axi_target_bid	4	Input	AXI identification tag for write response.
axi_target_bresp	2	Input	AXI write response. Indicates write response status.
axi_target_bvalid	1	Input	AXI valid signal for write response. Indicates that the write response channel signals are valid.
axi_target_bready	1	Output	AXI ready signal for write response. Indicates that the write response channel transfer can be accepted.
continued...			

Signal Role	Width	Direction	Description
AXI Manager Read Data Channel Signals			
axi_target_rdata	64	Input	AXI read data.
axi_target_rresp	2	Input	AXI read response. Indicates read transfer status.
axi_target_rlast	1	Input	AXI read transaction last data transfer. Indicates whether the current transfer is the last data transfer in a read transaction.
axi_target_rready	1	Output	AXI read data channel ready signal. Indicates that a transfer on the read data channel can be accepted.
axi_target_rvalid	1	Input	AXI valid signal for read data channel. Indicates that the read data channel signals are valid.
axi_target_rid	4	Input	AXI identification tag for read data and response.
AXI Manager Read Response Channel Signals			
axi_target_arid	4	Output	AXI identification tag for read address transaction.
axi_target_araddr	32	Output	AXI address of the first transfer in a read transaction.
axi_target_arlen	8	Output	AXI length. Identifies the number of data transfers during the read transaction.
axi_target_arsize	3	Output	AXI size. Identifies the number of bytes in each data transfer in a read transaction.
axi_target_arburst	2	Output	AXI burst type. Indicates how address changes between each transfer in a read transaction.
axi_target_arlock	1	Output	Provides information about the atomic characteristics of a AXI read transaction.
axi_target_arcache	4	Output	Indicates how a read transaction is required to progress through a system.
axi_target_arprot	3	Output	Protection attributes of a read transaction: privilege, security level, and access type.
axi_target_arqos	4	Output	Quality of Service identifier for a read transaction.
axi_target_arvalid	1	Output	AXI valid signal for read transaction. Indicates that the read address channel signals are valid.
axi_target_aruser	5	Output	AXI user-defined extension for the read address channel.
axi_target_arready	1	Input	AXI read address channel ready signal. Indicates that a transfer on the read address channel can be accepted.

1.4. Mailbox Client Intel FPGA IP Avalon MM Memory Map

Table 5. Avalon MM Memory Map

Offset (word)	R/W	31	30:2	1	0
Base address + 0	W	Command			
Base address + 1	W	Command last word (eop)			
continued...					

Offset (word)	R/W	31	30:2	1	0
Base address + 2	R	Command FIFO empty space			
Base address + 3	N/A	Reserved			
Base address + 4	N/A	Reserved			
Base address + 5	R	Response data			
Base address + 6	R	Response FIFO fill level		EOP	SOP
Base address + 7	R/W	Interrupt enable register (IER)			
Base address + 8	R	Interrupt status register (ISR)			
Base address + 9	R/W	Timer 1 enable	Timer 1 period		
Base address + 10	R/W	Timer 2 enable	Timer 2 period		

1.4.1. Interrupt Enable Register

Use the Interrupt Enable register to enable or disable interrupts.

Note: These enable bits do not prevent the value of interrupt status bit from showing up in ISR, they only prevent the interrupt status bit from causing interrupt output assertion via IRQ signal.

Table 6. Interrupt Enable Register

Bit	Fields	Access	Default Value	Description
31:8	Reserved			
9	EN_RD_RSP_FIFO_WHEN_EMPTY	R/W	0x0	The enable interrupt bit for read response FIFO when empty detection. <ul style="list-style-type: none"> 1: Enable the read response FIFO when empty detection interrupt bit. 0: Disable the read response FIFO when empty detection interrupt bit.
8	EN_WR_CMD_FIFO_WHEN_FULL	R/W	0x0	The enable interrupt bit for write command FIFO when full detection. <ul style="list-style-type: none"> 1: Enable the write command FIFO when full interrupt bit 0: Disable the write command FIFO when full interrupt bit
7	EN_CRYPTO_ERROR_RECOVERY_PROGRESS ⁽³⁾	R/W	0x0	The enable interrupt bit for crypto service error recovery progress status. <ul style="list-style-type: none"> 1: Enable the crypto service error recovery progress interrupt 0: Disable the crypto service error recovery progress interrupt
6	EN_CRYPTO_MEMORY_TIMEOUT ⁽³⁾	R/W	0x0	The enable interrupt bit for the crypto service client-side memory timeout.

continued...

⁽³⁾ The crypto service feature is only available for Intel Agilex devices.

Bit	Fields	Access	Default Value	Description
				<ul style="list-style-type: none"> 1: Enable the crypto service client-side memory timeout interrupt 0: Disable the crypto service client-side memory timeout interrupt
5	EN_BACKPRESSURE_TIMEOUT	R/W	0x0	The enable interrupt bit for SDM backpressure timeout. <ul style="list-style-type: none"> 1: Enable the SDM backpressure timeout interrupt 0: Disable the SDM backpressure timeout interrupt
4	EN_EOP_TIMEOUT	R/W	0x0	The enable interrupt bit for EN_EOP_TIMEOUT. <ul style="list-style-type: none"> 1: Enable the EOP timeout interrupt 0: disable the EOP timeout interrupt
3	EN_COMMAND_INVALID	R/W	0x0	The enable interrupt bit for COMMAND_INVALID. <ul style="list-style-type: none"> 1: Enable the command invalid interrupt 0: Disable the command invalid interrupt
2	Reserved	—	—	Reserved.
1	EN_CMD_FIFO_NOT_FULL	R/W	0x0	The enable for the command FIFO full interrupt. <ul style="list-style-type: none"> 1: Enable the FIFO full interrupt 0: Disable the FIFO full interrupt
0	EN_DATA_VALID	R/W	0x0	The enable for the data valid interrupt. <ul style="list-style-type: none"> 1: Enable the data valid interrupt 0: Disable the data valid interrupt

1.4.2. Interrupt Status Register

Use the `interrupt_status` register to monitor the status of the FIFO and identify invalid commands.

Your logic can poll the error bits of the `interrupt_status` register. Or, you can configure the `EN_COMMAND_INVALID` bit of the interrupt enable register to interrupt when an error occurs.

When an error occurs, the Mailbox Client IP clears all pending responses. Your logic should not expect any response from Mailbox Client IP after an error occurs. Your logic must assert reset for a minimum of 10 clock cycles to reset the Mailbox Client IP.

Table 7. Interrupt Status Register

Bit	Fields	Access	Default Value	Description
31:8	Reserved			
9	RD_RSP_FIFO_WHEN_EMPTY	R	0x0	Read response FIFO when empty detection interrupt. <ul style="list-style-type: none"> 1: Indicates the IP detected that you attempted an erroneous behavior to read the response FIFO when it is empty which is not allowed. You must reset the Mailbox Client IP. 0: Indicates no erroneous behavior to read the response FIFO when it is empty was detected.
<i>continued...</i>				

Bit	Fields	Access	Default Value	Description
8	WR_CMD_FIFO_WHEN_FULL	R	0x0	Write command FIFO when full detection interrupt. <ul style="list-style-type: none"> 1: Indicates the IP detected that you attempted an erroneous behavior to write to the command FIFO when it is full which is not allowed. You must reset the Mailbox Client IP. 0: Indicates no erroneous behavior to write the command FIFO when it is full was detected.
7	CRYPTO_ERROR_RECOVERY_PROGRESS ⁽⁴⁾	R	0x0	Error recovery flow progress interrupt for the cryptographic (crypto) flow. <ul style="list-style-type: none"> 1: Indicates that the crypto error recovery is in progress. You may use this bit to report the progress of the soft IP error recovery. While in recovery, the SDM is unable to perform read/write operations from the memory. 0: Indicates the crypto error recovery is completed.
6	CRYPTO_MEMORY_TIMEOUT ⁽⁴⁾	R	0x0	Cryptographic services timer for memory target interrupt. Timeout value is set by Crypto Memory Timeout Value parameter in the Mailbox Client IP. <ul style="list-style-type: none"> 1: Indicates that the timeout occurred in either the memory target write or read path in the AXI transaction. You must reset the Mailbox Client IP (<i>in_reset</i> and <i>axi_in_reset</i>) and your memory target device. 0: No timeout occurred
5	BACKPRESSURE_TIMEOUT	R	0x0	SDM backpressure timer interrupt. <ul style="list-style-type: none"> 1: The SDM backpressure timer has timeout. Indicates that a fatal error occurred in SDM. You must reset the device. To reset, reconfigure or power cycle the device. 0: The SDM backpressure timer has not timeout.
4	EOP_TIMEOUT	R	0x0	End of Packet (EOP) timer interrupt. <ul style="list-style-type: none"> 1: Indicates that the EOP timer has timeout. You must reset the Mailbox Client IP. 0: The EOP timer has not timeout. Indicates that the Mailbox Client IP did not receive the full command with EOP due to: <ul style="list-style-type: none"> Mailbox did not receive the last argument with EOP. Mailbox already received all arguments without the EOP in it.
3	COMMAND_INVALID	R	0x0	Invalid command interrupt. Indicates a mismatch between the command length specified in the command header and the number of words sent. Hardware clears this bit. <ul style="list-style-type: none"> 1: Indicates that the command is invalid. You must reset the Mailbox client. 0: The command is valid.
continued...				

⁽⁴⁾ The crypto service feature is only available for Intel Agilex devices.

Bit	Fields	Access	Default Value	Description
2	Reserved	—	—	Reserved.
1	CMD_FIFO_NOT_FULL	R	0x0	Command FIFO is not full interrupt. <ul style="list-style-type: none"> 1: Indicates command FIFO is not full. The client can drive data. 0: Indicates the FIFO is full. The FIFO automatically clears this bit. You do not need to clear this bit manually.
0	DATA_VALID	R	0x0	Data valid interrupt. <ul style="list-style-type: none"> 1: Indicates that valid data is available. The master can read. 0: Indicates the FIFO is empty. The FIFO automatically clears this bit. You do not need to clear this bit manually.

1.4.3. Timer Registers

Use timer registers to monitor and address incomplete transactions between host and the Mailbox Client IP.

Incomplete Command Transaction Error

When a host fails to send the last command word to the Mailbox Client IP or the system stops sending data before the last word, the incomplete command transaction error occurs. Timer 1 allows you to set a specific transaction time period to complete each command. When the timer's timeout occurs, `ISR[4]` is set to indicate the error. To recover the system, you must reset the Mailbox Client IP.

Table 8. Timer 1 Register

Bit	Fields	Access	Default Value ⁽⁵⁾	Description
31	Timer 1 enable	R/W	0x0	Timer 1 period enable bit. The bit is enabled once. <ul style="list-style-type: none"> 1: Enable timer 1 0: Disable timer 1 If a time out occurs, the timer 1 register becomes disabled. You must apply the Mailbox Client Intel FPGA IP reset. To start the timer 1, you must re-enable it again.
30:0	Timer 1 period	R/W	0x7FF_FFFF	When enabled, the timer counts down the specified period as the maximum number of clock cycles the system has not received a valid command. The timer 1 starts the count down as soon as the transaction writes the first data word into the Command FIFO (base address +0). The timer resets when the Mailbox Client Intel FPGA IP receives complete command transaction, indicated by successfully writing the last word into the command last word register

continued...

⁽⁵⁾ Resetting the Mailbox Client IP resets the timer 1 register to the default value.

Bit	Fields	Access	Default Value ⁽⁵⁾	Description
				(base address +1). When the timer 1 resets itself, it returns to its default or other defined value.

SDM Backpressure Error

SDM typically backpressures while it processes commands and sends responses. The SDM backpressure error occurs when SDM backpressures for some time period not allowing you to write any data into the Mailbox fabric and SDM. The timer 2, by setting a specific wait time, allows you detect the long wait and take steps to recover your system. When a timer's timeout occurs, `ISR[5]` is set to indicate an error. Note that this is a fatal error received from SDM, possibly indicating a system error. Resetting the Mailbox Client won't recover the system.

Table 9. Timer 2 Register

Bit	Fields	Access	Default Value ⁽⁶⁾	Description
31	Timer 2 enable	R/W	0x0	Timer 2 period enable bit. The bits is enabled once. <ul style="list-style-type: none"> 1: Enable timer 2 0: Disable timer 2 If a time out occurs, the timer 2 register becomes disabled. You must apply the Mailbox Client Intel FPGA IP reset. To start the timer 2, you must re-enable it again.
30:0	Timer 2 period	R/W	0x7FF_FFFF	When enabled, the timer counts down the specified period as the maximum number of clock cycles the system has not asserted ready high signal. The SDM backpressures commands sent by host to the Mailbox Client Intel FPGA IP.

1.5. Commands and Responses

The host controller communicates with the SDM using command and response packets via the Mailbox Client Intel FPGA IP.

The first word of the command and response packets is a header that provides basic information about the command or response.

Figure 3. Command and Response Header Format

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reserved								ID		0		Length								0		Command/Error Code									

Note: The LENGTH field in the command header must match the command length of corresponding command.

The following table describes the fields of the header command.

⁽⁵⁾ Resetting the Mailbox Client IP resets the timer 1 register to the default value.

⁽⁶⁾ Resetting the Mailbox Client IP resets the timer 2 register to the default value.

Table 10. Command and Response Header Description

Header	Bit	Description
Reserved	[31:28]	Reserved.
ID	[27:24]	The command ID. The response header returns the ID specified in the command header. Refer to <i>Operation Commands</i> for command descriptions.
0	[23]	Reserved.
LENGTH	[22:12]	Number of words of arguments following the header. The IP responds with an error if a wrong number of words of arguments is entered for a given command. If there is a mismatch between the command length specified in the command header and the number of words sent. The IP raises bit 3 of the Interrupt Status Register (COMMAND_INVALID) and the Mailbox Client must be reset.
Reserved	[11]	Reserved. Must be set to 0.
Command Code/Error Code	[10:0]	Command Code specifies the command. The Error Code indicates whether the command succeeded or failed. In the command header, these bits represent command code. In the response header, these bits represent error code. If the command succeeds, the Error Code is 0. If the command fails, refer to the error codes defined in the <i>Error Code Responses</i> .

1.5.1. Operation Commands

Resetting Quad SPI Flash

Important: For Intel Stratix 10 devices, do not reset the quad SPI flash when used as the configuration device and data storage device with FPGA. Resetting the quad SPI flash during the FPGA configuration and reconfiguration, or in the QSPI's READ/WRITE/ERASE operations, causes undefined behavior for quad SPI flash and the FPGA. To recover from the unresponsive behavior, you must power cycle your device. To reset the quad SPI flash via the external host, you must first complete the FPGA configuration and reconfiguration, or a quad SPI operation, and only then toggle the reset. The quad SPI operation is complete when the exclusive access to the quad SPI flash is closed by issuing the QSPI_CLOSE command via the Mailbox Client Intel FPGA IP or CLOSE command via the Serial Flash Mailbox Client Intel FPGA IP.

Important: For Intel Agilex devices, you must connect the serial flash or quad SPI flash reset pin to the AS_nRST pin. The SDM must fully control the QSPI reset. Do not connect the quad SPI reset pin to any external host.

Table 11. Command List and Description

Command	Code (Hex)	Command Length ⁽⁷⁾	Response Length ⁽⁷⁾	Description
NOOP	0	0	0	Sends an OK status response.
GET_IDCODE	10	0	1	The response contains one argument which is the JTAG IDCODE for the device
<i>continued...</i>				

⁽⁷⁾ This number does not include the command or response header.

Command	Code (Hex)	Command Length ⁽⁷⁾	Response Length ⁽⁷⁾	Description
GET_CHIPID	12	0	2	The response contains 64-bit CHIPID value with the least significant word first.
GET_USERCODE	13	0	1	The response contains one argument which is the 32-bit JTAG USERCODE that the configuration bitstream writes to the device.
GET_VOLTAGE	18	1	n ⁽⁸⁾	<p>The GET_VOLTAGE command has a single argument which is a bitmask specifying the channels to read. Bit 0 specifies channel 0, bit 1 specifies channel 1, and so on.</p> <p>The response includes a one-word argument for each bit set in the bitmask. The voltage returned is an unsigned fixed-point number with 16 bits below the binary point. For example, a voltage of 0.75V returns 0x0000C000.⁽⁹⁾ ⁽¹⁰⁾</p>
GET_TEMPERATURE	19	1	n ⁽¹¹⁾	<p>The GET_TEMPERATURE command returns the temperature or temperatures of the core fabric or transceiver channel locations you specify.</p> <p>For Intel Stratix 10 devices, use the <code>sensor_req</code> argument to specify the locations. The <code>sensor_req</code> includes the following fields:</p> <ul style="list-style-type: none"> Bits[31:9]: Reserved. Bits[8:0]: <code>Sensor mask</code>. Specifies the TSD location. <p>The channels return the temperatures for the following locations:</p> <ul style="list-style-type: none"> Channel 0: Samples the temperature from the core fabric. Channels 1- 6: Samples the temperature from the specified transceiver tile. Channels 7-8: Samples the temperature from the high-bandwidth DRAM memory (HBM2) stacks. <p>For Intel Agilex devices, use the <code>sensor_req</code> argument to specify the locations. The <code>sensor_req</code> includes the following fields:</p> <ul style="list-style-type: none"> Bits[31:28]: Reserved. Bits[27:16]: <code>Sensor Location</code>. Specifies the TSD location. Bits[15:0]: <code>Sensor mask</code>. Specifies the sensors to read for the <code>sensor location</code> specified. The response contains one word for each temperature requested. If omitted, the command reads channel 0. The least significant bit (lsb) corresponds to sensor 0. The most significant bit (msb) corresponds to channel 15. <p>The temperature returned is a signed fixed value with 8 bits below the binary point. For example, a temperature of 10°C returns 0x00000A00. A of temperature -1.5°C returns 0xFFFFFE80.</p> <p>If the bitmask specifies an invalid <code>Location</code>, the command returns an error code which is any value in the range 0x80000000 -0x800000FF.</p> <p>For Intel Stratix 10 devices, refer to the <i>Temperature Sensor Channels and Locations</i> in the <i>Intel Stratix 10 Analog to Digital Converter User Guide</i> for more information about sensor locations.</p>

continued...

⁽⁷⁾ This number does not include the command or response header.

⁽⁸⁾ For Intel Stratix 10 and Intel Agilex devices that support reading multiple devices, index n matches the number of channels you enable on your device.

⁽⁹⁾ Refer to *Intel Stratix 10 Analog to Digital Converter User Guide* for more information about reading voltage sensors on Intel Stratix 10 devices.

⁽¹⁰⁾ Refer to *Intel Agilex Power Management User Guide* for more information about temperature sensor channels and locations.

⁽¹¹⁾ Index n depends on the number of sensor masks.

Command	Code (Hex)	Command Length ⁽⁷⁾	Response Length ⁽⁷⁾	Description													
				For Intel Agilex devices, refer to the <i>Intel Agilex Power Management User Guide</i> for more information about local build-in temperature sensors.													
RSU_IMAGE_UPDATE	5C	2	0	<p>Triggers reconfiguration from the data source that can be either the factory or an application image.</p> <p>This command takes an optional 64-bit argument that specifies the reconfiguration data address in the flash. When sending the argument to the IP, you first send bits [31:0] followed by bits [63:32]. If you do not provide this argument its value is assumed to be 0.</p> <ul style="list-style-type: none">Bit [31:0]: The start address of an application image.Bit [63:32]: Reserved (write as 0). <p>Once the device processes this command, it returns the response header to response FIFO before it proceeds to reconfigure the device. Ensure the host PC or host controller stops servicing other interrupts and focuses on reading the response header data to indicate the command completed successfully. Otherwise, the host PC or host controller may not be able to receive the response once the reconfiguration process started.</p> <p>Once the device proceeds with reconfiguration, the link between the external host and FPGA is lost. If you use PCIe in your design, you need to re-enumerate the PCIe link.</p> <p><i>Important:</i> When resetting quad SPI, you must follow instructions specified in Resetting Quad SPI Flash on page 15.</p>													
RSU_GET_SPT	5A	0	4	<p>RSU_GET_SPT retrieves the quad SPI flash location for the two sub-partition tables that the RSU uses: SPT0 and SPT1.</p> <p>The 4-word response contains the following information:</p> <table><tr><th>Word</th><th>Name</th><th>Description</th></tr><tr><td>0</td><td>SPT0[63:32]</td><td rowspan="2">SPT0 address in quad SPI flash.</td></tr><tr><td>1</td><td>SPT0[31:0]</td></tr><tr><td>2</td><td>SPT1[63:32]</td><td rowspan="2">SPT1 address in quad SPI flash.</td></tr><tr><td>3</td><td>SPT1[31:0]</td></tr></table>	Word	Name	Description	0	SPT0[63:32]	SPT0 address in quad SPI flash.	1	SPT0[31:0]	2	SPT1[63:32]	SPT1 address in quad SPI flash.	3	SPT1[31:0]
Word	Name	Description															
0	SPT0[63:32]	SPT0 address in quad SPI flash.															
1	SPT0[31:0]																
2	SPT1[63:32]	SPT1 address in quad SPI flash.															
3	SPT1[31:0]																
CONFIG_STATUS	4	0	6	<p>Reports the status of the last reconfiguration. You can use this command to check the configuration status during and after configuration. The response contains the following information:</p> <table><tr><th>Word</th><th>Summary</th><th>Description</th></tr><tr><td>0</td><td>State</td><td><p>Describes the most recent configuration related error. Returns 0 when there are no configuration errors.</p><p>The error field has 2 fields:</p><ul style="list-style-type: none">Upper 16 bits: Major error code.Lower 16 bits: Minor error code.<p>Refer to <i>Appendix: CONFIG_STATUS and RSU_STATUS Error Code Descriptions</i> in the <i>Mailbox Client Intel FPGA IP User Guide</i> for more information.</p></td></tr><tr><td>1</td><td>Quartus Version</td><td><p>For Intel Stratix 10 devices:</p><p>Available in Intel Quartus Prime software version 19.4 or later, the field displays:</p></td></tr></table>	Word	Summary	Description	0	State	<p>Describes the most recent configuration related error. Returns 0 when there are no configuration errors.</p> <p>The error field has 2 fields:</p> <ul style="list-style-type: none">Upper 16 bits: Major error code.Lower 16 bits: Minor error code. <p>Refer to <i>Appendix: CONFIG_STATUS and RSU_STATUS Error Code Descriptions</i> in the <i>Mailbox Client Intel FPGA IP User Guide</i> for more information.</p>	1	Quartus Version	<p>For Intel Stratix 10 devices:</p> <p>Available in Intel Quartus Prime software version 19.4 or later, the field displays:</p>				
Word	Summary	Description															
0	State	<p>Describes the most recent configuration related error. Returns 0 when there are no configuration errors.</p> <p>The error field has 2 fields:</p> <ul style="list-style-type: none">Upper 16 bits: Major error code.Lower 16 bits: Minor error code. <p>Refer to <i>Appendix: CONFIG_STATUS and RSU_STATUS Error Code Descriptions</i> in the <i>Mailbox Client Intel FPGA IP User Guide</i> for more information.</p>															
1	Quartus Version	<p>For Intel Stratix 10 devices:</p> <p>Available in Intel Quartus Prime software version 19.4 or later, the field displays:</p>															

continued..

continued...

⁽⁷⁾ This number does not include the command or response header.

Command	Code (Hex)	Command Length ⁽⁷⁾	Response Length ⁽⁷⁾	Description	
					<ul style="list-style-type: none"> Bit [31:28]: Index of the firmware or decision firmware copy that was used the most recently. Possible values are 0, 1, 2, and 3. Bit [27:24]: Reserved Bit [23:0]: 24'd0 <p>For Intel Agilex devices: Available in Intel Quartus Prime software versions between 19.4 and 21.2, the field displays:</p> <ul style="list-style-type: none"> Bit [31:28]: Index of the firmware or decision firmware copy that was used the most recently. Possible values are 0, 1, 2, and 3. Bit [27:24]: Reserved Bit [23:16]: Major Quartus release number Bit [15:8]: Minor Quartus release number Bit [7:0]: Quartus update number <p>Available in Intel Quartus Prime software version 21.3 or later, the Quartus version displays:</p> <ul style="list-style-type: none"> Bit [31:28]: Index of the firmware or decision firmware copy that was used the most recently. Possible values are 0, 1, 2, and 3. Bit [27:24]: Reserved Bit [23:16]: Major Quartus release number Bit [15:8]: Minor Quartus release number Bit [7:0]: Quartus update number <p>For example, in Intel Quartus Prime software version 21.3.1, the following values represent the major and minor Quartus release numbers, and the Quartus update number:</p> <ul style="list-style-type: none"> Bit [23:16] = 8'd21 = 8'h15 Bit [15:8] = 8'd3 = 8'h3 Bit [7:0] = 8'd1 = 8'h1
			2	Pin status	<ul style="list-style-type: none"> Bit [31]: Current nSTATUS output value (active low) Bit [30]: Detected nCONFIG input value (active low) Bit [29:8]: Reserved Bit [7:6]: Configuration clock source <ul style="list-style-type: none"> 01 = Internal oscillator 10 = OSC_CLK_1 <p><i>Note:</i> Bit [7:6] is only applicable to Intel Agilex devices</p> <ul style="list-style-type: none"> Bit [5:3]: Reserved Bit [2:0]: The MSEL value at power up

continued...

⁽⁷⁾ This number does not include the command or response header.

Command	Code (Hex)	Command Length ⁽⁷⁾	Response Length ⁽⁷⁾	Description		
				3	Soft function status	Contains the value of each of the soft functions, even if you have not assigned the function to an SDM pin. <ul style="list-style-type: none"> Bit [31:6]: Reserved Bit [5]: HPS_WARMRESET Bit [4]: HPS_COLDRESET Bit [3]: SEU_ERROR Bit [2]: CVP_DONE Bit [1]: INIT_DONE Bit [0]: CONF_DONE
				4	Error location	Contains the error location. Returns 0 if there are no errors.
				5	Error details	Contains the error details. Returns 0 if there are no errors.
RSU_STATUS	5B	0	9	Reports the current remote system upgrade status. You can use this command to check the configuration status during configuration and after it has completed. This command returns the following responses:		
				Word	Summary	Description
				0-1	Current image	Flash offset of the currently running application image.
				2-3	Failing image	Flash offset of the highest priority failing application image. If multiple images are available in flash memory, stores the value of the first image that failed. A value of all 0s indicates no failing images. If there are no failing images, the remainder of the remaining words of the status information do not store valid information. <i>Note:</i> A rising edge on nCONFIG to reconfigure from ASx4, does not clear this field. Information about failing image only updates when the Mailbox Client receives a new RSU_IMAGE_UPDATE command and successfully configures from the update image.
				4	State	Failure code of the failing image. The error field has two parts: <ul style="list-style-type: none"> Bit [31:16]: Major error code Bit [15:0]: Minor error code Returns 0 for no failures. Refer to <i>Appendix: CONFIG_STATUS and RSU_STATUS Error Code Descriptions</i> in the <i>Mailbox Client Intel FPGA IP User Guide</i> for more information.
				5	Version	RSU interface version and error source. For more information, refer to RSU Status and Error Codes section in the <i>Hard Processor System Remote System Update User Guide</i> .

continued...

⁽⁷⁾ This number does not include the command or response header.

Command	Code (Hex)	Command Length ⁽⁷⁾	Response Length ⁽⁷⁾	Description		
				6	Error location	Stores the error location of the failing image. Returns 0 for no errors.
				7	Error details	Stores the error details for the failing image. Returns 0 if there are no errors.
				8	Current image retry counter	Count of the number of retries that have been attempted for the current image. The counter is 0 initially. The counter is set to 1 after the first retry, then 2 after a second retry. Specify the maximum number of retries in your Intel Quartus Prime Settings File (.qsf). The command is: set_global_assignment -name RSU_MAX_RETRY_COUNT 3. Valid values for the MAX_RETRY counter are 1-3. The actual number of available retries is MAX_RETRY -1 This field was added in version 19.3 of the Intel Quartus Prime Pro Edition software.
RSU_NOTIFY	5D	1	0	Clears all error information in the RSU_STATUS response and resets the retry counter. The one-word argument has the following fields: <ul style="list-style-type: none">0x00050000: Clear current reset retry counter. Resetting the current retry counter sets the counter back to zero, as if the current image was successfully loaded for the first time.0x00060000: Clear error status information.All other values are reserved. This command is not available before version 19.3 of the Intel Quartus Prime Pro Edition software.		
QSPI_OPEN	32	0	0	Requests exclusive access to the quad SPI. You issue this request before any other QSPI requests. The SDM accepts the request if the quad SPI is not in use and the SDM is not configuring the device. Returns OK if the SDM grants access. The SDM grants exclusive access to the client using this mailbox. Other clients cannot access the quad SPI until the active client relinquishes access using the QSPI_CLOSE command. Access to the quad SPI flash memory devices via any mailbox client IP is not available by default in designs that include the HPS, unless you disable the QSPI in HPS software configuration. <i>Important:</i> When resetting quad SPI, you must follow instructions specified in Resetting Quad SPI Flash on page 15.		
QSPI_CLOSE	33	0	0	Closes the exclusive access to the quad SPI interface. <i>Important:</i> When resetting quad SPI, you must follow instructions specified in Resetting Quad SPI Flash on page 15.		
QSPI_SET_CS	34	1	0	Specifies one of the attached quad SPI devices via the chip select lines. Takes a one-word argument as described below:		
continued...						

⁽⁷⁾ This number does not include the command or response header.

Command	Code (Hex)	Command Length ⁽⁷⁾	Response Length ⁽⁷⁾	Description
				<ul style="list-style-type: none"> Bits[31:28]: Flash device to select. Refer to the information below for the value that corresponds to the nCSO[0:3] pins. <ul style="list-style-type: none"> Value 4'h0000 selects the flash that corresponds to nCSO[0] Value 4'h0001 selects the flash that corresponds to nCSO[1] Value 4'h0002 selects the flash that corresponds to nCSO[2] Value 4'h0003 selects the flash that corresponds to nCSO[3] Bits[27:0]: Reserved (write as 0). <p><i>Note:</i> Intel Agilex or Intel Stratix 10 support one AS x4 flash memory device for AS configuration from quad SPI device connected to nCSO[0]. Once the device entered user mode, you can use up to four AS x4 flash memories with Mailbox Client IP or HPS as data storage. The Mailbox Client IP or HPS can use nCSO[3:0] to access quad SPI devices.</p> <p>This command is optional for the AS x4 configuration scheme, the chip select line follows the last executed QSPI_SET_CS command or defaults to nCSO[0] after the AS x4 configuration. The JTAG configuration scheme requires executing this command to access the QSPI flash that connects the SDM_IO pins.</p> <p>Access to the QSPI flash memory devices using SDM_IO pins is only available for the AS x4 configuration scheme, JTAG configuration, and a design compiled for AS x4 configuration. For the Avalon streaming interface (Avalon ST) configuration scheme, you must connect QSPI flash memories to GPIO pins.</p> <p><i>Important:</i> When resetting quad SPI, you must follow instructions specified in Resetting Quad SPI Flash on page 15.</p>
QSPI_READ	3A	2	N	<p>Reads the attached quad SPI device. The maximum transfer size is 4 kilobytes (KB) or 1024 words.</p> <p>Takes two arguments:</p> <ul style="list-style-type: none"> The quad SPI flash address (one word). The address must be word aligned. The device returns the 0x1 error code for non-aligned addresses. Number of words to read (one word). <p>When successful, returns OK followed by the read data from the quad SPI device. A failure response returns an error code.</p> <p>For a partially successful read, QSPI_READ may erroneously return the OK status.</p> <p><i>Note:</i> You cannot run the QSPI_READ command while device configuration is in progress.</p> <p><i>Important:</i> When resetting quad SPI, you must follow instructions specified in Resetting Quad SPI Flash on page 15.</p>
QSPI_WRITE	39	2+N	0	<p>Writes data to the quad SPI device. The maximum transfer size is 4 kilobytes (KB) or 1024 words.</p> <p>Takes three arguments:</p> <ul style="list-style-type: none"> The flash address offset (one word). The write address must be word aligned. The number of words to write (one word). The data to be written (one or more words). <p>A successful write returns the OK response code.</p> <p>To prepare memory for writes, use the QSPI_ERASE command before issuing this command.</p> <p><i>Note:</i> You cannot run the QSPI_WRITE command while device configuration is in progress.</p> <p><i>Important:</i> When resetting quad SPI, you must follow instructions specified in Resetting Quad SPI Flash on page 15.</p>
continued...				

⁽⁷⁾ This number does not include the command or response header.

Command	Code (Hex)	Command Length ⁽⁷⁾	Response Length ⁽⁷⁾	Description
QSPI_ERASE	38	2	0	<p>Erases a 4/32/64 KB sector of the quad SPI device. Takes two arguments:</p> <ul style="list-style-type: none"> The flash address offset to start the erase (one word). Depending on the number of words to erase, the start address must be: <ul style="list-style-type: none"> 4 KB aligned if number words to erase is 0x400 32 KB aligned if number words to erase is 0x2000 64 KB aligned if number words to erase is 0x4000 <p>Returns an error for non-4/32/64 KB aligned addresses.</p> <ul style="list-style-type: none"> The number of words to erase is specified in multiples of: <ul style="list-style-type: none"> 0x400 to erase 4 KB (100 words) of data. This option is the minimum erase size. 0x2000 to erase 32 KB (500 words) of data 0x4000 to erase 64 KB (1000 words) of data <p>A successful erase returns the OK response code.</p> <p><i>Important:</i> When resetting quad SPI, you must follow instructions specified in Resetting Quad SPI Flash on page 15.</p>
QSPI_READ_DEVICE_REG	35	2	N	<p>Reads registers from the quad SPI device. The maximum read is 8 bytes. Takes two arguments:</p> <ul style="list-style-type: none"> The opcode for the read command. The number of bytes to read. <p>A successful read returns the OK response code followed by the data read from the device. The read data return is in multiple of 4 bytes. If the bytes to read is not an exact multiple of 4 bytes, it is padded with multiple of 4 bytes until the next word boundary and the padded bit value is zero.</p> <p><i>Important:</i> When resetting quad SPI, you must follow instructions specified in Resetting Quad SPI Flash on page 15.</p>
QSPI_WRITE_DEVICE_REG	36	2+N	0	<p>Writes to registers of the quad SPI. The maximum write is 8 bytes. Takes three arguments:</p> <ul style="list-style-type: none"> The opcode for the write command. The number of bytes to write. The data to write. <p>To perform a sector erase or sub-sector erase, you must specify the serial flash address in most significant byte (MSB) to least significant byte (LSB) order as the following example illustrates.</p> <p>To erase a sector of a Micron 2 gigabit (Gb) flash at address 0x04FF0000 using the QSPI_WRITE_DEVICE_REG command, write the flash address in MSB to LSB order as shown here:</p> <p>Header: 0x00003036 Opcode: 0x000000DC Number of bytes to write: 0x00000004 Flash address: 0x0000FF04</p> <p>A successful write returns the OK response code. This command pads data that is not a multiple of 4 bytes to the next word boundary. The command pads the data with zero.</p> <p><i>Important:</i> When resetting quad SPI, you must follow instructions specified in Resetting Quad SPI Flash on page 15.</p>
QSPI_SEND_DEVICE_OP	37	1	0	<p>Sends a command opcode to the quad SPI. Takes one argument:</p> <ul style="list-style-type: none"> The opcode to send the quad SPI device. <p>A successful command returns the OK response code.</p> <p><i>Important:</i> When resetting quad SPI, you must follow instructions specified in Resetting Quad SPI Flash on page 15.</p>
continued...				

⁽⁷⁾ This number does not include the command or response header.

Command	Code (Hex)	Command Length ⁽⁷⁾	Response Length ⁽⁷⁾	Description						
QSPI_READ_SHA	6E	2	16/12/8	<p>Instructs the firmware to read data from the flash controller and calculate its hash value using one of three Secure Hashing Algorithms (SHA). The returned hash value can be compared to a previously calculated hash value using the same algorithm to determine the integrity of the flash contents.</p> <p>This command takes two 32-bit words as arguments.</p> <p>Word 0:</p> <ul style="list-style-type: none">Bits [1:0]: SHA Variant. This parameter determines the type of SHA algorithm used. It can take the following values:<ul style="list-style-type: none">00: SHA51201: SHA38410: SHA256Bits[31:2]: Start Address. This is the address in flash to start verifying from. The address must be 4 bytes aligned. <p>Word 1:</p> <ul style="list-style-type: none">Bits [31:0]: NumBytes. This represents the number of bytes to be used in the SHA read. Must be a multiple of 64. <p>The response length varies depending on the SHA variant chosen in the command.</p> <ul style="list-style-type: none">SHA512: Returns 16 wordsSHA384: Returns 12 wordsSHA256: Returns 8 words <p><i>Note:</i> This command is only supported on Intel Agilex devices.</p>						
GET_CONFIGURATION_TIME	65	0	2	<p>Returns the 64-bit cycle count of the configuration network control clock, with the least significant word first. Dividing the count value by the configuration network control clock frequency provides an estimate of the configuration time. The operating frequency of the configuration network clock depends on the clock source settings configuration in Intel Quartus Prime. This command can be used with any of the supported configuration schemes.</p> <p>Typically, configuration cycle count is captured in the lower 32 bits. It is unlikely that the firmware returns a 64-bit cycle count. If this happens, you must concatenate the two 32-bit words to obtain the total cycle count value.</p> <p>Example:</p> <p>Returned response: 0x007C27EE = 8136686 cycles</p> <p>Configuration control clock frequency: 200 MHz</p> <p>Configuration time: (8136686/200000000) × 1000 = 40.68 ms</p> <p><i>Note:</i> This command is only supported on Intel Agilex devices.</p> <table><tr><th>Configuration Clock Source</th><th>Configuration Network Control Clock Frequency</th></tr><tr><td>External Oscillator (OSC_CLK_1)</td><td>250 MHz</td></tr><tr><td>Internal Oscillator</td><td>170 MHz to 230 MHz</td></tr></table>	Configuration Clock Source	Configuration Network Control Clock Frequency	External Oscillator (OSC_CLK_1)	250 MHz	Internal Oscillator	170 MHz to 230 MHz
Configuration Clock Source	Configuration Network Control Clock Frequency									
External Oscillator (OSC_CLK_1)	250 MHz									
Internal Oscillator	170 MHz to 230 MHz									

For CONFIG_STATUS and RSU_STATUS major and minor error code descriptions, refer to *Appendix: CONFIG_STATUS and RSU_STATUS Error Code Descriptions*.

Related Information

- [Mailbox Client Intel FPGA IP Core Use Case Examples](#) on page 32
- [Appendix A: CONFIG_STATUS and RSU_STATUS Error Code Descriptions](#)

⁽⁷⁾ This number does not include the command or response header.

- [Intel Stratix 10 Analog to Digital Converter User Guide](#)
For more information about the temperature sensor channel numbers and temperature sensing diodes (TSDs).
- [Intel Stratix 10 Hard Processor System Technical Reference Manual](#)
- [Intel Stratix 10 FPGA Boot User Guide](#)
- [Intel eASIC™ N5X Hard Processor System Remote System Update User Guide](#)
For more information about version fields.
- [Intel Agilex Power Management User Guide](#)
For more information about the temperature sensor channel numbers and temperature sensing diodes (TSDs).
- [Intel Agilex Hard Processor System Technical Reference Manual](#)
- [Intel Agilex Hard Processor System Remote System Update User Guide](#)

1.5.2. Error Code Responses

Table 12. Error Codes

Value (Hex)	Error Code Response	Description
0	OK	Indicates that the command completed successfully. A command may erroneously return the OK status if a command, such as QSPI_READ is partially successful.
1	INVALID_COMMAND	Indicates that the currently loaded boot ROM cannot decode or recognize the command code.
3	UNKNOWN_COMMAND	Indicates that the currently loaded firmware cannot decode the command code.
4	INVALID_COMMAND_PARAMETERS	Indicates that the command is incorrectly formatted. For example, the length field setting in header is not valid.
6	COMMAND_INVALID_ON_SOURCE	Indicates that the command is from a source for which it is not enabled.
8	CLIENT_ID_NO_MATCH	Indicates that the Client ID cannot complete the request to close the exclusive access to quad SPI. The Client ID does not match the existing client with the current exclusive access to quad SPI.
9	INVALID_ADDRESS	The address is invalid. This error indicates one of the following conditions: <ul style="list-style-type: none"> • An unaligned address • An address range problem • A read permission problem • An invalid chip select value, displaying value of more than 3 • An invalid address in RSU case • An invalid bitmask value for GET_VOLTAGE command • An invalid page selection for GET_TEMPERATURE command
A	AUTHENTICATION_FAIL	Indicates the configuration bitstream signature authentication failure.
B	TIMEOUT	This error indicates time out due to the following conditions: <ul style="list-style-type: none"> • Command • Waiting for QSPI_READ operation to complete • Waiting for the requested temperature reading from one of the temperature sensors. May indicate a potential hardware error in the temperature sensor.
C	HW_NOT_READY	Indicates one of the following conditions:

continued...

Value (Hex)	Error Code Response	Description			
		<ul style="list-style-type: none"> The hardware is not ready. Can indicate either an initialization or configuration problem. The hardware may refer to quad SPI. RSU image is not used to configure the FPGA. 			
D	HW_ERROR	Indicates that the command completed unsuccessfully due to unrecoverable hardware error.			
80 - 8F	COMMAND_SPECIFIC_ERROR	Indicates a command specific error due to an SDM command you used.			
		SDM Command	Error Name	Error code	Description
		GET_CHIPID	EFUSE_SYSTEM_FAILURE	0x82	Indicates that the eFuse cache pointer is invalid.
		QSPI_OPEN/ QSPI_CLOSE/ QSPI_SET_CS/ QSPI_READ_DEVICE_REG/ QSPI_WRITE_DEVICE_REG/ QSPI_SEND_DEVICE_OP/ QSPI_READ	QSPI_HW_ERROR	0x80	Indicates QSPI flash memory error. This error indicates one of the following conditions: <ul style="list-style-type: none"> A QSPI flash chip select setting problem A QSPI flash initialization problem A QSPI flash resetting problem A QSPI flash settings update problem
			QSPI_ALREADY_OPEN	0x81	Indicates that the client's exclusive access to QSPI flash via QSPI_OPEN command is already open.
100	NOT_CONFIGURED	Indicates that the device is not configured.			
1FF	ALT_SDM_MBOX_RESP_DEVICE_BUSY	Indicates that the device is busy due to following use cases: <ul style="list-style-type: none"> RSU: Firmware is unable to transition to different version due to an internal error. HPS: HPS is busy when in HPS reconfiguration process or HPS cold reset. 			
2FF	ALT_SDM_MBOX_RESP_NO_VALID_RESP_AVAILABLE	Indicates that there is no valid response available.			
3FF	ALT_SDM_MBOX_RESP_ERROR	General Error.			

1.5.3. Error Code Recovery

The table below describes possible steps to recover from an error code. Error recovery depends on specific use case.

Table 13. Error Code Recovery for known Error Codes

Value	Error Code Response	Error Code Recovery
4	INVALID_COMMAND_PARAMETERS	Resend the command header or header with arguments with corrected parameters. For example, ensure that the length field setting in header is sent with the correct value.
6	COMMAND_INVALID_ON_SOURCE	Resend the command from valid source such as JTAG, HPS, or core fabric.
continued...		

Value	Error Code Response	Error Code Recovery
8	CLIENT_ID_NO_MATCH	Wait for the client who opened the access to quad SPI to complete its access and then closes the exclusive access to quad SPI.
9	INVALID_ADDRESS	Possible error recovery steps: For GET_VOLTAGE command: Send command with a valid bitmask. For GET_TEMPERATURE command: Send command with valid sensor location and sensor mask. For QSPI operation: <ul style="list-style-type: none"> Send command with a valid chip select. Send command with a valid QSPI flash address. For RSU: Send command with a valid start address of the factory image or application.
B	TIMEOUT	Possible recovery steps: For GET_TEMPERATURE command: Retry to send the command again. If problem persists, reconfigure or power cycle the device. For QSPI operation: Check signal integrity of QSPI interfaces and attempt command again. For HPS restart operation: Retry to send the command again.
C	HW_NOT_READY	Possible recovery steps: For QSPI operation: Reconfigure the device via source. Ensure that IP used to build your design allows access to the QSPI flash. For RSU: Configure the device with RSU image.
80	QSPI_HW_ERROR	Check the QSPI interface signal integrity and ensure the QSPI device is not damaged.
81	QSPI_ALREADY_OPEN	Client already opened QSPI. Continue with the next operation.
82	EFUSE_SYSTEM_FAILURE	Attempt reconfiguration or power cycle. If error persists after reconfiguration or power cycle, the device may be damaged and unrecoverable.
100	NOT_CONFIGURED	Send a bitstream that configures the HPS.
1FF	ALT_SDM_MBOX_RESP_DEVICE_BUSY	Possible error recovery steps: For QSPI operation: Wait for ongoing configuration or other client to complete operation. For RSU: Reconfigure device to recover from internal error. For HPS restart operation: Wait for reconfiguration via HPS or HPS Cold Reset to complete.

1.6. Specifying the Command and Response FIFO Depths

The optimal depth of the command and response FIFOs depends on the specific application. You should size these FIFOs to accommodate the maximum command and responses that your application requires.

The following example illustrates this point. Consider an application sends a maximum of eight back-to-back GET_TEMPERATURE commands to the FPGA core and one transceiver bank. Each command consists of a header and one command argument, specifying the mask of the temperature sensors to read. The optimal setting for the command FIFO is 16 words.

For the response FIFO, each response has one header word, and one word each for the core temperature and transceiver bank temperature. Each response is three words. The optimal setting for the response FIFO Depth is 24 words.

1.7. Enabling Cryptographic Services

The cryptographic offloading feature is available for Intel Agilex devices in Intel Quartus Prime Pro Edition software version 21.3 or later.

To enable this feature in the IP parameter editor, set **Enable Crypto Service** parameter to 1. When enabled, the Mailbox Client IP generates an 64-bit AXI manager interface that is used to pass data between the cryptographic fabric IP and user space memory.

For more information about the Cryptographic Services Mailbox Commands, refer to the *Security Methodology for Intel FPGAs and Structured ASICs User Guide*. The *Security Methodology for Intel FPGAs and Structured ASICs User Guide* document available on the Intel Resource & Design Center contains detailed descriptions of the security features and technologies in Intel Programmable Solutions products to help you select the security features necessary to meet your security objectives. Contact Intel Support with reference number 14014613136 for access to the *Security Methodology for Intel® FPGAs and Structured ASICs User Guide*.


Related Information

[Intel Agilex Device Security User Guide](#)

1.8. Using the Mailbox Client Intel FPGA IP

Writing Command Packet

Figure 4. Flow Chart for Writing Command Packet



Agenda:
n: Command FIFO empty space
t: Total Command Length

Write Command Description

When you send a command to the SDM, write the command word into command register, which is the base address. To stay in sync with the hardware, while the command length (t) is greater than zero, write the header and arguments in the Command register which is (base address + 0). Continue writing the header and/or

arguments, one word at the time, in the `Command` register (base address + 0) while there is available free space in the FIFO for commands ($n > t$). Write the last word to the `Command last word` register which is (base address + 1). For commands with no arguments, write the header to the `Command last word` register, (base address + 1).

Reading from (base address + 2) shows the remaining available free space in the FIFO for commands. The command FIFO can become full when the SDM is busy. The IP requires 3 clock cycles to update the `Command FIFO empty space` value. You can begin reading the `Command FIFO empty space` value 3 clock cycles after writing the command to the IP.

You must check the `Command FIFO empty space` register, (base address + 2) before proceeding to write into the `Command/Command last word` registers. The behavior of the IP is undefined if you write to (base address + 0) and (base address + 1) while the FIFO is full. The write data is discarded.

Unexpected or undefined behavior may occur if you send more commands than required. For example, send the following commands to read the Chip ID value:

- Write the command header to (base address + 0).
- Write again the command header to (base address + 1).


In the above scenario, the IP core expects a 3-word response (command header and 2 data words). However, the SDM only returns a one-word response, which is the error response code.

You must send commands in the correct order to the `Command` or `Command last word` register, as described in the [Writing Command Packet](#). Failure to send commands in the correct order can result in loss of services for all mailbox clients, including the following standalone IP cores:

- Temperature Sensor Intel FPGA IP
- Voltage Sensor Intel FPGA IP
- Chip ID Intel FPGA IP
- Advanced SEU Detection Intel IP
- Partial Reconfiguration Controller Intel IP
- Partial Reconfiguration External Configuration Controller Intel FPGA IP

Reading Response Packet

Figure 5. Flow Chart for Reading Response Packet



Read Command Description

1. Read (base address + 8) to check if bit 0 of Interrupt status register is 1, to indicate the valid data is available for the master to read. You can poll the Interrupt status register continuously until bit 0 is 1.
2. Read (base address + 6) to check the SOP (start of packet), EOP (end of packet), and the Response FIFO fill level (n).

To read multiple words, complete the following steps:

- a. If `SOP = 1` and `EOP = 0`, the response has multiple words.
- b. If the `Response FIFO fill level (n)` is non-zero, the FIFO has valid data.
- c. For example, if you perform a `QSPI_READ` operation to read 10 words from quad SPI flash, a return value of `0x0000002d` indicates that the SDM wrote 11 words to the response FIFO. The 11 words comprise a response header word and 10 data words.

To read a single word, complete the following steps:

- a. If `SOP = 1` and `EOP = 1`, the response has a single word.
 - b. If the `Response FIFO fill level` is non-zero, the FIFO has valid data.
 - c. A return value of `0x00000007` indicates that the SDM wrote a single word to the response FIFO. This single is both the start and end of the single-cycle packet.
3. Read the response header at `(base address + 5)`. The `LENGTH` value specifies the number of words in the response. Proceed to step 4 if the response error code is zero. The response error code is non-zero for unsuccessful commands. Refer to [Error Codes](#) for more information.
 4. When the length of the response header (`t`) is greater than zero (`LENGTH > 1`), read `(base address + 5)` to retrieve the response data. While continuously reading the response data, you must also continuously poll `(base address + 6)` to check the `Response FIFO fill level (n)`. For the final word of the packet, the `Response FIFO fill level (n)` and `EOP` value are expected to be 1 at the same time. You must check for `EOP = 1` before proceeding to read the final word from the response data.

Note: If the response FIFO is empty, the return data is undefined. You must check the `Interrupt status` register to ensure that valid data is available. You must verify that the `Response FIFO fill level (n)` is non-zero before reading the response data.

Ensure that you read or flush out the content in the response FIFO before issuing a new command to the mailbox. Continuously sending commands without reading back the valid data from the response FIFO gradually fills the response FIFO. When the response FIFO overflows the SDM freezes.

If the SDM freezes you must reconfigure the device. The Intel Quartus Prime software supports device reconfiguration starting in version 19.1. For earlier versions of the Intel Quartus Prime software, power cycle the device to recover.

Restrictions

1. You can only issue one request and read back the response before issuing a new request to the Mailbox Client IP.
2. Do not instantiate more than six mailbox clients in your design. For designs requiring more than six mailbox clients, use the Mailbox Client IP to replace the following standalone IP cores:

- Voltage Sensor Intel FPGA IP
- Chip ID Intel FPGA IP
- Serial Flash Mailbox Client Intel FPGA IP
- Temperature Sensor Intel FPGA IP

Attention: Starting in version 19.2 of the Intel Quartus Prime software, a restriction applies to the following mailbox client IPs that access the SDM mailbox over an Avalon Memory-Mapped (Avalon-MM) interface:

- Temperature Sensor
- Voltage Sensor
- Chip ID
- Serial Flash Mailbox Client
- Mailbox Client IP
- Advanced SEU Detection IP
- Partial Reconfiguration IP

If you use the Mailbox IP in designs compiled in Intel Quartus Prime Pro Edition software version 19.2 or later, you must only use SDM firmware starting from version 19.2 or later to configure the FPGA.

1.9. Mailbox Client Intel FPGA IP Core Use Case Examples

The Mailbox Client Intel FPGA IP is an Avalon MM slave component that must connect to an Avalon MM master. The simplest Avalon MM master is the JTAG-to-Avalon Master.

The `rsu1.tcl` script provides examples to perform all the available command functions. You can run the functions available in the `rsu1.tcl` script via System Console of the Intel Quartus Prime software.

The following example shows how to access the quad SPI flash memory. Follow this sequence to prevent errors.

1. `QSPI_OPEN`
2. `QSPI_SET_CS`
3. Any of the following quad SPI operations:
 - `QSPI_READ`
 - `QSPI_WRITE`
 - `QSPI_ERASE`
 - `QSPI_READ_DEVICE_REG`
 - `QSPI_WRITE_DEVICE_REG`
 - `QSPI_SEND_DEVICE_OP`
4. `QSPI_CLOSE`

Related Information

- [Operation Commands](#) on page 15

- [Example of Tcl Script](#)
A Tcl script that implements all the Mailbox Client operations.

1.10. Nios II and Nios V Processors HAL Driver

This section describes the HAL driver for the Mailbox Client Intel FPGA IP core. Intel provides HAL system library drivers that enable you to perform Mailbox Client operations using the HAL API functions and Nios processors. The operations along with their descriptions are listed in the following topics:

- [Operations Commands](#)
- [Mailbox Client HAL API](#)
- [LibRSU HAL API](#)

1.10.1. Mailbox Client HAL API

The Mailbox Client HAL API is available for this controller in the following software files:

- `altera_s10_mailbox_client.h`
- `altera_s10_mailbox_client.c`
- `altera_s10_mailbox_client_flash.h`
- `altera_s10_mailbox_client_flash.c`

These files implement the Mailbox Client core device driver for the HAL system library. The HAL driver provides exclusive functions on QSPI flash device-related operations to simplify your design flow.

To use the HAL API, enable `altera_safeclib` in the *BSP Software Package* from BSP Editor for Intel Quartus Prime Pro Edition software version prior to 21.4. Enter `mailbox_client_open()` function to start the HAL API. Note that the interrupt connection to the processor is necessary to use the HAL API.

The absolute addressing to the quad SPI memory specifies all the offset-related variables. You must complete the quad SPI operation by calling `mailbox_client_flash_open()` before any flash operation, and `mailbox_client_flash_close()` at the end of any flash operation.

Related Information

- [Nios® V Embedded Processor Design Handbook: Nios® V Configuration and Booting Solutions](#)
- [Nios II Software Developer Handbook: Using Flash Device](#)
For more information about using flash devices.
- [Nios II Configuration and Booting Solutions](#)
For more information about booting Nios II from flash.
- [Example of HAL API Application](#)
A .c source code that implements the Mailbox Client Nios II HAL Driver.

1.10.1.1. Mailbox Client Driver API

Table 14. `mailbox_client_open`

Prototype:	<code>mailbox_client_open(const char *name)</code>
Include:	<code><altera_s10_mailbox_client.h></code>
<i>continued...</i>	

Parameter:	<ul style="list-style-type: none"> name – character pointer to name of Mailbox Client Intel FPGA peripheral as registered with the HAL
Return:	Return non-NULL if successful and otherwise return: <ul style="list-style-type: none"> -NULL for Invalid argument. Found no device or wrong input name
Description:	Retrieve a pointer to the Mailbox Client block instance. Search for the list of registered mailbox client instances for the one with the supplied name.

Table 15. mailbox_client_send_cmd

Prototype:	mailbox_client_send_cmd (intel_mailbox_client* fd, alt_u8 id, alt_u32 cmd, alt_u32* arg, int arg_length, int cmd_length, alt_u32* input_data, alt_u32* resp_buf, alt_u32 resp_buf_len) (12)
Include:	<altera_s10_mailbox_client.h>
Parameter:	<ul style="list-style-type: none"> fd – pointer to the flash device structure id – command ID cmd – mailbox client command arg – mailbox Client argument⁽¹³⁾ arg_length – number of arguments cmd_length – command length (arg_length + input_data length) input_data – input data resp_buf – response buffer res_buf_len – response buffer length
Return:	Return 0 if successful and otherwise return: <ul style="list-style-type: none"> error codes for mailbox client in Error Code Responses -EINVAL for Invalid argument -ETIME for polling timeout and skipping the loop after 5 seconds -EBACK_TOUT for back pressure timer interrupt⁽¹⁴⁾ -EEOP_TOUT for end of packet timer interrupt⁽¹⁵⁾ -ECMD_INVLD for invalid command interrupt -ENOBUFFS for the response buffer length is insufficient⁽¹⁶⁾ -ENOSYS for unmatched returned command ID from SDM
Description:	Send commands and data to the Mailbox Client. Reads back the response when data valid interrupt occurs.

Table 16. mailbox_client_flash_open

Prototype:	mailbox_client_flash_open(intel_mailbox_client* fd)
Include:	<altera_s10_mailbox_client_flash.h>
continued...	

⁽¹²⁾ Prior to Intel Quartus Prime Pro Edition software version 21.3, the response buffer length (resp_buf_len) was declared as a pointer rather than an integer.

⁽¹³⁾ Argument represents the parameters needed for mailbox client operation, not including input data.

⁽¹⁴⁾ The recommended error code recovery is the full system reconfiguration.

⁽¹⁵⁾ The recommended error code recovery is to reset the Mailbox Client Intel FPGA IP.

⁽¹⁶⁾ If the response buffer length is insufficient, the HAL API discards the collected data from Mailbox Client Intel FPGA IP and return ENOBUFFS.

Parameter:	<ul style="list-style-type: none"> fd – pointer to the flash device structure
Return:	Return 0 if successful and otherwise return: <ul style="list-style-type: none"> -EINVAL for Invalid argument -ENODEV for unrecognized flash device
Description:	Send command to the mailbox client for QSPI open and QSPI chip select. Provides exclusive access to the quad SPI interface. Determines the QSPI flash size.

Table 17. mailbox_client_flash_close

Prototype:	mailbox_client_flash_close(intel_mailbox_client* fd)
Include:	<altera_s10_mailbox_client_flash.h>
Parameter:	<ul style="list-style-type: none"> fd – pointer to the flash device structure
Return:	Return 0 if successful and otherwise return: <ul style="list-style-type: none"> -EINVAL for Invalid argument
Description:	Send command to the mailbox client for QSPI close. Stops the exclusive access to the quad SPI interface.

Table 18. mailbox_client_flash_get_info

Prototype:	mailbox_client_flash_get_info(intel_mailbox_client* fd, flash_region** info, int* number_of_regions)
Include:	<altera_s10_mailbox_client_flash.h>
Parameter:	<ul style="list-style-type: none"> fd – pointer to the flash device structure info - pointer to the flash region number_of_regions - pointer to the number of regions
Return:	Return 0 if successful and otherwise return: <ul style="list-style-type: none"> -EINVAL for Invalid argument -EIO for possible hardware issue
Description:	Provide information corresponding to nCS0[0]. Returns the flash memory offset, flash memory size, number of flash device, number of sector, and sector size values.

Table 19. mailbox_client_flash_read

Prototype:	mailbox_client_flash_read (intel_mailbox_client* fd, int offset, void* dest_addr, int length)
Include:	<altera_s10_mailbox_client_flash.h>
Parameter:	<ul style="list-style-type: none"> fd – pointer to the flash device structure offset - read flash address (unaligned access) dest_addr - destination buffer (in byte size) length - size of read data (in byte size)
Return:	Return 0 if successful and otherwise return: <ul style="list-style-type: none"> -EINVAL for Invalid argument
Description:	Read data from selected address specified by the length in byte size. Length is a non-zero value.

Table 20. mailbox_client_flash_erase_block

Prototype:	mailbox_client_flash_erase_block (intel_mailbox_client* fd, int block_offset)
Include:	<altera_s10_mailbox_client_flash.h>
<i>continued...</i>	

Parameter:	<ul style="list-style-type: none"> fd – pointer to the flash device structure block_offset - address offset from the start of flash sector specified to be erased
Return:	Return 0 if successful and otherwise return: <ul style="list-style-type: none"> -EINVAL for Invalid argument -EIO for erase failed and sector might be protected
Description:	Erase a single flash sector.

Table 21. mailbox_client_flash_write_block

Prototype:	mailbox_client_flash_write_block (intel_mailbox_client* fd, int block_offset, int data_offset, const void* data, int length)
Include:	<altera_s10_mailbox_client_flash.h>
Parameter:	<ul style="list-style-type: none"> fd – pointer to the flash device structure block_offset - sector address. Starts at the flash sector specified to be written to data_offset - byte offset (unaligned access) of write into memory data - data buffer to be written (in byte size) length - size of write data (in byte size)
Return:	Return 0 if successful and otherwise return: <ul style="list-style-type: none"> -EINVAL for Invalid argument
Description:	Write one block or sector of data into the flash. The write data length cannot split between adjacent sectors. The function assumes the address is empty. You must erase it prior its programming.

Table 22. mailbox_client_flash_write

Prototype:	mailbox_client_flash_write (intel_mailbox_client* fd, int offset, const void* src_addr, int length)
Include:	<altera_s10_mailbox_client_flash.h>
Parameter:	<ul style="list-style-type: none"> fd – pointer to the flash device structure offset - flash address (unaligned access) of write to the flash memory src_addr - source buffer (in byte size) length - size of write data (in byte size)
Return:	Return 0 if successful and otherwise return: <ul style="list-style-type: none"> -EINVAL for Invalid argument
Description:	Program the data into the flash at the selected address. Automatically erase the block as needed before programming.

Table 23. mailbox_client_flash_erase_block

Prototype:	mailbox_client_flash_erase_block(intel_mailbox_client* fd, int block_offset, int block_size)
Include:	<altera_s10_mailbox_client_flash.h>
Parameter:	<ul style="list-style-type: none"> fd – pointer to the flash device structure block_offset – address offset from the start of flash sector specified to be erased block_size – sector of the quad SPI device. Input the following value: <ul style="list-style-type: none"> — 4096 for 4 Kbytes sector size — 32768 for 32 Kbytes sector size — 65536 for 64 Kbytes sector size
Return:	Return 0 for success and otherwise return: <ul style="list-style-type: none"> EINVAL for invalid argument
Description:	Erase a single flash sector depends on block size given.

Table 24. mailbox_client_flash_erase

Prototype:	mailbox_client_flash_erase(intel_mailbox_client* fd, int offset, int length)
Include:	<altera_s10_mailbox_client_flash.h>
Parameter:	<ul style="list-style-type: none"> fd – pointer to the flash device structure offset – address offset from the start of flash sector specified to be erased length – size of erase data in the multiple of 4096 bytes
Return:	Return 0 for success and otherwise return: <ul style="list-style-type: none"> EINVAL for invalid argument
Description:	Erase the flash according to the length given

Related Information

[Error Code Responses](#) on page 24

1.10.2. LibRSU HAL API

The LibRSU HAL API is available for this controller in the following software files:

- librsu.h
- librsu.c
- rsu_client.h
- rsu_client.c

The HAL driver implements the remote system update feature in SDM-based devices which update the Intel FPGA image and perform device reconfiguration remotely. The Nios II and Nios V processors act as the remote system update host controller throughout the whole process.

Note: You may need to modify the string MAILBOX_NAME based on your system.h to the following source codes:

```
altera_s10_mailbox_client_flash_rsu.c
```

```
altera_s10_mailbox_client_rsu.c
```

Note: You need the ZLIB binaries to use the LibRSU HAL API. One of the LibRSU software component, librsu_ll_qspi.c includes the ZLIB libraries under <Nios V processor project directory>/zlib. The following code generates the ZLIB libraries. You can modify the source code to the correct path.

```
wget http://zlib.net/zlib-1.2.12.tar.gz
tar xf zlib-1.2.12.tar.gz
mv zlib-1.2.12/ zlib
```

1.10.2.1. Configuration Parameter

The LibRSU HAL API configuration parameters are stored in Board Support Package (BSP) setting file. You can edit the configuration parameters through the **BSP Driver** tab. If they are not specified, the LibRSU HAL API uses the default value.

Table 25. Configuration Parameter

Variable	Default Value	Description
rsu_protected_slot	-1	Allows protection on a certain slot number. Only slots between 0 and 31 can be protected by this feature. By default (rsu_protected_slot = -1), no slot is protected.
rsu_log_level	3	Allows customization on how much logging information is displayed. The valid inputs are 1,2 and 3. By default, the log level is set as 3 and all logging information is displayed.
enable_spt_checksum	Disable	Enables check and maintenance of the SPT checksum. By default, the SPT checksum feature is disabled.
enable_rsu	Disable	Enables the RSU functions. By default, it is disabled and the Mailbox Client Intel FPGA IP core performs without the RSU functions.
fpga_device • Stratix10	Disable	Allows configuration targeting the selected Intel FPGA devices. By default, the configuration targets Intel Agilex devices, thus the Intel Stratix 10 setting is disabled.

1.10.2.2. Error Codes

In case of success, the LibRSU HAL APIs return the value 0; otherwise, the LibRSU HAL APIs return the negative values shown below.

```
#define ELIB          1 /* Error Library */
#define ECFG          2 /* Error Configuration */
#define ESLOTNUM      3 /* Error Slot Number */
#define EFORMAT       4 /* Error Format */
#define EERASE         5 /* Error Erase */
#define EPROGRAM       6 /* Error Program */
#define ECOMP          7 /* Error Compare */
#define ESIZE          8 /* Error Size */
#define ENAME          9 /* Error Name */
#define EFILEIO       10 /* Error File IO */
#define ECALLBACK     11 /* Error Callback */
#define ELOWLEVEL     12 /* Error Low Level */
#define EWRPROT       13 /* Error Write Protection */
#define EARGS         14 /* Error Argument */
#define ECORRUPTED_CPB 15 /* Error Corrupted CPB */
#define ECORRUPTED_SPT 16 /* Error Corrupted SPT */
```

1.10.2.3. Using LibRSU HAL API without Valid SPT or CPB

You can use the LibRSU HAL APIs when the SPTs or CPBs in flash are corrupted, but with reduced functionality. Intel provides specialized APIs to restore a saved SPT or CPB, and also to create an empty CPB. After the CPBs and SPTs are repaired using these APIs, the full RSU functionality is available.

Table 26. LibRSU HAL API without valid SPT or CPB

Data Corruption	Impact
Single SPT or Single CPB	The librsu_init function restores it from the good copy.
Both SPTs	The librsu_init is still successful (return code 0) but some of the functions returns the error code ECORRUPTED_SPT when called. Both SPTs being corrupted cause librsu_init to not be able to identify the location of the CPBs, and the CPBs is also considered as corrupted.
Both CPBs	The librsu_init is still successful (return code 0) but some of the functions returns the error code ECORRUPTED_CPB when called.

Note: When the processor implements the **Functions**, the processor needs to call the function `librsu_init` at the beginning of the whole application, and ends with `librsu_exit`. This is not necessary for **RSU Client API**.

The table below lists which APIs require valid SPT or CPB.

Table 27. Functions which require valid SPT or CPB

Functions	Requires Valid SPT	Requires Valid CPB
<code>librsu_init</code>		
<code>librsu_exit</code>		
<code>rsu_slot_count</code>	Yes	
<code>rsu_slot_by_name</code>	Yes	
<code>rsu_slot_get_info</code>	Yes	Yes
<code>rsu_slot_size</code>	Yes	
<code>rsu_slot_priority</code>	Yes	Yes
<code>rsu_slot_erase</code>	Yes	Yes
<code>rsu_slot_program_buf</code>	Yes	Yes
<code>rsu_slot_verify_buf</code>	Yes	Yes
<code>rsu_slot_program_callback</code>	Yes	Yes
<code>rsu_slot_verify_callback</code>	Yes	Yes
<code>rsu_slot_copy_to_buf</code>	Yes	Yes
<code>rsu_slot_enable</code>	Yes	Yes
<code>rsu_slot_disable</code>	Yes	Yes
<code>rsu_slot_load</code>	Yes	Yes
<code>rsu_slot_load_factory</code>	Yes	
<code>rsu_slot_rename</code>	Yes	
<code>rsu_slot_delete</code>	Yes	Yes
<code>rsu_slot_create</code>	Yes	
<code>rsu_status_log</code>		
<code>rsu_clear_error_status</code>		
<code>rsu_dcmf_version</code>		
<code>rsu_max_retry</code>		
<code>rsu_dcmf_status</code>		
<code>rsu_create_empty_cpb</code>		
<code>rsu_restore_cpb</code>		
<code>rsu_save_cpb</code>		Yes
<code>rsu_restore_spt</code>		
<code>rsu_save_spt</code>	Yes	
<code>rsu_running_factory</code>	Yes	

1.10.2.4. Data Type

rsu_slot_info - A structure contains slot (SPT entry) information.

```
struct rsu_slot_info {  
    char name[16];  
    alt_u64 offset;  
    int size;  
    int priority;  
};
```

rsu_status_info - A structure contains the RSU status information.

```
struct rsu_status_info {  
    alt_u64 current_image;  
    alt_u64 fail_image;  
    alt_u32 state;  
    alt_u32 version;  
    alt_u32 error_location;  
    alt_u32 error_details;  
    alt_u32 retry_counter;  
};
```

rsu_data_callback - A callback used in a scheme to provide data in blocks as opposed to all at once in a large buffer, which may minimize memory requirements.

```
/*  
 * rsu_data_callback - function pointer type for data source callback  
 */  
typedef int (*rsu_data_callback)(void *buf, int size);
```

1.10.2.5. Functions

Table 28. librsu_init

Prototype:	librsu_init(void)
Parameters:	-
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Initialize the LibRSU HAL API

Table 29. librsu_exit

Prototype:	librsu_exit (void)
Parameters:	-
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Stop the LibRSU HAL API, and close the Mailbox Client Intel FPGA IP if opened.

Table 30. rsu_slot_count

Prototype:	rsu_slot_count (void)
Parameters:	-
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Get the number of defined slots.

⁽¹⁷⁾ Refer to [Error Codes](#) for more information.

Table 31. rsu_slot_by_name

Prototype:	rsu_slot_by_name (char *name)
Parameters:	<ul style="list-style-type: none"> name – name of slot
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Get slot number based on name.

Table 32. rsu_slot_get_info

Prototype:	rsu_slot_get_info (int slot, struct rsu_slot_info *info)
Parameters:	<ul style="list-style-type: none"> slot – slot number info – pointer to slot information structure
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Get the attributes of a slot.

Table 33. rsu_slot_size

Prototype:	rsu_slot_size (int slot)
Parameters:	<ul style="list-style-type: none"> slot – slot number
Return:	Return the size of the slot in bytes for success, or otherwise return error code ⁽¹⁷⁾
Description:	Get the size of a slot.

Table 34. rsu_slot_priority

Prototype:	rsu_slot_priority (int slot)
Parameters:	<ul style="list-style-type: none"> slot – slot number
Return:	Return the priority of the slot for success, or otherwise return error code ⁽¹⁷⁾
Description:	Get the load priority of a slot. Priority of zero means the slot has no priority and is disabled. The slot with priority of one has the highest priority.

Table 35. rsu_slot_erase

Prototype:	rsu_slot_erase (int slot)
Parameters:	slot – slot number
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Erase all data in a slot to prepare for programming. Remove the slot if it is in the CPB.

Table 36. rsu_slot_program_buf

Prototype:	rsu_slot_program_buf (int slot, void *buf, int size)
Parameters:	<ul style="list-style-type: none"> slot – slot number buf – pointer to data buffer size – bytes to read from buffer
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Program a slot using Intel FPGA bitstream data from a buffer and enter slot into CPB as highest priority. The slot must be erased first.

Table 37. rsu_slot_program_callback

Prototype:	rsu_slot_program_callback(int slot, rsu_data_callback callback)
Parameters:	<ul style="list-style-type: none"> slot – slot number callback – callback function to provide input data
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	This function is to program and verify a slot using Intel FPGA config data provided by a callback function. Enter the slot (partition) into the CPB.

Table 38. rsu_slot_program_verify_buf

Prototype:	rsu_slot_verify_buf (int slot, void *buf, int size)
Parameters:	<ul style="list-style-type: none"> slot – slot number buf – pointer to data buffer size – bytes to read from buffer
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Verify FPGA config data in a slot against a buffer.

Table 39. rsu_slot_verify_callback

Prototype:	rsu_slot_verify_callback(int slot, rsu_data_callback callback)
Parameters:	<ul style="list-style-type: none"> slot – slot number callback – callback function to provide input data
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Verify a slot using Intel FPGA bitstream provided by a callback function.

Table 40. rsu_slot_copy_to_buf

Prototype:	rsu_slot_copy_to_buf(int slot, alt_u64 address)
Parameters:	<ul style="list-style-type: none"> slot – slot number address - address which stores the data in quad SPI.
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Read the data in a slot and write to a buffer.

Table 41. rsu_slot_enable

Prototype:	rsu_slot_enable (int slot)
Parameters:	<ul style="list-style-type: none"> slot – slot number
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Set the selected slot as the highest priority.

Table 42. rsu_slot_disable

Prototype:	rsu_slot_disable (int slot)
Parameters:	<ul style="list-style-type: none"> slot – slot number
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Remove the selected slot from the priority scheme, but the slot data remains..

Table 43. rsu_slot_load

Prototype:	rsu_slot_load (int slot)
Parameters:	<ul style="list-style-type: none"> slot – slot number
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Request the selected slot to be loaded immediately.

Table 44. rsu_slot_load_factory

Prototype:	rsu_slot_load_factory (void)
Parameters:	-
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Request the factory image to be loaded immediately.

Table 45. rsu_slot_rename

Prototype:	rsu_slot_rename (int slot, char *name)
Parameters:	<ul style="list-style-type: none"> slot – slot number name – name of slot
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Rename the selected slot.

Table 46. rsu_slot_create

Prototype:	rsu_slot_create (char *name, alt_u64 address, unsigned int size)
Parameters:	<ul style="list-style-type: none"> name – slot name address – slot start address size – slot size
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Create a new slot to the SPT, using unused space.

Table 47. rsu_slot_delete

Prototype:	rsu_slot_delete (int slot)
Parameters:	<ul style="list-style-type: none"> slot – slot number
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Delete the selected slot from SPT.

Table 48. rsu_status_log

Prototype:	rsu_status_log (struct rsu_status_info *info)
Parameters:	<ul style="list-style-type: none"> info – pointer to the rsu_status_info structure to fill in
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Copy firmware status log into the rsu_status_info structure.

Table 49. rsu_clear_error_status

Prototype:	rsu_clear_error_status (void)
Parameters:	-
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Clear the error fields from the current status log.

Table 50. rsu_dcmf_version

Prototype:	rsu_dcmf_version (alt_u32 *version)
Parameters:	<ul style="list-style-type: none"> versions – pointer to where the four DCMF versions are stored
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Retrieve the version of each of the four decision firmware copies in flash.

Table 51. rsu_max_retry

Prototype:	rsu_max_retry (alt_u8 *value)
Parameters:	<ul style="list-style-type: none"> value – pointer to where the max_retry is stored
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Retrieve the max_retry parameter from flash.

Table 52. rsu_dcmf_status

Prototype:	rsu_dcmf_status (int *status)
Parameters:	<ul style="list-style-type: none"> status – pointer to where the status is stored
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Determine whether decision firmware copies are corrupted in flash, with the currently used decision firmware being used as reference. The status is an array of four values, one for each decision firmware copy. A value of 0 means the copy is fine, anything else means the copy is corrupted.

Table 53. rsu_create_empty_cpb

Prototype:	rsu_create_empty_cpb (void)
Parameters:	-
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Create an empty CPB, which includes the CPB header only. All entries are marked as unused.

Table 54. rsu_restore_cpb

Prototype:	rsu_restore_cpb (alt_u64 address)
Parameters:	<ul style="list-style-type: none"> address – address of the buffer from which the CPB is restored
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Restore CPB from a buffer in memory. The buffer must contain the 4096 bytes of CPB data, followed by 4 bytes containing the CRC32 checksum of the data.

Table 55. rsu_save_cpb

Prototype:	rsu_save_cpb (alt_u64 address)
Parameters:	<ul style="list-style-type: none"> address – address of the buffer where CPB is saved to
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Save CPB to a memory buffer. A total of 4100 bytes are written: 4096 bytes for the data, plus 4 bytes with a CRC32 checksum of the data.

Table 56. rsu_restore_spt

Prototype:	rsu_restore_spt (alt_u64 address)
Parameters:	<ul style="list-style-type: none"> address – address of the buffer from which the SPT is restored
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Restore SPT from a buffer in memory. The buffer must contain the 4096 bytes of SPT data, followed by 4 bytes containing the CRC32 checksum of the data.

Table 57. rsu_save_spt

Prototype:	rsu_save_spt (alt_u64 address)
Parameters:	<ul style="list-style-type: none"> address – address where SPT and CRC32 checksum are saved to
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Save SPT to an address in memory. A total of 4100 bytes are written: 4096 bytes for the data, plus 4 bytes with a CRC32 checksum of the data.

Table 58. rsu_running_factory

Prototype:	rsu_running_factory (int *factory)
Parameters:	<ul style="list-style-type: none"> factory – value at this address is set to 1 if factory image is currently running, 0 otherwise
Return:	Return 0 for success, or otherwise return error code ⁽¹⁷⁾
Description:	Determine if current running image is factory image.

1.10.2.6. RSU Client API

Table 59. rsu_client_get_slot_count

Prototype:	rsu_client_get_slot_count(void)
Parameters:	-
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Get the number of predefined slots and display the number of slots.

Table 60. rsu_client_get_slot_by_name

Prototype:	rsu_client_get_slot_by_name (char *name)
Parameters:	<ul style="list-style-type: none"> name - name of slot
Return:	Return 0 for success, or otherwise return error code ⁽¹⁸⁾ .
Description:	Get slot number based on name and display it.

⁽¹⁸⁾ Refer to [Error Codes](#) for more information.

Table 61. rsu_client_list_slot_attribute

Prototype:	rsu_client_list_slot_attribute(int slot_num)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	List the attribute info from the selected slot. The attributes are image name, offset, size and priority level.

Table 62. rsu_client_get_slot_size

Prototype:	rsu_client_get_slot_size(int slot_num)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Get the size for a selected slot and display slot size in bytes.

Table 63. rsu_client_get_priority

Prototype:	rsu_client_get_priority(int slot_num)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Get the priority for a selected slot and display the priority of the selected slot.

Table 64. rsu_client_slot_enable

Prototype:	rsu_client_slot_enable(int slot_num)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Set the selected slot as the highest priority.

Table 65. rsu_client_slot_disable

Prototype:	rsu_client_slot_disable(int slot_num)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Disable selected slot but not erase it.

Table 66. rsu_client_request_slot_be_loaded

Prototype:	rsu_client_request_slot_be_loaded (int slot_num)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Request the selected slot be loaded.

Table 67. rsu_client_erase_image

Prototype:	rsu_client_erase_image(int slot_num)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Erase the application image from a selected slot.

Table 68. rsu_client_request_factory_be_loaded

Prototype:	rsu_client_request_factory_be_loaded(void)
Parameters:	-
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Request the factory image be loaded.

Table 69. rsu_client_add_image

Prototype:	rsu_client_add_image (int slot_num, void *buf, int size)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot buf - pointer to data buffer size - bytes to read from buffer
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Add a new image to the selected slot and make it the highest priority. The slot must be erased first.

Table 70. rsu_client_verify_data

Prototype:	rsu_client_verify_data(int slot_num, void *buf, int size)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot buf - pointer to data buffer size - bytes to read from buffer
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Verify the Intel FPGA bitstream in the selected slot.

Table 71. rsu_client_copy_to_buf

Prototype:	rsu_client_copy_to_buf(int slot_num, alt_u64 address)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot address - the address which saves data
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Read the data from a slot then write to an address.

Table 72. rsu_client_status_log

Prototype:	rsu_client_status_log(void)
Parameters:	-
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Print the status log.

Table 73. rsu_client_clear_error_status

Prototype:	rsu_client_clear_error_status(void)
Parameters:	-
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Clear errors from the current RSU status.

Table 74. rsu_client_display_dcmf_version

Prototype:	rsu_client_display_dcmf_version(void)
Parameters:	-
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Display the four decision firmware versions.

Table 75. rsu_client_display_dcmf_status

Prototype:	rsu_client_display_dcmf_status(void)
Parameters:	-
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Display the status for four decision firmware.

Table 76. rsu_client_display_max_retry

Prototype:	rsu_client_display_max_retry(void)
Parameters:	-
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Display the max retry parameter

Table 77. rsu_client_slot_create

Prototype:	rsu_client_slot_create(char *slot_name, alt_u64 slot_address, unsigned int slot_size)
Parameters:	<ul style="list-style-type: none"> slot_name - the selected slot slot_address - start address of slot size - size of slot
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Create a new slot in the SPT, using unused space.

Table 78. rsu_client_slot_rename

Prototype:	rsu_client_slot_rename (int slot, char *name)
Parameters:	-
Return:	Return 0 for success, or otherwise return error code ⁽¹⁸⁾ .
Description:	Rename the selected slot and display it.

Table 79. rsu_client_slot_delete

Prototype:	rsu_client_slot_delete(int slot_num)
Parameters:	<ul style="list-style-type: none"> slot_num - the selected slot
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Delete selected slot, freeing up allocated space.

Table 80. rsu_client_restore_spt

Prototype:	rsu_client_restore_spt (alt_u64 address)
Parameters:	<ul style="list-style-type: none"> address - the address which restores SPT
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Restore the SPT from an address.

Table 81. rsu_client_save_spt

Prototype:	rsu_client_save_spt (alt_u64 address)
Parameters:	<ul style="list-style-type: none"> address - the address which saves SPT
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Save the working SPT to an address.

Table 82. rsu_client_create_empty_cpb

Prototype:	rsu_client_create_empty_cpb(void)
Parameters:	-
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Create an empty CPB, which includes the CPB header only. All entries are marked as unused.

Table 83. rsu_client_restore_cpb

Prototype:	rsu_client_restore_cpb (alt_u64 address)
Parameters:	<ul style="list-style-type: none"> address - the address which restores CPB
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Restore the CPB from an address.

Table 84. rsu_client_save_cpb

Prototype:	rsu_client_save_cpb(alt_u64 address)
Parameters:	<ul style="list-style-type: none"> address - the address which saves CPB
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Save the working CPB to an address.

Table 85. **rsu_client_check_running_factory**

Prototype:	rsu_client_check_running_factory(void)
Parameters:	-
Return:	Return 0 for success, or otherwise return -1 on error.
Description:	Check if currently running image is the factory image.

1.11. Mailbox Client Intel FPGA IP User Guide Archives

For the latest and previous versions of this user guide, refer to [Mailbox Client Intel FPGA IP User Guide](#). If an IP or software version is not listed, the user guide for the previous IP or software version applies.

IP versions are the same as the Intel Quartus Prime Design Suite software versions up to v19.1. From Intel Quartus Prime Design Suite software version 19.2 or later, IP cores have a new IP versioning scheme.

1.12. Document Revision History for the Mailbox Client Intel FPGA IP User Guide

Document Version	Intel Quartus Prime Version	Changes
2022.12.19	22.4	<ul style="list-style-type: none"> Added GET_CONFIGURATION_TIME and QSPI_READ_SHA command in the <i>Command List and Description</i> table. Updated default value and description for <i>rsu_protected_slot</i> in the <i>Configuration Parameter</i> table.
2022.09.26	22.3	<ul style="list-style-type: none"> Updated the GET_VOLTAGE command row in the <i>Command List and Description</i> table. Revised <i>Using the Mailbox Client Intel FPGA IP</i>. Removed the "Wait 10 ms between back to back commands to the SDM mailbox" in Restrictions. Added a note to Table: <i>Device Family Support</i>. Revised the description for LENGTH header in Table: <i>Command and Response Header Description</i>. Revised note about enabled bits in <i>Interrupt Enable Register</i>. Added reference to <i>Intel Agilex Device Security User Guide</i> in Enabling Cryptographic Services. Revised QSPI_SET_CS command description in the <i>Command List and Description</i> table. Edited the title for <i>Nios II HAL Driver</i> to <i>Nios II and Nios V Processors Hal Driver</i> <ul style="list-style-type: none"> Added text to specify the use of Intel Quartus Prime Pro Edition software version prior 21.4. Added the following topics: <ul style="list-style-type: none"> <i>Mailbox Client HAL API</i> <i>LibRSU HAL API</i> <i>Configuration Parameter</i> <i>Error Codes</i> <i>Using LibRSU HAL API without Valid SPT or CPB</i> <i>Data Type</i> <i>Functions</i> <i>RSU Client API</i>
2022.04.04	22.1	<ul style="list-style-type: none"> Updated instances of AXI target to AXI manager. Updated crypto service-specific parameter name from HAS_OFFLOAD to Enable Crypto Service. Added bit 8 and bit 9 in the following tables: <ul style="list-style-type: none"> <i>Interrupt Enable Register</i> <i>Interrupt Status Register</i> Updated the <i>Command List and Description</i> table. <ul style="list-style-type: none"> Updated pin status description for the CONFIG_STATUS command. Removed the REBOOT_HPS command.
2021.11.10	21.3	<p>Made the following changes:</p> <ul style="list-style-type: none"> Updated the device family support for Intel Agilex devices. Added new section describing support for cryptographic services. Revised <i>Interrupt Enable Register</i> table. Added new registers: <ul style="list-style-type: none"> EN_CRYPTO_MEMORY_TIMEOUT EN_CRYPTO_ERROR_RECOVERY_PROGRESS

continued...

Document Version	Intel Quartus Prime Version	Changes
		<ul style="list-style-type: none"> Revised <i>Interrupt Status Register</i> table. Added new interrupts: <ul style="list-style-type: none"> CRYPTO_MEMORY_TIMEOUT CRYPTO_ERROR_RECOVERY_PROGRESS Revised <i>Command List and Description</i> table. Updated description for: <ul style="list-style-type: none"> CONFIG_STATUS RSU_STATUS Updated the mailbox_client_send_cmd command in the <i>Driver API</i> section. <ul style="list-style-type: none"> Revised response buffer length declaration from a pointer (alt_u32* resp_buf_len) to an integer (alt_u32 resp_buf_len). Added an ENOBUFS-related footnote.
2021.06.21	21.2	<p>Made the following changes:</p> <ul style="list-style-type: none"> Revised <i>Interrupt Enable Register</i>. Added note about enable bits. Revised <i>Command List and Description</i> table. Updated description for: <ul style="list-style-type: none"> RSU_STATUS QSPI_OPEN QSPI_SET_CS QSPI_ERASE Revised Read Command Description in the <i>Using the Mailbox Client Intel FPGA IP</i>. Added attention note about accessing SDM over an Avalon memory-mapped interface. Revised <i>Nios II HAL Driver</i>. Added text about absolute addressing to the quad SPI. Added mailbox_client_flash_get_info operation in the <i>Driver API</i> section. Removed <i>Driver API Application</i> topic. The content was moved to a file referenced in the <i>Driver API</i> section. Updated <i>Appendix: CONFIG_STATUS and RSU_STATUS Error Code Descriptions</i>. Added 0xD00D - 0xD013 minor error codes descriptions.
2021.03.29	21.1	<p>Made the following changes:</p> <ul style="list-style-type: none"> Revised the <i>Flow Chart for Response Packet</i> figure and the <i>Read Command Description</i> section. Revised RSU_IMAGE_UPDATE description in the <i>Command List and Description</i> table. Added new topics: <ul style="list-style-type: none"> Nios II HAL Driver Driver API Driver API Application Restructured <i>Operation Commands</i>. Moved major and minor error code descriptions for the CONFIG_STATUS and RSU_STATUS commands to the <i>Appendix: CONFIG_STATUS and RSU_STATUS Error Code Descriptions</i>.
2020.12.14	20.4	<p>Made the following changes:</p> <ul style="list-style-type: none"> Revised block diagram description in the <i>Mailbox Client Intel FPGA IP User Guide</i> topic. Updated the <i>Mailbox Client Intel FPGA IP System Block Diagram</i> figure. The figure depicts various ways to communicate with Mailbox Client IP. Added important note about resetting QSPI flash in the <i>Operation Commands</i> topic.
continued...		

Document Version	Intel Quartus Prime Version	Changes
		<ul style="list-style-type: none"> Updated the <i>Command List and Description</i> table: <ul style="list-style-type: none"> Revised GET_TEMPERATURE command description. Clarified difference between Intel Stratix 10 and devices. Revised RSU_IMAGE_UPDATE command description. <ul style="list-style-type: none"> Added text about resetting QSPI flash. Added text describing behavior between the external host and FPGA. Removed text: <i>Returns a non-zero response if the device is already processing a configuration command.</i> Updated QSPI_WRITE and QSPI_READ descriptions to specify that the maximum transfer size is 4 kilobytes or 1024 words. Corrected response length from 1 to 0 for the QSPI_OPEN, QSPI_CLOSE and QSPI_SET_CS command. Revised QSPI_OPEN, QSPI_WRITE, QSPI_READ_DEVICE_REG, and QSPI_WRITE_DEVICE_REG descriptions. Added a new command: REBOOT_HPS. Added new topic: Error Code Recovery. Revised <i>Timer Registers</i> topic. Added footnotes and updated registers description. Updated <i>Flow Chart for Reading Response Packet</i> figure.
2020.10.05	20.3	<p>Made the following changes:</p> <ul style="list-style-type: none"> Revised GET_TEMPERATURE command description for Intel Agilex devices in the <i>Command List and Description</i> table. Added recommendation about the reset synchronizer in the <i>Mailbox Client FPGA Core Signals</i> section. Updated the <i>Error Codes</i> table. Added new error code responses: <ul style="list-style-type: none"> HW_ERROR COMMAND_SPECIFIC_ERROR
2020.06.30	20.2	<p>Made the following changes:</p> <ul style="list-style-type: none"> Revised LENGTH and Command Code/Error Code descriptions in the <i>Command and Response Header Description</i> table. Revised GET_TEMPERATURE command description in the <i>Command List and Description</i> table. Removed UNKNOWN_BR command from the <i>Error Codes</i> table. Added new timer feature to handle the error detection for the incomplete transaction timeout error and the SDM backpressure timeout fatal error. Added support for an EOP_TIMEOUT interrupt which indicates that the full command did not include the EOP. Added support for a BACKPRESSURE_TIMEOUT interrupt which indicates that an error within the SDM occurred. Removed SD/MMC text from the CLIENT_ID_NO_MATCH description in the <i>Error Codes</i> table. Updated write and read command descriptions in the <i>Using the Mailbox Client Intel FPGA IP</i> section.
2020.04.13	20.1	Made the following changes:

continued...

Document Version	Intel Quartus Prime Version	Changes
		<ul style="list-style-type: none"> Added the following restriction to the definition of QSPI_SET_CS: <i>Access to the QSPI flash memory devices using SDM_IO pins is only available for the AS x4 configuration scheme, JTAG configuration, and a design compiled for ASx4 configuration. For the Avalon ST configuration scheme, you must connect QSPI flash memories to GPIO pins.</i> Added the following text to the definition of the Failing image field of the RSU_STATUS command: <ul style="list-style-type: none"> <i>Note:</i> A rising edge on nCONFIG to reconfigure from ASx4, does not clear this field. Information about failing image only updates when the Mailbox Client receives a new RSU_IMAGE_UPDATE command and successfully configures from the update image. Added RSU_NOTIFY command in the <i>Command List and Description</i> table. Revised the <i>Flow Chart for Writing Command Packet</i> and <i>Flow Chart for Reading Response Packet</i> to include the correct sequence for writing commands into a command FIFO and reading response packets from a response FIFO. Updated corresponding <i>Write Command Description</i> and <i>Read Command Description</i> sections.
2020.03.17	19.3	<p>Made the following changes:</p> <ul style="list-style-type: none"> Updated the <i>Error Codes</i> table: <ul style="list-style-type: none"> Renamed INVALID_COMMAND_PARAMETERS to INVALID_LENGTH. Changed COMMAND_INVALID_ON_SOURCE hex value from 5 to 6. Changed CLIENT_ID_NO_MATCH hex value from 6 to 8. Changed INVALID_ADDRESS hex value from 7 to 9. Added AUTHENTICATION_FAIL command. Changed TIMEOUT hex value from 8 to B. Changed HW_NOT_READY hex value from 9 to C.
2019.09.30	19.3	<p>Made the following changes:</p> <ul style="list-style-type: none"> Added device support for the Intel Agilex device. Added support for a COMMAND_INVALID interrupt which indicates the command length specified in the header does not match the actual command sent. Changed name of the IP from Mailbox Client Intel Stratix 10 FPGA IP to Mailbox Client Intel FPGA IP. Revised introduction including the <i>Figure 1: Mailbox Client Intel FPGA IP System Block Diagram</i>. Revised the <i>Flow Chart for Writing Command Packet</i> and <i>Flow Chart for Reading Response Packet</i> to include logic to handle multiple word commands and responses. Changed references to names of all mailbox client IPs. The mailbox clients IP no longer include the Intel Stratix 10 FPGA in their names. Added reference to <i>AN 891: Using the Reset Release Intel FPGA IP</i>. Added reference to the <i>Intel Agilex Power Management User Guide</i>. Updated the description of the GET_TEMPERATURE command to say the mask argument is optional. When omitted, the command returns the temperature for sensor 0. Updated the RSU_STATUS command to say the highest priority failing image, not the last failing image. The error information is for the first failing image which is the highest priority failing image. Added descriptions for CONFIG_STATUS and RSU_STATUS major and minor error codes.

Document Version	Intel Quartus Prime Version	Changes
		<ul style="list-style-type: none"> Added HPS_COLDRESET and HPS_WARMRESET to the list of soft functions for the CONFIG_STATUS command. Added <i>Mailbox Client Intel FPGA IP User Guide Archives</i> topic. Added the following Intel FPGA IPs to the list of IPs that require proper use of the Command and Command Last registers: <ul style="list-style-type: none"> Advanced SEU Detection Intel IP Partial Reconfiguration Controller Intel IP Partial Reconfiguration External Configuration Controller Intel FPGA IP Edited entire user guide for clarity and style.

Document Version	Changes
2019.04.19	<ul style="list-style-type: none"> Updated the <i>Feature Description</i> topic. Added a note to Figure: <i>Command and Response Header Format</i>. Updated Table: <i>Mailbox Client Intel Stratix 10 FPGA IP Command and Response Header Description</i> to update the description for bit[11] of the command and response header. Updated Table: <i>Command List and Description</i> to update the descriptions for CONFIG_STATUS and RSU_STATUS. Renamed topic title <i>Mailbox Client Intel Stratix 10 FPGA IP Core Avalon-MM Interface</i> to <i>Mailbox Client Intel Stratix 10 FPGA IP Core Signals</i>. Renamed table title <i>Mailbox Client Intel Stratix 10 FPGA IP Core Avalon-MM Interface</i> to <i>Mailbox Client Intel Stratix 10 FPGA IP Core Signal Description</i>. Updated Table: <i>Mailbox Client Intel Stratix 10 FPGA IP Core Signal Description</i> to include information on clock and reset signals. Updated Table: <i>Mailbox Client Intel Stratix 10 FPGA IP Core Avalon-Memory Map</i> to remove urgent command and urgent FIFO empty space. Updated the <i>Using the Mailbox Client Intel Stratix 10 FPGA IP Core</i> topic: <ul style="list-style-type: none"> Added new Figures: <i>Flow Chart for Writing Command Packet</i> and <i>Flow Chart for Reading Response Packet</i>. Added a new section—<i>Restrictions</i>. Updated the description in the <i>Writing Command Packet</i> section. Updated the <i>Mailbox Client Intel Stratix 10 FPGA IP Core Use Case Examples</i> topic. Made editorial updates throughout the document.
2019.03.14	<ul style="list-style-type: none"> Updated the <i>Mailbox Client Intel Stratix 10 FPGA IP Core User Guide</i> topic. Updated Figure: <i>Mailbox Client Intel Stratix 10 FPGA IP Core and System Block Diagram</i>. Updated Table: <i>Command List and Description</i>: <ul style="list-style-type: none"> Updated the column name <i>Number of Commands</i> to <i>Command Length</i>. Updated the column name <i>Number of Responses</i> to <i>Respond Length</i>. Corrected the description for QSPI_READ, QSPI_WRITE, and QSPI_ERASE.
2019.02.25	<ul style="list-style-type: none"> Updated the description in the <i>Mailbox Client Intel Stratix 10 FPGA IP Core User Guide</i> topic. Updated Figure: <i>Mailbox Client Intel Stratix 10 FPGA IP Core User Guide</i>. Updated Table: <i>Interrupt Status Register</i> to update the description for DATA_VALID. Renamed the following topic titles: <ul style="list-style-type: none"> <i>Commands and Error Codes</i> to <i>Commands and Responses</i> <i>Commands</i> to <i>Operation Commands</i>. Updated Table: <i>Mailbox Client Intel Stratix 10 FPGA IP Command and Response Header Description</i> to update the descriptions for Length and Command Code/Error Code. Updated Table: <i>Command List and Description</i>: <ul style="list-style-type: none"> Updated the number of responses and description for CONFIG_STATUS. Updated the number of responses for RSU_STATUS. Updated the descriptions for QSPI_READ, QSPI_WRITE, and QSPI_ERASE.
continued...	

Document Version	Changes
	<ul style="list-style-type: none"> Updated Table: <i>Mailbox Client Intel Stratix 10 FPGA IP Error Code Responses and Description</i> to update the description for UNKNOWN_BR. Updated the <i>Writing Command Packet</i> and <i>Reading Command Packet</i> sections in the <i>Using the Mailbox Client Intel Stratix 10 FPGA IP Core</i> topic. Updated the <i>Mailbox Client Intel Stratix 10 FPGA IP Core Use Case Examples</i> topic. Removed the following topics: <ul style="list-style-type: none"> Example 1: <i>Reading Intel eASIC™ N5X IDCODE and Voltage</i> Example 2: <i>Read and Write EPCQ-L or QSPI Devices</i>
2018.10.15	<ul style="list-style-type: none"> Updated Table: <i>Command List and Description</i> to include the following commands: <ul style="list-style-type: none"> Updated the descriptions for GET_TEMPERATURE. Added new commands: <ul style="list-style-type: none"> RSU_IMAGE_UPDATE CONFIG_STATUS RSU_STATUS Removed the command GET_DESIGNHASH. Updated Table: <i>Error Code Responses and Description</i> to update the value of the following error code responses: <ul style="list-style-type: none"> NOT_CONFIGURED ALT_SDM_MBOX_RESP_DEVICE_BUSY ALT_SDM_MBOX_RESP_NO_VALID_RESP_AVAILABLE ALT_SDM_MBOX_RESP_ERROR Added a note to Figure: <i>Mailbox Client Intel Stratix 10 FPGA IP Core Block Diagram</i>. Made minor editorial updates.
2018.02.14	Initial release.

2. Appendix: CONFIG_STATUS and RSU_STATUS Error Code Descriptions

The CONFIG_STATUS and RSU_STATUS commands allow you to check the current configuration status or the current remote system upgrade status. The commands return 0 when there is no error. If the operation was unsuccessful, the command returns at least one error code described in the table below.

The Error Code field in the command header provides details of major and minor error codes. For more information about specific bits representing the major and minor error codes in the CONFIG_STATUS and RSU_STATUS command, refer to the *Command List and Description* table.

Figure 6. Command Header Format

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reserved								ID	0	Length											0	Command/Error Code									

Table 86. CONFIG_STATUS and RSU_STATUS Major Error Code Descriptions

Table displays the major error codes and their descriptions received through the Error Code field.

Major Error Code	Error Type	Description
0xF001	ERR_BITSTREAM_ERROR	Indicates a bitstream error.
0xF002	ERR_EXT_HW_ACCESS_FAIL	Indicates an external hardware access error.
0xF003	ERR_BITSTREAM_CORRUPTION	Indicates a bitstream corruption error.
0xF004	ERR_INTERNAL_ERROR	Indicates an internal error due to misunderstood bitstream element.
0xF005	ERR_DEVICE_ERROR	Indicates a device operation error.
0xF006	ERR_HPS_WDT	Indicates the HPS watchdog timeout failure. Ensure that your design resets the watchdog timer correctly.
0xF007	ERR_INTERNAL_UNKNOWN_ERROR	Indicates an internal device error due to an unknown task.
0xF008	ERR_SYSTEM_INIT_ERROR	Indicates an error due to the system initialization failure.
0xF009	ERR_DECRYPTION_ERROR	Indicates an error due to a bitstream decryption.

Table 87. CONFIG_STATUS and RSU_STATUS Minor Error Code Descriptions

Table displays the minor error codes and their descriptions received through the Error Code field.

Minor Error Code	Description
0x0001	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0x0002	Indicates a QSPI-related error due to the following conditions: <ul style="list-style-type: none"> An incorrect connection between the QSPI device and the FPGA device. QSPI device is in reset mode.
0x0003	Indicates a configuration error due to a corrupted bitstream. Ensure a valid connection between the device and the configuration source.
0x0004	Indicates a configuration error due to an incompatible bitstream with the device. Ensure the usage of a correct bitstream.
0x0005 - 0x0007	Indicates a configuration error due to a corrupted bitstream. Ensure a valid connection between the device and the configuration source.
0x0008	Indicates an error during configuration.
0x0009 - 0x0014	Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0x0015	Indicates a bitstream authentication error during configuration. Ensure you signed the bitstream with the correct signing key.
0x0016	Indicates a configuration error due to a corrupted bitstream. Ensure a valid connection between the device and the configuration source.
0x0017 - 0x0024	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0x0025	Indicates a firmware transitional error during configuration. Ensure the device firmware and the current Intel Quartus Prime software version are compatible. To recover, remove the current running firmware from the device.
0x0026 - 0x0031	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0x0032	Indicates a PMBUS error during configuration due to an incorrect VID setting in the Intel Quartus Prime project. The target device failed to communicate with a smart regulator or PMBUS master on a board.
0x0033	Indicates a PMBUS error during configuration due to an incorrect VID setting in the Intel Quartus Prime project. The target device failed to communicate with a smart regulator or PMBUS master on a board.
0x0034 - 0x0035	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0x0036	Reserved
0x0037 - 0x0041	Indicates a configuration error due to a corrupted bitstream. Ensure a valid connection between the device and the configuration source.
0x0042	Indicates an incompatible partial reconfiguration (PR) bitstream. Ensure you use the PR bitstream compatible with the current base design.
0x0043 - 0x0049	Reserved
0x004A- 0x004F	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
continued...	

Minor Error Code	Description
0x0050	Indicates an error during configuration due to a device mismatch between the Intel Quartus Prime project and the target device.
0x0051 - 0x0052	Indicates a configuration error due to a corrupted bitstream. Ensure a valid connection between the device and the configuration source.
0x0053 - 0x0054	Indicates a bitstream decryption error due to a corrupted bitstream. Ensure a valid connection between the device and the configuration source.
0x0055	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0x0056 - 0x0058	Indicates a configuration error due to a corrupted bitstream. Ensure a valid connection between the device and the configuration source.
0x0059 - 0x0061	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0x0062	Indicates a configuration error due to a corrupted bitstream. Ensure a valid connection between the device and the configuration source.
0x0063	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0x0064 - 0x0066	Indicates a configuration error due to a corrupted bitstream. Ensure a valid connection between the device and the configuration source.
0x0067	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0x0068	Indicates that the detected bitstream is incompatible due to the security enabled settings. You cannot use the bitstream from an advanced security-enabled devices on a non-advanced security-enabled device. Ensure the Intel Quartus Prime project device matches the target device.
0x0069	Indicates that the detected bitstream is invalid due to reached maximum number of supported partial reconfiguration (PR) authentication. The bitstream supports up to 32 PR partitions.
0x006A - 0x0075	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0xC001	Indicates a firmware error during reconfiguration. Check the latest Intel Quartus Prime software release for possible fixes.
0xC002 - 0xC006	Indicates a bitstream error during reconfiguration. Check the bitstream validity. If corrupted, regenerate and configure bitstream again.
0xC007	Indicates an error due to transitioning to other firmware version or application image. Ensure the bitstream is valid. If corrupted, regenerate and reprogram QSPI flash with RSU image via the JTAG interface.
0xC008	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0xC009	Indicates a bitstream authentication error during reconfiguration. Ensure you use the correct signing key when signing the bitstream.
0xC00A	Indicates an error during configuration. To recover, power cycle the device.
0xC00B	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
continued...	

Minor Error Code	Description
0xC00D	Indicates a hardware error during reconfiguration. To recover, power cycle the device.
0xC00E	Indicates a bitstream error during reconfiguration. Check the bitstream validity. If corrupted, regenerate and configure bitstream again.
0xC00F	Indicates an error when accessing the QSPI flash memory. Reconfigure device by toggling nCONFIG pin signal or power cycle the device.
0xD001	Indicates an authentication failure for the firmware. Ensure you use the correct firmware signing key when enabling firmware co-signing feature.
0xD002	Indicates an authentication failure for the design. Ensure you sign the bitstream with a correct signing key.
0xD003	Indicates an error when loading the application image from QSPI flash. Ensure the application image located at the correct address in QSPI flash.
0xD004	Indicates an error when parsing the RSU CPB block. RSU CPB block is corrupted. To recover, toggle the nCONFIG pin to restart the RSU. If the issue persists, reprogram the RSU CPB block data.
0xD005	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0xD006	Failed to load factory image. Ensure the factory image is valid. If corrupted, regenerate and reprogram the factory image in the flash. When authentication is enabled, ensure you use the correct signing key.
0xD007	Indicates an error when loading the application image. Check the application image validity. If corrupted, regenerate and reprogram again the application image in the flash.
0xD008	Indicates an error during factory image update in flash memory. Check the factory update image validity. If corrupted, regenerate and reprogram again the factory updated image in the flash.
0xD009	Indicates an error during a decision firmware update in flash memory. Check the factory update image validity. If corrupted, regenerate and reprogram again the factory updated image. Ensure you use the correct signing key when authentication is enabled.
0xD00A	Indicates an error during a decision firmware update in flash memory. Flash memory may have reset during the update process. To recover, toggle the nCONFIG signal to restart the update process.
0xD00B	Indicates an error during a decision firmware update in flash memory. Flash memory may have reset during the update process. To recover, toggle the nCONFIG signal to restart the update process.
0xD00C	Indicates an error during RSU CPB table update in flash. RSU CPB block data may be corrupted. To recover, regenerate the RSU image containing the updated factory image and program it to flash.
0xD00D	Indicates an error during combined application image update in flash memory. Check the combined application image validity. If corrupted, regenerate and reprogram again the combined application update image in the flash.
0xD00E	Indicates an error during a decision firmware update in flash memory. Flash memory may have reset during the update process. To recover, toggle the nCONFIG signal to restart the update process.
0xD00F	Indicates an error when parsing the DCIO section. The DCIO section may be corrupted. To recover, regenerate the RSU image containing new decision firmware or DCIO section and program it to flash.
0xD010	Indicates an error in the RSU CPB0 table. The CPB0 table may be corrupted. To recover the CPB0, regenerate the RSU image containing new decision firmware and program it to flash.
continued...	

Minor Error Code	Description
0xD011	Indicates an error in the RSU CPB0 and CPB1 tables. Both CPB0 and CPB1 table entries may be corrupted. To recover CPB0 and CPB1, regenerate the RSU image containing new decision firmware and program it to flash.
0xD012	Indicates a successful non-JTAG device provisioning. The successful decision firmware loads the highest priority application image.
0xD013	Indicates an error during the device provisioning.
0xE001	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0xE002	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0xE003 - 0xE008	Reserved
0xE009 - 0xE00B	Indicates an error during configuration. Refer to the <i>Configuration User Guide</i> for details on the debug guidelines. Check the latest Intel Quartus Prime software release for possible fixes.
0xE00C	Reserved

Related Information

- [Intel Stratix 10 Configuration User Guide: Debugging Guide](#)
- [Intel Agilex Configuration User Guide: Debugging Guide](#)