

## PREFACE

Thank you for selecting a Hero MotoCorp **XTREME 160R PROGRAMMED FI**. We wish you many miles of continued riding pleasure in the years ahead.

We at Hero MotoCorp, are committed to demonstrate excellence in our environment performance on a continual basis, as an intrinsic element of our corporate philosophy. To achieve this we commit ourselves to continue product innovations to improve environment compatibility, comply with all applicable legislation including environment legislation and strengthen the green supply chain.

Your vehicle is conforming to latest (Bharat stage-VI norms) regulation for emission, safety & noise levels. We are also using non asbestos brake shoes/pads and engine gaskets which are environment friendly in nature.

This vehicle is fitted with a lighting feature known as “Automatic Headlamp ON”. The feature is mandated for all 2 Wheelers by Ministry of Road Transport & Highways (Government of India) vide notification GSR 188 (E) dated 22nd February 2016. This feature helps in conspicuity for improving rider safety. The headlamp of this vehicle will always be lit ON when the engine gets ON.

This booklet is your guide to the basic operation and maintenance of your new Hero MotoCorp **XTREME 160R PROGRAMMED FI**. Please take time to read it carefully. As with any fine machine, proper care and maintenance are essential for trouble-free operation and optimum performance.

Your Authorised Hero MotoCorp dealer will be glad to provide further information or assistance and is equipped to handle your future service needs.

Let us make this world a safer, healthier and more environment friendly place.



## NOTE

**ALL INFORMATION, ILLUSTRATION, PHOTOGRAPH, DIRECTIONS, SPECIFICATIONS AND OTHER CONTENTS COVERED IN THIS OWNER'S MANUAL ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF ITS PRINTING APPROVAL, AND THE ACCURACY OR CORRECTNESS OF THE SAME IS NOT UNDERTAKEN OR GUARANTEED.**

Hero MotoCorp Ltd **RESERVES THE RIGHT TO MAKE CHANGES IN ITS CONTENTS AT ANY TIME WITHOUT NOTICE AND/OR INCURRING ANY OBLIGATION, WHATSOEVER. NO ONE IS ALLOWED TO REPRODUCE ANY PART OF THIS PUBLICATION WITHOUT OBTAINING PRIOR WRITTEN PERMISSION FROM** Hero MotoCorp Ltd.

**ACCESSORIES SHOWN MAY NOT BE THE PART OF STANDARD FITMENT. IT IS OUR ENDEAVOUR TO CONSTANTLY IMPROVE OUR PRODUCTS. THIS COULD LEAD TO CHANGE IN PRODUCT SPECIFICATIONS WITHOUT NOTICE.** Hero MotoCorp Ltd **'XTREME 160R PROGRAMMED FI' COMPLIES WITH THE LATEST EMISSION NORMS.**

### **ADDENDUM**

**As per Ministry of Road Transport & Highways (Government of India) vide Notification G.S.R. 540(E), Hemostatic agent is excluded from first aid kit in reduction from existing kit effective from 31st August 2020.**

# CONTENTS

	Pg. No.		Pg. No.
VEHICLE IDENTIFICATION	1	MAINTENANCE SCHEDULE	33
VEHICLE VIEWS	2	SPARK PLUG INSPECTION	36
VEHICLE SPECIFICATION	7	ENGINE OIL	37
VEHICLE SAFETY	9	OIL FILTER SCREEN & CENTRIFUGAL FILTER	
• Important safety information	9	CLEANING	38
• Protective apparel	10	AIR CLEANER	39
• Accessories & modifications	11	VALVE CLEARANCE ADJUSTMENT	41
ANTI-THEFT TIPS	11	CLUTCH LEVER FREE PLAY	42
SAFE RIDING TIPS	12	THROTTLE OPERATION	43
TIPS FOR HEALTHY ENVIRONMENT	13	DRIVE CHAIN SLACKNESS	44
PART FUNCTION	14	DRIVE CHAIN SLIDER INSPECTION	47
• Ignition switch	14	BRAKES	47
• Instruments and indicators	15	SUSPENSION	51
• LCD panel	17	WHEEL	52
FEATURES	20	MAIN/SIDE STAND LUBRICATION	55
HANDLEBAR SWITCHES CONTROL	20	TUBELESS TYRES	55
ABS INDICATOR	22	NUT, BOLTS & FASTENERS	58
SIDE STAND INDICATOR/SWITCH	22	BATTERY	58
FUEL TANK	24	FUSE REPLACEMENT	60
SEAT LOCK	25	STOP LAMP SWITCH	61
PRE-RIDE INSPECTION	25	HEADLAMP FOCUS ADJUSTMENT	62
STARTING THE ENGINE	26	CATALYTIC CONVERTER	62
RIDING	28	EVAPORATIVE EMISSION CONTROL SYSTEM	63
BRAKING	28	POLISHING OF VEHICLE	63
PARKING	30	BASIC TROUBLESHOOTING	64
TOOL KIT/FIRST AID KIT	30	ROAD SIGNS	67
CLEANING AND WASHING OF VEHICLE	31	WARRANTY	
MAINTENANCE	31	HERO GENUINE PARTS	
SAFETY PRECAUTION	32	ZONAL/REGIONAL/AREA OFFICES	



## VEHICLE IDENTIFICATION



### Vehicle Identification Number (VIN)

Location: Stamped on the right side of the steering head tube.

### Engine No.

Location: Stamped on the lower side of the left crankcase.

**VIN: MBLKCU02#####**

MBL	KCU02	#	#	#	#	#####
Manufacturer code	Vehicle Description	Check Digit	Model Year	Plant Code	Month of Manufacturing	Production Serial Number

**Engine No.: KC01AA#####**

KC01AA	#	#	#	#####
Engine Description	Year of Manufacturing	Assembly Plant	Month of Manufacturing	Serial Number

**Model: XTREME160R PROGRAMMED FI**


Variants	VIN	Engine
Electric start/Front disc with ABS/Rear disc/Cast wheel	KCU02	KC01AA
Electric start/Front disc with ABS/Rear drum/Cast wheel	KCU03	KC01AA

### VIN and Engine No. may be required:

- During registration of the vehicle.
- For dealing with legal & insurance departments.

## VEHICLE VIEWS

### FRONT VIEW




1. Front fender
2. Front right turn signal lamp
3. Right position lamp
4. Front visor

5. Headlamp (Low beam)
6. Left position lamp
7. Front left turn signal lamp
8. Headlamp (High beam)

**\*Accessories and features shown may not be part of standard fitment.**

## REAR VIEW




- 1. Rear reflex reflector
- 2. Left rear turn signal lamp
- 3. Tail/stop lamp

- 4. Licence plate lamp
- 5. Right rear turn signal lamp
- 6. Rear fender

**\*Accessories and features shown may not be part of standard fitment.**

## TOP VIEW



- |  |  |
|--|--|
| (1) Neutral indicator                              | (12) LCD panel of meter console, refer instruments and indicators <b>(page 15)</b> for fuel gauge, speedometer and other features of console |
| (2) Programmed FI malfunction indicator lamp (MIL) | (13) High beam indicator   |
| (3) Side stand indicator                           | (14) ABS indicator   |
| (4) Horn switch                                    | (15) Mode button   |
| (5) Turn signal switch                             | (16) Front brake master cylinder/Reservoir   |
| (6) Clutch lever                                   | (17) Front brake lever   |
| (7) Passing switch                                 | (18) Throttle grip   |
| (8) Rear view mirrors                              | (19) Integrated start-kill switch  |
| (9) Headlamp dimmer switch                         | (20) Turn signal indicators  |
| (10) Hazard switch                                 | (21) Ignition switch with key  |
| (11) Set button                                    | (22) Fuel tank cap   |

**\*Accessories and features shown may not be part of standard fitment.**

## LEFT SIDE VIEW



- |                                   |                       |                                   |
|-----------------------------------|-----------------------|-----------------------------------|
| (1) Side reflex reflector         | (5) Main stand        | (10) Rear grip                    |
| (2) Throttle body/ECU<br>(inside) | (6) Side stand        | (11) Seat lock                    |
| (3) Starter motor                 | (7) Rider foot rest   | (12) Battery compartment (inside) |
| (4) Gear shift pedal              | (8) Pillion foot rest | (13) Side stand switch            |
|                                   | (9) Saree guard       |                                   |

**\*Accessories and features shown may not be part of standard fitment.**

## RIGHT SIDE VIEW



- (1) Rear brake fluid reservoir
- (2) Rear master cylinder
- (3) Brake pedal
- (4) Kick starter pedal
- (5) Oil level dipstick
- (6) Front caliper assembly
- (7) Front disc

- (8) Fuel tank cover
- (9) Seat
- (10) Fuse box (inside)
- (11) Document & Tool kit compartment
- (12) Rear caliper assembly
- (13) Exhaust muffler
- (14) Rear disc

**\*Accessories and features shown may not be part of standard fitment.**

## VEHICLE SPECIFICATION

ITEM		SPECIFICATIONS
<b>Dimensions</b>		
Overall length		2029 mm
Overall width		793 mm
Overall height		1052 mm
Wheelbase		1327 mm
Saddle height		795 mm
Ground clearance		165 mm
<b>Weight</b>		
Kerb weight	Disc-Disc	139.5 kg
	Disc-Drum	138.5 kg
<b>Capacities</b>		
Engine oil		1.3 litres at disassembly and 1.09 litres at draining
Fuel tank		12 litres
Hydraulic brake fluid		DoT-3 or DoT-4
<b>Engine</b>		
Maximum power		11.2 kW @ 8500±500 r/min
Maximum torque		14 N-m @ 6500±500 r/min
Bore and stroke		57.3x63.3 mm
Compression ratio		9.8:1
Displacement		163.23 cc
Spark plug		NGK-CPR 8 EA 9, BOSCH UR5DC
Spark plug gap		0.8-0.9 mm
Valve clearance	Intake (cold)	0.12 mm
	Exhaust (cold)	0.13 mm
Idle speed		1400±100 r/min
<b>Chassis and suspension</b>		
Front suspension		Telescopic hydraulic
Rear suspension		Rectangular swingarm with mono shock
Caster angle		25.5°
Trail length		98 mm
Tyre size	Front	100/80 17 52 P (Tubeless tyre)
	Rear	130/70 R17 62 P (Radial tubeless tyre)

## VEHICLE SPECIFICATION

ITEM		SPECIFICATIONS
Brakes	Front (Disc type)	Dia. 276 mm
	Rear (Disc type)	Dia. 220 mm
	Rear (Drum type)	Dia. 130 mm
<b>Transmission</b>		
Primary reduction		3.136 (69/22)
Final reduction		3.077 (40/13)
Gear box		5 Speed constant mesh
Gear ratio, 1 <sup>st</sup>		3.077 (40/13)
2 <sup>nd</sup>		1.789 (34/19)
3 <sup>rd</sup>		1.304 (30/23)
4 <sup>th</sup>		1.1 (22/20)
5 <sup>th</sup>		0.958 (23/24)
<b>Electricals</b>		
Battery		*MF Battery-12V-4 Ah/ETZ5
Alternator		120 W@5000 r/min (Single phase full DC system)
Headlamp (High/Low)		LED
Position lamp		LED
Tail/Stop lamp		LED
Turn signal lamp		LED
Meter illumination		Module illuminated LCD
Neutral indicator		LED
Turn signal indicator (RH/LH)		LED
Hi beam indicator		LED
ABS indicator		LED
Service reminder indicator		Module illuminated LCD
Licence plate lamp		12V-5W
Side stand indicator		LED
Programmed-Fi Malfunction indicator lamp (MIL)		LED
Fuse	Starter magnetic switch	20A (Circuit fuse) & 20A (Spare fuse)
	Fuse box	15A, 10A, 10A & 10A (Main fuse)
		15A & 10A (Spare fuse)

\*MF stands for Maintenance Free

\*\*MFR stands for Multi-Focal Reflector



## **VEHICLE SAFETY**

### **IMPORTANT SAFETY INFORMATION**

Your vehicle can provide many years of service and pleasure if you take responsibility for your own safety and understand the challenges you can meet on the road.

There is much that you can do to protect yourself when you ride. You will find many helpful recommendations through out this manual. Following are a few that we consider most important.

#### **Always wear a helmet**

It is a proven fact, helmet significantly reduces the number and severity of head injuries. So always wear a helmet and make sure your pillion rider does the same. We also recommend that you wear eye protection, sturdy boots, gloves and other protective gear.

#### **Before riding your vehicle**

Make sure that you are physically fit, mentally focused and free of alcohol and drugs. Check that you and your pillion are both wearing an approved vehicle helmet and protective apparel. Instruct your pillion on holding onto the grab rail or your waist, leaning with you in turns, and keeping their feet on the footrest, even when the vehicle is stopped.

#### **Take time to learn & practice your vehicle**

Even if you have ridden other vehicles, practice riding in a safe area to become familiar with how this vehicle works and handles, and to become accustomed to the vehicle's size and weight.

#### **Ride defensively**

Always pay due attention to other vehicles around you, and do not assume that other drivers see you. Be prepared to stop quickly or perform an evasive maneuver.

#### **Make yourself easily visible**

Some drivers do not see vehicles because they are not looking for them. To make yourself more visible, wear bright reflective clothing, position yourself so that others can see you, signal before turning or changing lanes, and use horn which will help others to notice you.

#### **Ride within your limits**

Pushing the limits is another major cause of vehicle accidents. Never ride beyond your personal abilities or faster than conditions demand. Remember that fatigue and negligence can significantly reduce your ability to make good judgements and ride safely.

#### **Do not drink and ride**

Riding under the influence of alcohol or drugs is dangerous. Alcohol can reduce your ability to respond to changing conditions and reduce the reaction time. Do not drink and ride.

#### **Keep your vehicle in safe condition**

For safe riding, its important to inspect your vehicle before every ride and perform all recommended maintenance. Never exceed load limits, and use accessories that have been recommended by Hero MotoCorp for this vehicle. See (page 11) for more details.

## If you are involved in a crash

Personal safety is your first priority. If you or anyone else has been injured, take time to assess the severity of the injuries and whether it is safe to continue riding. Call for emergency assistance if needed. Also follow applicable laws and regulations if another person or vehicle is involved in the crash.

If you decide to continue riding, first evaluate the condition of your vehicle. If the engine is still running, turn it off. Inspect for fluid leaks, check the tightness of critical nuts and bolts, and check the handlebar, brake levers, brakes, and wheels. Ride slowly and cautiously. Your vehicle may have suffered damage that is not immediately apparent. Have your vehicle thoroughly checked at a qualified service facility as soon as possible.

## PROTECTIVE APPAREL

For your safety, we strongly recommend that you always wear an approved helmet (ISI marked), eye protection, boots, gloves, long pants and a long sleeve shirt or jacket whenever you ride. Take care of loose/hanging clothes while solo/pillion riding. Although complete protection is not possible, wearing proper gear can reduce the chance of injury when you ride.

Following are suggestions to help you choose proper riding gear.



## WARNING

- ***Not wearing a helmet increases the chance of serious injury or death in a crash.***
- ***Be sure you and your pillion always wear a helmet, eye protection and other protective apparel when you ride.***

## Helmet and eye protection

Your helmet is your most important piece of riding gear because it offers the best protection against head injuries. A helmet should fit your head comfortably and securely. A bright coloured helmet can make you more noticeable in traffic, as can reflective strips.

An open-face helmet offers some protection, but a full-face helmet offers more. Always wear face shield or goggles to protect your eyes and help your vision.

## Additional riding gear

In addition to a helmet and eye protection, we also recommend:

- Sturdy boots with non-slip soles to help protect your feet and ankles.
- Leather gloves to keep your hands warm and help prevent blisters, cuts, burns, and bruises.
- A two wheeler riding suit or jacket for comfort as well as protection. Bright coloured reflective clothing can help make you more noticeable in traffic. Be sure to avoid loose clothes that could get caught on any part of your vehicle.

## ACCESSORIES & MODIFICATIONS

Modifying your vehicle or using non-Hero MotoCorp accessories can make your vehicle unsafe. Before you consider making any modifications or adding an accessory, be sure to read the following information.



### WARNING

- ***Improper accessories or modifications can cause a crash in which you can be seriously hurt or killed.***
- ***Follow all instructions in this owner's manual regarding accessories and modifications.***

### Accessories

- Make sure that the accessory does not obscure any lamps, reduce ground clearance, limit suspension travel or steering travel, affect your riding position or interfere with operating any controls.
- Be sure electrical equipment does not exceed the vehicle's electrical system capacity (**page 8**). A blown fuse can cause a loss of lights.
- Do not pull a trailer or sidecar with your vehicle. This vehicle was not designed for these attachments, and their use can seriously impair your vehicle's handling.

### Modifications

We strongly advise you not to remove any original equipment or modify your vehicle in any way that would change its design or

operation. Such changes could seriously impair your vehicle's handling, stability and braking, making it unsafe to ride. Removing or modifying your lamps, mufflers, emission control system or other equipment can also make your vehicle illegal.

### ANTI-THEFT TIPS

- Always lock the steering and never leave the key in the ignition switch. This sounds simple but people do forgets.
- Be sure the registration information for your vehicle is accurate and correct.
- Park your vehicle in a locked garage whenever possible.
- Use an additional anti-theft device of good quality.
- Never park your vehicle in an isolated area. Park as far as possible in a designated area.
- Enter your name, address and phone number in this Owner's Manual and keep it in your vehicle at all times. Many times stolen vehicles are identified by information in the Owner's Manuals that are still with them.

**NAME:** \_\_\_\_\_

**ADDRESS:** \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**PHONE NO :** \_\_\_\_\_

## SAFE RIDING TIPS



### Do's:

- Always conduct simple pre-ride inspection **(page 25)**.
- Always wear a helmet (ISI marked) with chin strap securely fastened and insist on a helmet for your pillion rider.
- While riding, sit in a comfortable position with your legs close to fuel tank.
- Ride defensively and at a steady speed (between 40-50 km/hr).
- For stopping vehicle, use both brakes simultaneously, keeping throttle in the close position.
- Respect road signs and obey traffic rules for your own safety and that of others on the road **(page 67)**.
- During night time, dip headlamps of your vehicle for oncoming traffic, or when following another vehicle.
- Give way to others on the road and signal before you make a turn.
- To make yourself more visible, wear bright reflective clothing that fits well.
- Take care of loose/hanging clothes while solo/pillion riding.
- Get your vehicle serviced regularly by the Authorised Hero MotoCorp workshop.
- Before riding make sure that integrated start-kill switch is in "ON" (🔘) position.
- Keep checking the ABS indicator. At any point if indicator remains on, then ABS is not working **(page 22)**.
- Keep checking speedometer. In case of ABS malfunction, speed display may go to zero.
- It is suggested to go through the do's & don't's of ABS **(page 29)** and practice your ABS vehicle initially in low-traffic condition unless you are thoroughly familiar with your vehicle and its controls.

### Don'ts

- Never use cell phone while riding the vehicle.
- Avoid sudden acceleration, braking and turning of your vehicle.
- Never shift gears without disengaging the clutch and closing the throttle.
- Never touch any part of the hot exhaust system like muffler.
- Never ride under the influence of alcohol or drugs.
- Concentrate on the road and avoid talking to the pillion rider or others on the road.
- Do not litter the road.
- Do not cross the continuous white/yellow line in the center of the road, while overtaking.
- Do not attach large or heavy items to the handlebars, front forks, or fenders.
- Never take your hands off the steering handle while riding.
- Do not attempt to apply the front brake lever intermittently for ABS vehicle.
- Do not panic by mechanical noises or slight pedal pulses while applying the brake in vehicle. These conditions are normal and indicates that ABS is working.
- Don't apply hard braking on loose, wet or slippery road surfaces.
- Do not switch off the integrated start-kill switch (🔘) while riding the vehicle **(page 21)**.
- Do not move the side stand down while riding, as engine will stop while vehicle is in gear **(page 23)**.



## TIPS FOR HEALTHY ENVIRONMENT

The following tips shall ensure a healthy vehicle, healthy environment, and a healthy you.

- **Healthy engine:** The engine is the lifeline of every vehicle. To keep it healthy, it should be tuned regularly, which will also help reduce pollution and improve vehicle performance & fuel efficiency.
- **Regular servicing:** Get your vehicle serviced at an Authorised Hero MotoCorp workshop, as per the service schedule, for an optimum performance and keep the emission level under check.
- **Genuine spares:** Always insist on Hero MotoCorp genuine parts as spurious or incompatible spares and accessories can upset or deteriorate your vehicle's running condition.
- **Genuine engine oil:** Hero 4T Plus SAE 10W 30 SL grade (JASO MA2) engine oil recommended by Hero MotoCorp and make sure you change it every **6000** km. (with top up every **3000** kilometres) to keep the engine fit and environment healthy.
- **Noise pollution:** Noise beyond a certain decibel is pollution. Whether it is from horns or defective mufflers, excessive noise will cause headaches and discomfort.
- **Emission pollution:** Get emission of your vehicle checked by Authorised agencies atleast once every **3** months or as notified by the government from time to time.
- **Fuel saving & reduce pollution:** Switch "OFF" the engine while waiting at traffic signal points to save fuel and reduce pollution, if the waiting period is long.
- **BS-VI grade fuel :** Always use BS-VI grade fuel to adhere BS-VI norms.

## PARTS FUNCTION

### Ignition switch




1. Ignition switch
2. Ignition key
3. “OFF” (X) position
4. Steering lock position
5. “ON” (O) position

Key position	Function	Key removal
“ON” (O)	The LCD panel illuminates & initial display of multi function digital segments are displayed. The tachometer segment and the fuel gauge segment will swing to the maximum scale once and back to its normal position. Scroll message and odometer will appear. The engine can be started. Turn signal lamp, horn, tail/stop lamp, fuel gauge, passing switch, position lamp, programmed FI malfunction indicator lamp (MIL) illuminates continuously, neutral indicator & hazard switch will be functional.	Key cannot be removed.
“OFF” (X)	Engine cannot be started and no electrical system will be functional.	Key can be removed.
“LOCK”	Steering can be locked.	Key can be removed.

## Instruments and Indicators

The indicators are in the speedometer panel above the headlamp. The functions are as below.



Sl. No.	Description	Function
1	Tachometer	Shows engine revolution per minute. The tachometer digital segments will swing to maximum scale on the meter console once the ignition switch is turned “ON”.
2	Speedometer	Indicates riding speed.
3	Odometer	Shows accumulated distance travelled ( <b>page 20</b> ).
4	Tripmeter A & B	Shows the distance travelled during a trip after setting to zero ( <b>page 18</b> ).
5	Digital clock	Indicates hours & minutes ( <b>page 17</b> ).
6	Scroll display	Displays a scrolling “GET SET GO” message for few seconds when the ignition switch is turned “ON” ( <b>page 18</b> ).
7	Service reminder indicator	Display when the next service is due ( <b>page 19</b> ).
8	Fuel gauge	Indicates approximate fuel quantity in the form of digital segments. The fuel gauge segments will display its maximum scale on the fuel gauge LCD panel once when the ignition switch it turned “ON” ( <b>page 19</b> ).

Sl. No.	Description	Function
9	Mode button	Switches display between odometer, tripmeter-A & B.
10	Anti-lock braking system (ABS) indicator	This indicator normally comes on for approx 1.8 seconds when the ignition switch is turned “ON” (🔌) & then keeps blinking until the vehicle attains speed of 5 km/h. If there is a problem with the anti-lock brake system, ABS indicator turns on ( <b>page 22</b> ).
11	Turn signal indicators	Flashes when turn signal switch is operated.
12	High beam indicator	Light glows when headlamp is in high beam.
13	Neutral indicator	Light glows when vehicle is in neutral position.
14	Programmed-FI malfunction indicator lamp (MIL)	When the ignition switch is turned “ON” the programmed FI malfunction indicator lamp (MIL) glows continuously and then should go “OFF” once the engine is started. It indicates that programmed FI system is OK. If it glows continuously there is an abnormality in the programmed FI system, it is recommended to reduce the speed and drive to the Authorised Hero MotoCorp workshop for check-up.
15	Side stand indicator	Light glows when the vehicle is parked on the side stand.
16	Set button	To adjust clock, date & tripmeter. When long pressed resets tripmeter to zero.




## LCD PANEL


### (a) Digital clock

Digital clock (1) shows hour and minute. To adjust the time, proceed as follows :


- Turn the ignition switch "ON" (O).
- Press and hold set button (2) and mode button (3) simultaneously for more than 2 seconds. The clock will be set in the adjust mode with the hour's digit displaying blinking.



- To set the hour, press mode button (3) until the desired hour is displayed.
  - The time is advanced by 1 hour each time the button is pressed.
  - The time advances fast when the button is pressed and held.
  - "AM" will change to "PM" after 12.




- Press the set button (2). The minutes display starts blinking.



- To set the minute press mode button (3) until the desired minute is displayed. The minute display will return to "00" when "60" is reached without affecting the hour display.
  - The time advances by 1 minute, each time the button is pressed.

- The time advances fast when the button is pressed and held.



### (3) Set button

- To end the adjustment press set button (2). The display will stop flashing automatically and it will return to its previous value if the button is not pressed for 30 seconds or more.



### NOTE

**The clock will reset "AM: 1:00" if the battery is disconnected.**

### (b) Odometer/Tripmeter


The odometer (1) shows accumulated distance travelled.

The tripmeter shows distance travelled since trip meter was reset last time. There are two tripmeters, tripmeter-A (2) and tripmeter-B (3).

Push the mode button (4) to select odometer, tripmeter-A or tripmeter-B. Tripmeter-A or tripmeter-B can be displayed upto "99999.9" km.

If the tripmeter exceeds "99999.9" km it will return to "0.0" km automatically. When tripmeter is selected long press the set button to reset tripmeter to zero.

The odometer can be displayed from "0 to 999999" km.



### (1) Odometer


### (2) Tripmeter-A

### (3) Tripmeter-B

### (4) Mode button

### (c) Scroll message

The scroll (1) displays a message "GET SET GO" for few seconds whenever the ignition switch is turned "ON".



### (1) Scroll

#### (d) Service reminder indicator

The service reminder indicator (1) is to indicate the user to bring the vehicle to an Authorised Hero MotoCorp workshop for service. The indicator shall start blinking when the vehicle covers kilometers as specified in the maintenance schedule. The indicator will keep on blinking throughout the kilometer interval for a particular service and will stay “ON” thereafter.

The service reminder indicator can be reset at an Authorised Hero MotoCorp workshop.



(1) Service reminder indicator



#### NOTE


After getting the vehicle serviced, make sure that the service reminder indicator has been reset.

#### (e) Fuel gauge

The fuel gauge (1) indicates approximate fuel available in the form of digital segments.

The digital segments (2) will swing to maximum scale on the meter console once the ignition switch is turned “ON” (ⓘ). If all the segments are displayed it means fuel quantity in the fuel tank is 12.0 litres.

If only one segment (3) is displayed and blinks, this indicates the fuel quantity is low and the fuel tank should be refilled as soon as possible.



(1) Fuel gauge

(3) One segment

(2) Segments



#### CAUTION

Please ensure the vehicle is not used continuously when the fuel level indicator reaches the one segment blinking. It will not only result in the vehicle running out of fuel, it may also cause serious damage to the fuel pump. Please ensure fuel is filled up as soon as the fuel level indicator reaches one segment blinking.




#### NOTE

To check the fuel level indication, the vehicle should be on levelled surface and in stationary condition.

## FEATURES

### Steering lock

Steering lock is with the ignition switch, turn the key (1) to “OFF” (⊗) position & turn the handle bar towards left or right & push the key downwards & turn towards “Lock” position. After locking take out the key.





(1) Ignition key

## HANDLEBAR SWITCHES CONTROL

### Left handlebar controls


#### 1. Headlamp dimmer switch

The headlamp operates only when the engine is running or when passing switch is operated. Press the switch (1) upwards for high beam “” downwards for low beam “”.

#### 2. Turn signal lamp switch (↔)

Shift the turn signal switch (2) sideways for right/left indications and leave it to come back to its normal position on its own.

**IMPORTANT :** To switch “OFF” the turn signal after completing the turn, gently push the switch inside.



- (1) Headlamp dimmer switch  
(2) Turn signal switch (3) Horn switch  
(4) Hazard switch

#### 3. Horn switch (🔊)

Press the switch to operate the horn (3).

#### 4. Hazard switch (⚠️)

Press the hazard switch (4) in ignition “ON” condition whenever your vehicle becomes a temporary hazard for other road users and it is necessary to park the vehicle due to breakdown or other unavoidable problems.

Upon pressing the hazard switch, all turn signal lamps start flashing simultaneously to warn other road users behind you of a hazard or obstruction ahead.

To turn “OFF” the indicator lamps in hazard switch “ON” condition, press the hazard switch again.



### NOTE

*Use hazard lights only when your vehicle becomes a temporary hazard for other road users.*

## 5. Passing switch

Gives an indication for passing ahead.

Press passing lamp switch (5) to operate the passing lamp.

## 6. Clutch switch

There is a clutch switch (6) provided for the safety of the rider. The vehicle cannot be started by electric starter switch until the clutch lever is engaged in gear.



(5) Passing switch

(6) Clutch switch


## Right handlebar controls

### 1. Integrated start-kill switch

#### (a) Electric starter operation (⚡)

Press the electric starter (⚡) (1) of integrated start-kill switch (2) downwards to start the vehicle. Ensure the electric starter operation is done when the vehicle transmission is in neutral. If the vehicle is engaged in gear, press the clutch lever before electric starter (⚡) operation. Release switch after the engine has started.

**! CAUTION**  
*Never hold electric starter (⚡) of integrated start-kill switch continuously more than 5 seconds as continuous cranking of engine will discharge the battery.*



(1) Electric starter

(2) Integrated start-kill switch

(3) Engine stop (ON/OFF)

#### (b) Engine stop switch operation

For engine stop operation (3) integrated start-kill switch (1) has two positions. In “ON” (○) position, engine will operate and in “OFF” (⊗) position, engine will not operate. The prime function of it is to stop the engine during emergency (Vehicle tip over, throttle cable stuck etc.). The switch should normally remain in “ON” (○) position. During emergency, put the switch to “OFF” (⊗) position.

## ! WARNING

**While riding the vehicle in normal condition, do not press the “Integrated start-kill switch to “OFF” (⊗) position to avoid any damage (Wheel locking leading to accident, part damage, battery discharge etc.).**

### ABS INDICATOR

The ABS indicator (1) on speedometer come “ON” for approx 1.8 seconds when the ignition switch is turned “ON” (O) & then keeps blinking until the vehicle attains a speed of 5 km/h.

When the system functions normally indicator goes “OFF” (⊗) once vehicle speed exceeds 5 km/h.

At any point if ABS indicator remains “ON” then ABS is not working, but the brakes still work normally. Reduce your vehicle speed and visit your Authorised Hero MotoCorp workshop.



(1) ABS indicator


### SIDE STAND INDICATOR/SWITCH

For the safety of the customer a side stand indicator (1) is provided.

A side stand switch (2) is provided in the side stand, when the side stand is down (ignition switch “ON” (O)), the switch enables the side stand indicator lamp to glow on the speedometer panel.



(1) Side stand indicator



(2) Side stand switch (3) Side stand spring

- Check the side stand for proper function and the spring (3) for damage or loss of tension and the side stand assembly for free movement.
- Check whether the side stand indicator (1) glows when the side stand is down.
- While the side stand is up, the side stand indicator (1) should not glow.
- If the side stand indicator (1) does not operate as described in above steps, please visit your Authorised Hero MotoCorp workshop.

### ! CAUTION

*Ensure that adequate care should be taken while cleaning the side stand switch.*

**Your vehicle is equipped with “Side stand engine kill” feature for safety purpose.**

This feature has following functions:

- It prevents starting the engine when transmission is in gear (irrespective of clutch lever operation) and side stand is down.
- It stops the running engine when transmission is in gear (irrespective of clutch lever operation) and side stand is moved down.


### ! WARNING

*“Side stand engine kill” system is not affected by clutch lever operation.*


To inspect the functionality of this feature, park the vehicle on its main stand and check all the conditions described in the inspection flow diagram:

### INSPECTION FLOW DIAGRAM


**1. Press the electric starter (Ⓐ) of integrated start-kill switch (with transmission in neutral and side stand is down).**



**2. Then shift the transmission to gear (with engine running and irrespective of clutch lever operation).**



**3. Now press the electric starter (Ⓐ) of integrated start-kill switch (After engine has stopped).**



If your vehicle doesn't operate as described in above flow diagram, please visit your Authorised Hero MotoCorp workshop.

**! WARNING**

**Regularly inspect the functionality of "Side stand engine kill" feature and in case of any malfunction visit Authorised Hero MotoCorp workshop.**

## FUEL TANK

Fuel tank capacity is 12 litres (Minimum fuel to be maintained above one segment blinking of fuel level indicator).



**(1) Key hole cover**


**(2) Ignition key**

- To unlock fuel tank cap, lift the key hole cover (1), insert key (2) turn it clockwise and lift open the cap (3).



**(3) Fuel tank cap**

- Do not overfill the tank. There should be no fuel (4) in filler neck (5). Fill the tank with fuel as shown.



**(4) Fuel**

**(5) Filler neck**

- To lock fuel tank cap, close the cap back on the opening and press gently. The key springs back to the normal position and cap gets locked.
- Remove the key and put back the keyhole cover.



### **! CAUTION**

***Do not park the vehicle under direct sunlight as it causes evaporation of petrol due to heat and deterioration of paint gloss due to ultra violet rays.***

### **! WARNING**

***Petrol is extremely flammable and is explosive under certain conditions. Refill in a well ventilated area with the engine stopped. Do not smoke or allow flames or sparks in the area where the vehicle is refilled or where petrol is stored.***

## **SEAT LOCK**

**Location :** On the left side of the rear cowl, above rear wheel.

**Operation :** Insert the ignition key (1) and turn in clockwise to unlock the seat. To install, engage the seat hooks with frame and press the seat until the lock clicks.



**(1) Ignition key**

## **PRE- RIDE INSPECTION**

You should conduct pre ride inspection before riding the vehicle to enhance riding comfort and safety.

Clean your vehicle regularly. It protects the surface finish. Avoid cleaning with products that are not specifically designed for vehicle surfaces.

Inspect your vehicle every day before you start the engine. The items listed here will only take a few minutes, and in the long run they can save time, expense, and possibly your life. Please follow the tips as given below:

- **Engine oil level**–Check and top up engine oil if required (**page 37**). Check for leaks.
- **Programmed FI malfunction indicator lamp (MIL)**–When the ignition switch is turned “ON” the programmed FI malfunction indicator lamp (MIL) glows continuously and then should go “OFF” once the engine is started.
- **Fuel level**–Ensure sufficient fuel is available in the fuel tank for your journey. Fuel level segment should be above one segment blinking (**page 19**). Check for leaks.
- **Front brake**–Check for correct brake fluid level in master cylinder/reservoir (**page 47**).
- **ABS indicator**–Check ABS indicator for proper functioning of ABS (**page 22**).
- **Rear brake (Disc type)**–Check for correct brake fluid level in the reservoir (**page 48**).

- **Rear brake (Drum type)**–Check operation. Adjust free play, if necessary (**page 50**).
- **Tyres**–Check condition and pressure (**page 55**).
- **Clutch**–Check for smooth operation. Adjust free play if necessary (**page 42**).
- **Drive chain**–Check condition and slackness (**page 44**). Lubricate if necessary.
- **Throttle**–Check for smooth opening and closing in all steering positions (**page 43**).
- **Lamps & Horn**–Check that headlamp, position lamps, tail/stop lamp, turn signal lamps, indicators and horn function properly.
- **Rear view mirror**–Ensure that the rear view mirror gives a good rear view when you are sitting on the vehicle.

- **Integrated start-kill switch**–Check for proper functionality (**page 21**).
- **Fitting & Fasteners**–Check & tighten if necessary.
- **Steering**–Check for smooth action and for easy maneuverability.
- **Side stand**–Check for proper functionality (**page 22**).

## STARTING THE ENGINE

Always follow the proper starting procedure described below :

- To protect the catalytic converter in your vehicle's exhaust system, avoid extended idling and the use of leaded petrol.

Your vehicle's exhaust contains poisonous carbon monoxide gas. High levels of carbon monoxide can collect rapidly in enclosed areas such as garage. Do not run the engine with the garage door closed.


### ! CAUTION

- **Never hold electric starter (Ⓢ) of integrated start-kill switch continuously more than 5 seconds as continuous cranking of engine will discharge the battery.**
- **This vehicle is equipped with a side stand engine kill feature (page 22).**

## Preparation

Before starting insert the key and follow the below mentioned procedure :

- Turn the ignition switch (1) to "ON" (Ⓢ) position.



(1) Ignition switch

(2) Malfunction indicator lamp (MIL)


- Confirm that the programmed FI malfunction indicator lamp (MIL) (2) glows continuously and then should go "OFF" once the engine is started.



## NOTE

**If MIL remains “ON” even if the vehicle is started, there is an abnormality in the programmed FI system. It is recommended to reduce the speed and drive to the Authorised Hero MotoCorp workshop for check-up**

- Find neutral position & check neutral (N) indicator (3) on instrument console with ignition “ON”.



**(3) Neutral indicator**



**(4) Integrated start-kill switch**

- Make sure that the integrated start-kill switch (4) is at “ON” (O) position.
- Electric start** : Press the electric starter (Ⓐ) of integrated start-kill switch with fully closed throttle.
- Kick start** : Depress the kick starter until resistance is felt. Then let the kick starter return to the top of its stroke. Kick from the top of the stroke through to the bottom with a rapid, continuous motion.

## Starting procedure

At any ambient temperature, Press the electric starter (Ⓐ) of integrated start-kill switch with the throttle completely closed.



## NOTE

**This vehicle has a fuel-injected engine with an idle air control valve (IACV).**

## Flooded engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel.

- If the engine does not start wait for 15-20 seconds, and try restarting the engine with throttle completely closed.
- If the engine starts with unstable idle, open the throttle slightly.

## Ignition cut off

Your vehicle is designed to automatically stop the engine & fuel pump, if vehicle falls down.

**(Bank angle sensor cuts off the ignition).**



## NOTE

**If the vehicle has fallen down, before restarting the engine you must turn the ignition switch to “OFF” (X) position and then back to “ON” (O) position.**

## Running in

Help assure your vehicle's future reliability and performance by paying extra attention to how you ride during the first 500 km.

During this period, avoid full-throttle starts and rapid acceleration.



### NOTE

- To start the engine if any gear is engaged, press the clutch lever and press the integrated start-kill switch.
- Do not open the throttle during starting the vehicle.



### WARNING

**Never run the engine in a closed area, the exhaust contains poisonous gases.**


## RIDING

- After the engine has been warmed up, the vehicle is ready for riding.
- While the engine is idling, press the clutch lever and depress the gearshift pedal downwards using the toe to shift into 1<sup>st</sup> gear.
- Slowly release the clutch lever and at the same time, gradually increase engine speed by opening the throttle. Coordination of the throttle and clutch lever will assure a smooth positive start.
- When the vehicle attains a moderate speed, close the throttle, press the clutch lever and shift to 2<sup>nd</sup> gear by placing the toe on the underside of gear pedal and lift upwards.
- This sequence is repeated progressively to shift to 3<sup>rd</sup>, 4<sup>th</sup> and 5<sup>th</sup> gear.



### CAUTION

**Do not shift gears without operation of clutch and without closing the throttle otherwise this would lead to damage of gears.**



## BRAKING

### Anti-lock braking system (ABS)

This model is equipped with Anti-lock braking system (ABS). ABS enhances active safety by helping to prevent the wheels from locking under braking.

ABS is designed to meet two essential requirements during every brake application:

- To help provide vehicle stability.
- To help maintain steering control and manoeuvrability—on road surfaces.

**The ABS system is self-regulating and always active once vehicle speed exceeds 5 km/h.**

- The ABS computer acts on the basis of the comparative speeds of the front wheel. The use of non-approved tyres can affect the speed of the wheels and supply incorrect information to the ABS computer.



**(1) Wheel speed sensor**

**(2) Hydraulic electronic control unit (HECU)**



**(3) ABS indicator**

The system has a wheel speed sensor (1), hydraulic electronic control unit (HECU) (2), and an ABS indicator lamp (3) on meter console.

Whenever you ride your vehicle, **Wheel speed sensor** monitors the speed of the wheel and sends the input to **Hydraulic Electronic control unit (HECU)**. Then **HECU** monitors your bike and takes control when vehicle speed exceeds 5 km/h.

Now whenever you will apply front brake, ABS will come into picture and based on the input from wheel speed sensor, HECU will modulate the pressure at front caliper thus avoiding wheel to lock and in turn resulting safe stop of the vehicle.

### **Do's and Dont's**

#### **Do's**

- Check your brake pads and be sure you have clean brake fluid. ABS systems can also fail due to worn brake pads or air or dirt in brake fluid.
- Use the recommended brake fluid.
- If brake gets wet, apply the brake while riding at low speed to help them dry.
- It is recommended that ABS should be serviced at Authorised Hero MotoCorp workshop.
- Read your owner's manual for additional riding instructions.
- Carefully remove the wheel during the puncture/tyre replacement to prevent the Sensing ring damage/bend.
- Use only the recommended make, type, size of tyre and maintain specified tyre pressure (**page 55**).
- Keep checking speedometer. In case of ABS malfunction, speed display may go to zero.
- Always maintain sufficient distance from the objects/vehicles ahead, for proper braking and to match riding speed.
- On certain surfaces, such as rough road or gravel road, brake lever may have hard/pulsating feel. Apply full braking on the lever even on the hard or pulsating feel of the lever to get the optimum performance.

- In case of ABS malfunction, the brake system will work as conventional (Non-ABS) brake. Rider is recommended not to apply hard brake to prevent wheel lock and visit Authorised Hero MotoCorp workshop.

### Don't's

- Don't panic by mechanical noises or slight lever pulses while applying the brake (whenever ABS actuates) in vehicle. These conditions are normal and indicates that ABS is working.
- Don't apply the hard braking in wet or rainy conditions and while taking a turn.
- Do not adjust the wheel speed sensor air gap yourself.
- Do not attempt to correct the encoder teeth by bending manually or by using any other mode. Do not use a different encoder teeth
- Do not insert any metallic part near wheel speed sensor.
- Don't try to service HECU or open to separate the parts.
- Don't use the non-genuine spares like pads, discs, tyres etc.



### NOTE

- **ABS may get activated without brake application while riding on uneven road surfaces (sharp drop or rise on the road level). This is normal functioning of ABS and won't be having any impact on performance.**
- **ABS may not work if the battery is discharged.**
- **ABS operation is also affected by road conditions, vehicle handling and brake operation. It is the rider's responsibility to ride at reasonable speed and to leave a margin of safety.**
- **ABS consists of an electric motor, from which sound can be heard.**

### PARKING

After stopping the vehicle, shift the transmission to neutral, turn the ignition switch "OFF" (⊗), park the vehicle on main stand, lock the steering and remove the key.



### CAUTION

- **Park the vehicle on firm level ground to prevent overturning.**
- **While parking on side stand engage the first gear.**

### TOOL KIT / FIRST AID KIT

The tool kit (1) is located below the seat in the rear. Some emergency repairs, minor adjustment and parts replacement can be performed with the tools contained in the kit.



(1) Tool kit

(2) First aid kit

Kit consists of following tool:

- Tool bag-1 No.
- + , - Driver No.2-1 No.
- Grip-1 No.
- Box wrench P16 x 14-1 No.
- Handle pin spanner-1 No.



- Pin spanner- 1 No.
- No.3 cross point screw driver- 1 No.

The first aid kit (2) is located below the seat in rear. For some emergency first aid can be performed by medicine contained in the kit.

Kit contains the following items :

- Antiseptic cream- 1 No.
- Sterilised dressing- 1 No.
- Water proof plaster- 1 No.
- Elastic bandage- 1 No.
- Gauze (Rolled bandage)- 1 No.
- Sterilised elastic plaster- 1 No.
- First aid bag- 1 No.

## CLEANING AND WASHING OF VEHICLE

Follow the below mentioned steps for washing the vehicle.

- Wet the vehicle with light water spray. Avoid directing water to meter console, muffler outlets and electrical parts.
- Clean the headlamp lens and other plastic parts using a cloth or sponge dampened with a solution of mild detergent and water.
- Rub the soiled area gently rinsing it frequently with fresh water.
- After cleaning spray water thoroughly.
- Dry the vehicle by wiping with dry soft cloth.



### NOTE

- *Our authorized dealership take all above mentioned precautions like recommended detergents and usage of muffler caps/plugs during wash to ensure quality wash.*
- *Do not use high pressure water (or air). It can damage certain parts of the vehicle.*

## MAINTENANCE

### The importance of maintenance

A well-maintained vehicle is essential for safe economical and trouble-free riding. It will also help reduce pollution.

To help you, take proper care of your vehicle, the following pages include a maintenance schedule and a maintenance record for regular scheduled maintenance.

These instructions are based on the assumption that the vehicle will be used exclusively for its designed purpose. Sustained high speed operation or operation in unusually wet or dusty conditions will require more frequent service than specified in the maintenance schedule. Consult your Authorised Hero MotoCorp dealer for recommendation applicable to your individual needs and use. If your vehicle overturns or is involved in a crash, be sure that you visit your Authorised Hero MotoCorp workshop for detailed inspections.



### WARNING

- *Improperly maintaining this vehicle or failing to correct a problem before you ride can cause a crash in which you can be seriously hurt or killed.*
- *Always follow the inspection and maintenance recommendations and schedules in this owner's manual.*

## Maintenance safety

This section includes instructions on some important maintenance tasks. You can perform some of these tasks with the tools provided (if you have basic mechanical skills).

Other tasks that are more difficult and require special tools are best performed by professionals. It is recommended that wheel removal should normally be handled by a Hero MotoCorp authorised workshop.

You will come across some of the most important safety precautions in the following pages of this manual.

However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.



### WARNING

- ***Failure to follow maintenance instructions and precautions properly can seriously injure you.***
- ***Always follow the procedures and precautions in this owner's manual.***

## SAFETY PRECAUTIONS

- Make sure the engine is “OFF” before you begin any maintenance or repair. This will help to eliminate several potential hazards:
  - **Carbon monoxide poisoning from engine exhaust.**  
Be sure there is adequate ventilation whenever you operate the engine.
  - **Burns from hot parts.**  
Let the engine and exhaust system cool before touching.
  - **Injury from moving parts.**  
Do not run the engine unless instructed to do so.
  - Read the instruction before you begin and make sure you have the tools and skills required.
  - To help prevent the vehicle from falling over, park it on a firm, level surface on the main stand.
  - To reduce the possibility of a fire or explosion, be careful when working around petrol or batteries. Use only nonflammable solvent, not petrol, to clean parts. Keep cigarettes, sparks and flames away from the battery and all fuel-related parts.
- Remember that your Authorised Hero MotoCorp workshop knows your vehicle best and is fully equipped to maintain and repair it. To ensure best quality and reliability, it is recommended to use Hero MotoCorp genuine parts for repair and replacement.



## MAINTENANCE SCHEDULE

Perform the pre-ride inspection (**page 25**) at each scheduled maintenance period.

**I: INSPECT C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE O: OIL CHANGE  
T: TOP UP E: EMISSION CHECK**

The following maintenance schedule specifies all maintenance required to keep your vehicle in peak operating condition. Maintenance work should be performed in accordance with standards and specifications of Hero MotoCorp by properly trained and equipped technicians. Your Authorised Hero MotoCorp workshop meets all of these requirements.

Ensure that each paid service is availed within **90** days or **3000** km from the date of previous service, whichever is earlier.



To be serviced by your Authorised Hero MotoCorp workshop unless the owner has the relevant tools, technical information and is technically qualified.



In the interest of safety, we recommend that these jobs are carried out only by your Authorised Hero MotoCorp workshop.

**Note-1** : At higher odometer readings, repeat the frequency interval established here.

**Note-2** : Replace air cleaner element once in every **15000** km or early replacement may be required when riding in dusty areas.

**Note-3** : Replace engine oil once in every **6000** km. Top up if the oil level is at or near the lower level mark.

**Note-4** : Visit Authorised Hero MotoCorp workshop for inspection, cleaning, lubrication and adjustment of drive chain at every **1000** km.

**Note-5** : Replace brake fluid once in every two years or **30000** km, whichever is earlier.

**Note-6** : Inspect & maintain specified torque.

**Note-7** : Inspect the wheel bearings free play, replace if necessary.

**Note-8** : Replace front fork oil once in a every **2** years or **30000** km, whichever is earlier.

**Note-9** : Inspect rear suspension mounting bushes play, replace rear shock absorber if necessary.

**Note-10** : Check CO emission at idle.

**Note-11** : Inspect the canister hoses for deterioration, damage or loose connections and canister for cracks or other damages.

**Note:** Always wipe the water from the vehicle after washing. Use clean soft cloth or pressurized air for completely drying the water.



Give a missed call to  
+91 8367796950














or Scan QR code

## MAINTENANCE SCHEDULE

Dear Customer,

We would strongly recommend the following schedule, to keep your vehicle in perfect running condition and healthy environment. Vehicle subjected to severe use or ridden in dusty area will require more frequent servicing.

ITEMS		WHICHEVER COMES FIRST	DURING FREE SERVICE PERIOD					AFTER FREE SERVICE ONCE IN EVERY				
		SERVICE	1 <sup>st</sup>	2 <sup>nd</sup>	3 <sup>rd</sup>	4 <sup>th</sup>	5 <sup>th</sup>					
		DAYS	1st 60	Next 100	Next 100	Next 100	Next 100					
		KM Note-1	500-750	3000-3500	6000-6500	9000-9500	12000-12500	3000	6000	9000	12000	15000
	Fuel Line		I	I	I	I	I	I				
	Throttle Operation		I, A	I, A	I, A	I, A	I, A	I, A				
	Air Cleaner Element	<b>Note-2</b>	<b>Do not open air cleaner element unless there is a drivability problem</b>									R
	Spark Plug		I, C, A	I, C, A	I, C, A	I, C, A	R	I, C, A			R	
	Valve Clearance		I, A	I, A	I, A	I, A	I, A	I, A				
	Engine Oil	<b>Note-3</b>	O	I, T	O	I, T	O	I, T	O			
	Engine Oil Strainer Screen		C		C		C		C			
	Engine Oil Centrifugal Filter		C		C		C		C			
	Electric Starter		I	I	I	I	I	I				
	Oil Circulation		I	I	I	I	I	I				
	Drive Chain	<b>Note-4</b>	<b>I,C,L,A at every 1000 km</b>					<b>I,C,L,A at every 1000 km</b>				
	Drive Chain Slider			I	I	I	I	I				
	Battery Voltage Inspection with Midtronics tester		I	I	I	I	I	I				
	Brake Shoe (Drum type)		I, A	I, A	I, A	I, A	I, A	I, A				

ITEMS		WHICHEVER COMES FIRST	DURING FREE SERVICE PERIOD					AFTER FREE SERVICE ONCE IN EVERY				
		SERVICE	1 <sup>st</sup>	2 <sup>nd</sup>	3 <sup>rd</sup>	4 <sup>th</sup>	5 <sup>th</sup>					
		DAYS	1st 60	Next 100	Next 100	Next 100	Next 100					
		KM Note-1	500- 750	3000- 3500	6000- 6500	9000- 9500	12000- 12500	3000	6000	9000	12000	15000
	Disc Wear/ Pad Wear (Disc type)		I	I	I	I	I	I				
	Brake Fluid (Disc type)	<b>Note-5</b>	I	I	I	I	I	I				
	Brake System (Brake Cam & Brake Pedal)			C, L		C, L				C, L		
	Stop Lamp Switch		I, A	I, A	I, A	I, A	I, A	I, A				
	Headlamp Focus		I, A	I, A	I, A	I, A	I, A	I, A				
	Clutch Lever Free Play		I, A	I, A	I, A	I, A	I, A	I, A				
	Side Stand/Main Stand		L	L	L	L	L	L				
	Side Stand Switch		I, C	I, C	I, C	I, C	I, C	I, C				
	Nut, Bolts & Fasteners	<b>Note-6</b>	I	I	I	I	I	I				
	Wheels Bearings	<b>Note-7</b>	I	I	I	I	I	I				
	Wheel/Tyres		I	I	I	I	I	I				
	Steering Head Bearing		I	I, A	I	I, A	I, L, A	I	I, A		I, L, A	
	Front Suspension/Oil	<b>Note-8</b>	I	I	I	I	I	I				
	Rear Suspension	<b>Note-9</b>	I	I	I	I	I	I				
	Muffler (Catalytic Converter)	<b>Note-10</b>			I, E		I, E		I, E			
	Evaporative Emission Control System	<b>Note-11</b>	I	I	I	I	I	I				


## SPARK PLUG INSPECTION

### Recommended plugs:

#### NGK-CPR 8 EA9, BOSCH UR5DC

For most riding conditions this spark plug heat range number is satisfactory. However, if the vehicle is going to be operated for extended periods at high speeds or near maximum power in hot climates, the spark plug should be changed to a cold heat range number, consult Authorised Hero MotoCorp workshop on this if required.

- Clean dirt around the spark plug base.
- Disconnect the noise suppressor cap (1) and remove the spark plug (2) with the help of spark plug box wrench provided in the tool bag.




(1) Noise suppressor cap

(2) Spark plug

- Visually inspect the spark plug electrodes for wear. The center electrode should have square edges and the side electrode should not be eroded. Discard the spark plug if there is apparent wear or if the insulator is cracked or chipped.

- Make sure that the spark plug gap is **0.8–0.9 mm** using a wire-type feeler gauge. If adjustment is necessary, bend the side electrode carefully. Make sure the plug washer is in good conditions.



- With the plug washer attached, thread the spark plug in by hand to prevent cross-threading.
- Tighten a new spark plug 1/2 turn after the plug seats, with a spark plug box wrench to compress the washer. If you are reusing a plug, it should only take 1/8–1/4 turn after the plug seats.

### ! CAUTION

- *Do not remove the spark plug and test for spark on the vehicle by cranking the engine as this could lead to fire or explosion*
- *Install a dummy spark plug in the cylinder head and test for spark.*
- *Never use a spark plug with improper heat range.*
- *Always use resistor type spark plug.*

## ENGINE OIL

Use hero genuine engine oil or recommended grade oil.

**BRAND: Hero 4T plus**

**GRADE: SAE 10W 30 SL Grade**

**(JASO MA2).**

Manufactured by:


- Tide Water Oil Co. (India) Ltd.
- Savita Oil Technologies Limited.
- Bharat Petroleum Corporation Limited.

**OIL CAPACITY : 1.3 litres**

**Engine oil level inspection/**

**Top up process**


Check engine oil level each day before operating the vehicle. The oil level dipstick (1) is on the right crankcase cover for measuring oil level. Oil level must be maintained between the upper (2) and lower (3) level marks on the oil level dipstick.



(1) Oil level dipstick  
(3) Lower level mark

(2) Upper level mark

- Do top up if oil level reaches towards the lower level mark or every 3000 km whichever is earlier.
- Park the vehicle on its main stand.
- Start the engine & let it idle for 3-5 minutes.
- Slightly loosen the engine oil check bolt (4) and check the engine oil entry into the cylinder head cover.




**(4) Engine oil check bolt**

- After checking the oil circulation, tighten the engine oil check bolt.
- Stop the engine and wait for 2-3 minutes.
- Remove the oil level dipstick, wipe it clean and insert without screwing it in.
- Remove the oil level dipstick and check the oil level.
- If required, add the specified oil up to the upper level mark. Do not overfill.
- Quantity of oil to be filled is 1.09 litres (approx.) during oil change (when right crankcase cover is not removed).

- Reinstall the oil level dipstick with new O-ring and check for oil leaks.

### Engine oil replacement/ Oil circulation inspection

- Start the engine, warm it up for several minutes and then turn it off.
- Wait a few minute until the oil settles down.
- To drain the oil, remove the oil level dipstick, drain bolt (1) and sealing washer (2).



**(1) Drain bolt**

**(2) Sealing washer**

- After the oil has completely drained, reinstall the drain bolt (1) with a new sealing washer (2).
- Fill the crankcase through the oil filler hole with 1.09 liters (approximately) of recommended grade oil during oil change when right crankcase cover is not removed.
- Reinstall the oil level dipstick with a new O-ring.
- Start the engine and allow it to idle for few minutes.


- Stop the engine and let the engine oil settle down.
- Recheck the oil level.
- Make sure that oil level is at the “UPPER” level mark of the oil level dipstick with the vehicle in an upright position and that there are no oil leaks.

### **! CAUTION**


- ***Running the engine with insufficient oil can cause serious engine damage.***
- ***Running the engine with excessive oil can cause spark plug fouling & loss in performance.***
- ***Engine oil is a major factor affecting the performance and service life of the engine. Non-detergent, vegetable or castor based racing oils are not recommended.***

### OIL FILTER SCREEN & CENTRIFUGAL FILTER CLEANING

- Drain the engine oil thoroughly.
- Remove the side stand switch bolts (1).
- Disconnect the clutch cable (2), remove the kick start pedal (3) and exhaust muffler (4).
- Remove the kick stopper with side stand (5) and right crankcase cover (6).
- Remove the dowel pins (7) and gasket (8).
- Remove the oil filter screen (9) and wash it in clean non flammable or high flash point solvent (kerosene).



- (1) Side stand switch bolts (2) Clutch cable  
(3) Kick start pedal (4) Exhaust muffler  
(5) Kick stopper with side stand  
(6) Right crankcase cover



- (7) Dowel pins (8) Gasket (9) Oil filter screen  
(10) Centrifugal filter cover

- Reinstall the filter screen with the tapered end facing in.
- Remove centrifugal filter cover (10) & clean the centrifugal filter (11) with non flammable or high flash point solvent (kerosene).



- (11) Centrifugal filter

- Reinstall the centrifugal filter cover with new gasket.
- Install the new dowel pins & gasket, right crankcase cover and connect the clutch cable.
- Install kick stopper with side stand, kick start pedal and exhaust muffler.
- Install the side stand switch bolts.
- Fill the crankcase with clean engine oil as per specification (**page 36**).



#### NOTE

- *Clean filters as specified in the maintenance schedule.*
- *Ensure to replace gasket & dowel pin with new one once removed*


## AIR CLEANER

### Air cleaner element inspection

The air cleaner is wet paper pleated type filter which has enhances filtering efficiency. The air cleaner should be replaced at regular intervals (**page 33**). When riding in dusty


areas, more frequent replacement may be necessary.

- Remove the seat assembly (**page 25**).
- Remove the air cleaner cover screws (1) and the cover (2).



(1) Side cover screws (2) Side cover

- Remove the air cleaner element (3).



(3) Air cleaner element





#### NOTE

**Align the tabs of air cleaner cover before installing screws & the cover.**



#### CAUTION



- **Never wash or clean the wet, paper pleated type filter. Replace filter element once in every 15000 km.**
- **Replace it earlier if it becomes very dirty, damage on surface or on the sealing area.**


- Clean the air cleaner housing using a shop towel.
- Install the new air cleaner element.
- Install the air cleaner element cover.
- Install the seat (**page 25**).

#### **Air cleaner drain tube cleaning**

Remove the drain tube (1) and drain the deposit into a container.

Follow the above process more frequently when riding in rain or at full throttle.





**(1) Drain tube**



### NOTE

***Always ensure to reinstall the drain tube after draining the deposit.***

## VALVE CLEARANCE ADJUSTMENT


Excessive valve clearance will cause noise, and little or no clearance will prevent the valve from closing and cause valve damage and power loss. Check valve clearance at the specified intervals **(page 33)**.



### NOTE

***The checking or adjustment of valve clearance should be performed while the engine is cold. The clearance will change as the engine temperature rises.***

- Remove the fuel tank cover **(page 59)**.
- Remove the crankshaft hole cap (1) and timing hole cap (2).
- Remove the cylinder head cover.



**(1) Crankshaft hole cap  
(3) "T" mark**


**(2) Timing hole cap  
(4) Index mark**

- Rotate the flywheel anticlockwise until the "T" mark (3) on the flywheel coincides with the index mark (4) on the left crankcase cover. In this position the piston will either be on the compression or exhaust stroke.


The adjustment must be made when the piston is at top dead center and both the inlet and exhaust valves are closed.

This condition can be determined by moving the rocker arms. If they are free, it is an indication that the valves are closed and the piston is in compression stroke. If they are tight, the valves are open, rotate the flywheel 360° anticlockwise and realign the "T" mark with the index mark.

- Check the clearance by inserting the feeler gauge (5) between the adjusting screw (6) and valve stem (7).



(5) Feeler gauge (6) Adjusting screw  
(7) Valve stem (8) Lock nut



### Standard clearance (cold condition)

**Intake: 0.12 mm**

**Exhaust: 0.13 mm**

- If adjustment is required, adjust by loosening the lock nut (8) and turning the adjusting screw until there is a slight drag on the feeler gauge.

- After tightening the lock nut, check the clearance again.
- Installation is in the reverse order of removal.



### NOTE


*Before inserting the feeler gauge, smear a bit of engine oil on the feeler gauge to avoid damage to the feeler gauge.*

## CLUTCH LEVER FREE PLAY

### Adjustment


Clutch adjustment may be required if the vehicle stalls when shifting into gear or tends to creep or if the clutch slips, causing acceleration to lag behind engine speed.

Normal clutch lever free play (1) is 10–20 mm at the lever (2).



(1) Free play: 10–20 mm (2) Clutch lever

- To adjust the free play, loosen the lock nut (3). Turn the adjusting nut (4) to obtain the specified free play. Tighten the lock nut and check the adjustment.



**(3) Lock nut (4) Clutch cable adjusting nut**  
**(A) Decrease free play (B) Increase free play**

- Start the engine, press the clutch lever and shift into gear. Make sure the engine does not stall, and the vehicle does not creep. Gradually release the clutch lever and open the throttle. The vehicle should start smoothly and accelerate.



#### NOTE

***If proper adjustment cannot be obtained or the clutch does not work correctly, visit your Authorised Hero MotoCorp workshop.***

#### Other checks

- Check the clutch cable for kinks or signs of wear that could cause sticking or failure.
- Check for clutch cable model. Use genuine clutch cables.
- Check for clutch cable routing.

## THROTTLE OPERATION

### Cable inspection


Check for smooth rotation of the throttle grip from the fully open to the fully closed position. Check at full left and full right steering positions. Inspect the condition of the throttle cable from the throttle grip down to the throttle body. If the cable is kinked, chafed or improperly routed, it should be replaced or rerouted. Standard throttle grip free play (1) is approximately 2–6 mm of grip rotation.



**(1) Free play 2–6 mm**

### Free play adjustment

To adjust the free play, slide the boot (2), then loosen the lock nut (3). Turn the adjuster (4) to adjust free play. After adjustment, tighten the lock nut and slide the boot on the adjuster and locknut securely.



- (2) Boot      (3) Lock nut      (4) Adjuster  
(A) Decrease free play    (B) Increase free play

## DRIVE CHAIN SLACKNESS

The service life of the drive chain depends upon proper lubrication and adjustment.


Poor maintenance can cause premature wear or damage to the drive chain and sprockets.

The drive chain (1) should be checked and lubricated as part of the pre-ride inspection (page 24). Under severe usage, or when the vehicle is ridden in unusually dusty areas, more frequent maintenance will be necessary.

### Inspection

- Turn the engine “OFF”, park the vehicle on its main stand and shift the transmission to neutral.
- Drive chain slack (2) should be checked in the lower run midway between the sprockets. Move the drive chain up and down by hand and chain slack should be adjusted to 20–25 mm vertical movement by hand.

- Rotate the wheel and check the drive chain slack. Repeat this procedure several times. Drive chain slack should remain constant (20–25 mm). If the chain is slack only in certain sections, some links are kinked or binding. Binding and kinking can be eliminated by frequent lubrication.




- (1) Drive chain  
(2) Drive chain slack: 20–25 mm



### NOTE

*Drive chain slack should be adjusted at your Authorised Hero MotoCorp workshop as per the specification.*

- Turn the chain to view chain lock plate (3). Ensure that the chain lock plate open end (4) is installed in the opposite direction of the chain rotation.
- Rotate the rear wheel slowly and inspect the drive chain and sprockets for any of the following conditions.



(3) Chain lock plate

(4) Open end

### Drive chain


- Damaged rollers
- Loose pins
- Dry or rusted links
- Kinked or binding links
- Excessive wear
- Improper adjustment
- Damaged or missing O-rings.

### Sprockets

- Excessively worn teeth
- Broken or damaged teeth.

If the drive chain has damaged rollers, loose links or missing O-rings, replace it. If the chain is dry or rusted, it should be lubricated. Lubricate the chain if the links are kinked or binding. If the problem is not solved after lubrication, replace the chain.

If the drive chain or sprockets are excessively worn or damaged, they should be replaced.



### ! CAUTION

**Always replace the drive chain and sprockets as a set. Otherwise the new part will wear prematurely.**

### Adjustment


Drive chain slack should be checked and adjusted, if necessary at every 1 000 km.

When operated at sustained high speeds or under conditions of frequent rapid acceleration, the chain may require more frequent adjustments.


If the drive chain requires adjustment, follow the procedures below:

- Park the vehicle on its main stand with the transmission in neutral and the ignition switch in “OFF” position.
- Loosen the rear axle nut (1).
- Loosen the drive chain lock nut (2).
- Turn the adjusting nut (3) in an equal number of turns until the correct drive chain slack is obtained. Turn the adjusting nut clockwise to decrease the slack or

- anticlockwise to increase the slack of the chain.
- Align the chain adjuster index mark (4) with the rear edge (5) of the adjusting slots on both sides of the swingarm equally.



**(1) Rear axle nut**



**(2) Drive chain lock nut**  
**(3) Drive chain adjusting nut**    **(4) Index mark**  
**(5) Axle**                      **(6) Rear edge of adjusting slot**

- Tighten the rear axle nut.

**Torque: 6.8 kgf-m**

- Check the drive chain slack again.
- If after adjustment of drive chain slack, axle (5) touches to the rear edge of adjustment slot (6). Chain kit has to be replaced.

### **WARNING**

***If a torque wrench is not used for installation, see your Authorised Hero MotoCorp workshop as soon as possible to check for proper assembly.***

### **Cleaning and Lubrication**

Lubricate every 1000 km or sooner if the chain appears dry.

- Turn the engine off, park the vehicle on its main stand and shift the transmission into neutral. Open side stand to facilitate cleaning.
- Spray a commercially available chain cleaner for cleaning the drive chain over its entire length.



### **NOTE**

***Ensure that the chain cleaner and lubricant used is the one recommended for use on an O-ring chain, otherwise the O-rings may deteriorate, fail and lose their sealing properties.***

- Rotate the rear wheel backwards to expose the next section of the drive chain and repeat second step until all of the drive chain is cleaned.
- Let the spray dry for about five minutes.
- To remove stubborn dirt, scrub the rollers and side plates with soft nylon brush.



- Apply SAE 90 grade oil on the hanger side of the entire length of the chain using an oil can.
- Wait for 7-10 minutes for penetration of lubricant inside the bush and roller wipe the excessive lubricant from the chain and nearby parts using a clean rag.



### NOTE

*Excessive lubricant if not wiped off, will aid in accumulation of dust, sand and dirt on the drive chain, increasing its wear and will also be sprayed on the vehicle as well due to chain movement.*




### CAUTION

- Steam cleaning, high pressure washers and certain solvents can damage the drive chain O-rings.
- While lubricating and cleaning hold the rear wheel with one hand to prevent the possibility of your finger being trapped between the chain and sprocket.
- Clean and lubricate the chain, whenever possible, after riding the vehicle under rain or in terrain with excessive dust, mud or sand.
- The drive chain is fitted with O-rings between the link plates. These O-rings retain grease inside the chain to improve its service life. However, special precautions must be taken when adjusting, lubricating, washing and replacing the chain.
- If the chain is excessively dirty, it should be removed and cleaned before lubrication. For your own safety, we recommend that service be performed by an Authorised Hero MotoCorp workshop.

## DRIVE CHAIN SLIDER INSPECTION

(Refer to “Maintenance schedule” on **page 32**).

Check the chain slider (1) for wear, The chain slider must be replaced if wear limit is reached. For replacement, see your Authorised Hero MotoCorp workshop.



(1) Chain slider

(2) Wear limit

## BRAKES

Refer to the safety precautions on (**page 31**).

### (a) Front brake

#### Master Cylinder/Reservoir (1)


**Location :** Right handlebar.

#### Brake fluid recommended:

DoT3 or DoT-4.


**Fluid level** – Ensure that the brake fluid level does not fall below “LWR” (lower) mark (2) on master cylinder, when checked with the master cylinder parallel to the ground. The level decreases gradually due to piston movement to compensate pad wear. If the

level decreases abruptly, check for the leakages in the brake system and consult your Authorised Hero MotoCorp workshop.



(1) Master cylinder

(2) "Lower" mark



(3) Brake pad

(4) Caliper

(5) Disc



### NOTE

- Clean the dirt and mud accumulation between the front brake caliper (3), brake pads (4) and the disc (5) by using a water jet.

- **Always contact your Authorised Hero MotoCorp workshop for refilling of master cylinder/reservoir when necessary. Do not mix DoT 3 and DoT 4 brake fluid.**
- **Always use recommended tyres (page 55) for better braking performance.**

### (b) Rear brake (Disc type)


Refer to the safety precautions on (page 32).  
Reservoir (1)

**Location :** Near pillion footrest.

**Brake fluid recommended:**

DoT3 or DoT-4.


**Fluid level** – Ensure that the brake fluid level does not fall below "LOWER" mark (2) on the reservoir parallel to the ground. The level decreases gradually due to piston movement to compensate pad wear. If the level decreases abruptly, check for the leakages in the brake system and consult your Authorised Hero MotoCorp workshop.



(1) Reservoir

(2) "Lower" mark





(3) Rear caliper (4) Brake pads (5) Disc



### NOTE


- **Clean the dirt and mud accumulation between the rear brake caliper (3), brake pads (4) and the disc (5) by using a water jet.**
- **Always contact your Authorised Hero MotoCorp workshop for refilling of reservoir when necessary. Do not mix DoT 3 and DoT 4 brake fluid.**

### (c) Brake pad wear

Brake pad wear depends upon the severity of usage, type of riding & road conditions. Generally, the pads will wear faster on wet & dirty roads. Inspect the pads at each regular maintenance interval.

#### Front brake

- Check the brake pads for wear by examining the wear indicator groove (1) on each pad.
- If either pad is worn to the bottom of the grooves replace both pads as a set. Visit your Authorised Hero MotoCorp workshop for this service.




(1) Wear indicator groove

### Rear brake (Disc type)

Check the wear indicator groove (1) in each pad.

If either pad is worn to the bottom of the groove, replace both as a set. Visit your Authorised Hero MotoCorp workshop for this service.



(1) Wear indicator groove




### WARNING


**Always apply front and rear brakes simultaneously to avoid skidding of vehicle.**

#### (d) Rear brake (Drum type)

- Park the vehicle on its main stand.
- Measure the distance brake pedal (1) moves before the brake starts to take hold. Free play (2) should be 20–30 mm.




(1) Rear brake pedal  
(2) Free play 20–30 mm



(3) Adjusting nut (4) Brake joint pin

CW- Clockwise ACW- Anticlockwise

- If adjustment is necessary, turn the rear brake adjusting nut (3).
- Make sure that the cut-out on the adjusting nut is seated on the brake arm pin (4) after the final adjustment has been made.
- Apply the brake several times and check for free wheel rotation when released.



(3) Adjusting nut (4) Brake arm pin




#### NOTE

*If proper adjustment cannot be obtained by this method, visit your Authorised Hero MotoCorp workshop.*

#### (e) Brake wear indicators (Drum type) Rear brake wear indication

When the brake is applied, an arrow (1), fixed to the brake arm (2), moves towards a reference mark (3) on the brake panel (4).

If the arrow aligns with the reference mark on full application of the brake, the brake shoes must be replaced.



(1) Arrow  
(3) Reference mark

(2) Brake arm  
(4) Brake panel

## SUSPENSION

### Front and rear suspension inspection

- Check the front forks by locking the front brake and pumping the front fork up and down vigorously. The suspension action should be smooth and there should be no oil leakage.

Front



Rear




- Check the rear mono shock absorber by pushing hard downwards on rear grip while the vehicle is not parked on stand. The suspension action should be smooth and there should be no oil leakage.

### Rear mono shock absorber adjustment

Rear shock absorber adjustment can be made in any position from 1st to 7th according to the load/road conditions or owner's requirement.

### Recommend adjustment

- Solo rider : 3rd position
- Rider + Pillion: 7th position



(1) Rear mono shock absorber  
(2) Pin spanner (3) Pin spanner handle  
(A) Softer (B) Stiffer

- In direction A: Softer
- In direction B: Stiffer



### NOTE

To adjust the rear mono shock absorber (1), use the rear shock absorber adjustment tool [Pin spanner (2) with handle (3)] available in the tool kit.


## WHEEL

### (a) Front wheel

#### Removal

Refer to the safety precautions on **(page 32)**.

- Support the vehicle securely on the main stand and raise the front wheel off the ground.
- Remove the wheel speed sensor bolt (1) from right fork leg and disconnect the wheel speed sensor cable (2).




(1) Wheel speed sensor bolt  
(2) Wheel speed sensor cable

- Remove the front axle nut (3), remove the axle (4) and wheel (5).



(3) Axle nut (4) Axle (5) Wheel



(6) Side collars

#### Installation

- Install the side collars (1) to both sides of the wheel hub.
- Insert the disc (2) between the pads in the caliper assembly (3). When installing the wheel, carefully fit the brake disc between the brake pads to avoid damage to the pads.
- Tighten the front axle nut (4) to the specified torque.

**TORQUE : 5.9 kgf-m**

**! CAUTION**  
**Do not operate front brake lever when the wheel is removed.**

- Remove the side collars (6) from both sides from the wheel.

- After installing the wheel apply the brake several times and then check if the wheel rotates freely. Recheck the wheel if the brake drags or if the wheel does not rotate freely.




(1) Side collar (2) Disc (3) Caliper  
(4) Front axle nut

### (b) Rear wheel (Disc type)

#### Removal

Refer safety precautions on (page 32).


- Support the vehicle securely on the main stand and raise the rear wheel off the ground.
- Remove the rear axle nut (1) and indicator plate (2).
- Remove the axle (3) and the right side collar (4).
- Move the caliper assembly (5) upwards.
- Remove the wheel.



(1) Rear axle nut (2) Indicator plate (3) Axle  
(4) Side collar (5) Caliper assembly

#### Installation

- Install the side collar (1) to the right side of the wheel hub.
- Tilt the vehicle and position the rear wheel between the swingarm.
- Insert the disc (2) between the pads in the caliper assembly. When installing the wheel, carefully fit the brake disc between the brake pads to avoid damage to the pads.
- Align the rear caliper holder (3) with the swingarm (4).
- Insert the axle (5) from the left side through the swingarm, wheel hub, collar and rear caliper holder.



(1) Side collar (2) Disc (3) Caliper holder  
(4) Swingarm (5) Rear axle  
(6) Indicator plate (7) Rear axle nut


- Install the indicator plate (6) and tighten the rear axle nut (7) to the specified torque.

**TORQUE : 6.8 kgf-m**


- Adjust the drive chain slack (**page 44**).

### (c) Rear wheel (Drum type)

- Support the vehicle securely on the main stand and raise the rear wheel off the ground.
- Remove the rear brake adjusting nut (1) and disconnect the brake rod (2) from the brake arm (3) by pushing down the brake pedal.
- Remove the rear axle nut (4).
- Pull out the axle (5) and collar (6).
- Remove the wheel.



(1) Rear brake adjusting nut  
(2) Rear brake rod (3) Brake arm



(4) Axle nut (5) Axle (6) Collar


### Installation

- Reverse the removal procedure
- **Axle nut torque: 6.8 kgf-m.**
- Adjust the rear brake free play (**page 50**) and drive chain slackness (**page 44**).
- After installing the wheel, apply the brake several times and check for free wheel rotation when released.



## MAIN/SIDE STAND LUBRICATION

- Park the vehicle on the level surface.
- Check the main/side stand return spring for damage or loss of tension.
- Check the main stand (1)/side stand (2) for freedom of movement.
- Lubricate the side stand pivot if necessary.
- Make sure the main/side stand is not bent.



(1) Main stand

(2) Side stand

## TUBELESS TYRES

The tyres fitted on your vehicles are of TUBELESS type.

To safely operate your vehicle, your tyres must be of the proper type and size, in good condition with adequate tread, and correctly inflated for the load you are carrying.

The following pages give more detailed information on how and when to check the air pressure, how to inspect your tyres for damage, and what to do when your tyres need to be repaired or replaced.

## WARNING

- *Using tyres that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.*
- *Follow all instructions in this owner's manual regarding tyres inflation and maintenance.*

## Air pressure

Keeping your tyres properly inflated provides the best combination of handling, tread life and riding comfort.

Generally, under-inflated tyres wear unevenly, adversely affect handling and are more likely to fail from being overheated.

Under inflated tyres can also cause wheel damage in rocky terrain.

Over-inflated tyres make your vehicle ride harshly, are more prone to damage from road hazards, and wear unevenly.

We recommend that you visually check your tyres before every ride and use a gauge to measure air pressure at least once a month or any time you think the tyres pressure might be low. Tubeless tyres have some self-sealing ability if they are punctured. However, because leakage is often very slow, you should look closely for punctures whenever a tyre is not fully inflated.

Always check air pressure when your tyres are "cold"—when the vehicle has been parked for at least three hours. If you check air pressure when your tyres are "warm"—when the vehicle

has been ridden for even a few km—the readings will be higher than if the tyres were “cold”. This is normal, so do not let air out of the tyres to match the recommended cold air pressures given below. If you do, the tyres will be under-inflated.

The recommended “cold” tyre pressures are:

	<b>Rider only</b>	<b>Rider and Pillion</b>
<b>Front</b>	1.75 kgf/cm <sup>2</sup> (25 psi)	1.75 kgf/cm <sup>2</sup> (25 psi)
<b>Rear</b>	1.96 kgf/cm <sup>2</sup> (28 psi)	2.10 kgf/cm <sup>2</sup> (30 psi)



**(1) Air pressure gauge**

### **! CAUTION**


***Over inflation/Under inflation will affect the performance.***

### **Inspection**


Whenever you check the tyre pressure, you should also examine tyre treads & side walls for wear, damage & foreign objects.

Look for:

- Bumps or bulges in the side of the tyre or the tread. Replace the tyre if you find any bumps or bulges.
- Cuts, splits or cracks in the tyre. Replace the tyre if you can see fabric or cord.



- Excessive tread wear.



- Carefully inspect the tyres for any damage, if the vehicle hits a pothole or hard object.



## Tread wear


Replace tyres immediately when the wear indicator (1) appears on the tyre. The tread limits are:

### MINIMUM TREAD DEPTH:

**Front:** 0.8 mm

**Rear:** 1.0 mm

Check the tread wear indicator for tyre wear.



(1) Tread wear indicator

(2) Arrow mark

## Unidirectional tyres

Whenever the tyre is removed and put back in case of puncture, ensure the arrow mark (2) on the tyre is in the same direction as that of forward rotation of wheel.

## Tyre repair

Repairing a puncture or removing a wheel requires special tools and technical expertise. If a tyre is punctured or damaged, it is advised to visit nearest tyre manufacture, Hero MotoCorp authorised dealer/workshop or the

tyre repair shop who has expertise in repairing methods of tubeless tyre.

A tyre that is repaired either temporarily or permanently, will have lower speed and performance limits than a new tyre. After an emergency repair, always have the tyre inspected/replaced at our authorised dealer and replace the tyre if suggested.

You should not exceed **70 km/hour** for the 1st 24 hours or **105 km/hour** at any time thereafter. In addition, you may not be able to safely carry as much load as with a new tyre.

If you decide to have a tyre replace be sure the wheel is balanced before you ride.

## Tyre replacement

The tyres that were installed on your vehicle were designed to match the performance capabilities of your vehicle and provide the best combination of handling, braking, durability and comfort.

The recommended tyre for your vehicle are:

<b>Front</b>	100/80 17 52 P (Tubeless tyre)
<b>Rear</b>	130/70 R17 62 P (Radial tubeless tyre)



### NOTE

**For repair and replacement of tyre it is advised to visit your Authorised Hero MotoCorp workshop.**

### **WARNING**

- **Operation with excessively worn tyres is hazardous and will adversely affect traction and handling.**
- **Under-inflation may result in the tyre slipping on or tyre coming off the rim.**
- **Always use the size and type of tyres recommended in this owner's manual.**

### **NOTE**

***The imported tyre(s) if fitted without ISI mark; are in compliance of BIS standard and Central Motor Vehicle Rules 1989, as declared by the Tyre manufacturer.***

### **Important safety reminders**

- Do not install a tube inside a tubeless tyre on this vehicle. Excessive heat buildup can cause the tube to burst.
- Use only tubeless tyres on this vehicle. The rims are designed for tubeless tyres, and during hard acceleration or braking, a tube-type tyre could slip on the rim and cause the tyre to rapidly deflate.

### **NUTS, BOLTS & FASTENERS**

- Tighten bolts and nuts at regular interval shown in the maintenance schedule.
- Check that all chassis nuts and bolts are tightened to correct torque values.
- Check that all cotter pins, safety clips, hose clamps and cable stays are in place.



### **BATTERY**

Refer to the safety precautions on **(page 32)**.

#### **Location**

The battery is located behind the left side of fuel tank cover.

#### **Specification**

**\*MF Battery-12V-4 Ah/ETZ5**

It is not necessary to check the battery electrolyte level or add distilled water as the battery is a **Maintenance-Free (sealed)** type. If your battery seems weak and/or electrolyte is leaking (causing hard starting or other electrical troubles), contact your Authorised Hero MotoCorp workshop.

**\*MF stands for Maintenance Free**



## NOTE



*This symbol on the battery means that this product must not be treated as household waste.*



*This symbol on the battery means the old battery must be returned to your Authorised Hero MotoCorp workshop as it must be treated as recyclable material.*

- **Battery is a maintenance-free (sealed) type and can be permanently damaged if the sealing strip is removed.**
- **An improperly disposed battery can be harmful to the environment and human health. Always confirm local regulations for battery disposal.**

## Battery charging

Always visit your Authorised Hero MotoCorp workshop if you see any symptom of battery discharge as earliest as possible to get the battery charged. The battery has a tendency to discharge rapidly if additional electrical accessories are fitted on the vehicle.


## Battery storage

- If in case your vehicle is not used for more than a month remove the battery, fully charge and store in a cool and dry place.
- If the battery is expected to be stored for more than two months, ensure to fully charge the battery once in a month.
- Always ensure the battery is fully charged before installation.

- Ensure the battery leads are properly connected to the battery terminals during installation.


## Battery removal

- Make sure the ignition switch is “OFF” (⏻).
- Remove the seat (**page 25**).
- Remove the screws (1) from the both the sides.



**(1) Screws**

- Remove the bolts (2) from the both rear and front side of the fuel tank.




**(2) Bolts**

- Remove the fuel tank cover (3).



**(3) Fuel tank cover**

- Disconnect the (-)ve terminal lead (4) from the battery first, then disconnect the (+)ve terminal lead (5).
- Remove the battery clamp bolt (6) and battery clamp (7).



**(4) (-)ve terminal**

**(5) (+)ve terminal**

**(6) Battery clamp bolt**

**(7) Battery clamp**

- Pullout the battery (8) from the battery box.



**(8) Battery**

### **Battery installation**

- Reinstall in the reverse order of removal. Be sure to connect the (+)ve terminal first, then the (-)ve terminal.
- Check all fasteners are secure.


### **FUSE REPLACEMENT**

Refer to the safety precautions on **(page 32)**.

The fuse box (A) is below the seat.

Main fuse (1) : 15A, 10A, 10A & 10A

Spare fuse (2) : 15A & 10A



**(A) Fuse box**

(1) Main fuse: 15A, 10A, 10A & 10A

(2) Spare fuse: 15A & 10A


**Starter magnetic switch (B)**

**Location :** Inside left side of fuel tank cover, below the starter magnetic switch.

**Fuse Type: Blade fuse**

Main fuse (1) : (20A)

Spare fuse (2) : (20A)



**(B) Starter magnetic switch**

(1) Main fuse (20A) (2) Spare fuse (20A)


**! WARNING**

- *Never use a fuse with a different rating from that specified. It may lead to serious damage to the electrical system or a fire due to short circuit.*
- *Battery gives off explosive gases. Keep sparks, flames & cigarettes away.*


**! CAUTION**

- *Do not attempt to start or ride the vehicle without a charged battery, it can cause fusing of the bulbs and permanent damage to certain electrical components.*
- *Turn the ignition switch "OFF" before checking or replacing the fuse to prevent accidental short-circuiting.*

GOOD FUSE



BLOWN FUSE




**STOP LAMP SWITCH**

The stop lamp switch (1) must be adjusted so that stop lamp glows when rear brake is applied. The procedure for adjusting stop lamp is as follows :

- Turn the ignition switch to the "ON" (O) position.

- Turn the adjusting nut (2) to position stop lamp switch at a point where the stop lamp glows once the brake pedal is depressed. Turn the adjusting nut in direction (A) to advance switch timing or in direction (B) to retard switch timing.




(1) Stop lamp switch  
(2) Adjusting nut

(A) Advance  
(B) Retard

## HEADLAMP FOCUS ADJUSTMENT

Headlamp is preset. However in case of adjustment required, please follow the steps as given below:

- Headlamp adjustment is done by the loosening the bolt (1) located below the headlamp.
- Park the vehicle on its main stand on level ground.
- Turn the ignition switch to “ON” position (ⓘ) and start the engine.
- Adjust the headlamp beam by loosening the bolt (1) and moving the headlamp unit forward and backward for correct focus adjustment.



(1) Headlamp adjusting bolt

- Tighten the bolt after adjustment.

## WARNING

*An improperly adjust headlamp may blind oncoming rider/driver or it may fail to light the road for a safe distance.*

## CATALYTIC CONVERTER

This vehicle is equipped with a catalytic converter (1) in the muffler to meet the emission norms.


The catalytic converter contains precious metals that serve as catalysts, promoting chemical reactions to convert the exhaust gasses without affecting the metals. The catalytic converter acts on HC, CO and NOx. The catalytic converter must operate at a high temperature for the chemical reactions to take place. It can set on fire any combustible material that come near it. Park your vehicle away from high grasses, dry leaves, or other flammable material.



A defective catalytic converter contributes to air pollution and can impair your engine's performance.

Follow these guidelines to protect your vehicle's catalytic converter.

- Always use unleaded petrol. Even a small amount of leaded petrol can contaminate the catalyst metals, making the catalytic converter ineffective.
- Keep the engine tuned up.




**(1) Catalytic converters**

## EVAPORATIVE EMISSION CONTROL SYSTEM

This vehicle is equipped with an evaporative emission control system to meet emission standards. During warm weather, the petrol vapours which contain HC evaporates easily into the atmosphere from the fuel tank, if the fuel system is unsealed or open.

The evaporative emission control system is used to prevent petrol vapours from escaping into the atmosphere from fuel tank.

The canister (1) collects the fuel vapour from the fuel tank and then the fuel vapour is drawn into the engine for re-burning to avoid pollution caused by the fuel vapour diffused into the air.



**(1) Canister**

## POLISHING OF VEHICLE

After washing your vehicle, wax all painted surfaces (except matte painted surfaces) using a commercially available polish/quality liquid or paste wax to finish the job. Use only a non abrasive polish or wax made specifically for automobiles. Apply the polish or wax according to the instructions on the container.



### NOTE

***Polishing or waxing is not applicable for models having matte paint.***

## BASIC TROUBLESHOOTING

### 1. STARTING TROUBLE - ENGINE DOES NOT START


#### A. Integrated Start-Kill Switch




#### B. Side Stand Engine Kill System



#### C. Fuel System




#### D. Electric Starter Not Working





## BASIC TROUBLESHOOTING


### E. No Spark At Spark Plug



### 2. ENGINE STARTS BUT STALLS




### 3. POOR PICK UP



## BASIC TROUBLESHOOTING

### 4. ELECTRICAL SYSTEM

#### Feeble Horn Sound or No Light



## ROAD SIGNS



**Mandatory signs:** These road signs inform drivers/riders of the traffic rules that apply on a certain stretch of road, thereby instructing them on how to drive/ride. Mandatory signs are distinguished by the bright red circle with black and blue markings. It is imperative that all riders follow these signs as they help avoid accidents. Their violation can be penalised under the Motor Vehicle Act.

### Mandatory



Stop



Give Way



One Way



No Horn



No Bicycles



No Automobiles



No Hand Craft



No Pedestrians



No Right Turn



No 'U' Turn




Overtaking Prohibited



Speed Limit



No Stopping  
or Standing



No Parking



Length Limit




High Limit



Restriction Ends




Compulsory-  
Ahead Only




Compulsory-Turn  
Left



Compulsory-Right  
Ahead



Compulsory-Ahead  
or Turn Right



Compulsory-Keep  
Left



Compulsory-Bicycle  
Track



Compulsory-Sound  
Horn

## ROAD SIGNS



**Cautionary signs:** These signs inform the driver/rider of the road conditions ahead. Cautionary signs therefore serve as a warning. They are usually in a red triangle with black pictures on a white background. Illustrations, diagrams and symbols are used to forewarn about dangers ahead. Cautionary road signs are as important as mandatory signs. However, the violation of cautionary signs does not attract penalty.

### Cautionary



Right Hand Curve



Right Reverse Bend



Incline Ahead



Narrow Road Ahead



Narrow Bridge



Pedestrian Crossing



School Ahead



Gap in Medium



Cross Road



Men at Work



Roundabout



Hump Road

## ROAD SIGNS

**Informatory signs:** These are facility signs that provide important information about road directions are maps of specific destinations. On highways, they provide information about the location of public telephones, restaurants, hospitals, parking, petrol pumps, resting-places and more. These signs are usually rectangular, with black or white pictures on a blue background.

### Informatory



Destination Sign



Hospital



First Aid Post



Petrol Pump



Eating Place



Resting Place



Public Telephone



Place Identification Place



Light Refreshment



Taxi Stand



Parking Both Sides



Parking This Side



No Through Road



No Through Side Road



Re-assure Sign

Signs and Signals are language of the road. Learn them, respect them.



# Hero MotoCorp Ltd.

## WARRANTY

### Scope of warranty

Hero MotoCorp Ltd. (hereinafter called 'Hero MotoCorp') warrants its **XTREME 160 R PROGRAMMED FI** vehicles, assembled/manufactured in its Plants and sold through its channel partners, to be free from any defect – both in material and workmanship, under normal use and conditions, subject to the following terms & conditions.

### Terms & conditions

- a) **XTREME 160R PROGRAMMED FI** vehicle is warranted for a period of **5 years or 70000 Km**, whichever is earlier, from the date of purchase, emission warranty is separately covered under the head of "Emission Warranty".
- b) It is advised that the purchaser avails all free and paid services from the Hero MotoCorp's authorized workshop as per the recommended schedule, to be eligible for warranty benefits. Each paid service should be availed within **90** days from the date of previous service or as per the recommended schedule, whichever is earlier.
- c) If any problem is observed in **XTREME 160R PROGRAMMED FI** vehicle, Hero MotoCorp's only obligation/ liability is to repair or replace that part/those parts which is/are considered to be the cause of such problem, provided however that such problem has not resulted due to misuse/improper handling etc. of the vehicle. Any **XTREME 160R PROGRAMMED FI** vehicle needing repair should be brought along with owner's manual to Hero MotoCorp's authorized workshop for necessary inspection and carrying rectification job.



# Hero MotoCorp Ltd.

## LIMITATIONS OF WARRANTY

### The warranty shall not apply—

- (1) If all free services/paid services/oil top-ups are not availed as per the recommended schedule at Hero MotoCorp's authorized workshop.
- (2) If any other engine oil which is non compatible with product is used other than SAE 10W30 SL Grade (JASO MA2).
- (3) To normal wear & tear components including (but not limited to) brake shoes/pads, clutch plates, drive chain & sprockets, bulbs, electrical wiring, filter, spark plug, fasteners, shims, washers, oil seals, gaskets, rubber parts, bush, rubber bellows, plastic parts breakage, wheel rim for misalignment/bend, steering ball race & cone, control cables such as brake cable/clutch cable, fuses (all types), steering handle for bend and sticker peel off.
- (4) If additional wheel(s) is/are fitted and/or any other modification carried out/unauthorized accessories fitted which shall be responsible for malfunction/deterioration of the vehicle.
- (5) If **XTREME 160R PROGRAMMED FI** vehicle has been used in any competitive events like races or rallies or for any commercial purposes as taxi etc.
- (6) To any damage on vehicle's painted surface cropping due to industrial pollution or other external factors.
- (7) For normal phenomena like noise vibration, oil seepage etc., which do not affect the performance of the vehicle.
- (8) To any damage caused due to usage of improper oil/grease, non-genuine parts.
- (9) If any defect crops or repairs needed as a result of using adulterated fuel.
- (10) If any maintenance/repairs required due to bad road conditions or misuse of **XTREME 160R PROGRAMMED FI** vehicle.
- (11) If any defect crops or repairs needed as a result of **XTREME 160R PROGRAMMED FI** vehicle meeting to some accident.
- (12) For consumables like oil, grease, gasket etc to be used during free services and/or warranty repairs.
- (13) To any part of the **XTREME 160R PROGRAMMED FI** vehicle which has been tampered or repaired in such a manner which has resulted in malfunction of the vehicle.
- (14) For **XTREME 160R PROGRAMMED FI** vehicle not used in accordance with the guidelines given in this Owner's Manual.
- (15) To proprietary items like Tyres, Tubes, Batteries etc, as they are subjected to the warranty terms & conditions of respective manufacturers and directly handled by them only.
- (16) Any defect(s) developing on account of external factors such as environmental factors; including but not limited to fading/peeling/rusting of paint and/or stripes and/or plated parts, seat leather tearing & cracking, aluminium parts oxidation and cracking & discoloring of control switches etc.

**Decision regarding warranty settlement shall be taken by Hero MotoCorp and the same shall be final and binding on all concern.**

**Subject to DELHI JURISDICTION only.**



# Hero MotoCorp Ltd.

## **BATTERY WARRANTY PERIOD**

1. 18 months from date of sale of vehicle or 20000 km. or
2. 21 months from the date of charging (whichever is earlier).
3. 3 months idle period is allowed from the date of charging to date of sale on vehicle.

## **Terms and condition of warranty**

1. Batteries are warranted against all defects in material and workmanship. Liability under this warranty is limited to making good of defects rising solely from the use of faulty material or workmanship during manufacturing and developing under proper use. The warranty commences from the date of delivery to the original purchase of the vehicle.
2. In the event of any complaint the battery is to be returned complete with electrolyte to nearest battery service station or any OEM dealer. On inspection, battery would be returned or replaced.
3. This warranty card accompanies a battery sold as OEM fitment only. Claims should be supported with vehicle purchase invoice to enable processing.
4. The right to determine whether a battery needs repair or totally replacement lies with the company. In case where the battery is replaced, the defective battery becomes the property of the company and no scrap rebate will be given for it. The warranty period on the battery being repaired/replaced shall commence from the date of sale of the original battery as stated in the original warranty card.
5. All liabilities under this warranty will cease if the battery is used on the vehicle other than that on which the battery was originally fitted and on the expiry of the warranty period as mentioned above.
6. Recharging is not covered under the purview of this warranty and shall be billed as extra. However, FOC battery replacement/repair includes cost of charging.
7. This warranty does not cover damage to the battery caused by faulty electrical systems, incorrect charging and filling, improper handling of the battery by unauthorized dealers/auto electricians, maintenance, willfull abuse, destruction by fire, collusion, theft or recharging.
8. Breakage of container and cover do not come under the purview of this warranty.
9. Adjudication and settlement of claim will take a couple of days as a battery has to be tested for the reported failure.
10. In case of tempering of the original wiring circuit in any manner whatsoever.
11. If a battery which is not recommended is fitted on the vehicle then such battery will not carry any warranty.
12. The applicable taxes which is leviable on the battery under repair or replacement will be borne by the customer.
13. Customers are deemed to have read, understood and agreed to these conditions at the time of purchase of the vehicle.



# Hero MotoCorp Ltd.

## EMISSION WARRANTY

### Scope of warranty

Hero MotoCorp Ltd. Warrants all its vehicles, assembled/manufactured at its various Plants and sold through its channel partners, to comply with emission standards as specified in sub rule (2) of Rule 115 of Central Motor Vehicles Rules, 1989, subject to following terms & conditions.

### Terms & conditions

- a) The emission warranty shall be applicable in India and shall remain valid for a period of **3 years or 30000 km**, whichever occurs earlier, from the date of vehicle purchase.
- b) In case any defect is observed in any emission-related component which are covered under emission warranty, Hero MotoCorp only obligation/liability shall be to repair and/or replace those part (s) which is/are considered to be the cause of non-compliance with the emission standards.
- c) The method (s) of examination to determine the warranty conditions of the emission warranty related component will be at the sole discretion of Hero MotoCorp Ltd. and / or Channel Partners / service center and result of such examination shall be final and binding. If on examination the warranty conditions of the part (s) is / are not established, Hero MotoCorp Ltd. will have the right to charge all, or part of the cost of such examination / service charges to the customer in addition to the cost of the components.
- d) Hero MotoCorp Ltd. shall have the sole discretion to decide to replace the defective components or the entire assembly or any other part required for such repair.
- e) The emission warranty shall be applicable only to those vehicles, which are being regularly maintained in accordance with the maintenance schedule provided in the owner's manual.
- f) The customer should follow the recommended parts replacement as per the maintenance schedule in order to avail the emission warranty.
- g) If any part (s) related to emission characteristics of the vehicles is/are tampered and/or repaired by unauthorized person/workshops etc, then the emission warranty shall stand cancelled.
- h) Any part (s) suffering wear and tear under the normal course of running shall not be covered under the emission warranty. Therefore, all such parts should be replaced by the customer from time to time, on payment basis, as per the maintenance schedule provided in owner's manual and dealer's advice
- i) It is recommended to avail the services as per the recommended schedule to be eligible for the emission warranty benefits. Please ensure that each paid service is availed within **90 days** from the date of previous services or as per the recommended schedule, whichever is earlier. All service details should be completely filled by the dealer, in the **Service Record Sheet** given in the owner's manual.





# Hero MotoCorp Ltd.

## EMISSION WARRANTY

- j) It is mandatory to obtain a PUC certificate from the Authorised PUC center. In case of non-compliance with the emission standards please contact the channel partner/authorised workshop immediately along with the previous OK certificate, for the necessary rectification. The manufacturer or the dealer is not responsible for any penalty levied on you on account of non-compliance with the emission standards.
- k) The parts, which are covered under emission warranty are fuel injector, fuel pump, throttle body, ignition coil, oxygen sensor and muffler.
- l) Emission warranty shall not be applicable if
- The vehicle has been subjected to abnormal use, abuse, neglect and improper maintenance or has met with an accident.
  - The vehicle, or parts thereof, has been altered, tampered with or modified or replaced in an unauthorized manner.
  - The odometer is not functioning or the odometer and/or its reading has been changed/tampered with, so that the actual distance covered cannot be readily determined.
  - The vehicle has been used for competitions, races, and rallies or for the purpose of establishing records.
- m) All decisions regarding emission warranty settlement shall be taken by Hero MotoCorp Ltd. and shall be final binding on all concerned.

**Subject to Delhi jurisdiction only.**



## **WHAT ARE THE BENEFITS OF Hero MotoCorp GENUINE SPARE PARTS ?**

- Assures long life
- Ensures economy for a long time
- Safety of vehicle and rider
- Peace of mind
- Value for money
- Assured quality

## **CONSEQUENTIAL DAMAGES ON USING NON-GENUINE PARTS**

<b>Clutch Plate</b>	<ul style="list-style-type: none"><li>• Material used is inferior</li><li>• Damages other parts of clutch like, clutch center and outer clutch</li><li>• Affects fuel efficiency</li><li>• Poor acceleration</li></ul>
<b>Cam Chain Kit</b>	<ul style="list-style-type: none"><li>• Poor performance</li><li>• Reduced life</li></ul>
<b>Gasket Cylinder Head</b>	<ul style="list-style-type: none"><li>• Improper sealing</li><li>• Engine knocking</li><li>• Leads to leakage and smoky exhaust</li><li>• Higher emission level</li></ul>



## CONSEQUENTIAL DAMAGES ON USING NON-GENUINE PARTS

<b>Element Air Cleaner</b>	<ul style="list-style-type: none"><li>• Improper air filtration resulting in premature engine failure</li><li>• Affects fuel efficiency</li><li>• Poor engine performance</li></ul>
<b>Spark Plug</b>	<ul style="list-style-type: none"><li>• Frequent stalling of engine</li><li>• Higher emission level</li><li>• Poor engine performance</li><li>• Affects fuel efficiency</li></ul>
<b>Brake Pads/Shoes</b>	<ul style="list-style-type: none"><li>• Poor braking efficiency</li><li>• Rider safety—an issue</li><li>• Discs/Drum wear out, resulting in subsequent repair cost</li></ul>
<b>Chain Sprocket Kit</b>	<ul style="list-style-type: none"><li>• Noisy Operation</li><li>• Failure of chain can cause fatal accident</li></ul>

## ZONAL/REGIONAL/AREA OFFICES

**For any of your service related query/requirements you may contact the respective Zonal/Regional/Area Offices**

### CENTRAL ZONE

**Hero MotoCorp Ltd.**, No. 209-210, Ganpati Plaza, M.I. Road, Jaipur-302001, (Rajasthan).  
Tel: +91 141 2389031, +91 141 2389156, E-mail: jaipur@heromotocorp.com

**Hero MotoCorp Ltd.**, Office No. 705-706, 7th Floor, Fun Square, Durga Nursery Road, Udaipur -313001 (Rajasthan).  
Tel: +91 0294-2980578, 79, E-mail: udaipur@heromotocorp.com

**Hero MotoCorp Ltd.**, Office. No.401, 4th Floor, Offizo, Magneto Mall, Labhandi, G.E. Road, Raipur -492 001, (Chhattisgarh)  
Tel: +91-771-4034749, E-mail: raipur@heromotocorp.com

**Hero MotoCorp Ltd.**, Third Floor, Alankar Palace, Plot No. 11, Zone II, M.P. Nagar Bhopal-462011, India.  
Tel: +91-755-4203160, 2553697, 4272429, 2550086, E-mail: bhopal@heromotocorp.com

**Hero MotoCorp Ltd.**, Maloo-01, 601-602, 6th Floor, Plot No. 26C, Scheme No. 94, Ring Road, Indore, M.P.-452010,  
Tel: +91-731-4978269, 70, E-mail: indore@heromotocorp.com

### EAST ZONE

**Hero MotoCorp Ltd.**, Flat No: 1002, 10th Floor, Martin Burn Business Park, BP3, Salt Lake, Sector-V, Kolkata-700091, West Bengal, India. Tel: +91-33-44026841, +91-33-44026830, E-mail: kolkata@heromotocorp.com

**Hero MotoCorp Ltd.**, Odysa Business Centre, Plot no. 30, 30/982, 172/1030, 4th Floor Cuttack, Bhubaneswar highway road, Rasulgarh, Bhubaneswar-751010, Odisha, India. Tel: +91-674-2581161, 62, 63, 64, E-mail: bhubaneswar@heromotocorp.com

**Hero MotoCorp Ltd.**, Yash Heights, 1st Floor Bariatu Road, Above Basudeb Tata Showroom Ranchi-834009, Jharkhand, India. Tel: +91-651-2542222, 2542224, 2542225, E-mail: ranchi@heromotocorp.com

**Hero MotoCorp Ltd.**, Sai Corporate Park, A Block, 6th Floor, Rukanpura, Bailey Road Patna, Bihar - 800014  
Tel: +919334280555/7004569648 E-mail: patna@heromotocorp.com

### NORTH ZONE

**Hero MotoCorp Ltd.**, 3rd Floor, Tower-A, DLF Centre Court, Sector-42, Golf Course Road, DLF Phase 5, Gurgaon -122002, Haryana, India. Tel: 0124-4754800, E-mail: delhi@heromotocorp.com

**Hero MotoCorp Ltd.**, 602, 6th Floor, Office Tower-1, Plot No BW58, Logix City Center, Sector-32, Noida - 201301.  
Tel: 0120-4631000, E-mail: noida@heromotocorp.com

**Hero MotoCorp Ltd.**, S.C.O-367-368, First Floor, Sector-34A, Chandigarh-160022, India.  
Tel: +91-172-2623773, 2623774, 2623775, E-mail: chandigarh@heromotocorp.com

**Hero MotoCorp Ltd.**, Kapoor Towers, Plot No- 284, 15-B, Rajpur Road, Dehradun-248001, India.  
Tel: 0135-2714661, 2713662, 2714663, E-mail: dehradun@heromotocorp.com

## ZONAL/REGIONAL/AREA OFFICES

### NORTH ZONE

**Hero MotoCorp Ltd.**, Summit Building (10th Floor) Plot No TCG 3/3 Vibhuti Khand, Gomti Nagar Lucknow – 226010, India. Tel: 0522-4006594, E-mail: lucknow@heromotocorp.com

**Hero MotoCorp Ltd.**, C-19/134-B, Third Floor I.P Grand, Lallapura, Siga, Varanasi, Uttar Pradesh – 221010, India. Tel: +91-0542- 2390949, 2390241, E-mail: varanasi@heromotocorp.com

### SOUTH ZONE

**Hero MotoCorp Ltd.**, SKAV 909, 3rd Floor, 9/1, Lavelle Road, Bangalore-560001, India. Tel: +91-80- 46881000, E-mail: bangalore@heromotocorp.com

**Hero MotoCorp Ltd.**, 3-6-289, 3rd Floor, Kareem Manzil, Hyderguda, Hyderabad-500029, India. Tel: +91-40-23223735, 23223727, 23223570, E-mail: hyderabad@heromotocorp.com

**Hero MotoCorp Ltd.**, 9th Floor Seshachalam Centre No.636/1, Anna Salai, Nandanam, Chennai-600035, India. Tel: +91-44- 24340974, 24340977, 24340978, E-mail: chennai@heromotocorp.com

**Hero MotoCorp Ltd.**, 6-A, DD Trade Tower, (6th Floor), Kaloor-Kadavanthra Road, Kaloor-682 017, Kochi-682017, India. Tel: +91-0484- 4039646 -7, E-mail: cochin@heromotocorp.com

**Hero MotoCorp Ltd.**, No 1547, 2nd Floor Classic Towers, Trichy Road, Coimbatore – 641018 Tel: +91-422-2200058, 2200061, E-mail: coimbatore@heromotocorp.com

**Hero MotoCorp Ltd.**, First Floor VA Kalburgi Mahalakshmi Mansion, Mandakini Hospital Road, New Cotton Market, Hubli-580029, India. Tel: 0836-2269717, 2361038, E-mail: hubli@heromotocorp.com

**Hero MotoCorp Ltd.**, D.NO. 54-11-18 E, 2nd Floor, Sai Odyssey Building, Opp Executive Club, Near NH-5, Vijayawada-520008, Andhra Pradesh, India. Tel: +91-866-2546859, 2546860, E-mail: vijayawada@heromotocorp.com

### WEST ZONE

**Hero MotoCorp Ltd.**, Chrome Building, Sr. No. 33, Hissa-A-1/1/2, Plot – 2, Viman Nagar Avenue 2, Nagar Road, Pune-411014, India. Tel: +91-020-71903500, E-mail: pune@heromotocorp.com

**Hero MotoCorp Ltd.**, 603-604, Gunjan Tower, Off Alembic Gorwa Road, Baroda-390023, India. Tel: +91-265-2286569/2286570, E-mail: baroda@heromotocorp.com

**Hero MotoCorp Ltd.**, Ground Floor, Block No.2, Vishnu Vaibhav Complex, 222, Palm Road, Civil Lines, Nagpur-440001 India. Tel: +91-712-2545990-91, E-mail: nagpur@heromotocorp.com

**Hero MotoCorp Ltd.**, Astarc House-Third Floor, 76/79, Makwana Lane, Off. Andheri-Kurla Road, Andheri (East), Mumbai-400059, India. Tel: +91-22-28562071, E-mail: mumbai@heromotocorp.com

**Hero MotoCorp Ltd.**, 604, Kings Plaza, Astron Chowk, Rajkot, Gujarat – 360001 Tel: 0281-2460622, 2460623, E-mail: rajkot@heromotocorp.com