



Cisco Catalyst 8000V Edge Software Installation And Configuration Guide

First Published: 2020-12-21

Last Modified: 2023-08-22

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

Full Cisco Trademarks with Software License ?

CHAPTER 1

Preface 1

- Audience and Scope 1
- Feature Compatibility 1
- Document Conventions 2
- Communications, Services, and Additional Information 3
- Documentation Feedback 4
- Troubleshooting 4

CHAPTER 2

Overview of Cisco Catalyst 8000V 5

- Benefits of Virtualization Using the Cisco Catalyst 8000V Router 5
- Router Interfaces 6
- Cisco IOS XE and Cisco Catalyst 8000V 6
- Cisco Unified Computing System (UCS) Products 7

CHAPTER 3

Installation Overview 9

- Installation Files 9
- Supported Hypervisors 10
- Download the Installation Files 11
- Guidelines and Limitations 11
- Where to Go Next 12

CHAPTER 4

Installing in VMware ESXi Environment 13

VMware Requirements	14
Supported VMware Features and Operations	16
General Features (vCenter Server)	16
Operations (for vCenter Server and vSphere Web Client)	17
High Availability	18
Storage Options (for vCenter Server and vSphere Web Client)	18
Deploying the OVA to the VM using vSphere	19
Restrictions and Requirements	19
Deploying the OVA to the VM	19
Deploying the OVA to the VM Using COT	22
Downloading COT	22
Editing the Basic Properties of Cisco Catalyst 8000V using COT	22
Editing the Custom Properties	23
cot edit-properties	24
cot inject-config	25
Deploying the Cisco Catalyst 8000V VM using COT	26
Example	27
Manually Creating the VM Using the .iso File	27
Increasing the Performance on VMware ESXi Configurations	29

CHAPTER 5

Installing in KVM Environments	31
Installation Requirements for KVM	31
Creating a KVM Instance	33
Creating the VM Using the GUI Tool	33
Adding a Serial Console	33
Customizing Configuration Before Creating the VM	34
Creating the VM Using CLI	34
Cloning the VM	36
Increasing the KVM Configuration Performance	36
Configure the halt_poll_ns Parameter	40

CHAPTER 6

Installing in an NFVIS Environment	43
Install the VM in NFVIS	45
Install the VM in NFVIS (Release 4.5.1 and Later)	45

Install Cisco Catalyst 8000V in NFVIS Environment	45
Upload the Image on NFVIS	46
Create a Network	46
Create a VM Package	47
Deploy the VM	47
Install the VM in NFVIS (Release 4.5.0 and Earlier)	48
Deploy the Virtual Machine on NFVIS	48
Download the Cisco Catalyst 8000V Image for NFVIS	49
Upload the Image on NFVIS	50
Create a VM Package Using the Web Interface	50
Create a Network	51
Monitor the Virtual Machine	51
Upgrade and Downgrade Between Cisco ISRV and Cisco Catalyst 8000V	52

CHAPTER 7
Installing in OpenStack Environment 55

Installation Requirements for OpenStack	55
Restrictions for Installing in OpenStack	56
Install Cisco Catalyst 8000V in OpenStack	56
Launching an Instance	56
Installing the VM Using a Heat Template	57

CHAPTER 8
Day 0 Configuration 59

Prerequisites for the Day0 Configuration	61
Restrictions for the Day Zero Configuration	61
Selecting the Bootstrapping Mechanism	61
Day 0 Configuration Using .txt or .xml Files	62
Creating the Bootstrap File	62
Bootstrap Properties	62
Sample iosxe_config.txt File	64
Sample ovf-env.xml File	65
Day 0 Configuration for OVF Templates	66
Day 0 Configuration Using Config-drive	66
Day 0 Configuration Using Custom Data	67
Editing the Day 0 Bootstrap File	68

Configuring the IOS Configuration Property	68
Configuring the Scripts Property	68
Configuring the Script credentials Property	69
Configuring the Python package Property	70
Configuring the License property	71
Providing the Day 0 Bootstrap File	71
Verifying the Custom Data Configuration (Microsoft Azure)	72
Verifying the Custom Data Configuration (Google Cloud Platform)	75
Day 0 Configuration in the Controller Mode	76
Verifying the Router Operation Mode and Day 0 Configuration	76
Frequently Asked Questions	77

CHAPTER 9	Mapping the Cisco Catalyst 8000V Network Interfaces to VM Network Interfaces	79
	Mapping the Router Network Interfaces to vNICs	79
	Adding and Deleting Network Interfaces on Cisco Catalyst 8000V	80
	Removing a vNIC from a Running VM	81
	Cisco Catalyst 8000V Network Interfaces and VM Cloning	81
	Mapping the Cisco Catalyst 8000V Network Interfaces with vSwitch Interfaces	82

CHAPTER 10	Enabling VNF Secure Boot	83
-------------------	---------------------------------	-----------

CHAPTER 11	Configuring Console Access	85
	Booting the Cisco Catalyst 8000V as the VM	85
	Accessing the Cisco Catalyst 8000V Console	86
	Accessing the Cisco Catalyst 8000V Through the Virtual VGA Console	86
	Accessing the Cisco Catalyst 8000V Through the Virtual Serial Port	87
	Introduction to Accessing the Cisco Catalyst 8000V through the Virtual Serial Port	87
	Creating Serial Console Access in VMware ESXi	87
	Creating the Serial Console Access in KVM	88
	Opening a Telnet Session to the Cisco Catalyst 8000V Console on the Virtual Serial Port	88
	Changing the Console Port Access After Installation	89

CHAPTER 12	Licenses and Licensing Models	91
	Feature Information for Available Licenses and Licensing Models	91

Available Licenses	93
Cisco DNA License	93
Guidelines for Using a Cisco DNA License	94
Ordering Considerations for a Cisco DNA License	95
High Security License	95
Guidelines for Using an HSECK9 License	96
Ordering Considerations for an HSECK9 License	97
Cisco CUBE License	97
Cisco Unified CME License	98
Cisco Unified SRST License	98
Throughput	98
Throughput as a Numeric Value	100
Throughput and System Hardware Throttling Specifications in the Autonomous Mode	101
Throughput and System Hardware Throttling Specifications in the SD-WAN Controller Mode	105
Throughput as a Tier	106
Numeric vs. Tier-Based Throughput Configuration	109
How to Configure Available Licenses and Throughput	112
Configuring a Boot Level License	112
Installing SLAC for an HSECK9 License	115
Configuring a Numeric Throughput	116
Configuring a Tier-Based Throughput	119
Converting From a Numeric Throughput Value to a Tier	123
Upgrading from a Release Supporting Numeric Throughput to a Release Supporting Tiers	126
Downgrading from a Release Supporting Tiers to a Release Supporting Only Numeric Throughput	127
Available Licensing Models	127

CHAPTER 13
Verifying the Cisco Catalyst 8000V Hardware and VM Requirements 129

CHAPTER 14
Upgrading the Cisco IOS XE Software 131

Prerequisites for Upgrading Cisco Catalyst 8000V	132
HSECK9 License Requirements for Cisco CSR1000V and Cisco ISRV Upgrade	132
Restrictions for Upgrading Cisco Catalyst 8000V	133
Install Mode Process Flow	134
Booting Cisco Catalyst 8000V in the Install Mode	138

One-Step Installation or Converting from Bundle Mode to Install Mode	138
Three-Step Installation	139
Sample Upgrade Output from Release 17.06.02 To Release 17.07.01	141
Upgrading in Install Mode	143
Downgrading in Install Mode	144
Terminating a Software Installation	144
Troubleshooting Software Installation Using install Commands	145
Frequently Asked Questions	146

CHAPTER 15

Configuring the vCPU Distribution	149
vCPU Distribution: Control Plane Extra heavy	149
vCPU Distribution: Control Plane heavy	150
vCPU Distribution: Data Plane heavy	150
vCPU Distribution: Data Plane normal	151
vCPU Distribution: Service Plane heavy	151
vCPU Distribution: Service Plane medium	151
Configuring the vCPU Distribution across the Data, Control, and Service Planes	152
Determining the Active vCPU Distribution Template	152

CHAPTER 16

Managing the SD-Routing Device Using Cisco SD-WAN Manager	153
Information About Using Cisco SD-WAN Manager to Monitor the SD-Routing Devices	153
Benefits of Managing the SD-Routing Devices Using Cisco SD-WAN Manager	154
Prerequisites	154
Limitations	155
Supported WAN Edge Devices	155
Onboarding the SD-Routing Devices	157
Onboarding the SD-Routing Devices Using Automated Workflow	157
Configuring the Plug and Play Connect Portal	158
Configuring the Cisco SD-WAN Manager Using Quick Connect Workflow	158
Bringing Up the SD-Routing Device	159
Onboarding the SD-Routing Devices Using Bootstrap	159
Onboarding the Devices Manually	161
Onboarding the Device by Activating the Chassis Using the Token	164
Onboarding the Multi-Tenancy SD-Routing Devices	165

Onboarding the Multi-Tenancy SD-Routing Devices Using Automated Workflow	165
Onboarding the Multi-Tenancy SD-Routing Devices Manually	166
Onboarding the Device to Cisco SD-WAN Manager Using One Touch Provisioning	168
Unprovisioning the Feature	169
Software Image Management	169
Software Upgrade Using CLI	169
Add Software Images to the Repository	170
Software Upgrade Using Cisco SD-WAN Manager	170
Delete a Software Image	172
View Log of Software Upgrade Activities	172
Monitoring the Device Using Cisco SD-WAN Manager	172
Monitoring the Device Using SSH	172
Pinging the Device	173
Tracing the Route	173
Alarms and Events	173
Monitoring the Alarms and Events	174
Admin-Tech Files	174
Requesting the Admin-tech File Using Cisco SD-WAN Manager	174
Requesting the Admin-tech File Using CLI	175
Monitoring the Real Time Data	175
Configuration Examples	175
Example: Enabling Control Connection on Cisco SD-WAN Manager	176
Example: Verifying the Enable Control Connection	176
Example: Installing the Root Certificate	176
Example: Verifying the Root Certificate Installation	176
Troubleshooting	177
Feature Information for Managing SD-Routing Devices Using vManage	178

CHAPTER 17
Web User Interface Management 179

Setting Up Factory Default Device Using WebUI	179
Using Basic or Advanced Mode Setup Wizard	180
Configure LAN Settings	180
Configure Primary WAN Settings	181
Configure Secondary WAN Settings	182

Configure Security Settings 182

CHAPTER 18

Accessing and Using the GRUB Mode 185

Accessing the GRUB Mode 186

Using the GRUB Menu 187

Entering the GRUB Mode and Selecting the Image 187

Modifying the Configuration Register (confreg) 189

Changing the Configuration Register Settings 190

Displaying the Configuration Register Settings 191

CHAPTER 19

Performing a Factory Reset 193

Information About Factory Reset 193

Prerequisites for Performing Factory Reset 194

Restrictions for Performing a Factory Reset 194

How to Perform a Factory Reset 194

Restoring Smart Licensing after a Factory Reset 195

What Happens after a Factory Reset 196

CHAPTER 20

Configuring VRF Route Sharing 199

Information About VRF Route Sharing 199

Prerequisites of VRF Route Sharing 199

Restrictions for VRF Route Sharing 200

How to Configure VRF Route Sharing 200

Sample Topology and Use Cases 200

Configuring VRF Route Sharing 202

Verifying VRF Route Sharing 203

CHAPTER 21

Configuring Bridge Domain Interfaces 205

Restrictions for Bridge Domain Interfaces 205

Information About Bridge Domain Interface 206

Ethernet Virtual Circuit Overview 206

Bridge Domain Interface Encapsulation 207

Assigning a MAC Address 207

Support for IP Protocols 207

Support for IP Forwarding	208
Packet Forwarding	208
Layer 2 to Layer 3	208
Layer 3 to Layer 2	208
Link States of a Bridge Domain and a Bridge Domain Interface	209
BDI Initial State	209
BDI Link State	209
Bridge Domain Interface Statistics	209
Creating or Deleting a Bridge Domain Interface	210
Bridge Domain Interface Scalability	210
Bridge-Domain Virtual IP Interface	210
How to Configure a Bridge Domain Interface	211
Example	213
Displaying and Verifying Bridge Domain Interface Configuration	213
Configuring Bridge-Domain Virtual IP Interface	214
Associating VIF Interface with a Bridge Domain	215
Verifying Bridge-Domain Virtual IP Interface	215
Example Configuration Bridge-Domain Virtual IP Interface	215
Configuring Flexible NetFlow over a Bridge Domain Virtual IP Interface	215
Examples: Flexible NetFlow over a Bridge Domain Virtual IP Interface	216
Additional References	221
Feature Information for Configuring Bridge Domain Interfaces	221

CHAPTER 22
Configuring MTP Software Support 223

Benefits	223
Prerequisites for Configuring Support for Software MTP	223
SRTP-DTMF Interworking	223
Restrictions for SRTP-DTMF Interworking	224
Supported Platforms for SRTP-DTMF Interworking	224
Configuring Support for Software MTP	224
Sample Software MTP Support Configuration	227
Verifying Software MTP Support	228

CHAPTER 23
Radio Aware Routing 231

Benefits of Radio Aware Routing	231
Restrictions and Limitations	232
Performance	232
System Components	232
QoS Provisioning on PPPoE Extension Session	233
Example: Configuring the RAR Feature in Bypass Mode	233
Verifying RAR Session Details	235



CONTENTS

Full Cisco Trademarks with Software License ?

CHAPTER 1

Preface 1

- Audience and Scope 1
- Feature Compatibility 1
- Document Conventions 2
- Communications, Services, and Additional Information 3
- Documentation Feedback 4
- Troubleshooting 4

CHAPTER 2

Overview of Cisco Catalyst 8000V 5

- Benefits of Virtualization Using the Cisco Catalyst 8000V Router 5
- Router Interfaces 6
- Cisco IOS XE and Cisco Catalyst 8000V 6
- Cisco Unified Computing System (UCS) Products 7

CHAPTER 3

Installation Overview 9

- Installation Files 9
- Supported Hypervisors 10
- Download the Installation Files 11
- Guidelines and Limitations 11
- Where to Go Next 12

CHAPTER 4

Installing in VMware ESXi Environment 13

- VMware Requirements 14
- Supported VMware Features and Operations 16

General Features (vCenter Server)	16
Operations (for vCenter Server and vSphere Web Client)	17
High Availability	18
Storage Options (for vCenter Server and vSphere Web Client)	18
Deploying the OVA to the VM using vSphere	19
Restrictions and Requirements	19
Deploying the OVA to the VM	19
Deploying the OVA to the VM Using COT	22
Downloading COT	22
Editing the Basic Properties of Cisco Catalyst 8000V using COT	22
Editing the Custom Properties	23
cot edit-properties	24
cot inject-config	25
Deploying the Cisco Catalyst 8000V VM using COT	26
Example	27
Manually Creating the VM Using the .iso File	27
Increasing the Performance on VMware ESXi Configurations	29

CHAPTER 5
Installing in KVM Environments 31

Installation Requirements for KVM	31
Creating a KVM Instance	33
Creating the VM Using the GUI Tool	33
Adding a Serial Console	33
Customizing Configuration Before Creating the VM	34
Creating the VM Using CLI	34
Cloning the VM	36
Increasing the KVM Configuration Performance	36
Configure the halt_poll_ns Parameter	40

CHAPTER 6
Installing in an NFVIS Environment 43

Install the VM in NFVIS	45
Install the VM in NFVIS (Release 4.5.1 and Later)	45
Install Cisco Catalyst 8000V in NFVIS Environment	45
Upload the Image on NFVIS	46

Create a Network	46
Create a VM Package	47
Deploy the VM	47
Install the VM in NFVIS (Release 4.5.0 and Earlier)	48
Deploy the Virtual Machine on NFVIS	48
Download the Cisco Catalyst 8000V Image for NFVIS	49
Upload the Image on NFVIS	50
Create a VM Package Using the Web Interface	50
Create a Network	51
Monitor the Virtual Machine	51
Upgrade and Downgrade Between Cisco ISRv and Cisco Catalyst 8000V	52

CHAPTER 7

Installing in OpenStack Environment 55

Installation Requirements for OpenStack	55
Restrictions for Installing in OpenStack	56
Install Cisco Catalyst 8000V in OpenStack	56
Launching an Instance	56
Installing the VM Using a Heat Template	57

CHAPTER 8

Day 0 Configuration 59

Prerequisites for the Day0 Configuration	61
Restrictions for the Day Zero Configuration	61
Selecting the Bootstrapping Mechanism	61
Day 0 Configuration Using .txt or .xml Files	62
Creating the Bootstrap File	62
Bootstrap Properties	62
Sample iosxe_config.txt File	64
Sample ovf-env.xml File	65
Day 0 Configuration for OVF Templates	66
Day 0 Configuration Using Config-drive	66
Day 0 Configuration Using Custom Data	67
Editing the Day 0 Bootstrap File	68
Configuring the IOS Configuration Property	68
Configuring the Scripts Property	68

Configuring the Script credentials Property	69
Configuring the Python package Property	70
Configuring the License property	71
Providing the Day 0 Bootstrap File	71
Verifying the Custom Data Configuration (Microsoft Azure)	72
Verifying the Custom Data Configuration (Google Cloud Platform)	75
Day 0 Configuration in the Controller Mode	76
Verifying the Router Operation Mode and Day 0 Configuration	76
Frequently Asked Questions	77

CHAPTER 9 Mapping the Cisco Catalyst 8000V Network Interfaces to VM Network Interfaces 79

Mapping the Router Network Interfaces to vNICs	79
Adding and Deleting Network Interfaces on Cisco Catalyst 8000V	80
Removing a vNIC from a Running VM	81
Cisco Catalyst 8000V Network Interfaces and VM Cloning	81
Mapping the Cisco Catalyst 8000V Network Interfaces with vSwitch Interfaces	82

CHAPTER 10 Enabling VNF Secure Boot 83

CHAPTER 11 Configuring Console Access 85

Booting the Cisco Catalyst 8000V as the VM	85
Accessing the Cisco Catalyst 8000V Console	86
Accessing the Cisco Catalyst 8000V Through the Virtual VGA Console	86
Accessing the Cisco Catalyst 8000V Through the Virtual Serial Port	87
Introduction to Accessing the Cisco Catalyst 8000V through the Virtual Serial Port	87
Creating Serial Console Access in VMware ESXi	87
Creating the Serial Console Access in KVM	88
Opening a Telnet Session to the Cisco Catalyst 8000V Console on the Virtual Serial Port	88
Changing the Console Port Access After Installation	89

CHAPTER 12 Licenses and Licensing Models 91

Feature Information for Available Licenses and Licensing Models	91
Available Licenses	93
Cisco DNA License	93

Guidelines for Using a Cisco DNA License	94
Ordering Considerations for a Cisco DNA License	95
High Security License	95
Guidelines for Using an HSECK9 License	96
Ordering Considerations for an HSECK9 License	97
Cisco CUBE License	97
Cisco Unified CME License	98
Cisco Unified SRST License	98
Throughput	98
Throughput as a Numeric Value	100
Throughput and System Hardware Throttling Specifications in the Autonomous Mode	101
Throughput and System Hardware Throttling Specifications in the SD-WAN Controller Mode	105
Throughput as a Tier	106
Numeric vs. Tier-Based Throughput Configuration	109
How to Configure Available Licenses and Throughput	112
Configuring a Boot Level License	112
Installing SLAC for an HSECK9 License	115
Configuring a Numeric Throughput	116
Configuring a Tier-Based Throughput	119
Converting From a Numeric Throughput Value to a Tier	123
Upgrading from a Release Supporting Numeric Throughput to a Release Supporting Tiers	126
Downgrading from a Release Supporting Tiers to a Release Supporting Only Numeric Throughput	127
Available Licensing Models	127

CHAPTER 13
Verifying the Cisco Catalyst 8000V Hardware and VM Requirements 129

CHAPTER 14
Upgrading the Cisco IOS XE Software 131

Prerequisites for Upgrading Cisco Catalyst 8000V	132
HSECK9 License Requirements for Cisco CSR1000V and Cisco ISRV Upgrade	132
Restrictions for Upgrading Cisco Catalyst 8000V	133
Install Mode Process Flow	134
Bootting Cisco Catalyst 8000V in the Install Mode	138
One-Step Installation or Converting from Bundle Mode to Install Mode	138
Three-Step Installation	139

Sample Upgrade Output from Release 17.06.02 To Release 17.07.01	141
Upgrading in Install Mode	143
Downgrading in Install Mode	144
Terminating a Software Installation	144
Troubleshooting Software Installation Using install Commands	145
Frequently Asked Questions	146

CHAPTER 15

Configuring the vCPU Distribution	149
vCPU Distribution: Control Plane Extra heavy	149
vCPU Distribution: Control Plane heavy	150
vCPU Distribution: Data Plane heavy	150
vCPU Distribution: Data Plane normal	151
vCPU Distribution: Service Plane heavy	151
vCPU Distribution: Service Plane medium	151
Configuring the vCPU Distribution across the Data, Control, and Service Planes	152
Determining the Active vCPU Distribution Template	152

CHAPTER 16

Managing the SD-Routing Device Using Cisco SD-WAN Manager	153
Information About Using Cisco SD-WAN Manager to Monitor the SD-Routing Devices	153
Benefits of Managing the SD-Routing Devices Using Cisco SD-WAN Manager	154
Prerequisites	154
Limitations	155
Supported WAN Edge Devices	155
Onboarding the SD-Routing Devices	157
Onboarding the SD-Routing Devices Using Automated Workflow	157
Configuring the Plug and Play Connect Portal	158
Configuring the Cisco SD-WAN Manager Using Quick Connect Workflow	158
Bringing Up the SD-Routing Device	159
Onboarding the SD-Routing Devices Using Bootstrap	159
Onboarding the Devices Manually	161
Onboarding the Device by Activating the Chassis Using the Token	164
Onboarding the Multi-Tenancy SD-Routing Devices	165
Onboarding the Multi-Tenancy SD-Routing Devices Using Automated Workflow	165
Onboarding the Multi-Tenancy SD-Routing Devices Manually	166

Onboarding the Device to Cisco SD-WAN Manager Using One Touch Provisioning	168
Unprovisioning the Feature	169
Software Image Management	169
Software Upgrade Using CLI	169
Add Software Images to the Repository	170
Software Upgrade Using Cisco SD-WAN Manager	170
Delete a Software Image	172
View Log of Software Upgrade Activities	172
Monitoring the Device Using Cisco SD-WAN Manager	172
Monitoring the Device Using SSH	172
Pinging the Device	173
Tracing the Route	173
Alarms and Events	173
Monitoring the Alarms and Events	174
Admin-Tech Files	174
Requesting the Admin-tech File Using Cisco SD-WAN Manager	174
Requesting the Admin-tech File Using CLI	175
Monitoring the Real Time Data	175
Configuration Examples	175
Example: Enabling Control Connection on Cisco SD-WAN Manager	176
Example: Verifying the Enable Control Connection	176
Example: Installing the Root Certificate	176
Example: Verifying the Root Certificate Installation	176
Troubleshooting	177
Feature Information for Managing SD-Routing Devices Using vManage	178

CHAPTER 17
Web User Interface Management 179

Setting Up Factory Default Device Using WebUI	179
Using Basic or Advanced Mode Setup Wizard	180
Configure LAN Settings	180
Configure Primary WAN Settings	181
Configure Secondary WAN Settings	182
Configure Security Settings	182

CHAPTER 18	Accessing and Using the GRUB Mode	185
	Accessing the GRUB Mode	186
	Using the GRUB Menu	187
	Entering the GRUB Mode and Selecting the Image	187
	Modifying the Configuration Register (confreg)	189
	Changing the Configuration Register Settings	190
	Displaying the Configuration Register Settings	191

CHAPTER 19	Performing a Factory Reset	193
	Information About Factory Reset	193
	Prerequisites for Performing Factory Reset	194
	Restrictions for Performing a Factory Reset	194
	How to Perform a Factory Reset	194
	Restoring Smart Licensing after a Factory Reset	195
	What Happens after a Factory Reset	196

CHAPTER 20	Configuring VRF Route Sharing	199
	Information About VRF Route Sharing	199
	Prerequisites of VRF Route Sharing	199
	Restrictions for VRF Route Sharing	200
	How to Configure VRF Route Sharing	200
	Sample Topology and Use Cases	200
	Configuring VRF Route Sharing	202
	Verifying VRF Route Sharing	203

CHAPTER 21	Configuring Bridge Domain Interfaces	205
	Restrictions for Bridge Domain Interfaces	205
	Information About Bridge Domain Interface	206
	Ethernet Virtual Circuit Overview	206
	Bridge Domain Interface Encapsulation	207
	Assigning a MAC Address	207
	Support for IP Protocols	207
	Support for IP Forwarding	208

Packet Forwarding	208
Layer 2 to Layer 3	208
Layer 3 to Layer 2	208
Link States of a Bridge Domain and a Bridge Domain Interface	209
BDI Initial State	209
BDI Link State	209
Bridge Domain Interface Statistics	209
Creating or Deleting a Bridge Domain Interface	210
Bridge Domain Interface Scalability	210
Bridge-Domain Virtual IP Interface	210
How to Configure a Bridge Domain Interface	211
Example	213
Displaying and Verifying Bridge Domain Interface Configuration	213
Configuring Bridge-Domain Virtual IP Interface	214
Associating VIF Interface with a Bridge Domain	215
Verifying Bridge-Domain Virtual IP Interface	215
Example Configuration Bridge-Domain Virtual IP Interface	215
Configuring Flexible NetFlow over a Bridge Domain Virtual IP Interface	215
Examples: Flexible NetFlow over a Bridge Domain Virtual IP Interface	216
Additional References	221
Feature Information for Configuring Bridge Domain Interfaces	221

CHAPTER 22

Configuring MTP Software Support	223
Benefits	223
Prerequisites for Configuring Support for Software MTP	223
SRTP-DTMF Interworking	223
Restrictions for SRTP-DTMF Interworking	224
Supported Platforms for SRTP-DTMF Interworking	224
Configuring Support for Software MTP	224
Sample Software MTP Support Configuration	227
Verifying Software MTP Support	228

CHAPTER 23

Radio Aware Routing	231
Benefits of Radio Aware Routing	231

Restrictions and Limitations	232
Performance	232
System Components	232
QoS Provisioning on PPPoE Extension Session	233
Example: Configuring the RAR Feature in Bypass Mode	233
Verifying RAR Session Details	235

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2020–2023 Cisco Systems, Inc. All rights reserved.



CHAPTER 1

Preface

This preface describes the audience, organization, and conventions of this document. It also provides information on how to obtain other documentation.

This preface includes the following sections:

- [Audience and Scope, on page 1](#)
- [Feature Compatibility, on page 1](#)
- [Document Conventions, on page 2](#)
- [Communications, Services, and Additional Information, on page 3](#)
- [Documentation Feedback, on page 4](#)
- [Troubleshooting, on page 4](#)

Audience and Scope

This document is designed for the person who is responsible for configuring your Cisco Enterprise router. This document is intended primarily for the following audiences:

- Customers with technical networking background and experience.
- System administrators familiar with the fundamentals of router-based internetworking but who might not be familiar with Cisco IOS software.
- System administrators who are responsible for installing and configuring internetworking equipment, and who are familiar with Cisco IOS software.

Feature Compatibility

For more information about the Cisco IOS XE software, including features available on your device as described in the configuration guides, see the respective router documentation set.

To verify support for specific features, use the [Cisco Feature Navigator](#) tool. This tool enables you to determine the Cisco IOS XE software images that support a specific software release, feature set, or a platform.

Document Conventions

This documentation uses the following conventions:

Convention	Description
^ or Ctrl	The ^ and Ctrl symbols represent the Control key. For example, the key combination ^D or Ctrl-D means hold down the Control key while you press the D key. Keys are indicated in capital letters but are not case sensitive.
<i>string</i>	A string is a nonquoted set of characters shown in italics. For example, when setting an SNMP community string to public, do not use quotation marks around the string or the string will include the quotation marks.

The command syntax descriptions use the following conventions:

Convention	Description
bold	Bold text indicates commands and keywords that you enter exactly as shown.
<i>italics</i>	Italic text indicates arguments for which you supply values.
[x]	Square brackets enclose an optional element (keyword or argument).
	A vertical line indicates a choice within an optional or required set of keywords or arguments.
[x y]	Square brackets enclosing keywords or arguments separated by a vertical line indicate an optional choice.
{x y}	Braces enclosing keywords or arguments separated by a vertical line indicate a required choice.

Nested sets of square brackets or braces indicate optional or required choices within optional or required elements. For example, see the following table.

Convention	Description
[x {y z}]	Braces and a vertical line within square brackets indicate a required choice within an optional element.

Examples use the following conventions:

Convention	Description
screen	Examples of information displayed on the screen are set in Courier font.
bold screen	Examples of text that you must enter are set in Courier bold font.
< >	Angle brackets enclose text that is not printed to the screen, such as passwords.
!	An exclamation point at the beginning of a line indicates a comment line. Exclamation points are also displayed by the Cisco IOS XE software for certain processes.
[]	Square brackets enclose default responses to system prompts.

**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

**Note**

Means *reader take note*. Notes contain helpful suggestions or references to materials that may not be contained in this manual.

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.

Documentation Feedback

To provide feedback about Cisco technical documentation, use the feedback form available in the right pane of every online document.

Troubleshooting

For the most up-to-date, detailed troubleshooting information, see the Cisco TAC website at <https://www.cisco.com/en/US/support/index.html>.

Go to **Products by Category** and choose your product from the list, or enter the name of your product. Look under **Troubleshoot and Alerts** to find information for the issue that you are experiencing.



CHAPTER 2

Overview of Cisco Catalyst 8000V

The Cisco Catalyst 8000V Edge Software is a virtual, form-factor router deployed on a virtual machine (VM) running on an x86 server hardware. This guide covers the overview, installation, upgrade, and configuration of Cisco Catalyst 8000V.

Cisco Catalyst 8000V supports both Cisco IOS XE and the Cisco IOS XE SD-WAN functionalities through the autonomous mode and the controller mode, respectively. Cisco Catalyst 8000V in the autonomous mode supports a subset of the Cisco IOS XE software features and technologies, and provides Cisco IOS XE security and switching features on a virtualization platform. The controller mode delivers comprehensive SD-WAN, WAN gateway, and network services functions in the virtual and cloud environments.

When you deploy Cisco Catalyst 8000V on a VM, the Cisco IOS XE software functions just as if it were deployed on a traditional Cisco hardware platform. This router includes a virtual Route Processor and a virtual Forwarding Processor (FP) as part of its architecture, and provides secure connectivity from an enterprise location such as a branch office or a data center, to a public or a private cloud.

Cisco Catalyst 8000V supports SSL VPN. From Cisco IOS XE Release 17.x, when you are running a Cisco IOS-XE router as an SSL VPN gateway, an extra SSL VPN overhead is added due to the TLS encapsulation. To prevent IP fragmentation and reassembly of packets between SSL VPN client and server, you must adjust the TCP-MSS value optimally. Otherwise, packet drop due to the IPFragErr error could occur in the SSL VPN gateway.

The Cisco Catalyst 8000V router also provides a virtual IOS XE operating system for routing and forwarding on the Enterprise Network Compute System (ENCS) platform and on the Cisco Cloud Services Platform 5000 Series.

To use the functionalities of this virtual router, read on to know how to deploy a Cisco Catalyst 8000V router as a virtual machine on a hypervisor.

- [Benefits of Virtualization Using the Cisco Catalyst 8000V Router, on page 5](#)
- [Router Interfaces, on page 6](#)
- [Cisco IOS XE and Cisco Catalyst 8000V, on page 6](#)
- [Cisco Unified Computing System \(UCS\) Products, on page 7](#)

Benefits of Virtualization Using the Cisco Catalyst 8000V Router

- **Hardware independence:** The Cisco Catalyst 8000V router uses the benefits of virtualization in the cloud to provide hardware independence. Since the Cisco Catalyst 8000V runs on a virtual machine, you can use this router on any x86 hardware that the virtualization platform supports.

- **Sharing of resources:** The resources used by Cisco Catalyst 8000V are managed by the hypervisor, and these resources can be shared among the VMs. You can regulate the amount of hardware resources that the VM server allocates to a specific VM. You can reallocate resources to another VM on the server.
- **Flexibility in deployment:** You can easily move a VM from one server to another. Thus, you can move a Cisco Catalyst 8000V instance from a server in one physical location to a server in another physical location without moving any hardware resources.
- **Enhanced software security - Secure Object Store:** In Cisco Catalyst 8000V, storage partitions for NVRAM, licensing, and other data are created as Object stores. The individual Object stores are encrypted to ensure data security, and this product is Cisco Secure Development lifecycle (CSDL) compliant. Further, Cisco Catalyst 8000V supports a 16G disk profile.

Router Interfaces

The Cisco Catalyst 8000V router interfaces perform the same functionality as those on hardware-based Cisco routers. The Cisco Catalyst 8000V interfaces function as follows:

- The interfaces are logically named as the Gigabit Ethernet (GE) interfaces.
- The available interface numbering depends on the Cisco Catalyst 8000V version.

When you first boot the device, the Cisco Catalyst 8000V router interfaces are mapped to the vNIC interfaces on the VM based on the vNIC enumeration to the Cisco Catalyst 8000V. On subsequent boot, the Cisco Catalyst 8000V router interfaces are mapped to the vNIC MAC addresses.

For more information, see [Mapping the Cisco Catalyst 8000V Network Interfaces to the VM Network Interfaces](#).

Interface Numbering

- The interface port numbering is from 1 and up to the number of interfaces supported. See [VMware Requirements, on page 14](#) to know the supported vNICs and the minimum and maximum number of vNICs supported for each VM instance.
- Gigabit Ethernet interface 0 is not supported.
- You can designate any interface as the management interface. You can designate a management interface by performing the appropriate Day0 bootstrapping mechanisms available for your target environment. For more details, see [Day 0 Configuration, on page 59](#).

Cisco IOS XE and Cisco Catalyst 8000V

Cisco Catalyst 8000V is a virtual router that runs on Cisco IOS XE and Cisco IOS XE SD-WAN. This guide provides the overview, installation, and configuration information for Cisco Catalyst 8000V on Cisco IOS XE.

You can configure and manage Cisco Catalyst 8000V by:

- Provisioning a serial port in the VM to connect and access the Cisco IOS XE CLI commands.



Note You can use a serial port to manage a Cisco Catalyst 8000V VM only if the underlying hypervisor supports associating a serial port with a VM. See your hypervisor documentation for more details.

- Using the remote SSH/Telnet to access the Cisco IOS XE CLI commands.



Note By default, Telnet is disabled for security reasons. SSH is disabled in an on-prem deployment. Although SSH is preferred for remote user management, you must manually enable SSH in an on-prem deployment.

In cloud deployments, SSH is enabled by default. To access SSH, ensure that your cloud security settings allow SSH connectivity for both inbound and outbound traffic.

The software for Cisco Catalyst 8000V uses the standard Cisco IOS XE CLI commands and conventions. The commands are not case sensitive, and you can abbreviate the commands and parameters if the abbreviations contain enough letters to be different from any other currently available commands or parameters. To access all the features of Cisco IOS XE CLI and how to use them, see the [Configuration Fundamentals Configuration Guide](#).

Cisco Unified Computing System (UCS) Products

Table 1: Cisco Catalyst 8000V Compatibility with Cisco UCS Servers

Cisco Unified Computing System (UCS) Products	<p>The Cisco UCS server requirements are:</p> <ul style="list-style-type: none"> • VMware-certified. • 4 or more cores configured. • A minimum UCS memory of 16 GB. If you use the SDWAN/Controller mode, at least 128 GB memory is required to accommodate SDWAN vManage, vBond, and vSmart. • A minimum UCS storage of 1 TB. • A UCS C220 M5 minimum is recommended. <p>See http://www.cisco.com/en/US/products/ps10477/prod_technical_reference_list.html to determine the UCS hardware and software that is compatible with the supported hypervisors.</p>
---	--



CHAPTER 3

Installation Overview

This chapter provides the high-level information on how to install Cisco Catalyst 8000V. Usually, Cisco hardware routers are shipped with the Cisco IOS XE software pre-installed. However, since Cisco Catalyst 8000V is not a hardware-based router, you must download the Cisco IOS XE software from Cisco.com and install the virtual router directly onto the virtual machine. Before you proceed to the installation, first provision the attributes of the VM so that the Cisco Catalyst 8000V software can install and boot.

See the following sections to know about the various installation files and the installation options that are dependent on the hypervisor you have chosen.

- [Installation Files, on page 9](#)
- [Supported Hypervisors, on page 10](#)
- [Download the Installation Files, on page 11](#)
- [Guidelines and Limitations, on page 11](#)
- [Where to Go Next, on page 12](#)

Installation Files

The following table specifies the software images that are available for installing Cisco Catalyst 8000V on the supported hypervisors:

Image Type	Hypervisor	Mode	Secure Boot	Sample Filename
bin	ESXi, KVM, AWS, Microsoft Azure, GCP	Upgrade (bundle mode) Upgrade (install mode)	No	c8000v-universalk9.17.04.01a.SPA.bin
iso - Used for installing the software image on the VM	ESXi, KVM	New installation	No	c8000v-universalk9.17.04.01a.iso

Image Type	Hypervisor	Mode	Secure Boot	Sample Filename
ova - used for deploying the OVA template on the VM (in TAR format)	ESXi	New installation	Yes	c8000v-universalk9.17.04.01a.ova
qcow2 - Used for installing the software image in KVM environments.	KVM	New installation	No	c8000v-universalk9.17.04.01a.qcow2
serial.qcow2	KVM	New installation	No	c8000v-universalk9.17.04.01a.efi.qcow2
efi.qcow2	KVM	New installation	Yes	c8000v-universalk9.17.04.01a.efi.qcow2
serial.efi.qcow2	KVM	New installation	Yes	c8000v-universalk9.17.04.01a-serial.efi.qcow2
tar.gz	NFVIS	New installation	Yes	c8000v-universalk9.17.04.01a-tar.gz



Note Although secure boot is supported for certain image types, this functionality is not enabled by default. See [VNF Secure Boot](#) to know how to enable secure boot for your hypervisor.

Supported Hypervisors

A hypervisor enables multiple operating systems to share a single hardware host machine. While each operating system could have a dedicated use of the host's processor, memory, and other resources, the hypervisor controls and allocates only the required resources to each operating system. This ensures that the operating systems (VMs) do not disrupt each other.

The following are the supported hypervisors for Cisco Catalyst 8000V:

- **VMware ESXi:** Cisco Catalyst 8000V runs on the VMware ESXi hypervisor, which runs on a x86 hardware containing virtualization extension. To see the VMware requirements and to learn how to install Cisco Catalyst 8000V in the ESXi environment, see [Installing in VMware ESXi Environment](#).
- **Red Hat KVM:** Cisco Catalyst 8000V also runs on the Red Hat Enterprise Linux (RHEL).
- **Public Clouds:** Apart from the above-mentioned hypervisors, you can also deploy and use Cisco Catalyst 8000V in Amazon Web Services, Microsoft Azure, Google Cloud Platform, and Alibaba Cloud. See the respective public cloud deployment guides for detailed information.

Virtual Machine Processing Resources

The Cisco Catalyst 8000V is a low-latency application and might not function properly when the processing resources on the host side are over subscribed. By default, most hypervisors support overcommitting the

processing resources. However, for Cisco Catalyst 8000V, if you oversubscribe and do not schedule the virtual CPUs (vCPUs) reliably, you could experience packet processing drops, error messages, or system outages.

The Cisco Catalyst 8000V vCPUs must be scheduled by the host hypervisor to run on real physical cores. Each hypervisor has various controls that influence the scheduling of the vCPUs to the physical cores. As a best practice, Cisco recommends that you to use a ratio of 1:1 for the vCPUs to real physical cores.

For detailed information on virtual machine processing resources, see the respective hypervisor tuning guides provided by the hypervisor. Additionally, you can refer to the appropriate hypervisor sections in this guide that describe the possible settings to increase the performance and improve the overall system determinism.

Download the Installation Files

-
- Step 1** Go to the [Cisco Software Download](#) page.
- Step 2** From the **Select a Product** field at the bottom of the page, search for Cisco Catalyst 8000V.
- Step 3** Click the Cisco Catalyst 8000V link and go to the Download page.
- Step 4** From the left pane, select the appropriate release. For example, *Bengaluru 17.4.1*.
- Step 5** From the list of available images, click **Download** or **Add to Cart**. Follow the instructions for downloading the software.
- Note** To know which installation file you want to download, see [Installation Files, on page 9](#).
-

Guidelines and Limitations

The following list specifies the general guidelines and restrictions before installing a Cisco Catalyst 8000V router in your network:

- Cisco Catalyst 8000V within a nested VM has not been tested and is not recommended for this reason.
- If the hypervisor does not support vNIC Hot Add/Remove, do not make any changes to the VM hardware (memory, CPUs, hard drive size, and so on) while the VM is powered on.
- Gigabit Ethernet0 interface is no longer available. You can designate any interface as the management interface.
- You can access the Cisco IOS XE CLI either through the virtual VGA console or the console on the virtual serial port. Select the console from the GRUB mode during the first-time installation or change the console using the Cisco IOS XE **platform console** command after the router boots. For more information, see [Booting the Cisco Catalyst 8000V as the VM, on page 85](#).
- If you are running a virtual function on an I350 device, redundancy protocols like HSRP/VRRP are not supported.
- For .qcow2 files, the image that you choose during installation plays a role in the type of console you can select.
- vNICs do not support duplex settings in an interface.
- vNICs do not support auto-negotiations.

- From Cisco IOS XE 17.9.1, the **show license udi** command is no longer supported in Cisco Catalyst 8000V.
- Cisco Catalyst 8000V does not support L2TP functionality including L2TP client and L2TP Network Server (LNS).
- We recommend that you use Cisco Catalyst 8000V with 8GB memory in the controller mode as the SDWAN configurations are tight in Cisco Catalyst 8000V deployments with lesser memory. Hence, Cisco Catalyst 8000V might experience high memory utilization.



Note Some hypervisors might not support serial console access. Verify support using your hypervisor documentation.

Where to Go Next

Now that you have downloaded the installation file, you can proceed to the deployment. Based on the hypervisor that you have chosen, the deployment procedures vary.

See the following chapters in this guide to know how to deploy Cisco Catalyst 8000V in the appropriate hypervisor environment:

- [Installing in VMware ESXi Environment](#)
- [Installing in Kernel Virtual Machine Support \(KVM\) Environments](#)

Deployment in Public Clouds

- For information about deploying Cisco Catalyst 8000V in an Amazon Web Services environment, see [Deploying Cisco Catalyst 8000V Edge Software on Amazon Web Services](#).
- For information about deploying Cisco Catalyst 8000V in the Microsoft Azure environment, see [Deploying Cisco Catalyst 8000V on Microsoft Azure](#).
- For information about deploying Cisco Catalyst 8000V in Google Cloud Platform, see [Deploying Cisco Catalyst 8000V on Google Cloud Platform](#).
- For more information about deploying Cisco Catalyst 8000V in Alibaba Cloud, see [Deploying Cisco Catalyst 8000V on Alibaba Cloud](#).



Note Refer the following chapters before you proceed with the installation:

- [Day 0 Configuration](#)
 - [VNF Secure Boot](#)
 - [Configuring Console Access](#)
-



CHAPTER 4

Installing in VMware ESXi Environment

VMware ESXi, a hypervisor that allows the basic creation and management of virtual machines, is one of the hypervisors supported by Cisco Catalyst 8000V. This hypervisor runs on an x86 hardware containing virtualization extension, and you can use the same hypervisor to run several VMs simultaneously.

From Cisco IOS XE 17.12.1 release, Cisco Catalyst 8000V is supported on Intel Atom® C3000 processor (Denverton) CPU-based servers with Intel x550 NIC on VMware ESXi 7.0.x. You can run Cisco Catalyst 8000V on other x86 CPUs with different versions of hypervisor operating systems, but support is only available on VMware ESXi 7.0.x.

This chapter contains information about how to deploy Cisco Catalyst 8000V in ESXi, and the requirements for a successful deployment. Before you read the requirements and the deployment procedures, see the following information that tells you the various deployment methods for the ESXi hypervisor:



Caution Oversubscription of host resources can lead to a reduction of performance and your instance could become instable. We recommend that you follow the guidelines and the best practices for your host hypervisor

Deploying the OVA template on the VM

Deploying using the OVA file: In this method, you must download the .ova file from Software Download page, and use this file for the deployment. Further, you can use the following two methods to deploy the OVA file:

- **Deploying using the vSphere client:** In this procedure, you need a VMware vSphere Client or a vSphere Web Client to deploy the *.ova installation file. The VMware vSphere Web Client is a web application that runs on a x86 hardware containing virtualization extension and accesses the VMware vCenter Server. You can use VMware vSphere Web Client software to create, configure, and manage VMs on the vCenter Server and to start or stop a Cisco Catalyst 8000V instance.



Note This is the recommended method of deployment for Cisco Catalyst 8000V.

- **Deploying using the Common Ovf Tool (COT):** COT is a tool that allows you to edit virtual appliances such as Cisco Catalyst 8000V. You can also use this tool to deploy the .ova file to the ESXi server and provision the VM.

To learn more about VMware vSphere products, see [VMware product documentation](#).

Manually deploying the .iso file

The third deployment option for the ESXi hypervisor is the manual creation of the VM and installation of Cisco Catalyst 8000V by using the .iso file. Download the .iso file from the Cisco Software Download page and use this file for the installation. In this method, you install the .iso file on the VMware ESXi host and manually create the VM using the vSphere GUI. This option is advisable only if you want to modify the OVA. However, note that this option is the least recommended since manual deployments invite opportunities to stray from supported configurations.



Important Create the VM using ESXi 6.5 or later. Ensure that you use VM version 13 or greater. To choose the EFI firmware mode, navigate through **VM Options > Boot Options > Firmware > EFI**. The firmware mode is required to enable the secure boot functionality. For more information, see [Enabling VNF Secure Boot, on page 83](#).



Important You cannot modify the firmware mode (from BIOS to EFI or vice versa) after you create the VM.

- [VMware Requirements, on page 14](#)
- [Supported VMware Features and Operations, on page 16](#)
- [Deploying the OVA to the VM using vSphere, on page 19](#)
- [Deploying the OVA to the VM Using COT, on page 22](#)
- [Manually Creating the VM Using the .iso File, on page 27](#)
- [Increasing the Performance on VMware ESXi Configurations, on page 29](#)

VMware Requirements

The following table specifies the supported VMware tools by Cisco Catalyst 8000V using Cisco IOS XE 17.4 and later releases. These versions have been fully tested and meet performance benchmarks.

Cisco IOS XE Release	vSphere Web Client	vCenter Server
Cisco IOS XE 17.4.x releases	The 6.7 and 6.5 versions of the VMware vSphere Web Client are supported.	VMware ESXi 6.7 and ESXi 6.5
Cisco IOS XE 17.5.x releases	The 6.7 and 6.5 versions of the VMware vSphere Web Client are supported.	VMware ESXi 6.7 and ESXi 6.5
Cisco IOS XE 17.6.x, 17.7.x, 17.8.x, 17.9.x, 17.10.x, 17.11.x, and 17.12.x releases	The 7.0 and 6.7 versions of the VMware vSphere Web Client are supported.	VMware ESXi 7.0 and ESXi 6.7



Note Do not use a standalone vSphere client to manage the ESXi server. Starting ESXi 6.0, it is no longer possible to directly deploy Cisco Catalyst 8000V in ESXi in the case of an ova deployment. You must have a VMware vCenter server and a vSphere client to deploy a .ova file.

- vCPUs - the following vCPU configurations are supported:
 - 1 vCPU: requires minimum 4 GB RAM allocation
 - 2 vCPUs: requires minimum 4 GB RAM allocation
 - 4 vCPUs: requires minimum 4 GB RAM allocation
 - 8 vCPUs: requires minimum 4 GB RAM allocation
 - 16 vCPUS: required minimum 8 GB RAM allocation (supported from Cisco IOS XE 17.11.1a)



Note The required vCPU configuration depends on the throughput license and technology package installed. For more information, see the data sheet for your release.

- Virtual Network Interface Cards (vNICs) - a maximum of 8 vNICs is supported. The following vNICs are supported:
 - VMXNET3 - Supported from Cisco IOS XE 17.4.1
 - iXGBEVF - Supported from Cisco IOS XE 17.4.1
 - i40eVF - Supported from Cisco IOS XE 17.4.1
 - ConnectX-5VF - Supported from Cisco IOS XE 17.9.1
 - ixgbe - Supported from Cisco IOS XE 17.10.1
- VMware vCenter - installation tool
- VMware vSwitch - standard or distributed vSwitches are supported
- Hard Drive - only a single hard disk drive is supported. Multiple hard disk drives on a VM are not supported
- Virtual Disk - both 16 GB and 8 GB virtual disks are supported
- ESXi hypervisor - refer the table in this section for the supported versions
- Virtual CPU core - one virtual CPU core is required. This needs a 64-bit processor with Virtualization Technology (VT) enabled in the BIOS setup of the host machine.
- Virtual hard disk space - a minimum size of 8 GB
- A default video and an SCSI controller set and an installed virtual CD/DVD drive are also required for this installation.



Note The supported version of the NIC driver and the firmware version are the default versions that are included with the hypervisor package.



Tip Familiarize yourself about the secure boot configuration before you proceed with the installation. To see information about secure boot, see [Enabling VNF Secure Boot, on page 83](#).

Supported VMware Features and Operations

VMware supports various features and operations that allow you to manage your virtual applications and perform operations such as cloning, migration, shutdown and resume.

Some of these operations cause the runtime state of the VM to be saved and then restored upon restarting. If the runtime state includes traffic-related state, then on resumption or replaying the runtime state, additional errors, statistics, or messages are displayed on the user console. If the saved state is just configuration driven, you can use these features and operations without a problem.

The *Supported VMware Features and Operations: Storage Options (for Both vCenter Server and vSphere Client)* table lists the VMware features and operations that are supported on Cisco Catalyst 8000V. For more information about VMware features and operations, see the [VMware Documentation](#).

The following VMware features and operations are not supported in all versions of Cisco Catalyst 8000V, but can still be used or performed on non-supported versions at the risk of encountering dropped packets, dropped connections, and other error statistics:

- Distributed Resource Scheduling (DRS)
- Fault Tolerance
- Resume
- Snapshot
- Suspend

General Features (vCenter Server)

Table 2: Supported VMware Features and Operations: General Features (for vCenter Server Only)

Supported Entities	Description
Cloning	Enables cloning a virtual machine or template, or cloning a virtual machine to a template.
Migrating	The entire state of the virtual machine as well as its configuration file, if necessary, is moved to the new host even while the data storage remains in the same location on shared storage.
vMotion	Enables moving the VM from one physical server to another while the VM remains active.
Template	Uses templates to create new virtual machines by cloning the template as a virtual machine.

Operations (for vCenter Server and vSphere Web Client)

Table 3: Supported VMware Features and Operations: Operations (for vCenter Server and vSphere Client)

Supported Entities	Description
Power On	Powers on the virtual machine and boots the guest operating system if the guest operating system is installed.
Power Off	Stops the virtual machine until it is powered back. The power off option performs a “hard” power off, which is analogous to pulling the power cable on a physical machine and always works.
Shut Down	Shut Down, or “soft” power off, leverages VMware Tools to perform a graceful shutdown of a guest operating system. In certain situations, such as when VMware Tools is not installed or the guest operating system is hung, shut down might not succeed and using the Power off option is necessary.
Suspend	Suspends the virtual machine.
Reset/Restart	Stops the virtual machine and restarts (reboots) it.
OVF Creation	An OVF package consisting of several files in a directory captures the state of a virtual machine including disk files that are stored in a compressed format. You can export an OVF package to your local computer.
OVA Creation	You can create a single OVA package file from the OVF package/template. The OVA can then be distributed more easily; for example, it may be downloaded from a website or moved via a USB key.

Table 4: Supported VMware Features and Operations: Networking Features

Supported Entities	Description
Custom MAC address	From both vCenter Server and vSphere Client. Allows you to set up the MAC address manually for a virtual network adapter.
Distributed VSwitch	From vCenter Server only. A vSphere distributed switch on a vCenter Server data center can handle networking traffic for all associated hosts on the data center.
Distributed Resources Scheduler	Provides automatic load balancing across hosts.
NIC Load Balancing	From both vCenter Server and vSphere Client. Load balancing and failover policies allow you to determine how network traffic is distributed between adapters and how to reroute traffic if an adapter fails.
NIC Teaming	<p>From both vCenter Server and vSphere Client. Allows you to set up an environment where each virtual switch connects to two uplink adapters that form a NIC team. The NIC teams can then either share the load of traffic between physical and virtual networks among some or all of its members, or provide passive failover in the event of a hardware failure or a network outage.</p> <p>Note NIC Teaming can cause a large number of ARP packets to flood the Cisco Catalyst 8000V and overload the CPU. To avoid this situation, reduce the number of ARP packets and implement NIC Teaming as Active-Standby rather than Active-Active.</p>

Supported Entities	Description
vSwitch	From both vCenter Server and vSphere Client. A vSwitch is a virtualized version of a Layer 2 physical switch. A vSwitch can route traffic internally between virtual machines and link to external networks. You can use vSwitches to combine the bandwidth of multiple network adapters and balance communications traffic among them. You can also configure a vSwitch to handle a physical NIC fail-over.

High Availability


Note

Cisco IOS-based High Availability is not supported by the Cisco Catalyst 8000V instance. High Availability is supported on the VM host only.

Table 5: Supported VMware Features and Operations: High Availability

Supported Entities	Description
VM-Level High Availability	To monitor operating system failures, VM-Level High Availability monitors heartbeat information in the VMware High Availability cluster. Failures are detected when no heartbeat is received from a given virtual machine within a user-specified time interval. VM-Level High Availability is enabled by creating a resource pool of VMs using VMware vCenter Server.
Host-Level High Availability	To monitor physical servers, an agent on each server maintains a heartbeat with the other servers in the resource pool such that a loss of heartbeat automatically initiates the restart of all affected virtual machines on other servers in the resource pool. Host-Level High Availability is enabled by creating a resource pool of servers or hosts, and enabling high availability in vSphere.
Fault Tolerance	Using high availability, fault tolerance is enabled on the ESXi host. When you enable fault tolerance on the VM running the Cisco Catalyst 8000V instance, a secondary VM on another host in the cluster is created. If the primary host goes down, then the VM on the secondary host will take over as the primary VM for the Cisco Catalyst 8000V.

Storage Options (for vCenter Server and vSphere Web Client)

Table 6: Supported VMware Features and Operations: Storage Options (for Both vCenter Server and vSphere Client)

Supported Entities	Description
Storage Options (for both vCenter Server and vSphere Client)	

Supported Entities	Description
Local Storage	Local storage is in the internal hard disks located inside your ESXi host. Local storage devices do not support sharing across multiple hosts. A datastore on a local storage device can be accessed by only one host.
External Storage Target	You can deploy the Cisco Catalyst 8000V instance on external storage. That is, a Storage Area Network (SAN).
Mount or Pass Through of USB Storage	<p>You can connect USB sticks to the Cisco Catalyst 8000V instance and use them as storage devices. In ESXi, you need to add a USB controller and then assign the disk devices to the Cisco Catalyst 8000V instance.</p> <ul style="list-style-type: none"> • Cisco Catalyst 8000V supports USB disk hot-plug. • You can use only two USB disk hot-plug devices at a time. • USB hub is not supported.

Deploying the OVA to the VM using vSphere

The Cisco Catalyst 8000V OVA file package allows you to deploy the Cisco Catalyst 8000V to the VM. The OVA package includes an OVF file that contains a default VM configuration based on the Cisco IOS XE release and the supported hypervisor.

Restrictions and Requirements

The following restrictions apply when deploying the OVA package to the VM:

If the virtual CPU configuration is changed, you must reboot the Cisco Catalyst 8000V instance. Changing the RAM allocation does not require you to reboot the Cisco Catalyst 8000V instance.

The OVA package provides an option to select the virtual CPU configuration.

When you deploy the OVA, the VM requires two virtual CD/DVD drives, one for the OVF environment file and one for the .iso file.

Deploying the OVA to the VM

Perform the following steps in VMware vSphere Client:

-
- Step 1** Log in to the VMware vSphere Client.
- Step 2** From the vSphere Client Menu Bar, choose **File > Deploy OVF Template**.
- Step 3** In the OVA Wizard, point the source to the Cisco Catalyst 8000V OVA to be deployed. Click **Next**.
The system displays the OVF Template Details with the information about the OVA. Click **Next**.

Step 4 Under **Name and Inventory Location**, specify the name for the VM and click **Next**.

Step 5 Under **Deployment Configuration**, select the desired hardware configuration profile from the drop-down menu and click **Next**.

Step 6 Under **Storage**, select the Datastore to use for the VM. Click **Next**.

Step 7 Under **Disk Format**, select the disk format option:

- Thick Provision Lazy Zeroed
- Thick Provision Eager Zeroed

Note The Thin Provision option is not supported. The Thick Provision Eager Zeroed option takes longer to install but provides better performance.

Click **Next**.

Step 8 Under **Network Mapping**, allocate one or more virtual network interface card (vNIC) on the destination network using the drop-down list.

Select the network mappings for the 3 default vNICs created during the OVA deployment. You can choose which vNIC will map to the router's management interface when setting the bootstrap properties.

Note After you make any change to the bootstrap properties, the system assumes that you are starting with a fresh VM. So, when the VM restarts, all the pre-existing networking configuration is removed.

Step 9 Select the vNIC to connect at **Power On**. Click **Next**.

When the Cisco Catalyst 8000V installation using the OVA is complete, two additional vNICs are allocated. Cisco Catalyst 8000V supports up to ten vNICs. You must manually create additional vNICs on the VM.

Step 10 Configure the properties for the VM.

Note After you make any change to the bootstrap properties the system assumes that you are starting with a fresh VM. So when the VM restarts, all pre-existing networking configuration is removed.

Note The bootstrap properties are optional when creating the VM. You can set these properties to easily provision the VM before starting it up.

Table 7: OVA Bootstrap Properties

Property	Description
Bootstrap Properties	
Console	Configures the console mode. Possible values: virtual, serial
Login Username	Sets the login username for the router.
Login Password	Sets the login password for the router.
Management Interface	Designates the management interface for the Cisco Catalyst 8000V instance. The format must be GigabitEthernetx or GigabitEthernetx.xxx. Note The GigabitEthernet0 interface is no longer supported.

Property	Description
Management vLAN	Configures the dot1Q VLAN interface. Requires the management interface to be configured using the GigabitEthernetx.xxx format.
Management Interface IPv4 Address/Mask	Configures the IPv4 address and subnet mask for the management interface.
Management IPv4 Default Gateway	Configures the IPv4 management default gateway address. If using DHCP, enter “dhcp” in the field.
Management IPv4 Gateway	Configures the IPv4 management default gateway address. If using DHCP, enter “dhcp” in the field.
Management IPv4 Network	Configures the IPv4 Network (such as “192.168.2.0/24” or “192.168.2.0 255.255.255.0”) that the management gateway should route to. If a default route (0.0.0.0/0) is desired, this may be left blank.
PNSC IPv4 Address	Configures the IP address of the Cisco Prime Network Services Controller. This setting is used if you plan to remotely manage the Cisco Catalyst 8000V instance using the Cisco Prime Network Services Controller.
Router name	Configures the hostname of the router.
Resource Template	Configures the Resource Template. Possible values: default, service_plane_medium, service_plane_heavy
Features	
Enable SCP Server	Enables the IOS SCP feature.
Enable SSH Login and Disable Telnet Login	Enables remote login using SSH and disables remote login via Telnet. Requires that the login username and password are set.
Additional Configuration Properties	
Enable Password	Configures the password for privileged (enable) access.
Domain Name	Configures the network domain name.
License Boot Level	Configures the license technology level that is available when the Cisco Catalyst 8000V instance boots. The available license levels are: <ul style="list-style-type: none"> • network-essentials • network-advantage • network-premier <p>Note For details on Cisco DNA licenses, see Cisco DNA Software for SD-WAN and Routing.</p>

After you configure the router properties, click **Next**. The system displays the Ready to Complete screen with the settings to be used when the OVA is deployed.

You can also configure advanced properties after the router boots.

Step 11 Select **Power On After Deployment** to automatically power on the VM.

Step 12 Click **Finish** to deploy the OVA.

The OVA deploys the .iso file, and if you select the **Power on after deployment** setting, the VM is automatically powered on. Once the VM is powered on, the Cisco Catalyst 8000V device begins the installation and boot process. If a bootstrap configuration file was included in the OVA, the router configuration is automatically enabled.

For more information, see [Booting the Cisco Catalyst 8000V and Accessing the Console](#).

Deploying the OVA to the VM Using COT

The Cisco Catalyst 8000V OVA file package allows you to deploy the Cisco Catalyst 8000V to the VM. The OVA package includes an OVF file that contains a default VM configuration based on the Cisco IOS XE release and the supported hypervisor. You can deploy the OVA using VMware vSphere or COT or the Common OVF Tool. This section describes how to deploy using the COT.

The Common OVF Tool (COT) included in the Cisco Catalyst 8000V software package is a Linux-based application that enables you to create attributes for one or more VMs and quickly deploy VMs with the Cisco Catalyst 8000V software pre-installed. This tool can speed the process of deploying Cisco Catalyst 8000V on multiple VMs.

COT provides a simple command-line interface to enter the VM attributes into the .ova file. You can run COT either in a LINUX shell or on Mac OS X. However, ensure that VMware ovftools are installed.



Danger The Common OVF Tool (COT) is provided without official Cisco support. Use it at your own risk.

Downloading COT

Download and install the COT libraries and script according to the instructions provided in the <http://cot.readthedocs.io/en/latest/installation.html> GitHub site.

Editing the Basic Properties of Cisco Catalyst 8000V using COT

Before you deploy Cisco Catalyst 8000V using COT, you can edit the basic or custom properties of the Cisco Catalyst 8000V VM in the OVA package using COT.

To edit the basic properties of the OVA, use the **cot edit-properties** command.

cot edit-properties

-p *key1=value1*, **--properties** *key1=value1*

This command sets properties using key value pairs. For Example, **-p "login-username=cisco"** sets the login username using a key value pair.

-o *output*

Specifies the name or the path to a new OVA package, if you are creating a new OVA instead of updating the existing OVA.

For more information on the **cot edit-properties** command, see:

http://cot.readthedocs.io/en/latest/usage_edit_properties.html

Editing the Basic Properties of Cisco Catalyst 8000V using COT [Sample]

```
cot edit-properties c8000v-universalk9.ova
-p "login-username=cisco"

-p "login-password=cisco"
-o c8000v-universalk9-customized.ova
\# save modifications to a new OVA
cot info c8000v-universalk9-customized.ova
\# verify the new values of properties in the OVA
(...)
Properties:
  <config-version>                                "1.0"
  Router Name                                       ""
  Login Username                                   "cisco"
  Login Password                                   "cisco"
  Management Interface                             "GigabitEthernet1"
  Management VLAN                                  ""
  Management Interface IPv4 Address/Mask           ""
```

The following table specifies the **cot edit-properties** command and arguments used in the above example.

Script Step	Description
<code>cot edit properties c8000v-universalk9.ova</code>	Edits the basic environment properties of the OVA file.
<code>-p "login-username=cisco"</code>	Sets the bootstrap login username.
<code>-p "login-password=cisco"</code>	Sets the bootstrap login password.
<code>-o "c8000v-universalk9-customized.ova"</code>	Saves a modified OVA, which contains configuration commands from the text file.

Editing the Custom Properties

You can add custom properties to your Cisco Catalyst 8000V instance based on the Cisco IOS XE CLI commands using the vSphere GUI. You can add these properties either before or after you boot the Cisco Catalyst 8000V instance. If you set these custom properties after you boot the Cisco Catalyst 8000V instance, you must reload the router or power-cycle the VM for the properties settings to take effect.

To edit the vApp options to add the custom Cisco Catalyst 8000V properties, do the following:

-
- Step 1** In the vSphere GUI, select the **Options** tab.
 - Step 2** Select **vApp Options > Advanced**.
 - Step 3** In the Advanced Property Configuration screen, click the **Properties** button.

Step 4 Click **New** to add a property.

Step 5 In the Edit Property Settings screen, enter the information to create the new custom property based on a Cisco IOS XE CLI command:

Note Before adding a custom property, make sure that the Cisco IOS XE command upon which it is based is supported for your Cisco Catalyst 8000V version.

- a) (Optional) Enter the label. This is a descriptive string for the property.
- b) Enter the class ID as “com.cisco.c8000v”.
- c) Assign the property an ID of “ios-config-xxxx” where xxxx is a sequence number from 0001 to 9999 that determines the order in which the custom properties are applied.
- d) (Optional) Enter a description for the property.
- e) Enter the property type as “string”. This is the only type supported.
- f) Enter the default value as the Cisco IOS XE CLI command the custom property is based on.

Step 6 Click **OK**.

Step 7 In the Advanced Property Configuration screen, click **OK**.

Step 8 Reboot the Cisco Catalyst 8000V instance.

You must reboot the router for the new or edited properties to take effect.

cot edit-properties

Use the **cot edit-properties** command to pre-apply a small number of configuration commands to the OVA.

To use more commands, use the **cot inject-config** command.

For more information about the **cot edit-properties** command, see http://cot.readthedocs.io/en/latest/usage_edit_properties.html.

Synopsis and Description

cot edit-properties *ova-filename*

-o *output*

Specifies the name or path to a new OVA package, if you are creating a new OVA instead of updating the existing OVA.

-c *config-file*

Specifies the name of a text file containing IOS XE commands to be added to the OVA.

Example

In this example, a previously created text file, `iosxe_config.txt`, containing IOS XE config commands is added to the OVA using the **cot edit-properties** command. Finally, the **cot info** command is used to show the modified OVA.

```
$ cat iosxe_config.txt

interface GigabitEthernet1
no shutdown
```



```

ip address 192.168.100.10 255.255.255.0
!
ip route 0.0.0.0 0.0.0.0 GigabitEthernet1 192.168.100.1
$ cot edit-properties c8000v-universalk9.ova \
    -o c8000v-universalk9-customized.ova \
    -c iosxe_config.txt
$ cot info c8000v-universalk9-customized.ova

...

Properties:
  <config-version>          "1.0"
  Router Name               ""

...

Intercloud Tunnel Interface Gateway IPv4 Address  ""
<ios-config-0001>          "interface GigabitEthernet1"
<ios-config-0002>          "no shutdown"
<ios-config-0003>          "ip address 192.168.100.10 255.255.255.0"
<ios-config-0004>          "ip route 0.0.0.0 0.0.0.0 GigabitEthernet1 192.168.100.1"

```

The following table specifies the **cot edit properties** command and arguments used in the example.

Script Step	Description
<code>cot edit properties c8000v-universalk9.ova</code>	Edits the custom environment properties of the OVA file.
<code>-o "c8000v-universalk9-customized.ova"</code>	New OVA, containing configuration commands from the text file.
<code>-c iosxe_config.txt</code>	The text file that contains IOS XE configuration commands. Each line of configuration in this file results in an entry such as <code>com.cisco.productname.ios-config-xxxx</code> in the XML of the OVF.

cot inject-config

Use the **cot inject-config** command if you have a large set of configuration commands to pre-apply to the OVA. For example, if you want to add a complete running configuration. This is efficient in terms of file size and loading time as this command uses plain text for the configuration commands (instead of XML). For further details about the **cot inject-config** command, see http://cot.readthedocs.io/en/latest/usage_inject_config.html

Synopsis and Description

`cot inject-config ova-filename`

-o *output*

Specifies the name or path to a new OVA package if you are creating a new OVA instead of updating the existing OVA.

-c *config-file*

Specifies the name of a text file, such as `iosxe_config.txt` to be embedded in the OVA.

Example

In this example, the **cot inject-config** command adds Cisco IOS XE commands in text file `iosxe_config.txt` to the OVA.

```
$ cat iosxe_config.txt
interface GigabitEthernet1
no shutdown
ip address 192.168.100.10 255.255.255.0
!
ip route 0.0.0.0 0.0.0.0 GigabitEthernet1 192.168.100.1
$ cot inject-config c8000v-universalk9.ova \
```

```
-o c8000v-universalk9-customized.ova \
-c iosxe_config.txt
$ cot info c8000v-universalk9-customized.ova
```

<.. other output snipped for brevity ..>

Files and Disks:	File Size	Capacity	Device
c8000v_harddisk.vmdk	71.50 kB	8.00 GB	harddisk @ SCSI 0:0
bdeo.sh	52.42 kB		
README-OVF.txt	8.53 kB		
README-BDEO.txt	6.75 kB		
cot.tgz	116.78 kB		
c8000v-universalk9.iso	484.80 MB		cdrom @ IDE 1:0
config.iso	350.00 kB		cdrom @ IDE 1:1

The following table specifies the **cot inject-config** command and arguments used in the example.

Script Step	Description
<code>cot inject-config c8000v-universalk9.ova</code>	Edits the custom environment properties of the OVA file.
<code>-o "c8000v-universalk9-customized.ova"</code>	The name of the new or the modified OVA, containing the config commands from the text file.
<code>-c iosxe_config.txt</code>	The name of the text file that contains the IOS XE configuration commands.

Deploying the Cisco Catalyst 8000V VM using COT

To deploy the Cisco Catalyst 8000V VM, use the **cot deploy ... esxi** command as shown in the following step. Note that the following description provides general guidance. The exact steps that you need to perform may vary depending on the characteristics of your VMware environment and setup.

Run the **cot deploy ... esxi** command to deploy the Cisco Catalyst 8000V. The script options are described at: http://cot.readthedocs.io/en/latest/usage_deploy_esxi.html

Note The default values may vary depending on the Cisco Catalyst 8000V version.

Example

The table below shows an example **cot deploy** command, and its arguments, that is used to deploy a Cisco Catalyst 8000V VM in a vCenter environment.

Script Step	Description
<code>cot deploy</code>	
<code>-s '10.122.197.5/UCS/host/10.122.197.38'</code>	vCenter server 10.122.197.5, target host UCS/host/10.122.197.38
<code>-u administrator -p password</code>	Credentials for the ESXi server. If unspecified, COT will use your userid and prompt for a password.
<code>-n XE3.13</code>	Name of the newly created Cisco Catalyst 8000V VM.
<code>-c 1CPU-4GB</code>	OVF hardware config profile. If this is not specified, COT displays a list of available profiles and prompts you to select one.
<code>-N "GigabitEthernet1=VM Network"</code> <code>-N "GigabitEthernet2=VM Network"</code> <code>-N "GigabitEthernet3=VM Network"</code>	Mapping each NIC in the Cisco Catalyst 8000V OVA to a vSwitch on the server.
<code>esxi</code>	Target hypervisor (currently always ESXi)
<code>~/Downloads/c8000v-universalk9.ova</code>	OVA to deploy
<code>-ds=datastore38a</code>	Any ESXi-specific parameters - here, the datastore to use for disk storage.

Manually Creating the VM Using the .iso File

Perform the following steps to install the .iso file on the VMware ESXi host and manually and create the VM using the vSphere GUI. While this procedure provides general guidance for how to deploy Cisco Catalyst 8000V, the exact steps that you need to perform may vary depending on the characteristics of your VMware environment and setup. The instructions in this procedure are based on VMware ESXi 5.0.

-
- Step 1** Download the C8000V_esxi.iso file from the Cisco Catalyst 8000V software installation image package and copy it onto the VM Datastore.
 - Step 2** In the VSphere client, select **Create a New Virtual Machine** option.
 - Step 3** Under **Configuration**, select the option to create a Custom configuration, and click **Next**.
 - Step 4** Under **Name and Location**, specify the name for the VM and click **Next**.
 - Step 5** Under **Storage**, select the datastore to use for the VM. Click **Next**.

- Step 6** From the **Virtual Machine Version** field, select **Virtual Machine Version 15** or a higher version that is available. Click **Next**.
- Note** Cisco Catalyst 8000V is not compatible with ESXi Server versions prior to 6.5 Update 2.
- Step 7** Under **Guest Operating System**, select **Linux** and the **Other 3.x Linux (64-bit)** setting from the drop-down menu. Click **Next**.
- Step 8** Under **CPUs**, select the following settings:
- Number of virtual sockets (virtual CPUs)
 - Number of cores per socket
- The number of cores per socket should always be set to 1, regardless of the number of virtual sockets selected. For example, a Cisco Catalyst 8000V with a 4 vCPU configuration should be configured as 4 sockets and 1 core per socket. Click **Next**.
- Step 9** Under **Memory**, configure the supported memory size for your **Cisco Catalyst 8000V** release. Click **Next**.
- Step 10** Under **Network**, allocate at least three virtual network interface cards (vNICs).
- a) Select the number of vNICs that you want to connect from the drop-down menu.

Note The VMware ESXi interface only allows the creation of 4 vNICs during the initial VM creation. You can add more vNICs after the VM is created and you boot the Cisco Catalyst 8000V the first time.
 - b) Add the vNICs.

Select a different network for each vNIC.

Select the adapter type from the drop-down menu. See the requirements sections in this guide for the supported adapter type in your release.
 - c) Select all the vNICs to connect at power-on.
 - d) Click **Next**.

Note You can add vNICs into the VM using vSphere while the Cisco Catalyst 8000V is running. For more information about adding vNICs to an existing VM, see the vSphere documentation.
- Step 11** Under **SCSI Controller**, select **VMware Paravirtual**. Click **Next**.
- Step 12** Under **Select a Disk**, click **Create a New Virtual Disk**.
- Step 13** From the **Create a Disk** field, configure the following:
- a) **Capacity: Disk Size:** See the requirements sections in this guide for the virtual hard disk size required in your release.
 - b) **Disk Provisioning:** select one of the following: Thick Provision Lazy Zeroed or Thick Provision Eager Zeroed.

Note The Thin Provision option is not supported. The **Thick Provision Eager Zeroed** option takes longer to install but provides better performance.
 - c) **Location:** Store with the Virtual Machine
- Click **Next**.
- Step 14** From the **Advanced Options** field, select **SCSI (0:0)** for the virtual device node.
- Step 15** On the Ready to Complete screen, click the **Edit the Virtual Machine** settings before completion. Select the **Continue** checkbox.
- Step 16** In the **Hardware** tab, click **New CD/DVD Drive**.

- a) Select the **Device Type** that the VM will boot from:

Select the **Datastore ISO file** option to boot from the .iso file. Browse to the location of the .iso file on the datastore set in step 1.

- b) In the **Device Status** field, select the **Connect at Power On** checkbox.

- c) Select the **Virtual Device Node CD/DVD** drive on the host that the VM will boot from.

Step 17 In the **Resources** tab, click the **CPU** setting:

Set the **Resource Allocation** setting to **Unlimited**.

Step 18 Click **OK**.

Step 19 Click **Finish**.

The VM is now configured for the Cisco Catalyst 8000V and is ready to boot. The Cisco Catalyst 8000V is booted when the VM is powered on. See [Booting the Cisco Catalyst 8000V VM and Accessing the Console](#) sections.

Note To configure the day0 settings of a manually installed Cisco Catalyst 8000V, attach a second CD/DVD drive pointing to an ISO that contains the said bootstrap configuration. For further details on the supported bootstrap ISO contents, see [Day 0 Configuration, on page 59](#).

Note To access and configure the Cisco Catalyst 8000V from the serial port on the ESXi host instead of the virtual VGA console, provision the VM to use this setting before powering on the VM and booting the router.

Increasing the Performance on VMware ESXi Configurations

You can improve the performance of Cisco Catalyst 8000V running on ESXi environment by modifying the settings on the host and the virtual machine.

- Enable the hypervisor performance settings.
- Limit the overhead of vSwitch by enabling SR-IOV on the supported Physical NICs.
- Configure the vCPUs of the VM to run on the same NUMA node as Physical NICs.
- Set the **VM Latency Sensitivity** to **High**.

For more information about the VMware best practices for versions 6.7 and 6.5, see https://www.vmware.com/content/dam/digitalmarketing/vmware/en/pdf/techpaper/performance/Perf_Best_Practices_vSphere65.pdf and <https://www.vmware.com/techpapers/2019/vsphere-esxi-vcenter-server-67U2-performance-best-practices.html>.

Modifications to the Host Configuration

To improve the performance of the VMware ESXi configuration, perform the following modifications in the host configuration:

- Select the **High Performance** option under **Power Management**.
- Disable **Hyperthreading**.
- Enable SR-IOV for the supported physical adapters.

Modifications to the Virtual Machine Configuration

To improve the performance of the VMware ESXi configuration, perform the following modifications in the host configuration:

- Ensure that the ESXi version is compatible with your Cisco Catalyst 8000V version.
- Set the Virtual Hardware: CPU reservation setting to Maximum.
- Reserve all the guest memory in Virtual Hardware: Memory.
- Select **VMware Paravirtual** from **Virtual Hardware: SCSI Controller**.
- From the **Virtual Hardware: Network Adapter: Adapter Type** option, select SR-IOV for the supported NICs
- Set the **General Guest OS Version > VM Options** option to **Other 3.x or later Linux (64-bit)**.
- Set the **VM Options** option under **Advanced Latency Sensitivity** to High.
- Under **VM Options > Advanced Edit Configuration**, add “numa.nodeAffinity” to the same NUMA node as the SRIOV NIC.



CHAPTER 5

Installing in KVM Environments

Red Hat Enterprise Linux (RHEL) is an enterprise virtualization product produced by Red Hat. RHEL is based on Kernel-based Virtual Machine (KVM) - an open source, full virtualization solution for Linux on x86 hardware that contains virtualization extensions.

From Cisco IOS XE 17.12.1 release, Cisco Catalyst 8000V is also supported on Intel Atom® C3000 processor (Denverton) CPU-based servers with Intel x550 NIC on RHEL 8.4 KVM hypervisor. You can run Cisco Catalyst 8000V on other x86 CPUs with different versions of hypervisor operating systems, but support is only available on these listed versions.

You can install the Cisco Catalyst 8000V virtual router as a virtual machine on Red Hat KVM virtualization. The installation procedure first involves the manual creation of a VM. This is followed by the installation using a .iso file or a qcow2 file. You can install Cisco Catalyst 8000V in a KVM environment by using the:

- **GUI Tool:** Download and install the virt-manager RPM package on the KVM server. Virt-manager is a desktop user interface for managing virtual machines. Installation by using the GUI is the recommended installation method.
- **Command Line Interface:** In this method of installation, use the command line interface to install the Cisco Catalyst 8000V VM.



Note Deploying the OVA template in a KVM environment is not supported.

Cisco Catalyst 8000V supports the Virtio vNIC type on the KVM implementation. KVM supports a maximum of 26 vNICs.

- [Installation Requirements for KVM, on page 31](#)
- [Creating a KVM Instance, on page 33](#)
- [Cloning the VM, on page 36](#)
- [Increasing the KVM Configuration Performance, on page 36](#)
- [Configure the halt_poll_ns Parameter, on page 40](#)

Installation Requirements for KVM

The KVM requirements for Cisco Catalyst 8000V using Cisco IOS XE 17.4.x releases and later are as follows:

KVM Versions

Cisco IOS XE Release	KVM Version
Cisco IOS XE 17.4.x releases Cisco IOS XE 17.5.x releases Cisco IOS XE 17.6.x releases	Linux KVM based on Red Hat Enterprise Linux 7.5 and 7.7 are recommended for release 17.4.1 - tested and meets performance benchmarks.
Cisco IOS XE 17.6.3 release	Supports SUSE Linux Enterprise Server version 15 SP3.
Cisco IOS XE 17.7.x releases Cisco IOS XE 17.8.x releases Cisco IOS XE 17.9.x releases Cisco IOS XE 17.10.x releases Cisco IOS XE 17.11.x releases Cisco IOS XE 17.12 releases	Linux KVM based on Red Hat Enterprise Linux 7.7 and 8.4 are recommended.

Table 8: Supported VNICs

VNIC	Supported Releases
Virtio	Cisco IOS XE Release 17.4.1 and later
ixgbevf	Cisco IOS XE Release 17.4.1 and later
i40evf	Cisco IOS XE Release 17.4.1 and later
ConnectX-5VF	Cisco IOS XE Release 17.9.1 and later
Ixgbe	Cisco IOS XE Release 17.10.1 and later



Note If a vNIC with an i40evf driver is used, the maximum number of physical VLANs is limited to 512, shared across all (Virtual Functions) VFs, and the number of VLANs for a VF can be further limited by the host (PF) driver for untrusted VFs. The latest Intel i40e PF driver limits untrusted VFs to a maximum of 8 VLANs/sub-interfaces.

Maximum number of vNICs supported per VM instance - 26

• vCPUs. The following vCPU configurations are supported:

- 1 vCPU: requires minimum 4 GB RAM allocation
- 2 vCPUs: requires minimum 4 GB RAM allocation
- 4 vCPUs: requires minimum 4 GB RAM allocation
- 8 vCPUs: requires minimum 8 GB RAM allocation
- 16 vCPUs: requires minimum 8 GB RAM allocation (supported from Cisco IOS XE 17.11.1a)

- Virtual CPU cores - 1 vCPU is required
- Virtual hard disk size - 8 GB minimum
- Virtual CD/DVD drive installed (applicable only when installing using an .iso file or when providing Day0 configuration via an ISO) - required

Creating a KVM Instance

Creating the VM Using the GUI Tool

Before you begin

Download and install the virt-manager RPM package on the KVM server.

Download either the .qcow2 image or the .iso image from the Cisco Software Download page, and copy the file onto a local device or a network device.

-
- | | |
|----------------|---|
| Step 1 | Launch the virt-manager GUI. |
| Step 2 | Click Create a New Virtual Machine . |
| Step 3 | Do one of the following: <ul style="list-style-type: none">a) If you have downloaded the .qcow2 file, select Import Existing Disk Image.b) If you have downloaded the .iso file, select Local Install Media (ISO Image or CDROM). |
| Step 4 | Select the Cisco Catalyst 8000V qcow2 or iso file location. |
| Step 5 | Configure the memory and the CPU parameters. |
| Step 6 | Configure the virtual machine storage. |
| Step 7 | (Optional) To add additional hardware before creating the VM, select Customize configuration before install . The system displays the Add Hardware button. Click this button to add various hardware options, such as additional disks or a serial port interface. |
| Step 8 | (Optional) To add a serial console, follow the procedure as mentioned in Adding a Serial Console, on page 33 . |
| Step 9 | (Optional) If you want to customize your configuration before you create the VM, see Customizing Configuration Before Creating the VM, on page 34 . |
| Step 10 | Click Finish . |
| Step 11 | Access the Cisco Catalyst 8000V console by performing one of the following actions: <ul style="list-style-type: none">a) If you are using a virtual console, double-click the VM instance to access the VM console.b) If you are using a serial console, see Booting the Cisco Catalyst 8000V and Accessing the Console. |
-

Adding a Serial Console

Perform this task to enable access to the Cisco Catalyst 8000V instance by adding a serial console.

-
- | | |
|---------------|-----------------------------|
| Step 1 | Click Add Hardware . |
|---------------|-----------------------------|

- Step 2** Select the **Serial** option from the menu.
- Step 3** From the **Device Type** drop-down menu, select **TCP net console (tcp)**.
- Step 4** Specify the port number, and select the **Use Telnet** checkbox.
- Step 5** Click **Finish**.
- Step 6** After adding all necessary hardware, click **Begin Installation**.

Customizing Configuration Before Creating the VM

Before you begin

Perform the [Creating the VM Using the GUI Tool, on page 33](#) task by using a .qcow2 or an .iso image. Before you click **Finish**, select the **Customize configuration before install** option. The **Add Hardware** button appears.

Proceed to this procedure which describes the optional steps after selecting the **Customize Configuration Before Install** option.

- Step 1** Click **Add Hardware**.
 - Step 2** Select the **Storage** option.
 - Step 3** Select the **Select Managed Or Other Existing Storage** checkbox.
 - Step 4** Click **Browse** and navigate to the **c8000v_config.iso** location. This step is applicable only when you add a Day0 or bootstrap configuration.
 - Step 5** From the **Device-type** drop-down menu, select **IDE CDROM**.
 - Step 6** Click **Finish**.
 - Step 7** After adding all the necessary hardware, click **Begin Installation**.
- To perform the bootstrap configuration, see [Day 0 Configuration, on page 59](#).

Creating the VM Using CLI

- Download and install the virt-install RPM package on the KVM server.
- Download the **.qcow2** image from the Cisco Catalyst 8000V software installation image package and copy it onto a local or network device.

- Step 1** To create the VM for a .qcow2 image, use the virt-install command to create the instance and boot. Use the following syntax:

Example:

```
virt-install \
  --connect=qemu:///system \
  --name=my_c8kv_vm \
  --os-type=linux \
  --os-variant=rhel4 \
```

```
--arch=x86_64 \
--cpu host \
--vcpus=1,sockets=1,cores=1,threads=1 \
--hvm \
--ram=4096 \
--import \
--disk path=<path_to_c8000v_qcow2>,bus=ide,format=qcow2 \
--network bridge=virbr0,model=virtio \
--noreboot
```

Step 2 To create the VM, for a .iso image, perform the following steps:

- a) Create an 8G disk image in the **.qcow2** format using the **qemu-img** command.

Example:

```
qemu-img create -f qcow2 c8000v_disk.qcow2 8G
```

- b) Use the **virt-install** command to install the Cisco Catalyst 8000V instance. This requires the correct permissions to create a new VM. The following example creates a 1 vCPU Cisco Catalyst 8000V with 4G of RAM, one network interface, and one serial port.

Example:

```
virt-install \
--connect=qemu:///system \
--name=my_c8000v_vm \
--description "Test VM" \
--os-type=linux \
--os-variant=rhel4 \
--arch=x86_64 \
--cpu host \
--vcpus=1,sockets=1,cores=1,threads=1 \
--hvm \
--ram=4096 \
--cdrom=<path_to_c8000v_iso> \
--disk path=c8000v_disk.qcow2,bus=virtio,size=8,sparse=false,cache=none,format=qcow2 \
--network bridge=virbr0,model=virtio \
--noreboot
```

The **virt-install** command creates a new VM instance and Cisco Catalyst 8000V installs the image onto the specified disk file.

After the installation is complete, the Cisco Catalyst 8000V VM is shutdown. You can start the VM by executing the **virsh start** command.

Note If you want to provide the day0 configuration through the c8000v_config.iso disk image, add an additional parameter to the **virt-install** command. For example, **--disk path=/my/path/c8000v_config.iso,device=cdrom,bus=ide**. For more information, see [Day 0 Configuration, on page 59](#).

Red Hat Enterprise Linux - Setting Host Mode

Due to an [issue](#) specific to Red Hat Enterprise Linux, when you launch Cisco Catalyst 8000V in a Red Hat Enterprise Linux environment using **virt-install**, set the host mode as follows:

- In Red Hat Enterprise Linux 6, use:

```
--cpu host
```

- In Red Hat Enterprise Linux 7, use:

```
--cpu host-model
```

Cloning the VM

Issue

In a KVM environment, when you clone a Cisco Catalyst 8000V virtual machine using the **virt-manager** virtual machine manager, it results in a Cisco Catalyst 8000V virtual machine that you might not be able to boot. The issue is caused by an increase in the size of the cloned image size created by **virt-manager** compared to the original Cisco Catalyst 8000V VM image. The extra bytes (in the KB range) cause the boot failure.

Workaround

There are three workarounds:

- Use the **virt-clone** command to clone the Cisco Catalyst 8000V VM image.
- For a cloned Cisco Catalyst 8000V VM image created by **virt-manager** during the bootup, select the GOLDEN image to boot instead of packages.conf.
- In the Create a new virtual machine window, deselect **Allocate Entire Disk Now** before the new Cisco Catalyst 8000V VM is created. This ensures that the cloned Cisco Catalyst 8000V VM image is able to boot up. However, this workaround does not support nested cloning. Use this method only on the first cloned Cisco Catalyst 8000V VM image.

Increasing the KVM Configuration Performance

You can increase the performance for a Cisco Catalyst 8000V running in a KVM environment by modifying some settings on the KVM host. These settings are independent of the IOS XE configuration settings on the Cisco Catalyst 8000V instance.

To improve the KVM configuration performance, Cisco recommends that you:

- Enable vCPU pinning
- Enable emulator pinning
- Enable numa tuning. Ensure that all the vCPUs are pinned to the physical cores on the same socket.
- Set hugepage memory backing
- Use virtio instead of IDE
- Use graphics VNC instead of SPICE
- Remove unused devices USB, tablet etc.
- Disable memballoon



Note These settings might impact the number of VMs that you can be instantiate on a server. Tuning steps are most impactful for a small number of VMs that you instantiate on a host.

In addition to the above mentioned, do the following:

Enable CPU Pinning

Increase the performance for the KVM environments by using the KVM CPU Affinity option to assign a virtual machine to a specific processor. To use this option, configure CPU pinning on the KVM host.

In the KVM host environment, use the following commands:

- **virsh nodeinfo**: To verify the host topology to find out how many vCPUs are available for pinning by using the following command.
- **virsh capabilities**: To verify the available vCPU numbers.
- **virsh vcpupin <vmname> <vcpu#> <host core#>**: To pin the virtual CPUs to sets of processor cores.

This KVM command must be executed for each vCPU on your Cisco Catalyst 8000V instance. The following example pins virtual CPU 1 to host core 3:

virsh vcpupin c8000v 1 3

The following example shows the KVM commands needed if you have a Cisco Catalyst 8000V configuration with four vCPUs and the host has eight cores:

virsh vcpupin c8000v 0 2

virsh vcpupin c8000v 1 3

virsh vcpupin c8000v 2 4

virsh vcpupin c8000v 3 5

The host core number can be any number from 0 to 7. For more information, see the KVM documentation.



Note When you configure CPU pinning, consider the CPU topology of the host server. If you are using a Cisco Catalyst 8000V instance with multiple cores, do not configure CPU pinning across multiple sockets.

BIOS Settings

Optimize the performance of the KVM configuration by applying the recommended BIOS settings as mentioned in the following table:

Configuration	Recommended Setting
Intel Hyper-Threading Technology	Disabled
Number of Enable Cores	ALL
Execute Disable	Enabled

Configuration	Recommended Setting
Intel VT	Enabled
Intel VT-D	Enabled
Intel VT-D coherency support	Enabled
Intel VT-D ATS support	Enabled
CPU Performance	High throughput
Hardware Prefetcher	Disabled
Adjacent Cache Line Prefetcher	Disabled
DCU Streamer Prefetch	Disable
Power Technology	Custom
Enhanced Intel Speedstep Technology	Disabled
Intel Turbo Boost Technology	Enabled
Processor Power State C6	Disabled
Processor Power State C1 Enhanced	Disabled
Frequency Poor Override	Enabled
P-State Coordination	HW_ALL
Energy Performance	Performance

For information about Red Hat Enterprise Linux requirements, see the subsequent sections.

Host OS Settings

In the host side, Cisco recommends that you use hugepages and enable emulator pinning. The following are some of the recommended settings in the host side:

- Enable IOMMU=pt
- Enable intel_iommu=on
- Enable hugepages
- Use SR-IOV if your system supports it for higher networking performance. Please check SR-IOV limitations your system might have.

In addition to enabling hugepages and emulator pinning, the following settings are also recommended: nmi_watchdog=0 elevator=cfq transparent_hugepage=never



Note If you use Virtio VHOST USER with VPP or OVS-DPDK, you can increase the buffer size to 1024 (`rx_queue_size='1024'`) provided the version of your QEMU supports it.

IO Settings

You can use SR-IOV for better performance. However, note that this might bring in some limitations such as number of virtual functions (VF), OpenStack limitations for SR-IOV like QoS support, live migration and security group support.

If you use a modern vSwitch like fd.io VPP or OVS-DPDK, reserve at least 2 cores for the VPP worker threads or the OVS-DPDK PMD threads.

Configure the following parameters to run the VPP through command line:

- `-cpu host`: This parameter causes the VM to inherit the host OS flags. You require libvirt 0.9.11 or greater for this to be included in the xml configuration.
- `-m 8192`: You require 8GB RAM for optimal zero packet drop rates.
- `rombar=0`: To disable PXE boot delays, set `rombar=0` to the end of each device option list or add "`<rombar=off />`" to the device xml configuration.

Sample XMLs for KVM Performance Improvement

Sample XML for numa tuning

```
<numatune>
  <memory mode='strict' nodeset='0' />
</numatune>
```

Sample XML for vCPU and emulator pinning

```
<cputune>
  <vcpupin vcpu='0' cpuset='3' />
  <emulatorpin cpuset='3' />
</cputune>
```

Sample XML for hugepages

```
<currentMemory unit='KiB'>4194304</currentMemory>
<memoryBacking>
  <hugepages>
    <page size='1048576' unit='KiB' nodeset='0' />
  </hugepages>
  <nosharepages />
</memoryBacking>
```

Sample XML for virtio instead of IDE

```
<devices>
  <emulator>/usr/libexec/qemu-kvm</emulator>
```

```
<disk type='file' device='disk'>
  <driver name='qemu' type='qcow2' />
  <source file='/var/lib/libvirt/images/rhel7.0.qcow2' />
  <backingStore />
  <target dev='vda' bus='virtio' />
  <boot order='1' />
  <address type='pci' domain='0x0000' bus='0x00' slot='0x05' function='0x0' />
</disk>
```

Sample XML for VNC graphics

```
<graphics type='vnc' port='5900' autoport='yes' listen='127.0.0.1' keymap='en-us'>
  <listen type='address' address='127.0.0.1' />
</graphics>
```

XML for disabling memballon

```
<memballoon model='none'>
```

Configure the halt_poll_ns Parameter

halt_poll_ns is a KVM parameter that allows you to alter the behaviour of how idle KVM guest virtual CPUs (vcpus) are handled.

When a virtual CPU in a KVM guest has no threads to run, the QEMU traditionally halts the idle CPU. This setting specifies a period of 400 nanoseconds by default, where a virtual CPU waits and polls before entering a CPU Idle state.

When new work arrives during the polling period before the vcpu is halted, the vcpu is immediately ready to execute the work. If the vcpu has been idle when new work arrives, the vcpu must be brought out of the idle state before the new work can be started. The time taken from idle to running state induces additional latency which negatively impacts latency sensitive workloads.

With the default kernel parameters, the guest Cisco Catalyst 8000V router CPU consumes 100% of the host CPU.

You can configure halt_poll_ns in two ways:

- **Large halt_poll_ns:** In this case, more CPU is spent busy-spinning for events that wake the virtual CPU, and less acpi deep sleeps occur. This means more power is consumed. However, there are less wakeups from deep states states, which depending on the state that's configured, can cause issues like cache misses etc.
- **Small halt_poll_ns:** In this case, less CPU time is spent busy-spinning for events that wake the CPU, more acpi deep sleeps occur. Here, less power consumed, but more wakeups from deep sleep states are required. More wakeups can cause large amounts of deep sleep instances, which depending on the configuration, can cause large amounts of cache misses and long wakeup time.

Configuring the halt_poll_ns parameter

You can configure the halt_poll_ns parameter in the following ways:

1. At run time, run the following: `echo 0 > /sys/module/kvm/parameters/halt_poll_ns.`

2. When you load the module, perform the following configuration:

```
# rmmod kvm_intel
# rmmod kvm
# modprobe kvm halt_poll_ns=0
# modprobe kvm_intel
```

3. When you boot the device, add `kvm.halt_poll_ns=<specify value>` in the parameters section of grub2.



CHAPTER 6

Installing in an NFVIS Environment

Cisco Enterprise Network Function Virtualization Infrastructure Software (Cisco Enterprise NFVIS) is a Linux-based infrastructure software designed to help service providers and enterprises dynamically deploy virtualized network functions such as a virtual router, firewall, and WAN acceleration on a supported Cisco device.

The Cisco Enterprise NFVIS solution helps you convert your critical network functions into software, making it possible to deploy network services in minutes across dispersed locations. This solution provides a fully integrated platform that can run on top of a diverse network of both virtual and physical devices.

This chapter specifies how you can upgrade from Cisco Integrated Services Virtual Router (ISRv) to Cisco Catalyst 8000V. If your hardware is running on Cisco NFVIS, and you want to deploy this setup on a Cisco Catalyst 8000V, perform the procedures as mentioned in the *Installing the VM on NFVIS* section.



Note From the Cisco IOS XE 17.4.x release onwards, Cisco Catalyst 8000V replaces ISRv.
Cisco Catalyst 8000V requires NFVIS version 4.4 or later for deployments.

Supported Hardware Platforms running NFVIS

- Cisco 5400 Series Enterprise Network Compute System (ENCS)
- Cloud Services Platform 5000 Series (CSP)
- Cisco 8200 UCPE Series

Supported NIMS

- NIM-4G-LTE-VZ
- NIM-4G-LTE-ST
- NIM-4G-LTE-NA
- NIM-4G-LTE-GA
- NIM-4G-LTE-LA
- NIM-LTEA-EA
- NIM-LTEA-LA

- NIM-1MFT-T1/E1
- NIM-2MFT-T1/E1
- NIM-4MFT-T1/E1
- NIM-8MFT-T1/E1
- NIM-1CE1T1-PRI
- NIM-2CE1T1-PRI
- NIM-8CE1T1-PRI
- NIM-16A
- NIM-24A
- NIM-VA-B
- NIM-VAB-A
- NIM-VAB-M
- NIM-4SHDSL-EA
- NIM-1GE-CU-SFP
- NIM-2GE-CU-SFP
- NIM-ES2-8-P
- NIM-ES2-8 NIM-ES2-4

Supported NICs

Hardware	VNIC
ENCS	virtio, igbvf and i40evf
UCPE	virtio, igbvf and ixgbevf
CSP	<ul style="list-style-type: none"> • virtio, igbvf and i40evf - Supported from Cisco IOS XE 17.4.1 • ConnectX-5VF - Supported from Cisco IOS XE 17.9.1 • Ixgbe - Supported from Cisco IOS XE 17.10.1

Supported Profiles

- Mini – 1vCPU
- Small – 2vCPU
- Medium – 4vCPU



Note Cisco Catalyst 8000V works as a low latency VM and performs as expected with dedicated vCPU cores.

- [Install the VM in NFVIS, on page 45](#)
- [Install the VM in NFVIS \(Release 4.5.1 and Later\), on page 45](#)
- [Install the VM in NFVIS \(Release 4.5.0 and Earlier\), on page 48](#)
- [Monitor the Virtual Machine, on page 51](#)
- [Upgrade and Downgrade Between Cisco ISRV and Cisco Catalyst 8000V, on page 52](#)

Install the VM in NFVIS

From the Cisco IOS XE 17.4.1 release, you can either freshly install a Cisco Catalyst 8000V VM in NFVIS, or you can upgrade from an Cisco ISRV to Cisco Catalyst 8000V. The following are the key tasks that you must perform for the installation or the upgrade:

- **Register a VM image:** To register a VM image, you must first copy or download the VM image to the NFVIS server or host the image on a HTTP or HTTPs server. After you download the file, register the image using the registration API. This API allows you to specify the file path to the location (on an HTTP or HTTPs server) where the tar.gz file is hosted. Registering the image is a one-time activity. After you register an image on the HTTP or HTTPs server, and the registration is in the active state, you can perform multiple VM deployments using the registered image.
- **Create a custom profile:** After registering a VM image, you can optionally create a custom profile for the VM image. This is especially beneficial if the profiles defined in the image file do not match your requirements. Custom profiles allow you to provide specific profiling details for a VM image such as the virtual CPU on which the VM will run, the amount of virtual memory the VM will consume. Depending on the topology that you require, you can create additional networks and bridges to attach the VM during deployment.
- **Deploy the VM:** Deploy the VM by using the deployment API. This API allows you to provide values to the parameters that are passed to the system during deployment. Depending on the VM that you are deploying, some parameters are mandatory and others are optional. For more details on the APIs, see the [VM Lifecycle Management APIs](#).
- **Manage and monitor the VM:** You can monitor a VM using APIs and commands that enable you to get the VM status and debug logs. Using the VM management APIs, you can start, stop, or reboot a VM, and view the statistics for a VM, such as CPU usage. You can also change or update a VM profile. You can change a VM profile to one of the existing profiles in the image file. Alternatively, you can create a new custom profile for the VM. The vNICs on a VM can also be added or updated.

Install the VM in NFVIS (Release 4.5.1 and Later)

Install Cisco Catalyst 8000V in NFVIS Environment

If you want to install Cisco Catalyst 8000V on NFVIS version 4.5.1 or later, follow the procedures that follow this section.

To install Cisco Catalyst 8000V on earlier releases of NFVIS, see [Installing in an NFVIS Environment, on page 43](#).

Upload the Image on NFVIS

-
- Step 1** Log in to the NFVIS Portal.
- Step 2** Choose **Configuration > Virtual Machine > Images > Image Repository**.
- Step 3** Upload the installation file by doing one of the following:
- Choose **Local > Select File**, and from your device, locate and select the installation file.
 - Choose **Remote**.
- Step 4** If you chose Remote, provide the following details:
- a) **Image Name**: Specify the name of the image file in this field.
 - b) **Protocol**: Choose the protocol from this drop-down list.
 - c) **IP Address**: Specify the IP address for the remote location in this field.
 - d) **Port**: Specify the port for the remote location in this field.
 - e) **Image File Path**: Specify the file path to the image file in this field.
-

Create a Network

-
- Step 1** In the NFVIS Portal, choose **Configuration > Virtual Machine > Networking > Networks**.
- Step 2** To create a new network, click the + icon.
- Step 3** In the **Add Network** area, enter the following details:
- a) **Network**: Choose the network from this drop-down list.
 - b) **Mode**: Enter the mode in which the VNF will boot.
 - c) **VLAN**: Choose the VLAN for the VM.
 - d) **VLAN-Range**: Enter the range of VLAN for your VM.
 - e) **Native VLAN**: Choose the native VLAN for your VM from this field.
 - f) **Bridge**: The Layer 2 domain between virtual network interface controllers (vNICs) of VMs. Choose either the **Existing** or the **Create New** radio button.
 - g) **Interface**: Choose the interface from this field for your VM.
- Note** Single Root Input/Output Virtualization (SR-IOV) is not supported in this installation.
- Step 4** Click **Submit**.
-

Create a VM Package

- Step 1** In the NFVIS portal, choose **Configuration > Virtual Machine > Images > Image Packaging**.
- Step 2** To create a VM package, click the + icon.
- Step 3** In the **Image Packaging** area, enter the following details:
- Name:** The name associated with the VM packaging.
 - Version:** The version of the package.
 - VM Type:** The type of the VM for which you're creating the package.
 - Dedicate Cores (Optimize):** The dedicated core a container requires. By default, the value is **False**.
 - Serial Console:** The field to either enable or disable access through the serial console. By default, the value is **Disable**.
 - SRIOV Driver:** The SRIOV supported by the VM interfaces.
 - Local:** The option you must use if the image you want to bundle is available in the intdatastore.
 - Upload Raw Images:** The option to upload an image to be packaged from your local machine.
 - Raw Disk File Bus:** Choose the root disk image bus from this drop-down list.
 - Thick Disk Provisioning:** Choose true from the drop-down list to enable thick provisioning. By default, the value is false.
- Step 4** To upload the bootstrap file, do one of the following:
- Choose **Local** and choose the **Add Local File** option to add a locally available bootstrap file.
 - Choose the **Upload Bootstrap Files** option to browse to the bootstrap configuration file from your computer.
 - Choose the track state of the VM from the **Monitored** drop-down field. By default, the value is **False**.
- Step 5** Click **Submit** to generate the VM Package.

Deploy the VM

- Step 1** In the NFVIS Portal, choose **Configuration > Deploy**.
- Step 2** In the **VM Deployment** window, choose the **Router** icon.
- Step 3** Click on the VM. Four drag handlers appears around the VM. Drag from one of those handlers to any of the networks and provide the details.
- Step 4** In the **VM Details** area, enter the following details:
- VM Name:** Specify the name for your VM.
 - Image:** Choose the appropriate value from the drop-down list.
 - Profile:** Choose a profile from the drop-down list. The default profile is used when no profile is specified during deployment.
 - Group Name:** Choose a group if you want this VM to be associated with a specific group.
 - VNC Password:** Enter the VNC password in this field.
 - Controller:** Choose **non-vManage** to deploy in autonomous mode and choose **vManage** to deploy the VM in controller mode.
 - Tech Package:** Choose the desired tech package from the drop-down field. The available options are network essentials, network advantage, and network premier.


- h) **NGIO**: The Next Generation Input/Output (NGIO) option that decides the NIM enablement capability available for the VM. Choose **ENABLE** from the NGIO drop-down list to enable NGIO.
- i) **SSH Username**: The username to remotely log in to the Cisco Catalyst 8000V VM.
- j) **SSH Password**: The SSH password to access the VM.
- k) **Port Number**: The port number that is required for the SSH connectivity to the VM.
- l) **External Port Number**: The external port number that is required for the SSH connectivity to the VM.

Step 5 Click **Deploy**.

Install the VM in NFVIS (Release 4.5.0 and Earlier)

Deploy the Virtual Machine on NFVIS

- Step 1** From the NFVIS Portal select **VM Lifecycle > Deploy**.
- Step 2** From the VM Deployment window, drag and drop the Router icon to the pane below and map to the desired networks as required.
- Step 3** In the VM Details section, enter the **VM Name**.
- Step 4** From the **Image** drop-down field, select the appropriate value.
- Step 5** From the **Mode** drop-down field, select the **non-vManage** option.
- Step 6** From the **Profile** drop-down field, select the profile name.
- Step 7** From the **Tech Package** drop-down field, select the desired tech package.
- Step 8** If a specific network function physical hardware is installed, you can pass it through into the VM by selecting **ENABLE** from the **NIM** drop-down field.
- Step 9** Select the **ENABLE** option from the **Crypto Offload** drop-down field to offload the crypto processing to a hardware chip.
- Step 10** Enter the username and password for the ssh login for Cisco Catalyst 8000V.
- Step 11** Optionally, add other VM details like **VNC Password**, **Port Number**, **External Port**, **Source Bridge**, **Deployment Disk**, and **Management IP**.
- Step 12** Select the **Add Bootstrap Config** option to provide the bootstrap configuration file before deploying the VM. Ensure that you use the filename `iosxe_config.txt` for the bootstrap configuration file.



Note Gigabit Ethernet 1 interface is reserved for management communications with NFVIS host.

Step 13 Click **Deploy**.

What to do next

After deploying the VM instance, check the Instance details through the **Manage** tab. This tab lists the summary of the VM instances.

To access the console, click the Console symbol next to the VM. You can also connect to the **serial console** of the VM using the following NFVIS command:

```
vmConsole <ROUTER-NAME>
```

Download the Cisco Catalyst 8000V Image for NFVIS

Step 1 Go to <https://software.cisco.com/download/home>

Step 2 In the Search bar at the bottom of the page, search Cisco Catalyst 8000V.


Step 3 Select the **Software Type** from the list. For example, IOS XE Software.

Step 4 From the list of files, download the latest Cisco Catalyst 8000V image file with the tar.gz extension.

Note To deploy a Cisco Catalyst 8000V image in NFVIS, the image must be packaged with the image properties file.

Upload the Image on NFVIS

- Step 1** Log in to the NFVIS Portal.
- Step 2** Select **VM Lifecycle > Image Repository**.
- Step 3** Click the **Image Registration** tab, and click the upload arrow next to the **Images** option.
- Step 4** From the **Drop Files or Click** option on the top of the page, select the appropriate file.




- Step 5** Click **Start** to upload the image.

After the image is uploaded, NFVIS creates the respective profiles and registers the image. You can find your file listed under the **Images** section on the same page.

Create a VM Package Using the Web Interface

- Step 1** From the NFVIS Web Portal, select **Image Repository > Image Packaging**. Click the **Create** icon.
- Step 2** Click **VM Packages**.
- Step 3** Enter the details in **Image Packaging** tab. Select **Yes** from the **Dedicated Code** drop-down list.



- Step 4** Click **Submit**. The bootstrap files are uploaded.

After the image is created, you have to register the image so that the profiles are populated in NFVIS.

Step 5 Select the image that you created and click **Register**.

Create a Network

Step 1 From the NFVIS Portal, select **VM Lifecycle > Networking**. The system displays the **Networks & Bridges** page.

Step 2 Click the **Create** icon next to Networks & Bridges.

Step 3 Enter the appropriate values for the **Network**, **Mode**, **VLAN**, **Bridge**, and **Interface** fields.

Single Root Input/Output Virtualization (SRIOV) is not supported.

The screenshot shows the 'Networks & Bridges' page in the NFVIS portal. On the left is a sidebar with navigation options: Home, VM Life Cycle, Deploy, Image Repository, Manage, Networking, Resource Allocation, VM Monitoring, Notifications, Host, About, Chassis, Calculator, and NFV Channel. The main area contains a form to create a new network. The form fields are: Network name (required), Mode (dropdown), Vlan (dropdown), Native Vlan (dropdown), Bridge (dropdown with 'Existing' and 'Create New' options), and Interface (dropdown). A 'Submit' button is at the bottom of the form. Below the form is a table titled 'Networks & Bridges' showing a list of existing networks and bridges.

Network	Mode	Vlans	Native Vlan	Bridge	Interfaces	Actions
lan-net	trunk			lan-br	GE0-2	
Not Associated	access			cellular-br	WI-CELL-1-0	
wan-net	trunk			wan-br	GE0-0	
wan2-net	trunk			wan2-br	GE0-1	

Showing 1 to 4 of 4 entries

Step 4 Click **Submit**. The network is now created.

Monitor the Virtual Machine

This procedure specifies the steps to monitor the VM and provides operational information such as resource allocation, VM statistics, and so on.

Step 1 To view the VM Resource Allocation follow these steps:

- From the NFVIS Portal select **VM Life Cycle > Resource Allocation**. The system displays the VM CPU Allocation tab which displays the overall CPU allocation.
- Click **VM Memory Allocation** to view the overall memory allocations.
- Click **VM Disk Allocation** to view the overall disk allocations.

Step 2 To view the VM Stastics, perform the following steps:

- From the NFVIS Portal select **VM Life Cycle > Resource Allocation**.

The system displays the VM CPU Utilization tab which displays the overall CPU utilization per VM.

- Click **Memory Allocation** to view the memory utilization per VM.

- c) Click **VNC Utilization** tab to view the VNIC utilization per VM.
- d) Click the **Disk Utilization** tab to view the disk utilization per VM.

The first interface on Cisco Catalyst 8000V is always reserved for Cisco NFVIS management network (generally Gigabit Ethernet 1). Cisco NFVIS assigns the IP address to this interface and it periodically monitors the VM by using ICMP pings via the interface.

Warning Shutting down the interface or changing the IP address might result in the recovery and reload of the NFVIS VM.

Upgrade and Downgrade Between Cisco ISRV and Cisco Catalyst 8000V

From the Cisco IOS XE 17.4.x release onwards, Cisco Catalyst 8000V replaces Cisco Integrated Services Virtual Router (ISRV). As a user, you have the option of upgrading your existing ISRV routers into Cisco Catalyst 8000V. To know how to upgrade to the latest release of Cisco Catalyst 8000V, see [Upgrading the Cisco IOS XE Software, on page 131](#).

Note

- You cannot downgrade from Cisco Catalyst 8000V to Cisco ISRV.
- To upgrade from Cisco ISRV to Cisco Catalyst 8000V, the minimum version of Cisco ISRV supported are 16.12.4, 17.2.3, 17.3.2. You cannot upgrade to Cisco Catalyst 8000V if you are using a Cisco ISRV device running on any other version than the ones mentioned above.
- When you upgrade from Cisco IOS XE 17.1.x or an earlier release to Cisco IOS XE 17.4.x, the **install add file bootflash:c8000v-universalk9.XXX.bin activate commit** command is not supported. To upgrade the Cisco ISRV to Cisco Catalyst 8000V, copy the c8000v-universalk9.XXX.bin file to bootflash:, under the Configuration folder. Then, use the **write memory** command to copy the configuration and start the upgrade process.
- If you are an existing Cisco CSR1000V user running Cisco IOS XE 16.12.3 release or earlier, and want to upgrade to Cisco Catalyst 8000V, you cannot upgrade by using the Web UI. You must first upgrade to Cisco CSR1000V releases 16.12.4, 17.2.3, or 17.3.2 before you upgrade to Cisco Catalyst 8000V.
- All licensing information is retained after you upgrade to Cisco Catalyst 8000V.

Supported Upgrade Paths

Autonomous Mode

- 16.12.x > 17.4 C8000V
- 17.2.x > 17.4 C8000V
- 17.3.x > 17.4 C8000V

Controller Mode

- 16.12.2 ISRV > 16.12.4 ISRV > 17.4 C8000V
- 16.12.3 ISRV > 16.12.4 ISRV > 17.4 C8000V
- 16.12.4 ISRV > 17.4 C8000V
- 17.1.1 ISRV > 17.3.x ISRV > 17.4 C8000V
- 17.2.1 ISRV > 17.2.2 ISRV > 17.4 C8000V
- 17.2.2 ISRV > 17.4 C8000V
- 17.3.x ISRV > 17.4 C8000V

**Note**

When you upgrade Cisco ISRV to Cisco Catalyst 8000V in the controller mode, first upgrade Cisco IOS XE to 17.3.1 and later releases or 16.12.4 and later releases.



CHAPTER 7

Installing in OpenStack Environment

From Cisco IOS XE Release 17.7.1, you can install and boot Cisco Catalyst 8000V on OpenStack Train which acts as a hypervisor manager. The OpenStack Train release is the 20th version of the open-source cloud infrastructure software on which you can launch virtual machines (VMs) or instances.

Both 8-GB and 16-GB disks are supported for this installation. You can install Cisco Catalyst 8000V VMs in OpenStack by using one of the following methods:

- Creating a VM manually through the OpenStack dashboard and then using the qcow2 image for the installation.
- Performing the installation by using a Heat template. In OpenStack, Heat is a service that orchestrates composite cloud applications using a template format through an OpenStack-core REST API. A Heat template describes the infrastructure for a cloud application in text files. These templates specify the relationships between resources, which enable Heat to call out to the OpenStack APIs. This action creates all your infrastructure in the correct order to launch your application.

After you install and launch a Cisco Catalyst 8000V instance, based on the bootstrap or the day zero configuration data that you provide, the router either starts in the autonomous mode or the controller mode.

Features Supported

The following are the features that are supported in the Cisco Catalyst 8000V installation in OpenStack:

- IPv6
- CDNA Licensing model
- vNIC hot add and delete in the autonomous mode
- [Installation Requirements for OpenStack, on page 55](#)
- [Restrictions for Installing in OpenStack, on page 56](#)
- [Install Cisco Catalyst 8000V in OpenStack, on page 56](#)

Installation Requirements for OpenStack

The requirements for installing Cisco Catalyst 8000V in OpenStack are:

- OpenStack Release: Train Release
- Red Hat Enterprise Linux (RHEL) Release 8.2 (Ootpa)

- RHEL OSP version 16.1 (Train)
- CVIM version 4.2
- Virtual disk: Both 8-GB and 16-GB virtual disks are supported
- Minimum supported profile: 1 vCPU with 4-GB memory and 8-GB or 16-GB virtual disk

Restrictions for Installing in OpenStack

Console URLs generated by OpenStack heat-deployments are subject to a token time-to-live (TTL) with a default setting of 10 minutes. Any NoVNC URLs that you use expires after this default time, especially under certain conditions, for example, with a lower profile instance bootup or while using different setups.

To overcome this limitation, use the built-in Instance VNC console in the portal, or the **virsh console** command in the compute node to access the console of the instance.

Install Cisco Catalyst 8000V in OpenStack

You can install Cisco Catalyst 8000V in one of the following ways:

- By using the OpenStack GUI. To learn how to do this, see [Launching an Instance, on page 56](#).
- By using the heat template. To learn how to perform this installation, see [Installing the VM Using a Heat Template, on page 57](#).
- By using the CLI. You can create a VM by running the **openstack server create** command in the OpenStack CLI. For more information, see <https://docs.openstack.org/python-openstackclient/train/cli/command-objects/server.html#server-create>.

Launching an Instance

-
- Step 1** On the OpenStack portal, click **Images**, and choose the image that you want to launch. Alternatively, you can also click **Instances** and then **Launch Instance**.
- Step 2** In the left pane, click **Details** and specify the following details:
- **Instance Name:** Enter a name for your instance.
 - **Description:** Enter a description for your instance. This field is optional.
 - **Availability Zone:** This field specifies the logical partitioning of the cloud. Enter **Nova** in this field.
 - **Count:** Enter the number of instances that you want to create. Increase the count to create multiple instances with the same settings.
- Step 3** Click **Next**.
- Step 4** In the left pane, click **Source**.
- Step 5** From the **Select Boot Source** drop-down field, choose either **Image**, **Instance Snapshot**, **Volume**, or **Volume Snapshot**.

The **Source** option specifies the template used to create an instance. You can use an image, a snapshot of an instance (image snapshot), a volume, or a volume snapshot (if enabled). You can also choose to use persistent storage by creating a new volume.

- Step 6** To delete the Volume when you delete the instance, from the **Delete Volume on Instance Delete** field, choose **Yes**.
- Step 7** In the left pane, click **Flavor**.
- Step 8** Choose an option based on your memory and storage requirements.
- Step 9** Click **Next**.
- Step 10** From the **Networks** option, choose a network to connect the Cisco Catalyst 8000V VM with the servers in that network. This option is also required if you want to set up a topology.
- Note** You can use the **Network Ports** drop-down list and choose an NIC if you want to select an SRIOV port to be attached to the VM.
- Step 11** Click **Next**.
- Step 12** From the **Security Groups** drop-down list, choose the security groups to launch your instance in. A default security group is also available.
- Step 13** Click **Next**.
- Step 14** In the **Configuration** section, copy and paste the user data in the **Customization Script** field. The following is a sample user data configuration script:
- ```
hostname c8kv-ios_cfg
license smart enable
username lab privilege 15 secret lab
ip domain-name cisco.com
interface GigabitEthernet1
ip address 10.0.0.5 255.255.255.0
no shut
exit
ip route 0.0.0.0 0.0.0.0 10.0.0.1
line vty 0 4
login local
exit
```
- Step 15** You can also upload an XML file or the iosxe\_config.txt file to provide user data or configuration data. Click **Choose File** and browse to your XML or .txt file.
- Note** For detailed information on configuring day zero settings, see [Day 0 Configuration, on page 59](#).
- Step 16** Check the **Configuration Drive** check box and click **Next**.
- Step 17** Click **Launch Instance** to launch your instance.
- Note** You must copy the ciscosdwan\_cloud\_init.cfg file to bootflash when you switch from the autonomous mode to the controller mode.

## Installing the VM Using a Heat Template

Heat templates in OpenStack allows you to create OpenStack resources such as instances, volumes, security groups, and so on. This template specifies the infrastructure for your cloud application in the form of text files and enables you to automate the deployment of infrastructure, services, and applications.

To install the OpenStack VM using a Heat template, perform the following steps:

- 
- Step 1** Log in to the OpenStack portal.
  - Step 2** From the menu options on top, click **Project**.
  - Step 3** Click **Orchestration** and select **Stack**.
  - Step 4** In the **Stacks** window, click **Launch Stack**.
  - Step 5** From the **Template Source** drop-down list, choose **File**, **URL**, or **Direct Input**, based on how you want to provide the template.
  - Step 6** If you chose the **File** option, click the **Choose File** option, browse to the location where you have saved your template file, upload this file, and click **Next**.
  - Step 7** Enter a name for your stack in the **Stack Name** field.
  - Step 8** To enable rollback, check the **Rollback on Failure** check box.
  - Step 9** Enter a password for the admin in the **Password for user “admin”** field.
  - Step 10** Click **Launch**.
- After the launch is complete, in the **Stacks** window, the system displays a Create Complete message in the **Status** column.
-



## CHAPTER 8

# Day 0 Configuration

Cisco Catalyst 8000V supports both Cisco IOS XE and the Cisco IOS XE SD-WAN functionalities. You can access the Cisco IOS XE functionalities by booting the instance in the autonomous mode. Similarly, to access and use the Cisco SD-WAN functionalities, boot your instance in the controller mode.

The autonomous mode is the default mode in which a Cisco Catalyst 8000V instance boots up. If you are a user who wants to proceed with the day 0 configuration in the autonomous mode, refer this chapter.



**Note** If you wish to deploy the Cisco Catalyst 8000V instance in the controller mode, see [Install and Upgrade for Cisco Catalyst 8000V Controller Mode](#).



**Attention** If the system is unable to detect any of the following four parameters – OTP, UUID, VBOND, ORG, the device boots in the autonomous mode.

### Bootstrap Support Across Hypervisors and Clouds

The following tables provide an overview of the bootstrap support across the hypervisors and the clouds for Cisco Catalyst 8000V in the autonomous mode:

| Hypervisor | iosxe_config.txt<br>on CD-ROM | ovf-env.xml<br>on CD-ROM | OVA<br>Installation | Config-drive<br>Format | Custom Data | User Data |
|------------|-------------------------------|--------------------------|---------------------|------------------------|-------------|-----------|
| VMware     | Yes                           | Yes                      | Yes                 | Yes                    | No          | No        |
| KVM        | Yes                           | Yes                      | No                  | Yes                    | No          | No        |
| AWS        | No                            | No                       | No                  | No                     | Yes         | Yes       |
| Azure      | No                            | No                       | No                  | No                     | Yes         | Yes       |
| GCP        | No                            | No                       | No                  | Yes                    | Yes         | Yes       |

### Feature Support for Day 0 Configuration

| Hypervisor                                    | iosxe_config.txt on CD-ROM        | ovf-env.xml on CD-ROM             | OVA Installation | Config-drive Format               | Custom Data | User Data                         |
|-----------------------------------------------|-----------------------------------|-----------------------------------|------------------|-----------------------------------|-------------|-----------------------------------|
| Raw configuration copy and paste              | Yes                               | Yes                               | No               | Yes                               | Yes         | Yes                               |
| Availability of specific configuration fields | No                                | Yes                               | Yes              | Yes                               | Yes         | Yes                               |
| GUI Availability                              | No                                | No                                | Yes              | No                                | No          | No                                |
| Guestshell Bootstrapping                      | Yes; via manual IOS configuration | Yes; via manual IOS configuration | No               | Yes; via manual IOS configuration | Yes         | Yes; via manual IOS configuration |

- Public clouds have one input mechanism through which you can provide the bootstrap information to a VM. However, on the device side, three bootstrap input formats are supported for each cloud – custom-data, user-data, and SDWAN (via the `ciscosdwan_cloud_init.cfg` file downloaded from vManage). For example, in AWS, you can provide the bootstrap information in any of the above-mentioned formats to the instance at launch via the EC2 user data text box or the File Upload option. Cisco Catalyst 8000V then determines and processes the configuration information that you provided.
- The custom-data and the user-data columns in the table mentioned above refer to the bootstrapping input formats and not the cloud native bootstrap input mechanisms for which they were originally named. All the public clouds support both the formats, but the custom-data format is more mature and is the recommended option for most applications.
- For private clouds, you can perform the bootstrap configuration by providing a configuration file in the `iosxe_config.txt` format or the `ovf-env.xml` format. You must upload the configuration file to the VM during Cisco Catalyst 8000V installation through an attached CD-ROM.
- [Prerequisites for the Day0 Configuration, on page 61](#)
- [Restrictions for the Day Zero Configuration, on page 61](#)
- [Selecting the Bootstrapping Mechanism, on page 61](#)
- [Day 0 Configuration Using .txt or .xml Files, on page 62](#)
- [Day 0 Configuration for OVF Templates, on page 66](#)
- [Day 0 Configuration Using Config-drive, on page 66](#)
- [Day 0 Configuration Using Custom Data, on page 67](#)
- [Day 0 Configuration in the Controller Mode, on page 76](#)
- [Verifying the Router Operation Mode and Day 0 Configuration, on page 76](#)
- [Frequently Asked Questions, on page 77](#)

## Prerequisites for the Day0 Configuration

- If you want to deploy the Cisco Catalyst 8000V instance in the controller mode, generate the bootstrap config file from vManage and rename the generated config file to `ciscosdwan_cloud_init.cfg`. Use the same file for the device to automatically bootup in the Controller mode and register to vManage.

Do not manually edit the automatically generated config file from vManage. This might cause the controller to go out of sync and the device's first power-on and bootup might not be successful.

## Restrictions for the Day Zero Configuration

- If you use the PayG licensing model, you cannot perform a mode switch as controller mode does not support the PayG licensing model.
- Only the autonomous mode supports Dual-IOSd.
- Images without payload encryption and NO-LI images are not supported in the controller mode.
- After onboarding and determining the mode of operation, if you switch from the controller mode to the autonomous mode or vice versa, it results in the loss of configuration.
- When you switch from the autonomous mode to the controller mode or vice versa, Cisco Federal Licensing and Smart Licensing registration does not work. You must reregister for the licenses to work.
- When you deploy a Cisco Catalyst 8000V VM by using GUI, the order of network interfaces added to the VM may not match the order in which the interfaces are created. This is because the interface numbering order is based on the name of the driver and the PCI address. Due to this behavior, the Day Zero Configuration might be applied incorrectly for some network interfaces. If you encounter this scenario, you must manually configure the affected network interfaces after you deploy the VM.

## Selecting the Bootstrapping Mechanism

Now that you know the supported bootstrap methods across the hypervisors and clouds, the next step is to decide the mechanism that you should choose to perform the day 0 configuration. You can configure the day 0 settings for your device by using:

- **The GUI tool:** If you have installed Cisco Catalyst 8000V on VMware, and you chose an OVA deployment, you can perform the configuration by using the OVA deployment wizard. This wizard supports the bootstrap-specific fields, and you don't have to manually create a bootstrap configuration file.
- **.txt file/.xml file:** If you are in a private cloud and you want to configure the day 0 settings through IOS configuration commands, we recommend choose the `iosxe_config.txt` file. This method allows you to take the CLIs that you wish to apply, paste them into a file, and provide it to the VM as a CD-ROM.
- **Custom data:** When you deploy Cisco Catalyst 8000V on AWS, Microsoft Azure, or GCP, the custom-data formatted bootstrap configuration is the recommended method. This configuration method is more functional and flexible compared to configuration by using user-data. Configuring the day 0 settings using user-data is primarily meant for users with an already established user-data deployment.

Read on to know more about each of these mechanisms in detail.

## Day 0 Configuration Using .txt or .xml Files

On a new, out-of-box device, during the installation, if you want to boot up the device in the autonomous mode, you can provide the bootstrap related configuration.

In a private cloud such as KVM environment, you can perform the bootstrap configuration by providing a `iosxe_config.txt` file or an `ovf-env.xml` file. This method allows you to gather the configurations that you wish to apply via the CLI, paste them into a file, and provide this content to the VM as a CD-ROM. Depending on the hypervisor environment, the data is then used for the bootstrap configuration.

The following sections explain this bootstrap configuration method in detail:

### Creating the Bootstrap File

This procedure provides the steps that you need to perform to create a bootstrap configuration file. This file, which is either in the .txt or .xml format, allows you to provide the day0 configuration for your device in a simple and flexible manner.

You can perform this procedure when you create the virtual machine in hypervisors such as KVM.

---

**Step 1** Create the `iosxe_config.txt` or the `ovf-env.xml` file.

- a) To create the `iosxe_config.txt` file, create a file with this name that contains the IOS config commands line by line.
- b) To create the `ovf-env.xml` file, select the properties that you wish to configure from Bootstrap Properties, and place them in a file with the specified name.

**Note** To know more about the individual properties in the .xml file, see [Bootstrap Properties, on page 62](#).

**Step 2** To convert the .xml or the .txt file to a consumable form for the virtual machine, create a disk image from the file using the following command:

**Example:**

```
mkisofs -l -o /my/path/c8000v_config.iso <configuration_filename>
```

**Step 3** Mount the `c8000v_config.iso` as an additional disk during creation of the Cisco Catalyst 8000V virtual machine.

---

### Bootstrap Properties

See the following table to know about the individual bootstrap properties using which you can create the `ovf-env.xml` file.

**Table 9: Bootstrap Properties**

| Property | Description                                                                 |
|----------|-----------------------------------------------------------------------------|
| console  | Configures the console mode. Possible values include auto, virtual, serial. |

| Property              | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| domain-name           | Domain name of the router.                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| enable-scp-server     | Enables the IOS SCP feature.                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| enable-ssh-server     | Enables remote login using SSH and disables remote login via Telnet. Requires that the login user name and password are set.                                                                                                                                                                                                                                                                                                                                                                  |
| hostname              | The host name of the router.                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| ios-config            | <p>Enables execution of a Cisco IOS command.</p> <p>To execute multiple commands, use multiple instances of ios-config, with a number appended to each instance. For example, ios-config-1, ios-config-2. The commands are executed in numerical order according to the appended number.</p> <p><b>Example</b></p> <pre>ios-config-1="username cisco priv 15 pass ciscoxyz" ios-config-2="ip scp server enable" ios-config-3="ip domain lookup" ios-config-4="ip domain name cisco.com"</pre> |
| license               | Configures the license technology level that is available when the Cisco Catalyst 8000V instance boots.                                                                                                                                                                                                                                                                                                                                                                                       |
| login-password        | The login password for the router.                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| login-username        | The user name for the router.                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| mgmt-interface        | Designates the management interface for the Cisco Catalyst 8000V instance. The format must be GigabitEthernetx or GigabitEthernetx.xxx.                                                                                                                                                                                                                                                                                                                                                       |
| mgmt-ipv4-addr        | The management gateway address/mask in the IPv4 format for the GigabitEthernet0 management interface.                                                                                                                                                                                                                                                                                                                                                                                         |
| mgmt-ipv4-gateway     | The IPv4 management default gateway address. If you're using DHCP, enter <b>dhcp</b> in the field.                                                                                                                                                                                                                                                                                                                                                                                            |
| mgmt-ipv4-network     | Configures the IPv4 Network (such as "192.168.2.0/24" or "192.168.2.0 255.255.255.0") that the management gateway should route to. If this value is not specified, the default route (0.0.0.0/0) is used.                                                                                                                                                                                                                                                                                     |
| mgmt-vlan             | Configures the dot1Q VLAN interface. Requires the management interface to be configured using the GigabitEthernetx.xxx format.                                                                                                                                                                                                                                                                                                                                                                |
| pnsd-agent-local-port | <p>(Optional) Configures the Cisco Prime Network Services Controller service agent SSL port on the local Cisco Catalyst 8000V to receive policies from the service manager.</p> <p>This setting is used if you plan to remotely manage the Cisco Catalyst 8000V using the Cisco Prime Network Services Controller.</p>                                                                                                                                                                        |

| Property               | Description                                                                                                                                                                                                                                                                                                                |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| pnsd-ipv4-addr         | Configures the IP address of the Cisco Prime Network Services Controller.<br>This setting is used if you plan to remotely manage the Cisco Catalyst 8000V instance using the Cisco Prime Network Services Controller.                                                                                                      |
| pnsd-shared-secret-key | Configures the Cisco Prime Network Services Controller shared secret key for the Cisco Prime Network Services Controller agent to set the SSL certificate from the controller.<br>This setting is used if you plan to remotely manage the Cisco Catalyst 8000V instance using the Cisco Prime Network Services Controller. |
| privilege-password     | Configures the password for privileged (enable) access.                                                                                                                                                                                                                                                                    |
| resource-template      | Configures the Resource Template. Possible values include default, service_plane_medium, and service_plane_heavy.                                                                                                                                                                                                          |



**Note** For a sample **ovf-env.xml** file, see [Sample ovf-env.xml File, on page 65](#).

## Sample iosxe\_config.txt File

```
hostname ultra-ios_cfg
license smart enable
username lab privilege 15 password lab
ip domain-name cisco.com
crypto key generate rsa modulus 1024
interface GigabitEthernet1
ip address 10.0.0.5 255.255.255.0
no shut
exit
ip route 0.0.0.0 0.0.0.0 10.0.0.1
line vty 0 4
login local
exit
```

### Sample iosxe\_config.txt File for OpenStack Environment

```
hostname c8kv-ios_cfg
license smart enable
username lab priv 15 secret lab
ip domain-name cisco.com
interface GigabitEthernet1
ip address 10.0.0.5 255.255.255.0
no shut
exit
ip route 0.0.0.0 0.0.0.0 10.0.0.1
line vty 0 4
login local
exit
```



## Sample ovf-env.xml File

```
<?xml version="1.0" encoding="UTF-8"?>
<Environment
 xmlns:oe="http://schemas.dmtf.org/ovf/environment/1">
 <PropertySection>
 <Property oe:key="com.cisco.c8000v.license.1" oe:value="security"/>
 <Property oe:key="com.cisco.c8000v.console.1" oe:value="serial"/>

 <Property oe:key="com.cisco.c8000v.config-version.1" oe:value="1.0"/>
 <Property oe:key="com.cisco.c8000v.domain-name.1" oe:value=""/>
 <Property oe:key="com.cisco.c8000v.enable-scp-server.1" oe:value="False"/>
 <Property oe:key="com.cisco.c8000v.enable-ssh-server.1" oe:value="False"/>
 <Property oe:key="com.cisco.c8000v.hostname.1" oe:value="lab"/>
 <Property oe:key="com.cisco.c8000v.license.1" oe:value="ax"/>
 <Property oe:key="com.cisco.c8000v.login-password.1" oe:value=""/>
 <Property oe:key="com.cisco.c8000v.login-username.1" oe:value="lab"/>
 <Property oe:key="com.cisco.c8000v.mgmt-interface.1" oe:value="GigabitEthernet1"/>
 <Property oe:key="com.cisco.c8000v.mgmt-ipv4-addr.1" oe:value="172.25.223.251/25"/>

 <Property oe:key="com.cisco.c8000v.mgmt-ipv4-gateway.1" oe:value="172.25.223.129"/>

 <Property oe:key="com.cisco.c8000v.mgmt-ipv4-network.1" oe:value=""/>
 <Property oe:key="com.cisco.c8000v.mgmt-vlan.1" oe:value=""/>
 <Property oe:key="com.cisco.c8000v.pnsc-agent-local-port.1" oe:value=""/>
 <Property oe:key="com.cisco.c8000v.pnsc-ipv4-addr.1" oe:value=""/>
 <Property oe:key="com.cisco.c8000v.pnsc-shared-secret-key.1" oe:value=""/>
 <Property oe:key="com.cisco.c8000v.privilege-password.1" oe:value=""/>
 <Property oe:key="com.cisco.c8000v.remote-mgmt-ipv4-addr.1" oe:value=""/>
 <Property oe:key="com.cisco.c8000v.resource-template.1"
oe:value="service_plane_medium"/>
 <Property oe:key="com.cisco.c8000v.ios-config-0001" oe:value="logging buffered
10000"/>
 <Property oe:key="com.cisco.c8000v.ios-config-0002" oe:value="hostname uut-ovf"/>
 <Property oe:key="com.cisco.c8000v.ios-config-0003" oe:value="ip domain-name
cisco.com"/>
 <Property oe:key="com.cisco.c8000v.ios-config-0004" oe:value="crypto key generate
rsa modulus 1024"/>
 <Property oe:key="com.cisco.c8000v.ios-config-0005" oe:value="interface
GigabitEthernet2"/>
 <Property oe:key="com.cisco.c8000v.ios-config-0006" oe:value="ip address 10.0.0.5
255.255.255.0"/>
 <Property oe:key="com.cisco.c8000v.ios-config-0007" oe:value="no shut"/>
 <Property oe:key="com.cisco.c8000v.ios-config-0008" oe:value="exit"/>
 <Property oe:key="com.cisco.c8000v.ios-config-0009" oe:value="ip route 0.0.0.0
0.0.0.0 10.0.0.1"/>
 </PropertySection>
</Environment>
```

### Sample ovf-env.xml File for OpenStack

```
<?xml version="1.0" encoding="UTF-8"?>
<Environment
 xmlns:oe="http://schemas.dmtf.org/ovf/environment/1">
 <PropertySection>
 <Property oe:key="com.cisco.c8000v.license.1" oe:value="network-premier add-on
dna-premier"/>
 <Property oe:key="com.cisco.c8000v.console.1" oe:value="virtual"/>

 <Property oe:key="com.cisco.c8000v.config-version.1" oe:value="1.0"/>
 <Property oe:key="com.cisco.c8000v.domain-name.1" oe:value=""/>
 <Property oe:key="com.cisco.c8000v.enable-scp-server.1" oe:value="False"/>
```

```

<Property oe:key="com.cisco.c8000v.enable-ssh-server.1" oe:value="False"/>
<Property oe:key="com.cisco.c8000v.hostname.1" oe:value="lab"/>
<Property oe:key="com.cisco.c8000v.login-password.1" oe:value="lab#123"/>
<Property oe:key="com.cisco.c8000v.login-username.1" oe:value="lab"/>
<Property oe:key="com.cisco.c8000v.mgmt-interface.1" oe:value="GigabitEthernet1"/>
<Property oe:key="com.cisco.c8000v.mgmt-ipv4-addr.1" oe:value=""/>
<Property oe:key="com.cisco.c8000v.mgmt-ipv4-gateway.1" oe:value="192.168.8.1"/>
<Property oe:key="com.cisco.c8000v.mgmt-ipv4-network.1" oe:value=""/>
<Property oe:key="com.cisco.c8000v.mgmt-vlan.1" oe:value=""/>
<Property oe:key="com.cisco.c8000v.pnsc-agent-local-port.1" oe:value=""/>
<Property oe:key="com.cisco.c8000v.pnsc-ipv4-addr.1" oe:value=""/>
<Property oe:key="com.cisco.c8000v.pnsc-shared-secret-key.1" oe:value=""/>
<Property oe:key="com.cisco.c8000v.privilege-password.1" oe:value="lab#123"/>
<Property oe:key="com.cisco.c8000v.remote-mgmt-ipv4-addr.1" oe:value=""/>
<Property oe:key="com.cisco.c8000v.resource-template.1" oe:value="service-plane-medium"/>
<Property oe:key="com.cisco.c8000v.ios-config-0001" oe:value="logging buffered 10000"/>
<Property oe:key="com.cisco.c8000v.ios-config-0002" oe:value="hostname uut-ovf"/>
<Property oe:key="com.cisco.c8000v.ios-config-0003" oe:value="ip domain name cisco.com"/>
<Property oe:key="com.cisco.c8000v.ios-config-0005" oe:value="interface GigabitEthernet2"/>
<Property oe:key="com.cisco.c8000v.ios-config-0006" oe:value="ip address dhcp"/>
<Property oe:key="com.cisco.c8000v.ios-config-0007" oe:value="no shut"/>
<Property oe:key="com.cisco.c8000v.ios-config-0008" oe:value="exit"/>
<Property oe:key="com.cisco.c8000v.ios-config-0009" oe:value="ip route 0.0.0.0 0.0.0.0
192.168.8.1"/>
<Property oe:key="com.cisco.c8000v.ios-config-0010" oe:value="interface GigabitEthernet1"/>
<Property oe:key="com.cisco.c8000v.ios-config-0011" oe:value="ip address dhcp"/>
<Property oe:key="com.cisco.c8000v.ios-config-0012" oe:value="no shut"/>
</PropertySection>
</Environment>

```

## Day 0 Configuration for OVF Templates

OVF deployments with full support for Day 0 bootstrapping are only supported in VMware via the vCenter UI or the COT tool. The Day 0 configuration for Cisco Catalyst 8000V running on the ESXi hypervisor is available in [Deploying the OVA to the VM, on page 19](#).

To know how to perform the day 0 configuration for deployments using the COT tool, see [Editing the Basic Properties of Cisco Catalyst 8000V using COT, on page 22](#).

## Day 0 Configuration Using Config-drive

Use the **--config-drive** option to specify that the configuration is loaded when Cisco Catalyst 8000V is booting. CD-ROMs and the second hard drive can also contain configuration information in the config-drive format. In either of these cases, this information is a file with contents that match the format of either the `iosxe_config.txt` file or the `ovf-env.xml` file.

To use the config drive option for your day zero configuration, set the **--config-drive** option to **true**, and specify the name of the configuration file in which you enter the router configuration to be booted. You can provide the configuration information in the following ways:

### As an XML/TXT File

In this option, you must provide the configuration file in one of the two possible formats:

- As an xml file in the `ovf-env.xml` file format (for OVF deployments)

- As a text file in the `iosxe_config.txt` file format

We strongly recommend that you use only one configuration file type, either the `.txt` file or the `.xml` file, and not both.

See the following sample configuration. Use one of these configurations to provide your configuration file in the filesystem:

```
nova boot c8000v-vm-174 --image c8000v-174 --flavor c8000v.2vcpu.4gb --nic
port-id=6773be11-7b95-48cd-b372-fb8a3cae2b50 --config-drive=true --file
ovf-env.xml=/home/stack/conf_files/ut/ovf-env.xml
```

OR

```
nova boot c8000v-vm-174 --image c8000v-174 --flavor c8000v.2vcpu.4gb --nic
port-id=6773be11-7b95-48cd-b372-fb8a3cae2b50 --config-drive=true --file
iosxe_config.txt=/home/stack/conf_files/ut/iosxe_config.txt
```




---

**Note** These file names are hard-coded and are required for the config-drive settings to boot.

---

### Using User Data

In certain environments such as OpenStack, use the **user\_data** option to provide the file into the filesystem with the config-drive format. See the following sample user data for the OpenStack environment:

```
openstack server create "admin-VK-C8KISOSerial-20210917"
--config-drive true
--image c8kv-image-176
--flavor m1.large
--network mgmt-nt
--network prod-nt
--block-device-mapping id=admin-VK-EmptyVolume-SerialTest:type=volume
--user-data userdata.txt
```

## Day 0 Configuration Using Custom Data

After you download the Cisco Catalyst 8000V installation files and deploy the image in your environment, the Cisco Catalyst 8000V instance requires manual configuration before the device is fully functional. To automate the configuration steps or to connect to on-premise sites, you can upload the Cisco Catalyst 8000V custom data or user data in all the supported public and private clouds.

By uploading the custom data for your cloud service provider or your private cloud, you can automate the day 0 and/or the bootstrap configuration. Upload or attach a bootstrap configuration file, (`iosxe_config.txt` file) or provide the user data to automate these processes to bring up the device into a functional state with minimal to no touch.

The Day 0 bootstrap file allows you to run Cisco IOS XE configuration commands, install Python packages in guestshell on Day0, run scripts in guestshell on Day0, and provide licensing information to boot the Cisco Catalyst 8000V instance with a desired technology package.

To launch a Cisco Catalyst 8000V instance by using custom data, perform the following steps:

## Editing the Day 0 Bootstrap File

To edit the bootstrap file, configure these properties: IOS Configuration, Scripts, Script credentials, Python package, and Licensing. The properties can be placed in the bootstrap file in any order. Dependencies between the properties are noted in each of the following property descriptions. See the example bootstrap files at: <https://github.com/csr1000v/customdata-examples>.

After you have defined the properties of the bootstrap file, upload the file .

## Configuring the IOS Configuration Property

If you want to bootstrap certain IOS configuration on Day0, configure the IOS Configuration property. See the following example:

```
Section: IOS configuration
hostname C8000V1
interface GigabitEthernet1
description "static IP address config"
ip address 10.0.0.1 255.255.255.0
interface GigabitEthernet2
description "DHCP based IP address config"
ip address dhcp
```

After the first line that reads `Section: IOS configuration`, enter a list of Cisco IOS XE configuration commands to be run on the Cisco Catalyst 8000V router.

When you run this command, the above mentioned IOS configuration is applied to the Cisco Catalyst 8000V router on Day0.

## Configuring the Scripts Property

Scripts property helps you to automate your deployment and achieve other automation goals. If you want to run a python or a bash script on Day0 under guestshell context, you can achieve the same by providing the public URL and arguments of the python or the bash script in Scripts property.

A script must include a piece of code that includes the shebang (!) character in the first line of the script. This line tells Cisco IOS-XE which script interpreter (Python or Bash) must be used to parse the script code. For example, the first line of a python script can contain `#!/usr/bin/env python`, while the first line of a bash script can contain `#!/bin/bash`. This line allows the Python or Bash script to run as executable code in a Linux environment.

When you execute the script, the script runs in the guestshell container of the Cisco Catalyst 8000V instance. To access the guestshell container, use the **guestshell** EXEC mode command. For more information on guestshell commands, see the [Programmability Configuration Guide](#).

To configure the Scripts property, follow the format given here:

```
Section: scripts
public_url <arg1> <arg2>
```

In this script, the first line of the property should read `Section: Scripts`.

In the second line of the property, enter the URL of the script and the script's arguments. The script can be either a python or a bash script. The script is run in guestshell in the first boot when the bootstrap file is uploaded when you create the Cisco Catalyst 8000V instance.

To view more examples of the scripts, see the *Scripts* section in <https://github.com/csr1000v/customdata-examples>. Also refer to the following two examples:

### Example 1

```
Section: Script
https://raw.githubusercontent.com/csr1000v/customdata-examples/master/scripts/smartLicensingConfigurator.py --idtoken "<token_string>" --throughput <throughput_value>
```

The two lines in the scripts property retrieve the `smartLicensingConfigurator.py` script from the `customdata-examples` repository at the specified URL. The script runs in the guestshell container of the Cisco Catalyst 8000V with the arguments `idtoken` and `throughput`.

### Example 2

```
Section: Scripts
ftp://10.11.0.4/dir1/dir2/script.py -a arg1 -s arg2
```

These two lines in the Scripts property retrieve the `script.py` script from the ftp server with the IP address 10.11.0.4, and runs the script with the `./script.py -a arg1 -s arg2 bash` command in the guestshell container of the Cisco Catalyst 8000V using arguments `arg1` and `arg2`.



**Note** If a script in the Scripts property requires a Python package that is not included in the standard CentOS Linux release (the CentOS Linux release that is used by the guestshell, which is currently CentOS Linux release 7.1.1503), you must include information about the Python package in the Python package property. For more information, see [Configuring the Python package Property, on page 70](#).

Prior to uploading the bootstrap file and running the bash or python script, Cisco recommends that you test the URL that you intend to use in the Scripts property. You can test the `ftp://10.11.0.4/dir1/dir2/script.py -a arg1 -s arg2` URL by first running the curl software tool to download the script file. In the guestshell, enter the curl command, as shown in the following example:

```
curl -m 30 --retry 5 --user username:password
ftp://10.11.0.4/dir1/dir2/script_needs_credentials.py.
```

If the curl command is successful, a copy of the python script is downloaded which verifies whether the URL is correct.

## Configuring the Script credentials Property

If you have specified an FTP server in the Script property, and the server requires a user name and password credentials, specify the credentials using the Script credentials property. If the FTP server can be accessed anonymously, you need not use the Script credentials property.

Configure the Scripts property with a URL and parameters that match those in the Script credentials property. To configure the Script credentials property, follow the format given below:

```
Section: Script credentials
public_url <username> <password>
```

### Example 1

```
Section: Script credentials
ftp://10.11.0.4/dir1/dir2/script1.py userfoo foospass
```

The second line in the Script credentials property specifies the values of the user name (`userfoo`) and password (`foospass`) credentials for the python script `script1.py`.

Include the name of the FTP server that is also in the Scripts property. An example line in the Scripts property is: `ftp://10.11.0.4/dir1/dir2/script1.py -a arg1 -s arg2`. See example 2 in [Configuring the Scripts Property, on page 68](#).

## Configuring the Python package Property

If a Python package is required by a script in the Scripts property and is not a part of the standard CentOS Linux release 7.1.1503, you must include information about the package in the Python package property. By including the Python package property in the bootstrap file, you ensure that the Cisco Catalyst 8000V downloads and installs the required Python package before running the script that you specified in the Scripts property.



**Note** Cisco Catalyst 8000V supports only Python3 in guestshell.

To configure the Python package property, follow the format as specified here:

```
Section: Python package
package_name [version] [sudo] { [pip_arg1 [..[pip_arg9]]] }
```

The arguments: *version*, **sudo**, and *pip\_arg1* to *pip\_arg9* are optional. You must put the arguments to the pip command between the “{” and “}” braces.

If you specify the *version* argument, the specific version number is downloaded.

If you specify the *sudo* argument, the package is downloaded as a sudo user.

### Sample Configuration (Microsoft Azure)

#### Example 1

In this example, the second line of the Python package property specifies that the *package\_name* is `ncclient` and the *version* is "0.5.2". When the bootstrap file is uploaded, version 0.5.2 of the `ncclient` package is installed in the guestshell container of Cisco Catalyst 8000V.

```
Section: Python package
ncclient 0.5.2
```

#### Example 2

```
Section: Python package
c8000v_azure_guestshell 1.1.2 sudo {--user}
```

In this example, the second line of the Python package property specifies that the *package\_name* is "c8000v\_azure\_guestshell" and the *version* is "1.1.2". When the bootstrap file is uploaded, version 1.1.2 of the `c8000v_azure_guestshell` package is installed in the guestshell container of Cisco Catalyst 8000V. The following command is executed as a sudo user: `sudo pip install c8000v_azure_guestshell==1.1.2 --user`.



**Note** If you do not specify an argument, `--user` is used as the default argument.

### Sample Configuration (Google Cloud Platform)

#### Example 1

Section: Python package

```
ncclient 0.5.2
```

In this example, the second line of the Python package property specifies that the *package\_name* is "ncclient", and the *version* is "0.5.2". When the bootstrap file is uploaded, version 0.5.2 of the ncclient package is installed in the guestshell container of the Cisco Catalyst 8000V instance.

#### Example 2

Section: Python package

```
c8000v_gcp_ha 3.0.0 sudo {--user}
```

In this example, the second line of the Python package property specifies that the *package\_name* is "c8000v\_gcp\_ha", and the *version* is "3.0.0". When the bootstrap file is uploaded, version 3.0.0 of the c8000v\_gcp\_ha package is installed in the guestshell container of the Cisco Catalyst 8000V instance. The following command is executed as a sudo user: `pip3 install c8000v_gcp_ha=3.0.0 --user`.




---

**Note** If you do not specify an argument, --user is used as the default argument.

---

## Configuring the License property

Configure the license property to specify the license technology level for Cisco Catalyst 8000V.

Enter the first line of the property: `Section: License`. Enter the second line of the property which specifies the tech level of the license, using the following format: **TechPackage:tech\_level**.




---

**Note** There must be no spaces between TechPackage: and the *tech\_level*. The possible *tech\_level* values include ax, security, appx, or ipbase)

---

*tech\_level* must be in lowercase.

#### Example 1

Section: License

```
TechPackage:security
```

## Providing the Day 0 Bootstrap File

Provide the Day 0 bootstrap file which creates a Cisco Catalyst 8000V VM by executing the following Azure CLI command:

```
az vm create --name C8000V-name --resource-group resource-group { [arg1 [..[arg9]]] }
--custom-data bootstrap-file
```

For further information on the **az vm create** command, see: <https://docs.microsoft.com/en-us/cli/azure/vm?view=azure-cli-latest#az-vm-create>.

See the following example:

```
az vm create -n c8000V-VM-Name -g MyResourceGroup --image
cisco:cisco-c8000V-1000v:16_6:16.6.120170804 --data-disk-sizes-gb 8 --availability-set
myAvlSet --nics nic1 nic2 nic3 nic4 --admin-username azureuser --admin-password "+Cisco123456"
--authentication-type password -l westus --size Standard_DS4_v2 --custom-data bootstrap.txt..
```

When you execute this command, a Cisco Catalyst 8000V VM is created. The router is configured using the commands in the bootstrap file: "bootstrap.txt".

Use the **Cisco C8000V Settings** option to provide the custom data bootstrap config file.

For further information on managing Linux VMs, see: [Tutorial: Create and Manage Linux VMs with the Azure CLI 2.0](#).

## Verifying the Custom Data Configuration (Microsoft Azure)

After you upload the Day 0 bootstrap file, the VM is created and configuration commands are executed. Perform the following commands to verify the configuration commands of each property.

To help determine if the license property worked, in Cisco IOS XE CLI on Cisco Catalyst 8000V, enter the **show version** command. For example, you should see a reference to the security license.

To see if errors occurred after running the commands in the scripts property, look at the customdata.log file in the /home/guestshell/customdata directory. The *scriptname.log* file stores any output sent to STDOUT by the script.

To check if the Python property worked, enter the **pip freeze | grep package-name** command to view the currently installed python packages. Search for the package *package-name* in which you are interested.

To check if the Cisco IOS XE commands were successful in the IOS Configuration property, enter the **show running-configuration** command. The following is a sample output for this command:

```
Router#show version
Cisco IOS XE Software, Version
Copyright (c) 1986-2020 by Cisco Systems, Inc.
```

```
Cisco IOS-XE software, Copyright (c) 2005-2020 by cisco Systems, Inc.
All rights reserved. Certain components of Cisco IOS-XE software are
licensed under the GNU General Public License ("GPL") Version 2.0. The
software code licensed under GPL Version 2.0 is free software that comes
with ABSOLUTELY NO WARRANTY. You can redistribute and/or modify such
GPL code under the terms of GPL Version 2.0. For more details, see the
documentation or "License Notice" file accompanying the IOS-XE software,
or the applicable URL provided on the flyer accompanying the IOS-XE
software.
```

```
ROM: IOS-XE ROMMON
```

```
Router uptime is 1 minute
Uptime for this control processor is 7 minutes
System returned to ROM by reload
System image file is "bootflash:packages.conf"
Last reload reason: Unknown reason
```

```
This product contains cryptographic features and is subject to United
States and local country laws governing import, export, transfer and
use. Delivery of Cisco cryptographic products does not imply
```



third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at: <http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to [export@cisco.com](mailto:export@cisco.com).

License Level: ipbase  
License Type: N/A(Smart License Enabled)  
Next reload license Level: ipbase

The current throughput level is 250000 kbps

Smart Licensing Status: Registration Not Applicable/Not Applicable

cisco C8000V (VXE) processor (revision VXE) with 2271486K/3075K bytes of memory.  
Processor board ID 9MUG8CATY8R  
Router operating mode: Controller-Managed  
1 Gigabit Ethernet interface  
32768K bytes of non-volatile configuration memory.  
8106756K bytes of physical memory.  
11530240K bytes of virtual hard disk at bootflash:.

Configuration register is 0x2102

```
[guestshell@guestshell ~]$ pip3 freeze | grep gpg==1.10.0
gpg==1.10.0
[guestshell@guestshell ~]$
```

```
Router#show running-config
Building configuration...
```

```
Current configuration : 6982 bytes
!
! Last configuration change at 14:34:36 UTC Fri Nov 6 2020 by NETCONF
!
version 17.3
service timestamps debug datetime msec
service timestamps log datetime msec
service password-encryption
! Call-home is enabled by Smart-Licensing.
service call-home
platform qfp utilization monitor load 80
platform punt-keepalive disable-kernel-core
platform console serial
!
hostname Router
!
boot-start-marker
boot-end-marker
!
vrf definition 65528
!
 address-family ipv4
 exit-address-family
!
no logging buffered
no logging rate-limit
!
```

```

aaa new-model
!
aaa authentication login default local
aaa authentication enable default enable
aaa authorization console
aaa authorization exec default local
!
aaa session-id common
fhrp version vrrp v3
!
no ip dhcp use class
!
no ip igmp ssm-map query dns
login on-success log
ipv6 unicast-routing
!
subscriber templating
!
multilink bundle-name authenticated
!
crypto pki trustpoint TP-self-signed-2465303444
 enrollment selfsigned
 subject-name cn=IOS-Self-Signed-Certificate-2465303444
 revocation-check none
 rsakeypair TP-self-signed-2465303444
!
crypto pki trustpoint SLA-TrustPoint
 enrollment pkcs12
 revocation-check crl
!
!
crypto pki certificate chain TP-self-signed-2465303444
certificate self-signed 01
 30820330 30820218 A0030201 02020101 300D0609 2A864886 F70D0101 05050030
 31312F30 2D060355 04031326 494F532D 53656C66 2D536967 6E65642D 43657274
 69666963 6174652D 32343635 33303334 3434301E 170D3230 31313036 31343333
 35345A17 0D333031 31303631 34333335 345A3031 312F302D 06035504 03132649
 4F532D53 656C662D 5369676E 65642D43 65727469 66696361 74652D32 34363533
 30333434 34308201 22300D06 092A8648 86F70D01 01010500 0382010F 00308201
 0A028201 0100B02F AD33A0FF 0C50D3F2 D06CFDC6 F3CB73BB 4070D649 E07D16CE
 E6271C90 34E86882 822C8D71 E4BAC29D 85285258 51E748E1 8C9FB2C5 12242A22
 7FB71551 02CB4DBC 64089D2F 8DBB6C4A D3E2F112 8E16E71F FE70D102 F59862A3
 E920E77E 52E62E02 1979F800 3D13601F 27C42F81 483BFB34 697F1C20 3952626A
 CA1F5805 26D50A39 33F264D6 1AD485A0 8EB45882 FC97DCA2 106C8FAD 8CDBC0E6
 FF609188 B4677AB0 FBBE77F2 359EA002 E1A5D37D EA895FF3 92732A2B 63465DFD
 4A2A277C 17E7F720 2007A6B6 A7C7296F D0CD2707 8C7C9690 F86B0642 1BA9F28C
 F729157B 8C472E40 78A4E6BE 70471018 4B62EE36 48193FCA 062DB09F 38BC420B
 687E5866 DFA10203 010001A3 53305130 0F060355 1D130101 FF040530 030101FF
 301F0603 551D2304 18301680 14ABBD00 3D02C6E1 7706FA96 29B037A8 583E7B2E
 69301D06 03551D0E 04160414 ABBD003D 02C6E177 06FA9629 B037A858 3E7B2E69
 300D0609 2A864886 F70D0101 05050003 82010100 40C60BF0 2184CF86 08CACB66
 73E74D63 E87A6661 DC839037 D0DB08D0 33C4993C EC326432 E3573D1B EC3B42AF
 F410BF72 2AAB6D8F 1406B352 FE6B5365 CCA7E094 96980FC7 A4B77A02 49CB8C01
 3EC87F01 58BFEE33 0DA222DB 0A1BA130 0AC01F1F FDBF2085 D41EFA45 7A4C7F5E
 2D004D04 D11433BF 69337D90 117A86ED 2CF57A49 AD7DA227 129E53DF 55E12E03
 4D8E0097 A29DC365 11E8B386 891C310E F19EDF6D D9B3EA1E E26ABDBD EF82D8E9
 B0484E26 C0FC1D71 91B19B70 221E1A1A 090F8EA1 3A5FC4FD A4EF36CD EFD2F1F4
 6056C87D 8A76ED1A 68FB76F5 956C6B50 7EFA9D8C 90EA910F 187EBD13 0BF76E5A
 0B9CE20E AA5927C4 7AD13C28 58C6E920 76E36475
 quit
crypto pki certificate chain SLA-TrustPoint
certificate ca 01
 30820321 30820209 A0030201 02020101 300D0609 2A864886 F70D0101 0B050030
 32310E30 0C060355 040A1305 43697363 6F312030 1E060355 04031317 43697363

```

```

6F204C69 63656E73 696E6720 526F6F74 20434130 1E170D31 33303533 30313934
3834375A 170D3338 30353330 31393438 34375A30 32310E30 0C060355 040A1305
43697363 6F312030 1E060355 04031317 43697363 6F204C69 63656E73 696E6720
526F6F74 20434130 82012230 0D06092A 864886F7 0D010101 05000382 010F0030
82010A02 82010100 A6BCBD96 131E05F7 145EA72C 2CD686E6 17222EA1 F1EFF64D
CBB4C798 212AA147 C655D8D7 9471380D 8711441E 1AAF071A 9CAE6388 8A38E520
1C394D78 462EF239 C659F715 B98C0A59 5BBB5CBD 0CFEBEA3 700A8BF7 D8F256EE
4AA4E80D DB6FD1C9 60B1FD18 FFC69C96 6FA68957 A2617DE7 104FDC5F EA2956AC
7390A3EB 2B5436AD C847A2C5 DAB553EB 69A9A535 58E9F3E3 C0BD23CF 58BD7188
68E69491 20F320E7 948E71D7 AE3BCC84 F10684C7 4BC8E00F 539BA42B 42C68BB7
C7479096 B4CB2D62 EA2F505D C7B062A4 6811D95B E8250FC4 5D5D5FB8 8F27D191
C55F0D76 61F9A4CD 3D992327 A8BB03BD 4E6D7069 7CBADF8B DF5F4368 95135E44
DFC7C6CF 04DD7FD1 02030100 01A34230 40300E06 03551D0F 0101FF04 04030201
06300F06 03551D13 0101FF04 05300301 01FF301D 0603551D 0E041604 1449DC85
4B3D31E5 1B3E6A17 606AF333 3D3B4C73 E8300D06 092A8648 86F70D01 010B0500
03820101 00507F24 D3932A66 86025D9F E838AE5C 6D4DF6B0 49631C78 240DA905
604EDCDE FF4FED2B 77FC460E CD636FDB DD44681E 3A5673AB 9093D3B1 6C9E3D8B
D98987BF E40CBD9E 1AECA0C2 2189BB5C 8FA85686 CD98B646 5575B146 8DFC66A8
467A3DF4 4D565700 6ADF0F0D CF835015 3C04FF7C 21E878AC 11BA9CD2 55A9232C
7CA7B7E6 C1AF74F6 152E99B7 B1FCF9BB E973DE7F 5BDDEB86 C71E3B49 1765308B
5FB0DA06 B92AFE7F 494E8A9E 07B85737 F3A58BE1 1A48A229 C37C1E69 39F08678
80DDCD16 D6BACECA EEB7CF9 8428787B 35202CDC 60E4616A B623CDBD 230E3AFB
418616A9 4093E049 4D10AB75 27E86F73 932E35B5 8862FDAE 0275156F 719BB2F0
D697DF7F 28
quit
!
license udi pid C8000V sn 9MUG8CATY8R
diagnostic bootup level minimal
memory free low-watermark processor 69848
!
!
username admin privilege 15 secret 9
14vkLj$yfnFjRidlKJg9.$4obKgKyy4TsoUs0sJ2t3HXpna3XjYWRBnnYKBwVeJrw
!
redundancy
!
interface Loopback65528
 vrf forwarding 65528
 ip address 192.168.1.1 255.255.255.255
!

```

## Verifying the Custom Data Configuration (Google Cloud Platform)

After you run the custom data script, the VM is created and the configuration commands are executed. To verify the same, use the following commands and scripts:

- **show version:** To help determine if the license property worked in Cisco IOS XE CLI on the Cisco Catalyst 8000V instance, enter the **show version** command. For example, the output displays a reference to the security license.
- To see if errors occurred after running commands in the scripts property, look at the `customdata.log` file in the `/bootflash/<cloud>/` directory. The `scriptname.log` file stores any output that is sent to STDOUT by the script.
- To verify whether the Python property worked, enter the `pip freeze | grep <package-name>` command from the Guestshell to view the currently installed Python packages. Here, *package-name* refers to the package that you are specifically searching for.
- To verify the Cisco IOS XE commands in the IOS Configuration property, run the **show running-configuration** command.

## Day 0 Configuration in the Controller Mode

If you want to perform the day 0 configuration for a Cisco Catalyst 8000V in the controller (SD-WAN) mode, you must provide the contents of the `ciscosdwan_cloud_init.cfg` file downloaded from vManage.

If you want to switch to the Controller mode, or if you are looking to bootstrap Cisco Catalyst 8000V with the Cisco SD-WAN functionalities, see [Install and Upgrade for Cisco Catalyst 8000V Controller Mode](#).



**Note** For a Cisco Catalyst 8000V instance running on Cisco CSP-5000 hypervisor, when you enter the settings in the **Day Zero Config** screen, ensure that you maintain the format mentioned here:

- **Source File Name:** Enter the value for this field in the format: `day0_ciscosdwan_cloud_init.cfg`.
- **Destination File Name:** Enter the value for this field in the format: `day0-dest-filename/openstack/content/ciscosdwan_cloud_init.cfg`.



**Note** With the SD-WAN format configurations, if the config cannot apply the config successfully at the first boot, the box might not have a working config at Day0. This is particularly critical in public cloud environments where SSH is necessary to login. Review the configuration carefully if you encounter issues upon provisioning.

## Verifying the Router Operation Mode and Day 0 Configuration

To verify whether you've deployed or upgraded to the IOS XE 17.4 or later releases successfully, run the **show version** command. This command displays the version of your instance, and the **operating device-mode** parameter displays the mode in which your Cisco Catalyst 8000V instance is running.

### Sample configuration output for a Cisco Catalyst 8000V instance in autonomous mode

```
Device# show version | inc operating
Router operating mode: Autonomous
Device# show platform software device-mode
Operating device-mode: Autonomous
Device-mode bootup status:

Device# show platform software chasfs r0 brief | inc device_managed_mode
/tmp/chassis/local/rp/chasfs/etc/device_managed_mode : [autonomous]
/tmp/fp/chasfs/etc/device_managed_mode : [autonomous]
Device# show version | inc Last reload
Last reload reason: Enabling autonomous-mode
```

## Frequently Asked Questions

- Q.** I have been using Cisco IOS XE image until now. Which mode should I now choose?
- A.** If you have been using the Cisco IOS XE universalk9 image so far, deploy the IOS XE 17.4 image and enter the autonomous mode.

- Q.** If I am upgrading to the Cisco Catalyst 8000V 17.4 release, do I need to provide the bootstrap configuration?
- A.** If you are an existing non-SD WAN user and are upgrading to the IOS XE 17.4 release (autonomous mode), you can directly perform the upgrade. You need not perform the Day 0 or custom data configuration again.

For a Cisco Catalyst 8000V instance running on Microsoft Azure or Google Cloud Platform, the device uses the custom data that you provided the first time you configured your Cisco Catalyst 8000V instance.

For Cisco Catalyst 8000V instances running on AWS, the device fetches the custom data from the cloud service provider.

- Q.** What happens to my custom data configuration after switching modes?
- A.** The existing configuration data is deleted. You must perform the bootstrap or custom data configuration just as you do for a fresh installation.
- Q.** What happens to my custom data after a factory reset?
- A.** When you perform a factory reset, the configuration and the files present on the disk are erased. The router boots up like a fresh install and looks for configuration files at the appropriate location. This action determines the mode and the associated configuration.
- Q.** Can I deploy my Cisco Catalyst 8000V instance in any mode with PayG license?
- A.** If you use the PayG licensing model, you cannot deploy the Cisco Catalyst 8000V instance in the controller mode or switch to the controller mode. This mode does not support the PayG licensing model.





## CHAPTER 9

# Mapping the Cisco Catalyst 8000V Network Interfaces to VM Network Interfaces

- [Mapping the Router Network Interfaces to vNICs, on page 79](#)
- [Adding and Deleting Network Interfaces on Cisco Catalyst 8000V, on page 80](#)
- [Removing a vNIC from a Running VM, on page 81](#)
- [Cisco Catalyst 8000V Network Interfaces and VM Cloning, on page 81](#)
- [Mapping the Cisco Catalyst 8000V Network Interfaces with vSwitch Interfaces, on page 82](#)

## Mapping the Router Network Interfaces to vNICs

Cisco Catalyst 8000V maps the GigabitEthernet network interfaces to the logical virtual network interface card (vNIC) name assigned by the VM. The VM in turn maps the logical vNIC name to a physical MAC address.

When you boot the Cisco Catalyst 8000V instance for the first time, the router interfaces are mapped to the logical vNIC interfaces that were added when the VM was created. The following image shows the relationship between the vNICs and the Cisco Catalyst 8000V router interfaces.

After you boot the Cisco Catalyst 8000V instance, you need to display the mapping between the logical interface on the router with the vNIC and the vNIC MAC address using the **show platform software vnic-if interface-mapping** command. The output for this command depends on your Cisco IOS XE release version.



**Note** GigabitEthernet0 interface is no longer supported.

```
Router# show platform software vnic-if interface-mapping
```

Interface Name	Short Name	vNIC Name	Mac Addr
GigabitEthernet2	Gi2	eth2 (vmxnet3)	0050.5689.0034
GigabitEthernet1	Gi1	eth1 (vmxnet3)	0050.5689.000b

The vNIC name shown in the display is a logical interface that the Cisco Catalyst 8000V instance uses to map to the interface on the hypervisor. It does not always map to the corresponding NIC name added during the VM installation. For example, the logical “eth1” vNIC name in the display may not necessarily map to “NIC1” that was added in the VM installation process.

**Caution**

It is important that you verify the interface mapping before you begin configuring the Gigabit Ethernet network interfaces on Cisco Catalyst 8000V. This ensures that the network interface configuration applies to the correct physical MAC address interface on the VM host.

If you reboot the router and do not add or delete any vNICs, the interface mapping remains the same as before. If you reboot the router and delete vNICs, ensure that the configuration for the remaining interfaces remains intact. For more information, see *Adding and Deleting Network Interfaces on Cisco Catalyst 8000V*.

## Adding and Deleting Network Interfaces on Cisco Catalyst 8000V

Cisco Catalyst 8000V maps the router GigabitEthernet interfaces to the logical vNIC name assigned by the VM which in turn is mapped to a MAC address on the VM host. You can add or delete vNICs on the VM to add or delete GigabitEthernet interfaces on Cisco Catalyst 8000V. You can add vNICs while the router is active.

To delete a vNIC from the VM, you must first power down the VM. If you delete any vNICs, you must reboot the router. For more information about adding and deleting vNICs, see the [VMware Documentation](#).

**Note**

Interface hot add/delete is not supported on Cisco Catalyst 8000V that operates in the Controller mode. If you need to perform interface hot add/delete, configure the reset operation in controller mode using the CLI: **request platform software sdwan config reset**.

**Caution**

If you remove a vNIC without first updating the Cisco Catalyst 8000V network interface configuration, you risk a configuration mismatch when the router reboots. When you reboot the router and remove a vNIC, the remaining logical vNIC names could get reassigned to different MAC addresses. As a result, the GigabitEthernet network interfaces on the Cisco Catalyst 8000V instances can be reassigned to different physical interfaces on the hypervisor.

Before you add or delete network interfaces, first verify the interface-to-vNIC mapping using the **show platform software vnic-if interface-mapping** command.

```
Router# show platform software vnic-if interface-mapping
```

Interface Name	Driver Name	Mac Addr
GigabitEthernet3	vmxnet3	000c.2946.3f4d
GigabitEthernet2	vmxnet3	0050.5689.0034
GigabitEthernet1	vmxnet3	0050.5689.000b

After adding or deleting network interfaces on the VM, verify the new interface-to-vNIC mapping before making configuration changes to the network interfaces. The following example shows the interface mapping after a new vNIC has been added. The new vNIC maps to the GigabitEthernet4 network interface on the Cisco Catalyst 8000V instance.

```
Router# show platform software vnic-if interface-mapping
```



Interface Name	Driver Name	Mac Addr
GigabitEthernet4	vmxnet3	0010.0d40.37ff
GigabitEthernet3	vmxnet3	000c.2946.3f4d
GigabitEthernet2	vmxnet3	0050.5689.0034
GigabitEthernet1	vmxnet3	0050.5689.000b

## Removing a vNIC from a Running VM

To remove a vNIC from a running VM, use the `clear platform software` command (described below). Perform this command before removing a vNIC from the hypervisor configuration. This is part of a "two-step hot remove".

To see which hypervisors support a two-step hot remove, look for hypervisors with vNIC Two-Step Hot Remove Support = Yes

**clear platform software vnic-if interface GigabitEthernet***interface-number*

*interface-number* - value from 0–32.

Example:

```
Router# clear platform software vnic-if interface GigabitEthernet4
```

Next, remove the vNIC from the hypervisor configuration.



**Note** You no longer need to execute the `clear platform software vnic-int interface` command before you remove the vNIC configuration from the hypervisor. This command will be deprecated in a future release.

## Cisco Catalyst 8000V Network Interfaces and VM Cloning

When you first install a Cisco Catalyst 8000V instance, a database that maps the vNIC name to the MAC address is created. This database is used to maintain a persistent mapping between the router interfaces and the vNIC-to-MAC address mapping in case you add or delete vNICs. The interfaces are mapped to the stored Universal Unique Identification (UUID) maintained by VMware.

The mapping between the router network interfaces and the vNICs only applies to the current VM that the Cisco Catalyst 8000V is installed on. If the VM is cloned, the stored UUID will not match the current UUID and the interface mapping will not match the router configuration.

To prevent the interface mapping from becoming mis-matched, perform the following steps on the original VM before cloning:



**Note** Ensure that the original VM includes the number of configured vNICs required on the cloned VM before beginning the cloning process.

- 
- Step 1** Enter the **clear platform software vnic-if nvtable** command on the original VM.
- This command clears the persistent interface database on the original VM and updates the interface mapping to the hypervisor.
- Step 2** Reboot the Cisco Catalyst 8000V.
- Step 3** On the cloned VM, verify the interface mapping using the **show platform software vnic-if interface-mapping** command.
- Step 4** Configure the router interfaces on the cloned VM accordingly.
- The router configuration on the cloned VM should match the configuration of the original VM.
- 

## Mapping the Cisco Catalyst 8000V Network Interfaces with vSwitch Interfaces

You can configure the network interfaces in ESXi in different ways to accommodate the Cisco Catalyst 8000V interfaces. You can configure the network interfaces so that each Cisco Catalyst 8000V router interface is mapped to one host Ethernet interface.

Alternatively, you can also configure the network interfaces so that multiple Cisco Catalyst 8000V interfaces share one host ESXi Ethernet interface.

The third possibility is mapping the Cisco Catalyst 8000V interfaces directly to a trunk interface on the vSwitch.



## CHAPTER 10

# Enabling VNF Secure Boot

Secure boot is part of the Unified Extensible Firmware Interface (**UEFI**) standard which ensures that a device boots only using a software that is trusted by the Original Equipment Manufacturer (OEM). The UEFI (Unified Extensible Firmware Interface) specification defines a secure boot methodology that prevents loading software which is not signed with an acceptable digital signature. When the device starts, the firmware checks the signature of the boot software and the operating system. If the signatures are valid, the device boots, and the firmware gives the control to the operating system.

The secure boot feature prevents malicious software applications and unauthorized operating systems from loading into the system during the system startup process. If you enable the secure boot feature, only the authorized software applications boots up from the device. This feature ensures that the software applications that boot up on the device are certified by Cisco. A secure compute system ensures that the intended software on the system runs without malware or tampered software.

To display the system boot mode and the bootloader version, run the **show platform software system boot** command.

```
Router#show platform software system boot
Boot mode: EFI
Bootloader version: 2.0
```

### Restrictions

- The following secure boot environments are supported:
  - ESXi version 6.5 or higher
  - KVM RHEL 7.5 using open stack license
  - NFVIS release 3.11 or later
- Only EFI firmware modes support the secure boot
- GRUB2 and new disk partition layout is available



**Note** Each hypervisor has a unique process to enable secure boot for the guest VMs. To enable secure boot, see the hypervisor specific documentation.

A set of high-level hypervisor specific steps to enable secure boot are mentioned below:

### ESXi Secure Boot Setup

- Create VM using ESXi 6.5 or later version using VM version 13 or greater. To choose the EFI firmware mode, navigate through **VM Options > Boot Options > Firmware > EFI**.
- Power down the VM after the initial boot and the IOS prompt is complete.
- Enable the EFI secure boot in **Edit Settings > VM Options > Boot Options > Secure Boot**.
- Power up the VM and the VNF boots up securely.



#### Important

You cannot modify the firmware mode (from BIOS to EFI or vice versa) after you create the VM.

### KVM Secure Boot Setup

- Create the VM.
- Power down the VM after the VM is created and the VNF IOS prompt is complete.
- Install the PK, KEK, and db certificates from the **EFI Firmware** menu and reset.  
To create the custom keys, see [Custom Keys for Secure boot](#). For db certificates, see [MicCorUEFCA2011\\_2011-06-27.crt](#) and [MicWinProPCA2011\\_2011-10-19.crt](#).
- Secure boot the VM.

### NFVIS Secure Boot Setup

- Upgrade to NFVIS 3.11 release or later.
- Register an Cisco Catalyst 8000V EFI tarball with the NFVIS repository.
- Create a VM using the registered EFI image.
- Secure boot the VM.



## CHAPTER 11

# Configuring Console Access

- [Booting the Cisco Catalyst 8000V as the VM, on page 85](#)
- [Accessing the Cisco Catalyst 8000V Console, on page 86](#)

## Booting the Cisco Catalyst 8000V as the VM

Cisco Catalyst 8000V boots when the VM is powered on. Depending on your configuration, you can monitor the installation process on the virtual VGA console or the console on the virtual serial port.



**Note** If you want to access and configure Cisco Catalyst 8000V from the serial port on the hypervisor instead of the virtual VGA console, you should provision the VM to use this setting before powering on the VM and booting the router.

**Step 1** Power-up the VM. Within 5 seconds of powering on the VM, choose a console described from one of the following two steps (steps 2 or 3) to select a console to view the router bootup and to access the Cisco Catalyst 8000V CLI.

**Step 2** (Optional) Select **Virtual Console**

If you choose to use the virtual console, the rest of the steps in this procedure do not apply. Cisco Catalyst 8000V boots using the Virtual Console if you do not select any other option within the 5 second timeframe. The Cisco Catalyst 8000V instance starts the boot process.

**Step 3** (Optional) Select **Serial Console**

Choose this option to use the virtual serial port console on the VM.

The virtual serial port must already be present on the VM for this option to work.

**Note** The option to select the console port during the boot process is available only the first time Cisco Catalyst 8000V boots. To change the console port access after Cisco Catalyst 8000V has booted for the first time, see [Changing the Console Port Access After Installation, on page 89](#).

The Cisco Catalyst 8000V starts the boot process.

**Step 4** Telnet to the VM using one of the following two commands: **telnet://host-ipaddress:portnumber** or, from a UNIX xTerm terminal: **telnet host-ipaddress portnumber**. The following example shows the Cisco Catalyst 8000V initial boot output on the VM.

The system first calculates the SHA-1, which may take a few minutes. Once the SHA-1 is calculated, the kernel is brought up. Once the initial installation process is complete, the .iso package file is removed from the virtual CD-ROM, and the VM is rebooted. This enables Cisco Catalyst 8000V to boot normally off the virtual Hard Drive.

**Note** The system reboots during first-time installation only.

The time required for the Cisco Catalyst 8000V to boot may vary depending on the release and the hypervisor you use.

### Step 5

After booting, the system presents a screen showing the main software image and the Golden Image, with an instruction that the highlighted entry is booted automatically in three seconds. Do not select the option for the Golden Image and allow the main software image to boot.

**Note** Cisco Catalyst 8000V does not include a ROMMON image that is included in many Cisco hardware-based routers. During installation, a backup copy of the installed version is stored in a backup partition. This copy can be selected to boot from in case you upgraded your boot image, deleted the original boot image, or somehow corrupted your disk. Booting from the backup copy is equivalent to booting a different image from ROMMON. For more information on changing the configuration register settings to access GRUB mode, see [Accessing the GRUB Mode, on page 186](#).

You can now enter the router configuration environment by entering the standard commands **enable** and then **configure terminal**.

When you boot a Cisco Catalyst 8000V instance for the first time, the mode the router boots in depends on the release version.

You must install the software license or enable an evaluation license to obtain the supported throughput and features. Depending on the release version, you must enable the boot level or change the maximum throughput level, and reboot Cisco Catalyst 8000V.

The installed license technology package must match the package level configured with the **license boot level** command. If the license package does not match the setting you have configured, the throughput is limited to 100 Kbps.

(VMware ESXi only) If you manually created the VM using the .iso file, you need to configure the basic router properties. You can either use the Cisco IOS XE CLI commands or you can manually configure the properties in the vSphere GUI.

## Accessing the Cisco Catalyst 8000V Console

### Accessing the Cisco Catalyst 8000V Through the Virtual VGA Console

When installing the Cisco Catalyst 8000V software image, the setting to use is the Virtual VGA console. You do not require any other configuration changes to access the Cisco Catalyst 8000V CLI through the virtual VGA console if:

- You do not change the console setting during the bootup process
- You do not add two virtual serial ports to the VM configuration. This is applicable if you're using automatic console detection.

# Accessing the Cisco Catalyst 8000V Through the Virtual Serial Port

## Introduction to Accessing the Cisco Catalyst 8000V through the Virtual Serial Port

By default, you can access a Cisco Catalyst 8000V instance using the virtual VGA console. If you use the automatic console detection and two virtual serial ports are detected, the Cisco Catalyst 8000V CLI will be available on the first virtual serial port.

You can also configure the VM to use the Serial Console, which always attempts to use the first virtual serial port for the Cisco Catalyst 8000V CLI. See the following sections to configure the virtual serial port on your hypervisor.



**Note** Citrix XenServer does not support access through a serial console.

## Creating Serial Console Access in VMware ESXi

Perform the following steps using VMware VSphere. For more information, refer to the VMware VSphere documentation.

- 
- Step 1** Power-down the VM.
- Step 2** Select the VM and configure the virtual serial port settings.
- a) Choose **Edit Settings > Add**.
  - b) Choose **Device Type > Serial port**. Click **Next**.
  - c) Choose **Select Port Type**.  
Select **Connect via Network**, and click **Next**.
- Step 3** Select **Select Network Backing > Server (VM listens for connection)**.
- Enter the **Port URI** using the following syntax:
- telnet://:portnumber**
- where *portnumber* is the port number for the virtual serial port.
- Under the I/O mode, select the **Yield CPU on poll** option, and click **Next**.
- Step 4** Power on the VM.
- Step 5** When the VM is powered on, access the virtual serial port console.
- Step 6** Configure the security settings for the virtual serial port.
- a) Select the ESXi host for the virtual serial port.
  - b) Click the **Configuration** tab and click **Security Profile**.
  - c) In the Firewall section, click **Properties**, and then select the **VM serial port connected over Network** value.
- You can now access the Cisco IOS XE console using the Telnet port URI. When you configure the virtual serial port, the Cisco Catalyst 8000V is no longer accessible from the VM's virtual console.

**Note** To use these settings, either the **Auto Console** option or the **Serial Console** option in the GRUB menu should be selected during the Cisco Catalyst 8000V bootup. If you have already installed the Cisco Catalyst 8000V software using the virtual VGA console, you must configure either the Cisco IOS XE **platform console auto** command or the Cisco IOS XE **platform console serial command** and reload the VM for the console access through the virtual serial port to work.

## Creating the Serial Console Access in KVM

Perform the following steps using the KVM console on your server. For more information, refer to the KVM documentation.

- Step 1** Power off the VM.
- Step 2** Click on the default **Serial 1** device (if it exists) and then click **Remove**. This removes the default pty-based virtual serial port which would otherwise count as the first virtual serial port.
- Step 3** Click **Add Hardware**.
- Step 4** Select **Serial** to add a serial device.
- Step 5** Under **Character Device**, choose the **TCP Net Console (tcp)** device type from the drop-down menu.
- Step 6** Under **Device Parameters**, choose the mode from the drop-down menu.
- Step 7** Under **Host**, enter 0.0.0.0. The server will accept a telnet connection on any interface.
- Step 8** Choose the port from the drop-down menu.
- Step 9** Choose the **Use Telnet** option.
- Step 10** Click **Finish**.

You can now access the Cisco IOS XE console using the Telnet port URI. For more information, see [Opening a Telnet Session to the Cisco Catalyst 8000V Console on the Virtual Serial Port, on page 88](#).

**Note** To use these settings, either the **Auto Console** option or the **Serial Console** option in the GRUB menu should be selected while the Cisco Catalyst 8000V booted. If you have already installed the Cisco Catalyst 8000V software using the virtual VGA console, you must configure either the Cisco IOS XE **platform console auto** command or the **platform console serial** command and reload the VM in order for the console access through the virtual serial port to work.

## Opening a Telnet Session to the Cisco Catalyst 8000V Console on the Virtual Serial Port

Perform the following steps using the Cisco IOS XE CLI commands:

- Step 1** Telnet to the VM.
  - Use the following command **telnet://host-ipaddress:portnumber**
  - Or, from a UNIX terminal use the command  
**telnet host-ipaddress portnumber**



- Step 2** At the Cisco Catalyst 8000V IOS XE password prompt, enter your credentials. The following example shows an entry of the password *mypass*:

**Example:**

```
User Access Verification
Password: mypass
```

**Note** If no password has been configured, press **Return**.

- Step 3** From the user EXEC mode, enter the **enable** command as shown in the following example:

**Example:**

```
Router> enable
```

- Step 4** At the password prompt, enter your system password. The following example shows entry of the password *enablepass*:

**Example:**

```
Password: enablepass
```

- Step 5** When the enable password is accepted, the system displays the privileged EXEC mode prompt:

**Example:**

```
Router#
```

- Step 6** You now have access to the CLI in the privileged EXEC mode and you can enter the necessary commands to complete your desired tasks.

- Step 7** To exit the Telnet session, use the **exit** or **logout** command as shown in the following example:

**Example:**

```
Router# logout
```

---

## Changing the Console Port Access After Installation

After the Cisco Catalyst 8000V instance has booted successfully, you can change the console port access to the router using Cisco IOS XE commands. After you change the console port access, you must reload or power-cycle the router.

- 
- Step 1** **enable**

**Example:**

```
Router> enable
```

Enables the privileged EXEC mode. Enter your password, if prompted.

- Step 2** **configure terminal**

**Example:**

```
Router# configure terminal
```

Enters the global configuration mode.

**Step 3** Do one of the following:

- **platform console virtual**
- **platform console serial**

**Example:**

```
Router(config)# platform console virtual
```

**Example:**

```
Router(config)# platform console serial
```

Options for **platform console x**:

- **virtual** - Specifies that the Cisco Catalyst 8000V is accessed through the hypervisor virtual VGA console.
- **serial** - Specifies that the Cisco Catalyst 8000V is accessed through the serial port on the VM.

**Note:** Use this option only if your hypervisor supports serial port console access.

**Step 4** **end**

**Example:**

```
Router(config)# end
```

Exits the configuration mode.

**Step 5** **copy system:running-config nvram:startup-config**

**Example:**

```
Router# copy system:running-config nvram:startup-config
```

Copies the running configuration to the NVRAM startup configuration.

**Step 6** **reload**

**Example:**

```
Router# reload
```

Reloads the operating system.

---

### What to do next

After you configure the console access, install the Cisco Catalyst 8000V licenses. To know how to install and use the licenses, see the *Licensing* chapter in this guide.



## CHAPTER 12

# Licenses and Licensing Models

This chapter provides information about the licenses that are available on Cisco Catalyst 8000 Edge Platforms Family, supported throughput options, and how to configure the available licenses and throughput. It also outlines the licensing models available on Cisco Catalyst 8000 Edge Platforms Family.



**Note** The information in this chapter applies predominantly to a device operating in the autonomous mode. References to the controller mode are included in certain sections for the sake of comparison and completeness. Where the information applies to controller mode, this has been called-out categorically.

For a more detailed overview on Cisco Licensing, go to <https://cisco.com/go/licensingguide>.

This chapter includes the following major sections:

- [Feature Information for Available Licenses and Licensing Models](#), on page 91
- [Available Licenses](#) , on page 93
- [Throughput](#) , on page 98
- [How to Configure Available Licenses and Throughput](#) , on page 112
- [Available Licensing Models](#), on page 127

## Feature Information for Available Licenses and Licensing Models

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.

Table 10: Feature Information for Available Licenses and Licensing Models

Feature Name	Releases	Feature Information
Aggregate Throughput Throttling - Virtual Platforms	Cisco IOS XE Cupertino 17.9.1a	<p>On virtual platforms of the Cisco Catalyst 8000 Edge Platforms Family, <i>for all throughput levels</i>, when you configure a bidirectional throughput value on the device, aggregate throughput throttling is effective.</p> <p>This enhancement does not change the throttling behaviour that has always been applicable to virtual platforms: any throttling applies only to data that is transmitted (Tx). Data that is received (Rx) is unthrottled.</p> <p>See <a href="#">Throughput</a> , on page 98, <a href="#">Throughput as a Numeric Value</a> , on page 100, and <a href="#">Throughput as a Tier</a>, on page 106.</p>
Aggregate Throughput Throttling - Physical Platforms	Cisco IOS XE Cupertino 17.8.1a	<p>On the <i>physical</i> platforms of Cisco Catalyst 8000 Edge Platforms Family, for throughput levels greater than 250 Mbps and Tier 2 and higher tiers, when you configure the bidirectional throughput value on the device, aggregate throughput throttling is effective. This means that traffic is throttled in an aggregate manner irrespective of the distribution of the traffic in the upstream and downstream direction.</p> <p>The bidirectional throughput is represented in the license PID (For example, DNA-C-<b>500M</b>-E-3Y and DNA-C-<b>T2</b>-E-3Y). The aggregate throughput is double the bidirectional throughput.</p> <p>See <a href="#">Throughput as a Numeric Value</a> , on page 100 and <a href="#">Throughput as a Tier</a>, on page 106.</p>
Tier-Based Licenses	Cisco IOS XE Cupertino 17.7.1a	<p>Support for tier-based throughput configuration was introduced in addition to existing bandwidth-based (numeric) throughput configuration.</p> <p>Starting with the lowest throughput level, the available tiers are Tier 0 (T0), Tier 1 (T1), Tier 2 (T2), and Tier3 (T3). Each tier represents a throughput level.</p> <p>If the license PID for a product is tier-based, the license is displayed with the tier value in the CSSM Web UI.</p> <p>For a product with a tier-based license, you can <i>configure</i> a tier-based throughput value, and you can also <i>convert</i> to a tier-based throughput value.</p>

Feature Name	Releases	Feature Information
Cisco Digital Network Architecture (DNA) licenses	Cisco IOS XE Amsterdam 17.3.2	Support for Cisco DNA licenses was introduced on Cisco Catalyst 8000 Edge Platforms Family.  Cisco DNA Licenses are categorised into network-stack licenses and a DNA-stack add-on licenses.
High Security License (HSECK9)	Cisco IOS XE Amsterdam 17.3.2	Support for the HSECK9 license was introduced on Cisco Catalyst 8000 Edge Platforms Family.
Cisco Unified Border Element license (Cisco UBE license)  Cisco Unified Communications Manager Express license (Cisco Unified CME license)  Cisco Unified Survivable Remote Site Telephony license (Cisco Unified SRST license)	Cisco IOS XE Amsterdam 17.3.2	Support for Cisco UBE, Cisco Unified CME, Cisco Unified SRST licenses was introduced on Cisco Catalyst 8000 Edge Platforms Family

## Available Licenses

This section lists all the licenses that are available on Cisco Catalyst 8000 Edge Platforms Family, usage guidelines, and ordering considerations.

### Cisco DNA License

A Cisco Digital Network Architecture (DNA) software license combines several feature-specific licenses.



**Note** A Cisco DNA license includes all feature licenses except the following: High Security (HSECK9), Cisco Unified Border Element (Cisco UBE), Cisco Unified Communications Manager Express (Cisco Unified CME), and Cisco Unified Survivable Remote Site Telephony (Cisco Unified SRST). See [Ordering Considerations for a Cisco DNA License, on page 95](#).

Cisco DNA licenses are categorized into network-stack licenses and DNA-stack add-on licenses.

**Cisco DNA Licenses Available on Catalyst 8000V Edge Software, Catalyst 8200, and 8300 Series Edge Platforms:**

Network-stack licenses:

- Network Essentials
- Network Advantage: includes features available with Network Essentials, and more.

- Network Premier: includes features available Network Essentials, Network Advantage, and more.

DNA-stack add-on licenses:

- Cisco DNA Essentials: add-on license available only with Network Essentials.
- Cisco DNA Advantage: add-on license available only with Network Advantage. Includes features available with DNA Essentials and more.
- Cisco DNA Premier: add-on license available only with Network Premier. Includes features available with DNA Essentials, DNA Advantage and more.

#### **Cisco DNA Licenses Available on Catalyst 8500 Series Edge Platforms:**

Network-stack licenses:

- Network Advantage
- Network Premier: includes features available Network Advantage, and more.

DNA-stack add-on licenses:

- Cisco DNA Advantage
- Cisco DNA Premier: add-on license available only with Network Premier. Includes features available with DNA Advantage and more.

## **Guidelines for Using a Cisco DNA License**

- Guidelines that apply to all platforms in the Cisco Catalyst 8000 Edge Platforms Family:
  - A network-stack license is a perpetual or permanent license and has no expiration date.
  - A DNA-stack add-on license is a subscription or term license and is valid only until a certain date. A 3-year and 5-year option is available for all DNA-stack add-on licenses. A 7-year subscription option is available for certain DNA-stack add-on licenses.
  - If you order a Cisco DNA license when purchasing new hardware, the license is not preconfigured on the device. You must configure the boot level license and then the throughput, on the device.
  - If you configure tier-based throughput, which is supported from Cisco IOS XE Cupertino 17.7.1a, Tier 3 (T3) is not supported with the Network Essentials and DNA Essentials licenses.

This means, to configure T3 (throughput greater than or equal to 2.5 G), you must configure Network Advantage/ DNA Advantage, or Network Premier/DNA Premier as the boot level license.

This also means that if you have configured T3 as the throughput, you cannot change the boot level license to Network Essentials and DNA Essentials.

- Guidelines that apply only to Catalyst 8000V Edge Software:

On Catalyst 8000V Edge Software, when you configure a network-stack license, you must also configure the corresponding DNA-stack add-on license.
- Guidelines that apply only to Catalyst 8200, 8300, 8500 Series Edge Platforms:

- The DNA-stack add-on license that is available with each network-stack license is optional. You can configure a network-stack license without a DNA-stack add-on license, but you cannot configure DNA-stack add-on license without the corresponding network-stack license.
- If you use a DNA-stack add-on license, renew the license before term expiry to continue using it, or deactivate the DNA-stack add-on license and then reload the device to continue operating with the network-stack license capabilities.

## Ordering Considerations for a Cisco DNA License

A Cisco DNA license subsumes all performance, boost, and technology package licenses (securityk9, uck9, and appxk9). This means that when you order a Cisco DNA network-stack license, or a Cisco DNA-stack add-on license, if a performance, boost, and technology package license is required or applicable, it is automatically added to the order.

The license Product ID (PID) you purchase can only be a DNA-stack add-on license PID.

The license PID also indicates the throughput you are entitled to. The throughput may be represented by a numeric value or a tier. For example:

- DNA-C-**10M**-E-3Y, is a license PID where the throughput is represented by a numeric value. The **10M** means that you are entitled to 10 Mbps bidirectional throughput.

For more information about a numeric throughput value and related concepts, see sections [Throughput](#) , on page 98 and [Throughput as a Numeric Value](#) , on page 100.

- DNA-C-**T0**-E-3Y, is a license PID where the throughput is represented by a tier value. The **T0** means that you are entitled to up to 15 Mbps bidirectional throughput.

For more information about a tier-based throughput value and related concepts, see sections [Throughput](#) , on page 98 and [Throughput as a Tier](#), on page 106.

If the throughput you order is greater than 250 Mbps, or Tier 2 or a higher tier, an HSECK9 license is *required*. See [High Security License](#) , on page 95.



---

**Note**

When you purchase a license PID with a tier-based throughput value of *T1*, an HSECK9 license is automatically provided. However, the maximum throughput on the device is still throttled to 250 Mbps *in each direction*.

---

## High Security License

The High Security license (HSECK9 license) is an export-controlled license. An export-controlled license is restricted by U.S. export control laws.

This license is required for the use of full cryptographic functionality, that is, throughput greater than 250 Mbps (Tier 2 and higher tiers), and tunnel count over and above a certain number (the number varies depending on the platform).



---

**Note**

The term "throughput" refers to encrypted throughput on physical platforms. On virtual platforms, it refers to encrypted *and* unencrypted throughput - combined.

---

Without an HSECK9 license, the supported tunnel count and the supported throughput for the various models of the Cisco Catalyst 8000 Edge Platforms Family is as follows:

PID	No. Of Tunnels <i>Without</i> HSECK9 License	Supported Throughput <i>Without</i> HSECK9 License
C8500-12X	N/A	N/A
C8500-12X4QC	N/A	N/A
C8500L-8G4X	N/A	N/A
C8300-2N2S-4T2X	1000	T0, T1
C8300-2N2S-6T	1000	T0, T1
C8300-1N1S-4T2X	1000	T0, T1
C8300-1N1S-6T	1000	T0, T1
C8200-1B-4T	1000	T0, T1
C8200L-1N-4T	1000	T0, T1
C8000V	150	T0, T1



**Note** By using an HSECK9 license the tunnel count restriction is lifted and you can configure throughput greater than 250 Mbps. For detailed information about the available throughput options, see [Throughput and System Hardware Throttling Specifications in the Autonomous Mode, on page 101](#) and [Numeric and Tier Mapping](#).

To know if an HSECK9 license is being used on a device, enter the **show license summary** command in privileged EXEC mode. On all devices in the Cisco Catalyst 8000 Edge Platforms Family, the HSECK9 license is displayed as: Router US Export Lic. for DNA (DNA\_HSEC). For example:

```
Device# show license summary
```

```
Account Information:
```

```
Smart Account: Eg-SA As of Dec 03 15:26:02 2021 UTC
```

```
Virtual Account: Eg-VA
```

```
License Usage:
```

License	Entitlement Tag	Count	Status
network-advantage_T2	(NWSTACK_T2_A)	1	IN USE
dna-advantage_T2	(DSTACK_T2_A)	1	IN USE
Router US Export Lic...	(DNA_HSEC)	1	IN USE

## Guidelines for Using an HSECK9 License

The HSECK9 license is tied to the chassis. Therefore, one HSECK9 license is required for each chassis UDI where you want to use cryptographic functionality.

An HSECK9 license requires authorization before use. This authorisation is provided by a Smart Licensing Authorization Code (SLAC), which you must install on the device. You must install a SLAC for each HSECK9 license you use. A SLAC is generated in and obtained from CSSM. How you obtain SLAC from CSSM



depends on the topology you have implemented. For more information, see [Installing SLAC for an HSECK9 License, on page 115](#).

Once SLAC is installed, enter the **show license authorization** command in privileged exec mode, to confirm. If SLAC is installed, the status field displays: SMART AUTHORIZATION INSTALLED on <timestamp>. For example:

```
Device# show license authorization
Overall status:
 Active: PID:C8300-1N1S-4T2X, SN:FDO2250A0J5
 Status: SMART AUTHORIZATION INSTALLED on Dec 03 08:24:35 2021 UTC
 Last Confirmation code: 418b11b3

Authorizations:
 Router US Export Lic. for DNA (DNA_HSEC):
 Description: U.S. Export Restriction Compliance license for DNA based Routers
 Total available count: 1
 Enforcement type: EXPORT RESTRICTED
 Term information:
 Active: PID:C8300-1N1S-4T2X, SN:FDO2250A0J5
 Authorization type: SMART AUTHORIZATION INSTALLED
 License type: PERPETUAL
 Term Count: 1

Purchased Licenses:
 No Purchase Information Available
```

## Ordering Considerations for an HSECK9 License

If you order your DNA licenses in the same configuration as Catalyst 8000 hardware platforms, the option to order an HSECK9 license is available or is selected, if applicable. For example, in case of Catalyst 8500 Series Edge Platforms, when you order hardware, an HSECK9 license is automatically added to the order, because throughput support *starts* at greater than 250 Mbps on these platforms. Further, the requisite SLAC for the HSECK9 license is also factory-installed on the device.

If you order your DNA licenses in a configuration that is separate from your Catalyst 8000 hardware platforms, you must order the HSECK9 license in the configuration for the Catalyst 8000 hardware platforms, if required.

If you plan to use an HSECK9 license with new hardware that you are ordering, provide your Smart Account and Virtual Account information *with* the hardware order. This enables Cisco to factory-install SLAC for the HSECK9 license on the hardware. You must still configure throughput on the device before you start using it.




---

**Note** If the HSECK9 license is ordered separately (not with the hardware order), SLAC cannot be factory-installed.

---

## Cisco CUBE License

A Cisco Unified Border Element License (Cisco UBE license) does not require any boot level configuration before you enable it. After purchase, you can refer to the configuration guide to configure the available Cisco UBE features.

For information about the features available with a Cisco UBE license, see the *Cisco Unified Border Element Configuration Guide* for the required release at: <https://www.cisco.com/c/en/us/support/unified-communications/unified-border-element/products-installation-and-configuration-guides-list.html>.

For information about supported platforms and about purchasing a Cisco UBE license, see the datasheet at: <https://www.cisco.com/c/en/us/products/collateral/unified-communications/unified-border-element/data-sheet-c78-729692.html>. You must order a Cisco UBE license separately if required. It is not automatically included with any other license.

For information about how to report usage of a Cisco UBE license, see [Smart Licensing Using Policy for Cisco Enterprise Routing Platforms](#). In the context of this licensing model, a Cisco UBE license is an *unenforced* license.

## Cisco Unified CME License

A Cisco Unified Communications Manager Express License (Cisco Unified CME license) does not require any boot level configuration before you enable it. After purchase, you can refer to the configuration guide to configure the available Cisco UBE features.

For information about the features available with a Cisco Unified CME license, see the [Cisco Unified Communications Manager Express System Administrator Guide](#).

For information about supported platforms and about purchasing a Cisco Unified CME license, see the datasheet at:

<https://www.cisco.com/c/en/us/products/collateral/unified-communications/unified-communications-manager-express/datasheet-c78-744069.html>.

You must order a Cisco Unified CME license separately if required. It is not automatically included with any other license.

For information about how to report usage of a Cisco Unified CME license, see [Smart Licensing Using Policy for Cisco Enterprise Routing Platforms](#). In the context of this licensing model, a Cisco UBE license is an *unenforced* license.

## Cisco Unified SRST License

A Cisco Unified Survivable Remote Site Telephony License (Cisco Unified SRST license) does not require any boot level configuration before you enable it. After purchase, you can refer to the configuration guide to configure the available Unified SRST features.

For information about the features available with a Cisco Unified SRST license, see the [Cisco Unified SCCP and SIP SRST System Administrator Guide \(All Versions\)](#).

For information about supported platforms and about purchasing a Cisco Unified SRST license, see the datasheet at:

<https://www.cisco.com/c/en/us/products/collateral/unified-communications/unified-communications-manager-express/datasheet-c78-744069.html>.

You must order a Cisco Unified SRST license separately if required. It is not automatically included with any other license.

For information about how to report usage of a Unified SRST license, see [Smart Licensing Using Policy for Cisco Enterprise Routing Platforms](#). In the context of this licensing model, a Unified SRST license is an *unenforced* license.

## Throughput

The *throughput* tells you how much data is allowed to be transferred on the device. You can configure this value in the autonomous mode. Data is then transmitted (Tx) and received (Rx) at the configured rate.

If you don't explicitly configure a throughput, default throughput is effective.

### Encrypted and Unencrypted Throughput

Encrypted throughput, also known as crypto throughput, is throughput that is protected by a cryptographic algorithm.

Unencrypted throughput on the other hand, is in plain text. Unencrypted throughput is also referred to as Cisco Express Forwarding (CEF) traffic.



#### Important

In case of physical platforms (Catalyst 8200, 8300, and 8500 Series Edge Platforms), all references to “throughput” in this document refer only to cryptographic throughput.

In case of virtual platforms (Catalyst 8000V Edge Software), all references to “throughput” in this document refer to both, encrypted and unencrypted throughput.

### Throttled and Unthrottled Throughput

Throttled throughput refers to the enforcement of a restriction on the throughput.

Unthrottled throughput means no limit is enforced, and the device throughput is at the maximum capability of the device.

Whether throughput will be throttled or not, is determined by the throughput value you configure, and if the system’s hardware is designed to impose a throttling limit for that configured throughput level. For more information about this, see [Throughput and System Hardware Throttling Specifications in the Autonomous Mode, on page 101](#) in this document.

Depending on whether the device is a physical or a virtual one, throttling is also applied differently. On virtual platforms, if throughput is throttled, throttling applies only to Tx data and not Rx data. On physical platforms, if throughput is throttled, throttling applies to Tx and Rx data.



#### Note

On physical platforms (Catalyst 8200, 8300, and 8500 Series Edge Platforms), unencrypted throughput (Tx and Rx), is unthrottled by default.

### Where to Find Throughput Information for a Device

The throughput you are entitled to, is a value that is represented in the License product ID (PID) when you order a Cisco DNA license. It can be a numeric throughput value, such as DNA-C-**10M**-E-3Y, or a tier-based throughput value, such as DNA-C-**T0**-E-3Y.

To display current throughput configuration on the device:

- For physical platforms enter the **show platform hardware throughput crypto** privileged EXEC command.
- For virtual platforms enter the **show platform hardware throughput level** privileged EXEC command.

Depending on whether your license PID has a numeric throughput value, or tier-based throughput value, refer to the corresponding section below for further details.

## Throughput as a Numeric Value

This refers to a numeric value (10M, 15M, 250M, 1G, and so on) that is configured as throughput.

The numeric throughput value you are entitled to is in the license PID and it is bi-directional. It is the maximum throughput that is allowed *in each direction* (Tx and Rx). The aggregate throughput is the *sum* of the throughput in both directions and therefore double the bi-directional throughput.

For example, if the license PID is DNA-C-**10M**-E-3Y, 10 Mbps is the bi-directional throughput, and the throughput value you configure on the device. It means that a maximum of 10 Mbps can be transmitted and 10 Mbps can be received. The aggregate throughput available is 20 Mbps.

Starting with Cisco IOS XE Cupertino 17.8.1a, throttling behaviour has changed as follows: *Only on physical platforms, and for throughput levels greater than 250 Mbps*, when you configure a throughput value on the device, aggregate throughput throttling is effective. This means that traffic is throttled in an aggregate manner irrespective of the distribution of Tx and Rx traffic.

Starting with Cisco IOS XE Cupertino 17.9.1a, throttling behaviour has changed as follows: *On virtual platforms, for all throughput levels*, when you configure a bidirectional throughput value on the device, aggregate throughput throttling is effective. This enhancement does not change the throttling behaviour that has always been applicable to virtual platforms: any throttling applies only to Tx data. Rx data is always unthrottled.




---

**Note** If the aggregate for the throughput level you configure on a virtual platform is greater than 250 Mbps, aggregate throttling is not effective unless an HSECK9 license is available on the device (that is, SLAC is installed).

---

### • Example: Throttling when throughput is greater than 250 Mbps

Let us suppose that you order license PID DNA-C-**500M**-A-3Y. This means that 500 Mbps is the bi-directional throughput and 1Gbps is the aggregate throughput. The release-wise configuration and behaviour is as follows:

- Until Cisco IOS XE Cupertino 17.7.x, on physical and virtual platforms: If you configure a throughput of 500 Mbps on the device, the maximum Tx throughput available is 500 Mbps and the maximum Rx throughput is 500 Mbps. (Except on virtual platforms, where Rx is not throttled.)
- From Cisco IOS XE Cupertino 17.8.1a:
  - On physical platforms, if you configure a throughput of 500 Mbps on the device, a maximum of 1 Gbps Tx and 0 Mbps Rx, or, 100 Mbps Tx and 900 Mbps Rx or any other ratio within the aggregate 1 Gbps throughput limit, is supported.
  - On virtual platforms, if you configure a throughput of 500 Mbps on the device, a maximum of 500 Mbps Tx throughput is supported. Rx is not throttled.
- From Cisco IOS XE Cupertino 17.9.1a:
  - On physical platforms, throughput throttling behaviour described above (starting with 17.8.1a) continues to apply.
  - On virtual platforms, if you configure a throughput of 500 Mbps on the device, a maximum of 1 Gbps Tx throughput is supported. Rx continues to remain unthrottled.

### • Example: Throttling when throughput is equal to or lesser than 250 Mbps

Let us suppose that you order license PID DNA-C-250M-A-3Y. This means that 250 Mbps is the bi-directional throughput, and 500 Mbps is the aggregate throughput. The release-wise configuration and behaviour is as follows:

- Until Cisco IOS XE Cupertino 17.8.x, on physical and virtual platforms: If you configure a throughput of 250 Mbps on the device, the maximum Tx throughput supported is 250 Mbps and the maximum Rx throughput is 250 Mbps - it is not aggregated. (Except on virtual platforms where Rx is not throttled.)



**Note** On C8200-1N-4T-L, if you configure a numeric value of 250 Mbps, a maximum of 250 Mbps is available in each direction. But if you configure a tier-based value (T2), 500 Mbps is available for use in any Tx and Rx ratio.

- From Cisco IOS XE Cupertino 17.9.1a, *only on virtual platforms*, if you configure a throughput of 250 Mbps on the device, the aggregate amounts to 500 Mbps, which requires an HSECK9 license. If you have installed SLAC for the HSECK9 license, then the maximum Tx throughput available is 500 Mbps. Rx throughput continues to remain unthrottled. By contrast, if you configure a throughput of 100 Mbps on a virtual device, then the maximum Tx throughput available is 200 Mbps. Rx throughput remains unthrottled.

The recommended way to arrive at the required throughput for your network is to first calculate the aggregate throughput (Tx and Rx) and divide that by 2 to arrive at the bidirectional throughput value. Finally, select the license PID that is equal to or greater than the bidirectional throughput (tier-based or numeric).

The tables below provide throughput specifications for all devices in the Cisco Catalyst 8000 Edge Platforms Family:



**Note** Separate tables are provided for throughput specifications in the autonomous mode and SD-WAN controller mode.

## Throughput and System Hardware Throttling Specifications in the Autonomous Mode

- Supported throughputs: All the throughput values you can configure on the device. These are the only throughput values you can configure on the specified device. The column heading also mentions the default throughput for a PID.
- Hardware throttled throughput: The throttling limit imposed by the system's hardware, for a supported throughput level. This column in the tables below tell you if hardware is throttled for each supported throughput level and what that hardware throttled level is. Where the value is listed as unthrottled, it means that throughput is not throttled even if you configure a limit.
- Require HSECK9?: Indicates if a supported throughput level requires an HSECK9 license (anything lesser than or equal to 250 Mbps does not require HSECK9).
- Supported Release & Throughput Throttling Behavior: This column provides a few different details. The applicable release for the specified throttling behaviour, if what is finally available is bi-directional or aggregate, and if the throughput being referred to is encrypted or unencrypted. Note that throughput always refers to encrypted throughput for physical platforms; for for virtual platforms it is both, encrypted and unencrypted.

<b>C8300-1N1S-4T2X</b>						
Supported Throughputs (default 10M)	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
10M, 15M, 25M, 50M, 100M, 250M	250M	No	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Bi-directional, encrypted
500M	500M	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
1G	1G	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
2.5G	unthrottled	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted

<b>C8300-2N2S-6T</b>						
Supported Throughputs (default 10M)	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
10M, 15M, 25M, 50M, 100M, 250M	250M	No	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Bi-directional; encrypted
500M	500M	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
1G	1G	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted

<b>C8300-1N1S-6T</b>						
Supported Throughputs (default 10M)	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
10M, 15M, 25M, 50M, 100M, 250M	250M	No	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Bi-directional; encrypted
500M	500M	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
1G	1G	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted

<b>C8300-2N2S-4T2X</b>						
Supported Throughputs (default 10M)	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
10M, 15M, 25M, 50M, 100M, 250M	250M	No	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Bi-directional; encrypted
500M	500M	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
1G	1G	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
2.5G	unthrottled	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted

<b>C8200-1N-4T</b>						
Supported Throughputs (default 10M)	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
10M, 15M, 25M, 50M, 100M, 250M	250M	No	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Bi-directional; encrypted
500M	500M	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted

<b>C8200-1N-4T-L</b>						
Supported Throughputs (default 10M)	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
10M, 15M, 25M, 50M, 100M, 250M	250M	No	>= 17.5.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
<b>Note</b> On C8200-1N-4T-L, if you configure a numeric value of 250 Mbps, a maximum of 250 Mbps is available in each direction. But if you configure tier-based value T2 (which requires an HSECK9 license), 500 Mbps is available for use in any Tx and Rx ratio.						

<b>C8500-12X40C</b>						
Supported Throughputs (default 2.5G)	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
2.5G	2.5G	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted

<b>C8500-12X40C</b>						
5G	5G	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
10G	unthrottled	Yes	>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted

<b>C8500-12X</b>						
Supported Throughputs (default 2.5G)	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
2.5G	2.5G		>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
5G	5G		>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
10G	unthrottled		>= 17.4.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted

<b>C8500L-8S4X</b>						
Supported Throughputs (default 1G)	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
1G	1G	Yes	>= 17.5.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
2.5G	2.5G	Yes	>= 17.5.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
5G	5G	Yes	>= 17.5.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted
10G	unthrottled	Yes	>= 17.5.1	Bi-directional; encrypted	>=17.8.1a	Aggregate, encrypted

<b>C8500-20X6C</b>						
Supported Throughputs (default T4)	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
T4	50G	Yes	-	-	>=17.8.1a	Aggregate, encrypted
T5	unthrottled	Yes	-	-	>=17.8.1a	Aggregate, encrypted



C8000v						
Supported Throughputs (default )	Hardware Throttled Throughput	Require HSECK9?	Supported Release & Throughput Throttling Behavior		Supported Release & Throughput Throttling Behavior	
10M	10M	No	>= 17.4.1	Bi-directional; encrypted and unencrypted throughput	>=17.9.1a	Aggregate; encrypted and unencrypted throughput
25M	25M	No				
50M	50M	No				
100M	100M	No				
250M	250M	No				
500M	500M	Yes				
1G	1G	Yes				
2.5G	2.5G	Yes				
5G	5G	Yes				
10G	10G	Yes				
<b>Note</b> This is a virtual platform; Rx is always unthrottled.						

## Throughput and System Hardware Throttling Specifications in the SD-WAN Controller Mode

PID	Throughput Without HSECK9	Throughput With HSECK9 (>=17.4.1 and <17.8.1a; Bi-directional)	Throughput With HSECK9 (>17.8.1a; Aggregate)
C8300-1N1S-4T2X (default 250M)	250M	unthrottled	unthrottled
C8300-2N2S-6T (default 250M)	250M	1G	2G
C8300-1N1S-6T (default 250M)	250M	1G	2G
C8300-2N2S-4T2X (default 250M)	250M	unthrottled	unthrottled
C8200-1N-4T (default 250M)	250M	500M	1G
C8200-1N-4T-L (default 250M)	250M	250M	500M

PID	Throughput Without HSECK9	Throughput With HSECK9 ( $\geq 17.4.1$ and $< 17.8.1a$ ; Bi-directional)	Throughput With HSECK9 ( $> 17.8.1a$ ; Aggregate)
C8500-12X4QC (default unthrottled)	unthrottled	unthrottled	unthrottled
C8500-12X (default unthrottled)	unthrottled	unthrottled	unthrottled
C8500L-8S4X (default unthrottled)	unthrottled	unthrottled	unthrottled
C8500-20X6C (default T4)	unthrottled	-	unthrottled
C8000v (default 250M)	250M	unthrottled	unthrottled

## Throughput as a Tier

Tier-based throughput configuration is supported starting with Cisco IOS XE Cupertino 17.7.1a.

A tier represents a throughput level. Starting with the lowest throughput level, the available tiers are Tier 0 (T0), Tier 1 (T1), Tier 2 (T2), and Tier 3 (T3). T2 and higher tiers require an HSECK9 license.

The tier-based throughput value you are entitled to is in the license PID and it is bi-directional. It is the maximum throughput that is allowed *in each direction* (Tx and Rx). The aggregate throughput is the *sum* of the throughput in both directions and therefore double the bi-directional throughput.

For example, if the license PID is DNA-C-**T0**-A-3Y, T0 is the bi-directional throughput, and the throughput value you configure on the device. When you configure this value, T0 Tx and T0 Rx, is supported. See [table Tier and Numeric Throughput Mapping, on page 107](#) for information about how numeric throughput values are mapped to tiers and the DNA licenses that are available with each tier.

Note the following:

- All tiers are not available with all Cisco DNA licenses. For example, T3 is not available with the Network Essentials and DNA-Essentials licenses. This also means that if you have T3 as the configured throughput, you cannot change the boot level license to Network Essentials and DNA Essentials. The [Tier and Numeric Throughput Mapping, on page 107](#) table clarifies this.
- Different platforms support different maximum throughput levels, therefore each tier means a different value for different platforms. For example, T2 means 1G throughput for C8300-2N2S-4T2, 500M for C8200-1N-4T, and 250M for C8200-1N-4T-L. The [Tier and Numeric Throughput Mapping, on page 107](#) table clarifies this.

Starting with Cisco IOS XE Cupertino 17.8.1a, throttling behaviour has changed as follows: *Only on physical platforms*, and when you configure T2 or higher tiers, aggregate throughput throttling is effective. This means that traffic is throttled in an aggregate manner irrespective of the distribution of Tx and Rx traffic.

Starting with Cisco IOS XE Cupertino 17.9.1a, throttling behaviour has changed as follows: *On virtual platforms*, when you configure a tier (*any tier*), aggregate throughput throttling is effective. This enhancement does not change the throttling behaviour that has always been applicable to virtual platforms: any throttling applies only to Tx data. Rx data is always unthrottled.

• **Example: Throttling when throughput is T2 or a higher tier**

Let us suppose that you order license PID DNA-C-**T2**-A-3Y. With T2, the bi-directional throughput can be upto 1 Gbps and the aggregate throughput can be upto 2 Gbps. The release-wise configuration and behaviour is as follows:

- Until Cisco IOS XE Cupertino 17.7.x, on physical and virtual platforms: You configure T2 on the device, and depending on the device, a maximum of up to 1 Gbps Tx and up to 1 Gbps Rx throughput is supported. Except on virtual platforms where Rx is not throttled.
- From Cisco IOS XE Cupertino 17.8.1a:  
On physical platforms if you configure T2, depending on the device, up to 2 Gbps of aggregate throughput is available for use in any Tx and Rx ratio.



**Note** On C8200-1N-4T-L, if you configure T2, 500 Mbps is available for use in any upstream and downstream ratio. But if you configure a numeric value of 250M, a maximum of 250 Mbps is available in each direction.

On virtual platforms if you configure T2, a maximum of 1 Gbps Tx is supported. Rx is not throttled.

- From Cisco IOS XE Cupertino 17.9.1a:  
On physical platforms, the throughput throttling behaviour described above (starting with 17.8.1a) continues to apply.  
On virtual platforms, if you configure T2, up to 2 Gbps of aggregate throughput is supported. Accordingly, Tx is throttled at the aggregate level and Rx continues to remain unthrottled.

• **Example: Throttling when throughput is T0 or T1**

Let us suppose that you order license PID DNA-C-**T1**-A-3Y. With T1, 100 Mbps is the bi-directional throughput, 200 Mbps is the aggregate throughput. The release-wise configuration and behaviour is as follows:

- Until Cisco IOS XE Cupertino 17.8.x, on physical and virtual platforms: if you configure a throughput of T1 on the device. A maximum of 100 Mbps Tx and 100 Mbps Rx throughput is available. (Except on virtual platforms where Rx is not throttled).
- From Cisco IOS XE Cupertino 17.9.1a, only on virtual platforms, if you configure a throughput of T1 on the device, Tx is throttled to a maximum of 200 Mbps. Rx continues to remain unthrottled.

### Tier and Numeric Throughput Mapping

The following tables provide information about how numeric throughput values are mapped to tiers and the DNA licenses that are available with each tier.



**Note** When you purchase a license PID with a tier-based throughput value of *T1*, an HSECK9 license is automatically provided. However, the maximum throughput on the device is still throttled to 250 Mbps *in each direction*.

- [Table 11: Tier and Numeric Throughput Mapping for Virtual Platforms \(C8000v\), Cisco IOS XE Cupertino 17.9.1a and Later Releases](#)
- [Table 12: Tier and Numeric Throughput Mapping for Physical Platforms, Cisco IOS XE Cupertino 17.8.1a and Later Releases](#)
- [Table 13: Tier and Numeric Throughput Mapping for Physical and Virtual Platforms, Cisco IOS XE Cupertino 17.7.x and Earlier Releases](#)

**Y**: Network Premium and DNA Premium

**Y**: Network Advantage and DNA Advantage

**Y**: Network Essentials and DNA Essentials

**Table 11: Tier and Numeric Throughput Mapping for Virtual Platforms (C8000v), Cisco IOS XE Cupertino 17.9.1a and Later Releases**

Tier (Agg. Value):	T0 (Tx 50M)		T1 ( Tx 200M)		T2* (Tx 2 Gbps)			T3* (Tx 20 Gbps)			
					*HSECK9 License Required.						
Configured Numeric Value:	15M	25M	50M	100M	250M	500M	1G	2.5G	5G	10G	
Available DNA Licenses:	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div></div>	<div><div></div><div></div></div>	

**Table 12: Tier and Numeric Throughput Mapping for Physical Platforms, Cisco IOS XE Cupertino 17.8.1a and Later Releases**

Tier (Agg.):	T0 (50M Agg)			T1 (200M Bi-directional)		T2* (2G Agg.)			T3* (20G Agg. or unthrottled)			T4* (50G Agg.)	T5* (Unthrottled)	
						*HSECK9 License Required								
Configured Numeric Value:	10M	15M	25M	50M	100M	250M	500M	1G	2.5G	5G	10G	-	-	
C8300-1N1S-6T	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>					
C8300-2N2S-6T	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>	<div><div></div><div></div><div></div></div>					

C8300-1N1S-4T2X	YYY	YYY	YYY	YYY	YYY	YYY	YYY	YYY	YY				
C8300-2N2S-4T2X	YYY	YYY	YYY	YYY	YYY	YYY	YYY	YYY	YY				
C8200-1N-4T	YYY	YYY	YYY	YYY	YYY	YYY	YYY						
C8200-1N-4T-L	YYY	YYY	YYY	YYY	YYY	YYY							
C8500-12X									YY	YY	YY		
C8500-12X4QC									YY	YY	YY		
C8500L-8S4X								YY	YY	YY	YY		
C8500-20X6C												YY	YY

Table 13: Tier and Numeric Throughput Mapping for Physical and Virtual Platforms, Cisco IOS XE Cupertino 17.7.x and Earlier Releases

Tier:	T0		T1			T2*			T3*			
						*HSECK9 License Required						
Configured Numeric Value:	10M	15M	25M	50M	100M	250M	500M	1G	2.5G	5G	10G	
C8300-1N1S-6T	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>			
C8300-2N2S-6T	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>			
C8300-1N1S-4T2X	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>		
C8300-2N2S-4T2X	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>		
C8200-1N-4T	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>				
C8200-1N-4T-L	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>						
C8500-12X									<div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>	
C8500-12X4QC									<div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>	
C8500L-8S4X								<div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>	
C8000v	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>	<div><div>Y</div><div>Y</div></div>	

## Numeric vs. Tier-Based Throughput Configuration

With the introduction of tier-based throughput configuration in Cisco IOS XE Cupertino 17.7.1a, when you configure throughput on the device, both numeric and tier-based options are available. This section provides information about when to configure a numeric throughput value and when to configure tier-based throughput.

Cisco Smart Software Manager (CSSM) is a portal that enables you to manage all your Cisco software licenses. All the license PIDs you purchase are listed in the CSSM Web UI at: <https://software.cisco.com> → Manage

licenses. Log in to the portal and in the corresponding Smart Account and Virtual Account, navigate to **Inventory > Licences**, to display the numeric and tier-based licenses in the account. Figure [Figure 1: Numeric and Tier Values Displayed in the CSSM Web UI, on page 111](#) shows you how to distinguish between the two.

- If you purchase a numeric license PID, the license is displayed with the numeric throughput value *and* tier-based value in the CSSM Web UI. For such a license, we recommend that you configure only a numeric throughput value.

See [Configuring a Numeric Throughput, on page 116](#).

- If you purchase a tier-based license PID, the license is displayed with only the tier value in the CSSM Web UI. For such a license, you can either configure a tier-based throughput value to match the display in the CSSM Web UI, or you can configure a numeric throughput value.

See [Configuring a Tier-Based Throughput, on page 119](#) or [Configuring a Numeric Throughput, on page 116](#).



---

**Note**

There is no functional impact if you have tier-based license PID in CSSM and you configure a numeric throughput value on the device.

---

Figure 1: Numeric and Tier Values Displayed in the CSSM Web UI

+	Routing DNA Advantage: Tier 2	→ Tier-Based	Prepaid
+	Routing DNA Advantage: Tier 2: 1G	→ Numeric	Prepaid
+	Routing DNA Advantage: Tier 2: 250M		Prepaid
+	Routing DNA Advantage: Tier 2: 500M		Prepaid
+	Routing DNA Advantage: Tier 3		Prepaid
+	Routing DNA Advantage: Tier 3: 5G		Prepaid
+	Routing DNA Advantage: Tier 4		Prepaid
+	Routing DNA Essentials: Tier 1: 100M		Prepaid
+	Routing DNA Essentials: Tier 2		Prepaid
+	Routing DNA Essentials: Tier 2: 1G		Prepaid
+	Routing DNA Essentials: Tier 2: 250M		Prepaid
+	Routing DNA Essentials: Tier 2: 500M		Prepaid
+	Routing DNA Essentials: Tier 3		Prepaid
+	Routing DNA Premier: Tier 1: 100M		Prepaid
+	Routing DNA Premier: Tier 2: 1G		Prepaid

The following scenarios further clarify when you can *convert* from numeric to tier-based throughput configuration, or from tier-based throughput configuration to numeric, when conversion is required, and when it is optional:

- You have configured a numeric throughput value on the device and the license PID is a numeric license: *You must not* convert to tier-based throughput value.

- You have configured a numeric throughput value on the device and the license PID is a tier-based license: You can convert the throughput configuration to tier-based value - but this is optional. There is no functional impact if you do not convert to a tier-based throughput value.

If you want to convert to a tier-based value, see [Converting From a Numeric Throughput Value to a Tier, on page 123](#)

- You are upgrading to a release where tier-based throughput values are supported and the license PID is tier-based: You can convert the throughput to tier-based value after upgrade - but this is optional. There is no functional impact if you do not convert to a tier-based throughput value.

See [Upgrading from a Release Supporting Numeric Throughput to a Release Supporting Tiers, on page 126](#).

- You are upgrading to a release where tier-based throughput values are supported, and your license PID is numeric: *You must not* convert to a tier-based throughput value.
- You are downgrading to a release where only numeric throughput values are supported and your license PID and throughput configuration are tier-based: *You must* change configuration to a numeric throughput value, *before you downgrade*.

See [Downgrading from a Release Supporting Tiers to a Release Supporting Only Numeric Throughput, on page 127](#).

## How to Configure Available Licenses and Throughput

This section provides information about the tasks you must complete, for the licenses available on the Cisco Catalyst 8000 Edge Platforms Family - before you can start using them.

For a Cisco DNA license: **Configure a Boot Level License → Configure Numeric or Tier-Based Throughput → Implement a Smart Licensing Using Policy Topology → Report License Usage (If Applicable)**.

For an HSECK9 license: **Configure a Boot Level License → Implement a Smart Licensing Using Policy Topology → Install SLAC<sup>1</sup> → Enable HSECK9 on applicable platforms<sup>2</sup> → Configure Numeric or Tier-Based Throughput → Report License Usage (If Applicable)**.

For a Cisco UBE, or Cisco Unified CME, or Cisco Unified SRST license: **Implement a Smart Licensing Using Policy Topology → Report License Usage (If Applicable)**.

## Configuring a Boot Level License

If you have purchased a Cisco DNA license for a new device, or if you have an existing device and you want to change (upgrade or downgrade, add or remove) the currently configured license on your device, complete the following task.

This sets a boot level license and requires a reload before the configured changes are effective.

<sup>1</sup> If a SLAC has been factory-installed by Cisco manufactory (in case of new hardware), skip this step

<sup>2</sup> Enter the **license feature hseck9** command in global configuration mode for Catalyst 8200, and 8300 Series Edge Platforms only.



## SUMMARY STEPS

1. **show version**
2. **configure terminal**
3. Depending on whether the device is a physical or virtual one, configure the applicable command:
  - For physical platforms: **[no] license boot level {network-advantage [addon dna-advantage] | network-essentials [addon dna-essentials] | network-premier [addon dna-premier] }**
  - For virtual platforms: **[no] license boot level {network-advantage {addon dna-advantage} | network-essentials {addon dna-essentials} | network-premier {addon dna-premier} }**
4. **exit**
5. **copy running-config startup-config**
6. **reload**
7. **show version**
8. **show license summary**
9. Complete usage reporting - if required

## DETAILED STEPS

	Command or Action	Purpose									
<b>Step 1</b>	<b>show version</b> <b>Example:</b> Device# <b>show version</b> <output truncated> Technology Package License Information:  <table border="1"> <thead> <tr> <th>Technology</th><th>Type</th><th>Technology-package</th></tr> </thead> <tbody> <tr> <td>Technology-package</td><td></td><td>Current Next</td></tr> <tr> <td>Reboot</td><td></td><td></td></tr> </tbody> </table> Smart License Perpetual network-advantage network-advantage Smart License Subscription dna-advantage dna-advantage  <output truncated>	Technology	Type	Technology-package	Technology-package		Current Next	Reboot			Displays the currently set boot level license.  In the accompanying example, Network Advantage and DNA Advantage licences are configured on the device.
Technology	Type	Technology-package									
Technology-package		Current Next									
Reboot											
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.									
<b>Step 3</b>	Depending on whether the device is a physical or virtual one, configure the applicable command: <ul style="list-style-type: none"> <li>• For physical platforms: <b>[no] license boot level {network-advantage [addon dna-advantage]   network-essentials [addon dna-essentials]   network-premier [addon dna-premier] }</b></li> <li>• For virtual platforms: <b>[no] license boot level {network-advantage {addon dna-advantage}  </b></li> </ul>	Sets a boot level license.  On all platforms, first configure a network-stack license. Only after this can you configure the corresponding add-on license.  In the command syntax note how the configuration of a DNA-stack add-on license is optional on physical platforms, but mandatory on virtual platforms.									

	Command or Action	Purpose									
	<b>network-essentials {addon dna-essentials}   network-premier {addon dna-premier} }</b>  <b>Example:</b> <pre>Device(config)# license boot level network-premier addon dna-premier % use 'write' command to make license boot config take effect on next boot</pre>	The accompanying example, shows configuration on a C8300-1N1S-4T2X router, which is a physical platform. The network-stack license, Network Premier and the corresponding add-on license, DNA-Premier are configured.									
<b>Step 4</b>	<b>exit</b>  <b>Example:</b> <pre>Device# exit</pre>	Exits global configuration mode and returns to privileged EXEC mode.									
<b>Step 5</b>	<b>copy running-config startup-config</b>  <b>Example:</b> <pre>Device# copy running-config startup-config Destination filename [startup-config]? Building configuration... [OK] &lt;output truncated&gt;</pre>	Saves your entries in the configuration file.									
<b>Step 6</b>	<b>reload</b>  <b>Example:</b> <pre>Device# reload Proceed with reload? [confirm]  *Dec  8 01:04:12.287: %SYS-5-RELOAD: Reload requested by console. Reload Reason: Reload Command. &lt;output truncated&gt;</pre>	Reloads the device. License levels configured in Step 3 are effective and displayed only after this reload.									
<b>Step 7</b>	<b>show version</b>  <b>Example:</b> <pre>Device# show version &lt;output truncated&gt; Technology Package License Information:</pre> <table border="1"> <thead> <tr> <th>Technology</th><th>Type</th><th>Technology-package</th></tr> </thead> <tbody> <tr> <td>Technology-package</td><td></td><td>Current</td></tr> <tr> <td>Reboot</td><td></td><td>Next</td></tr> </tbody> </table> <pre>Smart License Perpetual network-premier network-premier Smart License Subscription dna-premier dna-premier &lt;output truncated&gt;</pre>	Technology	Type	Technology-package	Technology-package		Current	Reboot		Next	Displays the currently set boot level license.  In the accompanying example, the output confirms that Network Premier and DNA-Premier licenses are configured.
Technology	Type	Technology-package									
Technology-package		Current									
Reboot		Next									
<b>Step 8</b>	<b>show license summary</b>  <b>Example:</b> <pre>Device# show license summary  Account Information:</pre>	Displays a summary of license usage, which includes information about licenses being used, the count, and status.									

	Command or Action	Purpose
	<pre>Smart Account: Eg-SA As of Dec 08 08:10:33 2021 UTC Virtual Account: Eg-VA  License Usage:   License                               Entitlement Tag     Count Status  network-premier_T2      (NWSTACK_T2_P)     1 IN USE dna-premier_T2          (DSTACK_T2_P)     1 IN USE</pre>	
<b>Step 9</b>	Complete usage reporting - if required	<p>After you configure a license level, you may have to send a RUM report (Resource Utilization Measurement Report) to CSSM to report license usage information. To know if reporting is required, you can wait for a system message or refer to the policy using show commands.</p> <ul style="list-style-type: none"> <li>The system message, which indicates that reporting is required: %SMART_LIC-6-REPORTING_REQUIRED: A Usage report acknowledgement will be required in [dec] days. [dec] is the amount of time (in days) left to meet reporting requirements.</li> <li>If using <b>show</b> commands, refer to the output of the <b>show license status</b> privileged EXEC command and check the <code>Next ACK deadline</code> field. This means a RUM report must be sent and the acknowledgement (ACK) from CSSM must be installed by this date.</li> </ul> <p><i>How you send the RUM report, depends on the topology you have implemented in the Smart Licensing Using Policy environment. For more information, see <a href="#">How to Configure Smart Licensing Using Policy: Workflows by Topology</a>.</i></p>

## Installing SLAC for an HSECK9 License

A Smart Licensing Authorization Code (SLAC) is generated in and obtained from Cisco Smart Software Manager (CSSM) portal.

There are multiple ways in which a product may be connected to the CSSM, in order to obtain a SLAC. Each way of connecting to CSSM is called a topology. You must implement one of the supported topologies so you can then install SLAC in the corresponding method.

For information about all the methods, see the [Supported Topologies](#) section of the [Smart Licensing Using Policy for Cisco Enterprise Routing Platforms](#) document.



**Note** Ensure that a boot level license is already configured on the device. See [Configuring a Boot Level License, on page 112](#). In the output of the show version privileged EXEC command ensure that a license is mentioned in the `License Level` field.

### Required Tasks After Installing SLAC

Complete the following required tasks after installing SLAC - only if applicable to the platform:

Platform	Required Tasks After Installing SLAC
For Catalyst 8200 and 8300 Series Edge Platforms	Enter the <b>license feature hseck9</b> command in global configuration mode. This <i>enables</i> the HSECK9 license on these platforms.
For the C8500L models of the Catalyst 8500 Series Edge Platforms	Reload the device after installing SLAC.

## Configuring a Numeric Throughput

This task shows you how to change the numeric throughput level on physical and virtual platforms. If you do not configure a throughput level, the platform's default throughput level is effective.

Configuration of a throughput level requires a reload on physical platforms (Catalyst 8200, 8300, and 8500 Series Edge Platforms). A reload is not required for virtual platforms (Catalyst 8000V Edge Software).

### Before you begin

- Read the [Throughput as a Numeric Value , on page 100](#) and [Numeric vs. Tier-Based Throughput Configuration, on page 109](#) sections.
- Ensure that a boot level license is already configured on the device. See [Configuring a Boot Level License, on page 112](#). In the output of the show version privileged EXEC command ensure that a license is mentioned in the `License Level` field.
- If you are configuring throughput greater than 250 Mbps, ensure that you have already installed a Smart Licensing Authorization Code (SLAC) according to the method that applies to your topology in the Smart Licensing Using Policy environment. See [Installing SLAC for an HSECK9 License, on page 115](#).
- Note the throughput you are entitled to. This is indicated in the Cisco DNA license PID you purchase.

### SUMMARY STEPS

1. Depending on whether the device is a physical or virtual one, enter the applicable command:
  - For physical platforms: **show platform hardware throughput crypto**
  - For virtual platforms: **show platform hardware throughput level**
2. **configure terminal**
3. Depending on whether the device is a physical or virtual one, configure the applicable command:

- For physical platforms: **platform hardware throughput crypto** {100M | 10M | 15M | 1G | 2.5G | 250M | 25M | 500M | 50M}
- For virtual platforms: **platform hardware throughput level MB** {100 | 1000 | 10000 | 15 | 25 | 250 | 2500 | 50 | 500 | 5000}

4. **exit**
5. **copy running-config startup-config**
6. **reload**
7. Depending on whether the device is a physical or virtual one, enter the applicable command:
  - For physical platforms: **show platform hardware throughput crypto**
  - For virtual platforms: **show platform hardware throughput level**

## DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<p>Depending on whether the device is a physical or virtual one, enter the applicable command:</p> <ul style="list-style-type: none"> <li>• For physical platforms: <b>show platform hardware throughput crypto</b></li> <li>• For virtual platforms: <b>show platform hardware throughput level</b></li> </ul> <p><b>Example:</b></p> <pre>Device# show platform hardware throughput crypto</pre> <p>Current configured crypto throughput level: 250M        Level is saved, reboot is not required        Current enforced crypto throughput level: 250M        Crypto Throughput is throttled at 250M        Default Crypto throughput level: 10M        Current boot level is network-advantage</p> <p>OR</p> <pre>Device# show platform hardware throughput level</pre> <p>The current throughput level is 1000000 kb/s</p>	<p>Displays the currently running throughput on the device.</p> <p>In the accompanying examples,</p> <ul style="list-style-type: none"> <li>• The <b>show platform hardware throughput crypto</b> sample output is of a physical platform (a C8300-2N2S-4T2X). Here the throughput level is throttled at 250M.</li> <li>• The <b>show platform hardware throughput level</b> sample output is of a virtual platform (a C8000V).</li> </ul>
<b>Step 2</b>	<p><b>configure terminal</b></p> <p><b>Example:</b></p> <pre>Device# configure terminal</pre>	Enters global configuration mode.
<b>Step 3</b>	<p>Depending on whether the device is a physical or virtual one, configure the applicable command:</p> <ul style="list-style-type: none"> <li>• For physical platforms: <b>platform hardware throughput crypto</b> {100M   10M   15M   1G   2.5G   250M   25M   500M   50M}</li> <li>• For virtual platforms: <b>platform hardware throughput level MB</b> {100   1000   10000   15   25   250   2500   50   500   5000}</li> </ul>	<p>Configures the throughput level. The displayed throughput options depend on the device.</p> <p>The following apply to both physical and virtual platforms:</p> <ul style="list-style-type: none"> <li>• At a minimum, you must have configured a network-stack license already. Otherwise the command is not recognized as a valid one on the command line interface.</li> </ul>

	Command or Action	Purpose
	<p><b>Example:</b></p> <pre>Device(config)# platform hardware throughput crypto ?  100M 100 mbps bidirectional thput  10M 10 mbps bidirectional thput  15M 15 mbps bidirectional thput  1G 2 gbps aggregate thput  2.5G 5 gbps aggregate thput  250M 250 mbps bidirectional thput  25M 25 mbps bidirectional thput  500M 1gbps aggregate thput  50M 50 mbps bidirectional thput</pre> <pre>Device(config)# platform hardware throughput crypto 1G % These values don't take effect until the next reboot. Please save the configuration.</pre> <p>OR</p> <pre>Device(config)# platform hardware throughput level MB 5000 %Throughput has been set to 5000 Mbps.</pre>	<ul style="list-style-type: none"> <li>If you are configuring throughput greater than 250 Mbps, you must have already installed SLAC. Options greater than 250 Mbps are displayed only if SLAC is installed.</li> </ul> <p>In the accompanying examples,</p> <ul style="list-style-type: none"> <li>1 Gbps is configured on the physical platform. Aggregate throughput throttling (Cisco IOS XE Cupertino 17.8.1a and later) is effective. After reboot, irrespective of the distribution of traffic in the upstream and downstream direction, an aggregate throughput limit of 2 Gbps is effective.</li> <li>5000 Mbps is configured on the virtual platform. A maximum of 5000 Mbps upstream and 5000 Mbps downstream throughput is supported.</li> </ul>
<b>Step 4</b>	<p><b>exit</b></p> <p><b>Example:</b></p> <pre>Device# exit</pre>	Exits global configuration mode and returns to privileged EXEC mode.
<b>Step 5</b>	<p><b>copy running-config startup-config</b></p> <p><b>Example:</b></p> <pre>Device# copy running-config startup-config</pre>	Saves your entries in the configuration file.
<b>Step 6</b>	<p><b>reload</b></p> <p><b>Example:</b></p> <pre>Device# reload</pre>	<p>Reloads the device.</p> <p><b>Note</b> Perform this step only if the device you are configuring throughput on is a physical platform (Catalyst 8200, 8300, and 8500 Series Edge Platforms).</p> <p>Skip this step if you are configuring throughput on a virtual platform (Catalyst 8000V Edge Software).</p>
<b>Step 7</b>	Depending on whether the device is a physical or virtual one, enter the applicable command:	Displays the currently running throughput on the device.

	Command or Action	Purpose
	<ul style="list-style-type: none"> <li>For physical platforms: <b>show platform hardware throughput crypto</b></li> <li>For virtual platforms: <b>show platform hardware throughput level</b></li> </ul> <p><b>Example:</b></p> <pre>Device# show platform hardware throughput crypto Current configured crypto throughput level: 1G Level is saved, reboot is not required Current enforced crypto throughput level: 1G Crypto Throughput is throttled at 2G(Aggregate) Default Crypto throughput level: 10M</pre> <p>OR</p> <pre>Device# show platform hardware throughput level The current throughput level is 5000000 kb/s</pre>	<p><b>Note</b> On physical platforms, you can also enter the <b>show platform hardware qfp active feature ipsec state</b> privileged EXEC command to display the configured throughput level.</p>

## Configuring a Tier-Based Throughput

This task shows you how to configure a tier-based throughput level on physical and virtual platforms. If you do not configure a throughput level, the platform's default throughput level is effective.

Tier-based throughput levels are supported starting with Cisco IOS XE Cupertino 17.7.1a only.

Configuration of a throughput level requires a reload on physical platforms (Catalyst 8200, 8300, and 8500 Series Edge Platforms). A reload is not required for virtual platforms (Catalyst 8000V Edge Software).

### Before you begin

- Read the [Throughput as a Tier, on page 106](#) and [Numeric vs. Tier-Based Throughput Configuration, on page 109](#) sections.
- Ensure that a boot level license is already configured on the device. See [Configuring a Boot Level License, on page 112](#). In the output of the **show version** privileged EXEC command, ensure that the license is mentioned.
- If you want to configure Tier 3 (T3) ensure that the boot level license is Network Advantage/ DNA Advantage, or Network Premier/DNA Premier. T3 is not supported with Network Essentials and DNA Essentials.
- If you are configuring Tier 2 (T2) or a higher tier, ensure that you have already installed a Smart Licensing Authorization Code (SLAC) according to the method that applies to your topology in the Smart Licensing Using Policy environment. See [Installing SLAC for an HSECK9 License, on page 115](#).
  - On physical platforms, T2 or higher tiers are not displayed if SLAC is not installed.
  - On virtual platforms, all tier options are displayed even if SLAC is not installed. But SLAC is required if you want to configure T2 or a higher tier.
- Note the throughput you are entitled to. This is indicated in the Cisco DNA license PID you purchase.

## SUMMARY STEPS

1. Depending on whether the device is a physical or virtual one, enter the applicable command:
  - For physical platforms: **show platform hardware throughput crypto**
  - For virtual platforms: **show platform hardware throughput level**
2. **show license authorization**
3. **configure terminal**
4. Depending on whether the device is a physical or virtual one, configure the applicable command:
  - For physical platforms: **platform hardware throughput crypto {T0 | T1 | T2 | T3}**
  - For virtual platforms: **platform hardware throughput level MB {T0 | T1 | T2 | T3 }**
5. **exit**
6. **copy running-config startup-config**
7. **reload**
8. Depending on whether the device is a physical or virtual one, enter the applicable command:
  - For physical platforms: **show platform hardware throughput crypto**
  - For virtual platforms: **show platform hardware throughput level**

## DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<p>Depending on whether the device is a physical or virtual one, enter the applicable command:</p> <ul style="list-style-type: none"> <li>• For physical platforms: <b>show platform hardware throughput crypto</b></li> <li>• For virtual platforms: <b>show platform hardware throughput level</b></li> </ul> <p><b>Example:</b></p> <pre>Device# show platform hardware throughput crypto show platform hardware throughput crypto  Current configured crypto throughput level: 250M Level is saved, reboot is not required Current enforced crypto throughput level: 250M Crypto Throughput is throttled at 250M Default Crypto throughput level: 10M Current boot level is network-premier</pre> <p>OR</p> <pre>Device# show platform hardware throughput level The current throughput level is 10000 kb/s</pre>	<p>Displays the currently running throughput on the device.</p> <p>In the accompanying examples:</p> <ul style="list-style-type: none"> <li>• The <b>show platform hardware throughput crypto</b> sample output is of a physical platform (a C8300-2N2S-4T2X). Here throughput is currently throttled at 250 Mbps.</li> <li>• The <b>show platform hardware throughput level</b> sample output is of a virtual platform (a C8000V). Here the current throughput level is 10 Mbps.</li> </ul>
<b>Step 2</b>	<p><b>show license authorization</b></p> <p><b>Example:</b></p> <pre>Device# show license authorization Overall status: Active: PID:C8300-2N2S-4T2X,SN:FDO2250A0J5 Status: SMART AUTHORIZATION INSTALLED on Mar</pre>	<p>(Optional) Displays SLAC information on the product instance.</p> <p>In the accompanying example:</p> <ul style="list-style-type: none"> <li>• SLAC is installed on the physical platform. This is so we can configure T2 in the subsequent steps.</li> </ul>



	Command or Action	Purpose
	<pre> 02 05:05:19 2022 UTC   Last Confirmation code: 418b11b3  Authorizations:   Router US Export Lic. for DNA (DNA_HSEC):     Description: U.S. Export Restriction Compliance     license for     DNA based Routers     Total available count: 1     Enforcement type: EXPORT RESTRICTED     Term information:       Active: PID:C8300-1N1S-4T2X,SN:FDO2250A0J5       Authorization type: SMART AUTHORIZATION     INSTALLED       License type: PERPETUAL       Term Count: 1  Purchased Licenses:   No Purchase Information Available  OR  Device# show license authorization Overall status:   Active: PID:C8000V,SN:9I8GRCH8CMN   Status: NOT INSTALLED </pre>	<ul style="list-style-type: none"> <li>SLAC is not available on the virtual platform. Note how this affects throughput configuration in the subsequent steps.</li> </ul>
Step 3	<b>configure terminal</b>  <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
Step 4	<p>Depending on whether the device is a physical or virtual one, configure the applicable command:</p> <ul style="list-style-type: none"> <li>For physical platforms: <b>platform hardware throughput crypto {T0   T1   T2   T3}</b></li> <li>For virtual platforms: <b>platform hardware throughput level MB {T0   T1   T2   T3 }</b></li> </ul> <p><b>Example:</b></p> <pre> Device(config)# platform hardware throughput crypto ?  100M  100 mbps bidirectional thput  10M   10 mbps bidirectional thput  15M   15 mbps bidirectional thput  1G    2 gbps aggregate thput  2.5G  5 gbps aggregate thput </pre>	<p>Configures a tier-based throughput. The throughput options that are displayed, depend on the device.</p> <p><b>Note</b> Only tiers are mentioned in command, for the sake of clarity. When you enter the command on the CLI, numeric and tier values are displayed - as shown in the accompanying examples.</p> <p>The following apply to both physical and virtual platforms:</p> <ul style="list-style-type: none"> <li>You have configured a boot level license already. Otherwise the command for throughput configuration is not recognized as a valid one on the command line interface.</li> <li>If you are configuring T2 or a higher tier, you have installed SLAC.</li> </ul>

	Command or Action	Purpose
	<pre> 250M 250 mbps bidirectional thput 25M 25 mbps bidirectional thput 500M 1gbps aggregate thput 50M 50 mbps bidirectional thput T0 T0(up to 15 mbps) bidirectional thput T1 T1(up to 100 mbps) bidirectional thput T2 T2(up to 2 gbps) aggregate thput T3 T3(up to 5 gbps) aggregate thput  Device(config)# platform hardware throughput crypto T2 % These values don't take effect until the next reboot. Please save the configuration. *Mar 02 05:06:19.042: %CRYPTO_SL_TP_LEVELS-6-SAVE_CONFIG_AND_RELOAD: New throughput level not applied until reload; please save config  OR Device(config)# platform hardware throughput level MB ? 100 Mbps 1000 Mbps 10000 Mbps 15 Mbps 25 Mbps 250 Mbps 2500 Mbps 50 Mbps 500 Mbps 5000 Mbps T0 Tier0(up to 15M throughput) T1 Tier1(up to 100M throughput) T2 Tier2(up to 1G throughput) T3 Tier3(up to 10G throughput) T4 Tier4(unthrottled)  Device(config)# platform hardware throughput level MB T2 %Requested throughput will be set once HSEC authorization code is installed </pre>	<p><b>Note</b></p> <p>On a physical platform, you will not be able to configure T2 or a higher tier if SLAC is not installed.</p> <p>On a virtual platform, if you configure T2 or a higher tier without SLAC, the product instance automatically tries to reach CSSM to request and install SLAC. If it is successful, throughput is set to the configured tier. If it is not successful, the system sets the throughput to 250 Mbps. If and when SLAC is installed, the throughput is automatically set to the last configured value.</p> <p>In the accompanying examples:</p> <ul style="list-style-type: none"> <li>On the physical platform (<b>platform hardware throughput crypto</b>), tiers T2 and higher tiers are displayed, because SLAC is installed. If SLAC were not available, T1 would have been the highest tier displayed.</li> <li>Further, aggregate throughput throttling (Cisco IOS XE Cupertino 17.8.1a and later) is effective. After reboot, irrespective of the distribution of traffic in the upstream and downstream direction, an aggregate throughput limit of 2 Gbps is supported.</li> <li>On the virtual platform (<b>platform hardware throughput level MB</b>), all tiers are displayed. After T2 is configured, the system message alerts you to the fact that the configuration is not set, because SLAC is not installed.</li> </ul>
<b>Step 5</b>	<p><b>exit</b></p> <p><b>Example:</b></p> <pre>Device# exit</pre>	Exits global configuration mode and returns to privileged EXEC mode.
<b>Step 6</b>	<p><b>copy running-config startup-config</b></p> <p><b>Example:</b></p>	Saves your entries in the configuration file.

	Command or Action	Purpose
	<pre>Device# copy running-config startup-config Destination filename [startup-config]? Building configuration... [OK]</pre>	
<b>Step 7</b>	<p><b>reload</b></p> <p><b>Example:</b></p> <pre>Device# reload Proceed with reload? [confirm] *Mar 02 05:07:00.979: %SYS-5-RELOAD: Reload requested by console. Reload Reason: Reload Command.</pre>	<p>Reloads the device.</p> <p><b>Note</b> A reload is required only for physical platforms.</p>
<b>Step 8</b>	<p>Depending on whether the device is a physical or virtual one, enter the applicable command:</p> <ul style="list-style-type: none"> <li>For physical platforms: <b>show platform hardware throughput crypto</b></li> <li>For virtual platforms: <b>show platform hardware throughput level</b></li> </ul> <p><b>Example:</b></p> <pre>Device# show platform hardware throughput crypto Current configured crypto throughput level: T2 Level is saved, reboot is not required Current enforced crypto throughput level: 1G Crypto Throughput is throttled at 2G(Aggregate) Default Crypto throughput level: 10M Current boot level is network-premier  OR  Device# show platform hardware throughput level The current throughput level is 250000 kb/s</pre>	<p>Displays the currently running throughput on the device.</p> <p>In the accompanying examples:</p> <ul style="list-style-type: none"> <li>On the physical platform, the tier value is set to T2.</li> </ul> <p><b>Note</b> On physical platforms, you can also enter the <b>show platform hardware qfp active feature ipsec state</b> privileged EXEC command to display the configured throughput level.</p> <ul style="list-style-type: none"> <li>On the virtual platform, throughput is set to 250 Mbps. If and when SLAC is installed, the throughput will be automatically set to the last configured value, which is T2.</li> </ul>

## Converting From a Numeric Throughput Value to a Tier

This task shows you how to convert a numeric throughput value to a tier-based throughput value. To know how numeric throughput values are mapped to tier values refer to the table here: [Tier and Numeric Throughput Mapping](#).

Converting the throughput level requires a reload on physical platforms (Catalyst 8200, 8300, and 8500 Series Edge Platforms). A reload is not required for virtual platforms (Catalyst 8000V Edge Software).

### Before you begin

- Read the [Numeric vs. Tier-Based Throughput Configuration, on page 109](#) section.
- If you are converting numeric throughput that is equal or greater than 250 Mbps, ensure that a SLAC is installed on the device. See [Installing SLAC for an HSECK9 License, on page 115](#).
- The software version running on the product instance is Cisco IOS XE Cupertino 17.7.1a or a later release.

## SUMMARY STEPS

1. Depending on whether the device is a physical or virtual one, enter the applicable command:
  - For physical platforms: **show platform hardware throughput crypto**
  - For virtual platforms: **show platform hardware throughput level**
2. Depending on whether the device is a physical or virtual one, enter the applicable command:
  - For physical platforms: **license throughput crypto auto-convert**
  - For virtual platforms: **license throughput level auto-convert**
3. **copy running-config startup-config**
4. **reload**
5. Depending on whether the device is a physical or virtual one, enter the applicable command:
  - For physical platforms: **show platform hardware throughput crypto**
  - For virtual platforms: **show platform hardware throughput level**
6. Verify that conversion is complete.
  - For physical platforms: **license throughput crypto auto-convert**
  - For virtual platforms: **license throughput level auto-convert**

## DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<p>Depending on whether the device is a physical or virtual one, enter the applicable command:</p> <ul style="list-style-type: none"> <li>• For physical platforms: <b>show platform hardware throughput crypto</b></li> <li>• For virtual platforms: <b>show platform hardware throughput level</b></li> </ul> <p><b>Example:</b></p> <pre>Device# show platform hardware throughput crypto Current configured crypto throughput level: 500M Level is saved, reboot is not required Current enforced crypto throughput level: 500M Crypto Throughput is throttled at 500M Default Crypto throughput level: 10M Current boot level is network-premier</pre> <p>OR</p> <pre>Device# show platform hardware throughput level The current throughput level is 100000 kb/s</pre>	Displays the currently running throughput on the device.
<b>Step 2</b>	<p>Depending on whether the device is a physical or virtual one, enter the applicable command:</p> <ul style="list-style-type: none"> <li>• For physical platforms: <b>license throughput crypto auto-convert</b></li> <li>• For virtual platforms: <b>license throughput level auto-convert</b></li> </ul>	Converts the numeric throughput to a tier-based throughput value. The converted tier value is displayed on the CLI.

	Command or Action	Purpose
	<p><b>Example:</b></p> <pre>Device# license throughput crypto auto-convert Crypto throughput auto-convert from level 500M to T2  % These values don't take effect until the next reboot. Please save the configuration. *Dec 8 03:21:01.401: %CRYPTO_SL_TP_LEVELS-6-SAVE_CONFIG_AND_RELOAD: New throughput level not applied until reload; please save config  OR  Device# license throughput level auto-convert %Throughput tier set to T1 (100 Mbps) % Tier conversion is successful. Please write memory to save the tier config</pre>	
<b>Step 3</b>	<p><b>copy running-config startup-config</b></p> <p><b>Example:</b></p> <pre>Device# copy running-config startup-config Destination filename [startup-config]? Building configuration... [OK]</pre>	<p>Saves your entries in the configuration file.</p> <p><b>Note</b> Even though the command you use to convert from numeric to tier-based throughput is a privileged EXEC command, it changes running configuration from a numeric value to a tier-based value. You must therefore save configuration for the next reload to be displayed with a tier value.</p>
<b>Step 4</b>	<p><b>reload</b></p> <p><b>Example:</b></p> <pre>Device# reload Proceed with reload? [confirm] *Dec 8 03:24:09.534: %SYS-5-RELOAD: Reload requested by console. Reload Reason: Reload Command</pre>	<p>Reloads the device.</p> <p><b>Note</b> A reload is required only on physical platforms.</p>
<b>Step 5</b>	<p>Depending on whether the device is a physical or virtual one, enter the applicable command:</p> <ul style="list-style-type: none"> <li>• For physical platforms: <b>show platform hardware throughput crypto</b></li> <li>• For virtual platforms: <b>show platform hardware throughput level</b></li> </ul> <p><b>Example:</b></p> <pre>Device# show platform hardware throughput crypto Current configured crypto throughput level: T2 Level is saved, reboot is not required Current enforced crypto throughput level: 1G Crypto Throughput is throttled at 1G Default Crypto throughput level: 10M Current boot level is network-premier</pre>	<p>Displays the currently running throughput on the device.</p>

	Command or Action	Purpose
	OR Device# <code>show platform hardware throughput level</code> The current throughput level is 100000 kb/s	
<b>Step 6</b>	Verify that conversion is complete. <ul style="list-style-type: none"> <li>For physical platforms: <b>license throughput crypto auto-convert</b></li> <li>For virtual platforms: <b>license throughput level auto-convert</b></li> </ul> <b>Example:</b> Device# <code>license throughput crypto auto-convert</code> Crypto throughput is already tier based, no need to convert. OR Device# <code>license throughput level auto-convert</code> % Tier conversion not possible since the device is already in tier licensing	<b>Tip</b> To cross-check that conversion is complete, you can also enter the conversion command again. If the numeric throughput value has already been converted, the system displays a message confirming this.

## Upgrading from a Release Supporting Numeric Throughput to a Release Supporting Tiers

If you are upgrading to Cisco IOS XE Cupertino 17.7.1 or later release *and* the license PID is a tier-based one, you can convert throughput configuration to a tier-based value, or you can retain the numeric throughput configuration.



**Note** There is no functional impact if you have tier-based license PID in CSSM and a numeric throughput value is configured on the device.

If you want to convert to a tier-based value note the required action depending on the throughput level that is configured:

Throughput Configuration Before Upgrade	Action Before Upgrade	Action After Upgrade to 17.7.1 or Later
Lesser than 250 Mbps	No action required.	<a href="#">Converting From a Numeric Throughput Value to a Tier, on page 123</a>
Equal to 250 Mbps	Obtain an HSECK9 license and install SLAC if you want to convert to T2.	<a href="#">Converting From a Numeric Throughput Value to a Tier, on page 123</a>
Greater than 250 Mbps	No action required.	<a href="#">Converting From a Numeric Throughput Value to a Tier, on page 123</a>

## Downgrading from a Release Supporting Tiers to a Release Supporting Only Numeric Throughput

If you are downgrading to a release where only numeric throughput configuration is supported, you *must* convert tier-based throughput configuration to a numeric throughput value before downgrade. This is applicable even if the license PID is a tier-based license PID.

**Caution**

If a tier-based throughput value was configured before downgrade and you downgrade without changing to a numeric value, tier configuration is not recognized by a pre-17.7.1 image and configuration fails. Further, throughput may not be restored to the pre-downgrade level and you have to configure a numeric throughput level after downgrade.

Throughput Configuration Before Downgrade	Action Before Downgrade	Action After Downgrade to a pre-17.7.1 Version
Numeric	No action required.	No action required.
Tier	<a href="#">Configuring a Numeric Throughput, on page 116</a>	No action required.

## Available Licensing Models

The licensing model defines *how* you account for or report the licenses that you use, to Cisco. The following licensing models are available on the Cisco Catalyst 8000 Edge Platforms Family:

### Smart Licensing Using Policy

With this licensing model, you purchase the licenses you want to use, configure them on the device, and then report license usage – as required. You do not have to complete any licensing-specific operations, such as registering or generating keys before you start using the software and the licenses that are tied to it - unless you are using export-controlled and enforced licenses.

This licensing model is supported on all products in the Cisco Catalyst 8000 Edge Platforms Family.

For more information, see [Smart Licensing Using Policy for Cisco Enterprise Routing Platforms](#).

### Pay As You Go (PAYG) Licensing

**Note**

This licensing model is available only on Catalyst 8000V Edge Software.

Cisco Catalyst 8000V supports the PAYG licensing model with Amazon Web Services (AWS) and Microsoft Azure Marketplace - in both the autonomous mode and the controller mode. The Cisco Catalyst 8000V hourly-billed Amazon Machine Image (AMI) or the Pay As You Go licensing model allows you to consume an instance for a defined period of time.

- In the autonomous mode, you can directly launch an instance from the AWS or Azure Marketplace and start using it. The licenses are embedded in the image and the selected license package and configured throughput level are effective when you launch the instance
- In the controller mode, which is supported from Cisco IOS-XE Bengaluru 17.5.1, you must first onboard the device into Cisco SD-WAN as per [Onboard Cisco Catalyst 8000V Edge Software Hosted by a Cloud Service, Using PAYG Licensing](#). After this, when you launch the instance from AWS, the device comes-up with the license already installed for unlimited throughput.

### Managed Service Licensing Agreement

Managed Service Licensing Agreement (MSLA) is a consumption-based software licensing model designed for Cisco's Managed Service Provider business.

- **MSLA in Cisco SD-WAN Controller Mode**

In the Cisco SD-WAN controller mode, an MSLA is supported on all products in the Cisco Catalyst 8000 Edge Platforms Family. For more information, see:

[Managed Service Licensing Agreement \(MSLA\) for Cisco SD-WAN At-a-Glance](#)

[Cisco SD-WAN Getting Started Guide](#) → *Manage Licenses for Smart Licensing Using Policy*.

[Cisco vManage How-Tos for Cisco IOS XE SD-WAN Devices](#) → *Manage Licenses for Smart Licensing Using Policy*.

- **MSLA in Autonomous Mode**

In the autonomous mode, an MSLA is available only with Catalyst 8000V Edge Software, starting from Cisco IOS XE Cupertino 17.9.1a.

Here, you begin by entering into an MSLA with Cisco, and purchase licenses with subscription IDs.

Licenses with subscription IDs can be ordered on [Cisco commerce workspace](#) (CCW). Ordered licenses are deposited in the specified Smart Account and Virtual Account in CSSM, with the corresponding subscription IDs.

To complete licensing workflows, you must implement a supported topology. After CSSM receives license usage information, you are billed based on the throughput and the Cisco DNA subscription tier that is activated and in-use. For more information, see: [MSLA](#) and [Utility Mode](#).





## CHAPTER 13

# Verifying the Cisco Catalyst 8000V Hardware and VM Requirements

---

To help troubleshoot issues with Cisco Catalyst 8000V, ensure that the router is installed on the supported hardware and that the VM requirements are being met:

- Verify that the server hardware is supported by the hypervisor vendor.

If you're using VMware, verify that the server is listed on the VMware Hardware Compatibility List. See the VMware documentation for more information.

- Verify that the I/O devices (for example, FC, iSCSI, SAS) being used are supported by the VM vendor.
- Verify that sufficient RAM is allocated on the server for the VMs and the hypervisor host.

If you're using VMware, ensure that the server has enough RAM to support both the VMs and VMware ESXi.

- Verify the hypervisor version is supported by Cisco Catalyst 8000V.
- Verify that the correct VM settings for the amount of memory, number of CPUs, and disk size are configured.
- Verify that the vNICs are configured using a supported network driver.
- From Cisco IOS XE 17.6.1, you can enable the FIPS mode if the host and VM supports RDRAND or RDSEED, or both instructions. Otherwise, an error message is displayed.



---

**Note** Some hypervisors have configuration options or runtime options to block the use of RDSEED or RDRAND, or both in a VM. These options must not be enabled. That is, RDSEED or RDRAND, or both must not be blocked by the hypervisor if you want to enable the FIPS mode.

---





## CHAPTER 14

# Upgrading the Cisco IOS XE Software

The Cisco Catalyst 8000V virtual router runs on the Cisco IOS XE platform, the same platform that has powered Cisco CSR1000V or Cisco ISRv. To use the Cisco Catalyst 8000V router, first obtain the software image from the [Cisco Software Download](#) page. Obtain the installation files and then begin the installation or upgrade. To know more about the installation files, see [Installation Files, on page 9](#).

If you are an existing Cisco CSR1000V or a Cisco ISRv user, you must download the latest installation file from the Cisco Software Download page and begin the upgrade process by following the procedures mentioned in this chapter.

### Software Packaging for Cisco Catalyst 8000V

The software image for Cisco Catalyst 8000V is available as a consolidated package and as optional subpackages. Each consolidated package contains a collection of software subpackages, and each software subpackage is an individual software file that controls a different element or elements of the virtual router. Using a consolidated package, you can upgrade all the individual subpackages with a single software image download.

You can upgrade an individual software subpackage individually, or upgrade all the software subpackages for a specific consolidated package as part of a complete consolidated package upgrade. If you want to run the router using individual subpackages that are part of a consolidated package, download the image from Cisco.com and extract the individual subpackages from the image.

Upgrading using subpackage consumes less memory than upgrading through a consolidated package. For this reason, upgrading through subpackages is the recommended method, especially for deployments with small footprints.



#### Note

Upgrading a Cisco ISRv or a Cisco CSR1000V to Cisco Catalyst 8000V does not alter the file system layout nor provide any of the new features such as the Secure Object Store which rely on the file system. You must perform a fresh installation to activate these features.

**Important**

If you are an existing Cisco CSR1000V or Cisco ISRV user, and you are upgrading to Cisco Catalyst 8000V, your licenses continue to function as-is. However, an HSECK9 license is mandatory to run any throughput level greater than 250 Mbps. If you were running a throughput level greater than 250 Mbps prior to the upgrade, you must purchase an HSECK9 license for service continuity after the upgrade. If an HSECK9 license is not available after upgrade, throughput is restricted to 250 Mbps. If you want to switch to Cisco DNA subscription-based licensing model, you must perform a fresh Catalyst 8000V deployment.

- [Prerequisites for Upgrading Cisco Catalyst 8000V, on page 132](#)
- [HSECK9 License Requirements for Cisco CSR1000V and Cisco ISRV Upgrade, on page 132](#)
- [Restrictions for Upgrading Cisco Catalyst 8000V, on page 133](#)
- [Install Mode Process Flow, on page 134](#)
- [Bootting Cisco Catalyst 8000V in the Install Mode, on page 138](#)
- [Upgrading in Install Mode, on page 143](#)
- [Downgrading in Install Mode, on page 144](#)
- [Terminating a Software Installation, on page 144](#)
- [Troubleshooting Software Installation Using install Commands, on page 145](#)
- [Frequently Asked Questions, on page 146](#)

## Prerequisites for Upgrading Cisco Catalyst 8000V

- Obtain the Cisco Catalyst 8000V software image from the Cisco Software Download page. To know how to obtain the installation files, see [Download the Installation Files](#).
- Check the version of your hypervisor before you perform the upgrade. The upgrade is not successful if your hypervisor version is not supported by your current version of Cisco IOS XE on Cisco Catalyst 8000V.
- Ensure that you meet the memory requirements of the VM for the Cisco Catalyst 8000V software image. If the upgraded version requires more memory than your previous version, increase the memory allocation on the VM before you begin the upgrade process.

## HSECK9 License Requirements for Cisco CSR1000V and Cisco ISRV Upgrade

If you are upgrading a Cisco CSR1000V or Cisco ISRV router where *throughput is greater than 250 Mbps*, to Cisco Catalyst 8000V (Cisco IOS XE Bengaluru 17.4.1 and later), a High Security (HSECK9) license is required.

Depending on your pre-upgrade setup, ensure that you meet the corresponding HSECK9 license requirements, before you upgrade:

- If the Cisco CSR1000V or Cisco ISRV is connected to CSSM, then you must ensure the following:
  - Throughput greater than 250 Mbps is part of start-up configuration.

To check start-up configuration, enter the **show running-config** command in privileged EXEC mode. For example:

```
Device# show running-config | include throughput
platform hardware throughput level MB 500
```

- There is a positive balance of the required number of HSECK9 licenses (DNA\_HSECK9) in the corresponding Smart Account and Virtual Account in CSSM.

No further pre-upgrade action is required. As long as the device is connected to CSSM, on upgrade, the device automatically triggers the HSECK9 request and installs the required Smart Licensing Authorization Code (SLAC).

- If the Cisco CSR1000V or Cisco ISRV is using Specific License Reservation (SLR), then you must update the SLR authorization code to include an HSECK9 license (DNA\_HSECK9) and only then upgrade the device. This ensures uninterrupted throughput after upgrade.

This example shows you how to update the SLR authorization code: [Example: Smart Licensing \(SLR With Throughput >250 Mbps, Without Export-Controlled License\) to Smart Licensing Using Policy](#).

If throughput is lesser than or equal to 250 Mbps, an HSECK9 license is not required.

## Restrictions for Upgrading Cisco Catalyst 8000V

- You can upgrade to a new software version on the same VM only. The procedures do not describe how to install or rehost an existing router running the same or upgraded software version on a different VM.
- The .bin file is applicable for upgrading or downgrading your software. The .iso, .qcow2, and .ova files are used for first-time installation only.
- If you are upgrading to Cisco Catalyst 8000V, your licenses will continue to function as is. However, if you wish to switch to the CDNA licensing model, you must perform a fresh installation.
- The Cisco Catalyst 8000V router does not support In-Service Software Upgrade (ISSU).
- The system requirements for the x86 hardware might differ from those of the hardware currently running on the router.
- In the case of an upgrade from Cisco CSR1000V or Cisco ISRv, the disk partition structure remains the same as the previous version, and the secure object storage functionality is not available.
- If you want to upgrade to Cisco Catalyst 8000V from a Cisco CSR1000V or a Cisco ISRv prior to 16.12.x, first upgrade from your current version to 16.12.x. Then, upgrade to the latest version of Cisco Catalyst 8000V.
- You cannot upgrade a Cisco CSR1000V running PCI pass-through to Cisco Catalyst 8000V as Cisco Catalyst 8000V does not support PCI pass-through.
- If you have freshly installed Cisco Catalyst 8000V, you cannot downgrade to Cisco ISRv or Cisco CSR1000V. If you previously had a Cisco CSR1000V and upgraded to Cisco Catalyst 8000V, you can downgrade in the case of Cisco CSR1000V but not Cisco ISRv.
- If you want to upgrade from Cisco CSR1000V to Cisco Catalyst 8000V, or if you're upgrading from a lower to a higher version of Cisco Catalyst 8000V, only an N-2 or an N-1 to N release upgrade path is supported. Here, N-1 and N-2 refer to extended maintenance releases. For example, if you want to upgrade a CSR1000V 17.3.x instance to a Cisco Catalyst 8000V 17.11.1a release, 17.6.x is the lowest N-x version you need to update.


- Cisco Catalyst 8000V does not support L2TP functionality including L2TP client and L2TP Network Server (LNS).

## Install Mode Process Flow

The install mode process flow comprises three commands to perform the installation and the upgrade of Cisco Catalyst 8000V—**install add**, **install activate**, and **install commit**.

The following flow chart explains the install process with the install commands:

Process with Install Commit



The **install add** command copies the software package from a local or remote location to the platform. The location can be FTP, HTTP, HTTPS, or TFTP. This command extracts individual components of the .package file into subpackages and packages.conf files. It also validates the file to ensure that the image file is specific to Cisco Catalyst 8000V.

The **install activate** command performs the required validations and provisions the packages previously added using the **install add** command. It also triggers a system reload.

The **install commit** command confirms the packages previously activated using the **install activate** command, and ensures the updates are persistent over reloads.



**Note** Installing an update replaces any previously installed software image. At any time, you can install only one image in your instance.

The following table specifies the list of commands that are used when you install or upgrade your Cisco IOS XE platform:

Table 14: List of install Commands

Command	Syntax	Purpose
<b>install add</b>	<b>install add file</b> <i>location:filename.bin</i>	<p>Copies the contents of the image and the package to the software repository. File location may be local or remote. This command does the following:</p> <ul style="list-style-type: none"><li>• Validates the file—checksum, platform compatibility checks, and so on.</li><li>• Extracts individual components of the package into subpackages and packages.conf</li><li>• Copies the image into the local inventory and makes it available for the next steps.</li></ul>
<b>install activate</b>	<b>install activate</b>	<p>Activates the package added using the <b>install add</b> command.</p> <ul style="list-style-type: none"><li>• Use the <b>show install summary</b> command to see which image is inactive.</li><li>• The system reloads on executing this command. Confirm if you want to proceed with the activation. Use this command with the <b>prompt-level none</b> keyword to automatically ignore any confirmation prompts.</li></ul>

Command	Syntax	Purpose
(install activate) auto abort-timer	install activate auto-abort timer <30-1200>	<p>The <b>auto-abort timer</b> starts automatically with a default value of 120 minutes. If the <b>install commit</b> command is not executed within the time provided, the activation process is terminated, and the system returns to the last-committed state.</p> <ul style="list-style-type: none"> <li>• You can change the time value while executing the <b>install activate</b> command.</li> <li>• The <b>install commit</b> command stops the timer and continues the installation process.</li> <li>• The <b>install activate auto-abort timer stop</b> command stops the timer without committing the package.</li> <li>• Use this command with the <b>prompt-level none</b> keyword to automatically ignore any confirmation prompts.</li> <li>• This command is valid only in the three-step install variant.</li> </ul>
install commit	install commit	<p>Commits the package activated using the <b>install activate</b> command and makes it persistent over reloads.</p> <ul style="list-style-type: none"> <li>• Use the <b>show install summary</b> command to see which image is not committed.</li> </ul>



Command	Syntax	Purpose
<b>install abort</b>	<b>install abort</b>	<p>Terminates the installation and returns the system to the last-committed state.</p> <ul style="list-style-type: none"> <li>• This command is applicable only when the package is in the activated status (uncommitted state).</li> <li>• If you have already committed the image using the <b>install commit</b> command, use the <b>install rollback to</b> command to return to the preferred version.</li> </ul>
<b>install remove</b>	<b>install remove {file &lt;filename&gt;   inactive}</b>	<p>Deletes the inactive packages from the platform repository. Use this command to free up space.</p> <ul style="list-style-type: none"> <li>• <b>file</b>: Removes the specified files.</li> <li>• <b>inactive</b>: Removes all the inactive files.</li> </ul>
<b>install rollback to</b>	<b>install rollback to {base   label   committed   id}</b>	<p>Rolls back the software set to a saved installation point or to the last-committed installation point. The following are the characteristics of this command:</p> <ul style="list-style-type: none"> <li>• Requires reload.</li> <li>• Is applicable only when the package is in the committed state.</li> <li>• Use this command with the <b>prompt-level none</b> keyword to automatically ignore any confirmation prompts.</li> </ul> <p><b>Note</b> If you are performing install rollback to a previous image, the previous image must be installed in the install mode.</p>

Apart from the above-mentioned commands, you can also use the following show commands to verify the installation or upgrade:

Table 15: List of show Commands

Command	Syntax	Purpose
<b>show install log</b>	<b>show install log</b>	Provides the history and details of all the install operations that have been performed since the platform was booted.
<b>show install package</b>	<b>show install package</b> <filename>	Provides details about the .pkg/.bin file that is specified.
<b>show install summary</b>	<b>show install summary</b>	Provides an overview of the image versions and their corresponding install states.
<b>show install active</b>	<b>show install active</b>	Provides information about the active packages.
<b>show install inactive</b>	<b>show install inactive</b>	Provides information about the inactive packages, if any.
<b>show install committed</b>	<b>show install committed</b>	Provides information about the committed packages.
<b>show install uncommitted</b>	<b>show install uncommitted</b>	Provides information about uncommitted packages, if any.
<b>show install rollback</b>	<b>show install rollback</b> {point-id   label}	Displays the package associated with a saved installation point.
<b>show version</b>	<b>show version</b> [rp-slot] [installed [user-interface]   provisioned   running]	Displays information about the current package along with the platform information.

## Booting Cisco Catalyst 8000V in the Install Mode

You can install, activate, and commit a software package using a single command (one-step install procedure) or multiple separate commands (three-step install procedure).

If your Cisco Catalyst 8000V device is working in the bundle mode, you must use the one-step install procedure to initially convert the platform from the bundle mode to the install mode. You can then perform subsequent installs and upgrades by using either the one-step or the three-step installation method.

### One-Step Installation or Converting from Bundle Mode to Install Mode

This procedure uses the **install add file activate commit** command in the privileged EXEC mode to install a software package and to upgrade the platform to a newer version.

The one-step install procedure converts a platform running in the bundle boot mode to the install mode. After the command is executed, the platform reboots in the install boot mode.

**Note**

- All the CLI actions (for example, add, activate, and so on) are executed.
- The configuration save prompt appears if an unsaved configuration is detected.
- The reload prompt appears after the second step in this workflow. Use the **prompt-level none** keyword to automatically ignore the confirmation prompts.
- If the prompt-level is set to None, and there is an unsaved configuration, the install fails. You must save the configuration before reissuing the command.

**SUMMARY STEPS**

1. **enable**
2. **install add file location:** *filename* [**activate commit**]
3. **exit**

**DETAILED STEPS**

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> enable	Enables the privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>install add file location:</b> <i>filename</i> [ <b>activate commit</b> ]  <b>Example:</b> Device# install add file bootflash:c8000v-universalk9.BLD_POLARIS_DEV_LATEST_20220227_153436.SSA.bin activate commit	Copies the software install package from a local or remote location (through FTP, HTTP, HTTPS, or TFTP) to the platform and extracts the individual components of the .package file into subpackages and packages.conf files. It also performs a validation and compatibility check for the platform and image versions, activates the package, and commits the package to make it persistent across reloads.  The platform reloads after this command is run.
<b>Step 3</b>	<b>exit</b>  <b>Example:</b> Device# exit	Exits the privileged EXEC mode and returns to the user EXEC mode.

## Three-Step Installation

The three-step installation procedure uses individual **install add**, **install activate**, and **install commit** commands for installing a software package, and to upgrade the platform to a newer version.

**Note**

- You can perform this procedure only after the platform is in the install mode.
- All the CLI actions (for example, add, activate, and so on) are executed.
- The configuration save prompt appears if an unsaved configuration is detected.
- The reload prompt appears after the install activate step in this workflow. Use the **prompt-level none** keyword to automatically ignore the confirmation prompts.

**SUMMARY STEPS**

1. **enable**
2. **install add file location:** *filename*
3. **show install summary**
4. **install activate** [**auto-abort-timer** *<time>*]
5. **install abort**
6. **install commit**
7. **install rollback to committed**
8. **install remove** {**file filesystem:** *filename* | **inactive**}
9. **show install summary**
10. **exit**

**DETAILED STEPS**

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> enable	Enables the privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>install add file location:</b> <i>filename</i> <b>Example:</b> Device# install add file bootflash:c8000v-universalk9.BLD_POLARIS_DEV_LATEST_20220227_153436.SSA.bin	Copies the software install package from a remote location (through FTP, HTTP, HTTPS, or TFTP) to the platform, and extracts the individual components of the .package file into subpackages and packages.conf files.
<b>Step 3</b>	<b>show install summary</b> <b>Example:</b> Device# show install summary	(Optional) Provides an overview of the image versions and their corresponding install state.
<b>Step 4</b>	<b>install activate</b> [ <b>auto-abort-timer</b> <i>&lt;time&gt;</i> ] <b>Example:</b> Device# install activate auto-abort-timer 120	Activates the previously added package and reloads the platform. <ul style="list-style-type: none"> <li>• When you're performing a full software install, do not provide a package filename.</li> <li>• The <b>auto-abort-timer</b> starts automatically with the <b>install activate</b> command; the default for the timer is 120 minutes. If the <b>install commit</b> command is not</li> </ul>

	Command or Action	Purpose
		run before the timer expires, the install process is automatically terminated. The platform reloads and boots up with the last committed version.
<b>Step 5</b>	<b>install abort</b> <b>Example:</b> Device# install abort	(Optional) Terminates the software install activation and returns the platform to the last committed version.  Use this command only when the image is in the activated state and not when the image is in the committed state.
<b>Step 6</b>	<b>install commit</b> <b>Example:</b> Device# install commit	Commits the new package installation and makes the changes persistent over reloads.
<b>Step 7</b>	<b>install rollback to committed</b> <b>Example:</b> Device# install rollback to committed	(Optional) Rolls back the platform to the last committed state.
<b>Step 8</b>	<b>install remove {file filesystem: filename   inactive}</b> <b>Example:</b> Device# install remove inactive	(Optional) Deletes the software installation files.  <ul style="list-style-type: none"> <li>• <b>file:</b> Deletes a specific file.</li> <li>• <b>inactive:</b> Deletes all the unused and inactive installation files.</li> </ul>
<b>Step 9</b>	<b>show install summary</b> <b>Example:</b> Device# show install summary	(Optional) Displays information about the current state of the system. The output of this command varies according to the <b>install</b> commands run prior to this command.
<b>Step 10</b>	<b>exit</b> <b>Example:</b> Device# exit	Exits the privileged EXEC mode and returns to the user EXEC mode.

## Sample Upgrade Output from Release 17.06.02 To Release 17.07.01

```

=====
Upgrade steps
install add file bootflash:/ c8000v-universalk9.17.07.01a.SPA.bin
install activate
install commit
=====

Router#show version | inc IOS XE
Cisco IOS XE Software, Version 17.06.02
Router#show version | inc mode
Router operating mode: Autonomous

Router# dir bootflash:*bin*
Directory of bootflash:/*bin*

Directory of bootflash:/

```

```

31 -rw- 832807301 Mar 7 2022 02:07:28 +00:00 c8000v-universalk9.17.07.01a.SPA.bin
5183766528 bytes total (2348220416 bytes free)

```

```

Router#install add file bootflash:/c8000v-universalk9.17.07.01a.SPA.bin
install_add: START Mon Mar 7 02:16:30 UTC 2022
install_add: Adding PACKAGE
install_add: Checking whether new add is allowed

```

```

--- Starting Add ---
Performing Add on Active/Standby
 [1] Add package(s) on R0
 [1] Finished Add on R0
Checking status of Add on [R0]
Add: Passed on [R0]
Finished Add

```

```

Image added. Version: 17.07.01a.0.1883
SUCCESS: install_add Mon Mar 7 02:20:07 UTC 2022
VK5-C8K-8G-1762-1#

```

```

Router# show install summary
[R0] Installed Package(s) Information:
State (St): I - Inactive, U - Activated & Uncommitted,
 C - Activated & Committed, D - Deactivated & Uncommitted

```

```

Type St Filename/Version

IMG C 17.06.02.0.2786
IMG I 17.07.01a.0.1883

```

```

Auto abort timer: inactive

```

```

=====
install activate
=====

```

```

Router# show install summary
[R0] Installed Package(s) Information:
State (St): I - Inactive, U - Activated & Uncommitted,
 C - Activated & Committed, D - Deactivated & Uncommitted

```

```

Type St Filename/Version

IMG C 17.06.02.0.2786
IMG I 17.07.01a.0.1883

```

```

Router# install activate
install_activate: START Mon Mar 7 02:50:00 UTC 2022
install_activate: Activating PACKAGE
Following packages shall be activated:
/bootflash/c8000v-rpboot.17.07.01a.SPA.pkg
/bootflash/c8000v-mono-universalk9.17.07.01a.SPA.pkg
/bootflash/c8000v-firmware_nim_xdsl.17.07.01a.SPA.pkg
/bootflash/c8000v-firmware_nim_shdsl.17.07.01a.SPA.pkg
/bootflash/c8000v-firmware_nim_ge.17.07.01a.SPA.pkg
/bootflash/c8000v-firmware_nim_cwan.17.07.01a.SPA.pkg
/bootflash/c8000v-firmware_nim_async.17.07.01a.SPA.pkg
/bootflash/c8000v-firmware_ngwic_tle1.17.07.01a.SPA.pkg
/bootflash/c8000v-firmware_dsp_sp2700.17.07.01a.SPA.pkg
/bootflash/c8000v-firmware_dreamliner.17.07.01a.SPA.pkg

```

```
This operation may require a reload of the system. Do you want to proceed? [y/n]y
--- Starting Activate ---
Performing Activate on Active/Standby
```

```
[1] Activate package(s) on R0
--- Starting list of software package changes ---
Old files list:
 Modified c8000v-firmware_dreamliner.17.06.02.SPA.pkg
 Modified c8000v-firmware_dsp_sp2700.17.06.02.SPA.pkg
 Modified c8000v-firmware_ngwic_tle1.17.06.02.SPA.pkg
 Modified c8000v-firmware_nim_async.17.06.02.SPA.pkg
 Modified c8000v-firmware_nim_cwan.17.06.02.SPA.pkg
 Modified c8000v-firmware_nim_ge.17.06.02.SPA.pkg
 Modified c8000v-firmware_nim_shdsl.17.06.02.SPA.pkg
 Modified c8000v-firmware_nim_xdsl.17.06.02.SPA.pkg
 Modified c8000v-mono-universalk9.17.06.02.SPA.pkg
 Modified c8000v-rpboot.17.06.02.SPA.pkg
New files list:
 Added c8000v-firmware_dreamliner.17.07.01a.SPA.pkg
 Added c8000v-firmware_dsp_sp2700.17.07.01a.SPA.pkg
 Added c8000v-firmware_ngwic_tle1.17.07.01a.SPA.pkg
 Added c8000v-firmware_nim_async.17.07.01a.SPA.pkg
 Added c8000v-firmware_nim_cwan.17.07.01a.SPA.pkg
 Added c8000v-firmware_nim_ge.17.07.01a.SPA.pkg
 Added c8000v-firmware_nim_shdsl.17.07.01a.SPA.pkg
 Added c8000v-firmware_nim_xdsl.17.07.01a.SPA.pkg
 Added c8000v-mono-universalk9.17.07.01a.SPA.pkg
 Added c8000v-rpboot.17.07.01a.SPA.pkg
Finished list of software package changes
[1] Finished Activate on R0
Checking status of Activate on [R0]
Activate: Passed on [R0]
Finished Activate
```

```
Send model notification for install_activate before reload
Install will reload the system now!
SUCCESS: install_activate Mon Mar 7 02:57:34 UTC 2022
```

```
=====
install commit
=====
```

```
Router# show version | inc IOS XE
Cisco IOS XE Software, Version 17.07.01a
Router# show version | inc mode
Router operating mode: Autonomous
Router# show license udi
UDI: PID:C8000V,SN:9JM01Z7G2JH
```

## Upgrading in Install Mode

Use either the one-step installation or the three-step installation procedures mentioned in this chapter to upgrade Cisco Catalyst 8000V in the install mode.

## Downgrading in Install Mode

Use the **install rollback** command to downgrade the platform to a previous version by pointing it to the appropriate image, provided the image you are downgrading to was installed in the install mode.

The **install rollback** command reloads the platform and boots it with the previous image.



**Note** The **install rollback** command succeeds only if you have not removed the previous file using the **install remove inactive** command.



**Note** If you're unable to use this command, you can downgrade by installing the older image using the **install** commands.

### Sample Downgrade Configuration

```
=====
install rollback
=====
```

```
Router# install rollback to base
install_rollback: START Tue Mar 01 03:25:46 UTC 2022
install_rollback: Rolling back to base
This operation may require a reload of the system. Do you want to proceed? [y/n]
*Mar 29 21:17:36.496: %INSTALL-5-INSTALL_START_INFO: R0/0: install_mgr: Started install
rollback
--- Starting Rollback ---
Performing Rollback on all members
[1] Rollback package(s) on R0
[1] Finished Rollback package(s) on R0
Checking status of Rollback on [R0]
Rollback: Passed on [R0]
Finished Rollback operation
SUCCESS: install_rollback Tue Mar 01 03:30:16 UTC UTC 2022
```

## Terminating a Software Installation

You can terminate the activation of a software package in the following ways:

- By allowing the auto-abort-timer to expire before issuing the **install commit** command. When the platform reloads after activating a new image, the auto-abort-timer is triggered (in the three-step install method). When this timer expires, the installation process is terminated and the platform reloads and boots with the last committed version of the software image.

By using the **install auto-abort-timer stop** command to stop this timer without using the **install commit** command. The new image remains uncommitted in this process.

- By using the **install abort** command which returns the platform to the version that was running before installing the new software. Use this command before issuing the **install commit** command.



## Sample Abort Configuration

```

=====
install abort
=====
Router# show install summary
[R0] Installed Package(s) Information:
State (St): I - Inactive, U - Activated & Uncommitted,
 C - Activated & Committed, D - Deactivated & Uncommitted
Type St Filename/Version

IMG U 17.09.01.0.154628

Auto abort timer: active , time before rollback - 01:56:56

Router# show version | inc IOS XE
Cisco IOS XE Software, Version BLD_POLARIS_DEV_LATEST_20220227_153436
Router# show version | inc mode
Router operating mode: Autonomous
Router# install abort
install_abort: START Tue Mar 01 04:03:52 UTC 2022

This operation may require a reload of the system. Do you want to proceed? [y/n]y

--- Starting Abort ---
Performing Abort on all members
 [1] Abort packages(s) on R0
 [1] Finished Abort packages(s) on R0
Checking status of Abort on [R0]
Abort: Passed on [R0]
Finished Abort operation

SUCCESS: install_abort Tue Mar 01 04:04:45 UTC 2022

Router# Mar 1 04:04:50.161: %PMAN-5-EXITACTION: R0/0: pvp: Process manager is exiting:
reload action requested

```

# Troubleshooting Software Installation Using install Commands

**Problem** Troubleshooting the software installation

**Solution** Use the following show commands to view installation summary, logs, and software versions.

- **show install summary**
- **show install log**
- **show version**
- **show version running**

**Problem** Other installation issues

**Solution** Use the following commands to resolve installation issue:

- **dir <install directory>**

- **more location:***packages.conf*
- **show tech-support install:** this command automatically runs the **show** commands that display information specific to installation.
- **request platform software trace archive target bootflash <location>:** this command archives all the trace logs relevant to all the processes running on the system since the last reload, and saves this information in the specified location.

## Frequently Asked Questions

- Q.** Can I downgrade from Cisco Catalyst 8000V to Cisco CSR1000V or Cisco ISRv?
- A.** You can downgrade from Cisco Catalyst 8000V only if you've upgraded to Cisco Catalyst 8000V from a Cisco CSR1000V or a Cisco ISRv 17.3.x or a later version.




---

**Note** You cannot downgrade to Cisco CSR1000V or Cisco ISRv if you have freshly installed Cisco Catalyst 8000V.

---

- Q.** When I upgrade from a Cisco CSR1000V 16.12.x version or below, will Secure Object Storage be supported?
- A.** No, Secure Object Storage is not carried over through upgrades. You must perform a fresh installation or reinstall the VM to enable Secure Object Storage support.
- Q.** Will my license need to change when I upgrade from a Cisco CSR1000V or a Cisco ISRv to Cisco Catalyst 8000V?
- A.** When you upgrade to Cisco Catalyst 8000V, the licenses remain the same. However, the licenses move from SL to SLE after the upgrade. If the throughput was  $\leq 250\text{M}$  before the upgrade, it is retained as is after the upgrade.

If the throughput was  $>250\text{M}$  and the device was registered to CSSM, the connection stays intact and the throughput automatically triggers the SLAC installation on the device. The corresponding throughput is set once SLAC is installed.

If the device was not connected to CSSM and throughput was  $>250\text{M}$ , you must manually install SLAC in the offline mode or configure SLE commands to establish trust with CSSM. Then, configure the throughput to trigger the SLAC installation.




---

**Note** If SLAC is not installed, the throughput remains at 250M.

---

- Q.** Is automation available for the upgrade process?
- A.** No, automation is currently not supported for the migration.
- Q.** What is the failure mode handling when I perform a downgrade?
- A.** When a Cisco CSR1000V image is booting up as a result of a downgrade, the system checks for the partition format. If the partition format does not match the requirements, the boot up is halted. If a Cisco

Catalyst 8000V image is booting up as a result of an upgrade or a downgrade, it continues to boot using the existing partition format.

- Q.** What is the memory and performance impact after the upgrade?
- A.** The size of the Cisco Catalyst 8000V image might be slightly larger which could affect the overall memory footprint. However, this does not alter the overall memory requirements. The minimum required RAM for this image is 4GB, and there is no impact on performance by this feature.





## CHAPTER 15

# Configuring the vCPU Distribution

This chapter specifies the allocation and distribution of the vCPUs in the following planes: Control Plane (CP), Data Plane (DP), and Service Plane (SP) by using templates. Note that the Service Plane includes containers running SNORT.

Use one of the following templates for vCPU distribution:

- [vCPU Distribution: Control Plane Extra heavy, on page 149](#)
- [vCPU Distribution: Control Plane heavy, on page 150](#)
- [vCPU Distribution: Data Plane heavy, on page 150](#)
- [vCPU Distribution: Data Plane normal, on page 151](#)
- [vCPU Distribution: Service Plane heavy, on page 151](#)
- [vCPU Distribution: Service Plane medium, on page 151](#)
- [Configuring the vCPU Distribution across the Data, Control, and Service Planes, on page 152](#)
- [Determining the Active vCPU Distribution Template, on page 152](#)

## vCPU Distribution: Control Plane Extra heavy

The following table shows the vCPU distribution for the Control Plane Extra heavy template.

**Table 16: Control Plane Extra heavy - vCPU Distribution**

Number of vCPUs	1	2	4	8
Control Plane	1/3	1/2	1 1/2	1 1/2
Service Plane	1/3	1/2	1 1/2	1 1/2
Data Plane	1/3	1	1	5



**Note** Using a Control Plane Extra heavy template, a service plane app can obtain 1.5 full cores for its operation. For example, in the case of Wide Area Application Services (WAAS).

## vCPU Distribution: Control Plane heavy

The following table shows the vCPU distribution for the Control Plane heavy template.

**Table 17: Control Plane heavy - vCPU Distribution**

Number of vCPUs	1	2	4	8
Control Plane	1/3	1/2	1	1
Service Plane	1/3	1/2	1	1
Data Plane	1/3	1	2	6



**Note** The Control Plane heavy template allocates an extra core to the Control Plane/Service Plane services compared to the Data Plane heavy template (there is one core for the Control Plane and another core for the Service Plane). If there is no Service Plane application, the Control Plane utilizes all the resources (both the cores).

## vCPU Distribution: Data Plane heavy



**Note** The Data Plane heavy template is the default vCPU Distribution template. Even if the configuration output for the Template option reads 'None', the Data Plane heavy template is applied by default.

The above mentioned statement is not applicable for Cisco Catalyst 8000V instances running in the controller mode.

The following table shows the vCPU distribution for the Data Plane heavy template.

**Table 18: Data Plane heavy - vCPU Distribution**

Number of vCPUs	1	2	4	8
Control Plane	1/3	1/2	1/2	1/2
Service Plane	1/3	1/2	1/2	1/2
Data Plane	1/3	1	3	7



**Note** By default, the Cisco Catalyst 8000V core allocation favors a larger data plane for performance. If there is no Service Plane application, the Control Plane also utilizes the Service Plane's resources.

## vCPU Distribution: Data Plane normal

You can use the vCPU distribution for the Data Plane normal template to force the Cisco Catalyst 8000V to behave in the same way as before using a template for vCPU distribution.

That is, assume you create a Cisco Catalyst 8000V VM using the Data Plane heavy template for vCPU distribution, as specified in the ovf-env.xml file. You can later use the CLI commands in the Data Plane normal template to override the XML file settings that were previously applied by the Data Plane heavy template.

## vCPU Distribution: Service Plane heavy

The following table shows the vCPU distribution for the Service Plane heavy template.

**Table 19: Service Plane heavy - vCPU Distribution**

Number of vCPUs	1	2	4	8
Control Plane	1/3	1/2	1	2
Service Plane	1/3	1/2	1	2
Data Plane	1/3	1	2	4



**Note** Using a Service Plane heavy template, a Service Plane application (such as Snort IPS) can use up to 2 full cores for its operation.

## vCPU Distribution: Service Plane medium

The following table shows the vCPU distribution for the Service Plane medium template.

**Table 20: Service Plane medium - vCPU Distribution**

Number of vCPUs	1	2	4	8
Control Plane	1/3	1/2	1	1
Service Plane	1/3	1/2	1	1
Data Plane	1/3	1	2	6

# Configuring the vCPU Distribution across the Data, Control, and Service Planes

Enter the `platform resource` command on the Cisco Catalyst 8000V CLI to select a template for vCPU distribution.

**configure template**

**platform resource** *template*

Example:

```
Router# configure template
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# platform resource ?
 control-plane-extra-heavy Use Control Plane Extra Heavy template
 control-plane-heavy Use Control Plane Heavy template
 data-plane-heavy Use Data Plane Heavy template
 data-plane-normal Use Data Plane Normal template
 service-plane-heavy Use Service Plane Heavy template
 service-plane-medium Use Service Plane Medium template
Router(config)# platform resource service-plane-heavy
```



---

**Note** After entering the `platform resource` command, you must reboot the Cisco Catalyst 8000V instance to activate the template.

---

## Determining the Active vCPU Distribution Template

To determine which template is being used for vCPU distribution, use the following command:

**show platform software cpu alloc**

Example:

```
Router# show platform software cpu alloc
CPU alloc information:
Control plane cpu alloc: 0-1
Data plane cpu alloc: 2-3
Service plane cpu alloc: 0-1
Template used: CLI-service_plane_heavy
```



---

**Note** The Control plane and the Service plane share cores 0 and 1.

---





## CHAPTER 16

# Managing the SD-Routing Device Using Cisco SD-WAN Manager

---

This chapter includes information about managing and monitoring the SD-Routing devices using Cisco SD-WAN Manager. It contains the following sections:

- [Information About Using Cisco SD-WAN Manager to Monitor the SD-Routing Devices, on page 153](#)
- [Supported WAN Edge Devices, on page 155](#)
- [Onboarding the SD-Routing Devices , on page 157](#)
- [Software Image Management, on page 169](#)
- [Monitoring the Device Using Cisco SD-WAN Manager, on page 172](#)
- [Alarms and Events, on page 173](#)
- [Admin-Tech Files, on page 174](#)
- [Configuration Examples, on page 175](#)
- [Troubleshooting , on page 177](#)
- [Feature Information for Managing SD-Routing Devcies Using vManage, on page 178](#)

## Information About Using Cisco SD-WAN Manager to Monitor the SD-Routing Devices

This feature allows you to perform the basic management capabilities through Cisco SD-WAN Manager on the Cisco IOS XE devices that are operating in non-SD-WAN mode. From Cisco IOS XE 17.12.1a onwards, such devices will be referred as SD-Routing devices. You can use a single Network Management System (NSM) (Cisco SD-WAN Manager) to manage and monitor all the Cisco IOS XE routers and help in simplifying solution deployments.




---

**Note**

The minimum software version required for this feature to work is Cisco IOS XE 17.12.1a and Cisco SD-WAN Release 20.12.1.

---

Figure 2: Managing the SD-Routing Devices



## Benefits of Managing the SD-Routing Devices Using Cisco SD-WAN Manager

1. Use of a single NMS (Cisco SD-WAN Manager) for Cisco Catalyst SD-WAN and SD-Routing deployments in an Enterprise network.
2. Co-existence of Cisco SD-WAN and SD-Routing devices on the same Cisco SD-WAN Manager.

## Prerequisites

The following are the prerequisites to onboard the SD-Routing devices:

- Ensure that the device run the Cisco IOS XE 17.12.1a image in install mode. For more information on the modes, see the [Modes Using Cisco CLI](#) section.
- A Cisco SD-WAN Manager instance either on-prem or hosted on a cloud.
- Connectivity from the device to the Cisco SD-WAN Manager.

- Enable netconf-yang models for enabling DMI which is required for managing from Cisco SD-WAN Manager.
- Devices operating in autonomous mode must be configured with the following basic configuration manually to establish the secure control connections with controllers (Cisco SD-WAN Validator and Cisco SD-WAN Manager):
  - System properties:
    - System-ip
    - Site-id
    - Organization-name
    - Cisco SD-WAN Validator information (IP address or FQDN Cisco SD-WAN Validator server)
  - Interface configuration:
    - Physical interface with a static or dynamic IP address and subnet mask
    - Dynamic routing or default route to provide reachability to Cisco SD-WAN Validator or Cisco SD-WAN Manager

## Limitations

- Cisco SD-routing devices onboarding onto Cisco SD-WAN Manager is only supported with universalk9 images. No Payload Encryption (NPE) images are not supported.
- In Cisco IOS XE 17.12.1a release, basic monitoring is supported and additional features will be supported in the subsequent releases. For more information on supported features list, see the platform specific Release Notes.
- Cisco SD-Routing devices can only have one control connection to Cisco SD-WAN Manager from an interface with reachability to the controllers.
- Cisco SD-routing devices will not have any active connection with Cisco SD-WAN Controller.
- Dedicated management interface is not supported for the connection to the Cisco SD-WAN Manager.

## Supported WAN Edge Devices

The table lists the supported WAN Edge platforms and onboarding options.

**Table 21: Supported WAN Edge Platforms and Onboarding Options**


Platforms	Automated	Bootstrap	Manual
<b>Cisco ASR 1000 Series Aggregation Services Routers</b>			
ASR1001-HX	Yes	Yes	Yes
ASR1002-HX	Yes	Yes	Yes

Platforms	Automated	Bootstrap	Manual
<b>Cisco 4400 Series Integrated Services Routers</b>			
Cisco 4431 ISR	Yes	Yes	Yes
Cisco 4451 ISR	Yes	Yes	Yes
Cisco 4461 ISR	Yes	Yes	Yes
<b>Cisco 4300 Series Integrated Services Routers</b>			
Cisco 4321 ISR	Yes	Yes	Yes
Cisco 4331 ISR	Yes	Yes	Yes
Cisco 4351 ISR	Yes	Yes	Yes
<b>Cisco 4200 Series Integrated Services Routers</b>			
Cisco 4221 ISR	Yes	Yes	Yes
<b>Cisco 100 Series Integrated Services Routers</b>			
Cisco 1000 ISR	Yes	Yes	Yes
<b>Cisco Catalyst 8000V Series Edge Platforms</b>			
Cisco Catalyst 8000V	Not applicable <b>Note</b> Automated onboarding is applicable only for the hardware device.	Yes	Yes
<b>Cisco Catalyst 8200 Series Edge Platforms</b>			
C8200-1N-4T	Yes	Yes	Yes
C8200L-1N-4T	Yes	Yes	Yes
<b>Cisco Catalyst 8300 Series Edge Platforms</b>			
C8300-1N1S-4T2X 6T	Yes	Yes	Yes
C8300-2N2S-4T2X 6T	Yes	Yes	Yes
<b>Cisco Catalyst 8500 Series Edge Platforms</b>			
C8500-12X4QC	Yes	Yes	Yes
C8500-12X	Yes	Yes	Yes
C8500L-8S4X	Yes	Yes	Yes

Platforms	Automated	Bootstrap	Manual
C8500-20X6C	Yes	Yes	Yes

## Onboarding the SD-Routing Devices

This section explains the workflows to onboard the SD-Routing devices:



- Onboarding the SD-Routing Devices
  - Automated Onboarding: Uses the Dynamic Host Configuration Protocol (DHCP and Cisco Plug and Play (PNP)) to automatically onboard the device to Cisco SD-WAN Manager.
  - Bootstrap Onboarding: Uses the bootstrap file either on the bootflash or on a USB and configures the device with the minimum configuration to reach the Cisco SD-WAN Manager.
  - Manual Onboarding: Configures the device manually using IOS-XE commands to onboard the device to Cisco SD-WAN Manager.

To onboard the SD-Routing devices, the prerequisites are:

- System IP

For manual Onboarding, the prerequisites are:

- Site ID
- Organization-name
- Cisco SD-WAN Validator information (IP address or FQDN Cisco SD-WAN Validator server)
- Interface for connection to Cisco SD-WAN Manager (Physical, Sub-interface, and Loopback)

## Onboarding the SD-Routing Devices Using Automated Workflow

To onboard the SD-routing devices using the automated workflow, perform these steps:

- Configure the Plug and Play Connect Portal
- Configure the Cisco SD-WAN Manager using quick connect workflow
- Bring up the device in Day0 mode

## Configuring the Plug and Play Connect Portal

To configure the PnP Connect portal, perform these steps:

### Before you begin

Ensure that you can access to the PnP Connect portal and an active Smart Account and Virtual Account using your Cisco User ID. You have to also use a CCO ID that is associated as the Smart Account or Virtual Account admin of the account, on PnP Connect portal.



**Note** You can enable the PnP Connect Sync only after you enter the Smart Account credentials in the Cisco SD-WAN Manager Settings page.

- 
- Step 1** Go to [software.cisco.com](https://software.cisco.com) > **Network Plug and Play** > **Manage Devices** and ensure that you have access to Smart Account and Virtual Account.
- Step 2** Create a Controller Profile and upload the **root-ca** if it is for an Enterprise network.
- Note** If the overlay network is **Cisco PKI**, you do not have to upload any certificate.
- Step 3** Enter the Controller Profile with controller type as VBond and click **Next**.
- Step 4** Enter the required parameters in the **Add Controller Profile** and click **Next**.
- Step 5** Add the device to PnP Connect. When you add the device, in the Device Mode field, select **AUTONOMOUS** for device in SD-Routing mode from the drop-down list.
- 

## Configuring the Cisco SD-WAN Manager Using Quick Connect Workflow

To configure the Cisco SD-WAN Manager using Quick Connect workflow, perform these steps:

- 
- Step 1** From the Cisco SD-WAN Manager menu, go to **Workflows** > **Quick Connect**.
- Step 2** Click **Get Started**.
- Step 3** Click **Next**.
- Step 4** If you have not uploaded the provisioning file (*.csv* or *.viptela*) from PnP to Cisco SD-WAN Manager, you can use either **.csv upload** or **.viptela upload** or **Sync Smart Account** option to add the device to Cisco SD-WAN Manager. If the device is already added to Cisco SD-WAN Manager, select the **skip for now** option.
- Note** The *.csv* file is applicable only for hardware devices. The *.viptela* file is applicable for both hardware and software devices.

- Step 5** Click **Sync Smart Account** if you have not synernized it already. You should now see your device listed in the table of the devices.  
Click Sync Smart Account,
- Step 6** Click **Next**.
- Step 7** In the Add and Review Device Configuration dialog box, enter the Site-ID, System-IP, Hostname, and click **Apply**.
- Step 8** Click **Next**.
- Step 9** Add any option Tag and click **Next**.
- Step 10** To verify the device that is added , choose **Configuration> Devices** and click enable **Device Model** in Table Settings.
- Step 11** A list of routers in the network is displayed, showing detailed information about each router. To verify that the devices are added, select **Configuration > Certificates**.

## Bringing Up the SD-Routing Device

To bring up the SD-Routing device, perform these steps:

- Step 1** Bring up the device in Day-0 state. If the device is not in Day-0 state, use either **controller-mode reset** or **writer erase** with **reload** option to bring it to Day-0 state.
- Step 2** Ensure that the device gets the IP address over DHCP on one of the interfaces other than the Gigabit Ethernet0 interface. Also, ensure that the device is reachable to devicehelper.cisco.com and the Cisco SD-WAN Validator.
- Note** Dedicated management interface is not supported for the connection to the Cisco SD-WAN Manager.
- Step 3** The device control connection comes up on Cisco SD-WAN Manager.
- Step 4** Verify the control connection status on the Edge device using the **show sd-routing connections summary** command:

### Example:

```
Router#show sd-routing connections summary
```

PEER	PEER	PEER	SITE	PEER	PEER	PEER	PEER	PEER
TYPE	PROT	SYSTEM	IP	ID	PRIVATE	IP	PORT	PUBLIC
IP				PORT	STATE	UPTIME		
Cisco SD-WAN Manager	dtls	172.16.255.22	200	10.0.12.22				
12446	10.0.12.22		12446	up	12:05:29:3			

- Step 5** Verify the control connection status on Cisco SD-WAN Manager.

## Onboarding the SD-Routing Devices Using Bootstrap

To onboard the SD-Routing device using the bootstrap, perform these steps:

- Step 1** From the Cisco SD-WAN Manager menu, go to **Workflows > Quick Connect**.

**Step 2** Click **Get Started**.

**Step 3** Click **Next**.

**Step 4** If you have not uploaded the provisioning file (.csv or .viptela ) from PnP to Cisco SD-WAN Manager, you can use either **.csv upload** or **.viptela upload** or **Sync Smart Account** option to add the device to Cisco SD-WAN Manager. If the device is already added to Cisco SD-WAN Manager, select the **skip for now** option.

**Note** The .csv file is applicable only for hardware devices. The .viptela file is applicable for both hardware and software devices.

**Step 5** Select the device that you want to onboard and click **Next**.

**Step 6** In the Add and Review Configuration dialog box, enter the Site-ID, System-IP, Hostname, and click **Apply**.

**Step 7** To verify the device that is added, choose **Configuration> Devices** and click enable **Device Model** in Table Settings.

**Step 8** Ensure that the device is in valid state from **Configuration > Certificate** page.

**Step 9** From the Cisco SD-WAN Manager menu, choose **Configuration> Devices**.

**Step 10** For the Cisco SD-Routing software devices ( Cisco c8000V), perform these steps to generated the bootstrap and onboard the device:

**Note** For hardware devices, follow the instructions in Step 11.

- a) Click ... at the right pane of the window and choose **Generate Bootstrap Configuration**.
- b) Choose Cloud-init option and enter a name for the WAN Interface Name and click **OK**.

**Note** Ensure that the DHCP is enabled on the selected interface and is reachable to Cisco SD-WAN Validator and Cisco SD-WAN Manager. Also, for the software device, use only Gigabit Ethernet1 interface as the VPN0 interface.

- c) Click **Download** to download the image on the device.

**Example:**

*Sample image: ciscosdwan\_cloud\_init.cfg*

*Sample image with Certificate : ciscosdwan\_cloud\_init\_with\_ent\_cert.cfg*

- d) For cloud-based controllers, the downloaded bootstrap file can be added as a user data field when you deploy the device. It will bring up the controller in SD-Routing mode and establish the connection with Cisco SD-WAN Validator and Cisco SD-WAN Manager.

**Step 11** For hardware devices, perform these steps to generate the bootstrap and onboard the device:

- a) From the Cisco SD-WAN Manager menu on the device page, click **Export Bootstrap Configuration**.
- b) Select the check box for SD-Routing. In the **Export Bootstrap Configuration** dialog box, enter the **WAN Interface name**.

**Note** The management interface name may vary among Cisco IOS XE device models. Specify the interface name based on the model you wish to onboard and which can reach the Cisco SD-WAN Validator and Cisco SD-WAN Controller.

- c) Click **Generate Generic Configuration** to download the generic .cfg bootstrap applicable for the hardware devices. Unzip the file and rename it as *ciscosdawn.cfg*.



**Note** Ensure that the DHCP is enabled on the selected interfaces and is reachable to Cisco SD-WAN Validator and Cisco SD-WAN Manager.

The bootstrap file will contain the organization name, Cisco SD-WAN validator IP, and root-ca certificates. For the enterprise network, it will have the enterprise root-ca- certificates.

- d) Copy the bootstrap file to the device bootflash as *ciscosdwan.cfg*.
- e) Execute the **sd-routing bootstrap load bootflash:ciscosdwan.cfg** command.

**Example:**

```
Router# sd-routing bootstrap load bootflash:ciscosdwan.cfg
Located the file. Beginning to extract the data
Extraction summary
-Organization name - "aniltb2"
-Interface - GigabitEthernet0/0/0
-vbond - 99.99.1.51
Successfully extracted root-cert info

Do you want to proceed and apply extracted
parameters to enable sd-routing feature?? (yes/[no]): yes
Successfully configured bootstrap extracted parameters
Router#
*May 10 08:56:11.159: %SYS-5-CONFIG_P: Configured programmatically by process Exec from console as console
*May 10 09:05:11.751: %DMI-5-AUTH_PASSED: R0/0: dmiauthd: User 'vmanage-admin' authenticated successfully from
201.201.201.1:41902 for netconf over ssh. External groups
```

- f) Verify the control connection using these **show sd-routing system status**, **show sd-routing system status**, and **show sd-routing local-properties summary** commands.

## Onboarding the Devices Manually

To onboard the SD-Routing devices manually, perform these steps:

- Step 1** From the Cisco SD-WAN Manager menu, go to **Workflows > Quick Connect**.
- Step 2** Click **Get Started**.
- Step 3** Click **Next**.
- Step 4** If you have not uploaded the provisioning file (*.csv* or *.viptela*) from PnP to Cisco SD-WAN Manager, you can use either **.csv upload** or **.viptela upload** or **Sync Smart Account** option to add the device to Cisco SD-WAN Manager. If the device is already added to Cisco SD-WAN Manager, select the **skip for now** option.
 

**Note** The *.csv* file is applicable only for hardware devices. The *.viptela* file is applicable for both hardware and software devices.
- Step 5** Select the device that you want to onboard and click **Next**.
- Step 6** In the Add and Review Configuration dialog box, enter the Site-ID, System-IP, Hostname, and click **Apply**.
- Step 7** To verify device that is added, choose **Configuration > Devices** and click enable **Device Model** in Table Settings.
- Step 8** A list of routers in the network is displayed with detailed information about each router. To verify that the devices are added, select **Configuration > Certificates**.

- Step 9** Preform one of the following steps based on the device that you want to onboard manually:
- For the hardware device, enter the initial day-0 configurations using the IOS command after a system boot up.
  - For the Cisco SD-Routing software devices, deploy the Cisco c8000v in Amazon Web Services (AWS) or Azure without the bootstrap.

- Step 10** Configure the minimum parameters to enable the control connection on Cisco SD-WAN Manager.

**Example:**

```
netconf-yang

sd-routing
 no ipv6-strict-control
 organization-name "%Your Org. Name%"
 site-id %id%
 system-ip %system ip%
 vbond name %vbond name or vbond ip%
 vbond port 12346
 wan-interface %uplink interface%

ip route 0.0.0.0 0.0.0.0 %next hop ip%

interface %uplink interface%
 ip address %dhcp or static%
 no shutdown
```

- Step 11** Configure the required parameter to enable the SD-Routing mode:
- Ensure that the interface is configured with a static IP address or through DHCP. Also, the interface must be in **no shut** state.
  - Configure either Validator IP or Validator Name.
  - Configure the System-IP, Site-ID, Organization-Name and WAN-Interface.

- Step 12** Verify that the feature is enabled by checking the status of the vdaemon.

**Example:**

```
Router# show platform software yang-management process state
Confd Status: Started
```

Process	Status	State
nesd	Running	Active
syncfd	Running	Active
ncsshd	Running	Not Applicable
dmiauthd	Running	Active
nginx	Running	Not Applicable
ndbmand	Running	Active
pubd	Running	Active

```
Router#show platform software process list r0 name vdaemon
```

```
Name: vdaemon
 Process id : 29075
 Parent process id: 29070
 Group id : 29075
 Status : S
 Session id : 8829
 User time : 263002
 Kernel time : 347183
 Priority : 20
 Virtual bytes : 405110784
 Resident pages : 12195
 Resident limit : 18446744073709551615
```

```
Minor page faults: 716496
Major page faults: 9130
```

**Step 13** If the overlay network is for an enterprise, install the root certificates using the **request platform software sd-routing root-cert-chain install bootflash:cacert.pem** command. If the Cisco SD-WAN Manager is configured with Enterprise Certificates instead of **Cisco PKI**, you must install the root certificate on the device.

**Step 14** Perform one of the following steps based on the device:

- a) For Cisco 8000v device, copy the root certificate from the CA to Cisco 8000v.
- b) Cisco devices are loaded with PKI and symantec root-certificates by default. If you need to install the enterprise root-certificate, install the certificate using the **request platform software sd-routing root-cert-chain install <path-to-root-cert>** command.

**Example:**

```
Device# request platform software sd-routing root-cert-chain install bootflash:ctrl_mng/cacert.pem
```

**Step 15** Install the client enterprise certificates.

**Note** By default, the certificates will be loaded on the hardware devices. This step is only applicable for manually onboarding the software devices.

**Step 16** Generate a Certificate Signed Request (CSR) for the device using the **request platform software sd-routing csr upload <bootflash:ctrl\_mng/test>** command. You can specify any name for the folder that is created within the *bootflash:ctrl\_mng/* directory.

**Step 17** Copy the generated CSR file to the directory where you have the Enterprise CA. You can sign the certificate using the root key and root CA certificate and generate the pem certificate file.

**Step 18** Copy the generated *certificate.pem* file to the device and use the **request platform software sd-routing certificate install <path-to-certificate-file>** command to install the certificate in the device.

**Step 19** Verify the installation status of the certificates.

**Example:**

```
SJC_Primary# show sd-routing local-properties summary
.....
certificate-status Installed
certificate-validity Valid
certificate-not-valid-before Apr 25 00:55:28 2023 GMT
certificate-not-valid-after Apr 24 00:55:28 2024 GMT
.....
dns-name Validator
site-id 100
tls-port 0
system-ip 172.16.255.11
chassis-num/unique-id C8K-aa079ca1-c141-4ac6-9b76-05864005f94e
serial-num 12345707
```

**Step 20** Onboard the device on Cisco SD-WAN Manager. When you install the client certificate, ensure that you add the following in Cisco SD-WAN Manager .

- a) Get the Chassis number and Serial number. To get the Chassis number and Serial number, use the **show sd-routing local-properties** or **show sd-routing certificate serial** command.

```
Router# show sd-routing local-properties summary
chassis-num/unique-id C8K-aa079ca1-c141-4ac6-9b76-05864005f94e
serial-num 12345707
```

- b) Upload the chassis-id using the **request vedge add chassis-num** *<Chassis id>* **org-name** *<Org Name>* **serial-num** *<Serial number from c8kv>* command on all the controllers.

Or

- c) Create a *.viptela* file using the chassis number and serial number and upload the file to Cisco SD-WAN Manager and send to controllers.

**Step 21** Verify the control connection status on Cisco SD-WAN Manager.

**Example:**

Router#**show sd-routing connections summary**

PEER	PEER	PEER		SITE	PEER		PRIV	
PEER					PUB			
TYPE	PROT	SYSTEM IP		ID	PRIVATE IP		PORT	PUBLIC
IP				PORT	STATE	UPTIME		
vmanage	dtls	172.16.255.22		200	10.0.12.22		12446	
10.0.12.22					12446 up	12:05:29:3		

## Onboarding the Device by Activating the Chassis Using the Token

To activate the chassis number, perform these steps:



**Note** This method is supported only on Cisco SD-WAN software devices (Cisco c8000v).

**Step 1** Add the device to Cisco SD-WAN Manager using PnP Smart Sync method.

**Step 2** Go to [software.cisco.com](https://software.cisco.com) > **Network Plug and Play** > **Manage Devices** and ensure that you have access to Smart Account and Virtual Account.

**Step 3** Create a controller profile and upload the **root-ca** if it is for an Enterprise network.

**Step 4** Enter the controller type as vBond and click **Next**.

**Step 5** Enter the required parameters in the **Add Controller Profile** and click **Next**.

**Step 6** Add the device to PnP Connect. When you add the device, in the Device Mode field, select **AUTONOMOUS** for device in SD-Routing mode from the drop-down list.

**Step 7** From the Cisco SD-WAN Manager menu, select **Administration** > **Settings**.

**Step 8** Go to **Smart Account Credentials** and click **Edit**.

**Step 9** Enter the **Username** and **Password** and click **Save**.

**Step 10** You can import the device list from PnP Connect Portal using these methods:

- a) Go to **Configuration** > **Devices** and click **Sync Smart account**.

Or

- a) Upload the *.viptela* that is downloaded from PnP Connect. Go to **Controller profiles** and click **Download the Provisioning file**.

b) From the Cisco SD-WAN Manager menu, choose **Configuration> Devices > Upload WAN Edge List**.

**Step 11** The device will be in autonomous mode with startup config. The device will not be in Day0 mode.

**Step 12** Apply the minimum configuration on the device.

**Example:**

```
netconf-yang
!
sd-routing
 no ipv6-strict-control
 organization-name "vIptela Inc Regression"
 site-id 500
 system-ip 172.16.255.15
 vbond ip 10.0.12.26
 vbond port 12346
 wan-interface GigabitEthernet2
!
ip route 0.0.0.0 0.0.0.0 10.0.5.13
!
ip interface GigabitEthernet2
 ip address 10.0.5.11 255.255.255.0
 no shutdown
!
```

**Step 13** From the Cisco SD-WAN Manager menu, choose **Configuration> Certificates** and get the UUID and One Time Password (OTP) of the device you want to onboard.

**Step 14** To override the chassis number that is generated by the software device, use the **request platform soft sd-routing activate chassis <newly uploaded chassis id> token <token generated by Cisco SD-WAN Manager>** command.

**Step 15** If the overlay network is for an enterprise, install the enterprise-root certificates using the request platform **software sd-routing root-cert-chain install bootflash:cacert.pem** command. If the overlay network is **Cisco PKI**, you do not have to install the root certificate.

**Note** You do not have to generate a Certificate Signing Request (CSR) and sign it. The CSR will be generated while executing the step 14.

**Step 16** Verify the control connection status on the Edge device using these commands:

**Example:**

```
show sd-routing local-properties summary
show sd-routing local-properties wan ipv4
show sd-routing connections summary
show sd-routing connections history
```

## Onboarding the Multi-Tenancy SD-Routing Devices

This section explains the workflows to onboard the Multi-Tenancy SD-Routing devices:

- Automated Onboarding
- Manual Onboarding

### Onboarding the Multi-Tenancy SD-Routing Devices Using Automated Workflow

To onboard the a multi-tenancy SD-Routing device, perform these steps:

- 
- Step 1** Go to [software.cisco.com](https://software.cisco.com) > **Network Plug and Play** > **Manage Devices** and ensure that you have access to Smart Account and Virtual Account.
- Create a virtual account.
  - Create a controller profile and upload the root-ca if it is for an Enterprise network.
  - Enter the controller type as vBond and click **Next**.
  - Enter the required parameters in the **Add Controller Profile** and click **Next**.
  - Add the device to PnP Connect. When you add the device, in the Device Mode field, select **AUTONOMOUS** for device in SD-Routing mode from the drop-down list.
- Or
- Step 2** From the Cisco SD-WAN Manager menu, go to **Workflows** > **Quick Connect**.
- Step 3** Click **Get Started**.
- Step 4** Click **Next**.
- Step 5** If you have not uploaded the .csv file to Cisco SD-WAN Manager, you can use one of the upload options to upload the file. Select **skip for now** option if you have uploaded the file.
- Step 6** Click **Sync Smart account** or **.csv upload** or **.viptela upload**. You should now see your device listed in the table of devices.
- Step 7** For Software device, generate bootstrap file as explained in previous section and add it as c8000v user config file.
- Note** For Multi-tenant setup, the System-IP must be configured only through quick connect workflow. You should not configure the system-IP using the CLI option.
- Step 8** Based on the device type, perform one of these steps:
- For the software device, deploy the Cisco c8000v in Azure or AWS and enter the bootstrap file either as custom data or user data input.
  - For hardware device, bring up the device in Day-0 state. If the device is not in Day-0 state, use either **controller-mode reset** or **writer erase** with **reload** option to bring it to Day-0 state.
- Step 9** The device comes up with the Cisco SD-WAN Manager.
- Step 10** To verify the status of the device, use the **show sd-routing connection summary status** and **show sd-routing local-properties summary** commands.
- 

## Onboarding the Multi-Tenancy SD-Routing Devices Manually

To onboard the Multi-Tenancy SD-Routing device manually, perform these steps:

- 
- Step 1** Deploy the Cisco Catalyst 8000v in Azure or AWS in autonomous mode.
- Go to [software.cisco.com](https://software.cisco.com) > **Network Plug and Play** > **Manage Devices** and ensure that you have access to Smart Account and Virtual Account.
  - Create a virtual account.
  - Create a controller profile and upload the root-ca if it is for an Enterprise network.
  - Enter the controller type as vBond and click **Next**.
  - Enter the required parameters in the **Add Controller Profile** and click **Next**.

- f) Add the device to PnP Connect. When you add the device, in the Device Mode field, select **AUTONOMOUS** for device in SD-Routing mode from the drop-down list.

**Step 2** Configure the minimum parameters to enable Netconf-Yang:

**Example:**

```
config terminal
 netconf-yang
end
```

**Step 3** Check the status of the Netconf-Yang using the **show platform software yang-management process state** command.

**Step 4** Configure the required parameter to enable the Cisco SD-Routing mode:

- Ensure that the interface is configured either with static IP address or through DHCP. Also, the interface must be in **no shut** state.
- Configure either Cisco SD-WAN Validator IP or Cisco SD-WAN Validator name.
- Configure the Cisco SD-WAN Validator, Site-ID, Organization-Name and WAN-Interface.

**Note** For Multi-tenant setup, the System-IP must be configured only through quick connect workflow. You must not configure the System-IP using the CLI option. Also, you do not have to configure the SP Organization Name for SD-Routing devices in Multi-tenant deployment. The organization name refers to tenant's organization name for Multi-tenant deployment. It is visible only under the **show sd-routing local-properties summary** command after the device is onboarded.

**Step 5** Verify that the feature is enabled by checking the status of the vdaemon.

**Example:**

```
Router#show platform software process list r0 name vdaemon
Name: vdaemon
 Process id : 29075
 Parent process id: 29070
 Group id : 29075
 Status : S
 Session id : 8829
 User time : 263002
 Kernel time : 347183
 Priority : 20
 Virtual bytes : 405110784
 Resident pages : 12195
 Resident limit : 18446744073709551615
 Minor page faults: 716496
 Major page faults: 9130
```

**Step 6** Verify the SD-Routing configurations in the Edge device. Also, get the chassis number for signing and upload to Cisco SD-WAN Manager WAN Edge List.

**Step 7** To verify the status of the device, use this **show sd-routing local-properties summary** command.

**Step 8** Copy the root-ca-chain.crt certificate from Cisco SD-WAN Manager into SD-Routing device.

**Note** This step is required only if you are using Enterprise certificate method. You can skip this step if you are using **Cisco PKI** method.

**Step 9** Install the *root-ca-chain.crt* in SD-Routing device.

**Step 10** Upload the provision file (*.Viptela* ) from PnP to Cisco SD-WAN Manager WAN Edge List and send to controllers.

**Step 11** Create a *.viptela* file using the chassis number, serial number and sign it. Upload the file to Cisco SD-WAN Manager and send to controllers.

- Step 12** Get the Token from Cisco SD-WAN Manager. To onboard the device by establishing the control connection with Cisco SD-WAN Validator and Cisco SD-WAN Manager, use the **request platform software sd-routing activate chassis-number <chassis-num> token <token>** command.
- Step 13** To verify the status of the device, use the **show sd-routing connection summary status** and **show sd-routing local-properties summary** commands.

## Onboarding the Device to Cisco SD-WAN Manager Using One Touch Provisioning

To perform the one touch provisioning for a device, follow these steps:

### Before you begin

When you configure a device by using the one touch provisioning, ensure that the process meets these requirements:

- Device must be in autonomous mode. You should stop the PnP discovery and device must have either a start up configuration or any configuration. The device should not be in Day-0 state.
- Device must be configured to reach Cisco SD-WAN Validator and Cisco SD-WAN over the WAN interface.

Device must have the minimum required configuration for SD-Routing feature to communicate with controllers.

Also, onboarding the device to Cisco SD-WAN Manager using One Touch Provisioning method eliminates these steps to add the device:

- Adding WAN Edge device to Cisco SD-WAN Manager by using **.csv** or **.viptela** or **sync smart account**.
- Cisco device must be configured in SD-routing mode. You have to use the Manual or Bootstrap method to configure the device without adding the device to Cisco SD-WAN Manager.

- Step 1** From the Cisco SD-WAN Manager menu, choose **Administration > Settings** and enable One Touch Provisioning.
- Step 2** Check if **One Touch Provisioning** is **Enabled**. If **Enabled**, go to Step 5.
- Step 3** If **One Touch Provisioning** is **Disabled**, click **Edit**.
- Step 4** For the **Enable Claim WAN Edges** setting, choose **Enabled** and click **Save**.
- Step 5** Go to **Configuration > Devices > Unclaimed Devices**.
- Choose the device you wish to claim and click **Claim Device(s)**.
  - The device is removed from **Unclaimed Devices List** and listed on **WAN Edge List**.
- Step 6** To verify the status of the device, use these **show sd-routing system status** , and **show sd-routing local-properties summary** commands.



## Unprovisioning the Feature

To unprovision the feature, perform these steps:

**Step 1** Remove the SD-Routing feature configuration from the device.

**Example:**

**Note** This option will delete all the certificates. You have to reinstall all the certificates.

**Example:**

```
Router#config terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#no sd-routing
Warning! Disabling this feature will result in deleting client certificates. Please backup the
certificates and use the CLIs to reinstall them on enabling this feature again.
Do you want to continue? (y/n)[n]: y
```

**Step 2** Invalidate the device. For instructions, see the step 4 from the [Onboarding the Devices Manually, on page 161](#) section.

**Step 3** To delete the device:

- a) From the Cisco SD-WAN Manager menu, choose **Configuration> Devices**.
- b) Click **WAN Edge List** and choose the device that you want to delete.
- c) Click **Delete WAN Edge**.
- d) Read the message and click **Yes**.

## Software Image Management

This section explains the process to upgrade the software image. Cisco SD-WAN Manager supports uploading a prepackaged Cisco virtual machine image, *tar.gz*, or an image in *qcow2* format. It is mandatory to upload a scaffold file if you choose a *qcow2* image file. Similarly, you can now select either an image package file or a *qcow2* image file with a scaffold file when configuring a Virtual Network Function (VNF) during service chain creation. Cisco SD-WAN Manager communicates with NETCONF that uses a simple Remote Procedure Call to retrieve operational data when an autonomous mode device is onboarded in Cisco SD-WAN Manager. (NETCONF) is a standard transport protocol that communicates with network devices. NETCONF provides mechanisms to edit configuration data. Cisco SD-WAN Manager upgrade workflow for the SD-Routing device is similar to the Controller mode Workflows.



**Note** The minimum software version required for this feature to work is Cisco IOS XE 17.12.1a.

## Software Upgrade Using CLI

To upgrade the software, perform these steps:

**Before you begin**

- Disk Space Check: Checks for available bootflash space for downloading and expanding image.
- Image repository Check: Checks for remote server reachability.
- Auto Boot Enable: Checks if auto boot is enabled on the device.

- 
- Step 1** Download the Cisco IOS XE Release 17.12 image from the software page <https://software.cisco.com>.
- Step 2** Upload the image to the device.
- Step 3** Install the new software using the **install add file <bootflash:/file name> activate commit** command and activate.

**Example:**

```
Device# install add file <bootflash:/c8000v-universalk9.17.12.01.0.166070.SSA.bin activate commit
```

The device reloads when the activation is complete.

**Note** This is an interactive command and it prompts to review and accept it. This command fails if there is any unsaved configuration in the device. You will have to execute the **write memory** command and reinstall the software.

- Step 4** Verify the upgrade using the **install commit** command.
- 

## Add Software Images to the Repository

Before you can upgrade the software on an SD-Routing device or Cisco SD-WAN Manager to a new software version, you need to add the software image to the Cisco SD-WAN Manager software repository. For more information on uploading the Cisco Catalyst 8000v Edge software to Cisco SD-WAN Controller using Cisco SD-WAN Manager and Remote server, see the [Manage Software Repository](#) section of the *Cisco SD-WAN Monitor and Maintain Configuration Guide*.

## Software Upgrade Using Cisco SD-WAN Manager

To upgrade the software image on a device, perform these steps:

**Before you begin**

- This procedure does not enable downgrading to an older software version. If you need to downgrade, see [Downgrade a Cisco vEdge Device to an Older Software Image](#) in the Cisco SD-WAN Getting Started Guide.
- If you want to perform a Cisco SD-WAN Manager cluster upgrade see, [Upgrade Cisco vManage Cluster](#)
- Auto Boot Enable: Checks if auto boot is enabled on device.

- 
- Step 1** From the Cisco SD-WAN Manager menu, choose **Maintenance > Software Upgrade**.
- Step 2** Click **WAN Edge**, **Controller**, or **vManage** based on the type of device for which you wish to upgrade the software.

**Step 3** In the table of devices, select the devices to upgrade by selecting the check box on the far left.

**Note** While upgrading Cisco SD-WAN Manager clusters, select all the nodes of the cluster in the table.

**Step 4** Click **Upgrade**.

**Step 5** In the **Software Upgrade** slide-in pane, do as follows:

- a) Choose the server from which the device should download the image: **vManage**, **Remote Server**, or **Remote Server – vManage**.

- Note**
- If you chose **Remote Server**, ensure that the device can reach the remote server.
  - When downloading an image from a remote server manually, ensure that only the following valid characters are used:
    - User ID: a-z, 0-9, ., \_ , -
    - Password: a-z, A-Z, 0-9, \_ , \*, ., +, =, %, -
    - URL Name or Path: a-z, A-Z, 0-9, \_ , \*, ., +, =, %, -, :, /, @, ?, ~

- b) For **SD-WAN Manager**, choose the image version from the **Version** drop-down list.
- c) For **Remote Server – SD-WAN Manager**, choose the **vManage OOB VPN** from the drop-down list and choose the image version from the **Version** drop-down list.
- d) Check the **Activate and Reboot** check box.

If you do not check this check box, the software image is downloaded and installed on the device, but, the image is not activated, and the device is not rebooted. You must activate the image after the upgrade task is completed.

**Note** The **Activate and Reboot** option is not available while upgrading Cisco SD-WAN Manager software. You must activate the image after the upgrade task is completed and reboot Cisco SD-WAN Manager.

- e) Click **Upgrade**

The device restarts, using the new software version, preserving the current device configuration. The **Task View** page opens, showing the progress of the upgrade on the devices.

**Step 6** Wait for the upgrade process, which takes several minutes, to complete. When the **Status** column indicates Success, the upgrade is complete.

**Step 7** From the Cisco SD-WAN Manager menu, choose **Maintenance > Software Upgrade** and view the devices.

**Step 8** Click **WAN Edge**, **Controller**, or **vManage** based on the type of device for which you wish to upgrade the software.

**Step 9** In the table of devices, confirm that the **Current Version** column for the upgraded devices shows the new version. Confirm that the **Reachability** column says reachable.

- Note**
- If the control connection to Cisco SD-WAN Manager does not come up within the configured time limit, Cisco SD-WAN Manager automatically reverts the device to the previously running software image.
  - If you upgrade the Cisco VEdge software to a version higher than that running on a controller device, a warning message is displayed that software incompatibilities might occur. It is recommended that you upgrade the controller software first before upgrading the Cisco VEdge software.

## Delete a Software Image

To delete a software image from a SD-Routing device:

1. From the Cisco SD-WAN Manager menu, choose **Maintenance > Software Upgrade**.
2. Click **WAN Edge, Controller, or Cisco SD-WAN Manager**.
3. Choose one or more devices from which you want to delete a software image.
4. Click the **Delete Available Software**.  
The **Delete Available Software** dialog box opens.
5. Choose the software version to delete.
6. Click **Delete**.

## View Log of Software Upgrade Activities

1. From the Cisco SD-WAN Manager toolbar, click the **Tasks** icon.  
Cisco SD-WAN Manager displays a list of all running tasks along with the total number of successes and failures.
2. Click the **Arrow** icon to see details of a task. Cisco SD-WAN Manager opens a status window displaying the status of the task and details of the device on which the task was performed.

## Monitoring the Device Using Cisco SD-WAN Manager

The **Monitor** window provides a single-page, real-time user interface that facilitates a consolidated view of all the monitoring components and services of a Cisco SD-Routing devices. You can establish the connection and monitor the device using the following options:

- SSH Terminal
- Ping
- Traceroute

Also, you can collect the system status information in a compressed *.tar* file. Cisco SD-WAN Manager can retrieve and download a *.tar* file from the device. After retrieving the file, you can delete the copy of the file on the device to free up the disk space.

When you enable the SD-Routing mode, this feature is enabled on the device and Cisco SD-WAN Manager by default.

## Monitoring the Device Using SSH

To establish the connection and monitor the device using the SSH option, perform these steps:

- 
- Step 1** From the Cisco SD-WAN Manager menu, choose **Monitor > Devices**.

- Step 2** Choose a device from the list of devices that is displayed.
- Step 3** For a single device, click . . . for the desired device and choose **SSH Terminal**.  
(Or )
- Step 4** From the Cisco SD-WAN Manager menu, choose **tools > SSH Terminal**.
- Step 5** Enter the password twice (same as SD-Routing) in the terminal to establish the connection with the device.
- Step 6** From the terminal, execute the **show commands** to monitor the device.
- 

## Pinging the Device

To ping the device, perform these steps:

- Step 1** From the Cisco SD-WAN Manager menu, choose **Monitor > Devices**.
- Step 2** Choose a device from the list of devices that is displayed.
- Step 3** For a single device, click . . . for the desired device and choose **Ping**.
- Step 4** From the **Monitor** page, enter the destination IP address.
- Step 5** Click **Ping**.
- The results of the ping will be printed in the window below.
- 

## Tracing the Route

To establish the connection and monitor the device using the trace routing option, perform these steps:

- Step 1** From the Cisco SD-WAN Manager menu, choose **Monitor > Devices**.
- Step 2** Choose a device from the list of devices that is displayed.
- Step 3** For a single device, click . . . for the desired device and choose **Trace Route**.
- Step 4** From the **Trace Route** page, enter the destination IP address.
- Step 5** Click the **Start** button to trace the route.
- 

## Alarms and Events

When an even occurs on an individual device in the overlay network, the device reports it by sending a notification to Cisco SD-WAN Manager. Cisco SD-WAN Manager then filters the event notifications and correlates related events, and it consolidates major and critical events into alarms.

Use the Alarms screen to display detailed information about alarms generated by SD-Routing devices in the overlay network.

## Monitoring the Alarms and Events

You can view alarms from the Cisco SD-WAN Manager dashboard by clicking the **Bell** icon at the top-left corner. The alarms are grouped into Active or Cleared. By default, alarms are displayed for the last 24 hours. Alternatively, follow these steps to view alarms from the **Alarms** screen in Cisco SD-WAN Manager.

---

**Step 1** From the Cisco SD-WAN Manager menu, choose **Monitor > Devices > Logs**.

**Step 2** From the Cisco SD-WAN Manager menu, choose **Monitor > Alarms**.

The alarms are displayed in graphical and tabular formats.

**Step 3** To view more details for a specific alarm, click ... for the desired alarm, and then click **Alarm Details**.

The **Alarm Details** window opens and displays the probable cause of the alarm, impacted entities, and other details.

---

## Admin-Tech Files

You can view the generated admin-tech files whenever the admin-tech files are available on a device.

You can view the list of generated admin-tech files and then decide which files to copy from your SD-Routing device to Cisco SD-WAN Manager. You can then download the selected admin-tech files to your local device, or delete the downloaded admin-tech files from Cisco SD-WAN Manager, the device, or both.

## Requesting the Admin-tech File Using Cisco SD-WAN Manager

An Admin-tech file is a collection of system status information used for troubleshooting a given issue. To request a Admin-tech file, perform these steps:

---

**Step 1** From the Cisco SD-WAN Manager menu, choose **Tools > Operational Commands**.

**Step 2** For a single device, click ... for the desired device and choose **Generate Admin Tech**.

**Step 3** In the **Generate admin-tech File** window, limit the contents of the Admin-tech tar file if desired:

- a) The **Include Logs** check box is checked by default. Uncheck this check box to omit any log files from the compressed tar file.
- b) Check the **Include Cores** check box to include any core files.

**Note** The core files are stored in the *bootflash:/core* or *harddisk:/core* directory on the local device.

- c) Check the **Include Tech** check box to include any files related to device processes (daemons), memory details and operations.

**Step 4** Click **Generate**.

Cisco SD-WAN Manager creates the Admin-tech file. The file name format is *hostname-date-time-admin-tech.tar.gz*.

**Step 5** To view the generated Admin-tech file, from the Cisco SD-WAN Manager menu, choose **Tools > Operational Commands > Show Admin Tech List**.

---

## Requesting the Admin-tech File Using CLI

To request a Admin-tech file using CLI, perform these steps:

Use the **request tech-support** command to generate the admin-tech file.

```
Device#request tech-support
21:03:46.447 UTC Thu Aug 10 2023 : Collecting 'show tech-support'...
21:04:51.880 UTC Thu Aug 10 2023 : 'show tech-support' collected successfully!
21:04:55.091 UTC Thu Aug 10 2023 : Collecting binary traces...
21:04:55.216 UTC Thu Aug 10 2023 : Binary traces collected successfully!
21:04:55.219 UTC Thu Aug 10 2023 : Collecting platform-dependent files...
21:05:43.467 UTC Thu Aug 10 2023 : Platform-dependent files collected successfully!
21:05:43.475 UTC Thu Aug 10 2023 : Generating tech-support bundle...
21:05:56.648 UTC Thu Aug 10 2023 : Tech-support bundle file
bootflash:core/1HX-2017-debug_bundle_20230810-210346-UTC.tar.gz [size: 8648 KB]
21:05:56.648 UTC Thu Aug 10 2023 : Tech-support bundle generated successfully!

1HX-2017#
1HX-2017#dir bootflash:core
Directory of bootflash:/core/

1471682 -rw- 1 Aug 11 2023 04:26:51 +00:00 .callhome
45 -rw- 25429 Aug 10 2023 21:05:56 +00:00
1HX-2017_RP_0-debug_bundle_20230810-210346-UTC-info.txt
49 -rw- 8854997 Aug 10 2023 21:05:54 +00:00
1HX-2017-debug_bundle_20230810-210346-UTC.tar.gz
1471685 drwx 4096 Mar 22 2021 20:03:54 +00:00 modules

29633794048 bytes total (16795193344 bytes free)
1HX-2017#
```

## Monitoring the Real Time Data

To ping the device, perform these steps:

- Step 1** From the Cisco SD-WAN Manager menu, choose **Monitor > Devices**.
  - Step 2** Choose a device from the list of devices that is displayed.
  - Step 3** For a single device, click ... for the desired device and choose **Real Time**.
  - Step 4** Select the category of data from the **Device Options** drop-down list.
- The results will be displayed.

## Configuration Examples

This section provides the configuration examples.

## Example: Enabling Control Connection on Cisco SD-WAN Manager

This example shows how to enable control connection on Cisco SD-WAN Manager:

```
(config) sd-routing
(config-sd-routing) system-ip 172.16.255.15
(config-sd-routing) organization-name viptela
(config-sd-routing) vbond ip 10.0.12.26
(config-sd-routing) site-id 500
(config-sd-routing) wan-interface GigabitEthernet2
```

## Example: Verifying the Enable Control Connection

Use the **show platform software yang-management process state** command to check the connection status.

```
Device#show platform software yang-management process state
ConfD Status: Started
```

Process	Status	State
nesd	Running	Active
syncfd	Running	Active
ncsshd	Running	Not Applicable
dmiauthd	Running	Active
nginx	Running	Not Applicable
ndbmand	Running	Active
pubd	Running	Active

Use the **show platform software yang-management process list r0 name vdaemon** command to check the vdaemon status.

```
Device#show platform software process list r0 name vdaemon
Name: vdaemon
 Process id : 29075
 Parent process id: 29070
 Group id : 29075
 Status : S
 Session id : 8829
 User time : 263002
 Kernel time : 347183
 Priority : 20
 Virtual bytes : 405110784
 Resident pages : 12195
 Resident limit : 18446744073709551615
 Minor page faults: 716496
 Major page faults: 9130
```

## Example: Installing the Root Certificate

This examples shows how to install the root certificate:

```
Device# request platform software sd-routing root-cert-chain install bootflash:root-ca.crt
```

## Example: Verifying the Root Certificate Installation

Use the **show sd-routing local-properties summary** command to check the root certificate installation status.



```

Device#show sd-routing local-properties summary
personality vedge
sp-organization-name vIPtela Inc Regression
organization-name vIPtela Inc Regression
root-ca-chain-status Installed
root-ca-crl-status Not-Installed

Device#show sd-routing local-properties summary
certificate-status Installed
certificate-validity Valid
certificate-not-valid-before Apr 25 00:55:28 2023 GMT
certificate-not-valid-after Apr 24 00:55:28 2024 GMT
.....
dns-name vbond
site-id 100
tls-port 0
system-ip 172.16.255.11
chassis-num/unique-id C8K-aa079cal-c141-4ac6-9b76-05864005f94e
serial-num 12345707

```

## Troubleshooting

This section provides commands that can be used to troubleshoot the common issues while managing and monitoring the SD-Routing devices using Cisco SD-WAN Manager:

- **Show version**



**Note** The operating mode is included in **show version** command.

```

When sd-routing feature is enabled:
Device#show version | include mode
Router operating mode: Autonomous (SD-Routing)
Device#

When sd-routing feature is not enabled:
Device#show version | include mode
Router operating mode: Autonomous
Device#

```

- **show platform software yang-management process state**
- **show sd-routing system status**
- **show sd-routing connections summary**
- **show platform software process list r0 name vdaemon**
- **show sd-routing local-properties summary**
- **show sd-routing local-properties wan ipv4**
- **show sd-routing local-properties vbond**
- **show sd-routing connections history**

## Feature Information for Managing SD-Routing Devcies Using vManage

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.

**Table 22: Feature Information for SD-Routing Devcies Using Cisco SD-WAN Manager**

Feature Name	Releases	Feature Information
Managing SD-Routing Devices Using Cisco SD-WAN Manager	Cisco IOS XE Release 17.12.1a	This feature allows you to perform management operations for SD-Routing devices using Cisco SD-WAN Manager. You can use a single network manage system (Cisco SD-WAN Manager) to monitor all the SD-Routing devices and therefore help in simplifying solution deployments.



## CHAPTER 17

# Web User Interface Management

You can access your router using a web user interface which allows you to monitor the performance of the router using an easy-to-read graphical interface.



**Note** To manage and configure crypto map tunnels, use the CLI. You can also configure the tunnels with Virtual Tunnel Interface (VTI) and then create the tunnels either by using the CLI or the GUI.

You can configure a router by performing the steps in one of the following tasks:

- [Setting Up Factory Default Device Using WebUI , on page 179](#)
- [Using Basic or Advanced Mode Setup Wizard, on page 180](#)

## Setting Up Factory Default Device Using WebUI

Quick Setup Wizard allows you to perform the basic router configuration. To configure the router:

### Before you begin

- Before you access the WebUI, you need to have the basic configuration on the device.

**Step 1** Connect the RJ-45 end of a serial cable to the RJ-45 console port on the router.

**Step 2** After the device initial configuration wizard appears, enter **No** to get into the device prompt when the following system message appears on the router.

Would you like to enter the initial configuration dialog? [yes/no]: no

**Step 3** From the configuration mode, enter the following configuration parameters.


```
!
ip dhcp pool WEBUIPool
network 192.168.1.0 255.255.255.0
default-router 192.168.1.1
username webui privilege 15 password cisco
!
interface gig 0/0/1
ip address 192.168.1.1 255.255.255.0
!
```

- Step 4** Connect your device to the router using an Ethernet cable to the gig 0/0/1 interface.
- Step 5** Set up your system as a DHCP client to obtain the IP address of the router automatically.
- Step 6** Launch the browser and enter the device IP address in your browser's address line. For a secure connection, type <https://192.168.1.1/#/dayZeroRouting>. For a less secure connection, enter <http://192.168.1.1/#/dayZeroRouting>.
- Step 7** Enter the default username (webui) and default password (cisco).

## Using Basic or Advanced Mode Setup Wizard

To configure the router using the basic or advanced mode setup:

- Step 1** Choose the **Basic Mode** or **Advanced Mode** and click **Go To Account Creation Page**.
- Step 2** Enter the username and password. Reenter the password to confirm.
- Step 3** Click **Create and Launch Wizard**.
- Step 4** Enter the device name and domain name.
- Step 5** Select the appropriate time zone from the **Time Zone** drop-down list.
- Step 6** Select the appropriate date and time mode from the **Date and Time** drop-down list.
- Step 7** Click **LAN Settings**.



## Configure LAN Settings

- Step 1** Choose the **Web DHCP Pool/DHCP Pool** name or the **Create and Associate Access VLAN** option.
- a) If you choose the Web DHCP Pool, specify the following:
- Pool Name**—Enter the DHCP Pool Name.
- Network**—Enter network address and the subnet mask.

- b) If you choose the Create and Associate Access VLAN option, specify the following:

**Access VLAN**—Enter the Access VLAN identification number. The range is from 1 to 4094.

**Network**—Enter the IP address of the VLAN.

**Management Interfaces**—Select the interface and move to the selected list box using the right and left arrows. You can also double click or drag and drop to move the interface to the selected list box.

**Step 2** Click **Primary WAN Settings**.

## Configure Primary WAN Settings

- Step 1** Select the primary WAN type. You can configure Serial, 3G/4G, Ethernet, or Broadband (xDSL) as primary WAN depending on the WAN types supported by the router.
- Step 2** Select the interface from the drop-down list.
- Step 3** Check the **Get DNS Server info directly from ISP** check box to get the DNS server information directly from the service provider. You can also manually enter the Primary DNS and Secondary DNS.
- Step 4** Check the **Get IP automatically from ISP** check box to get the IP address information directly from the service provider. You can also manually enter the IP address and subnet mask.
- Step 5** Check the **Enable NAT** check box to enable NAT. It is recommended to enable NAT.
- Step 6** Check the **Enable PPPOE** check box to enable PPPoE. If you have enabled PPPoE, select the required authentication mode. The options are: **PAP** and **CHAP**.
- Step 7** Enter the username and password provided by the service provider.
- Step 8** Click **Security / APP Visibility WAN Settings**.

## Configure Secondary WAN Settings


## Configure Secondary WAN Settings


For advanced configuration, you should configure the secondary WAN connection.


- Step 1** Select the secondary WAN type. You can configure Serial, 3G/4G, Ethernet, or Broadband (xDSL) as a secondary WAN depending on the WAN types supported by the router.
- Step 2** Select the interface from the drop-down list.
- Step 3** Check the **Get DNS Server info directly from ISP** check box to get the DNS server information directly from the service provider. You can also manually enter the Primary DNS and Secondary DNS.
- Step 4** Check the **Get IP automatically from ISP** check box to get the IP address information directly from the service provider. You can also manually enter the IP address and subnet mask.
- Step 5** Check the **Enable NAT** check box to enable NAT. It is recommended to enable NAT.
- Step 6** Check the **Enable PPPOE** check box to enable PPPoE. If you have enabled PPPoE, select the required authentication mode. The options are **PAP** and **CHAP**.
- Step 7** Enter the username and password provided by the service provider.
- Step 8** Click **Security / APP Visibility WAN Settings**.


## Configure Security Settings


- Step 1** Check the **Enable Cisco Recommended Security Settings** check box to ensure that all passwords are not shown in plain text. The passwords are encrypted.
- Step 2** Click **Day 0 Config Summary**.
- Step 3** To preview the configuration, click **CLI Preview** to preview the configuration.
- Step 4** Click **Finish** to complete the Day Zero setup.


  
BASIC

  
LAN

  
PRIMARY WAN

  
Wi-Fi

  
SECURITY / APP VISIBILITY

  
SUMMARY

SUMMARY

CLI Preview

This screen provides the summary of all the steps configured as a part of the day zero configuration. Please click Finish to configure the device.

> Basic	✓ Router Name: geo, ✓ Domain Name: mydomain.com, ✓ Time Zone: 5:30, ✓ Date & Time Mode: Automatic
> LAN	✓ LAN Interface: , ✓ IP Address: , ✓ Subnet Mask: , ✓ Use as DHCP Server: Yes, ✓ Pool Name: , ✓ Network: (), ✗ Management Interface Configured: No
> Primary WAN	✓ WAN Interface: , ✓ IP Address: Automatic, ✓ DNS: Automatic, ✓ NAT: Enabled
> Wi-Fi	✗ Wi-Fi Configuration:
> Security / App Visibility	✓ Cisco recommended security settings: Enabled, ✗ Application Visibility: Disabled

< SECURITY / APP VISIBILITY

Finish >







## CHAPTER 18

# Accessing and Using the GRUB Mode

Cisco Catalyst 8000V has a 16-bit configuration register in NVRAM. Each bit has the value 1 (on or set) or value 0 (off or clear), and each bit setting affects the router behavior upon the next reload power cycle. The GRUB mode supports a subset of configuration register options which is comparable to the ROMMON options on other Cisco routers.

You can use the configuration register to:

- Force the router to boot into the GRUB mode (bootstrap program)
- Select a boot source and the default boot filename
- Recover a lost password

The following table describes the configuration register bits.

**Table 23: Configuration Register Bit Descriptions**

BitNumber	Hexadecimal	Meaning
00–03	0x0000–0x000F	Boot field. The boot field setting determines whether the router loads an operating system and where it obtains the system image.  See the table "Boot Field Configuration Register Bit Descriptions" for details.
06	0x0040	Causes the system software to ignore the contents of NVRAM. This can be used for password recovery.



**Note** Entering the GRUB mode for Cisco Catalyst 8000V running on cloud solutions depends on the console access capabilities of the cloud provider. If the cloud provider provides limited access to console, you cannot access the GRUB mode for password recovery.



**Note** Use the 0x000 setting to configure the router to automatically enter the GRUB mode when the router reboots.

- [Accessing the GRUB Mode, on page 186](#)
- [Using the GRUB Menu, on page 187](#)
- [Modifying the Configuration Register \(confreg\), on page 189](#)
- [Changing the Configuration Register Settings, on page 190](#)
- [Displaying the Configuration Register Settings, on page 191](#)

## Accessing the GRUB Mode

Perform the following step to access the GRUB mode:

### Step 1 **enable**

**Example:**

```
Router> enable
```

Enables the privileged EXEC mode.

- Enter your password, if prompted.

### Step 2 **config-register 0x0000**

**Example:**

```
Router# config-register 0x0000
```

Enters the GRUB mode by entering the “0000” value (0x0).

The following shows an example of entering GRUB mode.

```
Router(config)# config-register 0x0000
```

```
GNU GRUB version 2.02
```

```
Minimal BASH-like line editing is supported. For the first word, TAB
lists possible command completions. Anywhere else TAB lists possible
device or file completions. ESC at any time exits.
```

```
grub> confreg 0x2102
```

If you enter a question mark at the grub> prompt, the system shows you the two options available - for either viewing the system help or for entering the **config register** command.

# Using the GRUB Menu

The GRUB menu is used to display the software images loaded on the router, and to select which image to boot from. To access the GRUB menu, enter **ESC** at the GRUB prompt. The following shows the GRUB menu display.

Select the image to boot the router from using the up and down arrow key. To return to the GRUB prompt, enter the letter **c**.

## Entering the GRUB Mode and Selecting the Image

To load the new system image from the GR and Unified Bootloader (GRUB) mode, follow these steps, beginning in EXEC mode.

---

### Step 1 **dir bootflash:**

Use this command to display a list of all files and directories in bootflash memory:

#### **Example:**

```
Router# dir bootflash:

Directory of bootflash:/
 3 -rw- 6458388 Dec 18 2020 00:00:58 c8000v.tmp
1580 -rw- 6462268 Dec 18 2020 06:14:02 c8000v-ata
63930368 bytes total (51007488 bytes free)
```

### Step 2 **configure terminal**

Use this command to enter the global configuration mode:

#### **Example:**

```
Router# configure terminal
Router(config)#
```

### Step 3 **boot system bootflash:system-image-filename.bin**

Use this command to load the new system image after the next system reload or power cycle. For example:

#### **Example:**

```
Router(config)# boot system bootflash:
c8000v-universalk9.17.04.01a.SPA.bin
```

**Note** If the new system image is the first file or the only file displayed in the **dir bootflash:** command output, you do not need to perform this step.

### Step 4 **do write**

or

**do write memory**

#### **Example:**

```
Router(config)# do write memory
```

**Note** Entering the **do write** or **do write memory** command updates the GRUB menu list of images available on the bootflash disk.

### Step 5 **config-register 0x0000**

Use this command to enter the GRUB mode.

The following shows a sample configuration output of entering the GRUB mode.

#### **Example:**

```
GNU GRUB version 2.02
```

```
Minimal BASH-like line editing is supported. For the first word, TAB
lists possible command completions. Anywhere else TAB lists possible
device or file completions. ESC at any time exits.
```

```
grub> confreg 0x2102
```

#### **Example:**

**Note** If you set the config-register to 0x0000, you should reset it back to the default of 0x2102 for the system to autoboot. If the value is 0x0, the system stops in the GRUB mode.

### Step 6 At the **grub>** prompt, enter ESC to access the GRUB menu.

The system displays the GRUB menu with the images that are available to boot.

#### **Example:**

```
Cisco IOS XE Software, Version 2020-09-17_09.24_kamitch
Cisco IOS Software [Bengaluru], Virtual XE Software (X86_64_LINUX_IOSD-UNIVERSALK9-M), Experimental
Version 17.5.20200916:194029 [HEAD-/scratch/kamitch/git/polaris-work/boottime1 106]
Copyright (c) 1986-2020 by Cisco Systems, Inc.
Compiled Wed 16-Sep-20 15:45 by kamitch
```

```
Cisco IOS-XE software, Copyright (c) 2005-2020 by cisco Systems, Inc.
All rights reserved. Certain components of Cisco IOS-XE software are
licensed under the GNU General Public License ("GPL") Version 2.0. The
software code licensed under GPL Version 2.0 is free software that comes
with ABSOLUTELY NO WARRANTY. You can redistribute and/or modify such
GPL code under the terms of GPL Version 2.0. For more details, see the
documentation or "License Notice" file accompanying the IOS-XE software,
or the applicable URL provided on the flyer accompanying the IOS-XE
software.
```

```
ROM: IOS-XE ROMMON
```

```
Router uptime is 18 minutes
Uptime for this control processor is 21 minutes
System returned to ROM by reload
System image file is "bootflash:packages.conf"
```

Select the image to boot the router by using the up and down arrow key. To return to the GRUB prompt, enter the letter **c**.

### Step 7 Select the .bin file to upgrade the software image on the router to the new version.

**Step 8** Press **Enter** to boot the selected image which begins the upgrade process.

## Modifying the Configuration Register (confreg)

This section describes how to modify the configuration register by using the **confreg** GRUB command. This command is similar to the **confreg** ROMMON command on other Cisco hardware routers. Because the router does not include a ROMMON mode, the similar functionality is handled in GRUB command mode.

You can also modify the configuration register setting from the Cisco IOS XE CLI by using the **config-register** command in global configuration mode.



**Note** The modified configuration register value is automatically written into NVRAM, but the new value does not take effect until you reset or power-cycle the router.

**confreg** [*value*]

### Example:

```
grub> confreg 0x2102
```

Changes the configuration register settings while in GRUB command mode.

- Optionally, enter the new hexadecimal value for the configuration register. The value range is from 0x0 to 0xFFFF.
- If you do not enter the value, the router prompts for each bit of the 16-bit configuration register.

### What to do next

The following code is an example of entering the GRUB mode and using the configuration register. You access the GRUB mode by entering the Cisco IOS XE **config-register** command and specifying the value as “0000”.

```
Router(config)# config-register 0x0000

GNU GRUB version 0.97 (638K lower / 3143616K upper memory)
[Minimal BASH-like line editing is supported. For the first word, TAB
 lists possible command completions. Anywhere else TAB lists the possible
 completions of a device/filename. ESC at any time exits to menu.]
grub> help
[Minimal BASH-like line editing is supported. For the first word, TAB
 lists possible command completions. Anywhere else TAB lists the possible
 completions of a device/filename. ESC at any time exits to menu.]
confreg [VALUE] help [--all] [PATTERN ...]
grub> confreg
Configuration Summary
(Virtual Configuration Register: 0x0)
enabled are:
boot: the boot loader
```

```

do you wish to change the configuration? y/n [n
]:
ignore system config info? y/n [n
]:
automatically boot default system image? y/n [n
]:
Configuration Register: 0x0
grub> confreg
 Configuration Summary
(Virtual Configuration Register: 0x0)
enabled are:
boot: the boot loader
do you wish to change the configuration? y/n [n
]:
ignore system config info? y/n [n]:
automatically boot default system image? y/n [n]:
Configuration Register: 0x42
grub> confreg 0x2102
Configuration Register: 0x2102
grub> confreg
 Configuration Summary
(Virtual Configuration Register: 0x2102)
enabled are:
boot: default image
do you wish to change the configuration? y/n [n
]:
grub>
grub>
GNU GRUB version 2.02 (638K lower / 3143616K upper memory)

0: C8000v - packages.conf
1: C8000v - c800v-packages-universalk9
2: C8000v - GOLDEN IMAGE

Use the ^ and v keys to select which entry is highlighted.
Press enter to boot the selected OS, or 'c' for a command-line.
Highlighted entry is 0:
Booting 'C8000v - packages.conf'
root (hd0,0)
Filesystem type is ext2fs, partition type 0x83
kernel /packages.conf rw root=/dev/ram console=ttyS1,9600 max_loop=64 HARDWARE=
virtual SR_BOOT=harddisk:packages.conf
Calculating SHA-1 hash...done
SHA-1 hash:
 calculated 817e1716:e8e62778:7dd0b806:32db2bdd:13e51407
 expected 817e1716:e8e62778:7dd0b806:32db2bdd:13e51407
package header rev 1 structure detected
Calculating SHA-1 hash...done
SHA-1 hash:
 calculated d4eaba99:34cbda63:26151233:9d0e9aa4:9c625302
 expected d4eaba99:34cbda63:26151233:9d0e9aa4:9c625302
Package type:0x7531, flags:0x0
[Linux-bzImage, setup=0x2e00, size=0x2c18c00]
[isord @ 0x7e6d0000, 0x191f000 bytes]

```

## Changing the Configuration Register Settings

You can change the configuration register settings from either the GRUB or the Cisco IOS XE CLI. This section describes how to modify the configuration register settings from the Cisco IOS XE CLI.

To change the configuration register settings from the Cisco IOS XE CLI, complete the following steps:

**Step 1** Power on the router.

**Step 2** If you are asked whether you would like to enter the initial dialog, answer no:

**Example:**

```
Would you like to enter the initial dialog? [yes]: no
```

After a few seconds, the system displays the user EXEC prompt ( Router> ).

**Step 3** Enter the privileged EXEC mode by typing enable, and if prompted, enter your password:

**Example:**

```
Router> enable
Password: password
Router#
```

**Step 4** Enter the global configuration mode:

**Example:**

```
Router# configure terminal
Enter configuration commands, one per line.
Edit with DELETE, CTRL/W, and CTRL/U; end with CTRL/Z
```

**Step 5** To change the configuration register settings, enter the **config-register** *value* command, where *value* is a hexadecimal number preceded by **0x**:

**Example:**

```
Router(config)# config-register 0x
value
```

**Step 6** Exit the global configuration mode:

**Example:**

```
Router(config)# end
Router#
```

**Step 7** Save the configuration changes to NVRAM:

Router# **copy running-config startup-config**

The new configuration register settings are saved to NVRAM, but they do not take effect until the next router reload or power cycle.

## Displaying the Configuration Register Settings

To display the configuration register settings that are currently in effect and the settings that will be used at the next router reload, enter the **show version** command in privileged EXEC mode.

The configuration register settings are displayed in the last line of the **show version** command output:

```
Configuration register is 0x142 (will be 0x142 at next reload)
```





## CHAPTER 19

# Performing a Factory Reset

This chapter provides information on performing a factory reset for Cisco Catalyst 8000V. The factory reset feature helps remove any sensitive information from the router, or to reset the router to a fully functional state.

- [Information About Factory Reset, on page 193](#)
- [Prerequisites for Performing Factory Reset, on page 194](#)
- [Restrictions for Performing a Factory Reset, on page 194](#)
- [How to Perform a Factory Reset, on page 194](#)

## Information About Factory Reset

The factory reset is a process of clearing the current running and start up configuration information on a router, and resetting the router to an earlier, fully functional state. The factory reset process uses the **factory-reset all** command.



**Note** The time taken for factory reset on a Cisco Catalyst 8000V instance is dependent on factors such as the type of storage and the devices present on the router.

### Information deleted:

When you perform a factory reset, the following information is deleted:

- Licenses – user installed, and manufacturer provided
- Non-volatile random-access memory data
- User credentials
- Start-up configuration
- All writable file systems and personal data
- ROMMON variable
- Persistent storage devices
- Any containers running on bootflash

**Information retained:**

However, the following information will be retained even after the factory reset:

- Critical information including files that provide access to the router after the reset is complete
- The software packages that are installed before you perform factory reset
- UDI and Smart Licensing files

**Supported Scenarios:**

You can use the factory reset feature in the following scenarios:

- When you want to delete a Cisco Catalyst 8000V instance in a secure manner.
- If the router data is compromised due to a malicious attack, you must reset the router to factory configuration and then reconfigure once again for further use.

**Supported Platforms:**

Factory reset is supported on a Cisco Catalyst 8000V instance running on all the platforms including Amazon Web Services, Microsoft Azure, GCP cloud, VMware ESXi, and Hyper-V.

## Prerequisites for Performing Factory Reset

- Ensure that you take a backup of all the software images, configurations and personal data before performing the factory reset operation.
- Ensure that there is uninterrupted power supply when the feature reset process is in progress.
- Ensure that the instance has at least 8 GB memory in the bootflash.

## Restrictions for Performing a Factory Reset

- Any software patches that are installed on the router are not restored after the factory reset operation.
- You must not restart the Cisco Catalyst 8000V instance during the factory reset process.
- If the factory reset command is issued through a Virtual Teletype (VTY) session, the session is not restored after the completion of the factory reset process.

## How to Perform a Factory Reset

- 
- Step 1** Log in to a Cisco Catalyst 8000V instance.
- Step 2** At the command prompt, execute the **factory-reset all** command.
- The system displays the following:

```

factoryreset#factory-reset all
The factory reset operation is irreversible for all operations. Are you sure? [confirm]
The following will be deleted as a part of factory reset:
1: All writable file systems and personal data
2: Licenses
3: Configuration
4: User Credentials
The system will reload to perform a factory reset.
Note that any day0 configuration will be applied after reload
DO NOT STOP OR INTERRUPT THE POWER DURING RESET
Are you sure you want to continue? [confirm]Connection to 172.18.25.29 closed by remote host.
Connection to 172.18.25.29 closed.

```

**Step 3** Enter confirm to proceed with the factory reset.

**Note** The time taken for the factory reset process depends on the type of storage and on which cloud service you deploy the Cisco Catalyst 8000V instances.

**Note** If you want to quit the factory reset process, press the **Escape** key.

---

### What to do next

After the factory reset process is completed, you receive a log file in the bootflash that indicates whether the process was successful or not.

## Restoring Smart Licensing after a Factory Reset

After the reset, Smart Licensing configuration is also deleted. You must reconfigure Smart Licensing on the router by using the token ID. In the connected mode, when you register your instance for Smart Licensing, you must use the force option. That is, you must use the **license smart register idtoken \*\*\*\*\*token\*\*\*\*\* force** command. The registration process begins.

When you do not use the force option, and configure Smart Licensing directly, the license registration fails. The following is an example of a failed registration output:

```

router#show license status
router#show license status
Smart Licensing is ENABLED

Utility:
 Status: DISABLED

Data Privacy:
 Sending Hostname: yes
 Callhome hostname privacy: DISABLED
 Smart Licensing hostname privacy: DISABLED
 Version privacy: DISABLED

Transport:
 Type: Callhome

Registration:
 Status: UNREGISTERED - REGISTRATION FAILED
 Export-Controlled Functionality: NOT ALLOWED
 Initial Registration: FAILED on Feb 15 22:03:29 2019 UTC
 Failure reason: The product
regid.2013-08.com.cisco.C8KV,1.0_1562da96-9176-4f99-a6cb-14b4dd0fa135 and sudi containing

```

```
udiSerialNumber:9XIVK9PIVPK,udiPid:C8000V has already been registered.
```

```
License Authorization:
 Status: No Licenses in Use
```

```
Export Authorization Key:
 Features Authorized:
```

After you execute the license smart register idtoken \*\*\*\*\*token\*\*\*\*\* force command, the license goes to the Registered state. The following is an example of a configuration output in the Registered state:

```
router#show license status
Smart Licensing is ENABLED
```

```
Utility:
 Status: DISABLED
```

```
Data Privacy:
 Sending Hostname: yes
 Callhome hostname privacy: DISABLED
 Smart Licensing hostname privacy: DISABLED
 Version privacy: DISABLED
```

```
Transport:
 Type: Callhome
```

```
Registration:
 Status: REGISTERED
 Smart Account: InternalTestDemoAccount8.cisco.com
 Virtual Account: RTP-CSR-DT-Prod
 Export-Controlled Functionality: ALLOWED
 Initial Registration: SUCCEEDED on Feb 15 22:04:07 2019 UTC
 Last Renewal Attempt: None
 Next Renewal Attempt: Dec 14 22:04:06 2020 UTC
 Registration Expires: Dec 15 21:59:05 2021 UTC
```

```
License Authorization:
 Status: AUTHORIZED on Dec 15 22:04:11 2020 UTC
 Last Communication Attempt: SUCCEEDED on Feb 15 22:04:11 2019 UTC
 Next Communication Attempt: Dec 17 22:04:11 2020 UTC
 Communication Deadline: Dec 16 21:58:10 2020 UTC
```

```
Export Authorization Key:
 Features Authorized:
 <none>
```

## What Happens after a Factory Reset

After the factory reset is successfully completed, the router boots up. However, before the factory reset process started, if the configuration register was set to manually boot from ROMMON, the router stops at ROMMON.



### Important

If the current boot image is a remote image or is stored in a USB or a NIM-SSD, ensure that you take a backup of the image before starting the factory reset process.

Factory reset does not change the UDI of the Cisco Catalyst 8000V instance. To verify whether the UDI is the same after the factory reset, execute the **factoryreset#show license udi** command before and after the factory reset process.

After you configure Smart Licensing, execute the **#show license status** command, to check whether Smart Licensing is enabled for your instance.



---

**Note** If you had SLR enabled before you performed the factory reset, use the same license and enter the same license key that you received from the smart agent.

---





## CHAPTER 20

# Configuring VRF Route Sharing

The following chapter describes how you can configure VRF Route Sharing on a Cisco Catalyst 8000V instance. VRF Route Sharing is required when you need to forward traffic between an On-Premise Site and a Public Cloud Site. Configure VRF Route Sharing across VxLAN peers to deploy shared services across the cloud.

- [Information About VRF Route Sharing, on page 199](#)
- [Prerequisites of VRF Route Sharing, on page 199](#)
- [Restrictions for VRF Route Sharing, on page 200](#)
- [How to Configure VRF Route Sharing, on page 200](#)
- [Verifying VRF Route Sharing, on page 203](#)

## Information About VRF Route Sharing

In a hybrid cloud solution where there is an APIC layer (On-Premise) and a Public Cloud Site, the Cisco Catalyst 8000V instance connects the Data Centers through Layer-3 boundaries. The Cisco Catalyst 8000V instance has a VRF instance configured with two sets of import and export route-targets. One set of the import/export route target is associated with the BGP EVPN session with VXLAN encapsulation and L3 routing information in the On-Premise router. The other set of import/export route-target is associated with the L3VPN BGP neighbour in the service provider network. The Cisco Catalyst 8000V instance enables the L3 traffic movement across the EVPN by stitching the route between the On-Premise site and the service provider network.

The Cisco Catalyst 8000V instance forwards traffic across the EVPN even if the VRFs have the same VTEP IP (VxLAN tunnel endpoint) and RMAC (router MAC address). With this feature, the Cisco Catalyst 8000V instance uses a binding label to setup the routing and forwarding chain.

Using the VRF Route Sharing functionality, you can deploy shared services across hybrid clouds. The shared services that run on the public cloud can be consumed by the endpoints on the On-Premise Site. The Cisco Catalyst 8000V instance shares the L3 prefix to multiple VRFs on the On-Premise Site, and vice versa. The APIC layer imports the addresses and the services are thus consumed in the APIC side.

## Prerequisites of VRF Route Sharing

Before you configure the VRF Route Sharing functionality to enable the traffic between the ACI and the public cloud, ensure that:

- You configure VRF1 and VRF2 on the vPC pair of ACI.
- VRF3 and VRF4 on the Cisco Catalyst 8000V instance which peers with VGW have two RTs for each VRF.
- The Cisco Catalyst 8000V instance imports EVPN routes of VRF1&2 from ACI into VRF3&4.
- The IP BGP on the Cisco Catalyst 8000V side redistributes the routes to the gateway in the public cloud.
- The next-hop of routes from ACI are the spine of the border leaf of the ACI.
- There are no overlaps of prefix across the Route Sharing VRF.
- Advertise the L3 VPN routing and to forward the VRF prefixes to the EVPN neighbours. Run the advertise l2vpn evpn command and export stitching RTs to push the native routes towards the EVPN.

## Restrictions for VRF Route Sharing

- The VRF Sharing functionality supports up to 32 common VRFs, and 1000 customer VRF combination.
- This functionality does not support RT filters.
- VRF Route Sharing is supported only for IPv4 addresses and not IPv6 addresses.

## How to Configure VRF Route Sharing

### Sample Topology and Use Cases

Consider a sample topology to explain the VRF Route Sharing in a hybrid cloud. In a sample topology, assume the Cisco Catalyst 8000V instance is deployed on the VM of the public cloud. Site A is an ACI deployment site, while Site B is the public cloud. Leaf 1 and Leaf 2 are the Virtual Port Channel (vPC) pair for ACI. These two vPCs are configured with different Route Distinguishers (RD). Here, VRF 1 and VRF 2 are configured on the vPC pair for ACI. For example,

VRF1 - RT:RT-EVPN-1, prefix:192.168.1.1

VRF2 - RT:RT-EVPN-2, prefix:192.168.2.2

VRF3 and VRF4 are configured on the Cisco Catalyst 8000V instance. These two VRFs pair with the Voice Gateway (VGW), and these two VRFs have two different Route Targets (RT). For example,

VRF3 – RT for EVPN: RT-EVPN-3, RT for IP BGP: RT-3, prefix:192.168.3.3

VRF4 – RT for EVPN: RT-EVPN-4, RT for IP BGP: RT-4, prefix:192.168.4.4

In the topology, the BGP-EVPN fabric is present between the ACI and the Cisco Catalyst 8000V instance in the public cloud and the IP BGP protocol is used between the Cisco Catalyst 8000V instance and the Cloud Service Provider such as Azure. The BGP-EVPN fabric redistributes the stitching routes between the EVPN and the IP BGP.

To enable the traffic flow between the ACI Site and the Public Cloud, both ACI and the Cisco Catalyst 8000V instance need to support VRF Route Sharing.



The Cisco Catalyst 8000V instance must be able to import the EVPN routes of VRF1 and VRF2 from ACI into VRF3 and VRF4. The IP BGP on the Cisco Catalyst 8000V side then redistributes the routes to the VGW in the public cloud.



**Note** When the VTEP (VxLAN Tunnel Endpoint) IP and the RMAC (Route MAC address) are the same for two leafs, and the VNIC alone differs, the Cisco Catalyst 8000V instance can forward the traffic across the tunnel.

### Use Cases

Using the same sample topology, here are the use cases for configuring VRF Route Sharing in a Cisco Catalyst 8000V instance:

- When VRF1 and VRF2 can talk to VRF3, but VRF3 and VRF4 cannot talk to each other, perform the following configuration:

```
vrf definition VRF3
rd 300:1
address-family ipv4
route-target export RT-EVPN-3 stitching
route-target import RT-EVPN-1 stitching
route-target import RT-EVPN-2 stitching
vrf definition VRF4
rd 400:1
address-family ipv4
```

- When VRF1 and VRF2 can talk to VRF3&4, but VRF3 and VRF4 cannot talk to each other, perform the following configuration:

```
vrf definition VRF3
rd 300:1
address-family ipv4
route-target export RT-EVPN-3 stitching
route-target import RT-EVPN-1 stitching
route-target import RT-EVPN-2 stitching
vrf definition VRF4
rd 400:1
address-family ipv4
route-target export RT-EVPN-4 stitching
route-target import RT-EVPN-1 stitching
route-target import RT-EVPN-2 stitching
```

- When VRF1 and VRF2 can talk to VRF3, but VRF3 and VRF4 can talk to each other, perform the following configuration:

```
vrf definition VRF3
rd 300:1
address-family ipv4
route-target export RT-EVPN-3 stitching
route-target import RT-EVPN-1 stitching
route-target import RT-EVPN-2 stitching
route-target export RT-3
route-target import RT-4
vrf definition VRF4
rd 400:1
address-family ipv4
route-target import RT-3
route-target export RT-4
```

- When VRF1 and VRF2 can talk to VRF3&4, but VRF3 and VRF4 can talk to each other, perform the following configuration:

```
vrf definition VRF3
rd 300:1
address-family ipv4
route-target export RT-EVPN-3 stitching
route-target import RT-EVPN-1 stitching
route-target import RT-EVPN-2 stitching
route-target export RT-3
route-target import RT-4
vrf definition VRF4
rd 400:1
address-family ipv4
route-target export RT-EVPN-4 stitching
route-target import RT-EVPN-1 stitching
route-target import RT-EVPN-2 stitching
route-target import RT-3
route-target export RT-4
```



**Note** For the above-mentioned use case, the Cisco Catalyst 8000V instance must configure EVPN on both VRF3 and VRF4.

Even IP BGP already imports all the routes from VRF3 and VRF4, BGP does not advertise the imported routes of the VRF to the EVPN peer.

You need to use the **Stitching** keyword in the configuration only when the sharing happens across the EVPN.

## Configuring VRF Route Sharing

Perform the following configuration to configure VRF Route Sharing in a hybrid cloud where VRF 1 and VRF 2 (On-Premise) can talk to VRF 3 and VRF 4 (in the public cloud). In this sample solution, VRF3 and VRF4 cannot talk to each other.

### Example:

```
vrf definition vrf3
rd 3:3
address-family ipv4
Route-target export 100:3
Route-target import 100:4
route-target export 3:3 stitching
route-target import 1:1 stitching
route-target import 2:2 stitching
exit-address-family
!
!
vrf definition vrf4
rd 4:4
address-family ipv4
Route-target import 100:3
Route-target export 100:4
route-target export 4:4 stitching
route-target import 1:1 stitching
route-target import 2:2 stitching
exit-address-family
```

```

!
!
interface BDI100
no shutdown
vrf forwarding vrf3
ip address 10.1.1.1 255.255.255.224
!
interface GigabitEthernet4.2
encapsulation dot1Q 2
vrf forwarding vrf3
ip address 10.4.4.1 255.255.255.224
bridge-domain 100
member vni 10100
!
interface nve1
source-interface loopback0
host-reachability protocol bgp
member vni 10100 vrf vrf3
!
router bgp 100
bgp router-id 10.11.11.11
no bgp default ipv4-unicast
neighbor 192.168.22.22 remote-as 200
neighbor 198.162.22.22 update-source loopback0
neighbor 198.162.22.22 ebgp-multihop 255
address-family ipv4 vrf vrf3
redistribute connected
neighbor 10.0.0.2 remote-as 300
neighbor 10.0.0.2 activate
neighbor 10.0.0.2 send-community both
advertise l2vpn evpn
exit-address-family
!
address-family l2vpn evpn
neighbor 198.162.22.22 activate
neighbor 198.162.22.22 send-community both
exit-address-family
end

```

## Verifying VRF Route Sharing

### Step 1 show ip bgp l2vpn evpn summary.

Provides the BGP summary information for the VRF default address family (L2VPN EVPN).

#### Example:

```

show ip bgp l2vpn evpn summary
BGP router identifier 10.11.11.11, local AS number 100
BGP table version is 8, main routing table version 8
7 network entries using 2408 bytes of memory
.....
BGP activity 14/0 prefixes, 16/0 paths, scan interval 60 secs
7 networks peaked at 17:34:38 Aug 14 2019 CST (00:00:26.895 ago)
Neighbor V AS MsgRcvd MsgSent TblVer InQ OutQ Up/Down State/PfxRcd
198.162.22.22 4 200 6 5 4 0 0 00:01:23 4
Device#

```

**Step 2**    **show ip route vrf vrf3 bgp | in binding.**

Displays the IP routing table information associated with the VRF. When you see the output with the binding label, it indicates that the configuration is successful and BGP uses the binding label as the next hop.

**Example:**

```
+++ 17:35:05 Minuet(default) exec +++
show ip route vrf vrf3 bgp | in binding
B 10.2.1.0/24 [20/0] via binding label: 0x3000001, 00:00:26
B 10.2.2.0/24 [20/0] via binding label: 0x3000002, 00:00:26
B 192.168.1.0/24 [20/0] via binding label: 0x3000001, 00:00:26
B 192.168.2.0/24 [20/0] via binding label: 0x3000002, 00:00:26
Device#
```

---



## CHAPTER 21

# Configuring Bridge Domain Interfaces

The Cisco C8000V routers support the bridge domain interface (BDI) feature for packaging Layer 2 Ethernet segments into Layer 3 IP address.

- [Restrictions for Bridge Domain Interfaces, on page 205](#)
- [Information About Bridge Domain Interface, on page 206](#)
- [Configuring Bridge-Domain Virtual IP Interface, on page 214](#)
- [Additional References, on page 221](#)
- [Feature Information for Configuring Bridge Domain Interfaces, on page 221](#)

## Restrictions for Bridge Domain Interfaces

The following are the restrictions pertaining to bridge domain interfaces:

- Only 4096 bridge domain interfaces are supported per system.
- For a bridge domain interface, the maximum transmission unit (MTU) size can be configured between 1500 and 9216 bytes.
- Bridge domain interfaces support only the following features:
  - IPv4 Multicast
  - QoS marking and policing. Shaping and queuing are not supported
  - IPv4 VRF
  - IPv6 unicast forwarding
  - Dynamic routing such as BGP, OSPF, EIGRP, RIP, IS-IS, and STATIC
  - Hot Standby Router Protocol (HSRP) from IOS XE 3.8.0 onwards.
  - Virtual Router Redundancy Protocol (VRRP) from IOS XE 3.8.0 onwards.
  - Flexible NetFlow



### Note

Flexible NetFlow is supported from Cisco IOS XE 17.7.1a and later releases.

- Bridge domain interfaces do not support the following features:
  - PPP over Ethernet (PPPoE)
  - Bidirectional Forwarding Detection (BFD) protocol
  - QoS
  - Network-Based Application Recognition (NBAR) or Advanced Video Coding (AVC)

## Information About Bridge Domain Interface

Bridge domain interface is a logical interface that allows bidirectional flow of traffic between a Layer 2 bridged network and a Layer 3 routed network traffic. Bridge domain interfaces are identified by the same index as the bridge domain. Each bridge domain represents a Layer 2 broadcast domain. Only one bridge domain interface can be associated with a bridge domain.

Bridge domain interface supports the following features:

- IP termination
- Layer 3 VPN termination
- Address Resolution Protocol (ARP), G-ARP, and P-ARP handling
- MAC address assignment

Prior to configuring a bridge domain interface, you must understand the following concepts:

- Ethernet Virtual Circuit Overview
- Bridge Domain Interface Encapsulation
- Assigning a MAC Address
- Support for IP Protocols
- Support for IP Forwarding
- Packet Forwarding
- Bridge Domain Interface Statistics

## Ethernet Virtual Circuit Overview

An Ethernet Virtual Circuit (EVC) is an end-to-end representation of a single instance of a Layer 2 service that is offered by a provider. It embodies the different parameters on which the service is being offered. In the Cisco EVC Framework, the bridge domains are made up of one or more Layer 2 interfaces known as service instances. A service instance is the instantiation of an EVC on a given port on a given router. Service instance is associated with a bridge domain based on the configuration.

An incoming frame can be classified as service instance based on the following criteria:

- Single 802.1Q VLAN tag, priority-tagged, or 802.1ad VLAN tag
- Both QinQ (inner and outer) VLAN tags, or both 802.1ad S-VLAN and C-VLAN tags

- Outer 802.1p CoS bits, inner 802.1p CoS bits, or both
- Payload Ethernet type (five choices are supported: IPv4, IPv6, PPPoE-all, PPPoE-discovery, and PPPoE-session)

Service instance also supports alternative mapping criteria:

- Untagged—Mapping to all the frames lacking a 802.1Q or 802.1ad header
- Default—Mapping to all the frames

For more information on the EVC architecture, see the section *Configuring Ethernet Virtual Connections on the Cisco ASR 1000 Router* in the [Carrier Ethernet Configuration Guide](#).

## Bridge Domain Interface Encapsulation

Security Group classification includes both Source and Destination Group, which is specified by source SGT and DGT. SGT Based PBR feature provides the PBR route-map match clause for SGT/DGT based packet classification. SGT Based PBR feature supports configuration of unlimited number of tags, but it is recommended to configure the tags based on memory available in the platform.

An EVC provides the ability to employ different encapsulations on each Ethernet flow point (EFP) present in a bridge domain. A BDI egress point may not be aware of the encapsulation of an egress packet because the packet may have egressed from one or more EFPs with different encapsulations.

In a bridge domain, if all the EFPs have different encapsulations, the BDI must be untagged (using the no 802.1Q tag). Encapsulate all the traffic in the bridge domain (popped or pushed) at the EFPs. Configure rewrite at each EFP to enable encapsulation of the traffic on the bridge domain.

In a bridge domain, if all the EFPs have the same encapsulation, configure the encapsulations on the BDI using the encapsulation command. Enabling encapsulation at the BDI ensures effective pushing or popping of tags, thereby eliminating the need for configuring the rewrite command at the EFPs. For more information on configuring the encapsulations on the BDI, see the *How to Configure a Bridge Domain Interface*.

## Assigning a MAC Address

All the bridge domain interfaces on the Cisco C8000V routers share a common MAC address. The first bridge domain interface on a bridge domain is allocated a MAC address. Thereafter, the same MAC address is assigned to all the bridge domain interfaces that are created in that bridge domain.



---

**Note** You can configure a static MAC address on a bridge domain interface using the **mac-address** command.

---

## Support for IP Protocols

Bridge domain interfaces enable the Cisco C8000V routers to act as a Layer 3 endpoint on the Layer 2 bridge domain for the following IP-related protocols:

- ARP
- DHCP

- HTTP
- ICMP
- NTP
- RARP
- SNMP
- TCP
- Telnet
- TFTP
- UDP

## Support for IP Forwarding

Bridge domain interface supports the following IP forwarding features:

- IPv4 input and output access control lists (ACL)
- IPv4 input and output QoS policies. The operations supported for the input and output service policies on a bridge domain interface are:
  - Classification
  - Marking
  - Policing
- IPv4 L3 VRFs

## Packet Forwarding

A bridge domain interface provides bridging and forwarding services between the Layer 2 and Layer 3 network infrastructure.

### Layer 2 to Layer 3

During a packet flow from a Layer 2 network to a Layer 3 network, if the destination MAC address of the incoming packet matches the bridge domain interface MAC address, or if the destination MAC address is a multicast address, the packet or a copy of the packet is forwarded to the bridge domain interface.



---

**Note** MAC address learning cannot not be performed on the bridge domain interface.

---

### Layer 3 to Layer 2

When a packet arrives at a Layer 3 physical interface of a router, a route lookup action is performed. If route lookup points to a bridge domain interface, then the bridge domain interface adds the layer 2 encapsulation and forwards the frame to the corresponding bridge domain. The byte counters are updated.



During a Layer 2 lookup on a bridge domain to which the bridge domain interface belongs, the bridge domain forwards the packets to the correct service instance based on the destination MAC address.

## Link States of a Bridge Domain and a Bridge Domain Interface

Bridge domain interface acts as a routable IOS interface on Layer 3 and as a port on a bridge domain. Both bridge domain interfaces and bridge domains operate with individual administrative states.

Shutting down a bridge domain interface stops the Layer 3 data service, but does not override or impact the state of the associated bridge domain.

Shutting down a bridge domain stops Layer 2 forwarding across all the associated members including service instances and bridge domain interfaces. The associated service instances influence the operational state of a bridge domain. Bridge domain interface cannot be operational unless one of the associated service instances is up.



**Note** Because a bridge domain interface is an internal interface, the operational state of bridge domain interface does not affect the bridge domain operational state.

### BDI Initial State

The initial administrative state of a BDI depends on how the BDI is created. When you create a BDI at boot time in the startup configuration, the default administrative state for the BDI is up. It will remain in this state unless the startup configuration includes the shutdown command. This behavior is consistent with all the other interfaces. When you create a BDI dynamically at command prompt, the default administrative state is down.

### BDI Link State

A BDI maintains a link state that comprises of three states: administratively down, operationally down, and up. The link state of a BDI is derived from two independent inputs: the BDI administrative state set by the corresponding users and the fault indication state from the lower levels of the interface states. It defines a BDI link state based on the state of the two inputs.

Fault Indication State	BDI Admin	
{start emdash} {end emdash}	Shutdown	No Shutdown
No faults asserted	Admin-down	Up
At least one fault asserted	Admin-down	Operationally-Down

## Bridge Domain Interface Statistics

For virtual interfaces, such as the bridge domain interface, protocol counters are periodically queried from the QFP.

When packets flow from a Layer 2 bridge domain network to a Layer 3 routing network through the bridge domain interface, the packets are treated as bridge domain interface input packets and bytes. When packets arrive at a Layer 3 interface and are forwarded through the bridge domain interface to a Layer 2 bridge domain, the packets are treated as output packets and bytes, and the counters are updated accordingly.

A BDI maintains a standard set of Layer 3 packet counters as the case with all Cisco IOS interfaces. Use the `show interface` command to view the Layer 3 packet counters.

The convention of the counters is relative to the Layer 3 cloud. For example, input refers to the traffic entry to the Layer 3 cloud from the Layer 2 BD, while output refers to the traffic exit from the Layer 3 cloud to the Layer 2 BD.

Use the **show interfaces accounting** command to display the statistics for the BDI status. Use the **show interface <if-name>** command to display the overall count of the packets and bytes that are transmitted and received.

## Creating or Deleting a Bridge Domain Interface

When you define an interface or subinterface for a Cisco IOS router, you name it and specify how it is assigned an IP address. You can create a bridge domain interface before adding a bridge domain to the system. This new bridge domain interface will be activated after the associated bridge domain is configured.



**Note** When a bridge domain interface is created, a bridge domain is automatically created.

When you create the bridge domain interface and the bridge domain, the system maintains the required associations for mapping the bridge domain-bridge domain interface pair.

The mapping of bridge domain and bridge domain interface is maintained in the system. The bridge domain interface uses the index of the associated bridge domain to show the association.

## Bridge Domain Interface Scalability

The following table lists the bridge domain interface scalability numbers, based on the type of Cisco C8000V routers' Forwarding Processors (FPs).

**Table 24: Bridge Domain Interface Scalability Numbers Based on the Type of Cisco C8000V routers' Forwarding Processor**

Description	0
Maximum bridge domain interfaces per router	

## Bridge-Domain Virtual IP Interface

The Virtual IP Interface (VIF) feature helps to associate multiple BDI interfaces with a BD instance. The BD-VIF interface inherits all the existing L3 features of IOS logical IP interface.



**Note** You must configure every BD-VIF interface with a unique MAC address and it should belong to a different VRF.

The Virtual IP Interface (VIF) feature has the following limitations:

- BD-VIF interface does not support IP multicast.

- Number of BD-VIF interfaces with automatically generated MAC address varies on the basis of platforms.
- BD-VIF Interface does not support MPLS.
- The maximum number of BD-VIF interfaces per bridge-domain and the total number of BD-VIF interface for per system vary based on the type of platforms.

The maximum number of BD-VIF supported on different platforms varies:

- ASR 1000 supports maximum 100 BD-VIF for a Bridge Domain
- CSR 1000v supports maximum 16 BD-VIF for a Bridge Domain
- ISR 4000 support maximum 16 BD-VIF for a Bridge Domain

From Cisco IOS XE 17.7.1a release, BD-VIF supports [Flexible Netflow \(FNF\)](#).

## How to Configure a Bridge Domain Interface

To configure a bridge domain interface, perform the following steps:

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface BDI** *{interface number}*
4. **encapsulation** *encapsulation dot1q <first-tag> [second-dot1q <second-tag>]*
5. Do one of the following:
6. **match security-group destination tag** *sgt-number*
7. **mac address** *{mac-address}*
8. **no shut**
9. **shut**

### DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b> <b>Example:</b> <pre>Router&gt; enable</pre>	Enables privileged EXEC mode. Enter your password, if prompted.
Step 2	<b>configure terminal</b> <b>Example:</b> <pre>Router# configure terminal</pre>	Enters global configuration mode.
Step 3	<b>interface BDI</b> <i>{interface number}</i> <b>Example:</b> <pre>Router(config-if)# interface BDI3</pre>	Specifies a bridge domain interface.

	Command or Action	Purpose
<b>Step 4</b>	<b>encapsulation</b> <i>encapsulation dot1q &lt;first-tag&gt; [second-dot1q &lt;second-tag&gt;]</i> <b>Example:</b> <pre>Router(config-if)# encapsulation dot1q 1 second-dot1q 2</pre>	<p>Defines the encapsulation type.</p> <p>The example shows how to define dot1q as the encapsulation type.</p>
<b>Step 5</b>	<p>Do one of the following:</p> <p><b>Example:</b></p> <pre>ip address ip-address mask</pre> <p><b>Example:</b></p> <p><b>Example:</b></p> <pre>ipv6 address {X:X:X:X::X link-local   X:X:X:X::X/prefix [anycast   eui-64]   autoconfig [default]}</pre> <p><b>Example:</b></p> <pre>Router(config-if)# ip address 10.2.2.1 255.255.255.0</pre> <p><b>Example:</b></p> <pre>Router(config-if)# ipv6 address AB01:CD1:123:C::/64 eui-64</pre>	<p>Specifies either the IPv4 or IPv6 address for the bridge domain interface.</p>
<b>Step 6</b>	<b>match security-group destination tag</b> <i>sgt-number</i> <b>Example:</b> <pre>Router(config-route-map)# match security-group destination tag 150</pre>	<p>Configures the value for security-group destination security tag.</p>
<b>Step 7</b>	<b>mac address</b> <i>{mac-address}</i> <b>Example:</b> <pre>Router(config-if)# mac-address 1.1.3</pre>	<p>Specifies the MAC address for the bridge domain interface.</p>
<b>Step 8</b>	<b>no shut</b> <b>Example:</b> <pre>Router(config-if)# no shut</pre>	<p>Enables the bridge domain interface.</p>
<b>Step 9</b>	<b>shut</b> <b>Example:</b>	<p>Disables the bridge domain interface.</p>

	Command or Action	Purpose
	Router(config-if)# shut	

## Example

The following example shows the configuration of a bridge domain interface at IP address 10.2.2.1 255.255.255.0:

```
Router# configure terminal
Router(config)# interface BDI3
Router(config-if)# encapsulation dot1Q 1 second-dot1q 2
Router(config-if)# ip address 10.2.2.1 255.255.255.0
Router(config-if)# mac-address 1.1.3
Router(config-if)# no shut
Router(config-if)# exit
```

## Displaying and Verifying Bridge Domain Interface Configuration

### SUMMARY STEPS

1. enable
2. show interfaces bdi
3. show platform software interface fp active name
4. show platform hardware qfp active interface if-name
5. debug platform hardware qfp feature
6. platform trace runtime process forwarding-manager module
7. platform trace boottime process forwarding-manager module interfaces

### DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	enable  Example:  Router> enable	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	show interfaces bdi  Example:  Router# show interfaces BDI3	Displays the configuration summary of the corresponding BDI.
<b>Step 3</b>	show platform software interface fp active name  Example:  Router# show platform software interface fp active name BDI4	Displays the bridge domain interface configuration in a Forwarding Processor.

	Command or Action	Purpose
<b>Step 4</b>	<b>show platform hardware qfp active interface if-name</b> <b>Example:</b> <pre>Router# show platform hardware qfp active interface if-name BDI4</pre>	Displays the bridge domain interface configuration in a data path.
<b>Step 5</b>	<b>debug platform hardware qfp feature</b> <b>Example:</b> <pre>Router# debug platform hardware qfp active feature l2bd client all</pre>	The selected CPP L2BD Client debugging is on.
<b>Step 6</b>	<b>platform trace runtime process forwarding-manager module</b> <b>Example:</b> <pre>Router(config)# platform trace runtime slot F0 bay 0 process forwarding-manager module interfaces level info</pre>	Enables the Forwarding Manager Route Processor and Embedded Service Processor trace messages for the Forwarding Manager process.
<b>Step 7</b>	<b>platform trace boottime process forwarding-manager module interfaces</b> <b>Example:</b> <pre>Router(config)# platform trace boottime slot R0 bay 1 process forwarding-manager forwarding-manager level max</pre>	Enables the Forwarding Manager Route Processor and Embedded Service Processor trace messages for the Route Processor Forwarding Manager process during bootup.

### What to do next

For additional information on the commands and the options available with each command, see the [Cisco IOS Configuration Fundamentals Command Reference Guide](#).

## Configuring Bridge-Domain Virtual IP Interface

```
enable
configure terminal
[no] interface BD-VIF interface-number
 [[no] vrf forwarding vrf-name]
 [[no] mac address mac-address]
 [[no] ip address ip-address mask]
 [[no] ipv6 address {X:X:X:X::X link-local| X:X:X:X::X/prefix [anycast | eui-64] |
autoconfig [default]}]]
```

```
exit
```

To delete BD-VIF interface, use the 'no' form of the command.

## Associating VIF Interface with a Bridge Domain

```
enable
configure terminal
bridge-domain bridge-domain number
[no] member BD-VIF interface-number
exit
```

To dissociate the VIF interface, use the 'no' form of the command.

## Verifying Bridge-Domain Virtual IP Interface

All existing show commands for interface and IP interface can be used for the BD-VIF interface.

```
show interface bd-vif bd-vif-id
show ip interface bd-vif bd-vif-id
show bd-vif interfaces in fman-fp
show pla sof inter fp ac brief | i BD_VIF
```

## Example Configuration Bridge-Domain Virtual IP Interface

Detail sample:

```
interface Port-channell
mtu 9000
no ip address
!Ethernet service endpoint one per neutron network
service instance 1756 ethernet
 description 4e8e5957-649f-477b-9e5b-f1f75b21c03c
 encapsulation dot1q 1756
 rewrite ingress tag pop 1 symmetric
 bridge-domain 1756
!
interface BD-VIF5001
no shutdown
vrf forwarding vrf5001
ip address 10.0.0.1 255.255.255.0
interface BD-VIF5002
no shutdown
vrf forwarding vrf5002
ip address 10.0.0.2 255.255.255.0

bridge-domain 1756
member Port-channell service-instance 1756
member bd-vif5001
member bd-vif5002
```

## Configuring Flexible NetFlow over a Bridge Domain Virtual IP Interface

### SUMMARY STEPS

1. enable
2. configure terminal

3. **interface** *type number*
4. **{ip | ipv6} flow monitor** *monitor-name* [**sampler** *sampler-name*] **{input | output}**
5. **exit**

## DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> <pre>Device&gt; enable</pre>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> <pre>Device# configure terminal</pre>	Enters global configuration mode.
<b>Step 3</b>	<b>interface</b> <i>type number</i> <b>Example:</b> <pre>Device (config)# interface BD-VIF 100</pre>	Specifies an interface and enters interface configuration mode. Enter the BD-VIF number.
<b>Step 4</b>	<b>{ip   ipv6} flow monitor</b> <i>monitor-name</i> [ <b>sampler</b> <i>sampler-name</i> ] <b>{input   output}</b> <b>Example:</b> <pre>Device(config-if)# ip flow monitor FLOW-MONITOR-1 input</pre>	Enables a Flexible NetFlow flow monitor for IP traffic that the router is receiving or transmitting on the interface.
<b>Step 5</b>	<b>exit</b> <b>Example:</b> <pre>Device(config-if)# exit</pre>	Exits interface configuration mode and returns to privileged EXEC mode.

## Examples: Flexible NetFlow over a Bridge Domain Virtual IP Interface

The following is a sample output for the **show platform hardware qfp active interface if-name** command showing the QFP information and flow direction for flow monitors. The table below provides the key to the CLI output.

Configuration	Output
ip flow monitor <monitor-name> input	IPV4_INPUT_FNF_FIRST IPV4_INPUT_FNF_FINAL
ip flow monitor <monitor-name> output	IPV4_BDI_OUTPUT_FNF_FINAL
ipv6 flow monitor <monitor-name> input	IPV6_INPUT_FNF_FIRST IPV6_INPUT_FNF_FINAL
ipv6 flow monitor <monitor-name> output	IPV6_BDI_OUTPUT_FNF_FINAL



```
Device# show run interface bd-vif2
Building configuration...

Current configuration: 227 bytes
!
interface BD-VIF2
vrf forwarding vrf1
ip flow monitor test1 input
ip flow monitor test1 output
ip address 10.11.11.11 255.255.255.0
ipv6 flow monitor test2 input
ipv6 flow monitor test2 output
ipv6 address 2001:DB8::1/32
end

Device# show platform hardware qfp active interface if-name BD-VIF 2
General interface information
 Interface Name: BD-VIF2
 Interface state: VALID
 Platform interface handle: 20
 QFP interface handle: 17
 Rx uidb: 262138
 Tx uidb: 262127
 Channel: 0
Interface Relationships

BGPPA/QPPB interface configuration information
 Ingress: BGPPA/QPPB not configured. flags: 0000
 Egress: BGPPA not configured. flags: 0000

ipv4_input enabled.
ipv4_output enabled.
ipv6_input enabled.
ipv6_output enabled.
layer2_input enabled.
layer2_output enabled.
ess_ac_input enabled.

Features Bound to Interface:
2 GIC FIA state
66 PUNT INJECT DB
70 cpp_l2bd_svr
43 icmp_svr
45 ipfrag_svr
46 ipreass_svr
47 ipv6reass_svr
44 icmp6_svr
58 stile
Protocol 0 - ipv4_input
FIA handle - CP:0x55a7f59df038 DP:0x3fff1000
 IPV4_INPUT_DST_LOOKUP_ISSUE (M)
 IPV4_INPUT_ARL_SANITY (M)
 IPV4_INPUT_SRC_LOOKUP_ISSUE
 IPV4_INPUT_DST_LOOKUP_CONSUME (M)
 IPV4_INPUT_SRC_LOOKUP_CONSUME
 IPV4_INPUT_FOR_US_MARTIAN (M)
 IPV4_INPUT_STILE_LEGACY
 IPV4_INPUT_FNF_FIRST
 IPV4_INPUT_LOOKUP_PROCESS (M)
 IPV4_INPUT_FNF_FINAL
 IPV4_INPUT_IPOPTIONS_PROCESS (M)
 IPV4_INPUT_GOTO_OUTPUT_FEATURE (M)
Protocol 1 - ipv4_output
FIA handle - CP:0x55a7f59df0d8 DP:0x3ffeff00
```

```

IPV4_VFR_REFRAG (M)
IPV4_OUTPUT_SRC_LOOKUP_ISSUE
IPV4_OUTPUT_L2_REWRITE (M)
IPV4_OUTPUT_SRC_LOOKUP_CONSUME
IPV4_OUTPUT_STILE_LEGACY
IPV4_OUTPUT_FRAG (M)
IPV4_BDI_OUTPUT_FNF_FINAL.
BDI_VLAN_TAG_ATTACH_AND_LAYER2_LOOKUP_GOTO
LAYER2_BRIDGE
BDI_OUTPUT_GOTO_OUTPUT_FEATURE
IPV4_OUTPUT_DROP_POLICY (M)
DEF_IF_DROP_FIA (M)
Protocol 6 - ipv6_input
FIA handle - CP:0x55a7f59dee58 DP:0x3fff4300
IPV6_INPUT_SANITY_CHECK (M)
IPV6_INPUT_DST_LOOKUP_ISSUE (M)
IPV6_INPUT_SRC_LOOKUP_ISSUE
IPV6_INPUT_ARL (M)
IPV6_INPUT_DST_LOOKUP_CONT (M)
IPV6_INPUT_SRC_LOOKUP_CONT
IPV6_INPUT_DST_LOOKUP_CONSUME (M)
IPV6_INPUT_SRC_LOOKUP_CONSUME
IPV6_INPUT_STILE_LEGACY
IPV6_INPUT_FNF_FIRST
IPV6_INPUT_FOR_US (M)
IPV6_INPUT_LOOKUP_PROCESS (M)
IPV6_INPUT_FNF_FINAL
IPV6_INPUT_LINK_LOCAL_CHECK (M)
IPV6_INPUT_GOTO_OUTPUT_FEATURE (M)
Protocol 7 - ipv6_output
FIA handle - CP:0x55a7f59dee08 DP:0x3fff4b80
IPV6_VFR_REFRAG (M)
IPV6_OUTPUT_SRC_LOOKUP_ISSUE
IPV6_OUTPUT_SRC_LOOKUP_CONT
IPV6_OUTPUT_SRC_LOOKUP_CONSUME
IPV6_OUTPUT_L2_REWRITE (M)
IPV6_OUTPUT_STILE_LEGACY
IPV6_OUTPUT_FRAG (M)
IPV6_BDI_OUTPUT_FNF_FINAL
BDI_VLAN_TAG_ATTACH_AND_LAYER2_LOOKUP_GOTO
LAYER2_BRIDGE
BDI_OUTPUT_GOTO_OUTPUT_FEATURE
IPV6_OUTPUT_DROP_POLICY (M)
DEF_IF_DROP_FIA (M)

```

□

The following is a sample out of the **show flow monitor** `[[name] [cache [format {csv | record | table}]] [statistics]]` command showing the cache output in record format.

```
Device# show flow monitor name FLOW-MONITOR-1 cache format record
```

```

Cache type: Normal
Cache size: 1000
Current entries: 4
High Watermark: 4
Flows added: 101
Flows aged: 97
- Active timeout (1800 secs) 3
- Inactive timeout (15 secs) 94
- Event aged 0
- Watermark aged 0
- Emergency aged
IPV4 DESTINATION ADDRESS:
198.51.100.1 0
ipv4 source address: 10.10.11.1

```

```

trns source port: 25
trns destination port: 25
counter bytes: 72840
counter packets: 1821
IPV4 DESTINATION ADDRESS: 198.51.100.2
ipv4 source address: 10.10.10.2
trns source port: 20
trns destination port: 20
counter bytes: 3913860
counter packets: 7326
IPV4 DESTINATION ADDRESS: 198.51.100.200
ipv4 source address: 192.168.67.6
trns source port: 0
trns destination port: 3073
counter bytes: 51072
counter packets: 1824

```

```
Device# show flow monitor name FLOW-MONITOR-2 cache format record
```

```

Cache type: Normal
Cache size: 1000
Current entries: 2
High Watermark: 3
Flows added: 95
Flows aged: 93
- Active timeout (1800 secs) 0
- Inactive timeout (15 secs) 93
- Event aged 0
- Watermark aged 0
- Emergency aged 0
IPV6 DESTINATION ADDRESS: 2001:DB8:0:ABCD::1
ipv6 source address: 2001:DB8:0:ABCD::2
trns source port: 33572
trns destination port: 23
counter bytes: 19140
counter packets: 349
IPV6 DESTINATION ADDRESS: FF02::9
ipv6 source address: 2001:DB8::A8AA:BBFF:FE9B

trns source port: 521
trns destination port: 521
counter bytes: 92
counter packets: 1

```

The following is a sample out of the **show flow interface** command showing the flow status for an interface.

```
Device# show flow interface BD-VIF2001
```

```

Interface GigabitEthernet0/0/0
FNF: monitor: FLOW-MONITOR-1
direction: Input
traffic(ip): on
FNF: monitor: FLOW-MONITOR-2
direction: Input traffic(ipv6): on

```

```
Device# show flow interface BD-VIF2002
```

```

Interface GigabitEthernet1/0/0
FNF: monitor: FLOW-MONITOR-1
direction: Output
traffic(ip): on
FNF: monitor: FLOW-MONITOR-2
direction: Input traffic(ipv6): on

```

The following is a sample output of the **show platform hardware qfp active interface if-name | in FNF** command showing the QFP information and flow direction for flow monitors in Flexible NetFlow configuration. The table below provides the key to the CLI output.

Configuration	Output
ip flow monitor <monitor-name> input	IPV4_INPUT_FNF_FIRST IPV4_INPUT_FNF_FINAL
ip flow monitor <monitor-name> output	IPV4_BDI_OUTPUT_FNF_FINAL
ipv6 flow monitor <monitor-name> input	IPV6_INPUT_FNF_FIRST IPV6_INPUT_FNF_FINAL
ipv6 flow monitor <monitor-name> output	IPV6_BDI_OUTPUT_FNF_FINAL

```
Device# show run interface bd-vif2
Building configuration...
```

```
Current configuration : 227 bytes
!
interface BD-VIF2
vrf forwarding vrf1
ip flow monitor test1 input
ip flow monitor test1 output
ip address 10.11.11.11 255.255.255.0
ipv6 flow monitor test2 input
ipv6 flow monitor test2 output
ipv6 address 2001::8/64
end
```

```
Device# show platform hardware qfp active interface if-name BD-VIF 2 | in FNF
IPV4_INPUT_FNF_FIRST
IPV4_INPUT_FNF_FINAL
IPV4_BDI_OUTPUT_FNF_FINAL.
IPV6_INPUT_FNF_FIRST
IPV6_INPUT_FNF_FINAL
IPV6_BDI_OUTPUT_FNF_FINAL
```

The **clear flow monitor name** *monitor-name* [**cache** [**force-export**] | **force-export** | **statistics**] command clears a Flexible NetFlow flow monitor, flow monitor cache, or flow monitor statistics, and can be used to force the export of the data in the flow monitor cache.

For more details on configuring Flexible NetFlow, see the [Flexible NetFlow Configuration Guide, Cisco IOS XE 17](#).

## Additional References

### Related Documents

Related Topic	Document Title
Configuring Ethernet Virtual Connections on the Cisco ASR 1000 Series Aggregation Services Routers	<a href="#">Carrier Ethernet Configuration Guide</a>
EVC Quality of Service	<a href="http://www.cisco.com/en/US/docs/ios/ios_xe/qos/configuration/guide/qos_evc_xe.html">http://www.cisco.com/en/US/docs/ios/ios_xe/qos/configuration/guide/qos_evc_xe.html</a>

### MIBs

MIB	MIBs Link
None	To locate and download MIBs for selected platforms, Cisco software releases, and feature sets, use Cisco MIB Locator found at the following URL: <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>

### Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	<a href="https://www.cisco.com/c/en_in/support/index.html">https://www.cisco.com/c/en_in/support/index.html</a>

## Feature Information for Configuring Bridge Domain Interfaces

The following table lists the features in this module and provides links to specific configuration information.

Use Cisco Feature Navigator to find information about platform support and software image support. Cisco Feature Navigator enables you to determine which software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.



**Note** The table below lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

**Table 25: Feature Information for Configuring Bridge Domain Interfaces**

Feature Name	Releases	Feature Information
Configuring Bridge Domain Interface	Cisco IOS XE Cupertino 17.7.1a	This feature was introduced on the Cisco C8000V routers.
Bridge-Domain Virtual IP Interface	Cisco IOS XE Cupertino 17.7.1a	This feature was introduced on the Cisco C8000V routers.  The Bridge-Domain Virtual IP Interface (VIF) now connects multiple Bridge Domain Interfaces (BDI) with a single BD instance so that each IP subnet within an L2 network can be associated with a single VRF.
Flexible NetFlow (FNF) on Bridge-Domain Virtual IP Interface (BD-VIF)	Cisco IOS XE Cupertino 17.7.1a	This feature was introduced on the Cisco C8000V routers. The following command was introduced:  <b>{ip   ipv6} flow monitor</b> <i>monitor-name</i> [ <b>sampler</b> <i>sampler-name</i> ] <b>{input   output}</b>



## CHAPTER 22

# Configuring MTP Software Support

A Media Termination Point (MTP) software device is an essential component of large-scale deployments of Cisco Unified Communications Manager (CUCM). In these deployments, the software MTP bridges the media streams between two connections by allowing the CUCM to relay the calls that are routed through Session Initiation Protocol (SIP) or H.323 endpoints through Skinny Client Control Protocol (SCCP) commands. The SCCP commands allow the CUCM to establish MTP for call signaling.

From Cisco IOS XE 17.8.1, you can configure the support for software MTP on Cisco Catalyst 8000V devices. If you use voice functionalities with your Cisco Catalyst 8000V device, you can leverage software MTP to enable and use supplementary services, such as Call Park and Call Transfer routed through an H.323 endpoint or an H.323 gateway.

- [Benefits, on page 223](#)
- [Prerequisites for Configuring Support for Software MTP, on page 223](#)
- [SRTP-DTMF Interworking, on page 223](#)
- [Configuring Support for Software MTP, on page 224](#)
- [Verifying Software MTP Support, on page 228](#)

## Benefits

Configuring software MTP in Cisco Catalyst 8000V allows you to:

- Register a Cisco Catalyst 8000V instance with the Unified CM as a Trusted Relay Point.
- Leverage the SWMTP support when one of the end points does not support DTMF signaling.

## Prerequisites for Configuring Support for Software MTP

- Configure codec and packetization in the inbound-call legs and the outbound-call legs.

## SRTP-DTMF Interworking

From Cisco IOS XE 17.10.1a, Secure Real-time Transport Protocol (SRTP) Dual-Tone Multi-Frequency (DTMF) interworking is supported with Software MTP in pass through mode. SMTP supports DTMF Interworking for nonsecure calls, and this feature adds support for SRTP DTMF interworking for secure calls.

CUCM support for this feature is expected to be implemented in a later release.

## Restrictions for SRTP-DTMF Interworking

- The SRTP-DTMF Interworking feature supports only the codec-passthrough format.
- The SRTP-DTMF Interworking feature does not support multiple concurrent Synchronised Sources (SSRCs) with the same destination IP and port.
- The calls that support SRTP-DTMF Interworking may have a minor performance impact as compared to calls supported on nonsecure DTMF interworking.

## Supported Platforms for SRTP-DTMF Interworking

From Cisco IOS XE 17.10.1a, the following platforms support SRTP DTMF interworking with SMTP:

- Cisco 4461 Integrated Services Router (ISR)
- Cisco Catalyst 8200 Edge Series Platforms
- Cisco Catalyst 8300 Edge Series Platforms
- Cisco Catalyst 8000V Edge Software

## Configuring Support for Software MTP

To enable and configure support for software MTP, perform the following steps.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **sccp local** *interface-type interface-number* [**port** *port-number*]
4. **sccp ccm** {*ipv4-address* | *ipv6-address* | *dns*} **identifier** *identifier-number* [**port** *port-number*] **version** *version-number*
5. **sccp**
6. **sccp ccm group** *group-number*
7. **associate ccm** *identifier-number* **priority** *number*
8. **associate profile** *profile-identifier* **register** *device-name*
9. **dspfarm profile** *profile-identifier* {**conference** | **mtp** | **transcode**} [**security**]
10. **trustpoint** *trustpoint-label*
11. **codec** *codec*
12. **maximum sessions** {**hardware** | **software**} *number*
13. **associate application** **sccp**
14. **no shutdown**



## DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> <pre>Router&gt; enable</pre>	Enables the privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> <pre>Router# configure terminal</pre>	Enters the global configuration mode.
<b>Step 3</b>	<b>sccp local <i>interface-type interface-number</i> [<b>port</b> <i>port-number</i>]</b> <b>Example:</b> <pre>Router(config)# sccp local gigabitethernet0/0/0</pre>	Selects the local interface that SCCP applications (transcoding and conferencing) use to register with the Cisco UCM. <ul style="list-style-type: none"> <li>• <i>interface type</i> : The interface address or a virtual-interface address such as Ethernet.</li> <li>• <i>interface number</i> : The interface number that the SCCP application uses to register with the Unified CM.</li> <li>• (Optional) <b>port</b> <i>port-number</i>: The port number used by the selected interface. The applicable range is 1025 to 65535, and the default is 2000.</li> </ul>
<b>Step 4</b>	<b>sccp ccm {<i>ipv4-address</i>   <i>ipv6-address</i>   <i>dns</i>} <b>identifier</b> <i>identifier-number</i> [<b>port</b> <i>port-number</i>] <b>version</b> <i>version-number</i></b> <b>Example:</b> <pre>Router(config)# sccp ccm 10.1.1.1 identifier 1 version 7.0+</pre>	Adds a Unified CM server to the list of available servers and sets the following parameters: <ul style="list-style-type: none"> <li>• <i>ipv4-address</i> : The IP version 4 address of the Cisco UCM server.</li> <li>• <i>ipv6-address</i> : The IP version 6 address of the Cisco UCM server.</li> <li>• <i>dns</i> : The DNS name.</li> <li>• <b>identifier</b> : The number that identifies the Unified CM server. The applicable range is 1 to 65535.</li> <li>• <b>port</b> <i>port-number</i> (Optional): The TCP port number. The applicable range is 1025 to 65535, and the default is 2000.</li> <li>• <b>version</b> <i>version-number</i> : The Unified CM version. The valid versions are 3.0, 3.1, 3.2, 3.3, 4.0, 4.1, 5.0.1, 6.0, and 7.0+.</li> </ul>
<b>Step 5</b>	<b>sccp</b> <b>Example:</b>	Enables the SCCP and its related applications (transcoding and conferencing).

	Command or Action	Purpose
	<code>Router(config)# sccp</code>	
<b>Step 6</b>	<b>sccp ccm group</b> <i>group-number</i> <b>Example:</b> <code>Router(config)# sccp ccm group 10</code>	Creates a Unified CM group and enters the SCCP Unified CM configuration mode. <ul style="list-style-type: none"> <li>• <i>group-number</i> : Identifies the Cisco Unified CM group. The applicable range is 1 to 50.</li> </ul>
<b>Step 7</b>	<b>associate ccm</b> <i>identifier-number</i> <b>priority</b> <i>number</i> <b>Example:</b> <code>Router(config-sccp-ccm)# associate ccm 10 priority 3</code>	Associates a Unified CM with a group and establishes its priority within the group. <ul style="list-style-type: none"> <li>• <i>identifier-number</i> : The Unified CM identifier. The applicable range is 1 to 65535.</li> <li>• <b>priority</b> <i>number</i> : The priority of the Unified CM within the Unified CM group. The applicable range is 1 to 4. The highest priority is 1.</li> </ul>
<b>Step 8</b>	<b>associate profile</b> <i>profile-identifier</i> <b>register</b> <i>device-name</i> <b>Example:</b> <code>Router(config-sccp-ccm)# associate profile 1 register MTP0011</code>	Associates a Digital Signal Processor (DSP) farm profile with a Unified CM group. <ul style="list-style-type: none"> <li>• <i>profile-identifier</i> : The DSP farm profile. The applicable range is 1 to 65535.</li> <li>• <b>register</b> <i>device-name</i> : The device name in Unified CM. A maximum of 15 characters can be entered for the device name.</li> </ul>
<b>Step 9</b>	<b>dspfarm profile</b> <i>profile-identifier</i> { <b>conference</b>   <b>mtp</b>   <b>transcode</b> } [ <b>security</b> ] <b>Example:</b> <code>Router(config-sccp-ccm)# dspfarm profile 1 mtp</code>	Enters the DSP farm profile configuration mode and defines a profile for the DSP farm services. <ul style="list-style-type: none"> <li>• <i>profile-identifier</i> : The number that uniquely identifies a profile. The applicable range is 1 to 65535, and there is no default.</li> <li>• <b>conference</b> : Enables a profile for conferencing.</li> <li>• <b>mtp</b> : Enables a profile for MTP.</li> <li>• <b>transcode</b> : Enables a profile for transcoding.</li> <li>• <b>security</b> (Optional): Enables a profile for secure DSP farm services. For more information on configuration examples, see section <a href="#">Sample Software MTP Support Configuration, on page 227</a>.</li> </ul>
<b>Step 10</b>	<b>trustpoint</b> <i>trustpoint-label</i> <b>Example:</b> <code>Router(config-dspfarm-profile)# trustpoint dspfarm</code>	(Optional) Associates a trustpoint with a DSP farm profile.
<b>Step 11</b>	<b>codec</b> <i>codec</i>	Specifies the codecs supported by a DSP farm profile.

	Command or Action	Purpose
	<b>Example:</b> <pre>Router(config-dspfarm-profile)# codec g711ulaw</pre>	<ul style="list-style-type: none"> <li>• <b>codec-type</b>: Specifies the preferred codec. Enter ? for a list of supported codecs.</li> </ul> <p>Repeat this step for each supported codec.</p>
<b>Step 12</b>	<b>maximum sessions {hardware   software} number</b> <b>Example:</b> <pre>Router(config-dspfarm-profile)# maximum sessions software 10</pre>	<p>Specifies the maximum number of sessions supported by the profile.</p> <ul style="list-style-type: none"> <li>• <b>hardware</b> : The number of sessions that the MTP hardware resources support.</li> <li>• <b>software</b> : The number of sessions that the MTP software resources support.</li> <li>• <b>number</b> : The number of sessions that are supported by the profile. The applicable range is 0 to x, and the default is 0. The value of x is determined at runtime depending on the number of resources available with the resource provider.</li> </ul>
<b>Step 13</b>	<b>associate application sccp</b> <b>Example:</b> <pre>Router(config-dspfarm-profile)# associate application sccp</pre>	Associates SCCP to the DSP farm profile.
<b>Step 14</b>	<b>no shutdown</b> <b>Example:</b> <pre>Router(config-dspfarm-profile)# no shutdown</pre>	Changes the status of the interface to the UP state.

## Sample Software MTP Support Configuration

The following output is a sample of the software MTP support configuration in a Cisco Catalyst 8000V device:

```
sccp local GigabitEthernet1
sccp ccm 9.35.46.100 identifier 1 priority 1 version 7.0
!
sccp ccm group 1
bind interface GigabitEthernet1
associate ccm 1 priority 1
associate profile 10 register SWMTP1
associate profile 1 register c8kvsmall-mtp1
associate profile 2 register c8kv-sec-swmtpl
!
!
!
dspfarm profile 1 mtp
codec g711ulaw
maximum sessions software 20000
associate application SCCP
```

The following example shows a sample configuration for the SRTP-DTMF Interworking feature-with secure dspfarm profile:

```
sccp local GigabitEthernet0/0/0
sccp ccm 172.18.151.125 identifier 1 version 7.0
sccp
!
sccp ccm group 1
bind interface GigabitEthernet0/0/0
associate ccm 1 priority 1
associate profile 1 register Router
!
dspfarm profile 1 mtp security
trustpoint IOSCA
codec g711ulaw
codec pass-through
tls-version v1.2
maximum sessions software 5000
associate application SCCP
```



**Note** SR-TP traffic can pass through an SMTP resource when the dspfarm profile is provisioned with codec pass-through, and if it does not have TLS and security-related configuration. For traffic flows that require SRTP-DTMF interworking support, the SMTP dspfarm profile must include the **security** keyword and the TLS and codec pass-through configuration. This dspfarm resource profile can also pass through SRTP traffic independent of SRTP-DTMF interworking support.

## Verifying Software MTP Support

To verify whether you have successfully configured the support for SWMTP in your Cisco Catalyst 8000V device, run the **show sccp** command:

```
Router# show sccp

SCCP Admin State: UP
Gateway IP Address: 10.13.40.157, Port Number: 2000
IP Precedence: 5
User Masked Codec list: None
Call Manager: 10.13.40.148, Port Number: 2000
 Priority: N/A, Version: 6.0, Identifier: 1
 Trustpoint: N/A
```

To verify the dspfarm profile, run the **show dspfarm profile** command:

```
Router# show dspfarm profile 1
Dspfarm Profile Configuration

Profile ID = 1, Service = MTP, Resource ID = 1
Profile Service Mode : Non Secure
Profile Admin State : UP
Profile Operation State : RESOURCE ALLOCATED
Application : SCCP Status : NOT ASSOCIATED
Resource Provider : NONE Status : NONE
Total Number of Resources Configured : 20000
Total Number of Resources Available : 20000
Total Number of Resources Out of Service : 0
Total Number of Resources Active : 0
Hardware Configured Resources : 0
```

```

Hardware Resources Out of Service: 0
Software Configured Resources : 20000

Number of Hardware Resources Active : 0
Number of Software Resources Active : 0
Codec Configuration: num_of_codecs:1
Codec : g711ulaw, Maximum Packetization Period : 30

```

To verify information about the secure dspfarm profile status, use the **show dspfarm profile** command and check that the secure service mode is set:

```

Router# show dspfarm profile 2
Dspfarm Profile Configuration
 Profile ID = 2, Service = MTP, Resource ID = 2
 Profile Service Mode : secure
 Trustpoint : IOSCA
 TLS Version : vl.2
 TLS Cipher : AES128-SHA
 Profile Admin State : UP
 Profile Operation State : ACTIVE
 Application : SCCP Status : ASSOCIATED
 Resource Provider : NONE Status : NONE
 Total Number of Resources Configured : 8000
 Total Number of Resources Available : 8000
 Total Number of Resources Out of Service : 0
 Total Number of Resources Active : 0
 Hardware Configured Resources : 0
 Hardware Resources Out of Service: 0
 Software Configured Resources : 8000
 Number of Hardware Resources Active : 0
 Number of Software Resources Active : 0
 Codec Configuration: num_of_codecs:2
 Codec : pass-through, Maximum Packetization Period : 0
 Codec : g711ulaw, Maximum Packetization Period : 30

```

To verify the call connection between the endpoints, run the **show sccp connection details** command. This command shows that the connection is successfully established. This is indicated through the active connections and call legs at the end of the configuration output:

```

Router# show sccp connection details

bridge-info(bid, cid) - Normal bridge information(Bridge id, Calleg id)

mmbridge-info(bid, cid) - Mixed mode bridge information(Bridge id, Calleg id)

sess_id conn_id call-id codec pkt-period dtmf_method type bridge-info
mmbridge-info srtp_cryptosuite dscp
call_ref spid conn_id_tx
(bid, cid)
16782237 16777254 110 g711u 20 rfc2833_pt thru rtpspi (40,0)
N/A N/A
29751839 16777216 - -
16782237 16777253 109 g711u 20 rfc2833_report rtpspi (40,0)
N/A N/A
29751839 16777216 - -
Total number of active session(s) 1, connection(s) 2, and callegs 2

```

For SMTP secure DTMF, the **show sccp connections** command displays the codec type (pass-th), the s-type (s-mtp), and information about the DTMF method (rfc2833\_pt thru):

```

Router#sh sccp connections

sess_id conn_id stype mode codec sport rport ripaddr conn_id_tx
dtmf_method

```

```

16791234 16777308 s-mtp sendrecv pass_th 8006 24610 172.18.153.37
rfc2833_pt thru
16791234 16777306 s-mtp sendrecv pass_th 8004 17576 172.18.154.2
rfc2833_report

```

Total number of active session(s) 1, and connection(s) 2

To display information about RTP connections, use the **show rtpspi call** command:

```
Router# show rtpspi call
```

RTP Service Provider info:

No.	CallId	dstCallId	Mode	LocalRTP	RmtRTP	LocalIP	RemoteIP	SRTP
1	22	19	Snd-Rcv	7242	17510	0x90D080F	0x90D0814	0
2	19	22	Snd-Rcv	18050	6900	0x90D080F	0x90D080F	0

If SRTP DTMF interworking is active, the SRTP field shows a non-zero value:

```
Router# show rtpspi call
```

RTP Service Provider info:

No.	CallId	dstCallId	Mode	LocalRTP	RmtRTP	LocalIP	RemoteIP	SRTP
1	13	14	Snd-Rcv	8024	18270	0xA7A5355	0xAC129A02	1
2	14	13	Snd-Rcv	8026	24768	0xA7A5355	0xAC129925	1



## CHAPTER 23

# Radio Aware Routing

Radio-Aware Routing (RAR) is a mechanism that uses radios to interact with the routing protocol OSPFv3 to signal the appearance, disappearance, and link conditions of one-hop routing neighbors.

In a large mobile networks, connections to the routing neighbors are often interrupted due to distance and radio obstructions. When these signals do not reach the routing protocols, protocol timers are used to update the status of a neighbor. Routing protocols have lengthy timer, which is not recommended in mobile networks.

The RAR feature is supported on Cisco ISR G2 and G3 Series Routers, Cisco ISR 4000 Series Routers.

PPPoE Extensions is the RAR protocol supported in Cisco 4000 Series ISRs. PPPoE Extensions with Aggregate support is introduced from Cisco IOS XE Fuji 16.7. release. OSPFv3 and EIGRP are the supported routing protocols.

- [Benefits of Radio Aware Routing, on page 231](#)
- [Restrictions and Limitations, on page 232](#)
- [Performance, on page 232](#)
- [System Components, on page 232](#)
- [QoS Provisioning on PPPoE Extension Session, on page 233](#)
- [Example: Configuring the RAR Feature in Bypass Mode, on page 233](#)
- [Verifying RAR Session Details, on page 235](#)

## Benefits of Radio Aware Routing

The Radio Aware Routing feature offers the following benefits:

- Provides faster network convergence through immediate recognition of changes.
- Enables routing for failing or fading radio links.
- Allows easy routing between line-of-sight and non-line-of-sight paths.
- Provides faster convergence and optimal route selection so that delay-sensitive traffic, such as voice and video, is not disrupted
- Provides efficient radio resources and bandwidth usage.
- Reduces impact on the radio links by performing congestion control in the router.
- Allows route selection based on radio power conservation.
- Enables decoupling of the routing and radio functionalities.

- Provides simple Ethernet connection to RFC 5578, R2CP, and DLEP compliant radios.

## Restrictions and Limitations

The Radio Aware Routing feature has the following restrictions and limitations:

- The DLEP and R2CP protocols are not supported in Cisco 4000 Series ISRs.
- Multicast traffic is not supported in aggregate mode.
- Cisco High Availability (HA) technology is not supported.

## Performance

The Radio Aware Routing feature has the ability to support a maximum of 10 neighbors per radio or VMI interface; and a total of 30 to 40 neighbors.

## System Components

The Radio Aware Routing (RAR) feature is implemented using the MANET (Mobile adhoc network) infrastructure comprising of different components such as PPPoE, Virtual multipoint interface (VMI), QoS, routing protocol interface and RAR protocols.

### Point-to-Point Protocol over Ethernet PPPoE or PPPoE

PPPoE is a well-defined communication mechanism between the client and the server. In the RAR implementation, radio takes the role of the PPPoE client and router takes the role of the PPPoE server. This allows a loose coupling of radio and router, while providing a well-defined and predictable communication mechanism.

As PPPoE is a session or a connection oriented protocol, it extends the point-to-point radio frequency (RF) link from an external radio to an IOS router.

### PPPoE Extensions

PPPoE extensions are used when the router communicates with the radio. In the Cisco IOS implementation of PPPoE, each individual session is represented by virtual access interface (connectivity to a radio neighbor) on which, QoS can be applied with these PPPoE extensions.

RFC5578 provides extensions to PPPoE to support credit-based flow control and session-based real time link metrics, which are very useful for connections with variable bandwidth and limited buffering capabilities (such as radio links).

### Virtual Multipoint Interface (VMI)

Though PPPoE Extensions provides the most of the setup to communicate between a router and a radio, VMI addresses the need to manage and translate events that higher layers (example, routing protocols) consume. In addition, VMI operates in the Bypass mode.



In Bypass mode, every Virtual Access Interface (VAI) representing a radio neighbor is exposed to routing protocols OSPFv3 and EIGRP, so that, the routing protocol directly communicates with the respective VAI for both unicast and multicast routing protocol traffic.

In Aggregate mode, VMI is exposed to the routing protocols (OSPF) so that the routing protocols can leverage VMI for their optimum efficiency. When the network neighbors are viewed as a collection of networks on a point-to-multipoint link with broadcast and multicast capability at VMI, VMI helps in aggregating the multiple virtual access interfaces created from PPPoE. VMI presents a single multi access layer 2 broadcast capable interface. The VMI layer handles re-directs unicast routing protocol traffic to the appropriate P2P link (Virtual-Access interface), and replicates any Multicast/Broadcast traffic that needs to flow. Since the routing protocol communicates to a single interface, the size of the topology database is reduced, without impacting the integrity of the network.

## QoS Provisioning on PPPoE Extension Session

The following example describes QoS provisioning on PPPoE extension session:

```
policy-map rar_policer
 class class-default
 police 10000 2000 1000 conform-action transmit exceed-action drop violate-action drop
policy-map rar_shaper
 class class-default
 shape average percent 1

interface Virtual-Template2
 ip address 10.92.2.1 255.255.255.0
 no peer default ip address
 no keepalive
 service-policy input rar_policer
end
```

## Example: Configuring the RAR Feature in Bypass Mode

The following example is an end-to-end configuration of RAR in the bypass mode:



**Note** Before you begin the RAR configuration, you must first configure the **subscriber authorization enable** command to bring up the RAR session. Without enabling authorization, the Point-to-Point protocol does not recognize this as a RAR session and may not tag *manet\_radio* in presentation of a PPPoE Active Discovery Initiate (PADI). By default, bypass mode does not appear in the configuration. It appears only if the mode is configured as bypass.

### Configure a Service for RAR

```
policy-map type service rar-lab
 pppoe service manet_radio //note: Enter the pppoe service policy name as manet_radio
!
```

### Configure Broadband

```

bba-group pppoe VMI2
 virtual-template 2
 service profile rar-lab
!
interface GigabitEthernet0/0/1
 description Connected to Client1
 negotiation auto
 pppoe enable group VMI2
!

```

### Configure a Service for RAR

```

policy-map type service rar-lab
 pppoe service manet_radio //note: Enter the pppoe service policy name as manet_radio
!

```

### Configuration in Bypass Mode

- IP Address Configured under Virtual-Template Explicitly

```

interface Virtual-Template2
 ip address 192.168.90.3 255.255.255.0
 no ip redirects
 peer default ip address pool PPPoEpool2
 ipv6 enable
 ospfv3 1 network manet
 ospfv3 1 ipv4 area 0
 ospfv3 1 ipv6 area 0
 no keepalive
 service-policy input rar_policer Or/And
 service-policy output rar_shaper

```

- VMI Unnumbered Configured under Virtual Template

```

interface Virtual-Template2
 ip unnumbered vmi2
 no ip redirects
 peer default ip address pool PPPoEpool2
 ipv6 enable
 ospfv3 1 network manet
 ospfv3 1 ipv4 area 0
 ospfv3 1 ipv6 area 0
 no keepalive
 service-policy input rar_policer Or/And
 service-policy output rar_shaper

```

### Configure the Virtual Multipoint Interface in Bypass Mode

```

interface vmi2 //configure the virtual multi interface
 ip address 192.168.2.1 255.255.0.0
 physical-interface GigabitEthernet0/0/1
 mode bypass

interface vmi3//configure the virtual multi interface
 ip address 192.168.3.1 255.255.0.0
 physical-interface GigabitEthernet0/0/1
 mode bypass

```

## Configure OSPF Routing

```
router ospfv3 1
 router-id 192.168.1.1
!
 address-family ipv4 unicast
 redistribute connected metric 1 metric-type 1
 log-adjacency-changes
 exit-address-family
!
 address-family ipv6 unicast
 redistribute connected metric-type 1
 log-adjacency-changes
 exit-address-family
!
ip local pool PPPoEpool2 192.168.12.3 192.168.12.254
```

# Verifying RAR Session Details

To retrieve RAR session details, use the following show commands:

```
Router#show pppoe session packets all
Total PPPoE sessions 2

session id: 9
local MAC address: 006b.f10e.a5e0, remote MAC address: 0050.56bc.424a
virtual access interface: Vi2.1, outgoing interface: Gi0/0/0
 1646 packets sent, 2439363 received
 176216 bytes sent, 117250290 received

PPPoE Flow Control Stats
Local Credits: 65535 Peer Credits: 65535 Local Scaling Value 64 bytes
Credit Grant Threshold: 28000 Max Credits per grant: 65535
Credit Starved Packets: 0
PADG xmit Seq Num: 32928 PADG Timer index: 0
PADG last rcvd Seq Num: 17313
PADG last nonzero Seq Num: 17306
PADG last nonzero rcvd amount: 2
PADG Timers: (ms) [0]-1000 [1]-2000 [2]-3000 [3]-4000 [4]-5000
PADG xmit: 33308 rcvd: 17313
PADC xmit: 17313 rcvd: 19709
In-band credit pkt xmit: 7 rcvd: 2434422
Last credit packet snapshot
 PADG xmit: seq_num = 32928, fcn = 0, bcn = 65535
 PADC rcvd: seq_num = 32928, fcn = 65535, bcn = 65535
 PADG rcvd: seq_num = 17313, fcn = 0, bcn = 65535
 PADC xmit: seq_num = 17313, fcn = 65535, bcn = 65535
 In-band credit pkt xmit: fcn = 61, bcn = 65533
 In-band credit pkt rcvd: fcn = 0, bcn = 65534
 ==== PADQ Statistics ====
 PADQ xmit: 0 rcvd: 0

session id: 10
local MAC address: 006b.f10e.a5e1, remote MAC address: 0050.56bc.7dcb
virtual access interface: Vi2.2, outgoing interface: Gi0/0/1
 1389302 packets sent, 1852 received
 77869522 bytes sent, 142156 received

PPPoE Flow Control Stats
```

```

Local Credits: 65535 Peer Credits: 65535 Local Scaling Value 64 bytes
Credit Grant Threshold: 28000 Max Credits per grant: 65535
Credit Starved Packets: 0
PADG xmit Seq Num: 18787 PADG Timer index: 0
PADG last rcvd Seq Num: 18784
PADG last nonzero Seq Num: 18768
PADG last nonzero rcvd amount: 2
PADG Timers: (ms) [0]-1000 [1]-2000 [2]-3000 [3]-4000 [4]-5000
PADG xmit: 18787 rcvd: 18784
PADG rcvd: 18784 rcvd: 18787
In-band credit pkt xmit: 1387764 rcvd: 956
Last credit packet snapshot
PADG xmit: seq_num = 18787, fcn = 0, bcn = 65535
PADG rcvd: seq_num = 18787, fcn = 65535, bcn = 65535
PADG rcvd: seq_num = 18784, fcn = 0, bcn = 65535
PADG xmit: seq_num = 18784, fcn = 65535, bcn = 65535
In-band credit pkt xmit: fcn = 0, bcn = 64222
In-band credit pkt rcvd: fcn = 0, bcn = 65534
==== PADQ Statistics ====
PADQ xmit: 0 rcvd: 1

```

#### Router#show pppoe session packets

Total PPPoE sessions 2

SID	Pkts-In	Pkts-Out	Bytes-In	Bytes-Out
9	2439391	1651	117252098	176714
10	1858	1389306	142580	77869914

#### Router#show vmi counters

Interface vmi2: - Last Clear Time =

##### Input Counts:

```

Process Enqueue = 0 (VMI)
Fastswitch = 0
VMI Punt Drop:
Queue Full = 0

```

##### Output Counts:

```

Transmit:
VMI Process DQ = 4280
Fastswitch VA = 0
Fastswitch VMI = 0

```

##### Drops:

```

Total = 0
QOS Error = 0
VMI State Error = 0
Mcast NBR Error = 0
Ucast NBR Error = 0

```

Interface vmi3: - Last Clear Time =

##### Input Counts:

```

Process Enqueue = 0 (VMI)
Fastswitch = 0
VMI Punt Drop:
Queue Full = 0

```

##### Output Counts:

```

Transmit:
VMI Process DQ = 2956
Fastswitch VA = 0
Fastswitch VMI = 0

```

##### Drops:

```

Total = 0
QOS Error = 0
VMI State Error = 0
Mcast NBR Error = 0
Ucast NBR Error = 0
Interface vmi4: - Last Clear Time =

```

```

Input Counts:
 Process Enqueue = 0 (VMI)
 Fastswitch = 0
 VMI Punt Drop:
 Queue Full = 0

```

```

Output Counts:
 Transmit:
 VMI Process DQ = 0
 Fastswitch VA = 0
 Fastswitch VMI = 0
 Drops:
 Total = 0
 QOS Error = 0
 VMI State Error = 0
 Mcast NBR Error = 0
 Ucast NBR Error = 0

```

Router#

Router#**show vmi neighbor details**

```

1 vmi2 Neighbors
 1 vmi3 Neighbors
 0 vmi4 Neighbors
 2 Total Neighbors

```

```

vmi2 IPV6 Address=FE80::21E:E6FF:FE43:F500
 IPV6 Global Addr=:
 IPV4 Address=192.168.2.2, Uptime=05:15:01
 Output pkts=89, Input pkts=0
 No Session Metrics have been received for this neighbor.
 Transport PPPoE, Session ID=9
 INTERFACE STATS:
 VMI Interface=vmi2,
 Input qcount=0, drops=0, Output qcount=0, drops=0
 V-Access intf=Virtual-Access2.1,
 Input qcount=0, drops=0, Output qcount=0, drops=0
 Physical intf=GigabitEthernet0/0/0,
 Input qcount=0, drops=0, Output qcount=0, drops=0

```

```

PPPoE Flow Control Stats
Local Credits: 65535 Peer Credits: 65535 Local Scaling Value 64 bytes
Credit Grant Threshold: 28000 Max Credits per grant: 65535
Credit Starved Packets: 0
PADG xmit Seq Num: 33038 PADG Timer index: 0
PADG last rcvd Seq Num: 17423
PADG last nonzero Seq Num: 17420
PADG last nonzero rcvd amount: 2
PADG Timers: (ms) [0]-1000 [1]-2000 [2]-3000 [3]-4000 [4]-5000
PADG xmit: 33418 rcvd: 17423
PADG xmit: 17423 rcvd: 19819
In-band credit pkt xmit: 7 rcvd: 2434446
Last credit packet snapshot
PADG xmit: seq_num = 33038, fcn = 0, bcn = 65535
PADG rcvd: seq_num = 33038, fcn = 65535, bcn = 65535
PADG rcvd: seq_num = 17423, fcn = 0, bcn = 65535
PADG xmit: seq_num = 17423, fcn = 65535, bcn = 65535

```

```

In-band credit pkt xmit: fcn = 61, bcn = 65533
In-band credit pkt rcvd: fcn = 0, bcn = 65534
==== PADQ Statistics ====
PADQ xmit: 0 rcvd: 0

```

```

vmi3 IPV6 Address=FE80::21E:7AFF:FE68:6100
 IPV6 Global Addr:::
 IPV4 Address=91.91.91.4, Uptime=05:14:55
 Output pkts=6, Input pkts=0
 METRIC DATA: Total rcvd=1, Avg arrival rate (ms)=0
 CURRENT: MDR=128000 bps, CDR=128000 bps
 Lat=0 ms, Res=100, RLQ=100, load=0
 MDR Max=128000 bps, Min=128000 bps, Avg=128000 bps
 CDR Max=128000 bps, Min=128000 bps, Avg=128000 bps
 Latency Max=0, Min=0, Avg=0 (ms)
 Resource Max=100%, Min=100%, Avg=100%
 RLQ Max=100, Min=100, Avg=100
 Load Max=0%, Min=0%, Avg=0%
 Transport PPPoE, Session ID=10
 INTERFACE STATS:
 VMI Interface=vmi3,
 Input qcount=0, drops=0, Output qcount=0, drops=0
 V-Access intf=Virtual-Access2.2,
 Input qcount=0, drops=0, Output qcount=0, drops=0
 Physical intf=GigabitEthernet0/0/1,
 Input qcount=0, drops=0, Output qcount=0, drops=0

```

```

PPPoE Flow Control Stats
Local Credits: 65535 Peer Credits: 65535 Local Scaling Value 64 bytes
Credit Grant Threshold: 28000 Max Credits per grant: 65535
Credit Starved Packets: 0
PADG xmit Seq Num: 18896 PADG Timer index: 0
PADG last rcvd Seq Num: 18894
PADG last nonzero Seq Num: 18884
PADG last nonzero rcvd amount: 2
PADG Timers: (ms) [0]-1000 [1]-2000 [2]-3000 [3]-4000 [4]-5000
PADG xmit: 18896 rcvd: 18894
PADG xmit: 18894 rcvd: 18896
In-band credit pkt xmit: 1387764 rcvd: 961
Last credit packet snapshot
PADG xmit: seq_num = 18896, fcn = 0, bcn = 65535
PADG rcvd: seq_num = 18896, fcn = 65535, bcn = 65535
PADG rcvd: seq_num = 18894, fcn = 0, bcn = 65535
PADG xmit: seq_num = 18894, fcn = 65535, bcn = 65535
In-band credit pkt xmit: fcn = 0, bcn = 64222
In-band credit pkt rcvd: fcn = 0, bcn = 65534
==== PADQ Statistics ====
PADQ xmit: 0 rcvd: 1

```

```

Router#show vmi neighbor details vmi 2

```

```

1 vmi2 Neighbors

```

```

vmi2 IPV6 Address=FE80::21E:E6FF:FE43:F500
 IPV6 Global Addr:::
 IPV4 Address=192.168.2.2, Uptime=05:16:03
 Output pkts=89, Input pkts=0
 No Session Metrics have been received for this neighbor.
 Transport PPPoE, Session ID=9
 INTERFACE STATS:
 VMI Interface=vmi2,
 Input qcount=0, drops=0, Output qcount=0, drops=0
 V-Access intf=Virtual-Access2.1,

```

```

Input qcount=0, drops=0, Output qcount=0, drops=0
Physical intf=GigabitEthernet0/0/0,
Input qcount=0, drops=0, Output qcount=0, drops=0

```

```

PPPoE Flow Control Stats
Local Credits: 65535 Peer Credits: 65535 Local Scaling Value 64 bytes
Credit Grant Threshold: 28000 Max Credits per grant: 65535
Credit Starved Packets: 0
PADG xmit Seq Num: 33100 PADG Timer index: 0
PADG last rcvd Seq Num: 17485
PADG last nonzero Seq Num: 17449
PADG last nonzero rcvd amount: 2
PADG Timers: (ms) [0]-1000 [1]-2000 [2]-3000 [3]-4000 [4]-5000
PADG xmit: 33480 rcvd: 17485
PADG rcvd: 17485 rcvd: 19881
In-band credit pkt xmit: 7 rcvd: 2434460
Last credit packet snapshot
PADG xmit: seq_num = 33100, fcn = 0, bcn = 65535
PADG rcvd: seq_num = 33100, fcn = 65535, bcn = 65535
PADG rcvd: seq_num = 17485, fcn = 0, bcn = 65535
PADG xmit: seq_num = 17485, fcn = 65535, bcn = 65535
In-band credit pkt xmit: fcn = 61, bcn = 65533
In-band credit pkt rcvd: fcn = 0, bcn = 65534
==== PADQ Statistics ====
PADQ xmit: 0 rcvd: 0

```

#### Router#show platform hardware qfp active feature ess session

```

Current number sessions: 2
Current number TC flow: 0
Feature Type: A=Accounting D=Policing(DRL) F=FFR M=DSCP Marking L=L4redirect P=Portbundle
T=TC

```

Session	Type	Segment1	SegType1	Segment2	SegType2	Feature	Other
21	PPP	0x0000001500001022	PPPOE	0x0000001500002023	LTERM	-----	
24	PPP	0x0000001800003026	PPPOE	0x0000001800004027	LTERM	-----	

#### Router#show platform software subscriber pppoe\_fctl evsi 21

```

PPPoE Flow Control Stats
Local Credits: 65535 Peer Credits: 65535 Local Scaling Value 64 bytes
Credit Grant Threshold: 28000 Max Credits per grant: 65535
Credit Starved Packets: 0
PADG xmit Seq Num: 33215 PADG Timer index: 0
PADG last rcvd Seq Num: 17600
PADG last nonzero Seq Num: 17554
PADG last nonzero rcvd amount: 2
PADG Timers: (ms) [0]-1000 [1]-2000 [2]-3000 [3]-4000 [4]-5000
PADG xmit: 33595 rcvd: 17600
PADG rcvd: 17600 rcvd: 19996
In-band credit pkt xmit: 7 rcvd: 2434485
Last credit packet snapshot
PADG xmit: seq_num = 33215, fcn = 0, bcn = 65535
PADG rcvd: seq_num = 33215, fcn = 65535, bcn = 65535
PADG rcvd: seq_num = 17600, fcn = 0, bcn = 65535
PADG xmit: seq_num = 17600, fcn = 65535, bcn = 65535
In-band credit pkt xmit: fcn = 61, bcn = 65533
In-band credit pkt rcvd: fcn = 0, bcn = 65534

```

#### BQS buffer statistics

```

Current packets in BQS buffer: 0
Total en-queue packets: 0 de-queue packets: 0
Total dropped packets: 0

```

Internal flags: 0x0

Router#show platform hardware qfp active feature ess session id 21  
Session ID: 21

```

EVSI type: PPP
SIP Segment ID: 0x1500001022
SIP Segment type: PPPOE
FSP Segment ID: 0x1500002023
FSP Segment type: LTERM
QFP if handle: 16
QFP interface name: EVSI21
SIP TX Seq num: 0
SIP RX Seq num: 0
FSP TX Seq num: 0
FSP RX Seq num: 0
Condition Debug: 0x00000000
session

```

Router#show ospfv3 neighbor

```

 OSPFv3 1 address-family ipv4 (router-id 192.168.3.3)

Neighbor ID Pri State Dead Time Interface ID Interface
192.168.1.1 0 FULL/ - 00:01:32 19 Virtual-Access2.1

 OSPFv3 1 address-family ipv6 (router-id 192.168.3.3)

Neighbor ID Pri State Dead Time Interface ID Interface
192.168.1.1 0 FULL/ - 00:01:52 19 Virtual-Access2.1
Router#

```

Router#sh ip route

```

Codes: L - local, C - connected, S - static, R - RIP, M - mobile, B - BGP
D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
E1 - OSPF external type 1, E2 - OSPF external type 2
i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
ia - IS-IS inter area, * - candidate default, U - per-user static route
o - ODR, P - periodic downloaded static route, H - NHRP, l - LISP
a - application route
+ - replicated route, % - next hop override, p - overrides from PfR

Gateway of last resort is not set

 192.168.0.3/8 is variably subnetted, 3 subnets, 2 masks
C 192.168.3.0/24 is directly connected, Virtual-Access2.1
O 192.168.4.0/32 [110/1] via 192.168.4.0, 00:00:03, Virtual-Access2.1
L 192.168.5.0/32 is directly connected, Virtual-Access2.1
 192.168.0.5/32 is subnetted, 1 subnets
C 192.168.2.21 is directly connected, Virtual-Access2.1

```