# Wi-Fi Home Security Camera

User Manual Version: May, 2020





Stereo speaker + Wireless charger+Clock camera









(14) Loudspeaker;

(15) USB port;

(16) AUX;

(17) 12V DC;

(19) Reset;

(18) Wi-Fi camera

microphone:


(20) Micro SD card slot;


(22) Indicator light;


(21) ON/OFF for Camera:

(23) Speaker diaphragm;









8

(16) Two-way audio speaker


- Camera:
- Night vision LED;
- (3) Bluetooth icon;
- Short press for V-, long press for Previous;
- Short press for V+. Iona press for Next;
- Short press for Pause / Pick up phone, Long press for Celsius and Fahrenheit:
- (1) Speaker On/Off;
- Short press for Time setting, Long press for 12 Hour / 24 Hour;
- (9) Q Alarm setting;
- ( Snooze;
- (11) 5W Wireless Charging Zone;
- (12) Wireless Charging Indicator;
- (13) Bluetooth Microphone;

# Wireless charging function:

- 1. Device with 4500mA built-in battery, pls plug in power or charge it
- 2. One press top On/Off to turn on the wireless charger;
- 3. Charge your phone;
- 4. Twice press top On/Off to turn off the wireless charger;

### Stereo speaker function:

- 1. Turn on speaker:
- Short press back bluetooth button (12) to turn on, it will say "DingDong"
- 2. Pair with smart phone:
- Phone setting=>Bluetooth=>find signal BT=>click to connect;
- Short press back bluetooth button 2 to turn off speaker;
- 4. Disconnect bluetooth:
- Phone setting=>Bluetooth=>find signal BT=>click to disconnect;
- 5. Automatically be off:
  - a. Speaker is not paired with phone in 5 minutes after turned











# Speaker Operation:

- 1. Turn on speaker:
- Short press above to turn on, with start tone;
- 2. Pair with smart phone:
- Phone setting=>Bluetooth=>find signal 019 BT=>click to connect:
- 3. Turn off speaker:
- Short press above () to turn off, with end tone;
- 4. Disconnect bluetooth:
  - Phone setting=>Bluetooth=>find signal 019 BT=>click to disconnect;
- 5. Automatically be off:
  - a. Speaker is not paired with phone in 10 minutes after turned On; b. There's no paired phone in speaker's receiving range with in 10

# Common fault solution:

- 1. Cannot connect to the speaker
- > Delete 019 BT from the phone's Bluetooth pairing list, and search 019 BT again;
- 2. Cannot search the speaker
- > When heard start tone, it will be found.

Tips: This product is without internal battery, please use package included 12V 2.5A DC adaptor to power on.

6

- b. There's no paired phone in speaker's receiving range with in 5 minutes:
- c. Speaker's battery less then 5%.

### Common fault solution:

- 1. Cannot connect to the speaker
- > Delete BT from the phone's Bluetooth pairing list, and search BT again:
- 2. Cannot search the speaker
- > Turn off speaker, and turn on again when heard "DingDong", it will be found

### Overview:

This security Wi-Fi camera kit is equipped with a powerful 1080p smart Wi-Fi camera for live streaming video, and it comes with motion detection video recording and alarm.

Mini design and easy hidden to DIY any kinds of unique and exclusive security cameras for home & business surveillance.

Usages: Nanny camera, home/ shop/ office/ warehouse surveillance camera.....

Warning: " illegal use is not allowed! Or, there will be consequences to bear! '

### In the box:

### Clock charger

- 1 x Wi-Fi camera
- 1 x 12V 2.5A DC power adapter
- 1 x Reset pin
- 1 x Cable
- 1 x User manual
- 1 x Micro SD card reader
- 1 x USB Cable 1 x User manual


1 x Reset pin

1 x Micro SD card reader

Wireless charger

1 x Wi-Fi camera

Product instruction



- (1) Camera lens
- (2) Wireless charging area
- (3) Wireless charging indicator
- (4) Battery indicator
- (5) On/Off for wireless charger
- (6) Stereo speaker
- (7) (8) Invisible night vision LEDs
- (12) On/Off for Speaker (13) Reset for Wi-Fi camera

(10) Speaker indicator

(1) Charging port

- (14) Indicator for Wi-Fi camera
- (15) On/Off for Wi-Fi camera

# Getting started of Wi-Fi camera part

Step1: Download and install APP

Search and download free APP named "HDSmartIPC" in Apple APP store, Google play or Electronic market, and install it.



**HDSmartIPC** 

Step 2: Plug in power and turn switch to ON, wait for 1 minute:

11

Step 3:Connect WiFi

10

 Open smartphone settings, search and connect the device's wireless signal named"AI/LM.....", wait Wi-Fi connected, and phone status bar appear Wi-Fi symbol.



2. Eneter APP, app will add just connected camera automatically, Camera Online then;



TIPS: This step = P2P mode, can check video locally when without Wi-Fi.

# APP introduction:




16

### **Specification**

•	
Sensor	2.0 Mega pixel CMOS Lens
Video resolution	Max 1920*1080
Frames	Max 25fps
Compressed format	H.264
View Angel	120° / 90°
Night Vision	Invisible 6M
Type of Memory Card	TF>=Class 4/10 HC Marked
Capacity of Memory Card	Max 128GB
PC operation system	Windows 7,8/Mac OS X
Mobile Phone operation system	Android/iOS
Video Player	VLC Player/SM Player
Recording	1min/20mb
Power adapter	12V/2.5A
Wireless charger power	5 W


20

3.Press the gear icon after the camera and select Device settings ,select Wi-Fi Config.



13

# Live video page - Click camera to check



### FAQ

- Q: Can't get device Wi-Fi signal?
   A:Press reset key for 10 seconds and wait 1 minute.
- Q: Live video not smooth and clear?
   A: Select suitable resolution according to the real time network environment.
- 3. Q: Motion detect set and alarm?
  - A: 1). Set motion detect sensitivity in Motion alarm config;
    2). When motion detected, camera will push a alarm message to your phone and take one picture for checking in the APP [Page 16 Message]. (A micro sd card MUST be inserted for saving alarm pictures)
- 4. Q: How to play micro SD card video?
  - A: 1). Use a card reader to read and play;
  - 2). Use APP to play back [ Page 16 📗 ];
  - 3). Play back in good speed network.

- 4. Select the router Wi-Fi and input password, camera will be connected to the router Wi-Fi. The smartphone will disconnect the signal from device and connect to the router Wi-Fi.
- 5. Quit APP, and device restart automatically and ready again in 30 seconds.
- 6. Enter APP and check live video locally or remotely anywhere.



Set name: Set camera name like, Office. Living room. Kids room...
Set new password: Set camera new password
Wi-Fi config: Set camera to other Wi-Fi
Video setting: Set SD card record mode /
Resolution /File length ...
Motion alarm config: Set motion detection sensitivity
Camera info: Camera ip address, Mac address, Reboot...

**TIPS**: Each setting in Device Settings, please scroll down and press ok to save the setting.

# 18


- 5. Q: Forget camera password, or item goes abnormal? A: Turn on camera and wait for 1 minute, press reset key around 10 seconds till back indicators off to restore factory default. Camera restarts and get ready again in 1 minute.
- Q: Any operation video demo of the camera for setting up?
   A: Please contact local dealer for video guide.

22

# Set camera name and private code

Set name:Press the after the camera and select Device settings,select Set name, insert name like Office,Room.....

Set new password:Press the fafter the camera and select Device settings,select Set new password and change it to new one. Default one is 8888.



Set and watch by PC remotely (Windows Only)



### Scan to download PC Client

This device complex with part 16 of the YSC Plans. Operation is project to the following few conditions (1) this device may not people benefit the foreign and

(ii) This device mad accompany mechanism modes, including interferons that you make interest specialist.

Therefore in recollections had represent agreeming the party responsible for purplement must need the warry suffering to represent the experience from experience that the source of the party suffering to the purplement of the source of the

- 1 Rooted or organic for movining arterior.
- " I tremost the according behavior the apparent and reserve.
- Constitute appropriate an artistic control and office of the field in which the monter is consisted.
- - Consult the Joseph or an experienced sales by September 14 help-

The apparent complex with the CCC ET validate appropriation and half As an executable execution. The apparent should be constant and appeared with a material at these believes the political and any and of year beginning.

21