


<Photographs of EUT>


Handle not removed



Remove the handle



<Antenna Location>



<EUT Front View>

Antenna	Supported bands
WIFI ANT	WLAN 2.4G/5G
Special 2.4GHz Wireless ANT0	Special 2.4GHz Wireless
Special 2.4GHz Wireless ANT1	Special 2.4GHz Wireless

<Photographs of SAR Setup>



Fig-4.1 Front Face of EUT with 0 cm Gap (Extremity Mode)




Fig-4.2 Rear Face of EUT with 0 cm Gap (Extremity Mode)




Fig-4.3 Left Side of EUT with 0 cm Gap (Extremity Mode)




Fig-4.4 Right Side of EUT with 0 cm Gap (Extremity Mode)




Fig-4.5 Top Side of EUT with 0 cm Gap (Extremity Mode)




Fig-4.6 Bottom Side of EUT with 0 cm Gap (Body Mode)