

Safety and Notice:↵

↵

Safety:↵

- Do not disassemble.↵
- Do not place near any high heat as direct sun light, fire, microwave and or the like.↵
- Do not expose the device to dripping or splashing water.↵
- Clean with a dry, soft lint-free cloth, do not use any corrosive cleaner or oil.↵
- Use original or certified cables.↵
- Avoid dropping from heights.↵

↵

FCC Statement:↵

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. ↵

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.↵

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. ↵

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:↵

- Reorient or relocate the receiving antenna.↵
- Increase the separation between the equipment and receiver↵
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.↵
- Consult the dealer or an experienced radio/TV technician for help↵

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.↵

The device has been evaluated to meet general RF exposure requirement.↵

↵

Trademark:↵

- Bluetooth: The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by C-Media Electronics Inc. is under license.↵
- Xear™, Cmedia™ word mark and logos are registered trademarks owned by C-Media Electronics, Inc.↵
- Other trademarks and trade names are those of their respective owners.↵

↵

使用安全：↵

- 請勿拆解設備。↵
- 請勿將本設備放置於高溫處或加熱設備周圍，例如高溫陽光曝曬、火源旁、微波爐等。↵
- 請勿將本設備曝露於滴水或濺水中。↵
- 請使用柔軟不起塵的乾布擦拭，請勿使用腐蝕性的清潔劑或是油料。↵
- 請使用隨附或是合格的線材。↵
- 避免本設備從高處摔落。↵

↵

低功率射頻器材技術規範：↵

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。↵

↵

版權宣告：↵

- Bluetooth: The Bluetooth® 為藍牙技術聯盟的註冊商標，驊訊電子企業股份有限公司對此的任何使用已獲得授權。↵
- Xear™, Cmedia™ 為驊訊電子企業股份有限公司的註冊商標。↵
- 本產品標示或使用的第三方商標與著作權屬於第三方所有權公司所有。↵

Safety:

- Do not disassemble.
- Do not place near any high heat as direct sun light, fire, microwave and or the like.
- Do not expose the device to dripping or splashing water.
- Clean with a dry, soft lint- free cloth, do not use any corrosive cleaner or oil.
- Use original or certified cables.
- Avoid dropping from heights.

■ CSP-102 Bluetooth Speakerphone Quick Start Guide


↩

- 產品高清線稿圖
- Kuro CSP-102 Bluetooth Speakerphone
- Kuro Logo + Website: www.kuro.com.tw
- 認證 Logo: Bluetooth/CE/FCC/NCC/BSMI
- Kuro QRCode
- English / 正體中文

↩

↩

▪ How to Use: & 使用說明：↵



(1) Power On/Off & 電源開啟/關閉↵

(2) Volume Up & 音量增加↵

(3) Volume Down & 音量減少↵

(4) Mute Button & 靜音鍵↵

(5) Mode Switch & 模式切換↵

(6) Answer/Hand Up & 接聽/掛斷↵

(F1) Bluetooth Button & 藍牙按鍵↵

(F2) USB Type-C Connect & USB Type-C 端口↵

(F3) 3.5mm Audio Jack & 3.5mm 音訊端口↵

(BK say: 請忽略 H & B)↵

↵

(1) Long press to power on/off. & 長按開機/關機。↵

(2) Mute/unmute in conference mode & 會議模式中靜音切換。↵

(3)&(4) Turn up/down volume. & 調高或降低音量。↵

(5) Music/Conference Mode Switch. & 切換音樂及會議模式。↵

(6) Tap to answer/hang up call. (Smartphone Bluetooth connected) Long-press to activate smartphone's voice assistant. (Music Mode) Play/Pause. & 電話來電時可接聽及掛斷。(手機藍牙連線時) 長按可執行智能手機語音助手。(音樂模式) 播放及暫停。↵

(F1) Press to enter the pairing mode, long-press to enable/disable Bluetooth. & 按下後進入藍牙配對模式，長按可開啟/關閉藍牙功能。↵

(F2) Battery charge and USB Audio Connection. & 充電輸入及 USB 音訊連線使用。↵

(F3) Extend CSP-102 as Audio-Output & Microphone-In for Smartphone or PC. & 將 CSP-102 作為智能手機或是電腦的音源輸出及麥克風輸入裝置使用。↵

↵

Note: & 註：↵

Please charge before you use. & 請在使用前先充電。↵

▪ How to Connect: & 連接說明：↵

↵

(1) Bluetooth Wireless Connection & 無線藍牙連線：示意可對手機及電腦。↵

(2) USB Wired Connection & 有線 USB 連線：示意主要是電腦。↵

(3) 3.5mm 音源線：示意手機透過 3.5mm 音源線接 CSP-102。↵

↵

(BK say: 要畫圖 ...)↵

↵

▪ Package Contents: & 包裝清單：↵

↵

(1) CSP-102 Device & CSP-102 設備↵

(2) Quick Start Guide & 快速入門指南↵

(3) USB Type-A to Type-C Cable & USB Type-A 對 Type-C 線材↵

(4) 3.5mm CTIA Audio Cable & 3.5mm CTIA 四環音源線↵

↵

(BK say: 要畫圖 ...)↵

↵

▪ Use Scenario: & 使用場景：↵

↵

(1) Meeting Room & 會議室：半徑六米內六人在會議室開會效果圖，強調距離、收音。↵

(2) Portable & 便攜性：隨身攜帶音樂享樂效果圖，強調大功率音樂輸出效果。↵

↵

(BK say: 要畫圖 ...)↵

↵

↵

↵

↵

▪ Product Specification & 產品規格：↵

↵

Product Name: Kuro Bluetooth Speakerphone↵

Model: CSP-102↵

Microphone: Omni-directional $-35 \pm 2\text{dBV}$ ↵

Speaker Output: 1.8" 6W Full Range↵

USB Connector Type: USB Type-C↵

Charge Input: 5V/1.2A (Max)↵

Audio Cable: 3.5mm CTIA Type↵

Bluetooth Version: Bluetooth 5.0, 10M↵

Bluetooth Protocol: A2DP, HFP/HSP, AVRCP↵

Battery: 18650 Li-Ion 3.7V 5,200mAh↵

Usage Time: (Music Mode) 10 Hours / (Conference Mode) 20 Hours↵

↵

產品名稱：酷樂藍牙會議機↵

產品型號：CSP-102↵

麥克風：全向性麥克風 $-35 \pm 2\text{dBV}$ ↵

喇叭輸出：1.8" 6W Full Range↵

充電接口：USB Type-C↵

充電電流：5V/1.2A (Max)↵

音源連接：3.5mm CTIA Type↵

藍牙版本：Bluetooth 5.0 有效距離 10M 內↵

藍牙協議：A2DP, HFP/HSP, AVRCP↵

電池規格：18650 鋰電池 3.7V 5,200mAh↵

使用時間：(音樂模式) 10 小時 / (會議模式) 20 小時↵

↵