



Cisco DCNM Compatibility Matrix, Release 10.4(2)

[Compatibility Matrix for Cisco DCNM, Release 10.4\(2\)](#) 2

Compatibility Matrix for Cisco DCNM, Release 10.4(2)

The below table shows the Cisco DCNM Compatibility Matrix for Release 10.4(2).

Cisco MDS 9100	8.2(1), 8.1(1a), 8.1(1), 7.3(1)DY(1), 7.3(1)D1(1), 7.3(0)DY(1), 7.3(0)D1(1), 6.2(23), 6.2.(21), 6.2(19), 6.2(17), 6.2(15), 6.2(13b), 6.2(13a), 6.2(13), 6.2(11c), 6.2(11b), 6.2(11), 6.2(9a), 6.2(9), 6.2(7), 6.2(5a), 6.2(5), 6.2(3), 6.2(1), 5.2(8i), 5.2(8h), 5.2(8c), 5.2(8d), 5.2(8e), 5.2(8f), 5.2(8g)
Cisco MDS 9200	8.2(1), 8.1(1a), 8.1(1), 7.3(1)DY(1), 7.3(1)D1(1), 7.3(0)DY(1), 7.3(0)D1(1), 6.2(23), 6.2.(21), 6.2(19), 6.2(17), 6.2(15), 6.2(13b), 6.2(13a), 6.2(13), 6.2(11c), 6.2(11b), 6.2(11), 6.2(9b), 6.2(9a), 6.2(9), 6.2(7), 6.2(5a), 6.2(5), 6.2(3), 6.2(1), 5.2(8h), 5.2(8c), 5.2(8d), 5.2(8e), 5.2(8f), 5, 2(8g)
Cisco MDS 9300	8.2(1), 8.1(1a), 8.1(1), 7.3(1)DY(1), 7.3(1)D1(1), 7.3(0)DY(1), 7.3(0)D1(1), 6.2(23), 6.2.(21), 6.2(19), 6.2(17), 6.2(15), 6.2(13b), 6.2(13a), 6.2(13)
Cisco MDS 9500	7.3(1)DY(1), 7.3(1)D1(1), 7.3(0)DY(1), 7.3(0)D1(1), 6.2(23), 6.2.(21), 6.2(19), 6.2(17), 6.2(15), 6.2(13b), 6.2(13a), 6.2(13), 6.2(11c), 6.2(11b), 6.2(11), 6.2(9b), 6.2(9a), 6.2(9), 6.2(7), 6.2(5a), 6.2(5), 6.2(3), 6.2(1), 5.2(8h), 5.2(8c), 5.2(8d), 5.2(8e), 5.2(8f), 5.2(8g)
Cisco MDS 9700	8.2(1), 8.1(1a), 8.1(1), 7.3(1)DY(1), 7.3(1)D1(1), 7.3(0)DY(1), 7.3(0)D1(1), 6.2(23), 6.2.(21), 6.2(19), 6.2(17), 6.2(15), 6.2(13b), 6.2(13a), 6.2(13), 6.2(11c), 6.2(11b), 6.2(11), 6.2(9b), 6.2(9a), 6.2(9), 6.2(7), 6.2(5a), 6.2(5), 6.2(3), 6.2(1)
Cisco Nexus 9000v	7.0(3)I7(2), 7.0(3)I7(1), 7.0(3)I6(2)
Cisco Nexus 9000 Series	7.0(3)F3(2), 7.0(3)F3(1), 7.0(3)F1(2), 7.0(3)I7(3), 7.0(3)I7(2), 7.0(3)I7(1), 7.0(3)I6(2), 7.0(3)I6(1), 7.0(3)F2(1), 7.0(3)F1(1), 7.0(3)I2(4), 7.0(3)I2(5), 7.0(3)I4(5), 7.0(3)I4(6), 7.0(3)I5(2), 7.0(3)I5(1), 7.0(3)I4(8), 7.0(3)I4(7), 7.0(3)I4(4), 7.0(3)I4(3), 7.0(3)I4(2), 7.0(3)I4(1), 7.0(3)I3(2), 7.0(3)I3(1), 7.0(3)I2.3, 7.0.3.I2.2c, 7.0(3)I2.2a, 7.0(3)I2.1, 7.0(3)I1.3, 7.0(3)I1.2, 6.2(9), 6.1(2)I3.4, 6.1(2)I3.2, 6.1(2)I3(1), 6.1(2)I2(1), 6.1(2)I1(2), 6.1(2)I1(1)
Cisco Nexus 7000 Series	8.2(1), 8.1(2), 8.1(1), 8.0(1), 7.3(2)D1(3), 7.3(2)D1(2), 7.3(2)D1(1), 7.3(1)D1(1), 7.3(0)DX(1), 7.3(0)D1(1), 7.2(2)D1(2), 7.2(2)D1(1), 7.2(1)D1(1), 7.2(0)D1(2), 7.2(0)D1(1), 6.2(20), 6.2(18), 6.2(16), 6.2(14), 6.2(12), 6.2(10), 6.2(8), 6.2(6a), 6.2(6), 6.2(2a), 6.2(2), 6.1, 6.0, 5.2, 5.1, 5.0, 4.2, 4.1, 4.0
Cisco Nexus 7700 Series	8.2(1), 8.1(2), 8.1(1), 8.0(1), 7.3(2)D1(3), 7.3(2)D1(2), 7.3(2)D1(1), 7.3(1)D1(1), 7.3(0)DX(1), 7.3(0)D1(1), 7.2(2)D1(2), 7.2(2)D1(1), 7.2(1)D1(1), 7.2(0)D1(2), 7.2(0)D1(1), 6.2(20), 6.2(18), 6.2(16), 6.2(14), 6.2(10), 6.2(8), 6.2(6a), 6.2(6), 6.2(2a), 6.2.2
Cisco Nexus 6000/5600 Series	7.3(3)N1(1), 7.3(2)N1(1), 7.3(1)N1(1), 7.3(0)N1(1), 7.2(1)N1(1), 7.1(5)N1(1), 7.2(0)N1(1), 7.1(5)N1(1), 7.1(4)N1(1), 7.1(3)N1(2), 7.1(3)N1(1), 7.1(2)N1(1), 7.1(1)N1(1), 7.1(0)N1(1), 7.0(8)N1(1), 7.0(7)N1(1), 7.0(6)N1(1), 7.0(5)N1(1), 7.0(4)N1(1), 7.0(3)N1(1), 7.0(2)N1(1), 7.0(1)N1(1), 6.0(2)N2(7), 6.0(2)N2(2), 6.0(2)N2(1), 6.0(2)N1(2)
Cisco Nexus 5000 Series	7.3(2)N1(1), 7.3(1)N1(1), 7.3(0)N1(1), 7.2(1)N1(1), 7.2(0)N1(1), 7.1(5)N1(1), 7.1(4)N1(1), 7.1(3)N1(2), 7.1(3)N1(1), 7.1(2)N1(1), 7.1(1)N1(1), 7.1(0)N1(1), 7.0(8)N1(1), 7.0(7)N1(1), 7.0(6)N1(1), 7.0(5)N1(1), 7.0(4)N1(1), 7.0(3)N1(1), 7.0(2)N1(1), 7.0(1)N1(1), 6.0(2)N2(7), 6.0(2), 5.2(1)N1(9a), 5.2(1)N1(9), 5.2(1), 5.1(3), 5.0(3), 5.0(2), 4.2(1), 4.1(3)
Cisco Nexus 4000 Series	4.1(2)
Cisco Nexus 3500 Series	7.0(3)I7(1), 7.0(3)I2(4), 7.0(3)I2(5), 7.0(3)I4(5), 7.0(3)I4(6), 7.0(3)I4(7), 7.0(3)I4(8), 7.0(3)I5(2), 7.0(3)I5(1), 7.0(3)I4(4), 7.0(3)I4(3), 7.0(3)I4(2), 7.0(3)I4(1), 7.0(3)I3(2), 7.0(3)I3(1), 7.0(3)I2.3, 7.0(3)I2.2a, 7.0(3)I2.1, 6.0(2)U3(2), 6.0(2)A3(1), 6.0(2)A1(1d), 5.0(3)A1(2a)

Cisco Nexus 3100 Series	7.0(3)I7(3), 7.0(3)I7(2), 7.0(3)I7(1), 7.0(3)I6(2), 7.0(3)I6(1), 7.0(3)I2(4), 7.0(3)I2(5), 7.0(3)I4(5), 7.0(3)I4(6), 7.0(3)I4(7), 7.0(3)I4(8), 7.0(3)I5(2), 7.0(3)I5(1), 7.0(3)I4(4), 7.0(3)I4(3), 7.0(3)I4(2), 7.0(3)I4(1), 7.0(3)I3(1), 7.0(3)I2.3, 7.0(3)I2.2a, 7.0(3)I2.1, 6.0(2)U3(2), 6.0(2)U3(1), 6.0(2)U2(1), 6.0(2)U2(1)
Cisco Nexus 3000 Series	7.0(3)I7(3), 7.0(3)I7(2), 7.0(3)I7(1), 7.0(3)I6(2), 7.0(3)I6(1), 7.0(3)I2(4), 7.0(3)I2(5), 7.0(3)I4(5), 7.0(3)I4(6), 7.0(3)I4(7), 7.0(3)I4(8), 7.0(3)I5(2), 7.0(3)I5(1), 7.0(3)I4(4), 7.0(3)I4(3), 7.0(3)I4(2), 7.0(3)I3(2), 7.0(3)I3(1), 7.0(3)I2.3, 7.0(3)I2.2a, 7.0(3)I2.1, 6.0(2)U3(2), 6.0(2)U3(1), 6.0(2)U2(3), 6.0(2)U2(1), 6.0(2)U1(3), 6.0(2)A1(1b), 6.0(2)A1(1a), 6.0(2)A1(1), 6.0(2)U1(2), 6.0(2)U1(1), 5.0(3)U5(1i), 5.0(3)U4(1), 5.0(3)A1(2a), 5.0(3)U5(1e), 5.0(3)U4, 5.0(3)U3, 5.0(3)U2, 5.0(3)U1,
Cisco Nexus 1010 Series	4.2(1)SP1(6.1), 4.2(1)SP1(5.1a) , 4.2(1)SP1(4a)
Cisco Nexus 1000v Series	5.2(1)SV3(1.4), 4.2(1)SV2(2.3), 4.2(1)SV2(2.2), 4.2(1)SV2(2.1), 4.2(1)SV2(1.1), 4.2(1)SV1(4), 5.2(1)SM1(5.1)
UCS FI	3.0.2d, 2.2.5a
Unified Computing System	1.4, 2.0



Note The Cisco NX-OS version of the Cisco Nexus 2000 Series Fabric Extenders will be same as the NX-OS version of the supported Nexus switch (that is, Cisco Nexus 5000, Cisco Nexus 7000 or Cisco Nexus 9000).

Interoperability Matrix for Cisco Nexus and MDS 9000 Products

For Cisco DCNM Connect Support, see the [Interoperability Matrix for Cisco Nexus and MDS 9000 Products](#).



Americas Headquarters
Cisco Systems, Inc.
San Jose, CA 95134-1706
USA

Asia Pacific Headquarters
CiscoSystems(USA)Pte.Ltd.
Singapore

Europe Headquarters
CiscoSystemsInternationalBV
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.