

Check welk model iPad je hebt

Bekijk aan de achterkant van je iPad welk model je hebt en zoek dit nummer op in de tabel

Model A1###



iPad model	Model nummer	Inch	Jaar	Aansluiting
iPad Pro 12,9-inch (3e gen.)	A1876, A2014, A1895, A1983	12,9	2018	USB-C
iPad Pro 11-inch	A1980, A2013, A1934, A1979	11	2018	USB-C
iPad Pro 12,9-inch (2e gen)	A1670, A1671, A1821	12,9	2017	Lightning
iPad Pro (10,5-inch)	A1701, A1709, A1852	10,5	2017	Lightning
iPad Pro (9,7-inch)	A1673, A1674, A1675	9,7	2016	Lightning
iPad Pro (12,9-inch)	A1584, A1652	12,9	2015	Lightning
iPad Air 2019 (3e gen)	A2152, A2123, A2154	10,5	2019	Lightning
iPad Air 2	A1566, A1567	9,7	2014	Lightning
iPad Air	A1474, A1475, A1476	9,7	2013	Lightning
iPad mini (5e gen)	A2133, A2124, A2126, A2125	7,9	2019	Lightning
iPad mini 4	A1538, A1550	7,9	2015	Lightning
iPad mini 3	A1599, A1600	7,9	2014	Lightning
iPad mini 2	A1489, A1490, A1491	7,9	2013	Lightning
iPad mini	A1432, A1454, A1455	7,9	2012	Lightning
iPad 2018 (6e gen)	A1893, A1954	9,7	2018	Lightning
iPad 2017 (5e gen)	A1822, A1823	9,7	2017	Lightning
iPad 4	A1458, A1459, A1460	9,7	2012	Lightning
iPad 3	A1416, A1430, A1403	9,7	2012	30-pins
iPad 2	A1395, A1396, A1397	9,7	2011	30-pins
iPad	A1219, A1337	9,7	2010	30-pins