



OTG Support List

Brand Name	Smartphone/Tablet	Model Name	Note		
Acer	Tablet	Iconia A1-810			
		Iconia A1-811			
		Iconia A3-A10			
ASUS	Tablet	Nexus 7,Nexus 7 2	*App "Nexus Media Importer" required: Nexus 7,Nexus 7 2		
	Smartphone	PadFone,PadFone 2,PadFone Infinity, The New PadFone Infinity			
	Tablet	Fonepad	*Fonepad need to update F/W to V3.2.2		
		MeMO Pad 8 (ME180A)			
		MeMO Pad 10 (ME180A)			
MeMO Pad FHD 10 LTE MeMO Pad FHD 10 Transformer Pad TF700T,701T					
hTC	Smartphone	Desire 500,600,U,X, +, HTC J Butterfly,Butterfly S			
		One,One X,One X+,One Dual, One mini, One Max,New One,One(M8)	*Android 4.1.1 required:One X, HTC J		
Huawei	Smartphone	Ascend D2,Ascend P1,Ascend P6,Stream X GL07S(Japan)			
	Tablet	MediaPad 7 Youth,Vogue MediaPad 10 FHD			
Lenovo	Smartphone	Lenovo LePhone P770,Lenovo Vibe Z K910, Lenovo Vibe X S960			
	Tablet	IdeaTab A3000,IdeaTab A1000, IdeaTab S6000			
LG	Smartphone	Nexus 5 Optimus G Pro,GJ,G2,G Pro Lite,G Pro Lite Dual			
Motorola	Smartphone	RAZR M			
MSI	Tablet	Enjoy 7 Plus,10 Plus Primo 73,76,81,91			
NOKIA	Tablet	NOKIA Lumia 2520			
Samsung	Smartphone	Galaxy Ace,Ace 2,Ace 3 Galaxy S2,S2 PLUS,S3,S4,S4 ZOOM,S4 LTE-A,S5 Galaxy Mega 6.3 Galaxy J,WIN	Needed USB Connection adapter : Galaxy Note 10.1, Galaxy Tab 7.0 Plus, Galaxy Tab 7.7 Plus, Galaxy Tab 8.9, Galaxy Tab 10.1, Galaxy Tab2 7.0, Galaxy Tab2 10.1		
		Galaxy Note,Note 2,Note 3,Note 3 LTE Note 8.0,Note 2014 4G LTE			
		Tablet		Galaxy Tab3 7.0,Tab3 8.0,Tab3 10.1 Galaxy Tab2 7.0,Tab2 10.1 Galaxy Tab 7.0 Plus,Tab 7.7,Tab 10.1 Galaxy TabPRO 8.4 LTE Galaxy TabPRO 10.1	
	SONY	Smartphone		Xperia C,,J,M Xperia U,UL,V,VC,VL Xperia Z,ZL,ZR,Z1,Z Ultra,Z2	
				Tablet	Xperia Tablet S,Z
	Xiami	Smartphone		MI1S,MI2,MI2A,MI2S,MI3 Hongmi,Hongmi NOTE	
ZTE	Smartphone	U950,U985,V967S			

*Please confirm your Smartphone or Tablet can support the USB OTG function
*Some device need to download the app in Google Play to unlock OTG function