


User Manual

503-1-US



Product Image



User Guidance

Smart sensing technology: When you leave the stylus pen idle for 5 minutes, it will automatically turn off to help you save precious battery life.

Turn on: Double touch the top of the stylus pen 2 times, and the indicator light will be on. The indicator light will display the remaining battery through indicator lights.

Turn off: Double touch the top of the stylus pen 2 times, the light will go off, and then the stylus pen shut down. If the battery is too low when the stylus pen is working, the indicator light will turn red, and the stylus pen automatically shut down after 5 minutes.

No need to connect Bluetooth & APP: No need to connect Bluetooth or APP before use, just double touch the top for 2 times to start to use easily.

High sensitivity and pixel-perfect precision: Stable performance. Precise pointing during use, low latency writing.

Comes with multiple extra nibs: You can replace the nibs yourself, doubling the life of the stylus pen.

Charging Method

1. Before the first time to use the stylus pen, please charge fully with the included Type C charging cable. The type C charging cable can able to connect the computer, power bank, or USB charger.
2. When the stylus pen is charging, the indicator light is flash red light. When the stylus pen is charged full, the indicator light is flash a green light. The whole charging time is about 90 minutes.
3. In the power-on state, the stylus pen will show the remaining power through the indicator light in real-time. If the stylus pen with 100% energy will be on a green light, 2%~99% will be on blue light and 1% will be on a red light.

Wide Compatibility

The stylus pen is compatible with many brands of models as follows:

Compatible with Pads: Lenovo, HUAWEI, Vivo, Mi, SAMSUNG, and other brand Pads.
Compatible with cell phones: iPhone, Android, HarmonyOS, and other system phones.

Note:

1. Before using the stylus, please confirm your pad with the screen touch function and the function can be able to work.
2. The stylus pen is not compatible with Microsoft Pad devices.

Parameter

Product Size	Φ9.1mm*166mm
Weight	16g
Battery Capacity	3.7V/130mAh
Charging Voltage/Current	5V/150mA
Maximum Input Voltage	5.5V
Charging Time	90 minutes
Standby time	12 months

Care and Maintenance

1. Do not use Fast Charger for charging. The instantaneous high voltage of the charger may damage the stylus.
2. Please don't let infants play with it. Children should use it under the supervision of adults to

avoid swallowing small parts (like nib) of the stylus by mistake.
3. Do not collide or bend the capacitive stylus with hard objects.

Attention

1. Please keep your Pad screen clean and dry, the water or dirt on the Pad may cause disconnection or delay in writing.
2. Do not place the stylus at high temperatures or humid places.
3. Do not use thickened nibs protective film, which may affect the sensitivity of the stylus.
4. Please fully charge before using it for the first time.

Package Included

- 1 x Active Stylus Pen (Extra Replaceable Tips)
- 1 x Type-C Cable
- 1 x User Manual
- 1 X Warranty Card