

Item	Brand Name	Model
1	Apple	iPhone 2G
2	Apple	iPhone 3G
3	Apple	iPhone 3Gs
4	Apple	iPhone 4
5	Garmin asus	G60
6	HP	iPAD912
7	HTC	Dash 3G
8	HTC	Droid Eris
9	HTC	FUZE (TM) P4600
10	HTC	G1
11	HTC	HD2
12	HTC	Hero
13	HTC	HTC HD mini
14	HTC	HTC Tattoo
15	HTC	HTC Touch Diamond 2 T5353
16	HTC	HTC Wildfire A3333
17	HTC	MyTouch 3g
18	HTC	Nexus One
19	HTC	Pure
20	HTC	SHADOW
21	HTC	Shadow 2009
22	HTC	SMT 5800
23	HTC	Snap
24	HTC	Tilt 2
25	HTC	Touch Diamond
26	HTC	Touch Dual
27	HTC	Touch HD
28	HTC	Touch Pro
29	HTC	Touch Pro 2
30	LG	BL20v
31	LG	BL40
32	LG	CF360
33	LG	Chocolate Touch
34	LG	Dare VX9700
35	LG	enV3
36	LG	eXpo (GW820)
37	LG	GB250
38	LG	GC900
39	LG	GD 580 Lollipop
40	LG	GD310 Ice Cream 2
41	LG	GD510 Pop
42	LG	GD900
43	LG	Glance
44	LG	GM750
45	LG	GT505
46	LG	GT540
47	LG	GU230
48	LG	GU285
49	LG	GW520
50	LG	GW620
51	LG	GX200

52	LG	GX500
53	LG	INCITE
54	LG	KC910
55	LG	KM555
56	LG	KM900
57	LG	KP275
58	LG	KP500
59	LG	KS360
60	LG	Lotus LX600
61	LG	LX290
62	LG	LX370
63	LG	Neon (TM) GT365
64	LG	Rumor 2
65	LG	Scoop / AX-260
66	LG	Shine 2
67	LG	Shine II GD710 AT&T
68	LG	Shine KE970
69	LG	Versa
70	LG	Voyager VX10000
71	LG	VX5500
72	LG	VX8360
73	LG	VX8610
74	LG	Xenon (TM) GR500
75	LG	LX400
76	Moto	Backflip ME600
77	Moto	EM35
78	Moto	Z9N
79	Motorola	Cliq
80	Motorola	Clutch (i465)
81	Motorola	Droid
82	Motorola	E1
83	Motorola	E1070
84	Motorola	E398
85	Motorola	E8
86	Motorola	EM30
87	Motorola	i365
88	Motorola	i576
89	Motorola	i776
90	Motorola	I9
91	Motorola	K3
92	Motorola	Karma QA1
93	Motorola	MOTO (TM) Z9
94	Motorola	Q11
95	Motorola	Q9H
96	Motorola	RAZR V3
97	Motorola	RAZR V3xx Pink
98	Motorola	RAZR2 V9
99	Motorola	Rival
100	Motorola	SLVR L72
101	Motorola	U9
102	Motorola	V1100
103	Motorola	V360
104	Motorola	V365

105	Motorola	V3i
106	Motorola	V3x
107	Motorola	V500
108	Motorola	V550
109	Motorola	V551
110	Motorola	V6
111	Motorola	V750
112	Motorola	V80
113	Motorola	V860
114	Motorola	V9
115	Motorola	V950
116	Motorola	V9x
117	Motorola	VE20
118	Motorola	VE66
119	Motorola	VU30
120	Motorola	W510
121	Motorola	W755
122	Motorola	W766
123	Motorola	XT701 Milestone
124	Motorola	Z3
125	Motorola	Z6w
126	Motorola	ZN300
127	Motorola	ZN4
128	Motorola	ZN5
129	Nokia	2605
130	Nokia	2705
131	Nokia	2730
132	Nokia	2760
133	Nokia	3555
134	Nokia	3711
135	Nokia	5220
136	Nokia	5230
137	Nokia	5310
138	Nokia	5320
139	Nokia	5530
140	Nokia	5610
141	Nokia	5800
142	Nokia	6085
143	Nokia	6086
144	Nokia	6103
145	Nokia	6133
146	Nokia	6205
147	Nokia	6263
148	Nokia	6301
149	Nokia	6350
150	Nokia	6555
151	Nokia	6600
152	Nokia	6650
153	Nokia	6700
154	Nokia	6730
155	Nokia	7205
156	Nokia	7310
157	Nokia	7510

158	Nokia	7705
159	Nokia	8800
160	Nokia	2600C
161	Nokia	2680s
162	Nokia	2720 Fold
163	Nokia	2730 Classic
164	Nokia	3710 fold
165	Nokia	5130 XpressMusic
166	Nokia	5330TV
167	Nokia	5630Xpress
168	Nokia	6220c
169	Nokia	6303C
170	Nokia	6500 Slide
171	Nokia	6600i Slide
172	Nokia	6700 Clasic
173	Nokia	6700 slide
174	Nokia	7100 Supernova
175	Nokia	7210 Supernova
176	Nokia	7610s
177	Nokia	C5-00
178	Nokia	E52
179	Nokia	E63
180	Nokia	E66
181	Nokia	E71
182	Nokia	E71x
183	Nokia	E75
184	Nokia	E90
185	Nokia	Mural (6750)
186	Nokia	N73
187	Nokia	N78
188	Nokia	N79
189	Nokia	N85
190	Nokia	N86
191	Nokia	N96
192	Nokia	N97
193	Nokia	N97 Mini
194	Nokia	Surge (TM) 6790
195	Nokia	X3
196	Nokia	X6
197	Nokia	Z730C
198	Palm	Centro
199	Palm	Pixi
200	Palm	Pre
201	Palm	Treo 680
202	Palm	Treo 800w
203	Palm	Treo Pro
204	Pantech	Matrix Pro (TM)
205	PCD	Razzle TXT8060
206	RIM	BlackBerry 8120
207	RIM	Blackberry 8220
208	RIM	Blackberry 8350i
209	RIM	Blackberry 8530
210	Rim	Blackberry 8820

211	RIM	Blackberry 9300
212	RIM	Blackberry 9500
213	RIM	Blackberry 9530
214	RIM	Blackberry 9630
215	RIM	Blackberry 9700
216	Rim	Blackberry Bold 9000
217	RIM	BlackBerry Curve (8520)
218	Rim	Blackberry Curve 8310
219	Rim	Blackberry Curve 8320
220	Rim	Blackberry Curve 8900
221	Rim	Blackberry Pearl 8100
222	Rim	Blackberry Pearl 8110
223	RIM	BlackBerry Storm 9550 (Storm 2)
224	Samsung	A237
225	Samsung	a727
226	Samsung	A737
227	Samsung	a747
228	Samsung	A767 Propel
229	Samsung	A777
230	Samsung	A827
231	Samsung	B2100
232	Samsung	B7300
233	Samsung	Behold 2 (T939)
234	Samsung	Behold T919
235	Samsung	BlackJack (TM) II (i617)
236	Samsung	C3050
237	Samsung	C3110
238	Samsung	C5130
239	Samsung	C5212
240	Samsung	C5510
241	Samsung	D780
242	Samsung	D880
243	Samsung	D900i
244	Samsung	D988
245	Samsung	E390
246	Samsung	Eternity A867
247	Samsung	F110
248	Samsung	F330
249	Samsung	F480
250	Samsung	F490
251	Samsung	Flight
252	Samsung	Galaxy Spica GT-i5700
253	Samsung	Gravity 2 (T469)
254	Samsung	Gravity T459
255	Samsung	Highlight
256	Samsung	i200
257	Samsung	I450
258	Samsung	i520
259	Samsung	i640v
260	Samsung	i7500 Galaxy
261	Samsung	i780
262	Samsung	i8000 Omnia
263	Samsung	i8510

264	Samsung	i8910 HD
265	Samsung	i907 Epix
266	Samsung	i910
267	Samsung	Impression (A877)
268	Samsung	Instinct HD (M850)
269	Samsung	Instinct S30
270	Samsung	Intensity
271	Samsung	Intrepid (I350)
272	Samsung	J200
273	Samsung	J700
274	Samsung	J758
275	Samsung	J808
276	Samsung	Jack i637
277	Samsung	L708
278	Samsung	L760
279	Samsung	L770
280	Samsung	M220
281	Samsung	M310
282	Samsung	M320
283	Samsung	M330
284	Samsung	M5650
285	Samsung	M630
286	Samsung	M7600
287	Samsung	M8910
288	Samsung	Magnet A257
289	Samsung	Moment
290	Samsung	Mythic A897
291	Samsung	Pixon M8800
292	Samsung	Propel (TM) Pro i627
293	Samsung	Rant M540
294	Samsung	Reclaim (M560)
295	Samsung	Renown
296	Samsung	Rogue
297	Samsung	Rugby (A837)
298	Samsung	S3030 Tobi
299	Samsung	S3600H
300	Samsung	S3650 Corby
301	Samsung	S5230
302	Samsung	S5500
303	Samsung	S5550 Shark
304	Samsung	S5560
305	Samsung	S5600
306	Samsung	S5628 Monte
307	Samsung	S7070 Diva
308	Samsung	S7350
309	Samsung	S8000
310	Samsung	S8300
311	Samsung	Smooth
312	Samsung	Solstice (TM) (A887)
313	Samsung	Steel U900
314	Samsung	t229
315	Samsung	t239
316	Samsung	t349

317	Samsung	T559 Comeback
318	Samsung	T659
319	Samsung	t819
320	Samsung	T929 Memoir
321	Samsung	Trance
322	Samsung	u440
323	Samsung	U808
324	Samsung	A637
325	Samsung	A657
326	Samsung	Galaxy S i9000
327	Samsung	M520
328	Samsung	T339
329	Samsung	u430
330	Samsung	Wave S8500
331	Sanyo	Incognito (SCP-6760)
332	Sanyo	Katana Eclipse
333	Sanyo	Katana LX
334	Sanyo	PRO-700
335	Sanyo	SCP-2700
336	Sanyo	SCP-3810
337	Sony	Equinox
338	Sony Ericsson	C510 Black
339	Sony Ericsson	C901
340	Sony Ericsson	C902
341	Sony Ericsson	C905 Black
342	Sony Ericsson	F305
343	Sony Ericsson	G502
344	Sony Ericsson	G700
345	Sony Ericsson	G705
346	Sony Ericsson	G900
347	Sony Ericsson	J105i
348	Sony Ericsson	S302
349	Sony Ericsson	T650i
350	Sony Ericsson	T700
351	Sony Ericsson	T715
352	Sony Ericsson	TM506
353	Sony Ericsson	W300i
354	Sony Ericsson	W302
355	Sony Ericsson	W350 (Refurbished)
356	Sony Ericsson	W350a
357	Sony Ericsson	W518a
358	Sony Ericsson	W580i
359	Sony Ericsson	W595
360	Sony Ericsson	W660i
361	Sony Ericsson	W705
362	Sony Ericsson	W760a
363	Sony Ericsson	W810i
364	Sony Ericsson	W850i
365	Sony Ericsson	W960i
366	Sony Ericsson	W980
367	Sony Ericsson	Xperia X1
368	Sony Ericsson	Z310a
369	Sony Ericsson	Z750a

370	Sony Ericsson	Z770i
371	SonyEricsson	Aion U10
372	SonyEricsson	C903
373	SonyEricsson	Elm J10
374	SonyEricsson	F100
375	SonyEricsson	Hazel J20
376	SonyEricsson	K510a
377	SonyEricsson	K660i
378	SonyEricsson	Satio U1i
379	SonyEricsson	Vivaz U5
380	SonyEricsson	W395
381	SonyEricsson	W902
382	SonyEricsson	W995
383	SonyEricsson	X10
384	SonyEricsson	X10 mini
385	SonyEricsson	X10 mini pro
386	SonyEricsson	X2
387	SonyEricsson	Yari U100
388	SonyEricsson	Z550a
389	SonyEricsson	Z555
390	T-Mobile	T-Mobile Wing (S730)
391	UT Starcom	CDM8950
392	UT Starcom	GZ1 C711
393	Google	Google Nexus S
394	HTC	Evo 4G
395	HTC	HD7
396	HTC	Incredible
397	HTC	Ozone
398	HTC	Surround
399	HTC	Touch Pro2
400	LG	enV3 VX9200
401	LG	Vortex
402	Motorola	Backflip MB300
403	Motorola	Cliq MB200
404	Motorola	Droid 2
405	Motorola	Droid Pro
406	Motorola	Droid X
407	Nokia	5230 Nuron
408	Nokia	N8
409	Nokia	X6
410	Palm	Pixi Plus CDMA
411	Palm	Pre Plus CDMA
412	RIM	Blackberry Curve 3G 9300
413	RIM	Blackberry Curve 3G 9330
414	RIM	Blackberry Storm 2
415	RIM	BlackBerry Style (9670)
416	RIM	BlackBerry Torch (9800)
417	Samsung	Alias 2 U750
418	Samsung	Captivate (I897)
419	Samsung	Continuum (I400)
420	Samsung	Epic 4G (D700)
421	Samsung	Fascinate (I500)
422	Sony Ericsson	Aino

423	T-Mobile	G2
424	T-Mobile	MyTouch 3G Slide
425	T-Mobile	MyTouch 4G
426	Acer	Acer beTouch E210
427	Acer	acer E400
428	Acer	acer P400
429	Acer	DX650
430	Acer	E200
431	Acer	Liquid E
432	Acer	Liquid Mini (E310)
433	Acer	M900
434	Acer	S110
435	Acer	Smart handheld
436	Acer	Smart handheld
437	Acer	Smart handheld E100
438	Acer	Smart handheld E101
439	Alcatel	MISS SIXTY MSX10
440	Alcatel	OT-800/ OT-800A
441	Alcatel	OT-802/ OT-802A
442	Alcatel	OT-806/ OT-806A/ OT-806D/ OT-807/ OT-807A/ OT-807D
443	Alcatel	OT-808/ OT-808A
444	Alcatel	OT-880/ OT-880A
445	Alcatel	OT-980/ OT-980A
446	Casio Hitachi	C721
447	Chi Mei	AQ4
448	Chi Mei	P300
449	FIH	FM600
450	FIH	N700
451	FIH	PDA Phone
452	FIH	test_RM-383
453	FIH	ViewPad7
454	Fujitsu	T-01C
455	Global High Tech	GHT Maestro
456	Hewlett-Packard	HSTNH-P21C
457	HTC	ADR6200VW
458	HTC	ADR6300
459	HTC	ADR6300
460	HTC	CDMA HTI11
461	HTC	CEDA100 Series
462	HTC	CEDA100 Series
463	HTC	CEDA100 Series (WM6.5)
464	HTC	EVO
465	HTC	HERO200
466	HTC	HTC Hero
467	HTC	HTC Snap
468	HTC	HTC Touch Diamond2
469	HTC	HTC Touch2
470	HTC	HTC Wildfire
471	HTC	Nexus One
472	HTC	PB00 Series
473	HTC	PB65 series
474	HTC	PB76100
475	HTC	PB81 Series

476	HTC	PB92100
477	HTC	PB92110
478	HTC	PB92110 series
479	HTC	PB99 (CDMA)
480	HTC	PB99 Android 2.2 series
481	HTC	PB99400
482	HTC	PC10100
483	HTC	PC10xxx
484	HTC	PC36100
485	HTC	PC36100
486	HTC	PC40100
487	HTC	PC402XX
488	HTC	PC57 Series
489	HTC	PC63xxx Android 2.2
490	HTC	PC70 series
491	HTC	PC92xxx
492	HTC	PC96 Series
493	HTC	PC991XX
494	HTC	PD051XX
495	HTC	PD06100
496	HTC	PD11 Series
497	HTC	PD15xxx
498	HTC	PD2610000
499	HTC	PD29xxx
500	HTC	PD42XXX
501	HTC	PD67100
502	HTC	PD98xxx(A9192)
503	HTC	PG05XXX
504	HTC	PG06XXX
505	HTC	PG321XX
506	HTC	PG32XXX
507	HTC	RHOD100 Series
508	HTC	RHOD50000 Series
509	HTC	TWIN10000 Series
510	HTC	WHIT10000 Series
511	HUAWEI	C8150
512	HUAWEI	C8150-1
513	HUAWEI	HUAWEI C8500
514	HUAWEI	HUAWEI C8600/ HUAWEI M860
515	HUAWEI	HUAWEI U8300/ U8300
516	HUAWEI	S31HW/ U8150-92/ HUAWEI U8150-92
517	HUAWEI	U8150-A
518	HUAWEI	U8150-D
519	HUAWEI	UM840
520	Inventec	T-101
521	iWOW	Libero
522	KT Tech	EV-S100
523	KT Tech	KM-S120
524	Kyocera	CLIP
525	Kyocera	Glide-M1400
526	Kyocera	K50
527	Kyocera	M2000
528	Kyocera	Mobile Phone 16 (E76)

529	Kyocera	S1310
530	Kyocera	S2300
531	Kyocera	S2410
532	Kyocera	SANYO SCP-3810
533	Kyocera	SCP-2700
534	Kyocera	SCP-8600
535	Kyocera	Torino
536	LG	BL20df/ BL20cf
537	LG	BL40/ BL40g/ BL40f
538	LG	BL40e
539	LG	BL42/ BL42e/ BL42v/ BL42k/ BL42N/ BL20/ BL20e/ BL20v/ BL20k/ BL20N
540	LG	GC900/ GC900F
541	LG	GC900e
542	LG	GC970/ GC970h
543	LG	GD510
544	LG	GD510N
545	LG	GD550
546	LG	GD550e
547	LG	GD570
548	LG	GD570AW, GD570AV
549	LG	GD880/ GC970
550	LG	GD880f, GD880g
551	LG	GD900/ GD900e
552	LG	GM210
553	LG	GM360i
554	LG	GM600
555	LG	GM730/ GM730f/ GM735/ GM730e
556	LG	GM750
557	LG	GM750h
558	LG	GM750Q
559	LG	GR700
560	LG	GS290
561	LG	GS390
562	LG	GS500
563	LG	GS500f for PCL
564	LG	GS500f, GS500g, GS500k, GS500v
565	LG	GS500gX
566	LG	GS505
567	LG	GT350
568	LG	GT350F
569	LG	GT350i
570	LG	GT360
571	LG	GT370
572	LG	GT400/ GT405
573	LG	GT500/ GT505
574	LG	GT550
575	LG	GT620
576	LG	GT950Q
577	LG	GU280, GU285, GU285f, GU285g
578	LG	GU280f
579	LG	GU282
580	LG	GU290/ GU290f

581	LG	GU290v
582	LG	GU295/ GU292
583	LG	GU295f, GU295g
584	LG	GU295g
585	LG	GU297 , GU297a
586	LG	GW300, LG900G
587	LG	GW300FD, GW305
588	LG	GW380/ GW370B/ GW375/ GW382f/ GW380f/ GW380g
589	LG	GW525gX
590	LG	GW550
591	LG	GW550h
592	LG	GW820, GW825, GW825v
593	LG	GX500
594	LG	KC910, KC910Q, KC910Qa, KC910e, KC910i
595	LG	KM553
596	LG	KM555
597	LG	KM555e
598	LG	KM555R
599	LG	KM570
600	LG	KP500N
601	LG	KP501/ KP502/ KP550
602	LG	KP505
603	LG	KS365
604	LG	KT770, KT770f
605	LG	L-04C
606	LG	LG 3G Mobile Phone (GD910)
607	LG	LG 3G Mobile Phone (GT950)
608	LG	LG 3G Mobile Phone (LG- GT540/ GT540f/ GT540g)
609	LG	LG 3G Mobile phone (LG-C550 / LG-C550f)
610	LG	LG 3G Mobile Phone (LG-GB258)
611	LG	LG 3G Mobile Phone (LG-P350)
612	LG	LG 3G Mobile Phone(GM730E)
613	LG	LG 3G Mobile Phone(GW820)
614	LG	LG 3G Mobile Phone(KB770, KB775, KB775f)
615	LG	LG 3G Mobile Phone(LG-KU3800)
616	LG	LG 3G Mobile Phone(LG-T320, LG-T320e, LG-T320g, LG-T320v, LG-T320k, LG-T320gv)
617	LG	LG CDMA Mobile Phone (LG-CX7100)
618	LG	LG CDMA Mobile Phone (LG-LG5500X for Koodo)
619	LG	LG CDMA Mobile Phone (LG-MN180)
620	LG	LG CDMA Mobile Phone (LG-UN200/ LG501C/ AN200/ VM200 / CM200 / BM200/ LW200/ MN200 / CX200B / CX200 / JN200)
621	LG	LG CDMA Mobile Phone (LG-VS910)
622	LG	LG CDMA Mobile Phone (VX7100)
623	LG	LG CDMA Mobile Phone (VX8575/ AX8575)
624	LG	LG CDMA Mobile Phone(LG LN510)
625	LG	LG CDMA Mobile Phone(LG- LN510)
626	LG	LG CDMA Mobile Phone(LG220C)
627	LG	LG CDMA Mobile Phone(LG-CX9200)
628	LG	LG CDMA Mobile Phone(LG-CX9600)
629	LG	LG CDMA mobile phone(LG-UX700, LG-AX700, MT700, LW700, LG700, CX700, MV700, MX700, MD700, VM700)
630	LG	LG GSM Mobile Phone (LG-C320i)

631	LG	LG GSM/ GPRS/ EDGE Mobile Phone (GM360)
632	LG	LG KM900, LG KM900e, LG KM900f, LG KM900g
633	LG	LG- LG265X
634	LG	LG TD-SCDMA Mobile Phone (GT910s)
635	LG	LG TD-SCDMA Mobile Phone(LG KT878)
636	LG	LG WCDMA Mobile Phone (LG-SU550)
637	LG	LG WCDMA Mobile Phone (LG-SU920, LG-KU9200)
638	LG	LG WCDMA Mobile Phone(LG-SU130)
639	LG	LG WCDMA Mobile Phone(LG-SU630)
640	LG	LG WCDMA Mobile Phone(LG-SU900/ LG-KU9000/ LG-LU9000)
641	LG	LG230(CX230), LG231(CX231), LG231C(CX231C)
642	LG	LG370
643	LG	LG700V, CX700V
644	LG	LG-A310/ LG-A310f/ LG-A310k/ LG-A315/ LG-A315v
645	LG	LG-AX265
646	LG	LG-AX265 [Not Approved by SIG]
647	LG	LG-AX8370
648	LG	LG-AX840
649	LG	LG-C320
650	LG	LG-C510/ C510
651	LG	LG-C570f
652	LG	LG-C570g
653	LG	LG-C710h/ LG-C710
654	LG	LG-C900
655	LG	LG-C900N, LG-C900k, LG-C900B
656	LG	LG-CX5500X
657	LG	LG-E500
658	LG	LG-E720, LG-E720b, LG-E720k
659	LG	LG-E900, LG-E900h
660	LG	LG-GB250
661	LG	LG-GD970
662	LG	LG-GM310/ LG-GM310f/ LG-GM310g
663	LG	LG-GW370
664	LG	LG-GW520/ LG-GW525/ GW525f/ GW525g
665	LG	LG-GW610
666	LG	LG-GW820, LG-GW825
667	LG	LG-JN240
668	LG	LG-JS750, LG-JS750g
669	LG	LG-KH3400
670	LG	LG-KH3400
671	LG	LG-KH3900
672	LG	LG-KH8000
673	LG	LG-KS720
674	LG	LG-KU2100, LG-SU210, LG-LU2100
675	LG	LG-KU2200
676	LG	LG-KU9300
677	LG	LG-KV700 (Lollipop2)
678	LG	LG-KV700T
679	LG	LG-KW730
680	LG	LG-LB4400
681	LG	LG-LG265T
682	LG	LG-LG8575/ LG-MX8575
683	LG	LG-LU2700

684	LG	LG-LU3000
685	LG	LG-LU4500
686	LG	LG-LU9400
687	LG	LG-LU9400W
688	LG	LG-LX295/ LG-LX290
689	LG	LG-MT375
690	LG	LG-P500/ LG-P509/ LG-P509TN
691	LG	LG-P500h
692	LG	LG-P501
693	LG	LG-P503
694	LG	LG-P505
695	LG	LG-P506
696	LG	LG-P920/ LG-P925/ LG-P929
697	LG	LG-P970
698	LG	LG-P990
699	LG	LG-SB210
700	LG	LG-SB260
701	LG	LG-SU310, LG-LU3100
702	LG	LG-SU370/ LG-KU3700/ LG-LU3700
703	LG	LG-SU410
704	LG	LG-SU420/ LG-KU4200
705	LG	LG-SU430/ LG-KU4300/ LG-LU4300
706	LG	LG-SU660
707	LG	LG-SU910/ LG-KU9100/ LG-LU9100
708	LG	LG-SU950/ KU9500
709	LG	LG-SU960, LG-KU9600
710	LG	LG-SV400
711	LG	LG-SV770
712	LG	LG-T325 , LG-T325f, LG-T325g
713	LG	LG-UN430
714	LG	LG-US760
715	LG	LG-UX310, AX310, MT310(MetroPCS), LP310, LW310(LeapWireless(Cricket)), G310, CX310, MV310, MX310,
716	LG	LG-VN270/ LN270/ UN270/ LG270/ LG270C/ LW270/ CX270/ MN270/ TN270/ AN270/ VM270
717	LG	LG-VN530
718	LG	LG-VS660/ LS670/ US670/ LG670C/ MS690/ LW690/ VM670/
719	LG	LG-VS740/ US740/ MS740/ AS740
720	LG	LG-VS750
721	LG	LG-VS760
722	LG	LG-VS761
723	LG	LG-VX11000
724	LG	LG-VX8576
725	LG	LG-VX9200
726	LG	LN240/ MN240/ LW240/ UN240/ AN240/ VN240/ CX240
727	LG	LU2300
728	LG	LW375
729	LG	LX610/ UX610/ CX610/ LG610/ VM610/ AX610/ UN610/ CN610/ VN610/ AN610
730	LG	MT375
731	LG	New LG 3G Mobile Phone(GD710)
732	LG	New LG CDMA Mobile Phone(LG-LG290C)
733	LG	UX220

734	LG	UX370
735	LG	VER-01
736	LG	VN250
737	LG	VX5600
738	LG	VX8370
739	MediaTek	MediaTek BlueZ (2.1+EDR)
740	MediaTek	Mediatek WM6.5 (EDR2.0)
741	Motorola	A3300c
742	Motorola	A853
743	Motorola	A855
744	Motorola	A955
745	Motorola	Amphora-i897
746	Motorola	Athens-i9 R2
747	Motorola	Banfi-i856
748	Motorola	Bei Hai TD
749	Motorola	Blackstone-R2
750	Motorola	Brightwater
751	Motorola	Castle
752	Motorola	Cordova
753	Motorola	Creekside-i886
754	Motorola	CRUSH
755	Motorola	EWP3100
756	Motorola	Fairbanks
757	Motorola	Finch
758	Motorola	FR6070, FR6076
759	Motorola	FR6874
760	Motorola	Halo
761	Motorola	Heartland
762	Motorola	i296-Gallo
763	Motorola	i410(Nevadacity)
764	Motorola	i686-Brightwater-2
765	Motorola	i786w (Mantra)
766	Motorola	MB200 refresh
767	Motorola	MB300 Backflip refresh
768	Motorola	MB501 refresh
769	Motorola	MB502
770	Motorola	MB508
771	Motorola	MB511
772	Motorola	MB520
773	Motorola	MB525
774	Motorola	MB810
775	Motorola	ME811
776	Motorola	Milestone XT720
777	Motorola	Moto A3000
778	Motorola	Motosurf A3000
779	Motorola	Motosurf A3100
780	Motorola	MT716
781	Motorola	Muscardini
782	Motorola	Oaknoll
783	Motorola	Quailhurst iDEN-i786
784	Motorola	RIVAL (TELUS)
785	Motorola	Rush
786	Motorola	VE440

787	Motorola	VoWLAN Single Mode Smartphone
788	Motorola	W418G
789	Motorola	W766
790	Motorola	WX345
791	Motorola	WX404
792	Motorola	XT502
793	Motorola	XT610
794	Motorola	XT701
795	Motorola	XT702
796	Motorola	XT711
797	Motorola	XT720
798	Motorola	XT800
799	Motorola	XT800+
800	Motorola	XT800c
801	Motorola	XT800W
802	Motorola	XT806
803	NEC CASIO	KMP7N4Y1-2A
804	Nokia	2705
805	Nokia	6788
806	Nokia	7705
807	Nokia	2332c
808	Nokia	6788i
809	Nokia	C1-03
810	Nokia	C5-01
811	Nokia	Nokia 1006
812	Nokia	Nokia 2705
813	Nokia	Nokia 3208c
814	Nokia	Nokia 3720c-2
815	Nokia	Nokia 5132
816	Nokia	Nokia 5611
817	Nokia	Nokia 5730s-1
818	Nokia	Nokia 6303c
819	Nokia	Nokia 6316s, 6316s-1
820	Nokia	Nokia 6350-1b
821	Nokia	Nokia 6350-1d
822	Nokia	Nokia 6600i-1c
823	Nokia	Nokia 6700c
824	Nokia	Nokia 6700c-1
825	Nokia	Nokia 6750-1b
826	Nokia	Nokia 6750-1c
827	Nokia	Nokia 6760s-1
828	Nokia	Nokia 6790s-1b
829	Nokia	Nokia 6790s-1c
830	Nokia	Nokia 7205
831	Nokia	Nokia 7208
832	Nokia	Nokia 7208
833	Nokia	Nokia 7505 CDMA Mobile Phone
834	Nokia	Nokia 7705
835	Nokia	Nokia 8208
836	Nokia	Nokia E71x
837	Nokia	Nokia E75-1
838	Nokia	Nokia E75-2
839	Nokia	Vertu ASCENT X

840	Nokia	Vertu Constellation F
841	Nokia	Vertu Signature SC
842	Nokia	X3-01
843	Nokia	X5-00
844	Palm	P100EWW
845	Palm	P100UNA/ P100UEU
846	Palm	P101EWW
847	Palm	P101UNA, P101UEU
848	Palm	P120EWW
849	Palm	P121EWW
850	Palm	P121UNA, P121UEU
851	Palm	Treo Pro, T850EWW
852	Pantech	CDM8999**
853	Pantech	CDMA PTI06 (IS06)
854	Pantech	IM-A600S
855	Pantech	IM-A630K (SP33K)
856	Pantech	IM-A630K (SP33K)
857	Pantech	IM-A650S
858	Pantech	IM-A690L
859	Pantech	IM-A690S
860	Pantech	IM-A710K
861	Pantech	MD Cube
862	Pantech	P2000
863	Pantech	P2020
864	Pantech	P6010
865	Pantech	P7000
866	Pantech	P7040
867	Pantech	P8000
868	Pantech	P9020
869	Pantech	P9050
870	Pantech	PIVOT **
871	Pantech	PIVOT/ TXT8030##
872	Pantech	Show(TXT8040, VZW-1026)
873	Pantech	TXT8035PP
874	Pantech	TXT8040##
875	Pantech	WP8990
876	Pharos	PTL117
877	Pharos	PTL127
878	RIM	BlackBerryR 8530 Smartphone
879	RIM	BlackBerryR 8910 Curve? Smartphone
880	RIM	BlackBerryR Bold? 9000
881	RIM	BlackBerryR Bold? 9650 Smartphone
882	RIM	BlackBerryR Bold? 9650 Smartphone
883	RIM	BlackBerryR Bold? 9700
884	RIM	BlackBerryR Bold? 9780 smartphone
885	RIM	BlackBerryR Curve? 8330
886	RIM	BlackBerryR Curve? 8350i
887	RIM	BlackBerryR Curve? 8520 Smartphone
888	RIM	BlackBerryR Curve? 8900
889	RIM	BlackBerryR Curve? 9300
890	RIM	BlackBerryR Curve? 9330 Smartphone
891	RIM	BlackBerryR Pearl? 8230
892	RIM	BlackBerryR Pearl? 9100 Smartphone

893	RIM	BlackBerryR Pearl? 9105 Smartphone
894	RIM	BlackBerryR Storm2? 9520
895	RIM	BlackBerryR Storm2? 9550
896	RIM	BlackBerryR Storm? 9500
897	RIM	BlackBerryR Storm? 9530
898	RIM	BlackBerryR Style? 9670 Smartphone
899	RIM	BlackBerryR Torch? 9800
900	RIM	BlackBerryR Tour? 9630 Smartphone
901	Samsung	C3050
902	Samsung	C3050
903	Samsung	C3110H
904	Samsung	C6625
905	Samsung	E3010
906	Samsung	GT- S8500
907	Samsung	GT-B2710
908	Samsung	GT-B2710D
909	Samsung	GT-B3210
910	Samsung	GT-B3310
911	Samsung	GT-B3310i
912	Samsung	GT-B3313i
913	Samsung	GT-B3410
914	Samsung	GT-B3410R
915	Samsung	GT-B3410W
916	Samsung	GT-B5210U
917	Samsung	GT-B5310
918	Samsung	GT-B5310B
919	Samsung	GT-B5310L
920	Samsung	GT-B5310R
921	Samsung	GT-B5310U
922	Samsung	GT-B6520
923	Samsung	GT-B6520L
924	Samsung	GT-B7300
925	Samsung	GT-B7300B
926	Samsung	GT-B7300C
927	Samsung	GT-B7320
928	Samsung	GT-B7320L
929	Samsung	GT-B7330
930	Samsung	GT-B7330B
931	Samsung	GT-B7330D
932	Samsung	GT-B7330R
933	Samsung	GT-B7350
934	Samsung	GT-B7350T
935	Samsung	GT-B7610
936	Samsung	GT-B7620
937	Samsung	GT-B7620U
938	Samsung	GT-C3010
939	Samsung	GT-C3013
940	Samsung	GT-C3050
941	Samsung	GT-C3050C
942	Samsung	GT-C3053
943	Samsung	GT-C3060
944	Samsung	GT-C3200
945	Samsung	GT-C3300

946	Samsung	GT-C3300D
947	Samsung	GT-C3300i
948	Samsung	GT-C3300K
949	Samsung	GT-C3303K
950	Samsung	GT-C3500
951	Samsung	GT-C3503
952	Samsung	GT-C3510
953	Samsung	GT-C3510T
954	Samsung	GT-C3518
955	Samsung	GT-C3530
956	Samsung	GT-C5180
957	Samsung	GT-C5510
958	Samsung	GT-C5510H
959	Samsung	GT-C5510U
960	Samsung	GT-E2330B
961	Samsung	GT-E2530
962	Samsung	GT-E2652
963	Samsung	GT-E2652W
964	Samsung	GT-E3210
965	Samsung	GT-E3210B
966	Samsung	GT-E3210L
967	Samsung	GT-I5500
968	Samsung	GT-I5500M
969	Samsung	GT-I5503T
970	Samsung	GT-I5508
971	Samsung	GT-I5510
972	Samsung	GT-I5510B
973	Samsung	GT-I5510L
974	Samsung	GT-I5510T
975	Samsung	GT-I5700
976	Samsung	GT-I5700
977	Samsung	GT-I5700L
978	Samsung	GT-I5700U
979	Samsung	GT-I5800
980	Samsung	GT-I5801
981	Samsung	GT-I6220
982	Samsung	GT-I6230
983	Samsung	GT-I6410
984	Samsung	GT-I6500U
985	Samsung	GT-I6500U
986	Samsung	GT-I7410
987	Samsung	GT-I7500U
988	Samsung	GT-I7680
989	Samsung	GT-I8000H
990	Samsung	GT-I8000L
991	Samsung	GT-I8000T
992	Samsung	GT-I8180C
993	Samsung	GT-I8320
994	Samsung	GT-I8330
995	Samsung	GT-I8520
996	Samsung	GT-I8910L
997	Samsung	GT-I8910U
998	Samsung	GT-I9000

999	Samsung	GT-I9000
1000	Samsung	GT-I9000B
1001	Samsung	GT-I9000L
1002	Samsung	GT-I9000M
1003	Samsung	GT-I9000M
1004	Samsung	GT-I9000T
1005	Samsung	GT-I9003
1006	Samsung	GT-I9003
1007	Samsung	GT-I9003L
1008	Samsung	GT-I9003L
1009	Samsung	GT-I9008
1010	Samsung	GT-I9010
1011	Samsung	GT-I9020
1012	Samsung	GT-I9020A
1013	Samsung	GT-I9020T
1014	Samsung	GT-I9023
1015	Samsung	GT-I9088
1016	Samsung	GT-M2510C
1017	Samsung	GT-M2513
1018	Samsung	GT-M2520
1019	Samsung	GT-M3710
1020	Samsung	GT-M7500C
1021	Samsung	GT-M7600B
1022	Samsung	GT-M7600H
1023	Samsung	GT-M7600L
1024	Samsung	GT-M7603
1025	Samsung	GT-M8910
1026	Samsung	GT-M8910B
1027	Samsung	GT-M8910U
1028	Samsung	GT-P1000
1029	Samsung	GT-P1000L
1030	Samsung	GT-P1000N
1031	Samsung	GT-P1000T
1032	Samsung	GT-S3100
1033	Samsung	GT-S3310i
1034	Samsung	GT-S3350
1035	Samsung	GT-S3353
1036	Samsung	GT-S3370
1037	Samsung	GT-S3370B
1038	Samsung	GT-S3370C
1039	Samsung	GT-S3370E
1040	Samsung	GT-S3370L
1041	Samsung	GT-S3500i
1042	Samsung	GT-S3501C
1043	Samsung	GT-S3550
1044	Samsung	GT-S3600i
1045	Samsung	GT-S3601C
1046	Samsung	GT-S3650
1047	Samsung	GT-S3650C
1048	Samsung	GT-S3650W
1049	Samsung	GT-S3653
1050	Samsung	GT-S3653W
1051	Samsung	GT-S5150

1052	Samsung	GT-S5230
1053	Samsung	GT-S5230C
1054	Samsung	GT-S5230G
1055	Samsung	GT-S5230N
1056	Samsung	GT-S5233A
1057	Samsung	GT-S5233S
1058	Samsung	GT-S5233T
1059	Samsung	GT-S5233W
1060	Samsung	GT-S5250
1061	Samsung	GT-S5260
1062	Samsung	GT-S5330
1063	Samsung	GT-S5333
1064	Samsung	GT-S5350
1065	Samsung	GT-S5350L
1066	Samsung	GT-S5510
1067	Samsung	GT-S5510T
1068	Samsung	GT-S5520
1069	Samsung	GT-S5530
1070	Samsung	GT-S5560
1071	Samsung	GT-S5560C
1072	Samsung	GT-S5560i
1073	Samsung	GT-S5570
1074	Samsung	GT-S5570B
1075	Samsung	GT-S5570L
1076	Samsung	GT-S5580
1077	Samsung	GT-S5600
1078	Samsung	GT-S5600B
1079	Samsung	GT-S5600H
1080	Samsung	GT-S5600L
1081	Samsung	GT-S5600T
1082	Samsung	GT-S5600V
1083	Samsung	GT-S5603
1084	Samsung	GT-S5603T
1085	Samsung	GT-S5608U
1086	Samsung	GT-S5620
1087	Samsung	GT-S5620B
1088	Samsung	GT-S5620L
1089	Samsung	GT-S5628
1090	Samsung	GT-S5628i
1091	Samsung	GT-S5670
1092	Samsung	GT-S5670B
1093	Samsung	GT-S5670L
1094	Samsung	GT-S5750E
1095	Samsung	GT-S5830
1096	Samsung	GT-S5830B
1097	Samsung	GT-S5830L
1098	Samsung	GT-S5830T
1099	Samsung	GT-S6700T
1100	Samsung	GT-S6703T
1101	Samsung	GT-S6888
1102	Samsung	GT-S7070
1103	Samsung	GT-S7070C
1104	Samsung	GT-S7220U

1105	Samsung	GT-S7230
1106	Samsung	GT-S7230B
1107	Samsung	GT-S7230E
1108	Samsung	GT-S7230L
1109	Samsung	GT-S7233E
1110	Samsung	GT-S7350i
1111	Samsung	GT-S7350U
1112	Samsung	GT-S7510
1113	Samsung	GT-S8000B
1114	Samsung	GT-S8000C
1115	Samsung	GT-S8000C
1116	Samsung	GT-S8000H
1117	Samsung	GT-S8000L
1118	Samsung	GT-S8000U
1119	Samsung	GT-S8500
1120	Samsung	GT-S8500
1121	Samsung	GT-S8500B
1122	Samsung	GT-S8500C
1123	Samsung	GT-S8500L
1124	Samsung	GT-S8500M
1125	Samsung	GT-S8500R
1126	Samsung	GT-S8530
1127	Samsung	GT-S8530B
1128	Samsung	GT-S8530L
1129	Samsung	Marcel Reloaded
1130	Samsung	S3110C
1131	Samsung	S3500C
1132	Samsung	S7350B
1133	Samsung	S7350C
1134	Samsung	S7350L
1135	Samsung	S8000
1136	Samsung	S8300C
1137	Samsung	S8300T
1138	Samsung	S8300V
1139	Samsung	Samsung GT-I5500B
1140	Samsung	Samsung GT-I5500L
1141	Samsung	Samsung GT-I5800L
1142	Samsung	Samsung Mobile Phone (GT-M2510)
1143	Samsung	Samsung Mobile Phone (SCH-R311)
1144	Samsung	Samsung Mobile Phone (SCH-U350)
1145	Samsung	Samsung Mobile Phone (SCH-U450)
1146	Samsung	Samsung Mobile Phone (SCH-U960)
1147	Samsung	Samsung Mobile Phone (SPH-M550)
1148	Samsung	Samsung Mobile Phone (SPH-M560)
1149	Samsung	Samsung Mobile Phone (SPH-M850)
1150	Samsung	Samsung Mobile Phone(GT-I8000)
1151	Samsung	Samsung Mobile Phone(I8910)
1152	Samsung	Samsung Mobile Phone(M7600)
1153	Samsung	Samsung Mobile Phone(SCH-R560)
1154	Samsung	Samsung Mobile Phone(SCH-U430)
1155	Samsung	Samsung Mobile Phone(SCH-U640)
1156	Samsung	SC-01B
1157	Samsung	SC-01C

1158	Samsung	SC-02B
1159	Samsung	SCH-F809
1160	Samsung	SCH-F859
1161	Samsung	SCH-I100
1162	Samsung	SCH-i220
1163	Samsung	SCH-i220(MPCS)
1164	Samsung	SCH-i225
1165	Samsung	SCH-i329
1166	Samsung	SCH-I400
1167	Samsung	SCH-I500
1168	Samsung	SCH-I520
1169	Samsung	SCH-I579
1170	Samsung	SCH-I800
1171	Samsung	SCH-i899
1172	Samsung	SCH-I909
1173	Samsung	SCH-i920
1174	Samsung	SCH-M710
1175	Samsung	SCH-M715
1176	Samsung	SCH-M720
1177	Samsung	SCH-R100
1178	Samsung	SCH-R250
1179	Samsung	SCH-R260
1180	Samsung	SCH-R260
1181	Samsung	SCH-R260
1182	Samsung	SCH-R260
1183	Samsung	SCH-R312
1184	Samsung	SCH-R330
1185	Samsung	SCH-R330
1186	Samsung	SCH-R335
1187	Samsung	SCH-R350
1188	Samsung	SCH-R351
1189	Samsung	SCH-R360
1190	Samsung	SCH-R520
1191	Samsung	SCH-R570
1192	Samsung	SCH-R580
1193	Samsung	SCH-R630
1194	Samsung	SCH-R631
1195	Samsung	SCH-R631 2Thumb
1196	Samsung	SCH-R700
1197	Samsung	SCH-R710
1198	Samsung	SCH-R850
1199	Samsung	SCH-R860
1200	Samsung	SCH-R880
1201	Samsung	SCH-R880
1202	Samsung	SCH-R900
1203	Samsung	SCH-R910
1204	Samsung	SCH-R915
1205	Samsung	SCH-U350
1206	Samsung	SCH-U360
1207	Samsung	SCH-U370
1208	Samsung	SCH-U450
1209	Samsung	SCH-U450
1210	Samsung	SCH-U450(Verizon)

1211	Samsung	SCH-U460
1212	Samsung	SCH-U820
1213	Samsung	SCH-W899
1214	Samsung	SGH-C414
1215	Samsung	SGH-C414Y
1216	Samsung	SGH-I896
1217	Samsung	SGH-I897
1218	Samsung	SGH-I897
1219	Samsung	SGH-i917
1220	Samsung	SGH-I917R
1221	Samsung	SGH-I997
1222	Samsung	SGH-J600E
1223	Samsung	SGH-T259
1224	Samsung	SGH-T499
1225	Samsung	SGH-T759
1226	Samsung	SGH-T839
1227	Samsung	SGH-T939
1228	Samsung	SGH-T959
1229	Samsung	SGH-T959
1230	Samsung	SGH-T959D
1231	Samsung	SGH-T959D
1232	Samsung	SGH-T959D
1233	Samsung	SGH-T959V
1234	Samsung	SHC-Z120L
1235	Samsung	SHW-A280K
1236	Samsung	SHW-A280L
1237	Samsung	SHW-A280S
1238	Samsung	SHW-M100S
1239	Samsung	SHW-M110S
1240	Samsung	SHW-M110S
1241	Samsung	SHW-M110S
1242	Samsung	SHW-M120S
1243	Samsung	SHW-M130K
1244	Samsung	SHW-M130K
1245	Samsung	SHW-M130L
1246	Samsung	SHW-M130L
1247	Samsung	SHW-M135K
1248	Samsung	SHW-M135L
1249	Samsung	SHW-M180K
1250	Samsung	SHW-M180L
1251	Samsung	SHW-M180S
1252	Samsung	SHW-M180W
1253	Samsung	SHW-M185S
1254	Samsung	SHW-M190S
1255	Samsung	SHW-M200K
1256	Samsung	SHW-M200S
1257	Samsung	SHW-M210S
1258	Samsung	SPH-D700
1259	Samsung	SPH-i350
1260	Samsung	SPH-M260
1261	Samsung	SPH-M330
1262	Samsung	SPH-M340
1263	Samsung	SPH-M350

1264	Samsung	SPH-M360
1265	Samsung	SPH-M380
1266	Samsung	SPH-M560
1267	Samsung	SPH-M570
1268	Samsung	SPH-M575
1269	Samsung	SPH-M7200
1270	Samsung	SPH-M7350
1271	Samsung	SPH-M8400
1272	Samsung	SPH-M900
1273	Samsung	SPH-M900
1274	Samsung	SPH-M910
1275	Samsung	SPH-P100
1276	Samsung	SWD-S500
1277	Samsung	X01SC
1278	Sonim	Sonim XP1300-A-R1 (Type: P25B005AA)
1279	Sonim	Sonim XP1300-E-R1 (Type: P24B005AA)
1280	Sonim	Sonim XP3300-A-R1 (Type: P25C005AA)
1281	Sonim	Sonim XP3300-E-R1 (Type: P24C005AA)
1282	Sony Ericsson	Aino/ U10
1283	Sony Ericsson	ASPEN
1284	Sony Ericsson	C510, C510a
1285	Sony Ericsson	C901, C901a
1286	Sony Ericsson	C903, C903a
1287	Sony Ericsson	Cedar?
1288	Sony Ericsson	Elm
1289	Sony Ericsson	F100i
1290	Sony Ericsson	Hazel
1291	Sony Ericsson	J105 (Naite?)
1292	Sony Ericsson	Satio/ U1
1293	Sony Ericsson	Sony Ericsson A8i
1294	Sony Ericsson	T707, T707a
1295	Sony Ericsson	T715
1296	Sony Ericsson	TM717
1297	Sony Ericsson	U10
1298	Sony Ericsson	Vivaz?
1299	Sony Ericsson	Vivaz? pro
1300	Sony Ericsson	W508, W508a
1301	Sony Ericsson	W518a
1302	Sony Ericsson	W705, W705u, W705a
1303	Sony Ericsson	W715
1304	Sony Ericsson	W995, W995a
1305	Sony Ericsson	Xperia Pureness/ X5
1306	Sony Ericsson	Xperia X10
1307	Sony Ericsson	Xperia? X10 mini (Rev 2)
1308	Sony Ericsson	Xperia? X10 mini pro (Rev2)
1309	Sony Ericsson	Xperia? X8
1310	Sony Ericsson	Yari
1311	Sony Ericsson	Zylo?
1312	ZTE	003Z
1313	ZTE	a5
1314	ZTE	Android Edition Starnaute
1315	ZTE	BJK1903
1316	ZTE	F160

1317	ZTE	F870
1318	ZTE	F870E
1319	ZTE	F930
1320	ZTE	F950
1321	ZTE	F951
1322	ZTE	F951E
1323	ZTE	Jack 3G
1324	ZTE	San Francisco
1325	ZTE	T870
1326	ZTE	T930
1327	ZTE	Tactile internet 2
1328	ZTE	Venus
1329	ZTE	Vodafone 945
1330	ZTE	XCD35
1331	ZTE	ZTE F870
1332	ZTE	ZTE F951
1333	ZTE	ZTE F952 UM KP
1334	ZTE	ZTE-1001
1335	ZTE	ZTE-BLADE
1336	ZTE	ZTE-C F350
1337	ZTE	ZTE-U X990
1338	ZTE	ZTE-U X991
1339	Adec & Partner AG	AG vegas
1340	Altek	Altek A14
1341	Amgoo Telecom Co LTD	AM83
1342	Aramasmobile.com	ZX021
1343	Ascom Sweden AB	3749
1344	Asustek	Garmin-ASUS M10E
1345	Asustek	P565c
1346	Asustek	G60
1347	Asustek	P320
1348	Asustek	A10
1349	Asustek	Galaxy3_L and Galaxy3_S
1350	Asustek	1000846
1351	Broadcom Corporation	BTL-A
1352	Cellnet 7 Inc.	DG-805
1353	Cellon Communications Technology(Shenzhen) Co., Ltd.	C3031
1354	Cellon Communications Technology(Shenzhen) Co., Ltd.	Claro ADR1105,
1355	Cellon Communications Technology(Shenzhen) Co., Ltd.	PCD ADR1105,
1356	Cellon Communications Technology(Shenzhen) Co., Ltd.	C7519
1357	Cellon Communications Technology(Shenzhen) Co., Ltd.	C8093,

1358	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5030,
1359	Cellon Communications Technology(Shenzhen) Co., Ltd.	C2053,
1360	Cellon Communications Technology(Shenzhen) Co., Ltd.	C2052,
1361	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5031,
1362	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5136,
1363	Chi Mei Communication Systems, Inc.	VIZIO (VPHN1044G)
1364	China Bird (HK) Limited	Carisma 150
1365	Cisco	Cius
1366	Cisco	CP-7926G VoIP Telephone
1367	Dell Computer Corporation	M01M
1368	Dell Computer Corporation	V03B, V03B001, V03B002
1369	Dell Computer Corporation	V03B
1370	Doro AB	Doro PhoneEasy® 615
1371	Doro AB	Doro PhoneEasy® 610
1372	ecom instruments GmbH	Ex-Handy 07 .0 -E
1373	ecom instruments GmbH	Ex-Handy 07 .0 -A
1374	ecom instruments GmbH	Ex-Handy 07 .2 -E
1375	ecom instruments GmbH	Ex-Handy 07 .2 -A
1376	FIH CO., LTD	VS14034
1377	FIH CO., LTD	FAD
1378	Fujitsu Limited	F-12C
1379	Fusion Garage Pte Ltd	Grid4
1380	HAUS	JS100
1381	HTC	PI391XX
1382	HTC	ADR6425 LVW
1383	HTC	PJ03XXX
1384	HTC	ADR6400L
1385	HTC	PC992XX
1386	HTC	PG86xxx
1387	HTC	PI46xxx
1388	HTC	PD261XX
1389	HTC	PC402XX
1390	HTC	PI39XXX
1391	HTC	PI06XXX
1392	HTC	PD421XX
1393	HTC	PH39xxx
1394	HTC	HTC 7 Pro
1395	HTC	PH85xxx
1396	HTC	ADR6330VW
1397	HTC	PI42XXX
1398	HTC	PC931XX
1399	HTC	ADR6425LVW

1400	HTC	PG7624000
1401	HTC	PH44XXX
1402	HTC	PG88xxx
1403	HTC	PH11xxx
1404	HTC	PG762XX
1405	HTC	PD112xx
1406	HTC	HTC ChaCha
1407	HTC	PG321XX
1408	HTC	PG061XX
1409	HTC	PG76XXX
1410	HTC	PG32XXX
1411	HTC	PC36XXX
1412	HTC	PG41xxx
1413	HTC	PG58100
1414	HTC	PG59xxx
1415	HTC	PI86XXX
1416	HUAWEI	HUAWEI G6605
1417	HUAWEI	HUAWEI G6008
1418	HUAWEI	007HW
1419	HUAWEI	HUAWEI M886/ M886/ HUAWEI C8860/ C8860
1420	HUAWEI	HUAWEI U8850-1
1421	HUAWEI	HUAWEI U8350-51/ U8350-51
1422	HUAWEI	HUAWEI U8350-3/ U8350-3
1423	HUAWEI	HUAWEI T5900
1424	HUAWEI	S7-105
1425	HUAWEI	HUAWEI T8300
1426	HUAWEI	PCDM650KT/ HUAWEI M650/ M650/ HUAWEI C8350/ C8350
1427	HUAWEI	HUAWEI G6151
1428	HUAWEI	G6609
1429	HUAWEI	HUAWEI G5500
1430	HUAWEI	HUAWEI U5300
1431	HUAWEI	HUAWEI U5200
1432	HUAWEI	G5510
1433	HUAWEI	C5120
1434	HUAWEI	U5110h-1
1435	HUAWEI	G7300
1436	HUAWEI	G6050
1437	HUAWEI	U8520/ HUAWEI U8520-1/ HUAWEI U8520/ U8520-1
1438	HUAWEI	HUAWEI U8520-51/ U8520-51
1439	HUAWEI	HUAWEI G7050
1440	HUAWEI	D51-1
1441	HUAWEI	U2801-34
1442	HUAWEI	HUAWEI C8850
1443	HUAWEI	GM Ultimate Slim/ HUAWEI U8510-1/ U8510-1
1444	HUAWEI	S7-201c
1445	HUAWEI	S7-202c
1446	HUAWEI	HUAWEI U8652/ U8652/ Huawei U8652/ U8652-51
1447	HUAWEI	HUAWEI U8820/ U8820/ Titan
1448	HUAWEI	HUAWEI U8180-1/ U8180-1/ HUAWEI U8180/ U8180/ Stockholm/ T-Mobile Rapport/ Android Edition™ StarShine
1449	HUAWEI	HUAWEI U8180-7/ U8180-7
1450	HUAWEI	HUAWEI U8350/ U8350/ U8350-1/ Barcelona/ Boulder
1451	HUAWEI	HUAWEI G6620

1452	HUAWEI	HUAWEI U8500/ U8500/ HUAWEI U8500-6/ U8500-6
1453	HUAWEI	HUAWEI T2361
1454	HUAWEI	HUAWEI U8160-U/ U8160-U/ Vodafone 858 Smart/ Vodafone 858/
1455	HUAWEI	HUAWEI M865, M865, HUAWEI M865 MUVE
1456	HUAWEI	HUAWEI G6626
1457	HUAWEI	HUAWEI U8650-1/ U8650-1
1458	HUAWEI	HUAWEI U8650NFC-1/ U8650NFC-1
1459	HUAWEI	HUAWEI U8800 Pro/ U8800 Pro
1460	HUAWEI	HUAWEI U2800
1461	HUAWEI	HUAWEI T2281
1462	HUAWEI	HUAWEI T2251
1463	HUAWEI	HUAWEI T2311
1464	HUAWEI	HUAWEI T6300
1465	HUAWEI	HUAWEI G6608
1466	HUAWEI	S7-201u
1467	HUAWEI	S7-202u
1468	HUAWEI	HUAWEI G7210 / PANAMA CU
1469	HUAWEI	HUAWEI U8800-51/ U8800-51
1470	HUAWEI	MTC 752
1471	HUAWEI	HUAWEI U6150
1472	HUAWEI	HUAWEI M635
1473	HUAWEI	HUAWEI U8160/ U8160/ Vodafone 858 Smart/ Vodafone 858/
1474	HUAWEI	HUAWEI M615
1475	HUAWEI	HUAWEI G7205
1476	HUAWEI	HUAWEI M835/ M835
1477	HUAWEI	HUAWEI T8600
1478	HUAWEI	HUAWEI U8860/ U8860/ Honor
1479	INQ Mobile	T2-219U/ T2-218U
1480	inventec	S42HW
1481	JRD Communication (ShenZhen) Inc	one touch 678G
1482	KT Tech	KM-S220H
1483	KT Tech	KM-S300
1484	KT Tech	KM-S220
1485	KT Tech	KM-S200
1486	Kyocera	ISW11K
1487	Kyocera	S1350
1488	Kyocera	M6000
1489	Kyocera	SCP-8600
1490	Kyocera	C4700
1491	Kyocera	Taho E4100
1492	LG	LG-F100S/ LG-F100L
1493	LG	L-01D
1494	LG	LG-VS840
1495	LG	LG GSM Mobile Phone (LG-A290)
1496	LG	LG-LS840
1497	LG	LG-T565b
1498	LG	LG-LN272 / LG272 / LG272c
1499	LG	LG-SU540/ LG-KU5400/ LG-LU5400
1500	LG	LG-MS695
1501	LG	LG-SH840, LG-KH8400
1502	LG	LG-E730f
1503	LG	LG 3G Mobile Phone (LG-A340)

1504	LG	L-02D, PR-01D
1505	LG	LG-SU880
1506	LG	LG-P940, LG-SU540, LG-KU5400, LG-LU5400, L-02D
1507	LG	LG-C395
1508	LG	LG-MS840
1509	LG	IS11LG
1510	LG	LG 3G Mobile Phone (LG-C800G)
1511	LG	LG 3G Mobile Phone (LG-C800)
1512	LG	LG GSM Mobile Phone (LG-T565/ LG-T575/ LG-T650)
1513	LG	LG-P935
1514	LG	LG-L95G
1515	LG	LG 3G Mobile Phone (LG-P698 / LG-P698f)
1516	LG	LG 3G Mobile Phone (LG-E510 / LG-E510f / LG-E510g)
1517	LG	LG-S367
1518	LG	LG-LU6500
1519	LG	LG 3G Mobile Phone(LG-A353)
1520	LG	LG-SU640/ LG-LU6200
1521	LG	LGL55C
1522	LG	LG 3G Mobile Phone (LG-P699)
1523	LG	CD02/ VER-01
1524	LG	LG CDMA Mobile Phone(LG-LS855/ LG-US855/ LG-AS855/ LG-LG855/ LG-VM855)
1525	LG	LG CDMA Mobile Phone(LGL85C)
1526	LG	LG-LS831/ LG-T130L/ LG-US831/ LG-AS831
1527	LG	LGL45C
1528	LG	X350
1529	LG	LG-AS680
1530	LG	LG CDMA Mobile Phone(LG-VN271/ LG-AN271/ LG-UN271)
1531	LG	LG 3G Mobile Phone (LG-P690b)
1532	LG	LG-E739
1533	LG	LG 3G Mobile Phone (LG-P690 / LG-P692 / LG-P690f / LG-P690g)
1534	LG	LG-P925g, LG-P920h
1535	LG	LG-SH560/ LG-KH5800
1536	LG	LG-E730
1537	LG	LG-SU760
1538	LG	LG-VS920
1539	LG	LG-P930
1540	LG	LG-C660/ LG-C660h/ LG-C660R
1541	LG	LG-A258
1542	LG	LG-C375/ LG-C370/ LG-C365/ LG-C360
1543	LG	LG-E906
1544	LG	LG-UN431/ AN431/ LG431
1545	LG	LG 3G Mobile Phone (LG-A350 / LG-A355 / LG-A360)
1546	LG	LG CDMA Mobile Phone (LG-LS700/ LG-VS700/ LG-US700/ LG-AS700/ LG-CS700/ LG-LG701/ LG-VM701)
1547	LG	LG430G
1548	LG	LG-LS685
1549	LG	CT520
1550	LG	LG CDMA Mobile Phone (LG-SV850)
1551	LG	LG CDMA Mobile Phone (LG-SV850)
1552	LG	LG-LU6800
1553	LG	LG-C729
1554	LG	LG-P990h

1555	LG	LG-P970h
1556	LG	LG-S365/ LG-S360
1557	LG	LG-P500/ LG-P509TN/ LG-P509BK/ LG-P509MZ/ LG-P500h/ LG-P503/ LG-P505/ LG-P504/
1558	LG	LG-A250 / LG-A255
1559	LG	LG-MS910
1560	LG	LG-V150
1561	LG	LG CDMA Mobile Phone (LG-VN251/ LG-UN251/ LG-MN251/
1562	LG	LG 3G Mobile Phone (LG-E300)
1563	LG	LG-3G Mobile phone (LG-C555)
1564	LG	LG-A230/ LG-A235/ LG-A225
1565	LG	LG-KU5900
1566	LG	LG-A200
1567	LG	L-07C
1568	LG	LG-KU2800
1569	LG	LG-CX670/ LGCX670
1570	LG	LG-UN270
1571	LG	LG GSM Mobile Phone (LG-C330i)
1572	LG	LG CDMA Phone (LG-SU780)
1573	LG	LG-UN150/ LG-VN150/ LG221C/ LG235C/ LG-MN150/ LW150/ LG-VP150/ LG150
1574	LG	LG-P999
1575	LG	LG670
1576	LG	LG-P999DW
1577	LG	LG-P970G
1578	LG	LG-P504
1579	LG	LG-T500/ LG-T505/ LG-T507/ LG-T510/ LG-T515/ LG-T520/ LG-
1580	LG	LG-P505R/ LG-P505CH
1581	LG	LG-C330
1582	LG	LG-LS696
1583	MediaTek	Mediatek Bluetooth® Host SW 4.0 + HS
1584	MediaTek	Phone
1585	Microsoft	Windows Phone 7
1586	Motorola	A955
1587	Motorola	XT615
1588	Motorola	MT620
1589	Motorola	Style
1590	Motorola	XT875
1591	Motorola	XT862
1592	Motorola	XT860
1593	Motorola	EX139
1594	Motorola	MT870
1595	Motorola	A956
1596	Motorola	XT610
1597	Motorola	XT317
1598	Motorola	Jorian-xt605
1599	Motorola	MB810
1600	Motorola	Fawnridge i940
1601	Motorola	WX346
1602	Motorola	Birdstone i475,
1603	Motorola	DominoV
1604	Motorola	Titanium
1605	Motorola	W409G

1606	Motorola	Hallcrest (WX 430)
1607	Motorola	XT531
1608	Motorola	XT530
1609	Motorola	XT532
1610	Motorola	XT311
1611	Motorola	XT311
1612	Motorola	MOSAIC-i440
1613	Motorola	XT882
1614	Motorola	WX292
1615	Motorola	WX294
1616	Motorola	BRIDGEVIEW iDEN
1617	Motorola	EX130
1618	Motorola	EX132
1619	Motorola	EX232
1620	Motorola	EX212
1621	Motorola	Brea
1622	Motorola	EX118
1623	Motorola	EX223
1624	Motorola	XT610
1625	Motorola	MB612
1626	Motorola	XT865
1627	Motorola	MB870
1628	Motorola	MB508
1629	Motorola	MB520
1630	Motorola	MB861
1631	Motorola	ME860
1632	Motorola	MB810 UR
1633	Motorola	MB525
1634	Motorola	XT301
1635	Motorola	MT810LX
1636	Motorola	XT300
1637	Motorola	A953
1638	Motorola	A956
1639	Motorola	MB611
1640	Motorola	i475 (Birdstone)
1641	Motorola	EX108
1642	Motorola	A957
1643	Motorola	EX109
1644	Motorola	GSM mobile phone
1645	Motorola	WX445
1646	NEC CASIO	KMP7N4AB-1A
1647	NEC CASIO	N-04C
1648	NEC CASIO	G'zOne
1649	NEC CASIO	C781
1650	NEC CASIO	N-02D
1651	NEC CASIO	G'zOne
1652	NEC CASIO	IS11CA
1653	NEC CASIO	N-06C
1654	NEC CASIO	N-05C
1655	NEC CASIO	CA-01C
1656	Nokia	2000
1657	Nokia	Nokia 801T
1658	Nokia	X2-02

1659	Nokia	201
1660	Nokia	2010
1661	Nokia	200
1662	Nokia	303
1663	Nokia	3030
1664	Nokia	300
1665	Nokia	3000
1666	Nokia	C2-05.1
1667	Nokia	C2-05
1668	Nokia	X2-05
1669	Nokia	Nokia 603
1670	Nokia	C3-01.5
1671	Nokia	Vertu CONSTELLATION T
1672	Nokia	C5-05
1673	Nokia	C5-06
1674	Nokia	C2-07
1675	Nokia	C2-08
1676	Nokia	Nokia 701
1677	Nokia	Nokia 700
1678	Nokia	Nokia 600
1679	Nokia	Nokia 500
1680	Nokia	N9
1681	Nokia	Nokia C7-00s
1682	Nokia	702T
1683	Nokia	C2-02
1684	Nokia	C2-02.1
1685	Nokia	C2-03
1686	Nokia	C2-06
1687	Nokia	T7-00
1688	Nokia	X3-02.5
1689	Nokia	X3-02i
1690	Nokia	C3-00.2
1691	Nokia	C5-00.03
1692	Nokia	C5-00.2
1693	Nokia	X7
1694	Nokia	Nokia E6-00
1695	Nokia	Nokia C7-00.1
1696	Nokia	C2-00
1697	Nokia	X2-03
1698	Nokia	C5-04.1
1699	Panasonic	EB-4054
1700	Panasonic	EB-4057
1701	Panasonic	EB-3236
1702	Panasonic	KX-TU311
1703	Panasonic	P-01D
1704	Panasonic	P-02D
1705	Panasonic	101P
1706	Panasonic	P-07C
1707	Panasonic	003P
1708	Pantech	P8000
1709	Pantech	IM-A775C
1710	Pantech	IM-A810K
1711	Pantech	IM-A810S

1712	Pantech	P6020
1713	Pantech	TXT8045US
1714	Pantech	IM-A800S
1715	Pantech	IM-A720L
1716	Pantech	IM-A730S
1717	Pantech	IM-A710K
1718	Pantech	IM-A690L
1719	Pantech	IM-A690S
1720	Pantech	Pantech P9070
1721	Pantech	PantechP7050
1722	Pantech	CDMA PTI111(PTI11)
1723	Pantech	CDMA EIS01PT(EIS01PT)
1724	Pantech	CDM8992
1725	Pantech	IM-T100K
1726	Pantech	IM-A780L
1727	Pantech	IM-A720L
1728	Pantech	IM-A725L
1729	Pantech	P5000
1730	Pantech	PantechP9060
1731	Pantech	IM-A770K
1732	Pantech	IM-A760S
1733	Pantech	IM-A750K
1734	Pantech	IM-A740S
1735	Pantech	ADR8995
1736	Pantech	CDM8992
1737	Pantech	P2030
1738	Pantech	TXT8045VW
1739	Pantech	IM-A730S
1740	RIM	RDL61TC
1741	RIM	BlackBerry® Bold™ 9790
1742	RIM	BlackBerry® Curve™ 9380
1743	RIM	BlackBerry® Curve™ 9370
1744	RIM	BlackBerry® Curve™ 9360 Smartphone
1745	RIM	BlackBerry® Curve™ 9350 Smartphone
1746	RIM	BlackBerry® Torch™ 9810 Smartphone
1747	RIM	BlackBerry® Torch™ 9860 Smartphone
1748	RIM	BlackBerry® Bold™ 9930 Smartphone
1749	RIM	BlackBerry® Torch™ 9850 Smartphone
1750	RIM	BlackBerry® Bold™ 9900 Smartphone
1751	RIM	BlackBerry® Curve™ 8980
1752	Samsung	GT-I9020
1753	Samsung	GT-I9023
1754	Samsung	GT-I9020T
1755	Samsung	GT-I9020A
1756	Samsung	SGH-I827
1757	Samsung	GT-S6102
1758	Samsung	GT-S6102B
1759	Samsung	SHV-E150S
1760	Samsung	CDMA SC111
1761	Samsung	SCH-R940
1762	Samsung	SGH-T959W
1763	Samsung	GT-S3770Y
1764	Samsung	GT-S3770M

1765	Samsung	GT-S5830M
1766	Samsung	SGH-I577
1767	Samsung	SGH-T769
1768	Samsung	SCH-U365
1769	Samsung	GT-S5222
1770	Samsung	GT-S5220
1771	Samsung	GT-C3312
1772	Samsung	GT-C3310
1773	Samsung	SPH-L700
1774	Samsung	GT-S7500
1775	Samsung	SHW-M410K
1776	Samsung	SHW-M410S
1777	Samsung	SCH-W279
1778	Samsung	SGH-I757
1779	Samsung	GT-P6201
1780	Samsung	SGH-I717R
1781	Samsung	SGH-I717D
1782	Samsung	SGH-I717M
1783	Samsung	GT-S5270Y
1784	Samsung	GT-E2222L
1785	Samsung	GT-I9250W
1786	Samsung	GT-B5512B
1787	Samsung	SGH-I717
1788	Samsung	SHW-M420S
1789	Samsung	SHW-M340K
1790	Samsung	SHW-M340S
1791	Samsung	SCH-R760
1792	Samsung	GT-S7250D
1793	Samsung	GT-P6200L
1794	Samsung	SGH-S425G
1795	Samsung	GT-N7000
1796	Samsung	GT-I9228
1797	Samsung	SPH-M580
1798	Samsung	SHW-M340L
1799	Samsung	GT-S5690
1800	Samsung	GT-S5690L
1801	Samsung	GT-S5690L
1802	Samsung	GT-B5512
1803	Samsung	GT-S5830i
1804	Samsung	GT-I9070
1805	Samsung	GT-S5369
1806	Samsung	SHW-M420K
1807	Samsung	SCH-P739
1808	Samsung	SCH-P739
1809	Samsung	SHV-E160S
1810	Samsung	SHV-E160K
1811	Samsung	SHV-E160L
1812	Samsung	SCH-W309
1813	Samsung	SGH-T245G
1814	Samsung	SCH-I579i
1815	Samsung	SC-04D
1816	Samsung	GT-I9250T
1817	Samsung	GT-I9250M

1818	Samsung	GT-S5380L
1819	Samsung	GT-S5380B
1820	Samsung	SCH-i889
1821	Samsung	GT-E1232B
1822	Samsung	SCH-I929
1823	Samsung	SC-03D
1824	Samsung	GT-I8150T
1825	Samsung	GT-I8350T
1826	Samsung	GT-N7000
1827	Samsung	SGH-i847
1828	Samsung	GT-S5380
1829	Samsung	GT-S5380D
1830	Samsung	GT-S5380K
1831	Samsung	GT-I8150B
1832	Samsung	GT-C3332
1833	Samsung	GT-I9250
1834	Samsung	GT-S5570I
1835	Samsung	GT-I9210
1836	Samsung	GT-S5368
1837	Samsung	GT-C3350
1838	Samsung	GT-E2600
1839	Samsung	SGH-I927R
1840	Samsung	SGH-T679M
1841	Samsung	SCH-i509
1842	Samsung	SGH-A967
1843	Samsung	SCH-R220
1844	Samsung	SCH-W999
1845	Samsung	GT-C3330
1846	Samsung	GT-S3970
1847	Samsung	GT-C3520
1848	Samsung	GT-I9220
1849	Samsung	GT-S8600
1850	Samsung	GT-S5360L
1851	Samsung	GT-S5360B
1852	Samsung	GT-B5510
1853	Samsung	GT-B5510L
1854	Samsung	GT-B5510B
1855	Samsung	SGH-T869
1856	Samsung	GT-S7250
1857	Samsung	SGH-i937
1858	Samsung	SCH-I515
1859	Samsung	SHV-E120S
1860	Samsung	SHV-E120K
1861	Samsung	SHV-E120L
1862	Samsung	GT-S5610
1863	Samsung	SPH-M580 BST
1864	Samsung	GT-S5360T
1865	Samsung	GT-S5363
1866	Samsung	SGH-I727R
1867	Samsung	SCH-R930
1868	Samsung	SGH-T989D
1869	Samsung	GT-I8350
1870	Samsung	GT-S5360

1871	Samsung	GT-E2230L
1872	Samsung	SCH-R680
1873	Samsung	SPH-D710
1874	Samsung	SPH-D705
1875	Samsung	SHV-E110S
1876	Samsung	SHV-E110S
1877	Samsung	SPH-M370
1878	Samsung	SGH-i677
1879	Samsung	GT-E3210O
1880	Samsung	GT-E3217B
1881	Samsung	SCH-I589
1882	Samsung	SCH-i919
1883	Samsung	GT-I8150
1884	Samsung	SGH-T679
1885	Samsung	GT-S3770
1886	Samsung	GT-S3778
1887	Samsung	GT-S3778V
1888	Samsung	GT-S3770B
1889	Samsung	GT-S3770K
1890	Samsung	SCH-I110
1891	Samsung	GT-S3770L
1892	Samsung	GT-I9100P
1893	Samsung	GT-S5660V
1894	Samsung	SCH-M828C
1895	Samsung	SGH-I937
1896	Samsung	SGH-T989
1897	Samsung	SPH-D600
1898	Samsung	SC-02C
1899	Samsung	SGH-I997R
1900	Samsung	GT-I9018
1901	Samsung	GT-S5838
1902	Samsung	GT-S5578
1903	Samsung	SHW-A310S
1904	Samsung	GT-S5273L
1905	Samsung	GT-S5270K
1906	Samsung	GT-S5511T
1907	Samsung	SPH-D710
1908	Samsung	GT-C3011
1909	Samsung	GT-S5780
1910	Samsung	SHW-M250L
1911	Samsung	SCH-R730
1912	Samsung	SCH-R920
1913	Samsung	SCH-W689
1914	Samsung	SPH-M930
1915	Samsung	SPH-M380
1916	Samsung	GT-S5270L
1917	Samsung	GT-S5820
1918	Samsung	SGH-I927
1919	Samsung	SGH-I807
1920	Samsung	SCH-I405
1921	Samsung	SGH-I727
1922	Samsung	GT-I9003
1923	Samsung	SGH-T589R

1924	Samsung	GT-S5660M
1925	Samsung	GT-I9188
1926	Samsung	GT-I9108
1927	Samsung	SGH-I807
1928	Samsung	SHW-M250S
1929	Samsung	SHW-M250K
1930	Samsung	SGH-T499Y
1931	Samsung	SGH-T499W
1932	Samsung	GT-I9100M
1933	Samsung	SGH-I777
1934	Samsung	SGH-I777
1935	Samsung	GT-I9100M
1936	Samsung	GT-I9100G
1937	Samsung	GT-I9103
1938	Samsung	SGH-I857
1939	Samsung	GT-C3322
1940	Samsung	GT-I9001
1941	Samsung	SGH-I997
1942	Samsung	SHW-M250L
1943	Samsung	SHW-A300S
1944	Samsung	SHW-A300K
1945	Samsung	GT-I9100T
1946	Samsung	GT-I9100T
1947	Samsung	GT-I9100
1948	Samsung	GT-E2222
1949	Samsung	GT-E2220
1950	Samsung	SGH-T269
1951	Samsung	SGH-T379
1952	Samsung	GT-I5510 (GB)
1953	Samsung	GT-S5571
1954	Samsung	SCH-R455
1955	Samsung	SGH-T669Y
1956	Samsung	SGH-T669V
1957	Samsung	GT-I9008L
1958	Samsung	GT-I5510M
1959	Samsung	GT-I6712
1960	Samsung	SC-02C
1961	Samsung	SCH-R641
1962	Samsung	GT-C3750
1963	Samsung	GT-C3752
1964	Samsung	SCH-R380
1965	Samsung	GT-C3560
1966	Samsung	SCH-R720
1967	Samsung	SCH-R640
1968	Samsung	SPH-D600
1969	Samsung	SCH-U380
1970	Samsung	SCH-U480
1971	Samsung	GT-C6712
1972	Samsung	SHW-M250S
1973	Samsung	SHW-M250K
1974	Samsung	SPH-M930
1975	Samsung	GT-E2152i
1976	Samsung	SPH-D720

1977	Samsung	GT-I9100
1978	Samsung	GT-B7510L
1979	Samsung	GT-B7510B
1980	Samsung	SGH-T589
1981	Samsung	GT-I9008L
1982	Samsung	SHW-M290S
1983	Samsung	SHW-M290K
1984	Samsung	GT-S5660B
1985	Samsung	GT-S5660L
1986	Samsung	SCH-I569
1987	Samsung	SCH-I809
1988	Samsung	SGH-T369R
1989	Samsung	SGH-T330G
1990	Samsung	GT-S5260P
1991	Samsung	GT-E3213K
1992	Samsung	SCH-R261
1993	Samsung	SGH-T669V
1994	Samsung	SGH-T669Y
1995	Samsung	SGH-T249R
1996	Samsung	SCH-I909L
1997	Samsung	SGH-T959P
1998	Samsung	SGH-C414V
1999	Samsung	SGH-C414M
2000	Samsung	SGH-C414R
2001	Samsung	SGH-C414W
2002	Samsung	SPH-M580
2003	Samsung	SCH-I510
2004	Samsung	SHW-M115S
2005	Samsung	SHW-M110S
2006	Samsung	GT-C3222W
2007	Samsung	SCH-U660
2008	Samsung	SCH-I559
2009	Samsung	GT-S3850
2010	Samsung	SHW-M240S
2011	Samsung	SHW-M240K
2012	Samsung	SHW-M220L
2013	Samsung	SPH-M820
2014	Samsung	GT-E2230
2015	Samsung	GT-E2232
2016	Samsung	GT-B7510
2017	Samsung	GT-S5660
2018	Samsung	GT-S5830C
2019	Seals Technologies Limited	VR7
2020	Sharp	SH-01D
2021	Sharp	P1FD52C
2022	Sharp	102SH
2023	Sharp	P1FD50C
2024	Sharp	ADS1
2025	Shenzhen Sang Fei Consumer Communications	Philips E122
2026	Shenzhen Sang Fei Consumer Communications	Philips X528

2027	Shenzhen Sang Fei Consumer Communications	Philips W626
2028	Shenzhen Sang Fei Consumer Communications	Philips W820
2029	Shenzhen Sang Fei Consumer Communications	Philips W727
2030	Shenzhen Sang Fei Consumer Communications	Philips X623
2031	Shenzhen Sang Fei Consumer Communications	Philips W527
2032	Shenzhen Sang Fei Consumer Communications	Philips W625
2033	Shenzhen Sang Fei Consumer Communications	Philips W725
2034	Shenzhen Sang Fei Consumer Communications	Philips X525
2035	Shenzhen Sang Fei Consumer Communications	Philips Xenium X325
2036	Shenzhen Sang Fei Consumer Communications	Philips W715
2037	Shenzhen Sang Fei Consumer Communications	Philips X526
2038	Shenzhen Sang Fei Consumer Communications	Philips W920
2039	Shenzhen Tinno Mobile Technology Corp.	T521
2040	SK telesys	SK-S150
2041	Sonim	Sonim XP3300-A-Y1 (Type: P25C005AJ)
2042	Sonim	Sonim XP3300-E-X1 (Type: P24C005AJ)
2043	Sonim	Sonim XP3300-A-X1 (Type: P25C005AJ)
2044	Sonim	Sonim XP1301-E-R1 (Type: P24B005AN)
2045	Sonim	Sonim XP1301-A-R1 (Type: P25B005AN)
2046	Sonim	Sonim XP3300-E-Y1 (Type: P24C005AJ)
2047	Sonim	Sonim XP3400-A-R1 (Type: C21F007AA)
2048	Sonim	Sonim XP3340-E-R1 (Type: P24C005AA)
2049	Sonim	Sonim XP5300-E-R1 (Type: P34F006AA)
2050	Sonim	Sonim XP5300-A-R1 (Type: P35F006AA)
2051	Sony Ericsson	S51SE
2052	Sony Ericsson	Xperia™ active
2053	Sony Ericsson	Live with Walkman
2054	Sony Ericsson	Xperia neo V
2055	Sony Ericsson	Xperia™ arc S
2056	Sony Ericsson	SO-03C
2057	Sony Ericsson	SO-01D
2058	Sony Ericsson	Sony Ericsson txt
2059	Sony Ericsson	WT18
2060	Sony Ericsson	Xperia X10
2061	Sony Ericsson	Xperia mini pro
2062	Sony Ericsson	Xperia mini
2063	Sony Ericsson	Xperia™ ray
2064	Sony Ericsson	Mix Walkman
2065	Sony Ericsson	CDMA SO111
2066	Sony Ericsson	Xperia acro

2067	Sony Ericsson	Xperia pro
2068	Sony Ericsson	Xperia™ acro
2069	Sony Ericsson	txt pro™
2070	Sony Ericsson	SO-01C
2071	Sony Ericsson	Xperia™ neo
2072	Sony Ericsson	Xperia arc
2073	Sony Ericsson	Sony Ericsson R800
2074	Sony Ericsson	Xperia PLAY
2075	TCT Mobile Suzhou Limited	one touch 536
2076	TCT Mobile Suzhou Limited	one touch 985/ one touch 985A/ one touch 985S/ one touch 985N/ TCL A966/ OT 985
2077	TCT Mobile Suzhou Limited	one touch 918/ one touch 918A/ one touch 918D/ one touch 918N/ one touch 918M/ TCL A919/ OT 918
2078	TCT Mobile Suzhou Limited	one touch 318D
2079	TCT Mobile Suzhou Limited	one touch 632D
2080	TCT Mobile Suzhou Limited	one touch 678G
2081	TCT Mobile Suzhou Limited	JukeB
2082	TCT Mobile Suzhou Limited	one touch 909B
2083	TCT Mobile Suzhou Limited	one touch 810/ one touch 810A/ one touch 810D
2084	TCT Mobile Suzhou Limited	one touch 910/ one touch 909A/ one touch 909M/ one touch 909S/ one touch 910A
2085	TCT Mobile Suzhou Limited	one touch 818/ one touch 818A/ one touch 818D
2086	TCT Mobile Suzhou Limited	one touch 913D/ one touch 913K/ one touch 913N
2087	TCT Mobile Suzhou Limited	one touch 888/ one touch 888A/ one touch 888D
2088	TCT Mobile Suzhou Limited	Vodafone 355
2089	TCT Mobile Suzhou Limited	one touch 906/ one touch 906Y
2090	TCT Mobile Suzhou Limited	S by SFR 3440
2091	TCT Mobile Suzhou Limited	Vodafone 555 Blue
2092	TCT Mobile Suzhou Limited	one touch 891
2093	TCT Mobile Suzhou Limited	TCL-7110
2094	TCT Mobile Suzhou Limited	TCL-8107
2095	TCT Mobile Suzhou Limited	MOVE/ one touch 908/ one touch 908A/ one touch 908S/ one touch 908M/ one touch 908F
2096	TCT Mobile Suzhou Limited	one touch 990/ one touch 990A/ one touch 990S/ one touch 990M/ Vodafone 958
2097	TCT Mobile Suzhou Limited	one touch 665/ one touch 665A
2098	TCT Mobile Suzhou Limited	one touch 900M/ one touch 900/ one touch 901A/ one touch 901S/ one touch 901N/ one touch 901D/ one touch 900A
2099	TCT Mobile Suzhou Limited	one touch 585/ 585D/ 585A
2100	TCT Mobile Suzhou Limited	one touch 602/ 602D/ 602A
2101	TCT Mobile Suzhou Limited	one touch 905/ 905A/ 907N/ 905M
2102	TCT Mobile Suzhou Limited	one touch 890/ one touch 890D
2103	TCT Mobile Suzhou Limited	Vodafone 455
2104	TCT Mobile Suzhou Limited	one touch 506/ one touch 506D / one touch 506A
2105	TCT Mobile Suzhou Limited	OT-799/ OT-799A
2106	TCT Mobile Suzhou Limited	one touch 803/ one touch 803A/ one touch 813/ one touch 813D/ one touch 813A/ one touch 819/ one touch 819A/ one touch 819D/ one touch 809/ one touch 813F/ one touch 803F
2107	Tsb Plus Deal Corp	X95
2108	Tsb Plus Deal Corp	EYO E97
2109	Tsb Plus Deal Corp	EYO DESERT 6
2110	ZTE	X500
2111	ZTE	ZTE-U V857

2112	ZTE	X500M
2113	ZTE	ZTE Skate/ ZTE SKATE/ ZTE-SKATE
2114	ZTE	ZTE-Tureis
2115	ZTE	ZTE-Tureis
2116	ZTE	Movistar One
2117	ZTE	ZTE N850
2118	ZTE	ZTE-G R250
2119	ZTE	ZTE-G R252
2120	ZTE	S by SFR 116
2121	ZTE	Light Tab 2W
2122	ZTE	Blade S
2123	ZTE	T28
2124	ZTE	ZTE F116/ F116/ ZTE-U F116
2125	ZTE	T28
2126	ZTE	San Francisco II
2127	ZTE	ZTE-U V859
2128	ZTE	ZTE V6000
2129	ZTE	TQ150
2130	ZTE	webphones Android™ by sfr STARTEXT II
2131	ZTE	Z431
2132	ZTE	ZTE-G R260
2133	ZTE	Vivacity
2134	ZTE	V875
2135	ZTE	Windows Phone-Internet 7
2136	ZTE	ZTE-U V875m
2137	ZTE	009Z
2138	ZTE	tmn smart a7
2139	ZTE	San Francisco II
2140	ZTE	ZTE-G R235
2141	ZTE	ZTE U6100
2142	ZTE	ZTE-U X720
2143	ZTE	Arizona
2144	ZTE	F451
2145	ZTE	RacerII
2146	ZTE	RacerII
2147	ZTE	ZTE-U V960
2148	ZTE	Skate4.3 H
2149	ZTE	ZTE N860
2150	ZTE	008Z
2151	ZTE	008Z
2152	ZTE	Vodafone 550
2153	ZTE	ZTE-G N292
2154	ZTE	MEDION Smartphone LIFE P4310
2155	ZTE	MEDION Smartphone LIFE P4310
2156	ZTE	ZTE V860
2157	ZTE	Android Edition Star Text
2158	ZTE	T60
2159	ZTE	ZTR-G V821
2160	ZTE	ZTE-U F953 / MIMOSA
2161	ZTE	ZTE-U5100
2162	ZTE	ZTE-C D930
2163	ZTE	ZTE-C X769
2164	ZTE	ZTE-U F110

2165	ZTE	ZTE N285
2166	ZTE	CARL/ ZTE-U V852
2167	ZTE	T50
2168	ZTE	ZTE V960
2169	ZTE	ZTE-G R228
2170	ZTE	Monte Carlo
2171	ZTE	ZTE-Atrial
2172	ZTE	Android edition by sfr STARADDICT
2173	ZTE	ZTE-SKATE/ ZTE Skate
2174	ZTE	BASE Lutea 2
2175	ZTE	E821
2176	ZTE	ZTE-U E850
2177	ZTE	ZTE-G N295/ Sydney/ Affinity
2178	ZTE	X500
2179	ZTE	ZTE-G N285
2180	ZTE	Movistar Vega
2181	ZTE	ZTE-C D980
2182	ZTE	Z331
2183	ZTE	ZTE E821S
2184	ZTE	ZTE-G R230
2185	ZTE	V871
2186	ZTE	Z990
2187	ZTE	ZTE-G R236
2188	ZTE	ZTE-C F450
2189	ZTE	Android Edition StarTrail
2190	ZTE	ZTE Libra
2191	ZTE	Vodafone 351
2192	ZTE	ZTE-G X730
2193	ZTE	S by SFR 344
2194	ZTE	KPN Smart 200
2195	ZTE	BLADE II
2196	ZTE	ZTE T12