

## Label information


FOB-4F75U44

MODEL: FOB-4F75U44

FCC ID: TQ8-FOB-4F75U44

IC: 5074A-FOB4F75U44

Label draft



## Label Position

Label will be put on the inside battery compartment. End user can see the label when replacing the battery.

## Label information


FOB-4F76U34

MODEL: FOB-4F76U34

FCC ID: TQ8-FOB-4F75U44

IC: 5074A-FOB4F75U44

Label draft



## Label Position

Label will be put on the inside battery compartment. End user can see the label when replacing the battery.

## Label information


FOB-4F76U43

MODEL: FOB-4F76U43

FCC ID: TQ8-FOB-4F75U44

IC: 5074A-FOB4F75U44

Label draft



## Label Position

Label will be put on the inside battery compartment. End user can see the label when replacing the battery.

## Label information


FOB-4F77U42

MODEL: FOB-4F77U42

FCC ID: TQ8-FOB-4F75U44

IC: 5074A-FOB4F75U44

Label draft



## Label Position

Label will be put on the inside battery compartment. End user can see the label when replacing the battery.

## Label information


FOB-4F77U33

MODEL: FOB-4F77U33

FCC ID: TQ8-FOB-4F75U44

IC: 5074A-FOB4F75U44

Label draft



## Label Position

Label will be put on the inside battery compartment. End user can see the label when replacing the battery.

## Label information


FOB-4F78U32

MODEL: FOB-4F78U32

FCC ID: TQ8-FOB-4F75U44

IC: 5074A-FOB4F75U44

Label draft



## Label Position

Label will be put on the inside battery compartment. End user can see the label when replacing the battery.

## Label information


FOB-4F78U41

MODEL: FOB-4F78U41

FCC ID: TQ8-FOB-4F75U44

IC: 5074A-FOB4F75U44

Label draft



## Label Position

Label will be put on the inside battery compartment. End user can see the label when replacing the battery.

## Label information


FOB-4F79U31

MODEL: FOB-4F79U31

FCC ID: TQ8-FOB-4F75U44

IC: 5074A-FOB4F75U44

Label draft



## Label Position

Label will be put on the inside battery compartment. End user can see the label when replacing the battery.



## Label information


FOB-4F80U30

MODEL: FOB-4F80U30

FCC ID: TQ8-FOB-4F75U44

IC: 5074A-FOB4F75U44

Label draft



## Label Position

Label will be put on the inside battery compartment. End user can see the label when replacing the battery.