


# Playdate Stereo Dock PDD-01



## **A. POWER ON/OFF**


1. Press POWER button to turn the unit on or off.

## **B. BLUETOOTH PAIRING**

1. Search for 'Playdate' on the source device.
2. Select 'Playdate' from the source list.

Beep sound will be heard once the unit is successfully paired with the source device.

Yellow LED will light up.



## **D. VOLUME UP/DOWN**

1. Turn the Rotary Switch clock wise, volume is decrease.  
When volume reach minimum level, Red Led will blink.
2. Turn the Rotary Switch counter clock wise , volume is increased.  
When volume reach maximum level, Green Led will blink.

## **C. BLUETOOTH UNPAIR**

1. To unpair the device, Press and hold the Power button until the beep sound is heard.  
Blue LED will blink continuously.



## **F. RESET**

If the Unit is freeze during operation, please reset the unit.

Use a small sharp pin tools, press the RESET key once.

The Unit will turn OFF and Led indicator is OFF.

## **E. Auto Power OFF**

When the Unit is inactivity for about 5 minutes , the Unit will turn OFF.

To turn off the unit manually, press the Power button.

## **FCC compliance statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **FCC Radiation Exposure statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

## **ISED compliance statement**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## **IC Radiation Exposure statement**

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.