


## Push Button Switches

### 30MBP and 30MBPN


#### Series

30MBPN illuminated 10A and 15A bell press mechanisms


- Neon permanently ON.
- LOAD permanently ON, momentarily OFF.




- Neon permanently ON.
- LOAD permanently OFF, momentarily ON.



- Neon permanently ON, momentarily OFF.
- LOAD permanently ON, momentarily OFF.





- Neon permanently OFF, momentarily ON.
- LOAD permanently OFF, momentarily ON.



## 30MBP non-illuminated 10A and 15A bell press mechanisms

- LOAD permanently ON, momentarily OFF.
- LOAD permanently OFF, momentarily ON.



---

### Clipsal Australia Pty Ltd

A member of Schneider Electric

[clipsal.com](http://clipsal.com)

Contact us: [clipsal.com/feedback](http://clipsal.com/feedback)

National Customer Care Enquiries:

**Tel 1300 2025 25 Fax 1300 2025 56**

Clipsal Australia Pty Ltd reserves the right to change specifications, modify designs and discontinue items without incurring obligation and whilst every effort is made to ensure that descriptions, specifications and other information in this catalogue are correct, no warranty is given in respect thereof and the company shall not be liable for any error therein.

© Clipsal Australia Pty Ltd. The identified trademarks and copyrights are the property of Clipsal Australia Pty Ltd unless otherwise noted.