

# SonicWall® 350W-550W AC Power Supply Replacement and Installation

This document provides instructions for removing and installing a replacement 350W-550W AC Power Supply in one of the following SonicWall appliances:

- Capture Security Appliance (CSa) 1000
- Secure Mobile Access (SMA) 7200/7210
- Email Security 9000

**NOTE:** Disconnect the power from the power supply being replaced. There is no need to power down the appliance.

**WARNING:** Power supply surfaces can be hot. Handle and store with care until the surfaces are cool.

Review the safety and regulatory information in the *Quick Start Guide*, *Getting Started Guide* or *Safety, Regulatory and Legal Information* provided with the SonicWall appliance.

## Rear view of the CSa 1000 and SMA 7200/7210



## Rear view of Email Security 9000



## Removing the AC power supply from the appliance

To remove a defective AC power supply from the SonicWall appliance:

- 1 Unplug the power cord from the SonicWall appliance power supply module that is being replaced. There is no need to power down the appliance.

- 2 Take note of the power supply orientation as it relates to the appliance, then press on the power supply release tab while using the module's handle to pull the module outwards and remove it.



## Installing an AC power supply into the appliance

**WARNING:** Do NOT insert anything except the 350W-550W AC Power Supply into the appliance.

*To install a new 350W-550W AC Power Supply into the appliance:*

- 1 Insert the new power supply module into the empty slot using the same orientation you noted when you removed the defective module.
- 2 Carefully and firmly push the power supply module until it is completely seated and snaps into place.
- 3 Connect the power cord to both the power supply and a power source.
- 4 Confirm that the new power supply is operating correctly. On the front panel, the LED indicator for the power supply should display a blue light. A yellow light indicates a problem.

## Installation et remplacement du module d'alimentation

**AVIS :** Débranchez le cordon d'alimentation à remplacer. Il n'est pas nécessaire de débrancher l'appareil.

**AVERTISSEMENT :** Les surfaces du bloc d'alimentation peuvent être chaudes. Manipulez et entreposez l'appareil avec soin jusqu'à ce que les surfaces soient refroidies.

Lisez les consignes de sécurité dans les documents qui viennent avec votre appareil.

## Retrait du bloc d'alimentation CA de l'appareil

*Pour retirer un bloc d'alimentation défectueux CA de l'appareil :*

- 1 Débranchez le cordon d'alimentation du module d'alimentation à remplacer dans l'appareil SonicWall. Il n'est pas nécessaire de débrancher l'appareil.
- 2 En prenant soin de noter l'orientation du bloc d'alimentation par rapport à l'appareil, appuyez sur l'onglet pour libérer le bloc. Tirez en avant pour sortir le bloc de l'appareil.

## Installation du bloc d'alimentation CA dans l'appareil

- 1 Insérez le nouveau module d'alimentation dans le logement vide dans le sens noté lors du retrait du module défectueux.
- 2 Poussez le module d'alimentation soigneusement et fermement jusqu'à ce qu'il soit complètement inséré et qu'il s'enclenche en place.
- 3 Branchez le cordon d'alimentation sur le bloc d'alimentation et sur la source électrique.
- 4 Vérifiez que le nouveau bloc d'alimentation fonctionne correctement. Le voyant DEL de l'alimentation électrique situé sur le panneau avant devrait être allumé en bleu. Un voyant jaune indique un problème.

## Entfernen des Netzteils aus der SonicWall Appliance

**HINWEIS:** Trennen Sie elektrische Energie von der Stromversorgung ersetzt. Das Gerät muss nicht ausgeschaltet werden.

**WARNUNG:** Stromversorgung Oberflächen können heiß sein. Handhaben und speichern Sie vorsichtig, bis die Oberflächen kühl sind.

*Führen Sie zum Entfernen eines defekten Netzteils aus der SonicWall Appliance die folgenden Schritte aus:*

- 1 Ziehen Sie das Netzkabel aus der SonicWall Appliance Stromversorgungsmodul, das ersetzt wird.
- 2 Beachten Sie die Stromversorgung Ausrichtung in das Gerät. Drücken Sie die Stromversorgung Lösehebel, während mit Griff des Moduls, das Modul nach außen ziehen und abnehmen.

## Einsetzen des Netzteils in die SonicWall Appliance

**⚠ | WARNUNG:** Stecken Sie nichts außer des Netzteils im Gerätesteckplatz.

Führen Sie zum Einsetzen des neuen Netzteils in die SonicWall Appliance die folgenden Schritte aus:

- 1 Führen Sie das Netzteil in die Appliance ein, bis es sich genau am vorgesehenen Platz befindet.
- 2 Drücken Sie die Stromversorgungsbaugruppe in Position, bis sie fest sitzt.
- 3 Schließen Sie das Netzteil mit dem Netzanschlusskabel an die Stromquelle an.
- 4 Überprüfen Sie, ob die Betriebs-LED jetzt blau leuchtet. Dies zeigt an, dass das neue Netzteilmodul erfolgreich eingesetzt und angeschlossen wurde.

## SonicWall 350W-550W 交流電源供應器 電源更換和安裝

此文件提供以下設備需移除與安裝需更換的350W-550W交流電源供應器指南：

- Capture Security Appliance (CSa) 1000
- Secure Mobile Access (SMA) 7200/7210
- Email Security 9000

**ⓘ | 注意 :** 斷開要更換的電源供應器的電源。不需要關閉設備電源。

**⚠ | 警告 :** 電源供應器表面會很熱。直到表面冷卻前，需小心的搬動及存放。

更換前請先閱讀隨設備提供的*Quick Start Guide, Getting Started Guide*或*Safety, Regulatory and Legal Information*。

## 從裝置移除交流電源供應器

若要從SonicWall裝置取出損壞的交流電源供應器，請執行下列步驟：

- 1 從將被替換的 SonicWall 裝置的電源供應器上拔除電源線。不需要關閉設備電源
- 2 記下電源供應器與裝置的相關方向，壓下電源供應器的釋放擋片，同時使用模組的拉把將電源供應器往外拉出移除。

## 安裝交流電源供應器到裝置中

**⚠ | 警告 :** 禁止插入 SonicWall 350W-550W 交流電源供應器以外的任何物品到設備中。

要安裝新的 350W-550W 交流電源供應器到設備中，請按照下列步驟：

- 1 按照移除要替換的電源供應器時所記下的方向插入新的電源供應器模組到 SonicWall 裝置的空插槽中。
- 2 小心的並牢靠的將電源供應器模組推入直到它完全的定位及卡住。
- 3 將電源線連接到電源供應器和電源。
- 4 確認新的電源供應器是正確的運轉。在前面板，電源的 LED 指示燈應該亮藍色，亮黃色表示有問題。

This AC power supply module is for use only with SonicWall appliances indicated below. Use of this module with a SonicWall appliance that is not approved will void the warranty for that appliance. This module is provided as a replacement power supply, and is provided on an "as is" basis without warranty of any kind.

This power supply, 01-SSC-8559 SONICWALL POWER SUPPLY, is approved for use with:  
CAPTURE SECURITY APPLIANCE CSA 1000  
SMA 7200 APPLIANCE  
SMA 7210 APPLIANCE  
EMAIL SECURITY APPLIANCE 9000

For information and related documents, see <https://www.sonicwall.com/support>.

**Copyright © 2020 SonicWall Inc. All rights reserved.**

SonicWall is a trademark or registered trademark of SonicWall Inc. and/or its affiliates in the U.S.A. and/or other countries. All other trademarks are property of their respective owners.

The information in this document is provided in connection with SonicWall Inc. and/or its affiliates' products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document. SonicWall Inc. and/or its affiliates do not make any commitment to update the information contained in this document. For more information, visit <https://www.sonicwall.com/legal>.

### Legend

**⚠ | WARNING:** A WARNING icon indicates a potential for property damage, personal injury, or death.

**⚠ | CAUTION:** A CAUTION icon indicates potential damage to hardware or loss of data if instructions are not followed.

**ⓘ | IMPORTANT, NOTE, TIP, MOBILE, or VIDEO:** An information icon indicates supporting information.

SonicWall 350W-550W AC Power Supply Installation Guide  
Updated - May 2020  
232-005285-50 Rev A



# SonicWall® 350W-550W AC Power Supply Installation Guide

SONICWALL®