

The document is continuously being updated, so if your computer model does not appear in the compatible or incompatible list below, please consult customer service directly.

COMPATIBILITY (Not a full list)

HP	<ul style="list-style-type: none"> ➤ Elitebook (X360 1030 G3/ 735 G6/ 745 G5/ 800 G4/ 830 G5/ 840 G5 series/ 840g6/850 G5/ 850 G7/ 850 G8/ 845 G7/ 840 G8/ 845 G8/ 830 G6/ X2/ 745) ➤ Envy (Geforce MX250/ 17T/ X360/ 13-AQ1/ 13t-ba100/ 113-aq001ms/ 17m-ae011dx) ➤ Spectre (13/ 360/ X360-13T/ 15T/ X369/ 13T-AK000CTO/ AF001TU) ➤ Zbook (15U G3/ 17 G4/ 14U G6/ 15 G5/G6/ 16 G6/ Studio Z5) ➤ Probook (440 G7/ 450 g5/ 450 G6/ 450 G7/ 640 G5/ 650 G5) ➤ Chromebook 11A G6 EE/ 14a-na0122od/ Omen laptops/ GTX 4 Pro15.6
Dell	<ul style="list-style-type: none"> ➤ Latitude (3310 2 in 1/ 3400/ 3410/ 3420/ 3490/ 3500/ 5290/ 5310/ 5320/ 5400/5410/5420/ 5480/ 5490/ 5500/ 5521/ 5530/ 5580/ 5591/ 7280/ 7300 series/ 7370/7389/7390/ 7400/ 7410/ 7420/ 7430/ 7480/ 7490) ➤ XPS (5590/ 9350/ 9380/ 13/ 13-9300/ 13 9305/ 13-9365/ 15/ 15-2018/ 15-9500) ➤ Precision (3561/ 3571/ 5520/ 5530/ 5540/ 5550/ 5560/ 7520/ 7730/ 7750) ➤ Inspiron (5402/ 5590/ 7300/ 13 7300/ 7373/ 7573/ 14 or 15 7000 series 2-in-1/155515) ➤ Dell G7 7790/ Dell G15- 5511/ Dell 17 9700/ Vostro 5620/Dell Vostro 15 5510
Lenovo	<ul style="list-style-type: none"> ➤ Yoga (370/ 720/ 730/ 900/ 910/ 920/ 930/ 940/ C740/ C930/ 15 UltrabookPro/613ALC6/ 7 14ial7/ 7i/9i) ➤ ThinkPad (P1 Gen2/ p15v gen 2/ T14 Gen 1 and 2/ T15p gen 1/ P50/ P52/ P70/P72/E14 / E590/ T470/ T470s/ T480s/ T490s/ 81N8/ Y530/ Y720/ X390/ X1 Carbon/X1Extreme/l490) ➤ IdeaPad (330s/ C330/ Slim7 Pro/ s540/ 720S/581yk006xus) ➤ Legion (Y 530/ 5i pro gen 7/ 5-17-82GN0000US)
Microsoft Surface	<ul style="list-style-type: none"> ➤ laptop (3/4) ➤ Pro (8/ 7/ 5/ X) ➤ Book 2/ Go-1943
Asus	<ul style="list-style-type: none"> ➤ Zenbook (UX330UA/ Flip UX370U/ Q529ZA/ UX435/ UX434F/ UX433FA/ UX425EA/3-UX390/ UX434FLC-AI284R/ 14 UX433FA) ➤ TUF Gaming A15 Gaming Laptop/ Zephyrus G14/ G15/ Rog GX501
Acer	<ul style="list-style-type: none"> ➤ aspirec (5/5 a515-57-760x laptop/ C24-865) ➤ Swift (1/ 3/ 7/ X) ➤ SPIN (5/ 7) ➤ Predator Helios 300
Samsung	<ul style="list-style-type: none"> ➤ Note (20/ 10/ 9 /8+) ➤ Galaxy (S20 ultra/ 10+/ S10/ S9+/ S9/ S8+/ Tablet S4/ S5e/ New S7/ chromebook/Flexalpha 2-in-1)
Huawei	<ul style="list-style-type: none"> ➤ MateBook (X Pro/ E/ X/ Mate10/ 10Pro/ Mate20/ Mate20 Pro/ Mate30/ 30Pro/P20/P20 Pro/ P30 Pro/ 13)
Apple	<ul style="list-style-type: none"> ➤ MacBook/ Pro (2016-2021)/ MacBook Air/ Mac mini (2018-2020) ➤ iMac Pro (2017-2019)/ iMac (2020)/ iPad/ Pro (2018-Newest)
other	<ul style="list-style-type: none"> ➤ Pixel (2016/ 2017)/C340-15/ Google Slate

INCOMPATIBILITY (Not a full list)

HP	<ul style="list-style-type: none"> ➤ All HP Pavillion Laptop ➤ Spectre (X360 13/ 14/ 15T) ➤ Elitebook (745 G3/ 745 G6/ 755 G5/ 800 G2 / 820 G3/ 820 G4/ 840 G3/ 840G4/850G4) ➤ Probook (600/ 640/ 650 G2/ 650 G3) ➤ Laptop (15-dy1xxx/ 15-dy2xxx/ 15t-dy100/ 15t-dy200/ 15-dy1059ms/ 15-dw3XXX/15-dw2025od/ 14-dq1033cl/ 14-dq2045cl/ 15-ef2xxx/ 17-by3613dx/ 17-cn1008cy/PC15s-fq2000(2D119AV)/ 15-dw3097nr/ 15s-fq200/ 17-by1xxx/ 15-EF1001DS/ 17-by2053cl/17z-cp000) ➤ Inspiron 14 5000 Series/ Levano Ideapad 1 15.6" FHD Touch Screen Laptop/ Folio1020B&O/ 17-cn0053cl/ 17-cn0275st/ 15-ef1072nr/ 15-ef0xx ➤ Earlier Pavilion series/ 2020 HP 14/ newer HP Envy 15/ 340S G7/ EVGASC15/17.3in Full HD Notebook/ prodesk 600 G2/ envy x360 15m-bp-112dx/ Notebook15-dy1071wm/ Notebook 15-dy1043dx ➤ Model (17t-by300/ 15-dy1076nr/ 15-dw2025cl/ 15-y1751ms/ 15-dw0037wm/14-dq1033cl/ 14-dq0005cl/ 15EF1300WM)
Dell	<ul style="list-style-type: none"> ➤ Inspiron (17-5000 series / 15-5000 series, 14-5410, 15-3000/3583,17-3793Business,7000 Gaming, Vostro MT 3671) ➤ Latitude (E7270,E7470, E7440,E7450,3520)
Lenovo	<ul style="list-style-type: none"> ➤ YOGA (710-15ikb/ 520) ➤ ThinkPad (I490/E580) ➤ IdeaPad (3/ 5/ 3-15itl6/ 330/ L340/ S340/ 130S/ Flex-15IWL/ Flex-14"/ 15.6" 2-in-1/Flex 5-1570/ Flex 5 14itl05/ Flex 5 15IIL05/ Flex-6 14IKB/ Flex 15 iml) ➤ V330/ T570/ Y520/ 710/ model 81we0016us/ Thinkbook 15P
Microsoft Surface	<ul style="list-style-type: none"> ➤ Surface Pro 3/ 4/ 6 ➤ book 3
Asus	<ul style="list-style-type: none"> ➤ Vivobook series/ Q547/ Q503U/ Q526F/ L203MA/ TUF 17.3 Gaming Laptop ➤ Zenbook (UX333FN/ UX330UA-AH55/ Flip 14 UX461FN-DH74T/ Flip 14UX463FL/Q4071)
Acer	<ul style="list-style-type: none"> ➤ E5-575/ R5-571T/ E5-576G/ R15/ G3-571/ Predator Helios 300/ Swift X 14
Samsung	<ul style="list-style-type: none"> ➤ Galaxy Tab 5 / A50 / A51-5G
Huawei	<ul style="list-style-type: none"> ➤ Matebook 14 / Mediapad M5 lite
Apple	<ul style="list-style-type: none"> ➤ Macbook Air (before 2018)/ MacBook Pro 2015/ iMac 2021
other	<ul style="list-style-type: none"> ➤ Redmi Note 7/VA912/ VA912 Series 4/ VA912B/satellite P25wc/ Radius P55W-B5224 ➤ High-power equipment/ USB Super Drive/ CD/ DVD player