![iFixit logo](X iFixit)

How to force restart the iPhone 7 Plus

Use this guide to force restart your iPhone 7 Plus when it is frozen and not responding. Force restarts are very simple and require no tools.

Written By: Chris Mason

This document was generated on 2020-11-13 05:35:18 PM (MST).

INTRODUCTION

Follow the steps in this guide to Force Restart an iPhone 7 Plus.

Step 1 — How to force restart the iPhone 7 Plus

- To force restart your device, press and hold both the Sleep/Wake and Volume Down buttons for at least ten seconds.

- (i) This Force Restart procedure is different from previous model years since the iPhone 7 series does not have a physical Home Button to press down.

Step 2

- Continue holding both buttons for about 10 seconds, until the Apple logo appears.

Step 3

- Once the Apple logo appears, release both buttons and your iPhone will restart.

You have successfully restarted your iPhone 7 Plus.