

Item	Brand Name	Model
1	Acer	Acer beTouch E210
2	Acer	acer E400
3	Acer	acer P400
4	Acer	DX650
5	Acer	E200
6	Acer	Liquid E
7	Acer	Liquid Mini (E310)
8	Acer	M900
9	Acer	S110
10	Acer	Smart handheld
11	Acer	Smart handheld
12	Acer	Smart handheld E100
13	Acer	Smart handheld E101
14	Adec & Partner AG	AG vegas
15	Alcatel	Alcatel OneTouch Fierce 2
16	Alcatel	MISS SIXTY MSX10
17	Alcatel	OT-800/ OT-800A
18	Alcatel	OT-802/ OT-802A
19	Alcatel	OT-806/ OT-806A/ OT-806D/ OT-807/ OT-807A/ OT-807D
20	Alcatel	OT-808/ OT-808A
21	Alcatel	OT-880/ OT-880A
22	Alcatel	OT-980/ OT-980A
23	Altek	Altek A14
24	Amazon	Amazon Fire Phone
25	Amgoo Telecom Co LTD	AM83
26	Apple	Apple iPhone 4S
27	Apple	Apple iPhone 5
28	Apple	Apple iPhone 6
29	Apple	Apple iPhone 6 Plus
30	Apple	iPhone 2G
31	Apple	iPhone 3G
32	Apple	iPhone 3Gs
33	Apple	iPhone 4
34	Apple	iPhone 5C
35	Apple	iPHone 5S
36	Aramasmobile.com	ZX021
37	Ascom Sweden AB	3749
38	Asustek	1000846
39	Asustek	A10
40	Asustek	G60
41	Asustek	Galaxy3 L and Galaxy3 S
42	Asustek	Garmin-ASUS M10E
43	Asustek	P320
44	Asustek	P565c
45	BlackBerry	BlackBerry Passport
46	BlackBerry	BlackBerry Q10
47	Broadcom Corporation	BTL-A
48	Casio Hitachi	C721
49	Cellnet 7 Inc.	DG-805
50	Cellon Communications Technology(Shenzhen) Co., Ltd.	C2052,
51	Cellon Communications Technology(Shenzhen) Co., Ltd.	C2053,
52	Cellon Communications Technology(Shenzhen) Co., Ltd.	C3031
53	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5030,
54	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5031,
55	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5136,
56	Cellon Communications Technology(Shenzhen) Co., Ltd.	C7519
57	Cellon Communications Technology(Shenzhen) Co., Ltd.	C8093,
58	Cellon Communications Technology(Shenzhen) Co., Ltd.	Claro ADR1105,
59	Cellon Communications Technology(Shenzhen) Co., Ltd.	PCD ADR1105,
60	Chi Mei	AQ4
61	Chi Mei	P300
62	Chi Mei Communication Systems, Inc.	VIZIO (VPHN1044G)
63	China Bird (HK) Limited	Carisma 150
64	Cisco	Cius
65	Cisco	CP-7926G VoIP Telephone
66	Dell Computer Corporation	M01M
67	Dell Computer Corporation	V03B
68	Dell Computer Corporation	V03B, V03B001, V03B002
69	Doro AB	Doro PhoneEasy@ 610
70	Doro AB	Doro PhoneEasy@ 615
71	ecom instruments GmbH	Ex-Handy 07 .0 -A
72	ecom instruments GmbH	Ex-Handy 07 .0 -E
73	ecom instruments GmbH	Ex-Handy 07 .2 -A
74	ecom instruments GmbH	Ex-Handy 07 .2 -E
75	FIH	FM600
76	FIH	N700
77	FIH	PDA Phone

Item	Brand Name	Model
78	FIH	test_RM-383
79	FIH	ViewPad7
80	FIH CO., LTD	FAD
81	FIH CO., LTD	VS14034
82	Fujitsu	T-01C
83	Fujitsu Limited	F-12C
84	Fusion Garage Pte Ltd	Grid4
85	Garmin asus	G60
86	Global High Tech	GHT Maestro
87	Google	Google Nexus 5
88	Google	Google Nexus S
89	HAUS	JS100
90	Hewlett-Packard	HSTNH-P21C
91	HP	iPAD912
92	HTC	ADR6200VW
93	HTC	ADR6300
94	HTC	ADR6300
95	HTC	ADR6330VW
96	HTC	ADR6400L
97	HTC	ADR6425 LVW
98	HTC	ADR6425LVW
99	HTC	CDMA HT111
100	HTC	CEDA100 Series
101	HTC	CEDA100 Series
102	HTC	CEDA100 Series (WM6.5)
103	HTC	Dash 3G
104	HTC	Droid Eris
105	HTC	EVO
106	HTC	Evo 4G
107	HTC	FUZE (TM) P4600
108	HTC	G1
109	HTC	HD2
110	HTC	HD7
111	HTC	Hero
112	HTC	HERO200
113	HTC	HTC 7 Pro
114	HTC	HTC Amaze 4G
115	HTC	HTC ChaCha
116	HTC	HTC Desire 610
117	HTC	HTC Droid DNA
118	HTC	HTC Droid Incredible 4G LTE
119	HTC	HTC First
120	HTC	HTC HD mini
121	HTC	HTC Hero
122	HTC	HTC One
123	HTC	HTC One E8
124	HTC	HTC One M8
125	HTC	HTC One Mini
126	HTC	HTC One Remix
127	HTC	HTC One X
128	HTC	HTC One X+
129	HTC	HTC Rezound
130	HTC	HTC Snap
131	HTC	HTC Tattoo
132	HTC	HTC Titan 2
133	HTC	HTC Touch Diamond 2 T5353
134	HTC	HTC Touch Diamond2
135	HTC	HTC Touch2
136	HTC	HTC Wildfire
137	HTC	HTC Wildfire A3333
138	HTC	HTC Windows Phone 8X
139	HTC	Incredible
140	HTC	MyTouch 3g
141	HTC	Nexus One
142	HTC	Nexus One
143	HTC	Ozone
144	HTC	PB00 Series
145	HTC	PB65 series
146	HTC	PB76100
147	HTC	PB81 Series
148	HTC	PB92100
149	HTC	PB92110
150	HTC	PB92110 series
151	HTC	PB99 (CDMA)
152	HTC	PB99 Android 2.2 series
153	HTC	PB99400
154	HTC	PC10100
155	HTC	PC10xxx
156	HTC	PC36100
157	HTC	PC36100
158	HTC	PC36XXX
159	HTC	PC40100
160	HTC	PC402XX
161	HTC	PC402XX
162	HTC	PC57 Series
163	HTC	PC63xxx Android 2.2
164	HTC	PC70 series

Item	Brand Name	Model
165	HTC	PC92xxx
166	HTC	PC931XX
167	HTC	PC96 Series
168	HTC	PC991XX
169	HTC	PC992XX
170	HTC	PD051XX
171	HTC	PD06100
172	HTC	PD11 Series
173	HTC	PD112xx
174	HTC	PD15xxx
175	HTC	PD2610000
176	HTC	PD261XX
177	HTC	PD29xxx
178	HTC	PD421XX
179	HTC	PD42XXX
180	HTC	PD67100
181	HTC	PD98xxx(A9192)
182	HTC	PG05XXX
183	HTC	PG061XX
184	HTC	PG06XXX
185	HTC	PG321XX
186	HTC	PG321XX
187	HTC	PG32XXX
188	HTC	PG32XXX
189	HTC	PG41xxx
190	HTC	PG58100
191	HTC	PG59xxx
192	HTC	PG7624000
193	HTC	PG762XX
194	HTC	PG76XXX
195	HTC	PG86xxx
196	HTC	PG88xxx
197	HTC	PH11xxx
198	HTC	PH39xxx
199	HTC	PH44XXX
200	HTC	PH85xxx
201	HTC	PI06XXX
202	HTC	PI391XX
203	HTC	PI39XXX
204	HTC	PI42XXX
205	HTC	PI46xxx
206	HTC	PI86XXX
207	HTC	PJ03XXX
208	HTC	Pure
209	HTC	RHOD100 Series
210	HTC	RHOD50000 Series
211	HTC	SHADOW
212	HTC	Shadow 2009
213	HTC	SMT 5800
214	HTC	Snap
215	HTC	Surround
216	HTC	Tilt 2
217	HTC	Touch Diamond
218	HTC	Touch Dual
219	HTC	Touch HD
220	HTC	Touch Pro
221	HTC	Touch Pro 2
222	HTC	Touch Pro2
223	HTC	TWIN10000 Series
224	HTC	WHIT10000 Series
225	HUAWEI	007HW
226	HUAWEI	C5120
227	HUAWEI	C8150
228	HUAWEI	C8150-1
229	HUAWEI	D51-1
230	HUAWEI	G5510
231	HUAWEI	G6050
232	HUAWEI	G6609
233	HUAWEI	G7300
234	HUAWEI	GM Ultimate Slim/ HUAWEI U8510-1/ U8510-1
235	Huawei	Huawei Ascend Mate 2 4G
236	Huawei	Huawei Ascend P7
237	HUAWEI	HUAWEI C8500
238	HUAWEI	HUAWEI C8600/ HUAWEI M860
239	HUAWEI	HUAWEI C8850
240	HUAWEI	HUAWEI G5500
241	HUAWEI	HUAWEI G6008
242	HUAWEI	HUAWEI G6151
243	HUAWEI	HUAWEI G6605
244	HUAWEI	HUAWEI G6608
245	HUAWEI	HUAWEI G6620
246	HUAWEI	HUAWEI G6626
247	HUAWEI	HUAWEI G7050
248	HUAWEI	HUAWEI G7205
249	HUAWEI	HUAWEI G7210 / PANAMA CU
250	HUAWEI	HUAWEI M615
251	HUAWEI	HUAWEI M635
252	HUAWEI	HUAWEI M835/ M835
253	HUAWEI	HUAWEI M865, M865, HUAWEI M865 MUVE

Item	Brand Name	Model
254	HUAWEI	HUAWEI M886/ M886/ HUAWEI C8860/ C8860
255	HUAWEI	HUAWEI T2251
256	HUAWEI	HUAWEI T2281
257	HUAWEI	HUAWEI T2311
258	HUAWEI	HUAWEI T2361
259	HUAWEI	HUAWEI T5900
260	HUAWEI	HUAWEI T6300
261	HUAWEI	HUAWEI T8300
262	HUAWEI	HUAWEI T8600
263	HUAWEI	HUAWEI U2800
264	HUAWEI	HUAWEI U5200
265	HUAWEI	HUAWEI U5300
266	HUAWEI	HUAWEI U6150
267	HUAWEI	HUAWEI U8160/ U8160/ Vodafone 858 Smart/ Vodafone 858/ VF858
268	HUAWEI	HUAWEI U8160-U/ U8160-U/ Vodafone 858 Smart/ Vodafone 858/ VF858
269	HUAWEI	HUAWEI U8180-1/ U8180-1/ HUAWEI U8180/ U8180/ Stockholm/ T-Mobile Rapport/ Android Edition™ StarShine
270	HUAWEI	HUAWEI U8180-7/ U8180-7
271	HUAWEI	HUAWEI U8300/ U8300
272	HUAWEI	HUAWEI U8350/ U8350/ U8350-1/ Barcelona/ Boulder
273	HUAWEI	HUAWEI U8350-3/ U8350-3
274	HUAWEI	HUAWEI U8350-51/ U8350-51
275	HUAWEI	HUAWEI U8500/ U8500/ HUAWEI U8500-6/ U8500-6
276	HUAWEI	HUAWEI U8520-51/ U8520-51
277	HUAWEI	HUAWEI U8650-1/ U8650-1
278	HUAWEI	HUAWEI U8650NFC-1/ U8650NFC-1
279	HUAWEI	HUAWEI U8652/ U8652/ Huawei U8652/ U8652-51
280	HUAWEI	HUAWEI U8800 Pro/ U8800 Pro
281	HUAWEI	HUAWEI U8800-51/ U8800-51
282	HUAWEI	HUAWEI U8820/ U8820/ Titan
283	HUAWEI	HUAWEI U8850-1
284	HUAWEI	HUAWEI U8860/ U8860/ Honor
285	HUAWEI	MTC 752
286	HUAWEI	PCDM650KT/ HUAWEI M650/ M650/ HUAWEI C8350/ C8350
287	HUAWEI	S31HW/ U8150-92/ HUAWEI U8150-92
288	HUAWEI	S7-105
289	HUAWEI	S7-201c
290	HUAWEI	S7-201u
291	HUAWEI	S7-202c
292	HUAWEI	S7-202u
293	HUAWEI	U2801-34
294	HUAWEI	U5110h-1
295	HUAWEI	U8150-A
296	HUAWEI	U8150-D
297	HUAWEI	U8520/ HUAWEI U8520-1/ HUAWEI U8520/ U8520-1
298	HUAWEI	UM840
299	INQ Mobile	T2-219U/ T2-218U
300	inventec	S42HW
301	inventec	T-101
302	iWOW	Libero
303	JRD Communication (ShenZhen)	one touch 678G
304	KT Tech	EV-S100
305	KT Tech	KM-S120
306	KT Tech	KM-S200
307	KT Tech	KM-S220
308	KT Tech	KM-S220H
309	KT Tech	KM-S300
310	Kyocera	C4700
311	Kyocera	CLIP
312	Kyocera	Glide-M1400
313	Kyocera	ISW11K
314	Kyocera	K50
315	Kyocera	Kyocera Brigadier
316	Kyocera	Kyocera Hydro Life
317	Kyocera	M2000
318	Kyocera	M6000
319	Kyocera	Mobile Phone 16 (E76)
320	Kyocera	S1310
321	Kyocera	S1350
322	Kyocera	S2300
323	Kyocera	S2410
324	Kyocera	SANYO SCP-3810
325	Kyocera	SCP-2700
326	Kyocera	SCP-8600
327	Kyocera	SCP-8600
328	Kyocera	Taho E4100
329	Kyocera	Torino
330	LG	BL20df/ BL20cf
331	LG	BL20v
332	LG	BL40
333	LG	BL40/ BL40g/ BL40f
334	LG	BL40e
335	LG	BL42/ BL42e/ BL42v/ BL42k/ BL42N/ BL20/ BL20e/ BL20v/ BL20k/ BL20N
336	LG	CD02/ VER-01
337	LG	CF360
338	LG	Chocolate Touch
339	LG	CT520
340	LG	Dare VX9700
341	LG	enV3
342	LG	enV3 VX9200
343	LG	eXpo (GW820)
344	LG	GB250

Item	Brand Name	Model
345	LG	GC900
346	LG	GC900/ GC900F
347	LG	GC900e
348	LG	GC970/ GC970h
349	LG	GD 580 Lollipop
350	LG	GD310 Ice Cream 2
351	LG	GD510
352	LG	GD510 Pop
353	LG	GD510N
354	LG	GD550
355	LG	GD550e
356	LG	GD570
357	LG	GD570AW, GD570AV
358	LG	GD880/ GC970
359	LG	GD880f, GD880g
360	LG	GD900
361	LG	GD900/ GD900e
362	LG	Glance
363	LG	GM210
364	LG	GM360i
365	LG	GM600
366	LG	GM730/ GM730f/ GM735/ GM730e
367	LG	GM750
368	LG	GM750h
369	LG	GM750Q
370	LG	GR700
371	LG	GS290
372	LG	GS390
373	LG	GS500
374	LG	GS500f for PCL
375	LG	GS500f, GS500g, GS500k, GS500v
376	LG	GS500gX
377	LG	GS505
378	LG	GT350
379	LG	GT350F
380	LG	GT350i
381	LG	GT360
382	LG	GT370
383	LG	GT400/ GT405
384	LG	GT500/ GT505
385	LG	GT540
386	LG	GT550
387	LG	GT620
388	LG	GT950Q
389	LG	GU230
390	LG	GU280, GU285, GU285f, GU285g
391	LG	GU280f
392	LG	GU282
393	LG	GU285
394	LG	GU290/ GU290f
395	LG	GU290v
396	LG	GU295/ GU292
397	LG	GU295f, GU295g
398	LG	GU297 , GU297a
399	LG	GW300, LG900G
400	LG	GW300FD, GW305
401	LG	GW380/ GW370B/ GW375/ GW382f/ GW380f/ GW380g
402	LG	GW520
403	LG	GW525gX
404	LG	GW550
405	LG	GW550h
406	LG	GW620
407	LG	GW820, GW825, GW825v
408	LG	GX200
409	LG	GX500
410	LG	GX500
411	LG	INCITE
412	LG	IS11LG
413	LG	KC910
414	LG	KC910, KC910Q, KC910Qa, KC910e, KC910i
415	LG	KM553
416	LG	KM555
417	LG	KM555
418	LG	KM555e
419	LG	KM555R
420	LG	KM570
421	LG	KM900
422	LG	KP275
423	LG	KP500
424	LG	KP500N
425	LG	KP501/ KP502/ KP550
426	LG	KP505
427	LG	KS360
428	LG	KS365
429	LG	KT770, KT770f
430	LG	L-01D
431	LG	L-02D, PR-01D
432	LG	L-04C
433	LG	L-07C

Item	Brand Name	Model
434	LG	LG 3G Mobile Phone (GD910)
435	LG	LG 3G Mobile Phone (GT950)
436	LG	LG 3G Mobile Phone (LG- GT540/ GT540f/ GT540g)
437	LG	LG 3G Mobile Phone (LG-A340)
438	LG	LG 3G Mobile Phone (LG-A350 / LG-A355 / LG-A360)
439	LG	LG 3G Mobile phone (LG-C550 / LG-C550f)
440	LG	LG 3G Mobile Phone (LG-C800)
441	LG	LG 3G Mobile Phone (LG-C800G)
442	LG	LG 3G Mobile Phone (LG-E300)
443	LG	LG 3G Mobile Phone (LG-E510 / LG-E510f / LG-E510g)
444	LG	LG 3G Mobile Phone (LG-GB258)
445	LG	LG 3G Mobile Phone (LG-P350)
446	LG	LG 3G Mobile Phone (LG-P690 / LG-P692 / LG-P690f / LG-P690g)
447	LG	LG 3G Mobile Phone (LG-P690b)
448	LG	LG 3G Mobile Phone (LG-P698 / LG-P698f)
449	LG	LG 3G Mobile Phone (LG-P699)
450	LG	LG 3G Mobile Phone(GM730E)
451	LG	LG 3G Mobile Phone(GW820)
452	LG	LG 3G Mobile Phone(KB770, KB775, KB775f)
453	LG	LG 3G Mobile Phone(LG-A353)
454	LG	LG 3G Mobile Phone(LG-KU3800)
455	LG	LG 3G Mobile Phone(LG-T320, LG-T320e, LG-T320g, LG-T320v, LG-T320k, LG-T320gv)
456	LG	LG A340
457	LG	LG CDMA Mobile Phone (LG-CX7100)
458	LG	LG CDMA Mobile Phone (LG-LG5500X for Koodo)
459	LG	LG CDMA Mobile Phone (LG-LS700/ LG-VS700/ LG-US700/ LG-AS700/ LG-CS700/ LG-LG701/ LG-VM701)
460	LG	LG CDMA Mobile Phone (LG-MN180)
461	LG	LG CDMA Mobile Phone (LG-SV850)
462	LG	LG CDMA Mobile Phone (LG-SV850)
463	LG	LG CDMA Mobile Phone (LG-UN200/ LG501C/ AN200/ VM200 / CM200 / BM200/ LW200/ MN200 / CX200B / CX200 /
464	LG	LG CDMA Mobile Phone (LG-VN251/ LG-UN251/ LG-MN251/ LG251)
465	LG	LG CDMA Mobile Phone (LG-VS910)
466	LG	LG CDMA Mobile Phone (VX7100)
467	LG	LG CDMA Mobile Phone (VX8575/ AX8575)
468	LG	LG CDMA Mobile Phone(LG LN510)
469	LG	LG CDMA Mobile Phone(LG- LN510)
470	LG	LG CDMA Mobile Phone(LG220C)
471	LG	LG CDMA Mobile Phone(LG-CX9200)
472	LG	LG CDMA Mobile Phone(LG-CX9600)
473	LG	LG CDMA Mobile Phone(LGL85C)
474	LG	LG CDMA Mobile Phone(LG-LS855/ LG-US855/ LG-AS855/ LG-LG855/ LG-VM855)
475	LG	LG CDMA mobile phone(LG-UX700, LG-AX700, MT700, LW700, LG700, CX700, MV700, MX700, MD700, VM700)
476	LG	LG CDMA Mobile Phone(LG-VN271/ LG-AN271/ LG-UN271)
477	LG	LG CDMA Phone (LG-SU780)
478	LG	LG Escape™
479	LG	LG G Vista
480	LG	LG G3
481	LG	LG G3 S
482	LG	LG G3 Vigor
483	LG	LG GSM Mobile Phone (LG-A290)
484	LG	LG GSM Mobile Phone (LG-C320i)
485	LG	LG GSM Mobile Phone (LG-C330i)
486	LG	LG GSM Mobile Phone (LG-T565/ LG-T575/ LG-T650)
487	LG	LG GSM/ GPRS/ EDGE Mobile Phone (GM360)
488	LG	LG Intuition
489	LG	LG KM900, LG KM900e, LG KM900f, LG KM900g
490	LG	LG- LG265X
491	LG	LG Lucid 2
492	LG	LG Mach
493	LG	LG Optimus G
494	LG	LG Optimus G Pro
495	LG	LG Optimus L90
496	LG	LG Spectrum 2
497	LG	LG TD-SCDMA Mobile Phone (GT910s)
498	LG	LG TD-SCDMA Mobile Phone(LG KT878)
499	LG	LG Tribute
500	LG	LG WCDMA Mobile Phone (LG-SU550)
501	LG	LG WCDMA Mobile Phone (LG-SU920, LG-KU9200)
502	LG	LG WCDMA Mobile Phone(LG-SU130)
503	LG	LG WCDMA Mobile Phone(LG-SU630)
504	LG	LG WCDMA Mobile Phone(LG-SU900/ LG-KU9000/ LG-LU9000)
505	LG	LG Xpression 2
506	LG	LG Xpression™
507	LG	LG230(CX230), LG231(CX231), LG231C(CX231C)
508	LG	LG370
509	LG	LG-3G Mobile phone (LG-C555)
510	LG	LG430G
511	LG	LG670
512	LG	LG700V, CX700V
513	LG	LG-A200
514	LG	LG-A230/ LG-A235/ LG-A225
515	LG	LG-A250 / LG-A255
516	LG	LG-A258
517	LG	LG-A310/ LG-A310f/ LG-A310k/ LG-A315/ LG-A315v
518	LG	LG-AS680
519	LG	LG-AX265
520	LG	LG-AX265 [Not Approved by SIG]
521	LG	LG-AX8370
522	LG	LG-AX840

Item	Brand Name	Model
523	LG	LG-C320
524	LG	LG-C330
525	LG	LG-C375/ LG-C370/ LG-C365/ LG-C360
526	LG	LG-C395
527	LG	LG-C510/ C510
528	LG	LG-C570f
529	LG	LG-C570g
530	LG	LG-C660/ LG-C660h/ LG-C660R
531	LG	LG-C710h/ LG-C710
532	LG	LG-C729
533	LG	LG-C900
534	LG	LG-C900N, LG-C900k, LG-C900B
535	LG	LG-CX5500X
536	LG	LG-CX670/ LGCX670
537	LG	LG-E500
538	LG	LG-E720, LG-E720b, LG-E720k
539	LG	LG-E730
540	LG	LG-E730f
541	LG	LG-E739
542	LG	LG-E900, LG-E900h
543	LG	LG-E906
544	LG	LG-F100S/ LG-F100L
545	LG	LG-GB250
546	LG	LG-GD970
547	LG	LG-GM310/ LG-GM310f/ LG-GM310g
548	LG	LG-GW370
549	LG	LG-GW520/ LG-GW525/ GW525f/ GW525g
550	LG	LG-GW610
551	LG	LG-GW820, LG-GW825
552	LG	LG-JN240
553	LG	LG-JS750, LG-JS750g
554	LG	LG-KH3400
555	LG	LG-KH3400
556	LG	LG-KH3900
557	LG	LG-KH8000
558	LG	LG-KS720
559	LG	LG-KU2100, LG-SU210, LG-LU2100
560	LG	LG-KU2200
561	LG	LG-KU2800
562	LG	LG-KU5900
563	LG	LG-KU9300
564	LG	LG-KV700 (Lollipop2)
565	LG	LG-KV700T
566	LG	LG-KW730
567	LG	LGL45C
568	LG	LGL55C
569	LG	LG-L95G
570	LG	LG-LB4400
571	LG	LG-LG265T
572	LG	LG-LG8575/ LG-MX8575
573	LG	LG-LN272 / LG272 / LG272c
574	LG	LG-LS685
575	LG	LG-LS696
576	LG	LG-LS831/ LG-T130L/ LG-US831/ LG-AS831
577	LG	LG-LS840
578	LG	LG-LU2700
579	LG	LG-LU3000
580	LG	LG-LU4500
581	LG	LG-LU6500
582	LG	LG-LU6800
583	LG	LG-LU9400
584	LG	LG-LU9400W
585	LG	LG-LX295/ LG-LX290
586	LG	LG-MS695
587	LG	LG-MS840
588	LG	LG-MS910
589	LG	LG-MT375
590	LG	LG-P500/ LG-P509/ LG-P509TN
591	LG	LG-P500/ LG-P509TN/ LG-P509BK/ LG-P509MZ/ LG-P500h/ LG-P503/ LG-P505/ LG-P504/
592	LG	LG-P500h
593	LG	LG-P501
594	LG	LG-P503
595	LG	LG-P504
596	LG	LG-P505
597	LG	LG-P505R/ LG-P505CH
598	LG	LG-P506
599	LG	LG-P920/ LG-P925/ LG-P929
600	LG	LG-P925g, LG-P920h
601	LG	LG-P930
602	LG	LG-P935
603	LG	LG-P940, LG-SU540, LG-KU5400, LG-LU5400, L-02D
604	LG	LG-P970
605	LG	LG-P970G
606	LG	LG-P970h
607	LG	LG-P990
608	LG	LG-P990h
609	LG	LG-P999
610	LG	LG-P999DW
611	LG	LG-S365/ LG-S360
612	LG	LG-S367
613	LG	LG-SB210

Item	Brand Name	Model
614	LG	LG-SB260
615	LG	LG-SH560/ LG-KH5800
616	LG	LG-SH840, LG-KH8400
617	LG	LG-SU310, LG-LU3100
618	LG	LG-SU370/ LG-KU3700/ LG-LU3700
619	LG	LG-SU410
620	LG	LG-SU420/ LG-KU4200
621	LG	LG-SU430/ LG-KU4300/ LG-LU4300
622	LG	LG-SU540/ LG-KU5400/ LG-LU5400
623	LG	LG-SU640/ LG-LU6200
624	LG	LG-SU660
625	LG	LG-SU760
626	LG	LG-SU880
627	LG	LG-SU910/ LG-KU9100/ LG-LU9100
628	LG	LG-SU950/ KU9500
629	LG	LG-SU960, LG-KU9600
630	LG	LG-SV400
631	LG	LG-SV770
632	LG	LG-T325 , LG-T325f, LG-T325g
633	LG	LG-T500/ LG-T505/ LG-T507/ LG-T510/ LG-T515/ LG-T520/ LG-T530
634	LG	LG-T565b
635	LG	LG-UN150/ LG-VN150/ LG221C/ LG235C/ LG-MN150/ LW150/ LG-VP150/ LG150
636	LG	LG-UN270
637	LG	LG-UN430
638	LG	LG-UN431/ AN431/ LG431
639	LG	LG-US760
640	LG	LG-UX310, AX310, MT310(MetroPCS), LP310, LW310(LeapWireless(Cricket)), G310, CX310, MV310, MX310, MD310
641	LG	LG-V150
642	LG	LGVN270/ LN270/ UN270/ LG270/ LG270C/ LW270/ CX270/ MN270/ TN270/ AN270/ VM270
643	LG	LG-VN530
644	LG	LG-VS660/ LS670/ US670/ LG670C/ MS690/ LW690/ VM670/ AS670
645	LG	LG-VS740/ US740/ MS740/ AS740
646	LG	LG-VS750
647	LG	LG-VS760
648	LG	LG-VS761
649	LG	LG-VS840
650	LG	LG-VS920
651	LG	LG-VX11000
652	LG	LG-VX8576
653	LG	LG-VX9200
654	LG	LN240/ MN240/ LW240/ UN240/ AN240/ VN240/ CX240
655	LG	Lotus LX600
656	LG	LU2300
657	LG	LW375
658	LG	LX290
659	LG	LX370
660	LG	LX610/ UX610/ CX610/ LG610/ VM610/ AX610/ UN610/ CN610/ VN610/ AN610
661	LG	MT375
662	LG	Neon (TM) GT365
663	LG	New LG 3G Mobile Phone(GD710)
664	LG	New LG CDMA Mobile Phone(LG-LG290C)
665	LG	Rumor 2
666	LG	Scoop / AX-260
667	LG	Shine 2
668	LG	Shine II GD710 AT&T
669	LG	Shine KE970
670	LG	UX220
671	LG	UX370
672	LG	VER-01
673	LG	Versa
674	LG	VN250
675	LG	Vortex
676	LG	Voyager VX10000
677	LG	VX5500
678	LG	VX5600
679	LG	VX8360
680	LG	VX8370
681	LG	VX8610
682	LG	X350
683	LG	Xenon (TM) GR500
684	LG	LX400
685	MediaTek	Mediatek Bluetooth® Host SW 4.0 + HS
686	MediaTek	MediaTek BlueZ (2.1+EDR)
687	MediaTek	Mediatek WM6.5 (EDR2.0)
688	MediaTek	Phone
689	Microsoft	Windows Phone 7
690	Moto	Backflip ME600
691	Moto	EM35
692	Moto	Z9N
693	Motorola	A3300c
694	Motorola	A853
695	Motorola	A855
696	Motorola	A955
697	Motorola	Amphora-i897
698	Motorola	Athens-i9 R2
699	Motorola	Backflip MB300
700	Motorola	Banfi-i856
701	Motorola	Bei Hai TD
702	Motorola	Blackstone-R2
703	Motorola	Brightwater
704	Motorola	Castle

Item	Brand Name	Model
705	Motorola	Cliq
706	Motorola	Cliq MB200
707	Motorola	Clutch (i465)
708	Motorola	Cordova
709	Motorola	Creekside-i886
710	Motorola	CRUSH
711	Motorola	Droid
712	Motorola	Droid 2
713	Motorola	Droid Pro
714	Motorola	Droid X
715	Motorola	E1
716	Motorola	E1070
717	Motorola	E398
718	Motorola	E8
719	Motorola	EM30
720	Motorola	EWP3100
721	Motorola	Fairbanks
722	Motorola	Finch
723	Motorola	FR6070, FR6076
724	Motorola	FR6874
725	Motorola	Halo
726	Motorola	Heartland
727	Motorola	i296-Gallo
728	Motorola	i365
729	Motorola	i410(Nevadacity)
730	Motorola	i576
731	Motorola	i686-Brightwater-2
732	Motorola	i776
733	Motorola	i786w (Mantra)
734	Motorola	I9
735	Motorola	K3
736	Motorola	Karma QA1
737	Motorola	MB200 refresh
738	Motorola	MB300 Backflip refresh
739	Motorola	MB501 refresh
740	Motorola	MB502
741	Motorola	MB508
742	Motorola	MB511
743	Motorola	MB520
744	Motorola	MB525
745	Motorola	MB810
746	Motorola	ME811
747	Motorola	Milestone XT720
748	Motorola	MOTO (TM) Z9
749	Motorola	Moto A3000
750	Motorola	Motorola Atrix 2
751	Motorola	Motorola Atrix HD
752	Motorola	Motorola Droid 4
753	Motorola	Motorola Droid Razr
754	Motorola	Motorola Droid Razr HD
755	Motorola	Motorola Droid Razr Maxx HD
756	Motorola	Motorola Moto G
757	Motorola	Motorola Moto G (4G LTE)
758	Motorola	Motorola Moto X
759	Motorola	Motorola Moto X
760	Motorola	Motosurf A3000
761	Motorola	Motosurf A3100
762	Motorola	MT716
763	Motorola	Muscardini
764	Motorola	Oaknoll
765	Motorola	Q11
766	Motorola	Q9H
767	Motorola	Quailhurst iDEN-i786
768	Motorola	RAZR V3
769	Motorola	RAZR V3xx Pink
770	Motorola	RAZR2 V9
771	Motorola	Rival
772	Motorola	RIVAL (TELUS)
773	Motorola	Rush
774	Motorola	SLVR L72
775	Motorola	U9
776	Motorola	V1100
777	Motorola	V360
778	Motorola	V365
779	Motorola	V3i
780	Motorola	V3x
781	Motorola	V500
782	Motorola	V550
783	Motorola	V551
784	Motorola	V6
785	Motorola	V750
786	Motorola	V80
787	Motorola	V860
788	Motorola	V9
789	Motorola	V950
790	Motorola	V9x
791	Motorola	VE20
792	Motorola	VE440
793	Motorola	VE66
794	Motorola	VoWLAN Single Mode Smartphone

Item	Brand Name	Model
795	Motorola	VU30
796	Motorola	W418G
797	Motorola	W510
798	Motorola	W755
799	Motorola	W766
800	Motorola	W766
801	Motorola	WX345
802	Motorola	WX404
803	Motorola	XT502
804	Motorola	XT610
805	Motorola	XT701
806	Motorola	XT701 Milestone
807	Motorola	XT702
808	Motorola	XT711
809	Motorola	XT720
810	Motorola	XT800
811	Motorola	XT800+
812	Motorola	XT800c
813	Motorola	XT800W
814	Motorola	XT806
815	Motorola	Z3
816	Motorola	Z6w
817	Motorola	ZN300
818	Motorola	ZN4
819	Motorola	ZN5
820	Motorola	A953
821	Motorola	A955
822	Motorola	A956
823	Motorola	A956
824	Motorola	A957
825	Motorola	Birdstone i475,
826	Motorola	Brea
827	Motorola	BRIDGEVIEW iDEN
828	Motorola	DominoV
829	Motorola	EX108
830	Motorola	EX109
831	Motorola	EX118
832	Motorola	EX130
833	Motorola	EX132
834	Motorola	EX139
835	Motorola	EX212
836	Motorola	EX223
837	Motorola	EX232
838	Motorola	Fawnridge i940
839	Motorola	GSM mobile phone
840	Motorola	Hallcrest (WX 430)
841	Motorola	i475 (Birdstone)
842	Motorola	Jorian-xt605
843	Motorola	MB508
844	Motorola	MB520
845	Motorola	MB525
846	Motorola	MB611
847	Motorola	MB612
848	Motorola	MB810
849	Motorola	MB810 UR
850	Motorola	MB861
851	Motorola	MB870
852	Motorola	ME860
853	Motorola	MOSAIC-i440
854	Motorola	MT620
855	Motorola	MT810LX
856	Motorola	MT870
857	Motorola	Style
858	Motorola	Titanium
859	Motorola	W409G
860	Motorola	WX292
861	Motorola	WX294
862	Motorola	WX346
863	Motorola	WX445
864	Motorola	XT300
865	Motorola	XT301
866	Motorola	XT311
867	Motorola	XT311
868	Motorola	XT317
869	Motorola	XT530
870	Motorola	XT531
871	Motorola	XT532
872	Motorola	XT610
873	Motorola	XT610
874	Motorola	XT615
875	Motorola	XT860
876	Motorola	XT862
877	Motorola	XT865
878	Motorola	XT875
879	Motorola	XT882
880	NEC CASIO	C781
881	NEC CASIO	CA-01C
882	NEC CASIO	G'zOne
883	NEC CASIO	G'zOne
884	NEC CASIO	IS11CA
885	NEC CASIO	KMP7N4AB-1A

Item	Brand Name	Model
886	NEC CASIO	N-02D
887	NEC CASIO	N-04C
888	NEC CASIO	N-05C
889	NEC CASIO	N-06C
890	NEC CASIO	KMP7N4Y1-2A
891	Nokia	200
892	Nokia	201
893	Nokia	300
894	Nokia	303
895	Nokia	2000
896	Nokia	2010
897	Nokia	2605
898	Nokia	2705
899	Nokia	2705
900	Nokia	2730
901	Nokia	2760
902	Nokia	3000
903	Nokia	3030
904	Nokia	3555
905	Nokia	3711
906	Nokia	5220
907	Nokia	5230
908	Nokia	5310
909	Nokia	5320
910	Nokia	5530
911	Nokia	5610
912	Nokia	5800
913	Nokia	6085
914	Nokia	6086
915	Nokia	6103
916	Nokia	6133
917	Nokia	6205
918	Nokia	6263
919	Nokia	6301
920	Nokia	6350
921	Nokia	6555
922	Nokia	6600
923	Nokia	6650
924	Nokia	6700
925	Nokia	6730
926	Nokia	6788
927	Nokia	7205
928	Nokia	7310
929	Nokia	7510
930	Nokia	7705
931	Nokia	7705
932	Nokia	8800
933	Nokia	2332c
934	Nokia	2600C
935	Nokia	2680s
936	Nokia	2720 Fold
937	Nokia	2730 Classic
938	Nokia	3710 fold
939	Nokia	5130 XpressMusic
940	Nokia	5230 Nuron
941	Nokia	5330TV
942	Nokia	5630Xpress
943	Nokia	6220c
944	Nokia	6303C
945	Nokia	6500 Slide
946	Nokia	6600i Slide
947	Nokia	6700 Clasic
948	Nokia	6700 slide
949	Nokia	6788i
950	Nokia	702T
951	Nokia	7100 Supernova
952	Nokia	7210 Supernova
953	Nokia	7610s
954	Nokia	C1-03
955	Nokia	C2-00
956	Nokia	C2-02
957	Nokia	C2-02.1
958	Nokia	C2-03
959	Nokia	C2-05
960	Nokia	C2-05.1
961	Nokia	C2-06
962	Nokia	C2-07
963	Nokia	C2-08
964	Nokia	C3-00.2
965	Nokia	C3-01.5
966	Nokia	C5-00
967	Nokia	C5-00.03
968	Nokia	C5-00.2
969	Nokia	C5-01
970	Nokia	C5-04.1
971	Nokia	C5-05
972	Nokia	C5-06
973	Nokia	E52
974	Nokia	E63
975	Nokia	E66
976	Nokia	E71

Item	Brand Name	Model
977	Nokia	E71x
978	Nokia	E75
979	Nokia	E90
980	Nokia	Mural (6750)
981	Nokia	N73
982	Nokia	N78
983	Nokia	N79
984	Nokia	N8
985	Nokia	N85
986	Nokia	N86
987	Nokia	N9
988	Nokia	N96
989	Nokia	N97
990	Nokia	N97 Mini
991	Nokia	Nokia 1006
992	Nokia	Nokia 2705
993	Nokia	Nokia 3208c
994	Nokia	Nokia 3720c-2
995	Nokia	Nokia 500
996	Nokia	Nokia 5132
997	Nokia	Nokia 5611
998	Nokia	Nokia 5730s-1
999	Nokia	Nokia 600
1000	Nokia	Nokia 603
1001	Nokia	Nokia 6303c
1002	Nokia	Nokia 6316s, 6316s-1
1003	Nokia	Nokia 6350-1b
1004	Nokia	Nokia 6350-1d
1005	Nokia	Nokia 6600i-1c
1006	Nokia	Nokia 6700c
1007	Nokia	Nokia 6700c-1
1008	Nokia	Nokia 6750-1b
1009	Nokia	Nokia 6750-1c
1010	Nokia	Nokia 6760s-1
1011	Nokia	Nokia 6790s-1b
1012	Nokia	Nokia 6790s-1c
1013	Nokia	Nokia 700
1014	Nokia	Nokia 701
1015	Nokia	Nokia 7205
1016	Nokia	Nokia 7208
1017	Nokia	Nokia 7208
1018	Nokia	Nokia 7505 CDMA Mobile Phone
1019	Nokia	Nokia 7705
1020	Nokia	Nokia 801T
1021	Nokia	Nokia 8208
1022	Nokia	Nokia C7-00.1
1023	Nokia	Nokia C7-00s
1024	Nokia	Nokia E6-00
1025	Nokia	Nokia E71x
1026	Nokia	Nokia E75-1
1027	Nokia	Nokia E75-2
1028	Nokia	Nokia Lumia 1020
1029	Nokia	Nokia Lumia 1020
1030	Nokia	Nokia Lumia 521
1031	Nokia	Nokia Lumia 530
1032	Nokia	Nokia Lumia 630
1033	Nokia	Nokia Lumia 635
1034	Nokia	Nokia Lumia 800
1035	Nokia	Nokia Lumia 810
1036	Nokia	Nokia Lumia 820
1037	Nokia	Nokia Lumia 822
1038	Nokia	Nokia Lumia 900
1039	Nokia	Nokia Lumia 920
1040	Nokia	Nokia Lumia 928
1041	Nokia	Nokia XL
1042	Nokia	Surge (TM) 6790
1043	Nokia	T7-00
1044	Nokia	Vertu ASCENT X
1045	Nokia	Vertu Constellation F
1046	Nokia	Vertu CONSTELLATION T
1047	Nokia	Vertu Signature SC
1048	Nokia	X2-02
1049	Nokia	X2-03
1050	Nokia	X2-05
1051	Nokia	X3
1052	Nokia	X3-01
1053	Nokia	X3-02.5
1054	Nokia	X3-02i
1055	Nokia	X5-00
1056	Nokia	X6
1057	Nokia	X6
1058	Nokia	X7
1059	Nokia	Z730C
1060	Palm	Centro
1061	Palm	P100EWW
1062	Palm	P100UNA/ P100UEU
1063	Palm	P101EWW
1064	Palm	P101UNA, P101UEU
1065	Palm	P120EWW

Item	Brand Name	Model
1066	Palm	P121EWW
1067	Palm	P121UNA, P121UEU
1068	Palm	Pixi
1069	Palm	Pixi Plus CDMA
1070	Palm	Pre
1071	Palm	Pre Plus CDMA
1072	Palm	Treo 680
1073	Palm	Treo 800w
1074	Palm	Treo Pro
1075	Palm	Treo Pro, T850EWW
1076	Panasonic	003P
1077	Panasonic	101P
1078	Panasonic	EB-3236
1079	Panasonic	EB-4054
1080	Panasonic	EB-4057
1081	Panasonic	KX-TU311
1082	Panasonic	P-01D
1083	Panasonic	P-02D
1084	Panasonic	P-07C
1085	Pantech	ADR8995
1086	Pantech	CDM8992
1087	Pantech	CDM8992
1088	Pantech	CDM8999**
1089	Pantech	CDMA PTI06 (IS06)
1090	Pantech	CDMA EIS01PT(EIS01PT)
1091	Pantech	CDMA PT111(PT111)
1092	Pantech	IM-A600S
1093	Pantech	IM-A630K (SP33K)
1094	Pantech	IM-A630K (SP33K)
1095	Pantech	IM-A650S
1096	Pantech	IM-A690L
1097	Pantech	IM-A690L
1098	Pantech	IM-A690S
1099	Pantech	IM-A690S
1100	Pantech	IM-A710K
1101	Pantech	IM-A710K
1102	Pantech	IM-A720L
1103	Pantech	IM-A720L
1104	Pantech	IM-A725L
1105	Pantech	IM-A730S
1106	Pantech	IM-A730S
1107	Pantech	IM-A740S
1108	Pantech	IM-A750K
1109	Pantech	IM-A760S
1110	Pantech	IM-A770K
1111	Pantech	IM-A775C
1112	Pantech	IM-A780L
1113	Pantech	IM-A800S
1114	Pantech	IM-A810K
1115	Pantech	IM-A810S
1116	Pantech	IM-T100K
1117	Pantech	Matrix Pro (TM)
1118	Pantech	MD Cube
1119	Pantech	P2000
1120	Pantech	P2020
1121	Pantech	P2030
1122	Pantech	P5000
1123	Pantech	P6010
1124	Pantech	P6020
1125	Pantech	P7000
1126	Pantech	P7040
1127	Pantech	P8000
1128	Pantech	P8000
1129	Pantech	P9020
1130	Pantech	P9050
1131	Pantech	Pantech Breeze III™
1132	Pantech	Pantech Burst™
1133	Pantech	Pantech Discover
1134	Pantech	Pantech Discover™
1135	Pantech	Pantech Flex
1136	Pantech	Pantech P9070
1137	Pantech	Pantech Pocket™
1138	Pantech	Pantech Renue™
1139	Pantech	Pantech Swift™
1140	Pantech	Pantech Vybe
1141	Pantech	PantechP7050
1142	Pantech	PantechP9060
1143	Pantech	PIVOT **
1144	Pantech	PIVOT/ TXT8030##
1145	Pantech	Show(TXT8040, VZW-1026)
1146	Pantech	TXT8035PP
1147	Pantech	TXT8040##
1148	Pantech	TXT8045US
1149	Pantech	TXT8045VW
1150	Pantech	WP8990
1151	PCD	Razzle TXT8060
1152	Pharos	PTL117
1153	Pharos	PTL127
1154	RIM	BlackBerry 8120
1155	RIM	Blackberry 8220

Item	Brand Name	Model
1156	RIM	Blackberry 8350i
1157	RIM	Blackberry 8530
1158	Rim	Blackberry 8820
1159	RIM	Blackberry 9300
1160	RIM	Blackberry 9500
1161	RIM	Blackberry 9530
1162	RIM	Blackberry 9630
1163	RIM	Blackberry 9700
1164	Rim	Blackberry Bold 9000
1165	RIM	BlackBerry Curve (8520)
1166	RIM	Blackberry Curve 3G 9300
1167	RIM	Blackberry Curve 3G 9330
1168	Rim	Blackberry Curve 8310
1169	Rim	Blackberry Curve 8320
1170	Rim	Blackberry Curve 8900
1171	Rim	Blackberry Pearl 8100
1172	Rim	Blackberry Pearl 8110
1173	RIM	Blackberry Storm 2
1174	RIM	BlackBerry Storm 9550 (Storm 2)
1175	RIM	BlackBerry Style (9670)
1176	RIM	BlackBerry Torch (9800)
1177	RIM	BlackBerry Z10
1178	RIM	BlackBerry® Bold™ 9790
1179	RIM	BlackBerry® Bold™ 9900
1180	RIM	BlackBerry® Bold™ 9900 Smartphone
1181	RIM	BlackBerry® Bold™ 9930 Smartphone
1182	RIM	BlackBerry® Curve™ 8980
1183	RIM	BlackBerry® Curve™ 9350 Smartphone
1184	RIM	BlackBerry® Curve™ 9360
1185	RIM	BlackBerry® Curve™ 9360 Smartphone
1186	RIM	BlackBerry® Curve™ 9370
1187	RIM	BlackBerry® Curve™ 9380
1188	RIM	BlackBerry® Torch™ 9810
1189	RIM	BlackBerry® Torch™ 9810 Smartphone
1190	RIM	BlackBerry® Torch™ 9850 Smartphone
1191	RIM	BlackBerry® Torch™ 9860 Smartphone
1192	RIM	BlackBerryR 8530 Smartphone
1193	RIM	BlackBerryR 8910 Curve? Smartphone
1194	RIM	BlackBerryR Bold? 9000
1195	RIM	BlackBerryR Bold? 9650 Smartphone
1196	RIM	BlackBerryR Bold? 9650 Smartphone
1197	RIM	BlackBerryR Bold? 9700
1198	RIM	BlackBerryR Bold? 9780 smartphone
1199	RIM	BlackBerryR Curve? 8330
1200	RIM	BlackBerryR Curve? 8350i
1201	RIM	BlackBerryR Curve? 8520 Smartphone
1202	RIM	BlackBerryR Curve? 8900
1203	RIM	BlackBerryR Curve? 9300
1204	RIM	BlackBerryR Curve? 9330 Smartphone
1205	RIM	BlackBerryR Pearl? 8230
1206	RIM	BlackBerryR Pearl? 9100 Smartphone
1207	RIM	BlackBerryR Pearl? 9105 Smartphone
1208	RIM	BlackBerryR Storm? 9500
1209	RIM	BlackBerryR Storm? 9530
1210	RIM	BlackBerryR Storm2? 9520
1211	RIM	BlackBerryR Storm2? 9550
1212	RIM	BlackBerryR Style? 9670 Smartphone
1213	RIM	BlackBerryR Torch? 9800
1214	RIM	BlackBerryR Tour? 9630 Smartphone
1215	RIM	RDL61TC
1216	Samsung	A237
1217	Samsung	a727
1218	Samsung	A737
1219	Samsung	a747
1220	Samsung	A767 Propel
1221	Samsung	A777
1222	Samsung	A827
1223	Samsung	Alias 2 U750
1224	Samsung	B2100
1225	Samsung	B7300
1226	Samsung	Behold 2 (T939)
1227	Samsung	Behold T919
1228	Samsung	BlackJack (TM) II (i617)
1229	Samsung	C3050
1230	Samsung	C3050
1231	Samsung	C3050
1232	Samsung	C3110
1233	Samsung	C3110H
1234	Samsung	C5130
1235	Samsung	C5212
1236	Samsung	C5510
1237	Samsung	C6625
1238	Samsung	Captivate (I897)
1239	Samsung	CDMA SCH1
1240	Samsung	Continuum (I400)
1241	Samsung	D780
1242	Samsung	D880
1243	Samsung	D900i
1244	Samsung	D988
1245	Samsung	E3010

Item	Brand Name	Model
1246	Samsung	E390
1247	Samsung	Epic 4G (D700)
1248	Samsung	Eternity A867
1249	Samsung	F110
1250	Samsung	F330
1251	Samsung	F480
1252	Samsung	F490
1253	Samsung	Fascinate (I500)
1254	Samsung	Flight
1255	Samsung	Galaxy Spica GT-I5700
1256	Samsung	Gravity 2 (T469)
1257	Samsung	Gravity T459
1258	Samsung	GT- S8500
1259	Samsung	GT-B2710
1260	Samsung	GT-B2710D
1261	Samsung	GT-B3210
1262	Samsung	GT-B3310
1263	Samsung	GT-B3310i
1264	Samsung	GT-B3313i
1265	Samsung	GT-B3410
1266	Samsung	GT-B3410R
1267	Samsung	GT-B3410W
1268	Samsung	GT-B5210U
1269	Samsung	GT-B5310
1270	Samsung	GT-B5310B
1271	Samsung	GT-B5310L
1272	Samsung	GT-B5310R
1273	Samsung	GT-B5310U
1274	Samsung	GT-B5510
1275	Samsung	GT-B5510B
1276	Samsung	GT-B5510L
1277	Samsung	GT-B5512
1278	Samsung	GT-B5512B
1279	Samsung	GT-B6520
1280	Samsung	GT-B6520L
1281	Samsung	GT-B7300
1282	Samsung	GT-B7300B
1283	Samsung	GT-B7300C
1284	Samsung	GT-B7320
1285	Samsung	GT-B7320L
1286	Samsung	GT-B7330
1287	Samsung	GT-B7330B
1288	Samsung	GT-B7330D
1289	Samsung	GT-B7330R
1290	Samsung	GT-B7350
1291	Samsung	GT-B7350T
1292	Samsung	GT-B7510
1293	Samsung	GT-B7510B
1294	Samsung	GT-B7510L
1295	Samsung	GT-B7610
1296	Samsung	GT-B7620
1297	Samsung	GT-B7620U
1298	Samsung	GT-C3010
1299	Samsung	GT-C3011
1300	Samsung	GT-C3013
1301	Samsung	GT-C3050
1302	Samsung	GT-C3050C
1303	Samsung	GT-C3053
1304	Samsung	GT-C3060
1305	Samsung	GT-C3200
1306	Samsung	GT-C3222W
1307	Samsung	GT-C3300
1308	Samsung	GT-C3300D
1309	Samsung	GT-C3300i
1310	Samsung	GT-C3300K
1311	Samsung	GT-C3303K
1312	Samsung	GT-C3310
1313	Samsung	GT-C3312
1314	Samsung	GT-C3322
1315	Samsung	GT-C3330
1316	Samsung	GT-C3332
1317	Samsung	GT-C3350
1318	Samsung	GT-C3500
1319	Samsung	GT-C3503
1320	Samsung	GT-C3510
1321	Samsung	GT-C3510T
1322	Samsung	GT-C3518
1323	Samsung	GT-C3520
1324	Samsung	GT-C3530
1325	Samsung	GT-C3560
1326	Samsung	GT-C3750
1327	Samsung	GT-C3752
1328	Samsung	GT-C5180
1329	Samsung	GT-C5510
1330	Samsung	GT-C5510H
1331	Samsung	GT-C5510U
1332	Samsung	GT-C6712
1333	Samsung	GT-E1232B
1334	Samsung	GT-E2152i
1335	Samsung	GT-E2220
1336	Samsung	GT-E2222

Item	Brand Name	Model
1337	Samsung	GT-E2222L
1338	Samsung	GT-E2230
1339	Samsung	GT-E2230L
1340	Samsung	GT-E2232
1341	Samsung	GT-E2330B
1342	Samsung	GT-E2530
1343	Samsung	GT-E2600
1344	Samsung	GT-E2652
1345	Samsung	GT-E2652W
1346	Samsung	GT-E3210
1347	Samsung	GT-E3210B
1348	Samsung	GT-E3210L
1349	Samsung	GT-E3210O
1350	Samsung	GT-E3213K
1351	Samsung	GT-E3217B
1352	Samsung	GT-I5500
1353	Samsung	GT-I5500M
1354	Samsung	GT-I5503T
1355	Samsung	GT-I5508
1356	Samsung	GT-I5510
1357	Samsung	GT-I5510 (GB)
1358	Samsung	GT-I5510B
1359	Samsung	GT-I5510L
1360	Samsung	GT-I5510M
1361	Samsung	GT-I5510T
1362	Samsung	GT-I5700
1363	Samsung	GT-I5700
1364	Samsung	GT-I5700L
1365	Samsung	GT-I5700U
1366	Samsung	GT-I5800
1367	Samsung	GT-I5801
1368	Samsung	GT-I6220
1369	Samsung	GT-I6230
1370	Samsung	GT-I6410
1371	Samsung	GT-I6500U
1372	Samsung	GT-I6500U
1373	Samsung	GT-I6712
1374	Samsung	GT-I7410
1375	Samsung	GT-I7500U
1376	Samsung	GT-I7680
1377	Samsung	GT-I8000H
1378	Samsung	GT-I8000L
1379	Samsung	GT-I8000T
1380	Samsung	GT-I8150
1381	Samsung	GT-I8150B
1382	Samsung	GT-I8150T
1383	Samsung	GT-I8180C
1384	Samsung	GT-I8320
1385	Samsung	GT-I8330
1386	Samsung	GT-I8350
1387	Samsung	GT-I8350T
1388	Samsung	GT-I8520
1389	Samsung	GT-I8910L
1390	Samsung	GT-I8910U
1391	Samsung	GT-I9000
1392	Samsung	GT-I9000
1393	Samsung	GT-I9000B
1394	Samsung	GT-I9000L
1395	Samsung	GT-I9000M
1396	Samsung	GT-I9000M
1397	Samsung	GT-I9000T
1398	Samsung	GT-I9001
1399	Samsung	GT-I9003
1400	Samsung	GT-I9003
1401	Samsung	GT-I9003
1402	Samsung	GT-I9003L
1403	Samsung	GT-I9003L
1404	Samsung	GT-I9008
1405	Samsung	GT-I9008L
1406	Samsung	GT-I9008L
1407	Samsung	GT-I9010
1408	Samsung	GT-I9018
1409	Samsung	GT-I9020
1410	Samsung	GT-I9020
1411	Samsung	GT-I9020A
1412	Samsung	GT-I9020A
1413	Samsung	GT-I9020T
1414	Samsung	GT-I9020T
1415	Samsung	GT-I9023
1416	Samsung	GT-I9023
1417	Samsung	GT-I9070
1418	Samsung	GT-I9088
1419	Samsung	GT-I9100
1420	Samsung	GT-I9100
1421	Samsung	GT-I9100G
1422	Samsung	GT-I9100M
1423	Samsung	GT-I9100M
1424	Samsung	GT-I9100P
1425	Samsung	GT-I9100T
1426	Samsung	GT-I9100T
1427	Samsung	GT-I9103

Item	Brand Name	Model
1428	Samsung	GT-I9108
1429	Samsung	GT-I9188
1430	Samsung	GT-I9210
1431	Samsung	GT-I9220
1432	Samsung	GT-I9228
1433	Samsung	GT-I9250
1434	Samsung	GT-I9250M
1435	Samsung	GT-I9250T
1436	Samsung	GT-I9250W
1437	Samsung	GT-M2510C
1438	Samsung	GT-M2513
1439	Samsung	GT-M2520
1440	Samsung	GT-M3710
1441	Samsung	GT-M7500C
1442	Samsung	GT-M7600B
1443	Samsung	GT-M7600H
1444	Samsung	GT-M7600L
1445	Samsung	GT-M7603
1446	Samsung	GT-M8910
1447	Samsung	GT-M8910B
1448	Samsung	GT-M8910U
1449	Samsung	GT-N7000
1450	Samsung	GT-N7000
1451	Samsung	GT-P1000
1452	Samsung	GT-P1000L
1453	Samsung	GT-P1000N
1454	Samsung	GT-P1000T
1455	Samsung	GT-P6200L
1456	Samsung	GT-P6201
1457	Samsung	GT-S3100
1458	Samsung	GT-S3310i
1459	Samsung	GT-S3350
1460	Samsung	GT-S3353
1461	Samsung	GT-S3370
1462	Samsung	GT-S3370B
1463	Samsung	GT-S3370C
1464	Samsung	GT-S3370E
1465	Samsung	GT-S3370L
1466	Samsung	GT-S3500i
1467	Samsung	GT-S3501C
1468	Samsung	GT-S3550
1469	Samsung	GT-S3600i
1470	Samsung	GT-S3601C
1471	Samsung	GT-S3650
1472	Samsung	GT-S3650C
1473	Samsung	GT-S3650W
1474	Samsung	GT-S3653
1475	Samsung	GT-S3653W
1476	Samsung	GT-S3770
1477	Samsung	GT-S3770B
1478	Samsung	GT-S3770K
1479	Samsung	GT-S3770L
1480	Samsung	GT-S3770M
1481	Samsung	GT-S3770Y
1482	Samsung	GT-S3778
1483	Samsung	GT-S3778V
1484	Samsung	GT-S3850
1485	Samsung	GT-S3970
1486	Samsung	GT-S5150
1487	Samsung	GT-S5220
1488	Samsung	GT-S5222
1489	Samsung	GT-S5230
1490	Samsung	GT-S5230C
1491	Samsung	GT-S5230G
1492	Samsung	GT-S5230N
1493	Samsung	GT-S5233A
1494	Samsung	GT-S5233S
1495	Samsung	GT-S5233T
1496	Samsung	GT-S5233W
1497	Samsung	GT-S5250
1498	Samsung	GT-S5260
1499	Samsung	GT-S5260P
1500	Samsung	GT-S5270K
1501	Samsung	GT-S5270L
1502	Samsung	GT-S5270Y
1503	Samsung	GT-S5273L
1504	Samsung	GT-S5330
1505	Samsung	GT-S5333
1506	Samsung	GT-S5350
1507	Samsung	GT-S5350L
1508	Samsung	GT-S5360
1509	Samsung	GT-S5360B
1510	Samsung	GT-S5360L
1511	Samsung	GT-S5360T
1512	Samsung	GT-S5363
1513	Samsung	GT-S5368
1514	Samsung	GT-S5369
1515	Samsung	GT-S5380
1516	Samsung	GT-S5380B
1517	Samsung	GT-S5380D
1518	Samsung	GT-S5380K

Item	Brand Name	Model
1519	Samsung	GT-S5380L
1520	Samsung	GT-S5510
1521	Samsung	GT-S5510T
1522	Samsung	GT-S5511T
1523	Samsung	GT-S5520
1524	Samsung	GT-S5530
1525	Samsung	GT-S5560
1526	Samsung	GT-S5560C
1527	Samsung	GT-S5560i
1528	Samsung	GT-S5570
1529	Samsung	GT-S5570B
1530	Samsung	GT-S5570I
1531	Samsung	GT-S5570L
1532	Samsung	GT-S5571
1533	Samsung	GT-S5578
1534	Samsung	GT-S5580
1535	Samsung	GT-S5600
1536	Samsung	GT-S5600B
1537	Samsung	GT-S5600H
1538	Samsung	GT-S5600L
1539	Samsung	GT-S5600T
1540	Samsung	GT-S5600V
1541	Samsung	GT-S5603
1542	Samsung	GT-S5603T
1543	Samsung	GT-S5608U
1544	Samsung	GT-S5610
1545	Samsung	GT-S5620
1546	Samsung	GT-S5620B
1547	Samsung	GT-S5620L
1548	Samsung	GT-S5628
1549	Samsung	GT-S5628i
1550	Samsung	GT-S5660
1551	Samsung	GT-S5660B
1552	Samsung	GT-S5660L
1553	Samsung	GT-S5660M
1554	Samsung	GT-S5660V
1555	Samsung	GT-S5670
1556	Samsung	GT-S5670B
1557	Samsung	GT-S5670L
1558	Samsung	GT-S5690
1559	Samsung	GT-S5690L
1560	Samsung	GT-S5690L
1561	Samsung	GT-S5750E
1562	Samsung	GT-S5780
1563	Samsung	GT-S5820
1564	Samsung	GT-S5830
1565	Samsung	GT-S5830B
1566	Samsung	GT-S5830C
1567	Samsung	GT-S5830i
1568	Samsung	GT-S5830L
1569	Samsung	GT-S5830M
1570	Samsung	GT-S5830T
1571	Samsung	GT-S5838
1572	Samsung	GT-S6102
1573	Samsung	GT-S6102B
1574	Samsung	GT-S6700T
1575	Samsung	GT-S6703T
1576	Samsung	GT-S6888
1577	Samsung	GT-S7070
1578	Samsung	GT-S7070C
1579	Samsung	GT-S7220U
1580	Samsung	GT-S7230
1581	Samsung	GT-S7230B
1582	Samsung	GT-S7230E
1583	Samsung	GT-S7230L
1584	Samsung	GT-S7233E
1585	Samsung	GT-S7250
1586	Samsung	GT-S7250D
1587	Samsung	GT-S7350i
1588	Samsung	GT-S7350U
1589	Samsung	GT-S7500
1590	Samsung	GT-S7510
1591	Samsung	GT-S8000B
1592	Samsung	GT-S8000C
1593	Samsung	GT-S8000C
1594	Samsung	GT-S8000H
1595	Samsung	GT-S8000L
1596	Samsung	GT-S8000U
1597	Samsung	GT-S8500
1598	Samsung	GT-S8500
1599	Samsung	GT-S8500B
1600	Samsung	GT-S8500C
1601	Samsung	GT-S8500L
1602	Samsung	GT-S8500M
1603	Samsung	GT-S8500R
1604	Samsung	GT-S8530
1605	Samsung	GT-S8530B
1606	Samsung	GT-S8530L
1607	Samsung	GT-S8600
1608	Samsung	Highlight
1609	Samsung	i200

Item	Brand Name	Model
1610	Samsung	I450
1611	Samsung	i520
1612	Samsung	i640v
1613	Samsung	i7500 Galaxy
1614	Samsung	i780
1615	Samsung	i8000 Omnia
1616	Samsung	i8510
1617	Samsung	i8910 HD
1618	Samsung	i907 Epix
1619	Samsung	i910
1620	Samsung	Impression (A877)
1621	Samsung	Instinct HD (M850)
1622	Samsung	Instinct S30
1623	Samsung	Intensity
1624	Samsung	Intrepid (I350)
1625	Samsung	J200
1626	Samsung	J700
1627	Samsung	J758
1628	Samsung	J808
1629	Samsung	Jack i637
1630	Samsung	L708
1631	Samsung	L760
1632	Samsung	L770
1633	Samsung	M220
1634	Samsung	M310
1635	Samsung	M320
1636	Samsung	M330
1637	Samsung	M5650
1638	Samsung	M630
1639	Samsung	M7600
1640	Samsung	M8910
1641	Samsung	Magnet A257
1642	Samsung	Marcel Reloaded
1643	Samsung	Moment
1644	Samsung	Mythic A897
1645	Samsung	Pixon M8800
1646	Samsung	Propel (TM) Pro i627
1647	Samsung	Rant M540
1648	Samsung	Reclaim (M560)
1649	Samsung	Renown
1650	Samsung	Rogue
1651	Samsung	Rugby (A837)
1652	Samsung	S3030 Tobi
1653	Samsung	S3110C
1654	Samsung	S3500C
1655	Samsung	S3600H
1656	Samsung	S3650 Corby
1657	Samsung	S5230
1658	Samsung	S5500
1659	Samsung	S5550 Shark
1660	Samsung	S5560
1661	Samsung	S5600
1662	Samsung	S5628 Monte
1663	Samsung	S7070 Diva
1664	Samsung	S7350
1665	Samsung	S7350B
1666	Samsung	S7350C
1667	Samsung	S7350L
1668	Samsung	S8000
1669	Samsung	S8000
1670	Samsung	S8300
1671	Samsung	S8300C
1672	Samsung	S8300T
1673	Samsung	S8300V
1674	Samsung	Samsung Captivate™ Glide
1675	Samsung	Samsung Exhilarate
1676	Samsung	Samsung Focus® 2
1677	Samsung	Samsung Focus™ S
1678	Samsung	Samsung Galaxy Alpha
1679	Samsung	Samsung Galaxy Avant
1680	Samsung	Samsung Galaxy Exhilarate™
1681	Samsung	Samsung Galaxy Express
1682	Samsung	Samsung Galaxy Express™
1683	Samsung	Samsung Galaxy K Zoom
1684	Samsung	Samsung Galaxy Nexus
1685	Samsung	Samsung Galaxy Note
1686	Samsung	Samsung Galaxy Note 2
1687	Samsung	Samsung Galaxy Note 3
1688	Samsung	Samsung Galaxy Note 4
1689	Samsung	Samsung Galaxy Rugby Pro
1690	Samsung	Samsung Galaxy Rugby Pro™
1691	Samsung	Samsung Galaxy S2 Skyrocket
1692	Samsung	Samsung Galaxy S3
1693	Samsung	Samsung Galaxy S4
1694	Samsung	Samsung Galaxy S4 mini
1695	Samsung	Samsung Galaxy S5
1696	Samsung	Samsung Galaxy S5 Active

Item	Brand Name	Model
1697	Samsung	Samsung Galaxy S5 Sport
1698	Samsung	Samsung Galaxy Stratosphere 2
1699	Samsung	Samsung GT-I5500B
1700	Samsung	Samsung GT-I5500L
1701	Samsung	Samsung GT-I5800L
1702	Samsung	Samsung Mobile Phone (GT-M2510)
1703	Samsung	Samsung Mobile Phone (SCH-R311)
1704	Samsung	Samsung Mobile Phone (SCH-U350)
1705	Samsung	Samsung Mobile Phone (SCH-U450)
1706	Samsung	Samsung Mobile Phone (SCH-U960)
1707	Samsung	Samsung Mobile Phone (SPH-M550)
1708	Samsung	Samsung Mobile Phone (SPH-M560)
1709	Samsung	Samsung Mobile Phone (SPH-M850)
1710	Samsung	Samsung Mobile Phone(GT-I8000)
1711	Samsung	Samsung Mobile Phone(I8910)
1712	Samsung	Samsung Mobile Phone(M7600)
1713	Samsung	Samsung Mobile Phone(SCH-R560)
1714	Samsung	Samsung Mobile Phone(SCH-U430)
1715	Samsung	Samsung Mobile Phone(SCH-U640)
1716	Samsung	Samsung Rugby 3
1717	Samsung	Samsung Rugby® Smart (Refurbished)
1718	Samsung	Samsung Stratosphere
1719	Samsung	SC-01B
1720	Samsung	SC-01C
1721	Samsung	SC-02B
1722	Samsung	SC-02C
1723	Samsung	SC-02C
1724	Samsung	SC-03D
1725	Samsung	SC-04D
1726	Samsung	SCH-F809
1727	Samsung	SCH-F859
1728	Samsung	SCH-I100
1729	Samsung	SCH-I110
1730	Samsung	SCH-i220
1731	Samsung	SCH-i220(MPCS)
1732	Samsung	SCH-i225
1733	Samsung	SCH-i329
1734	Samsung	SCH-I400
1735	Samsung	SCH-I405
1736	Samsung	SCH-I500
1737	Samsung	SCH-i509
1738	Samsung	SCH-I510
1739	Samsung	SCH-I515
1740	Samsung	SCH-I520
1741	Samsung	SCH-I559
1742	Samsung	SCH-I569
1743	Samsung	SCH-I579
1744	Samsung	SCH-I579i
1745	Samsung	SCH-I589
1746	Samsung	SCH-I800
1747	Samsung	SCH-I809
1748	Samsung	SCH-i889
1749	Samsung	SCH-i899
1750	Samsung	SCH-I909
1751	Samsung	SCH-I909L
1752	Samsung	SCH-i919
1753	Samsung	SCH-i920
1754	Samsung	SCH-I929
1755	Samsung	SCH-M710
1756	Samsung	SCH-M715
1757	Samsung	SCH-M720
1758	Samsung	SCH-M828C
1759	Samsung	SCH-P739
1760	Samsung	SCH-P739
1761	Samsung	SCH-R100
1762	Samsung	SCH-R220
1763	Samsung	SCH-R250
1764	Samsung	SCH-R260
1765	Samsung	SCH-R260
1766	Samsung	SCH-R260
1767	Samsung	SCH-R260
1768	Samsung	SCH-R261
1769	Samsung	SCH-R312
1770	Samsung	SCH-R330
1771	Samsung	SCH-R330
1772	Samsung	SCH-R335
1773	Samsung	SCH-R350
1774	Samsung	SCH-R351
1775	Samsung	SCH-R360
1776	Samsung	SCH-R380
1777	Samsung	SCH-R455
1778	Samsung	SCH-R520
1779	Samsung	SCH-R570
1780	Samsung	SCH-R580
1781	Samsung	SCH-R630
1782	Samsung	SCH-R631
1783	Samsung	SCH-R631 2Thumb
1784	Samsung	SCH-R640
1785	Samsung	SCH-R641
1786	Samsung	SCH-R680
1787	Samsung	SCH-R700

Item	Brand Name	Model
1788	Samsung	SCH-R710
1789	Samsung	SCH-R720
1790	Samsung	SCH-R730
1791	Samsung	SCH-R760
1792	Samsung	SCH-R850
1793	Samsung	SCH-R860
1794	Samsung	SCH-R880
1795	Samsung	SCH-R880
1796	Samsung	SCH-R900
1797	Samsung	SCH-R910
1798	Samsung	SCH-R915
1799	Samsung	SCH-R920
1800	Samsung	SCH-R930
1801	Samsung	SCH-R940
1802	Samsung	SCH-U350
1803	Samsung	SCH-U360
1804	Samsung	SCH-U365
1805	Samsung	SCH-U370
1806	Samsung	SCH-U380
1807	Samsung	SCH-U450
1808	Samsung	SCH-U450
1809	Samsung	SCH-U450(Verizon)
1810	Samsung	SCH-U460
1811	Samsung	SCH-U480
1812	Samsung	SCH-U660
1813	Samsung	SCH-U820
1814	Samsung	SCH-W279
1815	Samsung	SCH-W309
1816	Samsung	SCH-W689
1817	Samsung	SCH-W899
1818	Samsung	SCH-W999
1819	Samsung	SGH-A967
1820	Samsung	SGH-C414
1821	Samsung	SGH-C414M
1822	Samsung	SGH-C414R
1823	Samsung	SGH-C414V
1824	Samsung	SGH-C414W
1825	Samsung	SGH-C414Y
1826	Samsung	SGH-I577
1827	Samsung	SGH-I677
1828	Samsung	SGH-I717
1829	Samsung	SGH-I717D
1830	Samsung	SGH-I717M
1831	Samsung	SGH-I717R
1832	Samsung	SGH-I727
1833	Samsung	SGH-I727R
1834	Samsung	SGH-I757
1835	Samsung	SGH-I777
1836	Samsung	SGH-I777
1837	Samsung	SGH-I807
1838	Samsung	SGH-I807
1839	Samsung	SGH-I827
1840	Samsung	SGH-I847
1841	Samsung	SGH-I857
1842	Samsung	SGH-I896
1843	Samsung	SGH-I897
1844	Samsung	SGH-I897
1845	Samsung	SGH-I917
1846	Samsung	SGH-I917R
1847	Samsung	SGH-I927
1848	Samsung	SGH-I927R
1849	Samsung	SGH-I937
1850	Samsung	SGH-I937
1851	Samsung	SGH-I997
1852	Samsung	SGH-I997
1853	Samsung	SGH-I997R
1854	Samsung	SGH-J600E
1855	Samsung	SGH-S425G
1856	Samsung	SGH-T245G
1857	Samsung	SGH-T249R
1858	Samsung	SGH-T259
1859	Samsung	SGH-T269
1860	Samsung	SGH-T330G
1861	Samsung	SGH-T369R
1862	Samsung	SGH-T379
1863	Samsung	SGH-T499
1864	Samsung	SGH-T499W
1865	Samsung	SGH-T499Y
1866	Samsung	SGH-T589
1867	Samsung	SGH-T589R
1868	Samsung	SGH-T669V
1869	Samsung	SGH-T669V
1870	Samsung	SGH-T669Y
1871	Samsung	SGH-T669Y
1872	Samsung	SGH-T679
1873	Samsung	SGH-T679M
1874	Samsung	SGH-T759
1875	Samsung	SGH-T769
1876	Samsung	SGH-T839
1877	Samsung	SGH-T869

Item	Brand Name	Model
1878	Samsung	SGH-T939
1879	Samsung	SGH-T959
1880	Samsung	SGH-T959
1881	Samsung	SGH-T959D
1882	Samsung	SGH-T959D
1883	Samsung	SGH-T959D
1884	Samsung	SGH-T959P
1885	Samsung	SGH-T959V
1886	Samsung	SGH-T959W
1887	Samsung	SGH-T989
1888	Samsung	SGH-T989D
1889	Samsung	SHC-Z120L
1890	Samsung	SHV-E110S
1891	Samsung	SHV-E110S
1892	Samsung	SHV-E120K
1893	Samsung	SHV-E120L
1894	Samsung	SHV-E120S
1895	Samsung	SHV-E150S
1896	Samsung	SHV-E160K
1897	Samsung	SHV-E160L
1898	Samsung	SHV-E160S
1899	Samsung	SHW-A280K
1900	Samsung	SHW-A280L
1901	Samsung	SHW-A280S
1902	Samsung	SHW-A300K
1903	Samsung	SHW-A300S
1904	Samsung	SHW-A310S
1905	Samsung	SHW-M100S
1906	Samsung	SHW-M110S
1907	Samsung	SHW-M110S
1908	Samsung	SHW-M110S
1909	Samsung	SHW-M110S
1910	Samsung	SHW-M115S
1911	Samsung	SHW-M120S
1912	Samsung	SHW-M130K
1913	Samsung	SHW-M130K
1914	Samsung	SHW-M130L
1915	Samsung	SHW-M130L
1916	Samsung	SHW-M135K
1917	Samsung	SHW-M135L
1918	Samsung	SHW-M180K
1919	Samsung	SHW-M180L
1920	Samsung	SHW-M180S
1921	Samsung	SHW-M180W
1922	Samsung	SHW-M185S
1923	Samsung	SHW-M190S
1924	Samsung	SHW-M200K
1925	Samsung	SHW-M200S
1926	Samsung	SHW-M210S
1927	Samsung	SHW-M220L
1928	Samsung	SHW-M240K
1929	Samsung	SHW-M240S
1930	Samsung	SHW-M250K
1931	Samsung	SHW-M250K
1932	Samsung	SHW-M250L
1933	Samsung	SHW-M250L
1934	Samsung	SHW-M250S
1935	Samsung	SHW-M250S
1936	Samsung	SHW-M290K
1937	Samsung	SHW-M290S
1938	Samsung	SHW-M340K
1939	Samsung	SHW-M340L
1940	Samsung	SHW-M340S
1941	Samsung	SHW-M410K
1942	Samsung	SHW-M410S
1943	Samsung	SHW-M420K
1944	Samsung	SHW-M420S
1945	Samsung	Smooth
1946	Samsung	Solstice (TM) (A887)
1947	Samsung	SPH-D600
1948	Samsung	SPH-D600
1949	Samsung	SPH-D700
1950	Samsung	SPH-D705
1951	Samsung	SPH-D710
1952	Samsung	SPH-D710
1953	Samsung	SPH-D720
1954	Samsung	SPH-i350
1955	Samsung	SPH-L700
1956	Samsung	SPH-M260
1957	Samsung	SPH-M330
1958	Samsung	SPH-M340
1959	Samsung	SPH-M350
1960	Samsung	SPH-M360
1961	Samsung	SPH-M370
1962	Samsung	SPH-M380
1963	Samsung	SPH-M380
1964	Samsung	SPH-M560
1965	Samsung	SPH-M570
1966	Samsung	SPH-M575
1967	Samsung	SPH-M580
1968	Samsung	SPH-M580

Item	Brand Name	Model
1969	Samsung	SPH-M580 BST
1970	Samsung	SPH-M7200
1971	Samsung	SPH-M7350
1972	Samsung	SPH-M820
1973	Samsung	SPH-M8400
1974	Samsung	SPH-M900
1975	Samsung	SPH-M900
1976	Samsung	SPH-M910
1977	Samsung	SPH-M930
1978	Samsung	SPH-M930
1979	Samsung	SPH-P100
1980	Samsung	Steel U900
1981	Samsung	SWD-S500
1982	Samsung	t229
1983	Samsung	t239
1984	Samsung	t349
1985	Samsung	T559 Comeback
1986	Samsung	T659
1987	Samsung	t819
1988	Samsung	T929 Memoir
1989	Samsung	Trance
1990	Samsung	u440
1991	Samsung	U808
1992	Samsung	X01SC
1993	Samsung	A637
1994	Samsung	A657
1995	Samsung	Galaxy S i9000
1996	Samsung	M520
1997	Samsung	T339
1998	Samsung	u430
1999	Samsung	Wave S8500
2000	Sanyo	Incognito (SCP-6760)
2001	Sanyo	Katana Eclipse
2002	Sanyo	Katana LX
2003	Sanyo	PRO-700
2004	Sanyo	SCP-2700
2005	Sanyo	SCP-3810
2006	Seals Technologies Limited	VR7
2007	Sharp	t02SH
2008	Sharp	ADS1
2009	Sharp	P1FD50C
2010	Sharp	P1FD52C
2011	Sharp	SH-01D
2012	Sharp	Sharp® FX™ PLUS
2013	Shenzhen Sang Fei Consumer Com	Philips E122
2014	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W527
2015	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W625
2016	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W626
2017	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W715
2018	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W725
2019	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W727
2020	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W820
2021	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips X525
2022	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips X526
2023	Shenzhen Sang Fei Consumer Com	Philips X528
2024	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips X623
2025	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips Xenium X325
2026	Shenzhen Sang Fei Consumer Com	Philips W920
2027	Shenzhen Tinno Mobile Technology Corp.	T521
2028	SK telesys	SK-S150
2029	Sonim	Sonim XP1300-A-R1 (Type: P25B005AA)
2030	Sonim	Sonim XP1300-E-R1 (Type: P24B005AA)
2031	Sonim	Sonim XP1301-A-R1 (Type: P25B005AN)
2032	Sonim	Sonim XP1301-E-R1 (Type: P24B005AN)
2033	Sonim	Sonim XP3300-A-R1 (Type: P25C005AA)
2034	Sonim	Sonim XP3300-A-X1 (Type: P25C005AJ)
2035	Sonim	Sonim XP3300-A-Y1 (Type: P25C005AJ)
2036	Sonim	Sonim XP3300-E-R1 (Type: P24C005AA)
2037	Sonim	Sonim XP3300-E-X1 (Type: P24C005AJ)
2038	Sonim	Sonim XP3300-E-Y1 (Type: P24C005AJ)
2039	Sonim	Sonim XP3340-E-R1 (Type: P24C005AA)
2040	Sonim	Sonim XP3400-A-R1 (Type: C21F007AA)
2041	Sonim	Sonim XP5300-A-R1 (Type: P35F006AA)
2042	Sonim	Sonim XP5300-E-R1 (Type: P34F006AA)
2043	Sony	Equinox
2044	Sony	Sony Xperia Advance
2045	Sony	Sony Xperia T3
2046	Sony	Sony Xperia TL
2047	Sony	Sony Xperia Z3

Item	Brand Name	Model
2048	Sony	Sony Xperia Z3 Compact
2049	Sony	Sony Xperia™ TL
2050	Sony	Xperia™ ion by Sony
2051	Sony Ericsson	Aino
2052	Sony Ericsson	Aino/ U10
2053	Sony Ericsson	ASPEN
2054	Sony Ericsson	C510 Black
2055	Sony Ericsson	C510, C510a
2056	Sony Ericsson	C901
2057	Sony Ericsson	C901, C901a
2058	Sony Ericsson	C902
2059	Sony Ericsson	C903, C903a
2060	Sony Ericsson	C905 Black
2061	Sony Ericsson	CDMA SO111
2062	Sony Ericsson	Cedar?
2063	Sony Ericsson	Elm
2064	Sony Ericsson	F100i
2065	Sony Ericsson	F305
2066	Sony Ericsson	G502
2067	Sony Ericsson	G700
2068	Sony Ericsson	G705
2069	Sony Ericsson	G900
2070	Sony Ericsson	Hazel
2071	Sony Ericsson	J105 (Naite?)
2072	Sony Ericsson	J105i
2073	Sony Ericsson	Live with Walkman
2074	Sony Ericsson	Mix Walkman
2075	Sony Ericsson	S302
2076	Sony Ericsson	S51SE
2077	Sony Ericsson	Satio/ U1
2078	Sony Ericsson	SO-01C
2079	Sony Ericsson	SO-01D
2080	Sony Ericsson	SO-03C
2081	Sony Ericsson	Sony Ericsson A8i
2082	Sony Ericsson	Sony Ericsson R800
2083	Sony Ericsson	Sony Ericsson txt
2084	Sony Ericsson	T650i
2085	Sony Ericsson	T700
2086	Sony Ericsson	T707, T707a
2087	Sony Ericsson	T715
2088	Sony Ericsson	T715
2089	Sony Ericsson	TM506
2090	Sony Ericsson	TM717
2091	Sony Ericsson	txt pro™
2092	Sony Ericsson	U10
2093	Sony Ericsson	Vivaz?
2094	Sony Ericsson	Vivaz? pro
2095	Sony Ericsson	W300i
2096	Sony Ericsson	W302
2097	Sony Ericsson	W350 (Refurbished)
2098	Sony Ericsson	W350a
2099	Sony Ericsson	W508, W508a
2100	Sony Ericsson	W518a
2101	Sony Ericsson	W518a
2102	Sony Ericsson	W580i
2103	Sony Ericsson	W595
2104	Sony Ericsson	W660i
2105	Sony Ericsson	W705
2106	Sony Ericsson	W705, W705u, W705a
2107	Sony Ericsson	W715
2108	Sony Ericsson	W760a
2109	Sony Ericsson	W810i
2110	Sony Ericsson	W850i
2111	Sony Ericsson	W960i
2112	Sony Ericsson	W980
2113	Sony Ericsson	W995, W995a
2114	Sony Ericsson	WT18
2115	Sony Ericsson	Xperia acro
2116	Sony Ericsson	Xperia arc
2117	Sony Ericsson	Xperia mini
2118	Sony Ericsson	Xperia mini pro
2119	Sony Ericsson	Xperia neo V
2120	Sony Ericsson	Xperia PLAY
2121	Sony Ericsson	Xperia pro
2122	Sony Ericsson	Xperia Pureness/ X5
2123	Sony Ericsson	Xperia X1
2124	Sony Ericsson	Xperia X10
2125	Sony Ericsson	Xperia X10
2126	Sony Ericsson	Xperia? X10 mini (Rev 2)
2127	Sony Ericsson	Xperia? X10 mini pro (Rev2)
2128	Sony Ericsson	Xperia? X8
2129	Sony Ericsson	Xperia™ acro
2130	Sony Ericsson	Xperia™ active
2131	Sony Ericsson	Xperia™ arc S
2132	Sony Ericsson	Xperia™ neo
2133	Sony Ericsson	Xperia™ ray
2134	Sony Ericsson	Yari
2135	Sony Ericsson	Z310a
2136	Sony Ericsson	Z750a
2137	Sony Ericsson	Z770i

Item	Brand Name	Model
2138	Sony Ericsson	Zylo?
2139	Sony Ericsson	Aion U10
2140	Sony Ericsson	C903
2141	Sony Ericsson	Elm J10
2142	Sony Ericsson	F100
2143	Sony Ericsson	Hazel J20
2144	Sony Ericsson	K510a
2145	Sony Ericsson	K660i
2146	Sony Ericsson	Satio U1i
2147	Sony Ericsson	Vivaz U5
2148	Sony Ericsson	W395
2149	Sony Ericsson	W902
2150	Sony Ericsson	W995
2151	Sony Ericsson	X10
2152	Sony Ericsson	X10 mini
2153	Sony Ericsson	X10 mini pro
2154	Sony Ericsson	X2
2155	Sony Ericsson	Yari U100
2156	Sony Ericsson	Z550a
2157	Sony Ericsson	Z555
2158	TCT Mobile Suzhou Limited	JukeB
2159	TCT Mobile Suzhou Limited	MOVE/ one touch 908/ one touch 908A/ one touch 908S/ one touch 908M/ one touch 908F
2160	TCT Mobile Suzhou Limited	one touch 318D
2161	TCT Mobile Suzhou Limited	one touch 506/ one touch 506D / one touch 506A
2162	TCT Mobile Suzhou Limited	one touch 536
2163	TCT Mobile Suzhou Limited	one touch 585/ 585D/ 585A
2164	TCT Mobile Suzhou Limited	one touch 602/ 602D/ 602A
2165	TCT Mobile Suzhou Limited	one touch 632D
2166	TCT Mobile Suzhou Limited	one touch 665/ one touch 665A
2167	TCT Mobile Suzhou Limited	one touch 678G
2168	TCT Mobile Suzhou Limited	one touch 803/ one touch 803A/ one touch 813/ one touch 813D/ one touch 813A/ one touch 819/ one touch 819A/ one
2169	TCT Mobile Suzhou Limited	one touch 810/ one touch 810A/ one touch 810D
2170	TCT Mobile Suzhou Limited	one touch 818/ one touch 818A/ one touch 818D
2171	TCT Mobile Suzhou Limited	one touch 888/ one touch 888A/ one touch 888D
2172	TCT Mobile Suzhou Limited	one touch 890/ one touch 890D
2173	TCT Mobile Suzhou Limited	one touch 891
2174	TCT Mobile Suzhou Limited	one touch 900M/ one touch 900/ one touch 901A/ one touch 901S/ one touch 901N/ one touch 901D/ one touch 900A
2175	TCT Mobile Suzhou Limited	one touch 905/ 905A/ 907N/ 905M
2176	TCT Mobile Suzhou Limited	one touch 906/ one touch 906Y
2177	TCT Mobile Suzhou Limited	one touch 909B
2178	TCT Mobile Suzhou Limited	one touch 910/ one touch 909A/ one touch 909M/ one touch 909S/ one touch 910A
2179	TCT Mobile Suzhou Limited	one touch 913D/ one touch 913K/ one touch 913N
2180	TCT Mobile Suzhou Limited	one touch 918/ one touch 918A/ one touch 918D/ one touch 918N/ one touch 918M/ TCL A919/ OT 918
2181	TCT Mobile Suzhou Limited	one touch 985/ one touch 985A/ one touch 985S/ one touch 985N/ TCL A966/ OT 985
2182	TCT Mobile Suzhou Limited	one touch 990/ one touch 990A/ one touch 990S/ one touch 990M/ Vodafone 958
2183	TCT Mobile Suzhou Limited	OT-799/ OT-799A
2184	TCT Mobile Suzhou Limited	S by SFR 3440
2185	TCT Mobile Suzhou Limited	TCL-7110
2186	TCT Mobile Suzhou Limited	TCL-8107
2187	TCT Mobile Suzhou Limited	Vodafone 355
2188	TCT Mobile Suzhou Limited	Vodafone 455
2189	TCT Mobile Suzhou Limited	Vodafone 555 Blue
2190	T-Mobile	G2
2191	T-Mobile	MyTouch 3G Slide
2192	T-Mobile	MyTouch 4G
2193	T-Mobile	T-Mobile Wing (S730)
2194	Tsb Plus Deal Corp	EYO DESERT 6
2195	Tsb Plus Deal Corp	EYO E97
2196	Tsb Plus Deal Corp	X95
2197	UT Starcom	CDM8950
2198	UT Starcom	GZ1 C711
2199	Verykool	Verykool Spark s505
2200	ZTE	003Z
2201	ZTE	a5
2202	ZTE	Android Edition Starnaute
2203	ZTE	BJK1903
2204	ZTE	F160
2205	ZTE	F870
2206	ZTE	F870E
2207	ZTE	F930
2208	ZTE	F950
2209	ZTE	F951
2210	ZTE	F951E
2211	ZTE	Jack 3G
2212	ZTE	San Francisco
2213	ZTE	T870
2214	ZTE	T930
2215	ZTE	Tactile internet 2
2216	ZTE	Venus
2217	ZTE	Vodafone 945
2218	ZTE	XCD35
2219	ZTE	ZTE F870
2220	ZTE	ZTE F951
2221	ZTE	ZTE F952 UM KP
2222	ZTE	ZTE Open C
2223	ZTE	ZTE ZMax (T-Mobile)
2224	ZTE	ZTE-1001
2225	ZTE	ZTE-BLADE
2226	ZTE	ZTE-C F350
2227	ZTE	ZTE-U X990
2228	ZTE	ZTE-U X991

Item	Brand Name	Model
2229	ZTE	008Z
2230	ZTE	008Z
2231	ZTE	009Z
2232	ZTE	Android edition by sfr STARADDICT
2233	ZTE	Android Edition Star Text
2234	ZTE	Android Edition StarTrail
2235	ZTE	Arizona
2236	ZTE	BASE Lutea 2
2237	ZTE	BLADE II
2238	ZTE	Blade S
2239	ZTE	CARL/ ZTE-U V852
2240	ZTE	E821
2241	ZTE	F451
2242	ZTE	KPN Smart 200
2243	ZTE	Light Tab 2W
2244	ZTE	MEDION Smartphone LIFE P4310
2245	ZTE	MEDION Smartphone LIFE P4310
2246	ZTE	Monte Carlo
2247	ZTE	Movistar One
2248	ZTE	Movistar Vega
2249	ZTE	RacerII
2250	ZTE	RacerII
2251	ZTE	S by SFR 116
2252	ZTE	S by SFR 344
2253	ZTE	San Francisco II
2254	ZTE	San Francisco II
2255	ZTE	Skate4.3 H
2256	ZTE	T28
2257	ZTE	T28
2258	ZTE	T50
2259	ZTE	T60
2260	ZTE	tmn smart a7
2261	ZTE	TQ150
2262	ZTE	V871
2263	ZTE	V875
2264	ZTE	Vivacity
2265	ZTE	Vodafone 351
2266	ZTE	Vodafone 550
2267	ZTE	webphones Android™ by sfr STARTEXT II
2268	ZTE	Windows Phone-Internet 7
2269	ZTE	X500
2270	ZTE	X500
2271	ZTE	X500M
2272	ZTE	Z331
2273	ZTE	Z431
2274	ZTE	Z990