Carrier

AIR
PURIFIER

Quick Start Guide

RMAP-ST
RMAP-XL
RMAP-SST
RMAP-SXL

⚠ CAUTION	• Be sure to unplug the unit before removing the filter packaging. • Remove the plastic packaging from the filter before use. • Keep plastic packaging away from children as it may cause suffocation.

How to Prepare/Change the Filter

1 Hold the top cover of the product with both hands and pull up.

2 Grasp the filter cover hole on the rear and pull it forward. Remove the filter from the unit by pulling it straight out.

Filter cover hole

3 Remove the plastic packaging from the filter.
▸ Failing to remove the packaging will result in abnormal sounds and the filter will not work properly; and it may cause a fire or other damage to the product.

Plastic packaging

4 Slide the filter back into the unit.

5 Replace filter cover.
▸ Insert the cover into the fixed groove at the bottom of the product.
▸ Slide the cover forward so that the cover fits into the top grooves.

Fixed groove at bottom

Cover-positioning groove at top

6 Hold the top cover of the product with both hands and slide it back in place, making sure the logo appears in the front.

7 When the filter installation is complete, plug the unit into a 120V outlet, press the $\frac{Sleep}{\oplus}$ + "Auto" button on the control panel for five seconds or more to initialize it.

▸ The red filter light will turn off when the product is reset.

Display

- Smart Auto Mode — AUTO
- Sleep Mode
- Filter Replacement Indicator
- Wi-Fi

PM2.5

μg / m³

- Timer
- Indoor Air Quality Light

Control Panel

Sleep $\oplus$ LED $\widehat{\widehat{\ }}$ ∨ — Turbo — ∧   Auto   ⏻

Control Panel Descriptions

$\frac{Sleep}{\oplus}$	Sleep mode / Timer	∧	Turn up the fan speed and time (by 1 hour)
$\frac{LED}{\widehat{\widehat{\ }}}$	LED ON/OFF & Wi-Fi® connection	Auto	Smart automatic operation
∨	Turn down the fan speed and time (by 1 hour)	⏻	Power ON/OFF

Normal Operation

> ☀ **Note** When the air purifier turns on, the sensor is initialized and the display shows ⌐_ _⌐ during initialization.

1 Press the ⏻ button to turn on.
 ▸ The previously selected operation mode will be displayed.

2 Press the ∨ ∧ button on the control panel to select your desired fan speed.
 ▸ You can adjust the fan speed from level 1 (F1) to level 18 (F18).

 Note: The default home display on Wi-Fi® models will show a PM2.5 reading. Once the ∨ ∧ button is pushed, the display will switch to show designated fan speed.

How to Install Casters (Optional)

1 Inside of the air purifier package, there is a small box containing four casters and eight screws.

2 Remove the four bottom bases from the air purifier with a screw driver.

3 Replace each base with a caster, utilizing two screws per caster.

4 Retain the removed bottom bases and screws for future use.

> ☀ **Note** If there is no caster box inside the product box, please contact customer service at 1-888-320-0909.

AHAM VERIFIDE®   ETL Listed us Intertek   energy ENERGY STAR

Carrier