FCC ID: ARSCM569P



4.1.6 EUT OPERATING CONDITIONS

- a. Turn on the power of all equipment.
- b. PC runs a test program to enable all functions.
- c. PC reads and writes messages from FDD and HDD.
- d. PC sends "H" messages to Color Monitor (EUT) and Color Monitor displays "H" patterns on screen.
- e. PC sends "H" messages to modem.
- f. PC sends "H" messages to printer, and the printer prints them on paper.
- g. Repeat steps c-g.