

Possible instructions for programming Noma N1564 7-day digital timer.

Set current time:

Hold down Time button and push Day, Hour, and Min buttons until current time is set.

Make sure to choose correct AM or PM setting.

Release Time button.

Set Programs:

Press Prog button until 1 and ON display. This is program 1 ON.

Press day button until desired days of operation display.

Press Hour and Min buttons to set hour and minute for program 1 ON.

Press Prog button until 1 and OFF display. This is program 1 OFF.

Press day button until desired days of operation display. Choose OFF days so there is no conflict with ON days.

Press Hour and Min buttons to set hour and minute for program 1 OFF.

Press Prog button until 2 and ON display. This is program 2 ON.

Repeat instructions shown above to set on and off times.

Activate timer

Press OVR override button until display cursor sits above 'Auto'

To override timer and turn Load on-off manually, set cursor to OFF or ON.

Reset timer using reset button

