





Camera grip stand for gadget cover



User Manual
V20221117.01

Product Description



Contents


Camera grip stand for gadget cover *1
User Manual *1

Instruction of operation


1. Power on after long pressing the power button for 3 seconds, then turn on the phone bluetooth to enter search condition, and click "Camera Grip Stand" in the searched equipment. Green light of the remote control will be off after connected .




2. Align the adapter on the back of the cover with the bracket and rotate the adapter 45° to install .




3. Pick out the bottom tripod with your fingers .



4. Puling out the tripod and place it on a tabletop .




5. Holding down the push knob and rotating the cover 45°, then remove the product .



Replace the battery

Remove the remote control, turn the remote control to the back, push out the bottom cover with the card aimed at the pinhole on the bottom of the remote control, and then pull out the bottom cover by hand to replace the button battery .



Product Specifications

Product Name	Camera grip stand for gadget cover
Model No	GP-TOS911SA
Battery Capacity	75 mAh
Weight	86g
Material	PC / silica gel / zinc alloy
Bluetooth version	5.0
Place of Origin	China

PCC statements:
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.
The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction.



Made in China