SAMSUNG Galaxy A03s



Phone Quick Start Guide

AT&T 4-Star
Eco-Rating 2.0
att.com/ecospace

WIRELESS
EMERGENCY
ALERTS

AT&T Eco Rating 2.0 only applies to Samsung Galaxy

EcoSpace. Wireless Emergency Alerts is a registered

©2022 Samsung Electronics America, Inc. Samsung & Samsung Galaxy are registered trademarks of

Samsung Electronics Co., Ltd. Contains Lithium-ion

AT&T Intellectual Property. All rights reserved. AT&T,

the AT&T logo and all other AT&T marks contained

herein are trademarks of AT&T Intellectual Property.

All other marks are the property of their respective

battery - recycle or dispose of properly. © 2022

owners. Images shown are for reference only.


A03s. For limited factors evaluated visit att.com/

Trademark and Service Mark of CTIA.

CAPABLE

Optimize the battery

From the home screen, swipe up for Apps, and then tap Settings > Settings >



What's in the box

- Samsung Galaxy A03s
- SIM card
- SIM Ejector Pin
- USB-C to USB-C Cable
- Quick Start Guide
- Terms and Conditions

Useful apps*



myAT&T

Manage your account, track your usage, review and pay your bill, and update your data plan service.



AT&T ProTech

Have a question, call or chat with a live AT&T ProTech support expert.



AT&T Smart Wi-Fi

Find and auto-connect to available hotspots.



AT&T Call Protect

Tired of nuisance calls? Take more control with automatic fraud blocking and suspected spam warnings.



Device Help

Get easy to understand solutions and device-troubleshooting help

*Compatible device and subscription may be require Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, go to https://att.com/shop/apps

Find more information Manage your account with myAT&T





• On the web: att.com/myATT

Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need more help?

• On your phone: Swipe up for **Apps**, and then tap **AT&T** folder > **Device Help**.



Give us a call

- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878

Device Protection

Remember to protect your device against loss, theft and damage. Learn more at att.com/protectyourdevice

Samsung Care

- To access user manuals, tips, videos, and more, visit samsung.com/us/support
- For hardware or software support, call 800.726.7864 or visit samsung.com/us/ support/contact
- To find a repair center, visit support-us. samsung.com/cyber/locator/asc_locator.jsp





Your new phone



Need more help? Swipe up for **Apps > AT&T** folder **> Device Help**

Rear cover and battery are not removable.

Do not attempt to remove.

Easily adjust settings Settings menu

From the home screen, swipe up for **Apps**, and then tap **Settings** ②.



Quick settings

Drag the Status bar down to display the Notification panel.

In addition to notifications, swipe down again to display quick access to device functions such as Settings, Bluetooth and Wi-Fi.



3

6

9

Capture life's moments Take a picture

From the home screen, tap **Camera** • > **PHOTO**.

- Pinch the display to zoom in or out.
- Tap to take a photo.
- Tap 💿 to take selfies.
- Swipe left and select **MORE** for shooting modes.

Record a video

From the home screen, tap **Camera** • > **VIDEO**.

- Tap to start recording.
- Tap 💿 to capture a picture while recording.
- Tap (II) to pause recording.
- Tap

 to end recording.

Share a picture or video

- 1. After taking the picture, tap the image viewer at the bottom left of the screen.
- 2. Select the photo you want to share and then tap **Share** <**℃**.
- 3. Select the desired option to share your photo and follow the prompts.

How to replace the SIM Remove SIM/microSD

tray

• Use the tool to open the SIM/microSD[™] card tray.

Insert SIM/microSD card

 Place the SIM card and optional microSD card (sold separately) into the tray with the gold contacts facing down.

Turn on your new phone

 Press and hold the Side key until the device turns on.



Call family & friends

Make a call

- 1. From the home screen, tap **Phone C**.
- 2. Place a call using one of the following:
 - Keypad: Displays the keypad, and enter a phone number.
 - **Recents**: Select from call history.
 - Contacts: Select from address book.
- 3. Tap to make a voice call or to make a video call.

Check Voicemail

- 1. From the home screen, tap **Phone** .
- 2. Tap Voicemail .

Visual Voicemail

- 1. From the home screen, swipe up for **Apps**, and then tap **Visual Voicemail** ...
- 2. Select a message to play.

Surf & stream in no time

Connect to Wi-Fi

- From the home screen, swipe up for Apps, and then tap Settings > Connections > Wi-Fi.
- 2. Tap the Wi-Fi slider to turn it on.
- Tap a network, enter a password if required, then tap Connect.



Use Bluetooth

- From the home screen, swipe up for Apps, and then tap Settings • >
 - Connections > Bluetooth.
- 2. Tap the Bluetooth slider to turn it on.
- Tap the field next to your device name to make it visible for pairing.
- 4. Tap a device from the list to initiate pairing.

