

 ${\bf 250}$ litre frost free top mount with white finish

RRP AUS \$849.00





Product Details

FEATURES

FlexStor™ door bin storage Reversible doors Adjustable levelling feet Deodoriser (front) system Absorb pungent food smells to keep flavours fresh and distinct. Chiller drawer Frost free Full-width humidity controlled Door alarm crisper bin Twist ice and serve Multi-flow air delivery system R600a refrigerant Adjustable easy clean glass

BENEFITS

drinks at a twist

(removable)

make ice with ease and cool

Twist ice & Serve

Twist ice and serve with ice caddy provides you with easy access to more ice, more often

Adjustable solutions with FlexStor™

better for the environment

As your family changes and grows, so do the requirements of your fridge. With FlexStor™ you enjoy the convenience of being able to easily change the configuration, whatever your needs. Adjust the height and position of the door bins to fit in large and smaller items and arrange your fridge your way.

shelves

Humidity controlled crisper

Offers the perfect environment for preserving fruit and vegetables, as well as having a removable crisper front for easy cleaning

Easy to clean with glass shelves

Glass shelves improve visibility and are easy to clean



Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty to cover replacement of parts for the sealed refrigeration system (yrs)	3
Refrigerator Type	top mount
Exterior door finish	White
Fridge door opening	reversible (with optional door kit)
Cooling system	frost free
Refrigerant	R600a
_	_

DIMENSIONS

Total height (mm)	1470
Total width (mm)	540
Cabinet width (mm)	540
Total depth (mm)	615
Cabinet depth (mm)	540
Depth door open 90degree (mm)	1108
Air space above cabinet (mm)	90
Food compartment capacity (gross in litres)	168
Total Gross Capacity (L)	245
Freezer compartment capacity (gross in litres)	77

ENERGY

Energy Star Rating	3.5

REFRIGERATOR SYSTEM

Controls	manual
Controls	IIIaiiuai



ENERGY

Energy consumption (KWhr/yr)

282

REFRIGERATOR SYSTEM

Controls location	internal
Control functions	quick freeze function
Door alarm	fridge and freezer

FOOD COMPARTMENT

DELI-COMPARTMENT

Full width compartment

1

SHELVING

Shelf material

glass

CRISPERS

Crisper lid/shelf

plastic

Crispers Runner system

floor

Full width crisper

1

Crisper features

humidity controlled

LIGHTING

Main light

LED

OTHER PROPERTIES

Other Properties-FOOD COMPARTMENT

Deodoriser

FOOD COMPARTMENT DOOR

BINS

Deep bottle bin

1





Shallow bin 1

FREEZER COMPARTMENT

ICE FACILITY

Twist ice and serve 2

SHELVING

Shelving	plastic shelf
Number of shelves	1

FREEZER DOOR


INTERNAL


Freezer door bins - full width

2




Dimensions






Recommended minimum clearances

Please note: Doors are designed to sit proud of cabinetry (not flush).



If you have a cupboard above the refrigerator with a rear gap of less than 100mm (Y), recommended minimum clearance at the top of the refigerator increases from 30mm to 70mm (X).



When positioned in a corner, the clearance must be at least 300mm on the hinge side to allow the door to open smoothly so that bins and shelves can be removed easily.



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz