

# *the Salt & Pepper Mills™*

Instruction Book - LSP200



**Breville®**



## Contents

- 5 Components
- 6 Functions
- 7 Care & Cleaning

## **BREVILLE RECOMMENDS SAFETY FIRST**

At Breville we are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer, foremost in mind. In addition we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions.

## **IMPORTANT SAFEGUARDS**

**READ ALL  
INSTRUCTIONS BEFORE  
USE AND SAVE FOR  
FUTURE REFERENCE**

- Remove and safely discard any packaging material and promotional labels before using the Salt & Pepper Mills for the first time.
- The Salt & Pepper Mills are not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack experience and knowledge, unless they are supervised or have been given instruction concerning use of the Salt & Pepper Mills, by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the Salt & Pepper Mills.
- Do not use the Salt & Pepper Mills on or near a hot gas or electric burner, or anywhere it could touch a heated oven.
- Do not place the Salt & Pepper Mills in direct sunlight.
- Always ensure the 6 x AAA batteries are correctly inserted into the Salt & Pepper Mills before use. The mills will not operate unless properly assembled.
- Do not use a combination of old and new batteries; change all batteries at the same time when they run out of power.
- Ensure that the same type of batteries are used together ie: alkaline or heavy duty.
- Always remove the batteries if the Salt & Pepper Mills will not be used for an extended period of time.
- Only recharge batteries that are specifically designed to be recharged.
- Ensure used batteries are disposed of correctly.
- Children should not touch or play with the batteries or put them in their mouths.
- Any maintenance other than cleaning should be performed at any authorised Breville Service Centre.
- Do not use the Salt & Pepper Mills if they are damaged or have malfunctioned.
- The Salt & Pepper Mills are for household use only. Do not use the mills for anything other than its intended use.


**Misuse may cause injury.**

- Do not immerse the Salt & Pepper Mills in water or any other liquid. Do not place the Salt & Pepper Mills in the dishwasher.
- Do not place anything on top of the Salt & Pepper Mills when stored.
- Keep the Salt & Pepper Mills clean. Refer to the cleaning instructions in this booklet.

**FOR HOUSEHOLD USE ONLY  
SAVE THESE INSTRUCTION**



## Components



- A. One touch grinding button
- B. Easy load, removable battery cartridge  
Holds 6 x AAA batteries (not included)
- C. Stainless steel body
- D. Salt and pepper compartment  
/viewing window
- E. Ceramic grinding system

- F. Adjustable grind control  
Fine to coarse
- G. Built-in light  
Illuminates when operation button  
is pressed
- H. Base cover  
For mess-free storage



## Functions

### BEFORE FIRST USE

Remove any packaging material and promotional labels from the Salt & Pepper Mills before first use. Ensure that all parts are accounted for before discarding the packaging. Wipe the Salt & Pepper Mills with a soft, damp cloth and dry thoroughly. Do not immerse the Salt & Pepper Mills in water or any other liquid.

### INSERTING THE BATTERIES

To open the battery cartridge, hold the stainless steel mill body in one hand whilst turning the removable top in an anti-clockwise direction, so that the **■** aligns with the **⚙**. Pull the battery cartridge away from the stainless steel mill body.



Insert 6 x AAA batteries into the removable cartridge. Ensure that the polarity of each battery follows the graphics.

Replace the battery compartment on the mill body, ensuring the **■** aligns with the **⚙**. Hold the mill body in one hand whilst turning the top in a clockwise direction until the **■** aligns with the **⚙**.



### NOTE

Remove the batteries if the Salt & Pepper Mills are not to be used for an extended period of time.

### FILLING THE MILLS

The Salt & Pepper Mills are only suitable for grinding salt and pepper. Do not attempt to grind spices or other foods in the mills.

Refer to the salt or peppers manufacturers directions before using it in the Salt & Pepper Mills. Some varieties may not be suitable for use in a mill.

To open the salt and pepper compartment, hold the stainless steel mill body in one hand and using the other hand, turn the lower compartment in an anti-clockwise direction, until the **■** aligns with the **⚙**.



Pour the desired amount of salt or pepper into the compartment. Be careful not to over fill.

Once filled, replace the stainless steel mill body on top of the salt and pepper compartment, aligning the **■** with the **⚙**. Turn in a clockwise direction, until the **■** aligns with the **⚙**.

## ADJUSTING THE GRIND

The Salt & Pepper Mills have adjustable grind control, allowing the ground results to be fine or coarse to suit your preference. The grind control knob can be found at the base of the grinder where the ground salt/pepper falls from.



For a finer grind, turn the grind control knob in a clockwise direction.

For a coarser grind, turn the grind control knob in an anti-clockwise direction.

### NOTE

Do not turn the grind control knob more than 5 full rotations. Doing so will unscrew the grind control knob from other internal components.

## OPERATING THE MILLS

When using the Salt & Pepper Mills, ensure that the base storage cover has been removed.

Hold the mill directly over the food to be seasoned, press and hold the one touch operation button at the top of the mill.



While the mill is operating, the light at the base of the grinder will illuminate.

To stop grinding, release the one touch button.

If the salt and pepper grinder is no longer needed, replace the base storage cover onto the mill.

### WARNING

Do not use the Salt & Pepper Mills over cooking. Moisture from the steam can clog the mills grinding mechanism.

### Care & Cleaning

To clean the outside of the Salt & Pepper Mills, wipe the stainless steel housing with a soft, damp cloth and dry thoroughly.

Do not use steel wool, scouring pads or abrasive cleaners on the Salt & Pepper Mills, as they will damage the stainless steel housing.

To clean the inside of the salt and pepper compartment, empty out the contents of the compartment and use a dry pastry brush or another small brush to clear out any remaining salt or pepper.

### NOTE

Do not immerse the Salt & Pepper Mills in water or any other liquid.

## STORAGE

The Salt & Pepper Mills should be stored in a dry and cool location. This will help to prevent the contents from clumping.

Ensure that the base storage cover is attached to the base of the mill before storing.

If the Salt & Pepper Mills are not being used for an extended period of time, the batteries should be removed.

## Breville Customer Service Centre

### Australian Customers

**Mail:** Locked Bag 2000  
Botany NSW 1455  
AUSTRALIA

**Phone:** 1300 139 798

**Fax:** (02) 9700 1342

**Email:** [askus@breville.com.au](mailto:askus@breville.com.au)

**Web:** [www.breville.com.au](http://www.breville.com.au)

### New Zealand Customers

**Mail:** Private Bag 94411  
Botany Manukau 2163  
Auckland NEW ZEALAND

**Phone:** 0800 273 845

**Fax:** 0800 288 513

**Email:** [askus@breville.co.nz](mailto:askus@breville.co.nz)

**Web:** [www.breville.co.nz](http://www.breville.co.nz)

**Breville®**  
Thought for food

Breville is a registered trademark of Breville Pty. Ltd. A.B.N. 98 000 092 928.  
Copyright Breville Pty. Ltd. 2017.

Due to continued product improvement, the products illustrated/photographed  
in this brochure may vary slightly from the actual product.