# HB6231 英语说明书 (Hellobaby)

说明书为折叠式 尺寸: 540\*120MM 材质: 100g双胶纸 (彩色)

版本: V1.0 类型: 环保

版本	修改内容	日期
Ver: 1.0	文件首发。	2022/02/21

5.3 INFRARED NIGHT VISION (AUTOMATIC)

设计	审核	审批
王勇		
2022/02/21		

### - 540.00 mm -

## HelloBaby<sup>®</sup>

## User Manual

2.4GHz Digital Wireless Video Baby Monitor



Model: HB6231

The pictures are for reference only, please subject to practicality.

service@hellobaby.net.cn

Thank you for purchasing the HB6231 Baby Monitor. With our baby monitor, you coul

Please retain your original dated sales receipt for your records. For warranty se

### PLEASE MAKE SURE THE FOLLOWING INCLUDED IN YOUR PACKAGE Parent unit x 1 Camera unit x 1 User manual x 1 Wall-mounting kit x 1

1. SAFETY INSTRUCTIONS
CAUTION: Keep the device away from children.
Strangulation Hazard: Children have STRANGLED in cords. Keep this cord out of the reach children (more than 3ft (0.3m) away). Never use extension cords with AC Adapters. Only us

near vature.

DO NOT the the appliance if the cord or plug is damaged. If your boby monitor is not operating properly or has suffered any damage, contact "Videotimes" service center to request inspection and repair of the appliance in moder to avoid any possible risk.

DO NOT to not attempt to repair or of subjust any of the electrical or mechanical functions of the unit. Otherwise, the graantee will be maded void.

Ventilation. This bely monitor should not be used on a bely, feb, rug or smillar surface that may do look the ventilation openings, to be legical in a enclosed are such as a bolickase or the properties of the control of the properties of the control of the properties of the properties of the control of the properties of the prop

may block the ventilation openings, or he placed in an enclosed area such as a booksase or diverse that may implead a flow.

An experiment of the placed and the placed in the placed and the placed and

1

Note:The High temperature alarm range is 20-40 °C, and the Low temperature alarm

LA ULLARYSTING

Our can souther the baby to sleep by playing a gentle fullaby from the Camera unit.

1. Press the MENU® key and the menu will populy:

2. Press the 4 | P. beg until the fullaby (one) \$\frac{1}{2}\$ by helpfulpted;

3. Press A, 4 \times \ti

range is 0-19 °C. The high temperature alarm default setting is 36 °C, and the low temperature alarm default setting is 8 °C. When the temperature goes above or below the settings, the temperature is one turns real. It will flash to a beet user by audio beeps. Press

4. Press ▲ / ▼ keys to adjust the Lo limit then press ② to confirm.

2. WARRANTY TERMS

### 3.INSTALLATION GUIDELINES

5.IBSTALLATION GUIDLATOR.

Those your parent unit and control unit together, you have to establish a radio.

Those your parent unit and congress unit together, you have to establish a radio.

\*Any large metal object, like a refrigerator, a mirror, a filling cabinet, metallic doos or enindroced concrete between the baby and parent unit may block the radio signal.

\*The signal strength way so be reduced by other solid structures, like walls, or by radio or electrical equipment, such as 1 V. computers, cordies are mobile phanes, flourescent

to electrical equipment, social six youngeries, courses or moone graining, more exemi-lights or dimmer watches.

\*Use of other 2.4GHz product, such as wireless networks (Wi-Fi routers), Bluetooth systems, or microwave overs, may cause interference with this product, so keep the bit monitor away at least 5ft (1.5m) from such products, or turn them off if they cause interferences.

4. PLACEMENT OF THE BABY MONITOR
The camer can be placed on the desktop or mounted on the wall. Don't place baby monito
on soft quiltisor blankets or in the corners of cupboards, shelves, etc; Keep the baby monit
away from heat sources such as radiators, chimneys, cookers and direct sunlight; Keep the
baby unit away from TV sets, microwave oven and radios. If interference occurs, move the

### 5.1 THEN ON THE BARY HAIT

5.1 TURN ON THE BASY UNIT:

1. Insert the Op lug of the power adapter into the DC Jack in the rear of the Baby Unit;

2. Insert the Other end of the power adapter into a suitable electrical outlet;

3. Once the adapter is connected, the power LED will light up;

5.2 TURN ON THE PARKET UNIT:

2


🙀 ----- Signal Strength 🗰 🕬 ----- Volume




@ -----Zoom

The infrared night vision function allows the camera to pick up images in dark or low light conditions. In this mode, only black and white images will be displayed on the

monitor, the optimum image lie in where baby unit is 6ft (2m) away from object. The camera is in night vision mode, the icon (2) will be displayed on the top of screen.





7.1 POWER SAVE / SCREEN OF

Snort press the power ∰ key to tur
7.2 UP ▲ KEY

7.3 DOWN ▼ KEY

7.6 CAMERA VIEW/SCAN

7.a CAMERA VIEW/SCAN
Fress scan §4.ky to view/scan camera: during scan mode, the scan icon® outlible
displayed on the top of screen. Each camera video will be stay on the LCD around 10
seconds: then change to next camera
7.7.DigITAL ZOOM
Fress and bold the §8.key around 2 seconds to operate coom in/out;

7 S TWO WAY TALK Press and hold ∳⇒key to enter two way talk mode. A microphone icon ∲ will be displaye

## 8. MENU OPERATION 8.1 PAIRING THE CAMERA AND PARENT UNITS

4

# **∆WARNING**



Strangulation Hazard: Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9 m) away). Do not remove this tag.

## **AVERTISSEMENT**

DANGER D'ÉTRANGLEMENT: Des enfants se sont ÉTRANGLÉS avec des cordons électriques. Garde le cordonélectrique hors de la portée des enfants (à plus de 0.9m/3 pi du lit d'enfant). Ne pas enlever cette étiquette.



# Note: Camera icon with "\*" means it is well registered. You should select and pair with the

- camer is non-without."\* sign.

  1.1 Ano DCAMED.

  1.1 Press the MENUL® key then the menu will pop un;

  2. Press the "Akyou" p key until the camer a loan \( \begin{align\*} \) this highlighted, then press \( A \) key or

  \( V \) key to select syour desired camers;

  3. Press D(\begin{align\*} \) key to select so one it in its sub-in-equity.

  4. Press \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key to select \( A \) key or

  \( V \) key
- camera;
  6. Once paired, "

  " appears on the LCD screen.
- 7. If falls, repeat the above steps.

  8.1. DELETE CAMERA

  1. Press the MESU © key and the menu will pop up;
  2. Press the 4 key or \* key untit the camera ton is highlighted, then press ▲ key or
  ▼ key to select your desired camera;
  3. Press OR © key, to neter into unb-mou;
- 4. Press ▲ key or ▼ key to select DEL CAM ☐ then press OK ③ key;
  5. Press ▼ key to select ▼ to delete the camera;

- e.a IEMPERATURE UNIT SETTING

  1. Press the (Ø) key and the menu will pop up:
  2. Press the Key vor → key until the temperature Icon
  3. Press & key or ▼ Key to select between F or ℂ;
  5. Press the ፩ key to Confirm;
  5. Press the ፩ key to Exit.

  Walter The deservations.

## 8.3.1 TEMPERATURE ALARM SETTING

- 8.3.1 TMPERATURE ALAMASTITING

  1. Press A | Y vs. piece | See | The head for later setting.

  2. Press A | Y vs. piece | See | The head for later setting.

  2. Press A | Y vs. piece | See | The followed by @ for confirming alarm on or | See | The followed by @ for writching of I sham function.

  8.3.2 STITMPERATURE H/10. ALET LIMITS

  2. Press A | Y vs. piece | See | The followed by @ for piece | See | The followed by @ for piece | See | The followed by @ for piece | See |

- E. S.A.LAMSETING.

  You can use the Parent Unit to set an alarm as a reminder for you to take care of your baby, if an alarm mine is selected, the Parent Unit will beep at the end of the selected hour perior from Semina to dis send before the Seminar End Seminar Seminar
  - Press the (a) key and the menu bar will pop
     Press the ◀ / ▶ keys until (a) is highlighted.
  - (The default brightness level setting is level 3.)

    3.7 VOX SETTING
  - B-YOSKITING

    This mode allows you to contrad the sound activation of your budy unit. If there is no a recent the budy unit within 30 sections, it will stip unit or transmission and turn with the budy unit within 30 sections, it will stip unit or transmission and turn with the budy unit within 30 sections and turn with the section of the budy unit of the section of the section is unit or the section of the s

of the parent unit is off.

The speaker of the paren

### 9. TECHNICAL DATA

Frequency	2403.5MHz*2475.5MHz		
Power Adaptor	Parent Unit: Input: 100-240VAC 50/60Hz Output: 5V DC 1A Camera Unit: Input: 100-240VAC 50/60Hz Output: 5V DC 1A		
Operating Range	Up to 1000ft (300m) outdoor (line of sight) Up to 165ft (50m) indoor		
Display	3.2" Diagonal TFT LCD		
Battery (Parent Unit)	Li-ion 3.7V 950mAh (3.515Wh)		
Battery Life	Up to 6 hours		
Maximum power	< 19d8m		
Operation environment	Operation Temperature: +32F~+104F (0°C-40°C) Battery Charging Temperature: +50F~+104F (10°C-40°C)		
environment	Relative Humidity : 15%-85%		

No reception on the monitor	The power adapters may not be properly connected; Confirm that the camera and monitor are DN; Camera may be far away from the monitor; Camera and monitor may not be properly paired; follow PAIRING instructions,
Interference or poor reception	* Move the monitor close to the camera; * The camera or monitor may be placed too close to many metal objects; * Other electronic devices may be interfering with the signal; * The battery power may be too low;
Audio feedback	* The camera and monitor may be placed too closed;
(high pitched noise)	* The volume on the monitor may be set too high;
Frozen Picture on	<ul> <li>Repower the baby unit (plug out the adapter, then plug it into the</li></ul>
Screen	socket again); <li>Press the RESET key at the back of parent unit;</li>

11. MAINTENANCE nitor with a slightly damp or anti-static cloth.

# Never use cleaning agents or solvents. DISPOSAL GUIDE FOR BATTERY AND PRODUCT Do not attempt to repair or adjust any of the elections.

se personal injury or damage to property. Use only the types of the batteries which are indicated in this manual.

CAUTION: Risk of Fire and Burns. Do Not Open, Crush, Heat Above 45 degree C or Intellege Manual Control of the Cause of the

Follow Menufacturer's instructions.

Opingoal foll batter in fife or a hot over, or mechanically crushing or cutting of a battery that can result in an explosion, that can result in an explosion. I have been a set termely half temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas:

A battery subjected in certimely loval in grease that may sepast in an explosion or the leakage of flammable liquid or gas.

The battery subjected the expressed box and the surrounding environment of the leakage of flammable liquid or gas.

FICCS 1905 Statement
This could be supported to the FICC Bules and with Industry Canada licence-name, the supported coupling with Part 15 of the FICC Bules and with Industry Canada licence-name in case the fill bullet in the following two conditions: (1) bits device many the case the fill bullet ference, and (2) bits device must accept any innerference received, including interference chart may cause undesired operation. Cet apparall set conforms a lab part is 5 dec region de la FICC et au moment \$\$S\$ exemptive (i.e. licence d'industric les long the fill the fill

partie 15 des regles de 16 KC et aux nomes 155 exemptes de licence d'Industric Canela. I florationnement est soumis aux deuxondifishes insulates (116 Legis papirel in del sip a securité protein de l'extra personnement de la legis de l'extra d

## acouraged to try to correct the interference by one ormore of the following measures

device meets the exemption from the routine evaluation limits in section 2.5 of RSS compliance with RSS 102 RF exposure, users can obtain Canadian information on RF 

Middlioth Capacity Statement for careful with minimum distance 20cm between the radiator Ry our body.

Cet dispipement district fair installed are utilised as medistance minimals de 20cm entre le Statement de la comment de la commentation de la commentation de 20cm entre le Statement de la commentation de la comm

assurer la sécurité de toutes les personnes, quel que soit leur âge ou leur état de santé. Information et déclaration d'ISDE sur l'exposition aux RF la limite DAS du Canada (ISDE) est

de 1,6 W / kg en moyenne sur un gramme de tissu. Types d'apparells: la Moniteur a également été testée par rapport à certe limite SAR. Cet appareil à crét exte pour des opportants prépaires de dans été sair le constitue de de da Mondreire paré à d'um de uropé Pour maintain la conformité avec les origences d'expositions Ref d'EDE, quillice des conscessoires qui maintainent une distance de éparation de d'um entre le corps de constitue de la violence de la Mondreire de la Mondreire L'utilisation de clip de celetrure, d'étui et d'un de la commande de la Mondreire de la Mondreire de composants mediques dans son assemblage. L'utilisation d'accessiories qui me satisfort pas à ces exigences peut ne par être conforme aux exigences de deposition aux de 1950s et double de voile de la Mondreire aux prépareires de despersais de la maisse de la mai

Directive 2014/53/EU. The full text of the EU declaration of conformity is available on the website:

### Risk Group 1 WARNING IR emitted from this product. Do not stare at operating lamp

Product tested against EN62471