

Please make sure the USB-C port of your smart phone/Tablet/ Laptop supports the Display Port Alternate Mode, and the USB-C port is USB 3.1 Type-C (Gen2) or Thunderbolt 3 port (supports PD charging) before purchasing. Otherwise, your PC will not get output video signal.

Strong Compatible List (Not full list)	
HP	<ul style="list-style-type: none"> <li>Elitebook ( X360 1030 G3/ 735 G6/ 745 G5/ 800 G4/ 830 G5/ 840 G5 series/ 840g8/g7g6/850</li> <li>G5/ 850 G7/ 850 G8/ 845 G7/ 840 G8/ 845 G8/ 830 G6/ X2/ 745 )</li> <li>Envy ( Geforce MX250/ 17T/ X360/ 13-AQ1/ 13t-ba100/ 113-aq001ms/ 17m-ae011dx)</li> <li>Spectre ( 13/ 360/ X360- 13T/ 15T/ X369/ 13T-AK000CTO/ AF001TU )</li> <li>Zbook ( 15U G3/ 17 G4/ 14U G6/ 15 G5/G6/ 16 G6/ Studio Z5 )</li> <li>Probook ( 440 G7/ 450 g5/ 450 G6/ 450 G7/ 640 G5/ 650 G5 )</li> <li>Chromebook 11A G6 EE/ 14a-na0122od/ Omen laptops/ GTX 4 Pro15.6</li> </ul>
Dell	<ul style="list-style-type: none"> <li>Latitude ( 3310 2 in 1/ 3400/ 3410/ 3420/ 3490/ 3500/ 5290/ 5310/ 5320/ 5400/5410/5420/ 5480/ 5490/ 5491/ 5500/ 5521/ 5530/ 5580/ 5591/ 7280/ 7300 series/ 7370/7389/7390/ 7400/ 7410/ 7420/ 7430/ 7480/ 7490 )</li> <li>XPS ( 5590/ 9350/ 9380/ 13/ 13-9300/ 13 9305/ 13-9365/ 15/ 15-2018/ 15-9500)</li> <li>Precision ( 3561/ 3571/ 5520/ 5530/ 5540/ 5550/ 5560/ 7520/ 7730/ 7750 )</li> <li>Inspiron ( 5402/ 5590/ 7300/ 13 7300/ 7373/ 7573/ 14 or 15 7000 series 2-in- 1/ 155515)</li> <li>Dell G7 7790/ Dell G15- 5511/ Dell 17 9700/ Vostro 5620/Dell Vostro 15 5510</li> </ul>
Lenovo	<ul style="list-style-type: none"> <li>Yoga ( 370/ 720/ 730/ 900/ 910/ 920/ 930/ 940/ C740/ C930/ 15 UltrabookPro/613ALC6/ 7 14ial7/ 7i/9i )</li> <li>ThinkPad ( P1 Gen2/ p15v gen 2/ T14 Gen 1 and 2/ T15p gen 1/ P50/ P52/ P70/P72/ E14 / E590/ T470/ T470s/ T480s/ T490s/ 81N8/ Y530/ Y720/ X390/ X1 Carbon/X1Extreme/I490 )</li> <li>IdeaPad ( 330s/ C330/ Slim7 Pro/ s540/ 720S/581yk006xus )</li> <li>Legion ( Y 530/ 5i pro gen 7/ 5- 17-82GN0000US )</li> </ul>
Microsoft Surface	<ul style="list-style-type: none"> <li>laptop ( 3/4 )</li> <li>Pro ( 8/ 7/ 5/ X )</li> <li>Book 2/ Go- 1943</li> </ul>
Asus	<ul style="list-style-type: none"> <li>Zenbook ( UX330UA/ Flip UX370U/ Q529ZA/ UX435/ UX434F/ UX433FA/ UX425EA/3-UX390/ UX434FLC-AI284R/ 14 UX433FA )</li> <li>TUF Gaming A15 Gaming Laptop/ Zephyrus G14/ G15/ Rog GX501</li> </ul>
Acer	<ul style="list-style-type: none"> <li>aspirec ( 5/5 a515-57-760x laptop/ C24-865)</li> <li>Swift ( 1/ 3/ 7/ X )</li> <li>SPIN ( 5/ 7 )</li> <li>Predator Helios 300</li> </ul>
Samsung	<ul style="list-style-type: none"> <li>Note ( 20/ 10/ 9 /8+ )</li> <li>Galaxy ( S20 ultra/ 10+/ S10/ S9+/ S9/ S8+/ Tablet S4/ S5e/ New S7/</li> <li>Chromebook/Flexalpha 2-in- 1 )</li> </ul>
Huawei	<ul style="list-style-type: none"> <li>MateBook ( X Pro/ E/ X/ Mate10/ 10Pro/ Mate20/ Mate20 Pro/ Mate30/ 30Pro/P20/ P20 Pro/ P30 Pro/ 13 )</li> </ul>
Mac (Not Support MST)	<ul style="list-style-type: none"> <li>MacBook/ Pro ( 2016-2021 )/ MacBook Air/ Mac mini ( 2018-2020 )</li> <li>iMac Pro ( 2017-2019 )/ iMac ( 2020 )/ iPad/ Pro ( 2018- Newest )</li> </ul>
other	<ul style="list-style-type: none"> <li>Pixel ( 2016/ 2017 )/C340-15/ Google Slate</li> </ul>

## INCOMPATIBILITY Devices ( Not a full list )

HP	<ul style="list-style-type: none"> <li>◆ All HP Pavillion Laptop</li> <li>◆ Spectre ( X360 13/ 14/ 15T )</li> <li>◆ Elitebook ( 745 G3/ 745 G6/ 755 G5/ 800 G2 / 820 G3/ 820 G4/ 840 G3/ 840G4/850G4 )</li> <li>◆ Probook ( 600/ 640/ 650 G2/ 650 G3 )</li> <li>◆ Laptop ( 15-dy1xxx/ 15-dy2xxx/ 15t-dy100/ 15t-dy200/ 15-dy1059ms/ 15-dw3XXX/ 15-dw2025od/ 14-dq1033cl/ 14-dq2045cl/ 15-ef2xxx/ 17-by3613dx/ 17-cn1008cy/ PC15s-fq2000(2D119AV)/ 15-dw3097nr/ 15s-fq200/ 17-by1xxx/ 15-EF1001DS/ 17-by2053cl/17z-cp000 )</li> <li>◆ Inspiron 14 5000 Series/ Levano Ideapad 1 15.6" FHD Touch Screen Laptop/ Folio1020B&amp;O/ 17-cn0053cl/ 17-cn0275st/ 15-ef1072nr/ 15-ef0xx</li> <li>◆ Earlier Pavilion series/ 2020 HP 14/ newer HP Envy 15/ 340S G7/ EVGASC15/ 17.3in Full HD Notebook/ prodesk 600 G2/ envy x360 15m-bp- 112dx/ Notebook15-dy1071wm/ Notebook 15-dy1043dx</li> <li>◆ Model ( 17t-by300/ 15-dy1076nr/ 15-dw2025cl/ 15-y1751ms/ 15-dw0037wm/ 14-dq1033cl/ 14-dq0005cl/ 15EF1300WM)</li> </ul>
Dell	<ul style="list-style-type: none"> <li>◆ Inspiron ( 17-5000 series / 15-5000 series, 14-5410, 15-3000/3583,17-3793Business,7000 Gaming, Vostro MT 3671 )</li> <li>◆ Latitude ( E7270,E7470, E7440,E7450,3520 )</li> </ul>
Lenovo	<ul style="list-style-type: none"> <li>◆ YOGA ( 710-15ikb/ 520 )</li> <li>◆ ThinkPad ( I490/ E580 )</li> <li>◆ IdeaPad ( 3/ 5/ 3- 15itl6/ 330/ L340/ S340/ 130S/ Flex-15IWL/ Flex-14"/ 15.6" 2-in- 1/Flex 5- 1570/ Flex 5 14itl05/ Flex 5 15IIL05/ Flex-6 14IKB/ Flex 15 iml)</li> <li>◆ V330/ T570/ Y520/ 710/ model 81we0016us/ Thinkbook 15P</li> </ul>
Microsoft Surface	<ul style="list-style-type: none"> <li>◆ Surface Pro 3/ 4/ 6</li> <li>◆ book 3</li> </ul>
Asus	<ul style="list-style-type: none"> <li>◆ Vivobook series/ Q547/ Q503U/ Q526F/ L203MA/ TUF 17.3 Gaming Laptop</li> <li>◆ Zenbook ( UX333FN/ UX330UA-AH55/ Flip 14 UX461FN-DH74T/ Flip 14UX463FL/Q407I )</li> </ul>
Acer	<ul style="list-style-type: none"> <li>◆ E5-575/ R5-571T/ E5-576G/ R15/ G3-571/ Predator Helios 300/ Swift X 14</li> </ul>
Samsung	<ul style="list-style-type: none"> <li>◆ Galaxy Tab 5 / A50 / A51-5G</li> </ul>
Huawei	<ul style="list-style-type: none"> <li>◆ Matebook 14 / Mediapad M5 lite</li> </ul>
Apple	<ul style="list-style-type: none"> <li>◆ Macbook Air ( before 2018 )/ MacBook Pro 2015/ iMac 2021</li> </ul>
other	<ul style="list-style-type: none"> <li>◆ Redmi Note 7/VA912/ VA912 Series 4/ VA912B/satellite P25wc/ Radius P55W- B5224</li> <li>◆ High-power equipment/ USB Super Drive/ CD/ DVD player</li> </ul>