


**Transcend Elite App Download**


\* For Android version 4.0 or later.

\* This product is not supported on Windows phones.

## RDP9 Compatibility list

Compatibility		Compatible with conditions		Incompatibility	
Acer	ICONIA A1-810	ASUS	MeMO Pad ME301T	Acer	Tablet Iconia B1-A71
	ICONIA W3-810		PadFone Infinity	ASUS	PadFone 2
Samsung	Galaxy Tab 3 8.0 (SM-T310)	HTC	One M8	Google	Nexus 7
	Galaxy Tab PRO 10.1		Desire 600 (606h)	G-PLUS	X805
	Galaxy S5 (SM-G900I)		One (802W) CHINA 3G	HTC	Butterfly J
	Galaxy Note Pro 12.2	HUAWEI	Butterfly S	HUAWEI	HONOR 3C (H30-T10)
	Galaxy Note 3		MEDIAPAD 7 LITE	Samsung	Galaxy Ace 3 (GT-S7270)
	GALAXY Note 10.1	LG	OPTIMUS G PRO		Galaxy Core
	Galaxy S4 (I9500/I9505)		Optimus G2		Galaxy Grand 2 (SM-G7102)
	Galaxy Mega 6.3 (GT-I9200)	MSI	PRIMO 81		Galaxy Grand Neo (GT-I9060)
	Galaxy S4		Galaxy S2		Galaxy Mega 5.8 (GT-I9152)
	Galaxy S3	Samsung	GALAXY Note 2		Galaxy Premier (GT-I9260)
Galaxy S4 zoom (SM-C101)	Galaxy S2 Plus		Galaxy Win		
Galaxy Tab PRO 8.4	SONY		Xperia Z1	Galaxy S4 mini (GT-I9190)	
		Xperia VL	Galaxy Tab 7.7 PLUS (SC-01E)		
		Xperia TX (LT29T)	Galaxy Premier I9260		
		XPERIA Tablet Z (SGP311TW)	SONY	Xperia T	
	Xperia AX	Xperia Z			
	Xperia Acro S				
	Xperia Z Ultra				
	TCL	Y900			
	XIAOMI	Redmi			

Please follow the steps and precautions below to ensure optimum function:

1. Please insert the external storage device into the card reader, and then connect the reader to the smart-phone/tablet.
2. To change the storage device, please remove the card reader first; change the storage device and then reconnect the card reader to the smartphone/tablet.
3. The reader does not support simultaneous insertion of two cards.
4. When data transfer is in progress, please do not remove other storage devices on the reader.