

## TP-Link Archer C4000

Please follow the steps below to set up your TP-Link Archer C4000.

1. Ensure your **NBN Connection Box** is turned on.
2. Plug an Ethernet cable from the **UNI-D1 port** on your NBN Connection Box into the **blue Internet port** on your TP-Link modem.  
If UNI-D1 doesn't work, try each UNI-D port.



3. Plug in the power cable and turn your TP-Link modem on using the **Power** button.



4. You can connect devices such as PC desktops, laptops or gaming consoles by plugging Ethernet cables from the device to any of the four **yellow Ethernet ports**, or you can connect devices via WiFi.



5. Go to **http://192.168.0.1** in your browser.

6. Log in with your TP-Link modem username and password.  
By default, these are:  
**Username:** admin  
**Password:** admin
7. Select **Advanced, Network** then **Internet**.
8. Select **PPPoE** from **Internet Connection Type**.
9. Enter your **TPG username** and **password**.
10. Click **Save**.

Once you receive notification that your TPG NBN service is active, your TP-Link Archer C4000 should now be online. If you are still having issues, please call us on **1300 997 271** for further assistance.