



List for Passive holder with tilt swivel | Passive holder | Active holder with cig-plug | Active holder for fixed installation | Holder with lock. | Holder for Locking | MultiStand | Table Stand | Holder for Cable Attachment | Device Mounting Adapter | Monitor Mount. | Mount | Tough Sleeve | Active holder with USB-cable and cig-plug adapter | Charging Cable

### Passive holder with tilt swivel



Item no 216018

**Passive holder with tilt swivel (For all countries)**

Headrest mount with adjustable holder. With MoveClip. Fits devices with/without skin/case with height 120-150 mm and max thickness 25 mm. Fits headrests with minimum inner size 95 mm and max outer size 211 mm between the bars.



Item no 216019

**Passive holder with tilt swivel (For all countries)**

Headrest mount with adjustable holder. With MoveClip. Fits devices with/without skin/case with height 140-195 mm and max thickness 25 mm. Fits headrests with minimum inner size 95 mm and max outer size 211 mm between the bars.



Item no 216020

**Passive holder with tilt swivel (For all countries)**

Headrest mount with adjustable holder. With MoveClip. Fits devices with/without skin/case with height 180-230 mm and max thickness 25 mm. Fits headrests with minimum inner size 95 mm and max outer size 211 mm between the bars.



Item no 511244

**Passive holder with tilt swivel - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**



Item no 511244

**Passive holder with tilt swivel - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**



Item no 511244

**Passive holder with tilt swivel - Apple iPad With Retina (Lightning Connector) (For all countries)**



Item no 511244  
Passive holder with tilt swivel - Apple iPad 3rd Gen (A1416, A1430, A1403)  
(For all countries)



Item no 511300  
Passive holder with tilt swivel - Samsung Galaxy Tab 8.9 GT-P7300 (For all countries)



Item no 511317  
Passive holder with tilt swivel - Kindle Fire (For all countries)



Item no 511317  
Passive holder with tilt swivel - Amazon Kindle Fire (For all countries)



Item no 511329  
Passive holder with tilt swivel - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)



Item no 511329  
Passive holder with tilt swivel - Samsung Galaxy Tab 10.1 SCH-I905 (For USA)



Item no 511361  
Passive holder with tilt swivel - Samsung Galaxy Tab 7.7 GT-P6800 (For all countries)



Item no 511365  
Passive holder with tilt swivel - Dell Latitude ST 10,1" (For all countries)



Item no 511381

Passive holder with tilt swivel - Samsung Galaxy Tab 2 7.0 (For all countries)

---



Item no 511381

Passive holder with tilt swivel - Samsung Galaxy Tab 7.0 Plus GT-P6200 (For all countries)

---



Item no 511385

Passive holder with tilt swivel - Huawei MediaPad (For all countries)

---



Item no 511385

Passive holder with tilt swivel - Huawei MediaPad S7-301u (For all countries)

---



Item no 511412

Passive holder with tilt swivel - Asus Google Nexus 7 (For all countries)

---



Item no 511412

Passive holder with tilt swivel - Nexus 7 (For all countries)

---



Item no 511412

Passive holder with tilt swivel - Google Nexus 7 (For all countries)

---



Item no 511415

Passive holder with tilt swivel - Samsung Galaxy Tab 2 10.1 (For all countries)



Item no 511421  
Passive holder with tilt swivel - Kindle Fire HD 7.0 (For all countries)



Item no 511421  
Passive holder with tilt swivel - Amazon Kindle Fire HD 7.0 (For all countries)



Item no 511446  
Passive holder with tilt swivel - Microsoft Surface 2 (For all countries)



Item no 511446  
Passive holder with tilt swivel - Microsoft Surface (For all countries)



Item no 511470  
Passive holder with tilt swivel - Amazon Kindle Fire HD 8.9 LTE (For all countries)



Item no 511470  
Passive holder with tilt swivel - Kindle Fire HD 8.9 (For all countries)



Item no 511470  
Passive holder with tilt swivel - Kindle HD 8.9 LTE (For all countries)



Item no 511470  
Passive holder with tilt swivel - Amazon Kindle Fire HD 8.9 (For all countries)



Item no 511492  
Passive holder with tilt swivel - HP ElitePad 1000 10.1 (For all countries)



Item no 511492  
Passive holder with tilt swivel - HP ElitePad 900 10.1 (For all countries)



Item no 511505  
Passive holder with tilt swivel - HP ElitePad 1000 10.1 (For all countries)  
For device with Expansion Jacket H4J85AA.



Item no 511505  
Passive holder with tilt swivel - HP ElitePad 900 10.1 (For all countries)  
For device with Expansion Jacket H4J85AA.



Item no 511537  
Passive holder with tilt swivel - HP ElitePad 1000 10.1 (For all countries)  
For device with Expansion Jacket F5A38AA.



Item no 511537  
Passive holder with tilt swivel - HP ElitePad 900 10.1 (For all countries)  
For device with Expansion Jacket F5A38AA.



Item no 511538  
Passive holder with tilt swivel - Sony Xperia Tablet Z (For all countries)



Item no 511543  
Passive holder with tilt swivel - Samsung Galaxy Tab 3 7.0 SM-T210 (For all countries)



Item no 511543

Passive holder with tilt swivel - Samsung Galaxy Tab 3 7.0 SM-T2110 (For all countries)

---



Item no 511548

Passive holder with tilt swivel - Samsung Galaxy Tab 3 8.0 SM-T310 (For all countries)

---



Item no 511548

Passive holder with tilt swivel - Samsung Galaxy Tab 3 8.0 SM-T315 (For all countries)

---



Item no 511549

Passive holder with tilt swivel - Samsung Galaxy Tab 3 10.1 GT-P5220 (For all countries)

---



Item no 511549

Passive holder with tilt swivel - Samsung Galaxy Tab 3 10.1 GT-P5210 (For all countries)

---



Item no 511549

Passive holder with tilt swivel - Samsung Galaxy Tab 3 10.1 GT-P5200 (For all countries)

---



Item no 511554

Passive holder with tilt swivel - Pidion BP50 (For all countries)

---



Item no 511560

Passive holder with tilt swivel - Google Nexus 7 (2013) (For all countries)

---



Item no 511560

Passive holder with tilt swivel - Asus Google Nexus 7 (2013) (For all countries)



Item no 511560  
Passive holder with tilt swivel - Nexus 7 (2013) (For all countries)



Item no 511577  
Passive holder with tilt swivel - Apple iPad 9.7 New (For all countries)



Item no 511577  
Passive holder with tilt swivel - Apple iPad Air (A1474, A1475, A1476) (For all countries)



Item no 511577  
Passive holder with tilt swivel - Apple iPad 5th Gen (A1822, A1823) (For all countries)



Item no 511577  
Passive holder with tilt swivel - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)



Item no 511579  
Passive holder with tilt swivel - Dell Venue 8 Pro (For all countries)



Item no 511584  
Passive holder with tilt swivel - Apple iPad Mini Retina (For all countries)



Item no 511584  
Passive holder with tilt swivel - Apple iPad Mini (A1432, A1454, A1455) (For all countries)



Item no 511584  
Passive holder with tilt swivel - Apple iPad Mini 2 (A1489, A1490, A1491) (For all countries)



Item no 511584  
Passive holder with tilt swivel - Apple iPad Mini 3 (A1599, A1600) (For all countries)



Item no 511598  
Passive holder with tilt swivel - Samsung Galaxy Note 10.1 (2014 Edition) SM-P6050 (For all countries)



Item no 511598  
Passive holder with tilt swivel - Samsung Galaxy Note 10.1 (2014 Edition) SM-P6000 (For all countries)



Item no 511600  
Passive holder with tilt swivel - Apple iPad 9.7 New (For all countries)  
For Otterbox Defender Series.



Item no 511600  
Passive holder with tilt swivel - Apple iPad Air (A1474, A1475, A1476) (For all countries)  
For Otterbox Defender Series.



Item no 511600  
Passive holder with tilt swivel - Apple iPad 5th Gen (A1822, A1823) (For all countries)  
For Otterbox Defender Series.



Item no 511600  
Passive holder with tilt swivel - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)  
For Otterbox Defender Series.





Item no 511608  
Passive holder with tilt swivel - Samsung Galaxy Tab PRO 10.1 LTE SM-T525  
(For all countries)



Item no 511608  
Passive holder with tilt swivel - Samsung Galaxy Tab PRO 10.1 SM-T520 (For all countries)



Item no 511610  
Passive holder with tilt swivel - Samsung Galaxy Tab PRO 12.2 Wi-Fi SM-T900  
(For all countries)



Item no 511610  
Passive holder with tilt swivel - Samsung Galaxy Note PRO 12.2 Wi-Fi SM-P900 (For all countries)



Item no 511610  
Passive holder with tilt swivel - Samsung Galaxy Tab PRO 12.2 4G SM-T905  
(For all countries)



Item no 511610  
Passive holder with tilt swivel - Samsung Galaxy Note PRO 12.2 4G SM-P905  
(For all countries)



Item no 511614  
Passive holder with tilt swivel - Dell Venue 11 Pro, New (Model 7140) (For all countries)



Item no 511614  
Passive holder with tilt swivel - Dell Venue 11 Pro (Model 5130) (For all countries)



Item no 511616  
Passive holder with tilt swivel - Samsung Galaxy Tab PRO 8.4 SM-T320 (For all countries)

---



Item no 511616  
Passive holder with tilt swivel - Samsung Galaxy Tab PRO 8.4 SM-T325 (For all countries)

---



Item no 511632  
Passive holder with tilt swivel - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)

---



Item no 511632  
Passive holder with tilt swivel - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)

---



Item no 511632  
Passive holder with tilt swivel - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)

---



Item no 511637  
Passive holder with tilt swivel - Samsung Galaxy Tab 4 8.0 SM-T335 (For all countries)

---



Item no 511644  
Passive holder with tilt swivel - Microsoft Surface Pro 3 (For all countries)

---



Item no 511652  
Passive holder with tilt swivel - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)



Item no 511652  
Passive holder with tilt swivel - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)



Item no 511653  
Passive holder with tilt swivel - Samsung Galaxy Tab S 10.5 SM-T805 (For all countries)



Item no 511653  
Passive holder with tilt swivel - Samsung Galaxy Tab S 10.5 SM-T800 (For all countries)



Item no 511655  
Passive holder with tilt swivel - Sony Xperia Z2 Tablet (For all countries)



Item no 511672  
Passive holder with tilt swivel - Dell Venue 8 Pro (For all countries)  
For device with Targus SafePORT Rugged Max Pro protective case.



Item no 511676  
Passive holder with tilt swivel - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)  
Fits for devices with original skin.



Item no 511680  
Passive holder with tilt swivel - Toughshield T700 (For all countries)  
Fits for devices with original skin.



Item no 511684  
Passive holder with tilt swivel - Apple iPad Pro 9.7 (A1673, A1674, A1675) (For all countries)



Item no 511684  
Passive holder with tilt swivel - Apple iPad Air 2 (A1566, A1567) (For all countries)

---



Item no 511692  
Passive holder with tilt swivel - Sony Xperia Z3 Tablet Compact (For all countries)

---



Item no 511695  
Passive holder with tilt swivel - HTC Nexus 9 (For all countries)

---



Item no 511695  
Passive holder with tilt swivel - Nexus 9 (For all countries)

---



Item no 511717  
Passive holder with tilt swivel - Apple iPad Mini 3 (A1599, A1600) (For all countries)  
For Otterbox Defender series.

---



Item no 511725  
Passive holder with tilt swivel - Dell Venue 11 Pro (Model 5130) (For all countries)  
For device with Targus SafePORT Rugged Max Pro protective case.

---



Item no 511734  
Passive holder with tilt swivel - Microsoft Surface 3 (For all countries)

---



Item no 511737  
Passive holder with tilt swivel - Samsung Galaxy Tab A 9.7 (For all countries)



Item no 511754  
Passive holder with tilt swivel - Samsung Galaxy Tab A 8.0 (2015) SM-T350  
(For all countries)



Item no 511781  
Passive holder with tilt swivel - Samsung Galaxy Tab S2 8.0 SM-T713 /SM-T719 (For all countries)



Item no 511782  
Passive holder with tilt swivel - Samsung Galaxy Tab S2 9.7 SM-T810/SM-T813/SM-T815/SM-T819 (For all countries)



Item no 511793  
Passive holder with tilt swivel - Apple iPad Mini 2019 (For all countries)



Item no 511793  
Passive holder with tilt swivel - Apple iPad Mini 5th Gen (A2124, A2125, A2126, A2133) (For all countries)



Item no 511793  
Passive holder with tilt swivel - Apple iPad Mini 4 (A1538, A1550) (For all countries)



Item no 511799  
Passive holder with tilt swivel - HP Pro Tablet 608 (For all countries)



Item no 511816  
Passive holder with tilt swivel - Microsoft Surface Pro 6 (For all countries)



Item no 511816  
Passive holder with tilt swivel - Microsoft Surface Pro 7 (For all countries)



Item no 511816  
Passive holder with tilt swivel - Microsoft Surface Pro 4 (For all countries)



Item no 511816  
Passive holder with tilt swivel - Microsoft Surface PRO 2017 (For all countries)



Item no 511820  
Passive holder with tilt swivel - Apple iPad Pro 12.9 (A1584, A1652, A1670, A1671) (For all countries)



Item no 511821  
Passive holder with tilt swivel - Samsung Galaxy Tab E 9.6 (For all countries)



Item no 511822  
Passive holder with tilt swivel - LG G Pad F 8.0 (For all countries)



Item no 511835  
Passive holder with tilt swivel - Samsung Galaxy Tab E 8.0 (For all countries)



Item no 511838  
Passive holder with tilt swivel - Samsung Galaxy Tab 3 Lite (For all countries)



Item no 511856  
Passive holder with tilt swivel - Dell Venue 8 Pro NEW (Model 5855) (For all countries)



Item no 511859  
Passive holder with tilt swivel - Sony Xperia Z4 Tablet (For all countries)



Item no 511871  
Passive holder with tilt swivel - Huawei MediaPad T1 8.0 (For all countries)



Item no 511897  
Passive holder with tilt swivel - Samsung Galaxy Tab A 7.0 (2016) SM-T280/SM-T285 (For all countries)



Item no 511916  
Passive holder with tilt swivel - Microsoft Surface 3 (For all countries)  
Reinforced, tougher side supports for extra secure fit.



Item no 511919  
Passive holder with tilt swivel - Samsung Galaxy Tab A 10.1 (2016) SM-T580/SM-T585 (For all countries)



Item no 511938  
Passive holder with tilt swivel - Lenovo Tab 3 7 (For all countries)



Item no 511968  
Passive holder with tilt swivel - Samsung Galaxy Tab S3 9.7 SM-T820/SM-T825 (For all countries)



Item no 511990  
Passive holder with tilt swivel - Huawei MediaPad T3 8.0 (For all countries)



Item no 530480  
Passive holder with tilt swivel - Getac Z710 (EU Version) (For all countries)  
Fits unit both with and without handstrap.



Item no 530480  
**Passive holder with tilt swivel - Getac Z710 (US Version) (For all countries)**  
Fits unit both with and without handstrap.

---



Item no 711018  
**Passive holder with tilt swivel - LG G Pad F2 8.0 (For all countries)**

---



Item no 711077  
**Passive holder with tilt swivel - Samsung Galaxy Tab S4 10.5 SM-T830/SM-T835 (For all countries)**

---



Item no 711079  
**Passive holder with tilt swivel - Samsung Galaxy Tab A 10.5 SM-T590/SM-T595 (For all countries)**

---



Item no 711094  
**Passive holder with tilt swivel - Apple iPad Pro 11 2018 (A1980, A2013, A1934, A1979) (For all countries)**

---



Item no 711094  
**Passive holder with tilt swivel - Apple iPad Pro 11 2021 3rd Generation (A2301, A2459) (For all countries)**

---



Item no 711094  
**Passive holder with tilt swivel - Apple iPad Air 4th Gen (A2072, A2316, A2324, A2325) (For all countries)**

---



Item no 711094  
**Passive holder with tilt swivel - Apple iPad Pro 11 2020 2nd Generation (A2068, A2230) (For all countries)**

---



Item no 711095  
**Passive holder with tilt swivel - Apple iPad Pro 12.9 2020 (A2069, A2232, A2229) (For all countries)**

---



Item no 711095  
**Passive holder with tilt swivel - Apple iPad Pro 12.9 (5th Gen 2021) (For all countries)**

---





Item no 711095  
Passive holder with tilt swivel - Apple iPad Pro 12,9 2018 (A1876, A1895, A1983, A2014) (For all countries)



Item no 711114  
Passive holder with tilt swivel - Huawei MediaPad M5 8.4 (For all countries)



Item no 711125  
Passive holder with tilt swivel - Samsung Galaxy Tab S5e 10.5 SM-T720/SM-T725 (For all countries)



Item no 711132  
Passive holder with tilt swivel - Samsung Galaxy Tab A 10.1 (2019) SM-T510/SM-T515 (For all countries)



Item no 711148  
Passive holder with tilt swivel - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)  
Fits for devices with original skin.



Item no 711162  
Passive holder with tilt swivel - Samsung Galaxy Tab A 8.0 (2019) SM-T290/SM-T295 (For all countries)



Item no 711163  
Passive holder with tilt swivel - Huawei MediaPad M5 Lite 8" (For all countries)



Item no 711166  
Passive holder with tilt swivel - Samsung Galaxy Tab S6 10.5 SM-T860/SM-T865 (For all countries)



Item no 711168  
Passive holder with tilt swivel - Apple iPad 10.2 9th Gen (A2602, A2603, A2604, A2605) (For all countries)



Item no 711168  
Passive holder with tilt swivel - Apple iPad 10.2 7th Gen (A2197, A2198, A2200) (For all countries)



Item no 711168  
Passive holder with tilt swivel - Apple iPad 10.2 8th Gen (A2428, A2429, A2430, A2270) (For all countries)



Item no 711182  
Passive holder with tilt swivel - Samsung Galaxy Tab S7 FE SM-T733 (For all countries)  
With pen holder.



Item no 711193  
Passive holder with tilt swivel - Samsung Galaxy Tab A 8.4 (2020) SM-T307 (For all countries)



Item no 711211  
Passive holder with tilt swivel - Samsung Galaxy Tab S6 Lite SM-P610/SM-P615 (For all countries)



Item no 711229  
Passive holder with tilt swivel - Samsung Galaxy Tab A7 10.4 (2020) SM-T500/SM-T505 (For all countries)



Item no 711264  
Passive holder with tilt swivel - Samsung Galaxy Tab A7 Lite SM-T220/SM-T225 (For all countries)



Item no 711270  
Passive holder with tilt swivel - Lenovo Tab M8 HD TB-8505X (Micro-USB) (For all countries)



Item no 711270  
Passive holder with tilt swivel - Lenovo Tab M8 HD TB-8505XC (USB Type-C) (For all countries)



Item no 711271  
Passive holder with tilt swivel - Lenovo Tab K10 TB-X6C6F (For all countries)



Item no 711278  
Passive holder with tilt swivel - Apple iPad Mini 6th Gen (A2567, A2568, A2569) (For all countries)



Item no 711286

**Passive holder with tilt swivel - Samsung Galaxy Tab A8 SM-X200/205 (For all countries)**

### Passive holder



Item no 710285

**Passive holder - Honeywell RT10 (For all countries)**

Fits devices with and without handstrap. With AMPS, Vesa 75 holes.



Item no 710287

**Passive holder - Getac F110 6th Gen (For all countries)**

Fits devices with and without handstrap. With AMPS, Vesa 75/100 holes.

### Active holder with cig-plug



Item no 512209

**Active holder with cig-plug - Samsung Galaxy Tab GT-P1000 (For all countries)**

With tilt swivel.



Item no 512300

**Active holder with cig-plug - Samsung Galaxy Tab 8.9 GT-P7300 (For all countries)**

With tilt swivel.



Item no 512329

**Active holder with cig-plug - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)**

With tilt swivel.



Item no 512329

**Active holder with cig-plug - Samsung Galaxy Tab 10.1 SCH-I905 (For USA)**

With tilt swivel.



Item no 512361

**Active holder with cig-plug - Samsung Galaxy Tab 7.7 GT-P6800 (For all countries)**

With tilt swivel.



Item no 512381  
**Active holder with cig-plug - Samsung Galaxy Tab 2 7.0 (For all countries)**  
With tilt swivel.

---



Item no 512381  
**Active holder with cig-plug - Samsung Galaxy Tab 7.0 Plus GT-P6200 (For all countries)**  
With tilt swivel.

---



Item no 512385  
**Active holder with cig-plug - Huawei MediaPad (For all countries)**  
With tilt swivel.

---



Item no 512385  
**Active holder with cig-plug - Huawei MediaPad S7-301u (For all countries)**  
With tilt swivel.

---



Item no 512412  
**Active holder with cig-plug - Asus Google Nexus 7 (For all countries)**  
With tilt swivel.

---



Item no 512412  
**Active holder with cig-plug - Nexus 7 (For all countries)**  
With tilt swivel.

---



Item no 512412  
**Active holder with cig-plug - Google Nexus 7 (For all countries)**  
With tilt swivel.

---



Item no 512415  
**Active holder with cig-plug - Samsung Galaxy Tab 2 10.1 (For all countries)**  
With tilt swivel.

---



Item no 512535  
**Active holder with cig-plug - Samsung Galaxy Note 8.0 GT-N5110 (For all countries)**  
With tilt swivel.



Item no 512535

**Active holder with cig-plug - Samsung Galaxy Note 8.0 GT-N5120 (For all countries)**

With tilt swivel.

---



Item no 512538

**Active holder with cig-plug - Sony Xperia Tablet Z (For all countries)**

With tilt swivel.

---



Item no 512543

**Active holder with cig-plug - Samsung Galaxy Tab 3 7.0 SM-T2110 (For all countries)**

With tilt swivel.

---



Item no 512543

**Active holder with cig-plug - Samsung Galaxy Tab 3 7.0 SM-T210 (For all countries)**

With tilt swivel.

---



Item no 512548

**Active holder with cig-plug - Samsung Galaxy Tab 3 8.0 SM-T310 (For all countries)**

With tilt swivel.

---



Item no 512548

**Active holder with cig-plug - Samsung Galaxy Tab 3 8.0 SM-T315 (For all countries)**

With tilt swivel.

---



Item no 512549

**Active holder with cig-plug - Samsung Galaxy Tab 3 10.1 GT-P5220 (For all countries)**

With tilt swivel.

---



Item no 512549

**Active holder with cig-plug - Samsung Galaxy Tab 3 10.1 GT-P5210 (For all countries)**

With tilt swivel.



Item no 512549  
**Active holder with cig-plug - Samsung Galaxy Tab 3 10.1 GT-P5200 (For all countries)**  
With tilt swivel.

---



Item no 512554  
**Active holder with cig-plug - Pidion BP50 (For all countries)**  
With tilt swivel.

---



Item no 512560  
**Active holder with cig-plug - Google Nexus 7 (2013) (For all countries)**  
With tilt swivel.

---



Item no 512560  
**Active holder with cig-plug - Asus Google Nexus 7 (2013) (For all countries)**  
With tilt swivel.

---



Item no 512560  
**Active holder with cig-plug - Nexus 7 (2013) (For all countries)**  
With tilt swivel.

---



Item no 512579  
**Active holder with cig-plug - Dell Venue 8 Pro (For all countries)**  
With tilt swivel.

---



Item no 512598  
**Active holder with cig-plug - Samsung Galaxy Note 10.1 (2014 Edition) SM-P6050 (For all countries)**  
With tilt swivel.

---



Item no 512598  
**Active holder with cig-plug - Samsung Galaxy Note 10.1 (2014 Edition) SM-P6000 (For all countries)**  
With tilt swivel.



Item no 512608  
**Active holder with cig-plug - Samsung Galaxy Tab PRO 10.1 LTE SM-T525  
(For all countries)**  
With tilt swivel.

---



Item no 512608  
**Active holder with cig-plug - Samsung Galaxy Tab PRO 10.1 SM-T520 (For all countries)**  
With tilt swivel.

---



Item no 512610  
**Active holder with cig-plug - Samsung Galaxy Tab PRO 12.2 Wi-Fi SM-T900  
(For all countries)**  
With tilt swivel.

---



Item no 512610  
**Active holder with cig-plug - Samsung Galaxy Note PRO 12.2 Wi-Fi SM-P900  
(For all countries)**  
With tilt swivel.

---



Item no 512610  
**Active holder with cig-plug - Samsung Galaxy Note PRO 12.2 4G SM-P905  
(For all countries)**  
With tilt swivel.

---



Item no 512610  
**Active holder with cig-plug - Samsung Galaxy Tab PRO 12.2 4G SM-T905 (For all countries)**  
With tilt swivel.

---



Item no 512616  
**Active holder with cig-plug - Samsung Galaxy Tab PRO 8.4 SM-T320 (For all countries)**  
With tilt swivel.



Item no 512616  
**Active holder with cig-plug - Samsung Galaxy Tab PRO 8.4 SM-T325 (For all countries)**  
With tilt swivel.

---



Item no 512636  
**Active holder with cig-plug - Samsung Galaxy Tab 4 7.0 SM-T230 (For all countries)**  
With tilt swivel.

---



Item no 512636  
**Active holder with cig-plug - Samsung Galaxy Tab 4 7.0 SM-T231 (For all countries)**  
With tilt swivel.

---



Item no 512636  
**Active holder with cig-plug - Samsung Galaxy Tab 4 7.0 SM-T235 (For all countries)**  
With tilt swivel.

---



Item no 512637  
**Active holder with cig-plug - Samsung Galaxy Tab 4 8.0 SM-T335 (For all countries)**  
With tilt swivel.

---



Item no 512652  
**Active holder with cig-plug - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)**  
With tilt swivel.

---



Item no 512652  
**Active holder with cig-plug - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)**  
With tilt swivel.





Item no 512653

**Active holder with cig-plug - Samsung Galaxy Tab S 10.5 SM-T805 (For all countries)**

With tilt swivel.



Item no 512653

**Active holder with cig-plug - Samsung Galaxy Tab S 10.5 SM-T800 (For all countries)**

With tilt swivel.



Item no 512655

**Active holder with cig-plug - Sony Xperia Z2 Tablet (For all countries)**

With tilt swivel.



Item no 512676

**Active holder with cig-plug - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Fits for devices with original skin. With tilt swivel.



Item no 512692

**Active holder with cig-plug - Sony Xperia Z3 Tablet Compact (For all countries)**

With tilt swivel.



Item no 512695

**Active holder with cig-plug - HTC Nexus 9 (For all countries)**

With tilt swivel.



Item no 512695

**Active holder with cig-plug - Nexus 9 (For all countries)**

With tilt swivel.



Item no 512697

**Active holder with cig-plug - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Fits for devices with original skin. With tilt swivel.

---



Item no 512700

**Active holder with cig-plug - Huawei MediaPad M1 8.0 (For all countries)**

With tilt swivel.

---



Item no 512703

**Active holder with cig-plug - Samsung Galaxy Tab 4 7.0 SM-T235 (For all countries)**

With tilt swivel. For device with Otterbox Defender Series Case.

---



Item no 512703

**Active holder with cig-plug - Samsung Galaxy Tab 4 7.0 SM-T230 (For all countries)**

With tilt swivel. For device with Otterbox Defender Series Case.

---



Item no 512703

**Active holder with cig-plug - Samsung Galaxy Tab 4 7.0 SM-T231 (For all countries)**

With tilt swivel. For device with Otterbox Defender Series Case.

---



Item no 512737

**Active holder with cig-plug - Samsung Galaxy Tab A 9.7 (For all countries)**

With tilt swivel.

---



Item no 512754

**Active holder with cig-plug - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

With tilt swivel.



Item no 512781

**Active holder with cig-plug - Samsung Galaxy Tab S2 8.0 SM-T713 /SM-T719  
(For all countries)**

With tilt swivel.

---



Item no 512782

**Active holder with cig-plug - Samsung Galaxy Tab S2 9.7 SM-T810/SM-T813/SM-T815/SM-T819 (For all countries)**

With tilt swivel.

---



Item no 512821

**Active holder with cig-plug - Samsung Galaxy Tab E 9.6 (For all countries)**

With tilt swivel.

---



Item no 512822

**Active holder with cig-plug - LG G Pad F 8.0 (For all countries)**

With tilt swivel.

---



Item no 512835

**Active holder with cig-plug - Samsung Galaxy Tab E 8.0 (For all countries)**

With tilt swivel.

---



Item no 512838

**Active holder with cig-plug - Samsung Galaxy Tab 3 Lite (For all countries)**

With tilt swivel.

---



Item no 512856

**Active holder with cig-plug - Dell Venue 8 Pro NEW (Model 5855) (For all countries)**

With tilt swivel.

---



Item no 512859

**Active holder with cig-plug - Sony Xperia Z4 Tablet (For all countries)**

With tilt swivel.

---



Item no 512871

**Active holder with cig-plug - Huawei MediaPad T1 8.0 (For all countries)**

With tilt swivel.



Item no 512919

**Active holder with cig-plug - Samsung Galaxy Tab A 10.1 (2016) SM-T580/SM-T585 (For all countries)**

With tilt swivel. 2A charging. With USB A outlet in the cig-plug, 1A charging. 12/24V.



Item no 512938

**Active holder with cig-plug - Lenovo Tab 3 7 (For all countries)**

With tilt swivel. 2A charging. With USB A outlet in the cig-plug, 1A charging. 12/24V.



Item no 512968

**Active holder with cig-plug - Samsung Galaxy Tab S3 9.7 SM-T820/SM-T825 (For all countries)**

With tilt swivel.



Item no 512990

**Active holder with cig-plug - Huawei MediaPad T3 8.0 (For all countries)**

With tilt swivel.



Item no 521244

**Active holder with cig-plug - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

With tilt swivel. With USB cable. Apple approved charging cable.



Item no 521244

**Active holder with cig-plug - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**

With tilt swivel. With USB cable. Apple approved charging cable.



Item no 521520

**Active holder with cig-plug - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

With tilt swivel. With USB cable. Apple approved charging cable.



Item no 521520

**Active holder with cig-plug - Apple iPad With Retina (Lightning Connector) (For all countries)**

With tilt swivel. With USB cable. Apple approved charging cable.



Item no 521521

**Active holder with cig-plug - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**

With tilt swivel. With USB cable. Apple approved charging cable.

---



Item no 521548

**Active holder with cig-plug - Samsung Galaxy Tab 3 8.0 SM-T310 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521548

**Active holder with cig-plug - Samsung Galaxy Tab 3 8.0 SM-T315 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521549

**Active holder with cig-plug - Samsung Galaxy Tab 3 10.1 GT-P5220 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521549

**Active holder with cig-plug - Samsung Galaxy Tab 3 10.1 GT-P5210 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521549

**Active holder with cig-plug - Samsung Galaxy Tab 3 10.1 GT-P5200 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521577

**Active holder with cig-plug - Apple iPad 9.7 New (For all countries)**

With USB-cable with cig-plug adapter. Apple approved charging cable. With tilt swivel.

---



Item no 521577

**Active holder with cig-plug - Apple iPad Air (A1474, A1475, A1476) (For all countries)**

With USB-cable with cig-plug adapter. Apple approved charging cable. With tilt swivel.



Item no 521577

**Active holder with cig-plug - Apple iPad 5th Gen (A1822, A1823) (For all countries)**

With USB-cable with cig-plug adapter. Apple approved charging cable. With tilt swivel.

---



Item no 521577

**Active holder with cig-plug - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**

With USB-cable with cig-plug adapter. Apple approved charging cable. With tilt swivel.

---



Item no 521584

**Active holder with cig-plug - Apple iPad Mini Retina (For all countries)**

With tilt swivel. With USB cable. Apple approved charging cable.

---



Item no 521584

**Active holder with cig-plug - Apple iPad Mini 2 (A1489, A1490, A1491) (For all countries)**

With tilt swivel. With USB cable. Apple approved charging cable.

---



Item no 521584

**Active holder with cig-plug - Apple iPad Mini 3 (A1599, A1600) (For all countries)**

With tilt swivel. With USB cable. Apple approved charging cable.

---



Item no 521598

**Active holder with cig-plug - Samsung Galaxy Note 10.1 (2014 Edition) SM-P6050 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521598

**Active holder with cig-plug - Samsung Galaxy Note 10.1 (2014 Edition) SM-P6000 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521600

**Active holder with cig-plug - Apple iPad 9.7 New (For all countries)**

With USB-cable with cig-plug adapter. Apple approved charging cable. With tilt swivel. For Otterbox Defender Series.



Item no 521600

**Active holder with cig-plug - Apple iPad Air (A1474, A1475, A1476) (For all countries)**

With USB-cable with cig-plug adapter. Apple approved charging cable. With tilt swivel. For Otterbox Defender Series.

---



Item no 521600

**Active holder with cig-plug - Apple iPad 5th Gen (A1822, A1823) (For all countries)**

With USB-cable with cig-plug adapter. Apple approved charging cable. With tilt swivel. For Otterbox Defender Series.

---



Item no 521600

**Active holder with cig-plug - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**

With USB-cable with cig-plug adapter. Apple approved charging cable. With tilt swivel. For Otterbox Defender Series.

---



Item no 521608

**Active holder with cig-plug - Samsung Galaxy Tab PRO 10.1 LTE SM-T525 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521608

**Active holder with cig-plug - Samsung Galaxy Tab PRO 10.1 SM-T520 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521610

**Active holder with cig-plug - Samsung Galaxy Tab PRO 12.2 Wi-Fi SM-T900 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521610

**Active holder with cig-plug - Samsung Galaxy Note PRO 12.2 Wi-Fi SM-P900 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521610

**Active holder with cig-plug - Samsung Galaxy Tab PRO 12.2 4G SM-T905 (For all countries)**

With tilt swivel. With USB cable.



Item no 521610  
**Active holder with cig-plug - Samsung Galaxy Note PRO 12.2 4G SM-P905 (For all countries)**  
With tilt swivel. With USB cable.

---



Item no 521616  
**Active holder with cig-plug - Samsung Galaxy Tab PRO 8.4 SM-T320 (For all countries)**  
With tilt swivel. With USB cable.

---



Item no 521616  
**Active holder with cig-plug - Samsung Galaxy Tab PRO 8.4 SM-T325 (For all countries)**  
With tilt swivel. With USB cable.

---



Item no 521632  
**Active holder with cig-plug - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)**  
With tilt swivel. With USB cable.

---



Item no 521632  
**Active holder with cig-plug - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)**  
With tilt swivel. With USB cable.

---



Item no 521632  
**Active holder with cig-plug - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)**  
With tilt swivel. With USB cable.

---



Item no 521636  
**Active holder with cig-plug - Samsung Galaxy Tab 4 7.0 SM-T230 (For all countries)**  
With tilt swivel. With USB cable.





Item no 521636

**Active holder with cig-plug - Samsung Galaxy Tab 4 7.0 SM-T231 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521636

**Active holder with cig-plug - Samsung Galaxy Tab 4 7.0 SM-T235 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521637

**Active holder with cig-plug - Samsung Galaxy Tab 4 8.0 SM-T335 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521652

**Active holder with cig-plug - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521652

**Active holder with cig-plug - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521653

**Active holder with cig-plug - Samsung Galaxy Tab S 10.5 SM-T805 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521653

**Active holder with cig-plug - Samsung Galaxy Tab S 10.5 SM-T800 (For all countries)**

With tilt swivel. With USB cable.



Item no 521672

**Active holder with cig-plug - Dell Venue 8 Pro (For all countries)**

With tilt swivel. With USB cable and fly lead. For device with Targus SafePORT Rugged Max Pro protective case.

---



Item no 521676

**Active holder with cig-plug - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Fits for devices with original skin. With USB-cable with cig-plug adapter. With tilt swivel.

---



Item no 521684

**Active holder with cig-plug - Apple iPad Pro 9.7 (A1673, A1674, A1675) (For all countries)**

With USB-cable with cig-plug adapter. Apple approved charging cable. With tilt swivel

---



Item no 521684

**Active holder with cig-plug - Apple iPad Air 2 (A1566, A1567) (For all countries)**

With USB-cable with cig-plug adapter. Apple approved charging cable. With tilt swivel

---



Item no 521685

**Active holder with cig-plug - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)**

With USB-cable with cig-plug adapter. For Otterbox Defender Series. With tilt swivel.

---



Item no 521685

**Active holder with cig-plug - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)**

With USB-cable with cig-plug adapter. For Otterbox Defender Series. With tilt swivel.

---



Item no 521695

**Active holder with cig-plug - HTC Nexus 9 (For all countries)**

With USB-cable with cig-plug adapter. With tilt swivel.

---



Item no 521695

**Active holder with cig-plug - Nexus 9 (For all countries)**

With USB-cable with cig-plug adapter. With tilt swivel.



Item no 521700  
**Active holder with cig-plug - Huawei MediaPad M1 8.0 (For all countries)**  
With tilt swivel. With USB cable.



Item no 521737  
**Active holder with cig-plug - Samsung Galaxy Tab A 9.7 (For all countries)**  
With tilt swivel. With USB cable.



Item no 521754  
**Active holder with cig-plug - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**  
With tilt swivel. With USB Cable.



Item no 521781  
**Active holder with cig-plug - Samsung Galaxy Tab S2 8.0 SM-T713 /SM-T719 (For all countries)**  
With tilt swivel. With USB cable.



Item no 521782  
**Active holder with cig-plug - Samsung Galaxy Tab S2 9.7 SM-T810/SM-T813/SM-T815/SM-T819 (For all countries)**  
With tilt swivel. With USB cable.



Item no 521793  
**Active holder with cig-plug - Apple iPad Mini 2019 (For all countries)**  
With tilt swivel. With USB cable. Apple approved charging cable.



Item no 521793  
**Active holder with cig-plug - Apple iPad Mini 5th Gen (A2124, A2125, A2126, A2133) (For all countries)**  
With tilt swivel. With USB cable. Apple approved charging cable.



Item no 521793

**Active holder with cig-plug - Apple iPad Mini 4 (A1538, A1550) (For all countries)**

With tilt swivel. With USB cable. Apple approved charging cable.

---



Item no 521820

**Active holder with cig-plug - Apple iPad Pro 12.9 (A1584, A1652, A1670, A1671) (For all countries)**

With tilt swivel. With USB cable. Apple approved charging cable.

---



Item no 521821

**Active holder with cig-plug - Samsung Galaxy Tab E 9.6 (For all countries)**

With tilt swivel. With USB Cable.

---



Item no 521822

**Active holder with cig-plug - LG G Pad F 8.0 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521835

**Active holder with cig-plug - Samsung Galaxy Tab E 8.0 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 521838

**Active holder with cig-plug - Samsung Galaxy Tab 3 Lite (For all countries)**

With USB-cable with cig-plug adapter. With tilt swivel.

---



Item no 521856

**Active holder with cig-plug - Dell Venue 8 Pro NEW (Model 5855) (For all countries)**

With USB-cable with cig-plug adapter. With tilt swivel. 2,1A charging. 12/24V.

---



Item no 521859

**Active holder with cig-plug - Sony Xperia Z4 Tablet (For all countries)**

With tilt swivel. With USB cable.



Item no 521897

**Active holder with cig-plug - Samsung Galaxy Tab A 7.0 (2016) SM-T280/SM-T285 (For all countries)**

With tilt swivel. With USB cable.



Item no 521919

**Active holder with cig-plug - Samsung Galaxy Tab A 10.1 (2016) SM-T580/SM-T585 (For all countries)**

With cig-plug adapter. With tilt swivel. 2,1A charging. 12/24V.



Item no 530554

**Active holder with cig-plug - Pidion BP50 (For all countries)**

With tilt swivel. Slim design with charger integrated in the holder and with USB on-the-go connectivity.



Item no 712018

**Active holder with cig-plug - LG G Pad F2 8.0 (For all countries)**

With tilt swivel.



Item no 712077

**Active holder with cig-plug - Samsung Galaxy Tab S4 10.5 SM-T830/SM-T835 (For all countries)**

With tilt swivel.



Item no 712079

**Active holder with cig-plug - Samsung Galaxy Tab A 10.5 SM-T590/SM-T595 (For all countries)**

With tilt swivel.



Item no 712102

**Active holder with cig-plug - Panasonic FZ-L1 (For all countries)**

With tilt swivel and USB Host.



Item no 712148

**Active holder with cig-plug - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Fits for devices with original skin. With tilt swivel.



Item no 712149

**Active holder with cig-plug - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Fits for devices with original skin. With tilt swivel and USB Host.



Item no 712162

**Active holder with cig-plug - Samsung Galaxy Tab A 8.0 (2019 SM-T290/SM-T295) (For all countries)**

With tilt swivel. 2A charging. With USB A outlet in the cig-plug, 1A charging. 12/24V.



Item no 712163

**Active holder with cig-plug - Huawei MediaPad M5 Lite 8" (For all countries)**

With tilt swivel.



Item no 712182

**Active holder with cig-plug - Panasonic FZ-L1 (For all countries)**

Fits for devices with scanner frame. With tilt swivel and easy-switching system. 12/24V. 3A.



Item no 712183

**Active holder with cig-plug - Panasonic FZ-L1 (For all countries)**

Fits for devices with scanner frame and handstrap. With tilt swivel and easy-switching system. 12/24V. 3A.



Item no 712209

**Active holder with cig-plug - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Fits for devices with Otterbox uniVERSE skin. With tilt swivel.



Item no 712224

**Active holder with cig-plug - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Fits for devices with original skin. With tilt swivel. With Easy-switching system.



Item no 712224

**Active holder with cig-plug - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Fits for devices with original skin. With tilt swivel. With Easy-switching system.



Item no 712225

**Active holder with cig-plug - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Fits for devices with original skin. With tilt swivel and USB Host. With Easy-switching system.



Item no 712225

**Active holder with cig-plug - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Fits for devices with original skin. With tilt swivel and USB Host. With Easy-switching system.



Item no 721077

**Active holder with cig-plug - Samsung Galaxy Tab S4 10.5 SM-T830/SM-T835  
(For all countries)**

With tilt swivel. With USB cable.

---



Item no 721079

**Active holder with cig-plug - Samsung Galaxy Tab A 10.5 SM-T590/SM-T595  
(For all countries)**

With tilt swivel. With USB cable.

---



Item no 721094

**Active holder with cig-plug - Apple iPad Pro 11 2018 (A1980, A2013, A1934,  
A1979) (For all countries)**

With tilt swivel. With USB cable.

---



Item no 721094

**Active holder with cig-plug - Apple iPad Pro 11 2021 3rd Generation (A2301,  
A2459) (For all countries)**

With tilt swivel. With USB cable.

---



Item no 721094

**Active holder with cig-plug - Apple iPad Air 4th Gen (A2072, A2316, A2324,  
A2325) (For all countries)**

With tilt swivel. With USB cable.

---



Item no 721094

**Active holder with cig-plug - Apple iPad Pro 11 2020 2nd Generation (A2068,  
A2230) (For all countries)**

With tilt swivel. With USB cable.

---



Item no 721095

**Active holder with cig-plug - Apple iPad Pro 12.9 2020 (A2069, A2232, A2229)  
(For all countries)**

With tilt swivel. With USB cable.

---



Item no 721095

**Active holder with cig-plug - Apple iPad Pro 12.9 (5th Gen 2021) (For all  
countries)**

With tilt swivel. With USB cable.

---



Item no 721095

**Active holder with cig-plug - Apple iPad Pro 12.9 2018 (A1876, A1895, A1983,  
A2014) (For all countries)**

With tilt swivel. With USB cable.

---



Item no 721114

**Active holder with cig-plug - Huawei MediaPad M5 8.4 (For all countries)**

With tilt swivel. With USB cable.



Item no 721125

**Active holder with cig-plug - Samsung Galaxy Tab S5e 10.5 SM-T720/SM-T725 (For all countries)**

With tilt swivel. With USB-C cable.

---



Item no 721132

**Active holder with cig-plug - Samsung Galaxy Tab A 10.1 (2019) SM-T510/SM-T515 (For all countries)**

With tilt swivel. With USB cable.

---



Item no 721162

**Active holder with cig-plug - Samsung Galaxy Tab A 8.0 (2019 SM-T290/SM-T295) (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.

---



Item no 721166

**Active holder with cig-plug - Samsung Galaxy Tab S6 10.5 SM-T860/SM-T865 (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.

---



Item no 721168

**Active holder with cig-plug - Apple iPad 10.2 9th Gen (A2602, A2603, A2604, A2605) (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.

---



Item no 721168

**Active holder with cig-plug - Apple iPad 10.2 7th Gen (A2197, A2198, A2200) (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.

---



Item no 721168

**Active holder with cig-plug - Apple iPad 10.2 8th Gen (A2428, A2429, A2430, A2270) (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.

---



Item no 721182

**Active holder with cig-plug - Samsung Galaxy Tab S7 FE SM-T733 (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. With pen holder.

---



Item no 721193

**Active holder with cig-plug - Samsung Galaxy Tab A 8.4 (2020) SM-T307 (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.





Item no 721211

**Active holder with cig-plug - Samsung Galaxy Tab S6 Lite SM-P610/SM-P615  
(For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.

---



Item no 721224

**Active holder with cig-plug - Samsung Galaxy Tab Active 3 SM-T570/SM-T575  
(For all countries)**

Fits for devices with original skin. With USB-cable with cig-plug adapter. With tilt swivel. With Easy-switching system.

---



Item no 721224

**Active holder with cig-plug - Samsung Galaxy Tab Active 2 SM-T390/SM-T395  
(For all countries)**

Fits for devices with original skin. With USB-cable with cig-plug adapter. With tilt swivel. With Easy-switching system.

---



Item no 721225

**Active holder with cig-plug - Samsung Galaxy Tab Active 3 SM-T570/SM-T575  
(For all countries)**

Fits for devices with original skin. With USB-cable with cig-plug adapter. With tilt swivel and USB Host. With Easy-switching system.

---



Item no 721225

**Active holder with cig-plug - Samsung Galaxy Tab Active 2 SM-T390/SM-T395  
(For all countries)**

Fits for devices with original skin. With USB-cable with cig-plug adapter. With tilt swivel and USB Host. With Easy-switching system.

---



Item no 721229

**Active holder with cig-plug - Samsung Galaxy Tab A7 10.4 (2020) SM-T500/SM-T505 (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.

---



Item no 721255

**Active holder with cig-plug - Lenovo Tab M8 HD TB-8505X (Micro-USB) (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.

---



Item no 721264

**Active holder with cig-plug - Samsung Galaxy Tab A7 Lite SM-T220/SM-T225  
(For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.



Item no 721270

**Active holder with cig-plug - Lenovo Tab M8 HD TB-8505XC (USB Type-C)  
(For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.



Item no 721271

**Active holder with cig-plug - Lenovo Tab K10 TB-X6C6F (For all countries)**

With USB-A cable + cig-plug adapter with 2 USB-A ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.



Item no 721278

**Active holder with cig-plug - Apple iPad Mini 6th Gen (A2567, A2568, A2569)  
(For all countries)**

With USB Type-C + cig-plug adapter with 2 USB ports: Type-A and Type-C. With tilt swivel. 12/24 Volt.



Item no 721286

**Active holder with cig-plug - Samsung Galaxy Tab A8 SM-X200/205 (For all countries)**

With USB-cable + cig-plug adapter with 2 USB Type-A ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.

### Active holder for fixed installation



Item no 215705

**Active holder for fixed installation - Dell Venue 8 Pro (For all countries)**

With tilt swivel, with Molex adapter system. 2A charger. With fly lead.



Item no 513209

**Active holder for fixed installation - Samsung Galaxy Tab GT-P1000 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513300

**Active holder for fixed installation - Samsung Galaxy Tab 8.9 GT-P7300 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513329

**Active holder for fixed installation - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513329

**Active holder for fixed installation - Samsung Galaxy Tab 10.1 SCH-I905 (For USA)**

With tilt swivel, with Molex adapter system.



Item no 513361

**Active holder for fixed installation - Samsung Galaxy Tab 7.7 GT-P6800 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513381

**Active holder for fixed installation - Samsung Galaxy Tab 2 7.0 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513381

**Active holder for fixed installation - Samsung Galaxy Tab 7.0 Plus GT-P6200 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513385

**Active holder for fixed installation - Huawei MediaPad (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513385

**Active holder for fixed installation - Huawei MediaPad S7-301u (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513412

**Active holder for fixed installation - Asus Google Nexus 7 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513412

**Active holder for fixed installation - Nexus 7 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513412

**Active holder for fixed installation - Google Nexus 7 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513415

**Active holder for fixed installation - Samsung Galaxy Tab 2 10.1 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513535

**Active holder for fixed installation - Samsung Galaxy Note 8.0 GT-N5110 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513535

**Active holder for fixed installation - Samsung Galaxy Note 8.0 GT-N5120 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513538

**Active holder for fixed installation - Sony Xperia Tablet Z (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513543

**Active holder for fixed installation - Samsung Galaxy Tab 3 7.0 SM-T2110 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513543

**Active holder for fixed installation - Samsung Galaxy Tab 3 7.0 SM-T210 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513548

**Active holder for fixed installation - Samsung Galaxy Tab 3 8.0 SM-T310 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513548

**Active holder for fixed installation - Samsung Galaxy Tab 3 8.0 SM-T315 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513549

**Active holder for fixed installation - Samsung Galaxy Tab 3 10.1 GT-P5220 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513549

**Active holder for fixed installation - Samsung Galaxy Tab 3 10.1 GT-P5210  
(For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513549

**Active holder for fixed installation - Samsung Galaxy Tab 3 10.1 GT-P5200  
(For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513554

**Active holder for fixed installation - Pidion BP50 (For all countries)**

With tilt swivel.

---



Item no 513560

**Active holder for fixed installation - Google Nexus 7 (2013) (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513560

**Active holder for fixed installation - Asus Google Nexus 7 (2013) (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513560

**Active holder for fixed installation - Nexus 7 (2013) (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513579

**Active holder for fixed installation - Dell Venue 8 Pro (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513598

**Active holder for fixed installation - Samsung Galaxy Note 10.1 (2014 Edition)  
SM-P6050 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513598

**Active holder for fixed installation - Samsung Galaxy Note 10.1 (2014 Edition)  
SM-P6000 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513608

**Active holder for fixed installation - Samsung Galaxy Tab PRO 10.1 LTE SM-T525 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513608

**Active holder for fixed installation - Samsung Galaxy Tab PRO 10.1 SM-T520 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513610

**Active holder for fixed installation - Samsung Galaxy Tab PRO 12.2 Wi-Fi SM-T900 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513610

**Active holder for fixed installation - Samsung Galaxy Note PRO 12.2 Wi-Fi SM-P900 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513610

**Active holder for fixed installation - Samsung Galaxy Note PRO 12.2 4G SM-P905 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513610

**Active holder for fixed installation - Samsung Galaxy Tab PRO 12.2 4G SM-T905 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513616

**Active holder for fixed installation - Samsung Galaxy Tab PRO 8.4 SM-T320 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513616

**Active holder for fixed installation - Samsung Galaxy Tab PRO 8.4 SM-T325 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513632

**Active holder for fixed installation - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513632

**Active holder for fixed installation - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513632

**Active holder for fixed installation - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513636

**Active holder for fixed installation - Samsung Galaxy Tab 4 7.0 SM-T230 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513636

**Active holder for fixed installation - Samsung Galaxy Tab 4 7.0 SM-T231 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513636

**Active holder for fixed installation - Samsung Galaxy Tab 4 7.0 SM-T235 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513637

**Active holder for fixed installation - Samsung Galaxy Tab 4 8.0 SM-T335 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513652

**Active holder for fixed installation - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513652

**Active holder for fixed installation - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513653

**Active holder for fixed installation - Samsung Galaxy Tab S 10.5 SM-T805 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513653

**Active holder for fixed installation - Samsung Galaxy Tab S 10.5 SM-T800 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513655

**Active holder for fixed installation - Sony Xperia Z2 Tablet (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513672

**Active holder for fixed installation - Dell Venue 8 Pro (For all countries)**

With tilt swivel, with Molex adapter system. 2A charger. With fly lead. For device with Targus SafePORT Rugged Max Pro protective case.



Item no 513676

**Active holder for fixed installation - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Fits for devices with original skin. With tilt swivel. 2,5A charger.





Item no 513692

**Active holder for fixed installation - Sony Xperia Z3 Tablet Compact (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513697

**Active holder for fixed installation - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Fits for devices with original skin. With tilt swivel. 2,5A charger.

---



Item no 513700

**Active holder for fixed installation - Huawei MediaPad M1 8.0 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513703

**Active holder for fixed installation - Samsung Galaxy Tab 4 7.0 SM-T235 (For all countries)**

With tilt swivel, with Molex adapter system. For device with Otterbox Defender Series Case.

---



Item no 513703

**Active holder for fixed installation - Samsung Galaxy Tab 4 7.0 SM-T230 (For all countries)**

With tilt swivel, with Molex adapter system. For device with Otterbox Defender Series Case.

---



Item no 513703

**Active holder for fixed installation - Samsung Galaxy Tab 4 7.0 SM-T231 (For all countries)**

With tilt swivel, with Molex adapter system. For device with Otterbox Defender Series Case.

---



Item no 513737

**Active holder for fixed installation - Samsung Galaxy Tab A 9.7 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513754

**Active holder for fixed installation - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

With tilt swivel, with Molex adapter system.



Item no 513781  
**Active holder for fixed installation - Samsung Galaxy Tab S2 8.0 SM-T713 /SM-T719 (For all countries)**  
With tilt swivel, with Molex adapter system.

---



Item no 513782  
**Active holder for fixed installation - Samsung Galaxy Tab S2 9.7 SM-T810/SM-T813/SM-T815/SM-T819 (For all countries)**  
With tilt swivel, with Molex adapter system.

---



Item no 513822  
**Active holder for fixed installation - LG G Pad F 8.0 (For all countries)**  
With tilt swivel, with Molex adapter system.

---



Item no 513835  
**Active holder for fixed installation - Samsung Galaxy Tab E 8.0 (For all countries)**  
With tilt swivel, with Molex adapter system.

---



Item no 513838  
**Active holder for fixed installation - Samsung Galaxy Tab 3 Lite (For all countries)**  
With tilt swivel, with Molex adapter system.

---



Item no 513856  
**Active holder for fixed installation - Dell Venue 8 Pro NEW (Model 5855) (For all countries)**  
With tilt swivel, with Molex adapter system.

---



Item no 513859  
**Active holder for fixed installation - Sony Xperia Z4 Tablet (For all countries)**  
With tilt swivel, with Molex adapter system.

---



Item no 513871  
**Active holder for fixed installation - Huawei MediaPad T1 8.0 (For all countries)**  
With tilt swivel, with Molex adapter system.



Item no 513897

**Active holder for fixed installation - Samsung Galaxy Tab A 7.0 (2016) SM-T280/SM-T285 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513919

**Active holder for fixed installation - Samsung Galaxy Tab A 10.1 (2016) SM-T580/SM-T585 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513938

**Active holder for fixed installation - Lenovo Tab 3 7 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 513990

**Active holder for fixed installation - Huawei MediaPad T3 8.0 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 527244

**Active holder for fixed installation - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

With tilt swivel. 2A charger. Apple approved charging cable.

---



Item no 527244

**Active holder for fixed installation - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**

With tilt swivel. 2A charger. Apple approved charging cable.

---



Item no 527520

**Active holder for fixed installation - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527520

**Active holder for fixed installation - Apple iPad With Retina (Lightning Connector) (For all countries)**

With tilt swivel. Apple approved charging cable.



Item no 527521

**Active holder for fixed installation - Apple iPad Mini (A1432, A1454, A1455)  
(For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527577

**Active holder for fixed installation - Apple iPad 9.7 New (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527577

**Active holder for fixed installation - Apple iPad 5th Gen (A1822, A1823) (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527577

**Active holder for fixed installation - Apple iPad Air (A1474, A1475, A1476) (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527577

**Active holder for fixed installation - Apple iPad 9.7 6th Gen (A1893, A1954)  
(For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527584

**Active holder for fixed installation - Apple iPad Mini 3 (A1599, A1600) (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527584

**Active holder for fixed installation - Apple iPad Mini Retina (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527584

**Active holder for fixed installation - Apple iPad Mini 2 (A1489, A1490, A1491)  
(For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527600

**Active holder for fixed installation - Apple iPad 9.7 New (For all countries)**

With tilt swivel. Apple approved charging cable. For Otterbox Defender Series.



Item no 527600

**Active holder for fixed installation - Apple iPad 5th Gen (A1822, A1823) (For all countries)**

With tilt swivel. Apple approved charging cable. For Otterbox Defender Series.

---



Item no 527600

**Active holder for fixed installation - Apple iPad Air (A1474, A1475, A1476) (For all countries)**

With tilt swivel. Apple approved charging cable. For Otterbox Defender Series.

---



Item no 527600

**Active holder for fixed installation - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**

With tilt swivel. Apple approved charging cable. For Otterbox Defender Series.

---



Item no 527684

**Active holder for fixed installation - Apple iPad Pro 9.7 (A1673, A1674, A1675) (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527684

**Active holder for fixed installation - Apple iPad Air 2 (A1566, A1567) (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527793

**Active holder for fixed installation - Apple iPad Mini 2019 (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527793

**Active holder for fixed installation - Apple iPad Mini 5th Gen (A2124, A2125, A2126, A2133) (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 527793

**Active holder for fixed installation - Apple iPad Mini 4 (A1538, A1550) (For all countries)**

With tilt swivel. Apple approved charging cable.



Item no 527820

**Active holder for fixed installation - Apple iPad Pro 12.9 (A1584, A1652, A1670, A1671) (For all countries)**

With tilt swivel. Apple approved charging cable.

---



Item no 532554

**Active holder for fixed installation - Pidion BP50 (For all countries)**

With tilt swivel. Slim design with charger integrated in the holder and with USB on-the-go connectivity.

---



Item no 713018

**Active holder for fixed installation - LG G Pad F2 8.0 (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 713102

**Active holder for fixed installation - Panasonic FZ-L1 (For all countries)**

With tilt swivel and USB Host.

---



Item no 713148

**Active holder for fixed installation - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Fits for devices with original skin. With tilt swivel.

---



Item no 713149

**Active holder for fixed installation - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Fits for devices with original skin. With tilt swivel and USB Host.

---



Item no 713162

**Active holder for fixed installation - Samsung Galaxy Tab A 8.0 (2019 SM-T290/SM-T295) (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 713163

**Active holder for fixed installation - Huawei MediaPad M5 Lite 8" (For all countries)**

With tilt swivel, with Molex adapter system.

---



Item no 713182

**Active holder for fixed installation - Panasonic FZ-L1 (For all countries)**

Fits for devices with scanner frame. With tilt swivel and easy-switching system. 12/24V. 2A.



Item no 713183

**Active holder for fixed installation - Panasonic FZ-L1 (For all countries)**

Fits for devices with scanner frame and handstrap. With tilt swivel and easy-switching system. 12/24V. 2A.



Item no 713209

**Active holder for fixed installation - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Fits for devices with Otterbox uniVERSE skin. With tilt swivel.



Item no 713224

**Active holder for fixed installation - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Fits for devices with original skin. With tilt swivel. With Easy-switching system. 2,5A charger via pogo pins. 12/24 Volt.



Item no 713224

**Active holder for fixed installation - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Fits for devices with original skin. With tilt swivel. With Easy-switching system. 2,5A charger via pogo pins. 12/24 Volt.



Item no 713225

**Active holder for fixed installation - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Fits for devices with original skin. With tilt swivel and USB Host. With Easy-switching system. 2,5A charger via pogo pins. 12/24 Volt.



Item no 713225

**Active holder for fixed installation - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Fits for devices with original skin. With tilt swivel and USB Host. With Easy-switching system. 2,5A charger via pogo pins. 12/24 Volt.



Item no 727077

**Active holder for fixed installation - Samsung Galaxy Tab S4 10.5 SM-T830/SM-T835 (For all countries)**

With tilt swivel.



Item no 727079

**Active holder for fixed installation - Samsung Galaxy Tab A 10.5 SM-T590/SM-T595 (For all countries)**

With tilt swivel.



Item no 727094

**Active holder for fixed installation - Apple iPad Pro 11 2018 (A1980, A2013, A1934, A1979) (For all countries)**

With tilt swivel.



Item no 727094  
**Active holder for fixed installation - Apple iPad Pro 11 2021 3rd Generation (A2301, A2459) (For all countries)**  
With tilt swivel.



Item no 727094  
**Active holder for fixed installation - Apple iPad Air 4th Gen (A2072, A2316, A2324, A2325) (For all countries)**  
With tilt swivel.



Item no 727094  
**Active holder for fixed installation - Apple iPad Pro 11 2020 2nd Generation (A2068, A2230) (For all countries)**  
With tilt swivel.



Item no 727095  
**Active holder for fixed installation - Apple iPad Pro 12.9 2020 (A2069, A2232, A2229) (For all countries)**  
With tilt swivel.



Item no 727095  
**Active holder for fixed installation - Apple iPad Pro 12.9 (5th Gen 2021) (For all countries)**  
With tilt swivel.



Item no 727095  
**Active holder for fixed installation - Apple iPad Pro 12.9 2018 (A1876, A1895, A1983, A2014) (For all countries)**  
With tilt swivel.



Item no 727114  
**Active holder for fixed installation - Huawei MediaPad M5 8.4 (For all countries)**  
With tilt swivel.



Item no 727125  
**Active holder for fixed installation - Samsung Galaxy Tab S5e 10.5 SM-T720/SM-T725 (For all countries)**  
With tilt swivel.



Item no 727132  
**Active holder for fixed installation - Samsung Galaxy Tab A 10.1 (2019) SM-T510/SM-T515 (For all countries)**  
With tilt swivel.



Item no 727166  
**Active holder for fixed installation - Samsung Galaxy Tab S6 10.5 SM-T860/SM-T865 (For all countries)**  
With tilt swivel.





Item no 727168

**Active holder for fixed installation - Apple iPad 10.2 8th Gen (A2428, A2429, A2430, A2270) (For all countries)**

With tilt swivel.

---



Item no 727168

**Active holder for fixed installation - Apple iPad 10.2 9th Gen (A2602, A2603, A2604, A2605) (For all countries)**

With tilt swivel.

---



Item no 727168

**Active holder for fixed installation - Apple iPad 10.2 7th Gen (A2197, A2198, A2200) (For all countries)**

With tilt swivel.

---



Item no 727182

**Active holder for fixed installation - Samsung Galaxy Tab S7 FE SM-T733 (For all countries)**

With USB-cable. 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2A charging. With pen holder.

---



Item no 727193

**Active holder for fixed installation - Samsung Galaxy Tab A 8.4 (2020) SM-T307 (For all countries)**

With USB-cable. 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2A charging.

---



Item no 727211

**Active holder for fixed installation - Samsung Galaxy Tab S6 Lite SM-P610/SM-P615 (For all countries)**

With USB-cable. 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2A charging.

---



Item no 727229

**Active holder for fixed installation - Samsung Galaxy Tab A7 10.4 (2020) SM-T500/SM-T505 (For all countries)**

With USB-cable. 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2A charging.

---



Item no 727255

**Active holder for fixed installation - Lenovo Tab M8 HD TB-8505X (Micro-USB) (For all countries)**

With USB-cable. 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2A charging.

---



Item no 727264

**Active holder for fixed installation - Samsung Galaxy Tab A7 Lite SM-T220/SM-T225 (For all countries)**

With USB-cable. 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2A charging.



Item no 727270  
**Active holder for fixed installation - Lenovo Tab M8 HD TB-8505XC (USB Type-C) (For all countries)**  
With USB-cable. 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2A charging.



Item no 727271  
**Active holder for fixed installation - Lenovo Tab K10 TB-X6C6F (For all countries)**  
With USB-A cable. 2 USB-A ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt.



Item no 727278  
**Active holder for fixed installation - Apple iPad Mini 6th Gen (A2567, A2568, A2569) (For all countries)**  
With USB-cable. 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2A charging.



Item no 727286  
**Active holder for fixed installation - Samsung Galaxy Tab A8 SM-X200/205 (For all countries)**  
With USB-cable. 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2A charging.

## Holder with lock.



Item no 216098  
**Holder with lock. - Zebra L10 XPAD (For all countries)**  
2 keys included. Can be used with Zebra XDIM module, Zebra article. no. 300140.



Item no 216098  
**Holder with lock. - Xplore L10 XPAD (For all countries)**  
2 keys included. Can be used with Zebra XDIM module, Zebra article. no. 300140.



Item no 216098  
**Holder with lock. - Zebra L10 XSLATE (For all countries)**  
2 keys included. Can be used with Zebra XDIM module, Zebra article. no. 300140.



Item no 216098  
**Holder with lock. - Xplore L10 XSLATE (For all countries)**  
2 keys included. Can be used with Zebra XDIM module, Zebra article. no. 300140.



Item no 216126  
**Holder with lock. - Zebra ET50 10.1 (For all countries)**  
Extra strength holder. For device with rugged frame. Battery swap slot. With lock, 2 keys included. With AMPS, Vesa 75 holes.



Item no 216126

**Holder with lock. - Zebra ET51 10.1 (For all countries)**

Extra strength holder. For device with rugged frame. Battery swap slot. With lock, 2 keys included. With AMPS, Vesa 75 holes.



Item no 216126

**Holder with lock. - Zebra ET56 10.1 (For all countries)**

Extra strength holder. For device with rugged frame. Battery swap slot. With lock, 2 keys included. With AMPS, Vesa 75 holes.



Item no 216126

**Holder with lock. - Zebra ET55 10.1 (For all countries)**

Extra strength holder. For device with rugged frame. Battery swap slot. With lock, 2 keys included. With AMPS, Vesa 75 holes.



Item no 216268

**Holder with lock. - Microsoft Surface Pro 8 (For all countries)**

Passive holder with tilt swivel. 2 keys included. For device with UAG Metropolis Series Case. With AMPS, Vesa 75/100 holes.



Item no 241671

**Holder with lock. - Zebra ET50 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75/100 holes. Fits devices with rugged frame. 2 keys included.



Item no 241671

**Holder with lock. - Zebra ET55 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75/100 holes. Fits devices with rugged frame. 2 keys included.



Item no 241671

**Holder with lock. - Zebra ET51 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75/100 holes. Fits devices with rugged frame. 2 keys included.



Item no 241671

**Holder with lock. - Zebra ET56 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75/100 holes. Fits devices with rugged frame. 2 keys included.



Item no 514458

**Holder with lock. - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**

For cable attachment, for use with Apple original Lightning to USB Cable. With tilt swivel. 2 keys included.



Item no 514459

**Holder with lock. - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**

For cable attachment, for use with Apple original Lightning to 30-pin Adapter Cable. With tilt swivel. 2 keys included.



Item no 535261

**Holder with lock. - Samsung Galaxy Tab GT-P1000 (For all countries)**

With Cigarette Lighter Cable. With tilt swivel. 2 keys included. For OtterBox Defender Series.



Item no 535287

**Holder with lock. - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)**

Active holder with cig-plug and tilt swivel. 2 keys included.



Item no 535392

**Holder with lock. - Samsung Galaxy Tab 2 7.0 (For all countries)**

Active holder with cig-plug and tilt swivel. 2 keys included.



Item no 535392

**Holder with lock. - Samsung Galaxy Tab 7.0 Plus GT-P6200 (For all countries)**

Active holder with cig-plug and tilt swivel. 2 keys included.



Item no 535395

**Holder with lock. - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included. For OtterBox Defender Series.



Item no 535480

**Holder with lock. - Getac Z710 (EU Version) (For all countries)**

Passive holder with tilt swivel. 2 keys included. Fits unit both with and without handstrap.



Item no 535480

**Holder with lock. - Getac Z710 (US Version) (For all countries)**

Passive holder with tilt swivel. 2 keys included. Fits unit both with and without handstrap.



Item no 535494

**Holder with lock. - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

For cable attachment. For use with Apple original Lightning to USB Cable. With tilt swivel. 2 keys included.



Item no 535494

**Holder with lock. - Apple iPad With Retina (Lightning Connector) (For all countries)**

For cable attachment. For use with Apple original Lightning to USB Cable. With tilt swivel. 2 keys included.



Item no 535519  
**Holder with lock. - Samsung Galaxy Tab 2 10.1 (For all countries)**  
Active holder with cig-plug and tilt swivel. 2 keys included.



Item no 535543  
**Holder with lock. - Samsung Galaxy Tab 3 7.0 SM-T210 (For all countries)**  
Active holder with cig-plug and tilt swivel. 2 keys included.



Item no 535543  
**Holder with lock. - Samsung Galaxy Tab 3 7.0 SM-T2110 (For all countries)**  
Active holder with cig-plug and tilt swivel. 2 keys included.



Item no 535549  
**Holder with lock. - Samsung Galaxy Tab 3 10.1 GT-P5220 (For all countries)**  
Active holder with cig-plug and tilt swivel. 2 keys included.



Item no 535549  
**Holder with lock. - Samsung Galaxy Tab 3 10.1 GT-P5210 (For all countries)**  
Active holder with cig-plug and tilt swivel. 2 keys included.



Item no 535549  
**Holder with lock. - Samsung Galaxy Tab 3 10.1 GT-P5200 (For all countries)**  
Active holder with cig-plug and tilt swivel. 2 keys included.



Item no 535560  
**Holder with lock. - Google Nexus 7 (2013) (For all countries)**  
Active holder with cig-plug and tilt swivel. 2 keys included.



Item no 535560  
**Holder with lock. - Asus Google Nexus 7 (2013) (For all countries)**  
Active holder with cig-plug and tilt swivel. 2 keys included.



---

Item no 535560  
**Holder with lock. - Nexus 7 (2013) (For all countries)**  
Active holder with cig-plug and tilt swivel. 2 keys included.



---

Item no 535577  
**Holder with lock. - Apple iPad 9.7 New (For all countries)**  
Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.



---

Item no 535577  
**Holder with lock. - Apple iPad Air (A1474, A1475, A1476) (For all countries)**  
Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.



---

Item no 535577  
**Holder with lock. - Apple iPad 5th Gen (A1822, A1823) (For all countries)**  
Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.



---

Item no 535577  
**Holder with lock. - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**  
Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.



---

Item no 535579  
**Holder with lock. - Dell Venue 8 Pro (For all countries)**  
Active holder with cig-plug (12/24V) and tilt swivel. 2 keys included.



---

Item no 535584  
**Holder with lock. - Apple iPad Mini 2 (A1489, A1490, A1491) (For all countries)**  
Active holder with USB cable. Apple approved charging cable. With tilt swivel. 2 keys included.



---

Item no 535584  
**Holder with lock. - Apple iPad Mini Retina (For all countries)**  
Active holder with USB cable. Apple approved charging cable. With tilt swivel. 2 keys included.



Item no 535584

**Holder with lock. - Apple iPad Mini 3 (A1599, A1600) (For all countries)**

Active holder with USB cable. Apple approved charging cable. With tilt swivel. 2 keys included.

---



Item no 535632

**Holder with lock. - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)**

Active holder with USB cable and tilt swivel. 2 keys included.

---



Item no 535632

**Holder with lock. - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)**

Active holder with USB cable and tilt swivel. 2 keys included.

---



Item no 535632

**Holder with lock. - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)**

Active holder with USB cable and tilt swivel. 2 keys included.

---



Item no 535637

**Holder with lock. - Samsung Galaxy Tab 4 8.0 SM-T335 (For all countries)**

Active holder with cig-plug. With tilt swivel. With lock, 2 keys included.

---



Item no 535652

**Holder with lock. - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)**

Active holder with cig-plug. With tilt swivel. With lock, 2 keys included.

---



Item no 535652

**Holder with lock. - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)**

Active holder with cig-plug. With tilt swivel. With lock, 2 keys included.

---



Item no 535676

**Holder with lock. - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Active holder with cig-plug and tilt swivel. Fits for devices with original skin. 2 keys included.



Item no 535682

**Holder with lock. - Samsung Galaxy Tab 4 7.0 SM-T230 (For all countries)**

Active holder with cig-plug and tilt swivel. 2 keys included.

---



Item no 535682

**Holder with lock. - Samsung Galaxy Tab 4 7.0 SM-T231 (For all countries)**

Active holder with cig-plug and tilt swivel. 2 keys included.

---



Item no 535682

**Holder with lock. - Samsung Galaxy Tab 4 7.0 SM-T235 (For all countries)**

Active holder with cig-plug and tilt swivel. 2 keys included.

---



Item no 535684

**Holder with lock. - Apple iPad Pro 9.7 (A1673, A1674, A1675) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With lock, 2 keys included.

---



Item no 535684

**Holder with lock. - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With lock, 2 keys included.

---



Item no 535708

**Holder with lock. - LG G Pad 7.0 (For all countries)**

Active holder with cig-plug and tilt swivel. 2 keys included.





Item no 535769

**Holder with lock. - Samsung Galaxy Tab A 9.7 (For all countries)**

Active holder with cig-plug. With tilt swivel. With lock, 2 keys included.

---



Item no 535781

**Holder with lock. - Samsung Galaxy Tab S2 8.0 SM-T713 /SM-T719 (For all countries)**

Active holder with cig-plug. With tilt swivel. With lock, 2 keys included.

---



Item no 535821

**Holder with lock. - Samsung Galaxy Tab E 9.6 (For all countries)**

Active holder with cig-plug. With tilt swivel. With lock, 2 keys included.

---



Item no 535835

**Holder with lock. - Samsung Galaxy Tab E 8.0 (For all countries)**

Active holder with cig-plug. With tilt swivel. With lock, 2 keys included.

---



Item no 535852

**Holder with lock. - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

Active holder with cig-plug. With tilt swivel. With lock, 2 keys included. For Otterbox Defender Series Case.

---



Item no 535853

**Holder with lock. - Samsung Galaxy Tab A 9.7 (For all countries)**

Active holder with cig-plug. With tilt swivel. With lock, 2 keys included. For Otterbox Defender Series Case.

---



Item no 536261

**Holder with lock. - Samsung Galaxy Tab GT-P1000 (For all countries)**

For fixed installation. With tilt swivel. 2 keys included. For OtterBox Defender Series.

---



Item no 536287

**Holder with lock. - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536392

**Holder with lock. - Samsung Galaxy Tab 2 7.0 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536392

**Holder with lock. - Samsung Galaxy Tab 7.0 Plus GT-P6200 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536395

**Holder with lock. - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included. For OtterBox Defender Series.



Item no 536543

**Holder with lock. - Samsung Galaxy Tab 3 7.0 SM-T2110 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536543

**Holder with lock. - Samsung Galaxy Tab 3 7.0 SM-T210 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536549

**Holder with lock. - Samsung Galaxy Tab 3 10.1 GT-P5220 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536549

**Holder with lock. - Samsung Galaxy Tab 3 10.1 GT-P5210 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536549

**Holder with lock. - Samsung Galaxy Tab 3 10.1 GT-P5200 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536560  
**Holder with lock. - Google Nexus 7 (2013) (For all countries)**  
Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536560  
**Holder with lock. - Asus Google Nexus 7 (2013) (For all countries)**  
Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536560  
**Holder with lock. - Nexus 7 (2013) (For all countries)**  
Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536577  
**Holder with lock. - Apple iPad 9.7 New (For all countries)**  
Active holder for fixed installation. With tilt swivel. 2 keys included.



Item no 536577  
**Holder with lock. - Apple iPad Air (A1474, A1475, A1476) (For all countries)**  
Active holder for fixed installation. With tilt swivel. 2 keys included.



Item no 536577  
**Holder with lock. - Apple iPad 5th Gen (A1822, A1823) (For all countries)**  
Active holder for fixed installation. With tilt swivel. 2 keys included.



Item no 536577  
**Holder with lock. - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**  
Active holder for fixed installation. With tilt swivel. 2 keys included.



Item no 536579  
**Holder with lock. - Dell Venue 8 Pro (For all countries)**  
Active holder for fixed installation, with tilt swivel. 2 keys included.



---

Item no 536584  
**Holder with lock. - Apple iPad Mini 2 (A1489, A1490, A1491) (For all countries)**  
Active holder for fixed installation, with tilt swivel. 2 keys included.



---

Item no 536584  
**Holder with lock. - Apple iPad Mini Retina (For all countries)**  
Active holder for fixed installation, with tilt swivel. 2 keys included.



---

Item no 536584  
**Holder with lock. - Apple iPad Mini 3 (A1599, A1600) (For all countries)**  
Active holder for fixed installation, with tilt swivel. 2 keys included.



---

Item no 536600  
**Holder with lock. - Apple iPad 9.7 New (For all countries)**  
Active holder for fixed installation. With tilt swivel. 2 keys included. For Otterbox Defender Series.



---

Item no 536600  
**Holder with lock. - Apple iPad Air (A1474, A1475, A1476) (For all countries)**  
Active holder for fixed installation. With tilt swivel. 2 keys included. For Otterbox Defender Series.



---

Item no 536600  
**Holder with lock. - Apple iPad 5th Gen (A1822, A1823) (For all countries)**  
Active holder for fixed installation. With tilt swivel. 2 keys included. For Otterbox Defender Series.



---

Item no 536600  
**Holder with lock. - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**  
Active holder for fixed installation. With tilt swivel. 2 keys included. For Otterbox Defender Series.



---

Item no 536632  
**Holder with lock. - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)**  
Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536632

**Holder with lock. - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.

---



Item no 536632

**Holder with lock. - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.

---



Item no 536637

**Holder with lock. - Samsung Galaxy Tab 4 8.0 SM-T335 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536652

**Holder with lock. - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536652

**Holder with lock. - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536676

**Holder with lock. - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Active holder for fixed installation, with tilt swivel. Fits for devices with original skin. 2 keys included. 2,5A charger.

---



Item no 536682

**Holder with lock. - Samsung Galaxy Tab 4 7.0 SM-T230 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.



Item no 536682

**Holder with lock. - Samsung Galaxy Tab 4 7.0 SM-T231 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.

---



Item no 536682

**Holder with lock. - Samsung Galaxy Tab 4 7.0 SM-T235 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.

---



Item no 536684

**Holder with lock. - Apple iPad Pro 9.7 (A1673, A1674, A1675) (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536684

**Holder with lock. - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536708

**Holder with lock. - LG G Pad 7.0 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included.

---



Item no 536759

**Holder with lock. - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included. For OtterBox Defender Series.



Item no 536760

**Holder with lock. - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536769

**Holder with lock. - Samsung Galaxy Tab A 9.7 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536781

**Holder with lock. - Samsung Galaxy Tab S2 8.0 SM-T713 /SM-T719 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536820

**Holder with lock. - Apple iPad Pro 12.9 (A1584, A1652, A1670, A1671) (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536821

**Holder with lock. - Samsung Galaxy Tab E 9.6 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536822

**Holder with lock. - LG G Pad F 8.0 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536835

**Holder with lock. - Samsung Galaxy Tab E 8.0 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included.

---



Item no 536852

**Holder with lock. - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included. For Otterbox Defender Series Case.



Item no 536853

**Holder with lock. - Samsung Galaxy Tab A 9.7 (For all countries)**

Active holder for fixed installation. With tilt swivel. With lock, 2 keys included. For Otterbox Defender Series Case.



Item no 539209

**Holder with lock. - Samsung Galaxy Tab GT-P1000 (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 539244

**Holder with lock. - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 539244

**Holder with lock. - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 539244

**Holder with lock. - Apple iPad With Retina (Lightning Connector) (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 539244

**Holder with lock. - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 539300

**Holder with lock. - Samsung Galaxy Tab 8.9 GT-P7300 (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 539329

**Holder with lock. - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 539329

**Holder with lock. - Samsung Galaxy Tab 10.1 SCH-I905 (For USA)**

Passive holder with tilt swivel. 2 keys included.





Item no 539366

**Holder with lock. - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**

Passive holder with tilt swivel. 2 keys included. For OtterBox Defender Series.

---



Item no 539366

**Holder with lock. - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Passive holder with tilt swivel. 2 keys included. For OtterBox Defender Series.

---



Item no 539446

**Holder with lock. - Microsoft Surface (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539448

**Holder with lock. - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539491

**Holder with lock. - Microsoft Surface Pro 2 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539541

**Holder with lock. - Apple iPad With Retina (Lightning Connector) (For all countries)**

Passive holder with tilt swivel. 2 keys included. For iZettle card reader.

---



Item no 539541

**Holder with lock. - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Passive holder with tilt swivel. 2 keys included. For iZettle card reader.

---



Item no 539541

**Holder with lock. - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

Passive holder with tilt swivel. 2 keys included. For iZettle card reader.



Item no 539541

**Holder with lock. - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**

Passive holder with tilt swivel. 2 keys included. For iZettle card reader.

---



Item no 539549

**Holder with lock. - Samsung Galaxy Tab 3 10.1 GT-P5210 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539549

**Holder with lock. - Samsung Galaxy Tab 3 10.1 GT-P5220 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539549

**Holder with lock. - Samsung Galaxy Tab 3 10.1 GT-P5200 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539560

**Holder with lock. - Google Nexus 7 (2013) (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539560

**Holder with lock. - Asus Google Nexus 7 (2013) (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539560

**Holder with lock. - Nexus 7 (2013) (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539577

**Holder with lock. - Apple iPad 9.7 New (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 539577  
**Holder with lock. - Apple iPad Air (A1474, A1475, A1476) (For all countries)**  
Passive holder with tilt swivel. 2 keys included.



Item no 539577  
**Holder with lock. - Apple iPad 5th Gen (A1822, A1823) (For all countries)**  
Passive holder with tilt swivel. 2 keys included.



Item no 539577  
**Holder with lock. - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**  
Passive holder with tilt swivel. 2 keys included.



Item no 539585  
**Holder with lock. - Dell Latitude 10 - ST2 (For all countries)**  
Passive holder with tilt swivel. 2 keys included.



Item no 539587  
**Holder with lock. - Microsoft Surface Pro 2 (For all countries)**  
Passive holder. 2 keys included. For Incipio Capture Case.



Item no 539600  
**Holder with lock. - Apple iPad 9.7 New (For all countries)**  
Passive holder with tilt swivel. 2 keys included. For device with Otterbox Defender Series case.



Item no 539600  
**Holder with lock. - Apple iPad Air (A1474, A1475, A1476) (For all countries)**  
Passive holder with tilt swivel. 2 keys included. For device with Otterbox Defender Series case.



Item no 539600  
**Holder with lock. - Apple iPad 5th Gen (A1822, A1823) (For all countries)**  
Passive holder with tilt swivel. 2 keys included. For device with Otterbox Defender Series case.



Item no 539600

**Holder with lock. - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**

Passive holder with tilt swivel. 2 keys included. For device with Otterbox Defender Series case.

---



Item no 539610

**Holder with lock. - Samsung Galaxy Tab PRO 12.2 Wi-Fi SM-T900 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539610

**Holder with lock. - Samsung Galaxy Note PRO 12.2 Wi-Fi SM-P900 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539610

**Holder with lock. - Samsung Galaxy Tab PRO 12.2 4G SM-T905 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539610

**Holder with lock. - Samsung Galaxy Note PRO 12.2 4G SM-P905 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539614

**Holder with lock. - Dell Venue 11 Pro, New (Model 7140) (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539614

**Holder with lock. - Dell Venue 11 Pro (Model 5130) (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539644

**Holder with lock. - Microsoft Surface Pro 3 (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 539672

**Holder with lock. - Dell Venue 8 Pro (For all countries)**

2 keys included. For device with Targus SafePORT Rugged Max Pro protective case.

---



Item no 539676

**Holder with lock. - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Passive holder with tilt swivel. For devices with original skin. With lock, 2 keys included.

---



Item no 539718

**Holder with lock. - Microsoft Surface Pro 3 (For all countries)**

Passive holder with tilt swivel. 2 keys included. For device with UAG case.

---



Item no 539759

**Holder with lock. - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Passive holder with tilt swivel. 2 keys included. For device with Otterbox Defender Series case.

---



Item no 539816

**Holder with lock. - Microsoft Surface Pro 6 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539816

**Holder with lock. - Microsoft Surface Pro 4 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539816

**Holder with lock. - Microsoft Surface Pro 7 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539816

**Holder with lock. - Microsoft Surface PRO 2017 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 539820

**Holder with lock. - Apple iPad Pro 12.9 (A1584, A1652, A1670, A1671) (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 539821  
**Holder with lock. - Samsung Galaxy Tab E 9.6 (For all countries)**  
Passive holder with tilt swivel. 2 keys included.

---



Item no 539827  
**Holder with lock. - Microsoft Surface Pro 6 (For all countries)**  
Passive holder with tilt swivel. 2 keys included. For device with UAG Case.

---



Item no 539827  
**Holder with lock. - Microsoft Surface Pro 4 (For all countries)**  
Passive holder with tilt swivel. 2 keys included. For device with UAG Case.

---



Item no 539827  
**Holder with lock. - Microsoft Surface Pro 7 (For all countries)**  
Passive holder with tilt swivel. 2 keys included. For device with UAG Case.

---



Item no 539827  
**Holder with lock. - Microsoft Surface PRO 2017 (For all countries)**  
Passive holder with tilt swivel. 2 keys included. For device with UAG Case.

---



Item no 539835  
**Holder with lock. - Samsung Galaxy Tab E 8.0 (For all countries)**  
Passive holder with tilt swivel. 2 keys included.

---



Item no 539852  
**Holder with lock. - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**  
Passive holder with tilt swivel. 2 keys included. For device with Otterbox Defender Series case.

---



Item no 539853  
**Holder with lock. - Samsung Galaxy Tab A 9.7 (For all countries)**  
Passive holder with tilt swivel. 2 keys included. For device with Otterbox Defender Series case.

---



Item no 539867  
**Holder with lock. - Microsoft Surface Pro 6 (For all countries)**  
Passive holder without tilt swivel. 2 keys included. For device with UAG Case.



Item no 539867

**Holder with lock. - Microsoft Surface Pro 7 (For all countries)**

Passive holder without tilt swivel. 2 keys included. For device with UAG Case.

---



Item no 539867

**Holder with lock. - Microsoft Surface Pro 4 (For all countries)**

Passive holder without tilt swivel. 2 keys included. For device with UAG Case.

---



Item no 539867

**Holder with lock. - Microsoft Surface PRO 2017 (For all countries)**

Passive holder without tilt swivel. 2 keys included. For device with UAG Case.

---



Item no 552600

**Holder with lock. - Apple iPad 9.7 New (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included. For Otterbox Defender Series.

---



Item no 552600

**Holder with lock. - Apple iPad Air (A1474, A1475, A1476) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included. For Otterbox Defender Series.

---



Item no 552600

**Holder with lock. - Apple iPad 5th Gen (A1822, A1823) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included. For Otterbox Defender Series.

---



Item no 552600

**Holder with lock. - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included. For Otterbox Defender Series.

---



Item no 552637

**Holder with lock. - Samsung Galaxy Tab 4 8.0 SM-T335 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included.

---



Item no 552652

**Holder with lock. - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included.



Item no 552652

**Holder with lock. - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included.

---



Item no 552681

**Holder with lock. - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)**

Active holder with USB-cable, with tilt swivel. 2 keys included. For Otterbox Defender Series case.

---



Item no 552681

**Holder with lock. - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)**

Active holder with USB-cable, with tilt swivel. 2 keys included. For Otterbox Defender Series case.

---



Item no 552681

**Holder with lock. - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)**

Active holder with USB-cable, with tilt swivel. 2 keys included. For Otterbox Defender Series case.

---



Item no 552682

**Holder with lock. - Samsung Galaxy Tab 4 7.0 SM-T230 (For all countries)**

Active holder with USB-cable. With tilt swivel. 2 keys included.

---



Item no 552682

**Holder with lock. - Samsung Galaxy Tab 4 7.0 SM-T231 (For all countries)**

Active holder with USB-cable. With tilt swivel. 2 keys included.

---



Item no 552682

**Holder with lock. - Samsung Galaxy Tab 4 7.0 SM-T235 (For all countries)**

Active holder with USB-cable. With tilt swivel. 2 keys included.

---



Item no 552759

**Holder with lock. - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included. For OtterBox Defender Series.





Item no 552760  
**Holder with lock. - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included.

---



Item no 552769  
**Holder with lock. - Samsung Galaxy Tab A 9.7 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included.

---



Item no 552781  
**Holder with lock. - Samsung Galaxy Tab S2 8.0 SM-T713 /SM-T719 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included.

---



Item no 552820  
**Holder with lock. - Apple iPad Pro 12.9 (A1584, A1652, A1670, A1671) (For all countries)**

Active holder with USB-cable. Apple approved charging cable. With tilt swivel. 2 keys included.

---



Item no 552821  
**Holder with lock. - Samsung Galaxy Tab E 9.6 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included.

---



Item no 552822  
**Holder with lock. - LG G Pad F 8.0 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included.

---



Item no 552835  
**Holder with lock. - Samsung Galaxy Tab E 8.0 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included.

---



Item no 552852  
**Holder with lock. - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included. For Otterbox Defender Series Case.



Item no 552853

**Holder with lock. - Samsung Galaxy Tab A 9.7 (For all countries)**

Active holder with USB-cable. With tilt swivel. With lock, 2 keys included. For Otterbox Defender Series Case.



Item no 735102

**Holder with lock. - Panasonic FZ-L1 (For all countries)**

Active holder with cig-plug and tilt swivel. 2 keys included. With USB Host.



Item no 735148

**Holder with lock. - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Active holder with cig-plug and tilt swivel. Fits for devices with original skin. 2 keys included.



Item no 735149

**Holder with lock. - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Active holder with cig-plug and tilt swivel. Fits for devices with original skin. 2 keys included. With USB Host.



Item no 735224

**Holder with lock. - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Active holder with cig-plug and tilt swivel. Fits for devices with original skin. 2 keys included. With Easy-switching system.



Item no 735224

**Holder with lock. - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**


Active holder with cig-plug and tilt swivel. Fits for devices with original skin. 2 keys included. With Easy-switching system.



Item no 735225

**Holder with lock. - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Active holder with cig-plug and tilt swivel. Fits for devices with original skin. 2 keys included. With USB Host. With Easy-switching system.



Item no 735225

**Holder with lock. - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Active holder with cig-plug and tilt swivel. Fits for devices with original skin. 2 keys included. With USB Host. With Easy-switching system.



Item no 735278

**Holder with lock. - Apple iPad Mini 6th Gen (A2567, A2568, A2569) (For all countries)**

With USB Type-C + cig-plug adapter with 2 USB ports: Type-A and Type-C. With tilt swivel. 12/24 Volt. 2 keys included.



Item no 735286

**Holder with lock. - Samsung Galaxy Tab A8 SM-X200/205 (For all countries)**

With USB-cable + cig-plug adapter with 2 USB Type-A ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2 keys included.

---



Item no 736094

**Holder with lock. - Apple iPad Pro 11 2018 (A1980, A2013, A1934, A1979) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included.

---



Item no 736094

**Holder with lock. - Apple iPad Pro 11 2021 3rd Generation (A2301, A2459) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included.

---



Item no 736094

**Holder with lock. - Apple iPad Pro 11 2020 2nd Generation (A2068, A2230) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included.

---



Item no 736094

**Holder with lock. - Apple iPad Air 4th Gen (A2072, A2316, A2324, A2325) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included.

---



Item no 736095

**Holder with lock. - Apple iPad Pro 12.9 2020 (A2069, A2232, A2229) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included.

---



Item no 736095

**Holder with lock. - Apple iPad Pro 12,9 2018 (A1876, A1895, A1983, A2014) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included.

---



Item no 736102

**Holder with lock. - Panasonic FZ-L1 (For all countries)**

Active holder for fixed installation, with tilt swivel. 2 keys included. With USB Host.

---



Item no 736148

**Holder with lock. - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Active holder for fixed installation, with tilt swivel. Fits for devices with original skin. 2 keys included.



Item no 736149

**Holder with lock. - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Active holder for fixed installation, with tilt swivel. Fits for devices with original skin. 2 keys included. With USB Host.



Item no 736168

**Holder with lock. - Apple iPad 10.2 8th Gen (A2428, A2429, A2430, A2270) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included.



Item no 736168

**Holder with lock. - Apple iPad 10.2 7th Gen (A2197, A2198, A2200) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included.



Item no 736168

**Holder with lock. - Apple iPad 10.2 9th Gen (A2602, A2603, A2604, A2605) (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included.



Item no 736208

**Holder with lock. - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Active for fixed installation. With easy-switch system and tilt swivel. With USB Host. Fits for devices with OtterBox uniVERSE case. 2 keys included.



Item no 736209

**Holder with lock. - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Active for fixed installation. With easy-switch system and tilt swivel. With USB Host. Fits for devices with OtterBox uniVERSE case. 2 keys included.



Item no 736224

**Holder with lock. - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**


Active holder, fixed installation. Tilt swivel. For devices with original skin. 2 keys. Easy-switching system. 2,5A charging.



Item no 736224

**Holder with lock. - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Active holder, fixed installation. Tilt swivel. For devices with original skin. 2 keys. Easy-switching system. 2,5A charging.



Item no 736225

**Holder with lock. - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Active holder, fixed installation. Tilt swivel. For original skin. 2 keys. USB Host. Easy-switching system. 2,5A charging.



Item no 736225

**Holder with lock. - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Active holder, fixed installation. Tilt swivel. For original skin. 2 keys. USB Host. Easy-switching system. 2,5A charging.

---



Item no 736229

**Holder with lock. - Samsung Galaxy Tab A7 10.4 (2020) SM-T500/SM-T505 (For all countries)**

Active holder for fixed installation. With tilt swivel. 2 keys included.

---



Item no 736271

**Holder with lock. - Lenovo Tab K10 TB-X6C6F (For all countries)**

**NEW!**

Active holder for fixed installation. With USB-cable. 2 USB ports: QC 3.0A + 2.4A. 12/24 Volt. 2A charging. With tilt swivel. 2 keys included. With AMPS, Vesa 75 holes.

---



Item no 736278

**Holder with lock. - Apple iPad Mini 6th Gen (A2567, A2568, A2569) (For all countries)**

Active holder for fixed installation. With USB-cable. 2 USB ports: QC 3.0A + 2.4A. 12/24 Volt. 2A charging. With tilt swivel. 2 keys included.

---



Item no 736286

**Holder with lock. - Samsung Galaxy Tab A8 SM-X200/205 (For all countries)**

Active holder for fixed installation. With USB-cable. 2 USB ports: QC 3.0A + 2.4A. 12/24 Volt. 2A charging. With tilt swivel. 2 keys included.

---



Item no 739046

**Holder with lock. - Logic Instrument Fieldbook K101 G2 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 739047

**Holder with lock. - Athesi E10B (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 739066

**Holder with lock. - Microsoft Surface Go 3 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 739066

**Holder with lock. - Microsoft Surface Go (For all countries)**

Passive holder with tilt swivel. 2 keys included.



Item no 739066

**Holder with lock. - Microsoft Surface Go 2 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 739101

**Holder with lock. - Panasonic FZ-L1 (For all countries)**

Passive holder with tilt swivel. With lock, 2 keys included.

---



Item no 739168

**Holder with lock. - Apple iPad 10.2 8th Gen (A2428, A2429, A2430, A2270) (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 739168

**Holder with lock. - Apple iPad 10.2 7th Gen (A2197, A2198, A2200) (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 739168

**Holder with lock. - Apple iPad 10.2 9th Gen (A2602, A2603, A2604, A2605) (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 739229

**Holder with lock. - Samsung Galaxy Tab A7 10.4 (2020) SM-T500/SM-T505 (For all countries)**

Passive holder with tilt swivel. 2 keys included.

---



Item no 739241

**Holder with lock. - Logic Instrument Fieldbook N101 (For all countries)**

Passive holder. 2 keys included. With AMPS, Vesa 75/100 holes.

---



Item no 739285

**Holder with lock. - Honeywell RT10 (For all countries)**

Passive holder. Fits devices with and without handstrap. With AMPS, Vesa 75 holes. 2 keys included.

---



Item no 739287

**Holder with lock. - Getac F110 6th Gen (For all countries)**

Passive holder. Fits devices with and without handstrap. With AMPS, Vesa 75/100 holes. 2 keys included.

---



Item no 739290

**Holder with lock. - Microsoft Surface Pro 8 (For all countries)**

Passive holder with tilt swivel. 2 keys included. For use with a naked device (not for use with a case).



Item no 752002

**Holder with lock. - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

**NEW!**

With USB-cable + cig-plug adapter with 2 USB Type-A ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2 keys included.

---



Item no 752002

**Holder with lock. - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

**NEW!**

With USB-cable + cig-plug adapter with 2 USB Type-A ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2 keys included.

---



Item no 752094

**Holder with lock. - Apple iPad Pro 11 2021 3rd Generation (A2301, A2459) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.

---



Item no 752094

**Holder with lock. - Apple iPad Pro 11 2018 (A1980, A2013, A1934, A1979) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.

---



Item no 752094

**Holder with lock. - Apple iPad Air 4th Gen (A2072, A2316, A2324, A2325) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.

---



Item no 752094

**Holder with lock. - Apple iPad Pro 11 2020 2nd Generation (A2068, A2230) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.

---



Item no 752095

**Holder with lock. - Apple iPad Pro 12.9 2020 (A2069, A2232, A2229) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.

---



Item no 752095

**Holder with lock. - Apple iPad Pro 12.9 (5th Gen 2021) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.

---



Item no 752095

**Holder with lock. - Apple iPad Pro 12,9 2018 (A1876, A1895, A1983, A2014) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. 2 keys included.



Item no 752168

**Holder with lock. - Apple iPad 10.2 9th Gen (A2602, A2603, A2604, A2605) (For all countries)**

Active holder with USB cable and cig-plug adapter. With tilt swivel. 2 keys included.



Item no 752168

**Holder with lock. - Apple iPad 10.2 7th Gen (A2197, A2198, A2200) (For all countries)**

Active holder with USB cable and cig-plug adapter. With tilt swivel. 2 keys included.



Item no 752168

**Holder with lock. - Apple iPad 10.2 8th Gen (A2428, A2429, A2430, A2270) (For all countries)**

Active holder with USB cable and cig-plug adapter. With tilt swivel. 2 keys included.



Item no 752229

**Holder with lock. - Samsung Galaxy Tab A7 10.4 (2020) SM-T500/SM-T505 (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2 keys included.



Item no 752271

**Holder with lock. - Lenovo Tab K10 TB-X6C6F (For all countries)**

**NEW!**

With USB-cable + cig-plug adapter with 2 USB Type-A ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. 2 keys included. With AMPS, Vesa 75 holes.

## Holder for Locking



Item no 241670

**Holder for Locking - Zebra ET50 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75/100 holes. Fits devices with rugged frame.



Item no 241670

**Holder for Locking - Zebra ET55 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75/100 holes. Fits devices with rugged frame.



Item no 241670

**Holder for Locking - Zebra ET51 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75/100 holes. Fits devices with rugged frame.



Item no 241670

**Holder for Locking - Zebra ET56 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75/100 holes. Fits devices with rugged frame.





Item no 241695

**Holder for Locking - Zebra ET50 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75 holes. Fits devices with rugged frame, with and without expansion module/handstrap.



Item no 241695

**Holder for Locking - Zebra ET55 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75 holes. Fits devices with rugged frame, with and without expansion module/handstrap.



Item no 241695

**Holder for Locking - Zebra ET56 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75 holes. Fits devices with rugged frame, with and without expansion module/handstrap.



Item no 241695

**Holder for Locking - Zebra ET51 10.1 (For all countries)**

Passive holder. With AMPS, Vesa 75 holes. Fits devices with rugged frame, with and without expansion module/handstrap.



Item no 514460

**Holder for Locking - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**

For cable attachment, for use with Apple original Lightning to USB Cable. With tilt swivel. With spring stud locking.



Item no 514461

**Holder for Locking - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**

For cable attachment, for use with Apple original Lightning to 30-pin Adapter Cable. With tilt swivel. With spring stud locking.



Item no 541209

**Holder for Locking - Samsung Galaxy Tab GT-P1000 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 541244

**Holder for Locking - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 541244

**Holder for Locking - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 541244

**Holder for Locking - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541244

**Holder for Locking - Apple iPad With Retina (Lightning Connector) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541300

**Holder for Locking - Samsung Galaxy Tab 8.9 GT-P7300 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541329

**Holder for Locking - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541329

**Holder for Locking - Samsung Galaxy Tab 10.1 SCH-I905 (For USA)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541366

**Holder for Locking - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For OtterBox Defender Series.

---



Item no 541366

**Holder for Locking - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For OtterBox Defender Series.

---



Item no 541366

**Holder for Locking - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For OtterBox Defender Series.



Item no 541366

**Holder for Locking - Apple iPad With Retina (Lightning Connector) (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For OtterBox Defender Series.

---



Item no 541448

**Holder for Locking - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541491

**Holder for Locking - Microsoft Surface Pro 2 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541517

**Holder for Locking - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For Lifeproof Case.

---



Item no 541517

**Holder for Locking - Apple iPad With Retina (Lightning Connector) (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For Lifeproof Case.

---



Item no 541517

**Holder for Locking - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For Lifeproof Case.

---



Item no 541517

**Holder for Locking - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For Lifeproof Case.

---



Item no 541549

**Holder for Locking - Samsung Galaxy Tab 3 10.1 GT-P5210 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 541549

**Holder for Locking - Samsung Galaxy Tab 3 10.1 GT-P5220 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541549

**Holder for Locking - Samsung Galaxy Tab 3 10.1 GT-P5200 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541560

**Holder for Locking - Google Nexus 7 (2013) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541560

**Holder for Locking - Asus Google Nexus 7 (2013) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541560

**Holder for Locking - Nexus 7 (2013) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541577

**Holder for Locking - Apple iPad 9.7 New (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541577

**Holder for Locking - Apple iPad Air (A1474, A1475, A1476) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541577

**Holder for Locking - Apple iPad 5th Gen (A1822, A1823) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541577

**Holder for Locking - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 541585  
**Holder for Locking - Dell Latitude 10 - ST2 (For all countries)**  
Passive holder with tilt swivel. With spring stud locking.



Item no 541587  
**Holder for Locking - Microsoft Surface Pro 2 (For all countries)**  
Passive holder. With spring stud locking. For Incipio Capture Case.



Item no 541600  
**Holder for Locking - Apple iPad 9.7 New (For all countries)**  
Passive holder with tilt swivel. With spring stud locking. For device with Otterbox Defender Series case.



Item no 541600  
**Holder for Locking - Apple iPad Air (A1474, A1475, A1476) (For all countries)**  
Passive holder with tilt swivel. With spring stud locking. For device with Otterbox Defender Series case.



Item no 541600  
**Holder for Locking - Apple iPad 5th Gen (A1822, A1823) (For all countries)**  
Passive holder with tilt swivel. With spring stud locking. For device with Otterbox Defender Series case.




Item no 541600  
**Holder for Locking - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**  
Passive holder with tilt swivel. With spring stud locking. For device with Otterbox Defender Series case.



Item no 541610  
**Holder for Locking - Samsung Galaxy Tab PRO 12.2 Wi-Fi SM-T900 (For all countries)**  
Passive holder with tilt swivel. With spring stud locking.



Item no 541610  
**Holder for Locking - Samsung Galaxy Note PRO 12.2 Wi-Fi SM-P900 (For all countries)**  
Passive holder with tilt swivel. With spring stud locking.



Item no 541610  
**Holder for Locking - Samsung Galaxy Tab PRO 12.2 4G SM-T905 (For all countries)**  
Passive holder with tilt swivel. With spring stud locking.



Item no 541610  
**Holder for Locking - Samsung Galaxy Note PRO 12.2 4G SM-P905 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541614  
**Holder for Locking - Dell Venue 11 Pro, New (Model 7140) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541614  
**Holder for Locking - Dell Venue 11 Pro (Model 5130) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541644  
**Holder for Locking - Microsoft Surface Pro 3 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541676  
**Holder for Locking - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Passiv holder with tilt swivel. Fits for devices with original skin. With spring stud locking.

---



Item no 541759  
**Holder for Locking - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For device with Otterbox Defender Series case.

---



Item no 541816  
**Holder for Locking - Microsoft Surface Pro 4 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541816  
**Holder for Locking - Microsoft Surface Pro 7 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 541816  
**Holder for Locking - Microsoft Surface Pro 6 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 541816

**Holder for Locking - Microsoft Surface PRO 2017 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 541820

**Holder for Locking - Apple iPad Pro 12.9 (A1584, A1652, A1670, A1671) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 541821

**Holder for Locking - Samsung Galaxy Tab E 9.6 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 541835

**Holder for Locking - Samsung Galaxy Tab E 8.0 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 541852

**Holder for Locking - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For device with Otterbox Defender Series case.



Item no 541853

**Holder for Locking - Samsung Galaxy Tab A 9.7 (For all countries)**

Passive holder with tilt swivel. With spring stud locking. For device with Otterbox Defender Series case.



Item no 546261

**Holder for Locking - Samsung Galaxy Tab GT-P1000 (For all countries)**

With Cigarette Lighter Cable. With tilt swivel. With spring stud locking. For OtterBox Defender Series.



Item no 546287

**Holder for Locking - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)**

Active holder with cig-plug and tilt swivel. With spring stud locking.



Item no 546395

**Holder for Locking - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking. For OtterBox Defender Series.



Item no 546494

**Holder for Locking - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

For cable attachment, for use with Apple original Lightning to USB Cable. With tilt swivel. With spring stud locking.



Item no 546494

**Holder for Locking - Apple iPad With Retina (Lightning Connector) (For all countries)**

For cable attachment, for use with Apple original Lightning to USB Cable. With tilt swivel. With spring stud locking.



Item no 546543

**Holder for Locking - Samsung Galaxy Tab 3 7.0 SM-T2110 (For all countries)**

With Cigarette Lighter Cable. With tilt swivel. With spring stud locking.



Item no 546543

**Holder for Locking - Samsung Galaxy Tab 3 7.0 SM-T210 (For all countries)**

With Cigarette Lighter Cable. With tilt swivel. With spring stud locking.



Item no 546549

**Holder for Locking - Samsung Galaxy Tab 3 10.1 GT-P5210 (For all countries)**

Active holder with cig-plug. With spring stud locking.



Item no 546549

**Holder for Locking - Samsung Galaxy Tab 3 10.1 GT-P5220 (For all countries)**

Active holder with cig-plug. With spring stud locking.



Item no 546549

**Holder for Locking - Samsung Galaxy Tab 3 10.1 GT-P5200 (For all countries)**

Active holder with cig-plug. With spring stud locking.





Item no 546560

**Holder for Locking - Google Nexus 7 (2013) (For all countries)**

With Cigarette Lighter Cable. With tilt swivel. With spring stud locking.



Item no 546560

**Holder for Locking - Asus Google Nexus 7 (2013) (For all countries)**

With Cigarette Lighter Cable. With tilt swivel. With spring stud locking.



Item no 546560

**Holder for Locking - Nexus 7 (2013) (For all countries)**

With Cigarette Lighter Cable. With tilt swivel. With spring stud locking.



Item no 546577

**Holder for Locking - Apple iPad 9.7 New (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.



Item no 546577

**Holder for Locking - Apple iPad Air (A1474, A1475, A1476) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.



Item no 546577

**Holder for Locking - Apple iPad 5th Gen (A1822, A1823) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.



Item no 546577

**Holder for Locking - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.



Item no 546579

**Holder for Locking - Dell Venue 8 Pro (For all countries)**

Active holder with cig-plug, 12/24V. With spring stud locking.



Item no 546584

**Holder for Locking - Apple iPad Mini 2 (A1489, A1490, A1491) (For all countries)**

Active holder with USB cable. Apple approved charging cable. With tilt swivel. With spring stud locking.



Item no 546584

**Holder for Locking - Apple iPad Mini Retina (For all countries)**

Active holder with USB cable. Apple approved charging cable. With tilt swivel. With spring stud locking.



Item no 546584

**Holder for Locking - Apple iPad Mini 3 (A1599, A1600) (For all countries)**

Active holder with USB cable. Apple approved charging cable. With tilt swivel. With spring stud locking.



Item no 546632

**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)**

Active holder with USB cable and tilt swivel. With spring stud locking.



Item no 546632

**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)**

Active holder with USB cable and tilt swivel. With spring stud locking.



Item no 546632

**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)**

Active holder with USB cable and tilt swivel. With spring stud locking.



Item no 546637

**Holder for Locking - Samsung Galaxy Tab 4 8.0 SM-T335 (For all countries)**

Active holder with cig-plug. With tilt swivel. With spring stud locking.



Item no 546652

**Holder for Locking - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)**

Active holder with cig-plug. With tilt swivel. With spring stud locking.



Item no 546652

**Holder for Locking - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)**

Active holder with cig-plug. With tilt swivel. With spring stud locking.

---



Item no 546676

**Holder for Locking - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Active holder with cig-plug. With spring stud locking. Fits for devices with original skin.

---



Item no 546682

**Holder for Locking - Samsung Galaxy Tab 4 7.0 SM-T230 (For all countries)**

Active holder with cig-plug. With spring stud locking.

---



Item no 546682

**Holder for Locking - Samsung Galaxy Tab 4 7.0 SM-T231 (For all countries)**

Active holder with cig-plug. With spring stud locking.

---



Item no 546682

**Holder for Locking - Samsung Galaxy Tab 4 7.0 SM-T235 (For all countries)**

Active holder with cig-plug. With spring stud locking.

---



Item no 546684

**Holder for Locking - Apple iPad Pro 9.7 (A1673, A1674, A1675) (For all countries)**

Active holder with cig-plug. With tilt swivel. With spring stud locking.

---



Item no 546684

**Holder for Locking - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Active holder with cig-plug. With tilt swivel. With spring stud locking.



Item no 546708  
**Holder for Locking - LG G Pad 7.0 (For all countries)**  
Active holder with cig-plug. With spring stud locking.



Item no 546769  
**Holder for Locking - Samsung Galaxy Tab A 9.7 (For all countries)**  
Active holder with cig-plug. With tilt swivel. With spring stud locking.



Item no 546821  
**Holder for Locking - Samsung Galaxy Tab E 9.6 (For all countries)**  
Active holder with cig-plug. With tilt swivel. With spring stud locking.



Item no 546835  
**Holder for Locking - Samsung Galaxy Tab E 8.0 (For all countries)**  
Active holder with cig-plug. With tilt swivel. With spring stud locking.



Item no 546852  
**Holder for Locking - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**  
Active holder with cig-plug. With tilt swivel. With spring stud locking. For Otterbox Defender Series Case.



Item no 546853  
**Holder for Locking - Samsung Galaxy Tab A 9.7 (For all countries)**  
Active holder with cig-plug. With tilt swivel. With spring stud locking. For Otterbox Defender Series Case.



Item no 547261  
**Holder for Locking - Samsung Galaxy Tab GT-P1000 (For all countries)**  
For fixed installation. With tilt swivel. With spring stud locking. For OtterBox Defender Series.



Item no 547287  
**Holder for Locking - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)**  
Active holder for fixed installation, with tilt swivel. With spring stud locking.



Item no 547395

**Holder for Locking - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking. For OtterBox Defender Series.



Item no 547543

**Holder for Locking - Samsung Galaxy Tab 3 7.0 SM-T210 (For all countries)**

For fixed installation. With tilt swivel. With spring stud locking.



Item no 547543

**Holder for Locking - Samsung Galaxy Tab 3 7.0 SM-T2110 (For all countries)**

For fixed installation. With tilt swivel. With spring stud locking.



Item no 547549

**Holder for Locking - Samsung Galaxy Tab 3 10.1 GT-P5220 (For all countries)**

Active holder for fixed installation. With spring stud locking.



Item no 547549

**Holder for Locking - Samsung Galaxy Tab 3 10.1 GT-P5210 (For all countries)**

Active holder for fixed installation. With spring stud locking.



Item no 547549

**Holder for Locking - Samsung Galaxy Tab 3 10.1 GT-P5200 (For all countries)**

Active holder for fixed installation. With spring stud locking.



Item no 547560

**Holder for Locking - Google Nexus 7 (2013) (For all countries)**

For fixed installation. With tilt swivel. With spring stud locking.



Item no 547560

**Holder for Locking - Asus Google Nexus 7 (2013) (For all countries)**

For fixed installation. With tilt swivel. With spring stud locking.



Item no 547560

**Holder for Locking - Nexus 7 (2013) (For all countries)**

For fixed installation. With tilt swivel. With spring stud locking.



Item no 547577

**Holder for Locking - Apple iPad 9.7 New (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.



Item no 547577

**Holder for Locking - Apple iPad Air (A1474, A1475, A1476) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.



Item no 547577

**Holder for Locking - Apple iPad 5th Gen (A1822, A1823) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.



Item no 547577

**Holder for Locking - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.



Item no 547579

**Holder for Locking - Dell Venue 8 Pro (For all countries)**

Active holder for fixed installation. With spring stud locking.



Item no 547584

**Holder for Locking - Apple iPad Mini 2 (A1489, A1490, A1491) (For all countries)**

For fixed installation. With tilt swivel. With spring stud locking.



Item no 547584

**Holder for Locking - Apple iPad Mini Retina (For all countries)**

For fixed installation. With tilt swivel. With spring stud locking.



Item no 547584  
**Holder for Locking - Apple iPad Mini 3 (A1599, A1600) (For all countries)**  
For fixed installation. With tilt swivel. With spring stud locking.



Item no 547600  
**Holder for Locking - Apple iPad 9.7 New (For all countries)**  
Active holder for fixed installation. With tilt swivel. With spring stud locking. For Otterbox Defender Series.



Item no 547600  
**Holder for Locking - Apple iPad Air (A1474, A1475, A1476) (For all countries)**  
Active holder for fixed installation. With tilt swivel. With spring stud locking. For Otterbox Defender Series.



Item no 547600  
**Holder for Locking - Apple iPad 5th Gen (A1822, A1823) (For all countries)**  
Active holder for fixed installation. With tilt swivel. With spring stud locking. For Otterbox Defender Series.



Item no 547600  
**Holder for Locking - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**  
Active holder for fixed installation. With tilt swivel. With spring stud locking. For Otterbox Defender Series.



Item no 547632  
**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)**  
Active holder for fixed installation. With spring stud locking.



Item no 547632  
**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)**  
Active holder for fixed installation. With spring stud locking.



Item no 547632  
**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)**  
Active holder for fixed installation. With spring stud locking.



Item no 547637

**Holder for Locking - Samsung Galaxy Tab 4 8.0 SM-T335 (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547652

**Holder for Locking - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)**

Active holder or fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547652

**Holder for Locking - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)**

Active holder or fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547676

**Holder for Locking - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

Active holder for fixed installation. With spring stud locking. Fits for devices with original skin. 2,5A charger.

---



Item no 547681

**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)**

Active holder for fixed installation. With spring stud locking. For Otterbox Defender Series case.

---



Item no 547681

**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)**

Active holder for fixed installation. With spring stud locking. For Otterbox Defender Series case.

---



Item no 547681

**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)**

Active holder for fixed installation. With spring stud locking. For Otterbox Defender Series case.

---



Item no 547682

**Holder for Locking - Samsung Galaxy Tab 4 7.0 SM-T230 (For all countries)**

Active holder for fixed installation. With spring stud locking.





Item no 547682

**Holder for Locking - Samsung Galaxy Tab 4 7.0 SM-T231 (For all countries)**

Active holder for fixed installation. With spring stud locking.

---



Item no 547682

**Holder for Locking - Samsung Galaxy Tab 4 7.0 SM-T235 (For all countries)**

Active holder for fixed installation. With spring stud locking.

---



Item no 547684

**Holder for Locking - Apple iPad Pro 9.7 (A1673, A1674, A1675) (For all countries)**

Active holder or fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547684

**Holder for Locking - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Active holder or fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547708

**Holder for Locking - LG G Pad 7.0 (For all countries)**

Active holder for fixed installation. With spring stud locking.

---



Item no 547759

**Holder for Locking - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking. For OtterBox Defender Series.



Item no 547760

**Holder for Locking - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

Active holder or fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547769

**Holder for Locking - Samsung Galaxy Tab A 9.7 (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547820

**Holder for Locking - Apple iPad Pro 12.9 (A1584, A1652, A1670, A1671) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547821

**Holder for Locking - Samsung Galaxy Tab E 9.6 (For all countries)**

Active holder or fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547822

**Holder for Locking - LG G Pad F 8.0 (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547835

**Holder for Locking - Samsung Galaxy Tab E 8.0 (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 547852

**Holder for Locking - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

Active holder or fixed installation. With tilt swivel. With spring stud locking. For Otterbox Defender Series Case.

---



Item no 547853

**Holder for Locking - Samsung Galaxy Tab A 9.7 (For all countries)**

Active holder or fixed installation. With tilt swivel. With spring stud locking. For Otterbox Defender Series Case.



Item no 553600

**Holder for Locking - Apple iPad 9.7 New (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking. For Otterbox Defender Series.

---



Item no 553600

**Holder for Locking - Apple iPad Air (A1474, A1475, A1476) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking. For Otterbox Defender Series.

---



Item no 553600

**Holder for Locking - Apple iPad 5th Gen (A1822, A1823) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking. For Otterbox Defender Series.

---



Item no 553600

**Holder for Locking - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking. For Otterbox Defender Series.

---



Item no 553652

**Holder for Locking - Samsung Galaxy Tab S 8.4 SM-T705 (For all countries)**

Active holder with USB cable.. With tilt swivel. With spring stud locking.

---



Item no 553652

**Holder for Locking - Samsung Galaxy Tab S 8.4 SM-T700 (For all countries)**

Active holder with USB cable.. With tilt swivel. With spring stud locking.

---



Item no 553681

**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)**

Active holder with USB-cable, with tilt swivel. With spring stud locking. For Otterbox Defender Series case.

---



Item no 553681

**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)**

Active holder with USB-cable, with tilt swivel. With spring stud locking. For Otterbox Defender Series case.

---



Item no 553681

**Holder for Locking - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)**

Active holder with USB-cable, with tilt swivel. With spring stud locking. For Otterbox Defender Series case.

---



Item no 553759

**Holder for Locking - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking. For OtterBox Defender Series.



Item no 553760

**Holder for Locking - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

Active holder with USB cable.. With tilt swivel. With spring stud locking.



Item no 553769

**Holder for Locking - Samsung Galaxy Tab A 9.7 (For all countries)**

Active holder with USB-cable. With tilt swivel. With spring stud locking.



Item no 553820

**Holder for Locking - Apple iPad Pro 12.9 (A1584, A1652, A1670, A1671) (For all countries)**

Active holder with USB-cable. Apple approved charging cable. With tilt swivel. With spring stud locking.



Item no 553821

**Holder for Locking - Samsung Galaxy Tab E 9.6 (For all countries)**

Active holder with USB cable.. With tilt swivel. With spring stud locking.



Item no 553835

**Holder for Locking - Samsung Galaxy Tab E 8.0 (For all countries)**

Active holder with USB-cable. With tilt swivel. With spring stud locking.



Item no 553852

**Holder for Locking - Samsung Galaxy Tab A 8.0 (2015) SM-T350 (For all countries)**

Active holder with USB cable.. With tilt swivel. With spring stud locking. For Otterbox Defender Series Case.



Item no 553853

**Holder for Locking - Samsung Galaxy Tab A 9.7 (For all countries)**

Active holder with USB cable.. With tilt swivel. With spring stud locking. For Otterbox Defender Series Case.



Item no 741046

**Holder for Locking - Logic Instrument Fieldbook K101 G2 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 741047

**Holder for Locking - Athesi E10B (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 741066

**Holder for Locking - Microsoft Surface Go 3 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 741066

**Holder for Locking - Microsoft Surface Go (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 741066

**Holder for Locking - Microsoft Surface Go 2 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 741101

**Holder for Locking - Panasonic FZ-L1 (For all countries)**

Passiv holder with tilt swivel. With spring stud locking.

---



Item no 741168

**Holder for Locking - Apple iPad 10.2 8th Gen (A2428, A2429, A2430, A2270) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 741168

**Holder for Locking - Apple iPad 10.2 9th Gen (A2602, A2603, A2604, A2605) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 741168

**Holder for Locking - Apple iPad 10.2 7th Gen (A2197, A2198, A2200) (For all countries)**

Passive holder with tilt swivel. With spring stud locking.

---



Item no 741229

**Holder for Locking - Samsung Galaxy Tab A7 10.4 (2020) SM-T500/SM-T505 (For all countries)**

Passive holder with tilt swivel. With spring stud locking.



Item no 741241

**Holder for Locking - Logic Instrument Fieldbook N101 (For all countries)**

Passive holder. With AMPS, Vesa 75/100 holes.

---



Item no 741287

**Holder for Locking - Getac F110 6th Gen (For all countries)**

Passive holder. Fits devices with and without handstrap. With AMPS, Vesa 75/100 holes.

---



Item no 746102

**Holder for Locking - Panasonic FZ-L1 (For all countries)**

Active holder with cig-plug. With spring stud locking. With USB Host.

---



Item no 746148

**Holder for Locking - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Active holder with cig-plug. With spring stud locking. Fits for devices with original skin.

---



Item no 746149

**Holder for Locking - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Active holder with cig-plug. With spring stud locking. Fits for devices with original skin. With USB Host.

---



Item no 746224

**Holder for Locking - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Active holder with cig-plug. With spring stud locking. Fits for devices with original skin. With Easy-switching system.

---



Item no 746224

**Holder for Locking - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Active holder with cig-plug. With spring stud locking. Fits for devices with original skin. With Easy-switching system.

---



Item no 746225

**Holder for Locking - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Active holder with cig-plug. With spring stud locking. Fits for devices with original skin. With USB Host. With Easy-switching system.

---



Item no 746225

**Holder for Locking - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Active holder with cig-plug. With spring stud locking. Fits for devices with original skin. With USB Host. With Easy-switching system.



Item no 746286

**Holder for Locking - Samsung Galaxy Tab A8 SM-X200/205 (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. With spring stud locking.

---



Item no 747094

**Holder for Locking - Apple iPad Pro 11 2018 (A1980, A2013, A1934, A1979) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 747094

**Holder for Locking - Apple iPad Pro 11 2021 3rd Generation (A2301, A2459) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 747094

**Holder for Locking - Apple iPad Air 4th Gen (A2072, A2316, A2324, A2325) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 747094

**Holder for Locking - Apple iPad Pro 11 2020 2nd Generation (A2068, A2230) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 747095

**Holder for Locking - Apple iPad Pro 12.9 2020 (A2069, A2232, A2229) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 747095

**Holder for Locking - Apple iPad Pro 12,9 2018 (A1876, A1895, A1983, A2014) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 747102

**Holder for Locking - Panasonic FZ-L1 (For all countries)**

Active holder for fixed installation. With spring stud locking. With USB Host.

---



Item no 747148

**Holder for Locking - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Active holder for fixed installation. With spring stud locking. Fits for devices with original skin.



Item no 747149  
**Holder for Locking - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

Active holder for fixed installation. With spring stud locking. Fits for devices with original skin. With USB Host.

---



Item no 747168  
**Holder for Locking - Apple iPad 10.2 8th Gen (A2428, A2429, A2430, A2270) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 747168  
**Holder for Locking - Apple iPad 10.2 7th Gen (A2197, A2198, A2200) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.


---



Item no 747168  
**Holder for Locking - Apple iPad 10.2 9th Gen (A2602, A2603, A2604, A2605) (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 747224  
**Holder for Locking - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Active holder for fixed installation. With spring stud locking. Fits original skin. Easy-switching system. 2,5A charging.

---



Item no 747224  
**Holder for Locking - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Active holder for fixed installation. With spring stud locking. Fits original skin. Easy-switching system. 2,5A charging.

---



Item no 747225  
**Holder for Locking - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

Active holder, fixed installation. With spring stud locking. For original skin. USB Host. Easy-switching system. 2,5A charging.

---



Item no 747225  
**Holder for Locking - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

Active holder, fixed installation. With spring stud locking. For original skin. USB Host. Easy-switching system. 2,5A charging.

---



Item no 747229  
**Holder for Locking - Samsung Galaxy Tab A7 10.4 (2020) SM-T500/SM-T505 (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.





Item no 747286

**Holder for Locking - Samsung Galaxy Tab A8 SM-X200/205 (For all countries)**

Active holder for fixed installation. With tilt swivel. With spring stud locking.

---



Item no 753094

**Holder for Locking - Apple iPad Pro 11 2021 3rd Generation (A2301, A2459) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.

---



Item no 753094

**Holder for Locking - Apple iPad Pro 11 2018 (A1980, A2013, A1934, A1979) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.

---



Item no 753094

**Holder for Locking - Apple iPad Pro 11 2020 2nd Generation (A2068, A2230) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.

---



Item no 753094

**Holder for Locking - Apple iPad Air 4th Gen (A2072, A2316, A2324, A2325) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.

---



Item no 753095

**Holder for Locking - Apple iPad Pro 12.9 2020 (A2069, A2232, A2229) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.

---



Item no 753095

**Holder for Locking - Apple iPad Pro 12,9 2018 (A1876, A1895, A1983, A2014) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.

---



Item no 753095

**Holder for Locking - Apple iPad Pro 12.9 (5th Gen 2021) (For all countries)**

Active holder with cig-plug and USB cable. With tilt swivel. With spring stud locking.

---



Item no 753168

**Holder for Locking - Apple iPad 10.2 9th Gen (A2602, A2603, A2604, A2605) (For all countries)**

Active holder with USB cable and cig-plug adapter. With tilt swivel. With spring stud locking.



Item no 753168

**Holder for Locking - Apple iPad 10.2 7th Gen (A2197, A2198, A2200) (For all countries)**

Active holder with USB cable and cig-plug adapter. With tilt swivel. With spring stud locking.



Item no 753168

**Holder for Locking - Apple iPad 10.2 8th Gen (A2428, A2429, A2430, A2270) (For all countries)**

Active holder with USB cable and cig-plug adapter. With tilt swivel. With spring stud locking.



Item no 753229

**Holder for Locking - Samsung Galaxy Tab A7 10.4 (2020) SM-T500/SM-T505 (For all countries)**

With USB-cable + cig-plug adapter with 2 USB ports: QC 3.0A + 2.4A. With tilt swivel. 12/24 Volt. With spring stud locking.

## MultiStand



Item no 215483

**MultiStand - Apple iPad With Retina (Lightning Connector) (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215483

**MultiStand - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215483

**MultiStand - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215483

**MultiStand - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215506

**MultiStand - Samsung Galaxy Tab 8.9 GT-P7300 (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215512  
**MultiStand - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)**  
Mounting Adapter and Screws Included. Black.



Item no 215512  
**MultiStand - Samsung Galaxy Tab 10.1 SCH-I905 (For USA)**  
Mounting Adapter and Screws Included. Black.



Item no 215520  
**MultiStand - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**  
Mounting Adapter and Screws Included. With spring stud locking. For OtterBox Defender Series.



Item no 215520  
**MultiStand - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**  
Mounting Adapter and Screws Included. With spring stud locking. For OtterBox Defender Series.



Item no 215520  
**MultiStand - Apple iPad With Retina (Lightning Connector) (For all countries)**  
Mounting Adapter and Screws Included. With spring stud locking. For OtterBox Defender Series.



Item no 215520  
**MultiStand - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**  
Mounting Adapter and Screws Included. With spring stud locking. For OtterBox Defender Series.



Item no 215544  
**MultiStand - Samsung Galaxy Tab 2 7.0 (For all countries)**  
Mounting Adapter and Screws Included.



Item no 215544  
**MultiStand - Samsung Galaxy Tab 7.0 Plus GT-P6200 (For all countries)**  
Mounting Adapter and Screws Included.



Item no 215554  
**MultiStand - Samsung Galaxy Tab 2 10.1 (For all countries)**  
Mounting Adapter and Screws Included. Black.



Item no 215577  
**MultiStand - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**  
Mounting Adapter and Screws Included. Black.



Item no 215592  
**MultiStand - Apple iPad Mini 3 (A1599, A1600) (For all countries)**  
Mounting Adapter and Screws Included. Black.



Item no 215592  
**MultiStand - Apple iPad Mini Retina (For all countries)**  
Mounting Adapter and Screws Included. Black.



Item no 215592  
**MultiStand - Apple iPad Mini 2 (A1489, A1490, A1491) (For all countries)**  
Mounting Adapter and Screws Included. Black.



Item no 215661  
**MultiStand - Apple iPad 9.7 New (For all countries)**  
Mounting Adapter and Screws Included. For Otterbox Defender Series.



Item no 215661  
**MultiStand - Apple iPad 5th Gen (A1822, A1823) (For all countries)**  
Mounting Adapter and Screws Included. For Otterbox Defender Series.



Item no 215661  
**MultiStand - Apple iPad Air (A1474, A1475, A1476) (For all countries)**  
Mounting Adapter and Screws Included. For Otterbox Defender Series.



Item no 215661  
**MultiStand - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**  
Mounting Adapter and Screws Included. For Otterbox Defender Series.



Item no 215698  
**MultiStand - Samsung Galaxy Tab 4 10.1 SM-T535 (For all countries)**  
Mounting Adapter and Screws Included.



Item no 215698  
**MultiStand - Samsung Galaxy Tab 4 10.1 SM-T530 (For all countries)**  
Mounting Adapter and Screws Included.



Item no 215698

**MultiStand - Samsung Galaxy Tab 4 10.1 SM-T531 (For all countries)**

Mounting Adapter and Screws Included.



Item no 215722

**MultiStand - Apple iPad Pro 9.7 (A1673, A1674, A1675) (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215722

**MultiStand - Apple iPad Air 2 (A1566, A1567) (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215738

**MultiStand - Apple iPad 9.7 New (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215738

**MultiStand - Apple iPad 9.7 6th Gen (A1893, A1954) (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215738

**MultiStand - Apple iPad 5th Gen (A1822, A1823) (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215738

**MultiStand - Apple iPad Air (A1474, A1475, A1476) (For all countries)**

Mounting Adapter and Screws Included. Black.



Item no 215780

**MultiStand (For all countries)**

MultiStand support leg, for larger surfpads. Length: 120 mm. Mounting Adapter and Screws Included. Black.



Item no 215781

**MultiStand (For all countries)**

MultiStand support leg, for smaller surfpads. Length: 98 mm. Mounting Adapter and Screws Included. Black.

## Table Stand



Item no 215735

**Table Stand - Samsung Galaxy Tab Active 8.0 SM-T365 (For all countries)**

5 way desktop charging dock. Fits for devices with original skin.



Item no 215985

**Table Stand - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

5 way desktop charging dock. With power cable, worldwide adapters included. Fits for devices with original skin.



Item no 216080

**Table Stand - Samsung Galaxy Tab Active Pro T540/T545/T547/T547U (For all countries)**

4-way desktop charging dock. With power cable, worldwide adapters included. Fits for devices with original skin.



Item no 216080

**Table Stand - Samsung Galaxy Tab Active 3 SM-T570/SM-T575 (For all countries)**

4-way desktop charging dock. With power cable, worldwide adapters included. Fits for devices with original skin.



Item no 216080

**Table Stand - Samsung Galaxy Tab Active 2 SM-T390/SM-T395 (For all countries)**

4-way desktop charging dock. With power cable, worldwide adapters included. Fits for devices with original skin.

## Holder for Cable Attachment



Item no 514209

**Holder for Cable Attachment - Samsung Galaxy Tab GT-P1000 (For all countries)**

For Samsung Galaxy Tab original cable.



Item no 514448

**Holder for Cable Attachment - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**

For use with Apple original Lightning to USB Cable. With tilt swivel.



Item no 514449

**Holder for Cable Attachment - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**

For use with Apple original Lightning to 30-pin Adapter Cable.



Item no 514450

**Holder for Cable Attachment - Apple iPad Mini (A1432, A1454, A1455) (For all countries)**

For use with Apple original Lightning to USB Cable. With tilt swivel. Griffin USB/cig-plug adapter included.

---



Item no 514451

**Holder for Cable Attachment - Apple iPad With Retina (Lightning Connector) (For all countries)**

For use with Apple original Lightning to USB Cable. With tilt swivel.

---



Item no 514451

**Holder for Cable Attachment - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

For use with Apple original Lightning to USB Cable. With tilt swivel.

---



Item no 514452

**Holder for Cable Attachment - Apple iPad With Retina (Lightning Connector) (For all countries)**

For use with Apple original Lightning to 30-pin Adapter Cable.

---



Item no 514452

**Holder for Cable Attachment - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

For use with Apple original Lightning to 30-pin Adapter Cable.

---



Item no 514453

**Holder for Cable Attachment - Apple iPad With Retina (Lightning Connector) (For all countries)**

For use with Apple original Lightning to USB Cable. With tilt swivel. Griffin USB/cig-plug adapter included.

---



Item no 514453

**Holder for Cable Attachment - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

For use with Apple original Lightning to USB Cable. With tilt swivel. Griffin USB/cig-plug adapter included.

---



Item no 514540

**Holder for Cable Attachment - Samsung Galaxy Tab 2 7.0 (For all countries)**

For Samsung Galaxy Tab original cable.

---



Item no 514540

**Holder for Cable Attachment - Samsung Galaxy Tab 7.0 Plus GT-P6200 (For all countries)**

For Samsung Galaxy Tab original cable.



Item no 515244  
**Holder for Cable Attachment - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**  
For Apple Composite AV Cable. With tilt swivel.



Item no 515244  
**Holder for Cable Attachment - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**  
For Apple Composite AV Cable. With tilt swivel.

### Device Mounting Adapter



Item no 215461  
**Device Mounting Adapter (For all countries)**  
Mounting adapter for MultiStand. Screws included. 50x60x8 mm.

### Monitor Mount.



Item no 215485  
**Monitor Mount. - Apple iPad With Retina (Lightning Connector) (For all countries)**  
Wall mount. Black.



Item no 215485  
**Monitor Mount. - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**  
Wall mount. Black.



Item no 215485  
**Monitor Mount. - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**  
Wall mount. Black.



Item no 215485  
**Monitor Mount. - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**  
Wall mount. Black.



Item no 215487  
**Monitor Mount. - Apple iPad With Retina (Lightning Connector) (For all countries)**  
Wall mount. White.





Item no 215487

**Monitor Mount. - Apple iPad 3rd Gen (A1416, A1430, A1403) (For all countries)**

Wall mount. White.



Item no 215487

**Monitor Mount. - Apple iPad 2 (A1395, A1396, A1397) (For all countries)**

Wall mount. White.



Item no 215487

**Monitor Mount. - Apple iPad 4th Gen (A1458, A1459, A1460) (For all countries)**

Wall mount. White.

## Mount



Item no 216059

**Mount (For all countries)**

Keyboard and tablet mount. With VESA 75/100 + multiple 5 mm AMPS holes.

Material: Metal.

## Tough Sleeve



Item no 216181

**Tough Sleeve - Zebra ET50 10.1 (For all countries)**

Wall mount. With Vesa 75mm and with  $\varnothing$  4 mm AMPS-holes.



Item no 216181

**Tough Sleeve - Zebra ET51 10.1 (For all countries)**

Wall mount. With Vesa 75mm and with  $\varnothing$  4 mm AMPS-holes.



Item no 758193

**Tough Sleeve - Samsung Galaxy Tab A 8.4 (2020) SM-T307 (For all countries)**

With USB-cable with cig-plug adapter. With active MultiMoveClip. 12/24V. With tilt swivel.



Item no 759193

**Tough Sleeve - Samsung Galaxy Tab A 8.4 (2020) SM-T307 (For all countries)**

For fixed installation. With active MultiMoveClip. 12/24V. With tilt swivel.

## Active holder with USB-cable and cig-plug adapter



Item no 521938

**Active holder with USB-cable and cig-plug adapter - Lenovo Tab 3 7 (For all countries)**

With cig-plug adapter. With tilt swivel. 2,1A charging. 12/24V.



Item no 521990

**Active holder with USB-cable and cig-plug adapter - Huawei MediaPad T3 8.0 (For all countries)**

With tilt swivel. With USB cable.



Item no 721018

**Active holder with USB-cable and cig-plug adapter - LG G Pad F2 8.0 (For all countries)**

With tilt swivel. With USB cable.

## Charging Cable



Item no 944209

**Charging Cable - Samsung Galaxy Tab 2 7.0 (For all countries)**



Item no 944209

**Charging Cable - Samsung Galaxy Tab GT-P1000 (For all countries)**



Item no 944209

**Charging Cable - Samsung Galaxy Tab 10.1 GT-P7500 (For all countries)**



Item no 944209

**Charging Cable - Samsung Galaxy Tab 8.9 GT-P7300 (For all countries)**



Item no 944209

**Charging Cable - Samsung Galaxy Tab 7.7 GT-P6800 (For all countries)**



Item no 944209  
Charging Cable - Samsung Galaxy Tab 2 10.1 (For all countries)



Item no 944209  
Charging Cable - Samsung Galaxy Tab 10.1 SCH-I905 (For USA)



Item no 944209  
Charging Cable - Samsung Galaxy Tab 7.0 Plus GT-P6200 (For all countries)