

**This document is continuously being updated, so if your computer model does not appear in the compatible or incompatible list below, please consult customer service directly.**

<b>COMPATIBILITY : ( Not a full list )</b>	
Apple:	<ul style="list-style-type: none"> <li>❖ MacBook/ Pro ( 2016-2021 )/ MacBook Air/ Mac mini ( 2018-2020 )</li> <li>❖ iMac Pro ( 2017-2019 )/ iMac ( 2020 )/ iPad/ Pro ( 2018-Newest )</li> </ul>
Lenovo:	<ul style="list-style-type: none"> <li>❖ Yoga ( 370/ 720/ 730/ 900/ 910/ 920/ 930/ 940/ C740/ C930/ 15 Ultrabook Pro/ 6 13ALC6/ 7 14ial7/ 7i )</li> <li>❖ ThinkPad ( P1 Gen2/ p15v gen 2/ T14 Gen 1 and 2/ T15p gen 1/ P50/ P52/ P70/ P72/ E14 / E590/ T470/ T470s/ T480s/ T490s/ 81N8/ Y530/ Y720/ X390/ X1 Carbon/ X1 Extreme )</li> <li>❖ IdeaPad ( chromebook flex 5/ Flex 14/ 330s/ C330/ Slim 7 Pro/ s540/ 720S/ 5 81yk006xus )</li> <li>❖ Legion ( Y 530/ 5i pro gen 7/ 5-17-82GN0000US )</li> </ul>
Dell:	<ul style="list-style-type: none"> <li>❖ Latitude ( 3310 2 in 1/ 3400/ 3410/ 3420/ 3490/ 3500/ 5290/ 5310/ 5320/ 5400/ 5410/ 5420/ 5480/ 5490/ 5500/ 5521/ 5530/ 5580/ 5591/ 7280/ 7300 series/ 7370/ 7389/ 7390/ 7400/ 7410/ 7420/ 7430/ 7480/ 7490 )</li> <li>❖ XPS ( 5590/ 9350/ 9380/ 13/ 13-9300/ 13 9305/ 13-9365/ 15/ 15-2018/ 15-9500 )</li> <li>❖ Precision ( 3561/ 3571/ 5520/ 5530/ 5540/ 5550/ 5560/ 7520/ 7730/ 7750 )</li> <li>❖ Inspiron ( 5402/ 5590/ 7300/ 13 7300/ 7373/ 7573/ 14 or 15 7000 series 2-in-1/ 15 5515)</li> <li>❖ Dell G7 7790/ Dell G15- 5511/ Dell 17 9700/ vostro 5620</li> </ul>
HP:	<ul style="list-style-type: none"> <li>❖ Spectre ( 13/ 360/ X360-13T/ 15T/ X369/ 13T-AK000CTO/ AF001TU )</li> <li>❖ Envy ( Geforce MX250/ 17T/ X360/ 13-AQ1/ 13t-ba100/ 113-aq001ms/ 17m-ae011dx )</li> <li>❖ Zbook ( 15U G3/ 17 G4/ 14U G6/ 15 G5/ 16 G6/ Studio Z5 )</li> <li>❖ Probook ( 440 G7/ 450 g5/ 450 G6/ 450 G7/ 640 G5/ 650 G5 )</li> <li>❖ Pavilion ( 14t-dv000/ 15t-eg100/ 15 i7-1195G7/ 15-eg0xxx/ 15-eg1xxx/ 15-eg2xxx )</li> <li>❖ Elitebook ( X360 1030 G3/ 735 G6/ 745 G5/ 800 G4/ 830 G5/ 840 G5 series/ 840 g6/ 850 G5/ 850 G7/ 850 G8/ 845 G7/ 840 G8/ 845 G8/ 830 G6/ X2/ 745 )</li> <li>❖ Chromebook 11A G6 EE/ 14a-na0122od/ Omen laptops/ GTX 4 Pro15.6</li> </ul>
Samsung:	<ul style="list-style-type: none"> <li>❖ Note ( 20/ 10/ 9 /8+ )</li> <li>❖ Galaxy ( S20 ultra/ 10+/ S10/ S9+/ S9/ S8+/ Tablet S4/ S5e/ New S7/ chromebook/ Flex alpha 2-in-1 )</li> </ul>
Asus:	<ul style="list-style-type: none"> <li>❖ Zenbook ( UX330UA/ Flip UX370U/ Q529ZA/ UX435/ UX434F/ UX433FA/ UX425EA/ 3-UX390/ UX434FLC-AI284R/ 14 UX433FA )</li> <li>❖ TUF Gaming A15 Gaming Laptop/ Zephyrus G14/ G15/ Rog GX501</li> </ul>
Huawei:	<ul style="list-style-type: none"> <li>❖ MateBook ( X Pro/ E/ X/ Mate10/ 10Pro/ Mate20/ Mate20 Pro/ Mate30/ 30Pro/ P20/ P20 Pro/ P30 Pro/ 13 )</li> </ul>
Acer:	<ul style="list-style-type: none"> <li>❖ Swift ( 1/ 3/ 7/ X )</li> <li>❖ SPIN ( 5/ 7 )</li> <li>❖ Predator Helios 300</li> </ul>
Google Chromebook:	<ul style="list-style-type: none"> <li>❖ Pixel ( 2016/ 2017 )</li> <li>❖ C340-15/ Google Slate</li> </ul>
Microsoft Surface:	<ul style="list-style-type: none"> <li>❖ laptop ( 3/4 )</li> <li>❖ Pro ( 8/ 7/ 5/ X )</li> <li>❖ Book 2/ Go-1943</li> </ul>
MI:	<ul style="list-style-type: none"> <li>❖ Air ( 12.5/ 13.3 ) / Pro 15.6</li> </ul>
MSI:	<ul style="list-style-type: none"> <li>❖ GT76 Titan/ GS66 Stealth</li> </ul>

## INCOMPATIBILITY : ( Not a full list )

Apple:	❖ Macbook Air ( before 2018 )/ MacBook Pro 2015/ iMac 2021
Lenovo:	❖ YOGA ( 710-15ikb/ 520 ) ❖ ThinkPad ( I490/E580 ) ❖ IdeaPad ( 3/ 5/ 3-15itl6/ 330/ L340/ S340/ 130S/ Flex-15IWL/ Flex-14"/ 15.6" 2-in-1/ Flex 5-1570/ Flex 5 14itl05/ Flex 5 15IIL05/ Flex-6 14IKB/ Flex 15 iml) ❖ V330/ T570/ Y520/ 710/ model 81we0016us/ Thinkbook 15P
Dell:	❖ Inspiron ( 17-5000 series / 15-5000 series, 14-5410, 15-3000/3583,17-3793 Business, 7000 Gaming, Vostro MT 3671 ) ❖ Latitude ( E7270,E7470, E7440,E7450,3520 )
HP:	❖ Earlier Pavilion series/ 2020 HP 14/ newer HP Envy 15/ 340S G7/ EVGA SC15/ 17.3in Full HD Notebook/ prodesk 600 G2/ envy x360 15m-bp-112dx/ Notebook 15-dy1071wm/ Notebook 15-dy1043dx ❖ Spectre ( X360 13/ 14/ 15T ) ❖ Elitebook ( 745 G3/ 745 G6/ 755 G5/ 800 G2 / 820 G3/ 820 G4/ 840 G3/ 840 G4/ 850 G4 ) ❖ Probook ( 600/ 640/ 650 G2/ 650 G3 ) ❖ Model ( 17t-by300/ 15-dy1076nr/ 15-dw2025cl/ 15-y1751ms/ 15-dw0037wm/ 14-dq1033cl/ 14-dq0005cl/ 15EF1300WM ) ❖ Pavilion ( 17-ar050wm/ x360 Convertible 14-dh1xxx/ 24-b277c/ 15cs3xxx ) ❖ Laptop ( 15-dy1xxx/ 15-dy2xxx/ 15t-dy100/ 15t-dy200/ 15-dy1059ms/ 15-dw3XXX/ 15-dw2025od/ 14-dq1033cl/ 14-dq2045cl/ 15-ef2xxx/ 17-by3613dx/ PC 15s-fq2000 (2D119AV)/ 15-dw3097nr/ 15s-fq200/ 17-by1xxx/ 15-EF1001DS/ 17-by 2053cl/ 17z-cp000 ) ❖ Inspiron 14 5000 Series/ Levano Ideapad 1 15.6" FHD Touch Screen Laptop/ Folio 1020 B&O/ 17-cn0053cl/ 17-cn0275st/ 15-ef1072nr/ 15-ef0xx
Asus:	❖ Vivobook series/ Q547/ Q503U/ Q526F/ L203MA/ TUF 17.3 Gaming Laptop ❖ Zenbook ( UX333FN/ UX330UA-AH55/ Flip 14 UX461FN-DH74T/ Flip 14 UX463FL/ Q407I )
Acer Aspire:	❖ E5-575/ R5-571T/ E5-576G/ R15/ G3-571/ Predator Helios 300/ Swift X 14
MSI:	❖ GI65/ GF63/ GF65 THIN 9SD-252/ GERVR 7RF Apache Pro/ GS73VR 7RG Stealth Pro/ GE73 Raider RGB 8RF
Microsoft:	❖ Surface Pro 3/ 4/ 6 ❖ book 3
MI:	❖ Redmi Note 7
Samsung :	❖ Galaxy Tab 5 / A50 / A51-5G
Huawei :	❖ Matebook 14 / Mediapad M5 lite
ViewSonic:	❖ VA912/ VA912 Series 4/ VA912B
Toshiba:	❖ satellite P25wc/ Radius P55W-B5224
Other:	❖ High-power equipment/ USB Super Drive/ CD/ DVD player