

**1. External Photograph of EUT**

**Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android**



Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android



**Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android**



Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android







**Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android**



**Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android**





2. Photograph of Accessory

Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;
Marketing Name: PIXI 4 6" 3G Android

List of Accessory:

Table with 4 columns: Accessory Name, Brand Name, Model Name, and Specification. Rows include AC Adapter 1, AC Adapter 2, Battery 1, Battery 2, USB Cable 1, USB Cable 2, Earphone 1, and Earphone 2.

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android





Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android

**AC Adapter 1**



Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android

AC Adapter 2



Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android



Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android





Brand Name: ALCATEL ONETOUCH; Model Name: 8050E;  
Marketing Name: PIXI 4 6" 3G Android





