comsol

Dual Port Power Bank Charger

7800mAh

User Manual

Power Bank Layout

- LED Indicators
- LED Torch
- Micro USB Input
- USB 1 Output 1A
- USB 2 Output 2.1A
- Durable Hook
- Power On/Off

Suitable for

- iPhone/iPad/iPod
- Most smartphones & tablets including Samsung, HTC, Motorola, Nokia, LG, Sony, BlackBerry, Huawei, Asus, Telstra, Doro & more
- GPS devices, digital cameras, portable hand-held gaming consoles
- Portable Bluetooth devices such as fitness tracker or headset
- eReaders such as Kindle, Kobo & Sony

Features

- Rugged & shock proof design for maximum durability
- Water resistant, dust proof and dirt proof rated to IP65
- The power bank can withstand spray or splashed water but cannot be totally submersed underwater
- Dual USB ports for simultaneous charging of two devices
- 2.1A high output for fast charging of iPad
- Rechargeable more than 800 times
- Handy built-in LED torch
- Four LED indicators to show remaining capacity
- Includes micro USB cable for charging and re-charging
- Built-in over charging and short circuit protection
- Input: DC5V 1A
- Output 1: DC5V 1A
- Output 2: DC5V 2.1A
- Charging Time: 7 to 8 hours
- Size: 115mm (L) x 69mm (W) x 25mm (H)
- Weight: 260g

To Charge Power Bank

Charge via USB Wall Charger   Charge via Computer USB Port

- Using the included USB cable, connect the larger USB connector to an AC wall adapter or USB port on a computer
- Connect the smaller USB connector to the input port on the power bank
- During charging the LEDs will flash to show charging status
- When charging is complete all four LED's will be permanently on

To Charge Phone or USB Device

- USB 1 Output is for charging a phone or other USB device
- USB 2 Output is for fast charging an iPad
- USB 2 Output can also be used to charge a phone or any other USB device
- Using your phone, tablet or other USB device's charging cable, connect the USB Type A connector to USB Output 1 or 2 on the power bank
- Connect the other end of the cable to your device
- Press the power button to start charging your device
- If your phone or device uses a standard micro USB Type B connector then you can also use the included cable to charge your device
- When your phone or device is fully charged, the power bank will stop charging to prevent over charging or over heating

To Check Remaining Capacity

- Press the On/Off button and the LEDs will light to show remaining capacity
- Press the On/Off button again to turn off the LEDs

LED ● On / ○ Off / ◉ Flashing	Remaining Capacity
◉ ○ ○ ○	Less than 5%
● ○ ○ ○	5% to 25%
● ● ○ ○	25% to 50%
● ● ● ○	50% to 75%
● ● ● ●	75% to 100

To Operate LED Torch

- Press the On/Off button for 3 seconds and the LED torch will turn on
- Press the On/Off button again for 3 seconds and the LED torch will turn off

Important Safety Instructions

- The power bank can withstand spray or splashed water but cannot be totally submersed underwater
- To maximize battery life span, fully charge power bank before first use for 7 to 8 hours
- Store power bank in a cool and dry place.
- Do not store power bank in hot or humid environment
- Operating temperature should be between -10c to 45c
- If power bank is not used for long periods of time, you should charge and discharge once every three months
- When charging a device, the power bank may feel warm, this is a normal operating condition and should not be cause for concern
- In normal conditions, the battery performance will decline over several years
- Do not dispose of power bank in heat or fire
- Do not clean power bank with harmful chemicals or detergents
- Misuse, dropping or excessive force may cause product damage

www.comsol.com.au