



Configuring the Cisco OpenFlow Agent

All tasks in this section require the fulfillment of the prerequisites listed in [Prerequisites for Cisco OpenFlow Agent](#).

- [Enabling the Cisco OpenFlow Agent, on page 1](#)
- [Configuring Physical Device Parameters for Cisco Nexus 3000 and 9000 Series Switches, on page 3](#)
- [Cisco OpenFlow Agent for Cisco Nexus 3500 Platform Switches, on page 7](#)
- [Specifying a Route to a Controller, on page 14](#)
- [Configuring Interfaces for a Cisco OpenFlow Agent Logical Switch, on page 17](#)
- [Configuring a Cisco OpenFlow Agent Logical Switch , on page 19](#)
- [Configuring Logical Sub-Switches, on page 24](#)
- [Configuration Examples for Cisco OpenFlow Agent, on page 27](#)
- [NXOS NXAPI Migration from OpenFlow, on page 31](#)
- [Achieving OpenFlow Functionality, on page 31](#)
- [Verifying Cisco OpenFlow Agent, on page 32](#)
- [Additional Information for Cisco OpenFlow Agent, on page 44](#)
- [Feature Information for Cisco OpenFlow Agent, on page 44](#)

Enabling the Cisco OpenFlow Agent

Enabling the Cisco OpenFlow Agent on the Cisco Nexus 3000 Series Switch

To run the Cisco OpenFlow Agent, a Cisco Nexus 3000 Series switch must run in Cisco NX-OS 9000 software mode. This procedure activates the Cisco Nexus 9000 mode and enables the Cisco OpenFlow Agent.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none">• Enter your password if prompted.
Step 2	configure terminal Example:	Enters global configuration mode.

	Command or Action	Purpose
	Device# <code>configure terminal</code>	
Step 3	system switch-mode n9k Example: Device (config)# <code>system switch-mode n9k</code>	Activates the Cisco NX-OS 9000 mode on the Cisco Nexus 3000 Series switch.
Step 4	exit Example: Device (config)# <code>exit</code>	Exits global configuration mode and enters privileged EXEC mode.
Step 5	write erase Example: Device# <code>write erase</code>	Erases the startup configuration file. Note It is highly recommended to make a backup copy of the running configuration before entering the write erase command.
Step 6	reload Example: Device# <code>reload</code>	Reloads the operating system of the device.
Step 7	configure terminal Example: Device# <code>configure terminal</code>	Enters global configuration mode (after reload).
Step 8	feature openflow Example: Device (config)# <code>feature openflow</code>	Enables the Cisco OpenFlow Agent.

What to do next

Adjust the number of flow entries.

Enabling the Cisco OpenFlow Agent on the Cisco Nexus 9000 Series Switch

This procedure enables the Cisco OpenFlow Agent.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# <code>configure terminal</code>	Enters global configuration mode.

	Command or Action	Purpose
Step 2	feature openflow Example: Device(config) # feature openflow	Enables the Cisco OpenFlow Agent.

What to do next

Adjust the number of flow entries.

Configuring Physical Device Parameters for Cisco Nexus 3000 and 9000 Series Switches

Adjusting the Number of Flow Entries

You can use this task to adjust the number of L3 flow entries.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	Required: hardware access-list tcam region racl size Example: Device(config) # hardware access-list tcam region racl 0	Configures the size of TCAM region for router ACLs.
Step 3	Required: hardware access-list tcam region e-racl size Example: Device(config) # hardware access-list tcam region e-racl 0	Configures the size of TCAM region for egress router ACLs.
Step 4	Required: hardware access-list tcam region l3qos size Example: Device(config) # hardware access-list tcam region l3qos 0	Configures the size of TCAM region for QoS.

	Command or Action	Purpose
Step 5	Required: hardware access-list tcam region span size Example: <pre>Device(config)# hardware access-list tcam region span 0</pre>	Configures the size of TCAM region for SPAN.
Step 6	Required: hardware access-list tcam region redirect size Example: <pre>Device(config)# hardware access-list tcam region redirect 0</pre>	Configures the size of TCAM region for redirects.
Step 7	Required: hardware access-list tcam region vpc-convergence size Example: <pre>Device(config)# hardware access-list tcam region vpc-convergence 0</pre>	Configures the size of TCAM region for virtual port channel (vPC) convergence.
Step 8	Required: Enter one of the following commands: <ul style="list-style-type: none"> • hardware access-list tcam region openflow size [double-wide] • hardware access-list tcam region openflow-ipv6 size [double-wide] Example: <pre>Device(config)# hardware access-list tcam region openflow 1024</pre> Example: <pre>Device(config)# hardware access-list tcam region openflow-ipv6 1024 double-wide</pre>	<p>Configures the size of TCAM region for interface ACLs. For a TCAM region larger than 256, configure the size in multiples of 512.</p> <p>To accommodate the additional match criteria of source and destination MAC addresses, the Cisco Nexus 3000 and 9000 Series switches support a new TCAM region, double-wide, which is a double-wide interface ACL. The maximum TCAM size is 3072 for single-wide and 1536 for double-wide.</p> <p>For more information, see the following tables for matches and actions supported for Cisco Nexus 9000 Series switches.</p> <p>The openflow-ipv6 option forces the use of the IPv6 stack for OpenFlow.</p> <p>Note To activate the TCAM regions, a reload is needed.</p> <p>You can view the supported pipeline values by entering the show openflow hardware capabilities command.</p>

	Command or Action	Purpose			
		Table 1: Matches Supported in Cisco Nexus 9000 Series Switches			
		Packet Match Fields	L3 Table 201	L3 Table 202	L2 Table 202
		Source MAC address	✓ (double wide)	✓ (double wide)	
		Destination MAC address	✓ (double wide)		✓
		Ether type	✓	✓	
		VLAN ID	✓	✓	✓
		VLAN CoS	✓	✓	
		Source IPv4 Address	✓	✓	
		Destination IPv4 Address	✓	✓	
		Source IPv4 UDP/TCP Port	✓	✓	
		Destination IPv4 UDP/TCP Port	✓	✓	
		IPv4 DSCP	✓		
		Protocol IP	✓		
		Input Interface	✓		

	Command or Action	Purpose																																
		<div>Table 2: Action Supported in Cisco Nexus 9000 Series Switches</div> <table><tr><td>Actions</td><td>L3 Table 201</td><td>L3 Table 201</td><td>L2 Table 202</td></tr><tr><td>Output Interfaces</td><td>✓</td><td>✓</td><td>✓</td></tr><tr><td>Punt to Controller</td><td>✓</td><td>✓</td><td>✓</td></tr><tr><td>Copy to Controller</td><td>✓</td><td>✓</td><td></td></tr><tr><td>Push VLAN</td><td>✓</td><td>✓</td><td></td></tr><tr><td>POP VLAN</td><td>✓</td><td>✓</td><td></td></tr><tr><td>DROP</td><td>✓</td><td>✓</td><td>✓</td></tr><tr><td>Normal Forwarding</td><td>✓</td><td>✓</td><td>✓</td></tr></table>	Actions	L3 Table 201	L3 Table 201	L2 Table 202	Output Interfaces	✓	✓	✓	Punt to Controller	✓	✓	✓	Copy to Controller	✓	✓		Push VLAN	✓	✓		POP VLAN	✓	✓		DROP	✓	✓	✓	Normal Forwarding	✓	✓	✓
Actions	L3 Table 201	L3 Table 201	L2 Table 202																															
Output Interfaces	✓	✓	✓																															
Punt to Controller	✓	✓	✓																															
Copy to Controller	✓	✓																																
Push VLAN	✓	✓																																
POP VLAN	✓	✓																																
DROP	✓	✓	✓																															
Normal Forwarding	✓	✓	✓																															
Step 9	<div>exit</div> <div>Example:</div> <div>Device (config) # exit</div>	Exits global configuration mode and enters privileged EXEC mode.																																
Step 10	<div>copy running-config startup-config</div> <div>Example:</div> <div>Device# copy running-config startup-config</div>	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.																																
Step 11	<div>reload</div> <div>Example:</div> <div>Device# reload</div>	Reloads the operating system of a device.																																

What to do next

Configure global variables for Cisco OpenFlow Agent logical switch.

Configuring Global Variables for Cisco OpenFlow Agent Logical Switch

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	(Optional) spanning-tree mode mst Example: Device(config)# spanning-tree mode mst	Sets the Spanning Tree Protocol (STP) mode to MST. This step is required if you need VLANs more than 512.
Step 3	(Optional) vlan {vlan-id / vlan-range} Example: Device(config)# vlan 1-512	Adds a VLAN or VLAN range for interfaces on the device and enters the VLAN configuration mode. This step is needed only if VLAN tagging is required. <ul style="list-style-type: none"> • Total number of VLANs across all interfaces cannot exceed 32000. • Maximum VLAN range supported is 4000 (in Multiple Spanning Tree [MST] mode). • Recommended VLAN range is 512.
Step 4	exit Example: Device(config)# exit	Ends global configuration mode and enters privileged EXEC mode.
Step 5	copy running-config startup-config Example: Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

What to do next

Configure control plane policing for packets sent to a controller.

Cisco OpenFlow Agent for Cisco Nexus 3500 Platform Switches

Guidelines and Limitations for Cisco Nexus 3500 Platform Switches

The following are guidelines and limitations for Cisco Nexus 3500 platform switches:

- Packets incoming with the following etherTypes are treated differently for Cisco Nexus 3500 platform switches as part of OpenFlow. Packets with these etherTypes cannot be matched and forwarded using

OpenFlow rules with match on specific etherTypes, instead the MATCH_ANY rule works under certain conditions as mentioned in the following table. The difference in behavior for processing such packets is mostly due to a limitation with the ASIC.

- 0x22e9
- 0x8035
- 0x8100
- 0x8927
- 0x8926
- 0x8903
- 0x88a8
- 0xfe1
- 0x8808

Table 3: Specific EtherTypes and Behaviors on Cisco Nexus 3500 Platform Switches

SL#	EtherTypes	Purpose	Match Specific EtherType	Remarks
1	0x22e9	CNTag	Does not match on specific EtherType and default rule to drop gets applied	Match ANY works
2	0x8035	RARP	Does not match on specific EtherType and default rule to drop gets applied	Match ANY works

SL#	EtherTypes	Purpose	Match Specific EtherType	Remarks
3	0x8100	Dot1q	Does not match on specific EtherType and default rule to drop gets applied	<p>Match ANY works.</p> <p>Special Case:- If VLAN_ID is '0'</p> <p>Dot1q header (4 bytes) is removed and packet is forwarded</p> <p>Ingress_pkt [DA+SA+8100+0000+PAYLOAD] → switch_3500 → egress_pkt [DA+SA+PAYLOAD]</p> <p>The VLAN ID 0 is used to send priority-tagged frames. In general, ASIC pipeline this VLAN ID tag to be ignored and the Ethernet frame to be processed according to the priority configured in the 802.1P bits of the 802.1Q Ethernet frame header.</p>
4	0x8808	PauseFrames (FlowControl)	Matches specific Ethertype. Limitation is, stats will not get updated.	<p>Match ANY works</p> <p>Limitation - Stats will not get updated</p>
5	0x8927	CopperLan	Does not match on specific EtherType and default rule to drop gets applied	<p>Match ANY works with the following caveat. 0x8927 header (8 bytes) is removed and the packet is forwarded matching Match-ANY rule.</p> <p>Ingress_pkt [DA+SA+8927+6bytes+PAYLOAD] → switch_3500 → egress_pkt [DA+SA+PAYLOAD]</p>
6	0x8926	Cisco VNTag	Does not match on specific EtherType and default rule to drop gets applied	<p>Match ANY works with the following caveat. VNTag header (6 bytes) is removed and the packet is forwarded matching Match-ANY rule.</p> <p>Ingress_pkt [DA+SA+8926+4bytes+PAYLOAD] → switch_3500 → egress_pkt [DA+SA+PAYLOAD]</p>
7	0x8903	Cisco FabricPath	Does not match on specific EtherType and default rule to drop gets applied	<p>Match ANY works with the following caveat. Outer DCE header (16 bytes) is removed and inner packet gets forwarded matching Match-ANY rule.</p> <p>Ingress_pkt [ODA+OSA+8903+2bytes+IDA+ISA+PAYLOAD] → switch_3500 → egress_pkt [IDA+ISA+PAYLOAD]</p>

SL#	EtherTypes	Purpose	Match Specific EtherType	Remarks
8	0x88a8	QinQ	Does not match on specific EtherType and default rule to drop gets applied	Match ANY works with the following caveat. 0x88a8 etherType is modified to dot1q (0x8100) etherType and forwarded matching Match-ANY rule. Ingress_pkt → [DA+SA+88a8+TAG+PAYLOAD] → switch_3500 → egress_pkt [DA+SA+8100+TAG+PAYLOAD]
9	0xfeef	UNKNOWN	Does not match on specific EtherType and default rule to drop gets applied	Match ANY works with the following caveat. 0xfeef header (8 bytes) is removed and packet is forwarded matching Match-ANY rule. Ingress_pkt → [DA+SA+feef+6bytes+DATA] → switch_3500 → egress_pkt [DA+SA+DATA]
10	0x8903	Encapsulation header with EtherType 0x8903	Does not match 0x8903 EtherType if it is in an encapsulated header as the header is removed.	There is an ASIC limitation for DCE packets with multicast DA being handled in a different way. Packets are flooded out of all active ports instead of being forwarded to specific port as per the OpenFlow flows installed on the switch.

Enabling the Cisco OpenFlow Agent on Cisco Nexus 3500 Platform Switches

This procedure enables the Cisco OpenFlow Agent.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal	Enters global configuration mode.
Step 2	feature openflow Example: switch(config)# feature openflow	Enables the Cisco OpenFlow Agent.

What to do next

Adjust the number of flow entries.

Enabling Hardware Support for OpenFlow on Cisco Nexus 3500 Platform Switches

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal	Enters global configuration mode.
Step 2	Enter one of the following commands: <ul style="list-style-type: none"> • hardware profile forwarding-mode openflow-hybrid • hardware profile forwarding-mode openflow-only Example: switch(config)# hardware profile forwarding-mode openflow-hybrid Example: switch(config)# hardware profile forwarding-mode openflow-only	<p>The hardware profile forwarding-mode openflow-hybrid command sets the OpenFlow hybrid forwarding mode.</p> <p>Note In the OpenFlow hybrid model, normal ports and OpenFlow enabled ports can coexist. When using the OpenFlow hybrid model, VLANs configured for OpenFlow logical switch ports must not overlap with normal device interfaces.</p> <p>The hardware profile forwarding-mode openflow-only command set the OpenFlow only forwarding mode.</p> <p>Note In this mode, all available ports are considered a part of OpenFlow-based forwarding.</p>
Step 3	exit Example: switch(config)# exit	Exits global configuration mode and enters privileged EXEC mode.
Step 4	copy running-config startup-config Example: Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.
Step 5	reload Example: switch# reload	Reloads the operating system of a device.

Enabling Re-Direct Control Plane Packets for OpenFlow Ports on the Cisco Nexus 3500

The **hardware profile openflow forward-pdu** command is introduced in the Cisco NX-OS 9.3(5) release to forward link-level PDUs. With this CLI, the behavior of PDUs with destinations the same as one of the following MAC addresses skip punt-to-CPU and honor configured OpenFlow rules. There is no change in the behavior of other Layer 2 or Layer 3 protocol packets.

```
0180.c200.0000
0180.c200.0002
0100.0ccc.cccc
0100.0ccc.cccd
```

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: switch# configure terminal	Enter global configuration mode.
Step 2	hardware profile openflow forward-pdu Example: switch(config)# hardware profile openflow forward-pdu	Configures the protocol data unit.
Step 3	(Optional) no hardware profile openflow forward-pdu Example: switch(config)# no hardware profile openflow forward-pdu	Removes the protocol data unit configuration.

Configuring Global Variable for Cisco OpenFlow Agent Logical Switch for Cisco Nexus 3500

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	(Optional) spanning-tree mode mst Example: Device(config)# spanning-tree mode mst	Sets the Spanning Tree Protocol (STP) mode to MST. This step is required if you need VLANs more than 512.

	Command or Action	Purpose
Step 3	(Optional) vlan { <i>vlan-id</i> / <i>vlan-range</i> } Example: Device(config)# vlan 1-512	Adds a VLAN or VLAN range for interfaces on the device and enters the VLAN configuration mode. This step is needed only if VLAN tagging is required. <ul style="list-style-type: none"> • Total number of VLANs across all interfaces cannot exceed 32000. • Maximum VLAN range supported is 4000 (in Multiple Spanning Tree [MST] mode). • Recommended VLAN range is 512.
Step 4	exit Example: Device(config)# exit	Ends global configuration mode and enters privileged EXEC mode.
Step 5	copy running-config startup-config Example: Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

What to do next

Configure control plane policing for packets sent to a controller.

Configuration Examples for the Cisco Nexus 3500 Platform Switches

Example Enabling Cisco OpenFlow Agent in the Cisco Nexus 3500 Platform Switches

```
Device# configure terminal
Device(config)# feature openflow
Device(config)# show feature | inc openflow
openflow          1          enabled
```

Enter either of the following commands at the prompt to configure OpenFlow TCAM:

```
Device(config)# hardware profile forwarding-mode openflow-hybrid
```

```
Device(config)# hardware profile forwarding-mode openflow-only
```

```
Device(config)# exit
Device# copy running-config startup-config
Device# reload
```

Example: Cisco OpenFlow Agent Logical Switch Configuration (Default VRF) for Cisco Nexus 3500 Platform Switches

```
Device# configure terminal
Device(config)# openflow
```

```

Device(config-ofa)# switch 1 pipeline 203
! Specifies the pipeline that enables the IP Forwarding Table.
Device(config-ofa-switch)# logging flow-mod
Device(config-ofa-switch)# max-backoff 5
Device(config-ofa-switch)# probe-interval 5
Device(config-ofa-switch)# rate-limit packet-in 300 burst 50
Device(config-ofa-switch)# controller ipv4 10.0.1.6 security none
! Adding an interface to the Cisco OpenFlow Agent logical switch.
Device(config-ofa-switch)# of-port interface ethernet1/1
Device(config-ofa-switch)# of-port interface ethernet1/2
! Adding a port channel to the Cisco OpenFlow Agent switch.
Device(config-ofa-switch)# of-port interface port-channel 2
Device(config-ofa-switch)# end
Device# copy running-config startup-config

```

Example: Configuring a Cisco OpenFlow Agent Logical Switch (Management VRF) for Cisco Nexus 3500 Platform Switches

```

Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1 pipeline 203
! Specifying a controller that is part of a VRF.
Device(config-ofa-switch)# controller ipv4 10.0.1.6 vrf management security none
! Adding an interface to the Cisco OpenFlow Agent logical switch.

Device(config-ofa-switch)# of-port interface ethernet1/1
Device(config-ofa-switch)# of-port interface ethernet1/2
! Adding a port channel to the Cisco OpenFlow Agent switch.
Device(config-ofa-switch)# of-port interface port-channel 2
Device(config-ofa-switch)# end
Device# copy running-config startup-config

```

Example: Creating a Sub-Switch for Cisco Nexus 3500 Platform Switches

```

Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1 pipeline 203
Device(config-ofa-switch)# controller ipv4 5.30.199.200 port 6645 vrf management security
none
Device(config-ofa-switch)# of-port interface port-channel1000
Device(config-ofa-switch)# of-port interface Ethernet1/1
Device(config-ofa-switch)# of-port interface Ethernet1/37
Device(config-ofa-switch)# of-port interface Ethernet1/39
Device(config-ofa-switch)# logging flow-mod
Device(config-ofa-switch)# sub-switch 2 vlan 100
Device(config-ofa-switch-subswitch)# controller ipv4 5.30.19.239 port 6653 vrf management
security none

```

Specifying a Route to a Controller

The following tasks are used to specify a route from the device to a controller. This can be done using a physical interface (Front Panel) or a management interface.

- Physical Interface . Refer to [Specifying a Route to a Controller Using a Physical Interface](#), on page 15.

- Management Interface. Refer to [Specifying a Route to a Controller Using a Management Interface](#), on page 16.

The IP address of the controller is configured in the [Configuring a Cisco OpenFlow Agent Logical Switch](#), on page 19 section.

Specifying a Route to a Controller Using a Physical Interface

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	interface <i>type number</i> Example: Device(config)# interface Ethernet1/1	Enters the physical interface. The interface used here should not be a Cisco OpenFlow Agent port.
Step 3	no switchport Example: Device(config-if)# no switchport	Configures a specified interface as a Layer 3 interface and deletes any interface configuration specific to Layer 2.
Step 4	ip address <i>ip-address mask</i> Example: Device(config-if)# ip address 10.0.1.4 255.255.255.0	Configures an IP address for a specified interface.
Step 5	exit Example: Device(config-if)# exit	Exits interface configuration mode and enters global configuration mode.
Step 6	ip route <i>0.0.0.0 0.0.0.0 next-hop</i> Example: Device(config)# ip route 0.0.0.0 0.0.0.0 10.0.1.6	Configures a default route for packet addresses not listed in the routing table. Packets are directed toward a controller.
Step 7	ping <i>controller-ip-address</i> Example: Device(config)# ping 192.0.20.123	Ping your controller to verify a working route.
Step 8	exit Example: Device(config)# exit	Exits global configuration mode and enters privileged EXEC mode.

	Command or Action	Purpose
Step 9	copy running-config startup-config Example: Device# copy running-config startup-config	Saves the changes persistently through reboots and restarts by copying the running configuration to the startup configuration.

What to do next

Specify a route to a controller using a management interface.

Specifying a Route to a Controller Using a Management Interface

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	interface <i>management-interface-name</i> <i>number</i> Example: Device(config)# interface mgmt0	Enters the management interface.
Step 3	ip address <i>ip-address</i> <i>mask</i> Example: Device(config-if)# ip address 10.0.1.4 255.255.255.0	Configures an IP address for the interface.
Step 4	exit Example: Device(config-if)# exit	Exits interface configuration mode and enters global configuration mode.
Step 5	vrf context <i>management</i> Example: Device(config)# vrf context management	Configures the management Virtual routing and forwarding (VRF) instance.
Step 6	ip route 0.0.0.0 0.0.0.0 <i>next-hop</i> Example: Device(config)# ip route 0.0.0.0 0.0.0.0 10.0.1.6	Configures a default route for packet addresses not listed in the routing table. Packets are directed toward a controller.
Step 7	exit Example: Device(config)# exit	Exits global configuration mode and enters privileged EXEC mode.

	Command or Action	Purpose
Step 8	copy running-config startup-config Example: Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

What to do next

Configure interfaces for the Cisco OpenFlow Agent logical switch.

Configuring Interfaces for a Cisco OpenFlow Agent Logical Switch

You must configure physical or port-channel interfaces before the interfaces are added as ports of a Cisco OpenFlow Agent logical switch. These interfaces are added as ports of the Cisco OpenFlow Agent logical switch in the [Configuring a Cisco OpenFlow Agent Logical Switch](#) , on page 19 section.

Configuring a Physical Interface in Layer 2 mode

Perform the task below to add a physical interface to a Cisco OpenFlow Agent logical switch in Layer 2 mode.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	interface <i>type number</i> Example: Device(config)# interface Ethernet1/23	Specifies the interface for the logical switch and enters interface configuration mode.
Step 3	(Optional) channel-group <i>group-number</i> Example: Device(config-if)# channel-group 2	Adds the interface to a port-channel.
Step 4	Required: switchport Example: Device(config-if)# switchport	Specifies an interface as a Layer 2 port.
Step 5	Required: switchport mode trunk Example: Device(config-if)# switchport mode trunk	Specifies an interface as a trunk port. <ul style="list-style-type: none"> • A trunk port can carry traffic of one or more VLANs on the same physical link. (VLANs are based on the trunk-allowed

	Command or Action	Purpose
		VLANs list.) By default, a trunk interface carries traffic for all VLANs.
Step 6	Required: switchport mode trunk allowed vlan [vlan-list] Example: Device(config-if) # switchport trunk allowed vlan 1-3	Sets the list of allowed VLANs that transmit traffic from this interface in tagged format when in trunking mode.
Step 7	no shutdown Example: Device(config-if) # no shutdown	Enables the interface.
Step 8	end Example: Device(config-if) # end	Exits interface configuration mode and enters privileged EXEC mode.
Step 9	copy running-config startup-config Example: Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

What to do next

Repeat these steps to configure any additional interfaces for a Cisco OpenFlow Agent logical switch.

Configuring a Port-Channel Interface

Perform the task below to create a port-channel interface for a Cisco OpenFlow Agent logical switch.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	interface port-channel number Example: Device(config)# interface port-channel 2	Specifies the interface for the logical switch and enters interface configuration mode.
Step 3	switchport mode trunk Example: Device(config-if) # switchport mode trunk	Specifies the interface as an Ethernet trunk port. A trunk port can carry traffic in one or more VLANs on the same physical link (VLANs are

	Command or Action	Purpose
		based on the trunk-allowed VLANs list). By default, a trunk interface can carry traffic for all VLANs. Note If the port-channel is specified as a trunk interface, ensure that member interfaces are also configured as trunk interfaces.
Step 4	Required: switchport mode trunk allowed vlan [vlan-list] Example: Device(config-if)# switchport trunk allowed vlan 1-3	Sets the list of allowed VLANs that transmit traffic from this interface in tagged format when in trunking mode.
Step 5	end Example: Device(config-if)# end	Ends interface configuration mode and enters privileged EXEC mode.
Step 6	copy running-config startup-config Example: Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

What to do next

Activate Cisco OpenFlow Agent.

Configuring a Cisco OpenFlow Agent Logical Switch

This task configures a Cisco OpenFlow Agent logical switch and the IP address of a controller.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	openflow Example: Device(config)# openflow	Enters OpenFlow configuration mode.
Step 3	Required: switch switch-id pipeline pipeline-id	Creates an OpenFlow switch with a pipeline.

	Command or Action	Purpose
	Example: <pre>Device(config-ofa)# switch 1 pipeline 201</pre>	<ul style="list-style-type: none"> This step is mandatory for a logical switch configuration. You can view the supported pipeline values using the show openflow hardware capabilities command. <p>Note For the Cisco Nexus 3500 platform switches, the value of <i>pipeline-id</i> is 203.</p>
Step 4	<p>Enter one of the following commands:</p> <ul style="list-style-type: none"> of-port interface <i>interface-name</i> of-port interface <i>port-channel-name</i> <p>Example:</p> <p>For a physical interface:</p> <pre>Device(config-ofa-switch)# of-port interface ethernet1/1</pre> <p>For a port-channel interface:</p> <pre>Device(config-ofa-switch)# of-port interface port-channel2</pre>	<p>Configures an Ethernet interface or port-channel interface as a port of a Cisco OpenFlow Agent logical switch.</p> <ul style="list-style-type: none"> Standard Cisco NX-OS interface type abbreviations are supported. The interface must be designated for the Cisco OpenFlow Agent logical switch only. The mode openflow configuration is added to an interface when an interface is configured as a port of Cisco OpenFlow Agent. To add or remove an interface as a port of Cisco OpenFlow Agent, ensure that the Cisco OpenFlow Agent is activated and running to ensure the proper automatic addition and removal of the mode openflow configuration. To remove an interface as a port of Cisco OpenFlow Agent, use the no form of this command. An interface configured for a port channel should not be configured as a Cisco OpenFlow Agent logical switch port. Repeat this step to configure additional interfaces.
Step 5	<pre>controller ipv4 ip-address [port tcp-port] [vrf vrf-name] security {none tls}</pre> <p>Example:</p> <p>Controller in default VRF:</p> <pre>Device(config-ofa-switch)# controller ipv4 10.1.1.2 security none</pre>	<p>Specifies the IPv4 address, port number, and VRF of a controller that can manage the logical switch, port number used by the controller to connect to the logical switch and the VRF of the controller.</p> <ul style="list-style-type: none"> If unspecified, the default VRF is used. Controllers use TCP port 6653 by default.

	Command or Action	Purpose
		<ul style="list-style-type: none"> You can configure up to eight controllers. Repeat this step if you need to configure additional controllers. If TLS is not disabled in this step, configure TLS trustpoints using the tls command. You can use the clear openflow switch 1 controller all command to clear controller connections. This command can reset a connection after Transport Layer Security (TLS) certificates and keys are updated. This is not required for TCP connections. <p>A connection to a controller is initiated for the logical switch.</p>
Step 6	(Optional) tls trust-point local <i>local-trust-point remote remote-trust-point</i> Example: <pre>Device(config-ofa-switch) # tls trust-point local mylocal remote myremote</pre>	Specifies the local and remote TLS trustpoints to be used for the controller connection. <ul style="list-style-type: none"> For information on configuring trustpoints, refer to the "Configuring PKI" chapter of the <i>Cisco Nexus 7000 Series NX-OS Security Configuration Guide</i>.
Step 7	(Optional) logging flow-mod Example: <pre>Device(config-ofa-switch) # logging flow-mod</pre>	Enables logging of flow changes, including addition, deletion, and modification of flows. <ul style="list-style-type: none"> Logging of flow changes is disabled by default. Flow changes are logged in syslog and can be viewed using the show logging command. Logging of flow changes is a CPU intensive activity and should not be enabled for networks greater than 1000 flows.
Step 8	(Optional) probe-interval <i>probe-interval</i> Example: <pre>Device(config-ofa-switch) # probe-interval 5</pre>	Configures the interval, in seconds, at which the controller is probed with echo requests. <ul style="list-style-type: none"> The default value is 5. The range is from 5 to 65535.
Step 9	(Optional) rate-limit packet_in <i>controller-packet-rate burst</i> <i>maximum-packets-to-controller</i>	Configures the maximum packet rate of the connection to the controller and the maximum

	Command or Action	Purpose
	Example: <pre>Device(config-ofa-switch)# rate-limit packet_in 300 burst 50</pre>	<p>packets permitted in a burst of packets sent to the controller in a second.</p> <ul style="list-style-type: none"> • The default value is zero, meaning that an indefinite packet rate and packet burst are permitted. • This rate limit is for Cisco OpenFlow Agent. It is not related to the rate limit of the device (data plane) configured by COPP.
Step 10	(Optional) max-backoff <i>backoff-timer</i> Example: <pre>Device(config-ofa-switch)# max-backoff 8</pre>	<p>Configures the time, in seconds, for which the device must wait before attempting to initiate a connection with the controller.</p> <ul style="list-style-type: none"> • The default value is eight. • The range is from 1 to 65535.
Step 11	(Optional) datapath-id <i>id</i> Example: <pre>Device(config-ofa-switch)# datapath-id 0x111</pre>	<p><i>id</i> is a 64bit hex value. A valid <i>id</i> is in the range [0x1-0xffffffffffff]. This identifier allows the controller to uniquely identify the device.</p>
Step 12	(Optional) protocol-version [1.0 1.3 negotiate] Example: <pre>Device(config-ofa-switch)# protocol-version 1.3</pre>	<p>This command forces a specific version of the controller connection. If you force version 1.3 and the controller supports only 1.0, no session is established (or vice versa). The default behavior is to negotiate a compatible version between the controller and device.</p> <p>Supported values are:</p> <ul style="list-style-type: none"> • 1.0—Configures device to connect to 1.0 controllers only • 1.3—Configures device to connect to 1.3 controllers only • negotiate—(Default) Negotiates the protocol version with the controller. The device uses version 1.3 for negotiation.
Step 13	(Optional) shutdown Example: <pre>Device(config-ofa-switch)# shutdown</pre>	<p>This disables the OpenFlow switch without having to remove all the other configuration.</p>
Step 14	Required: default-miss <i>value</i> Example:	<p>The default-miss command sets the behavior when a packet does not match a flow in the flow table. The controller flows may override default-miss flows.</p>

	Command or Action	Purpose
	Device(config-ofa-switch) # default-miss continue-normal	<p>Note Not every action is supported on every platform.</p> <p>continue-drop: a miss in a flow table will cascade to perform a match in the next table (if applicable). A miss in the terminal table in the pipeline will result in the packet being dropped.</p> <p>continue-normal: a miss in a flow table will cascade to perform a match in the next table (if applicable). A miss in the terminal table in the pipeline will result in the packet being sent to the switch's normal hardware processing.</p> <p>continue-controller: a miss in a flow table will cascade to perform a match in the next table (if applicable). A miss in the terminal table in the pipeline will result in the packet being sent to the controller.</p> <p>drop: a miss in the first flow table of the pipeline will not cascade to any other table. Instead the packet will be dropped.</p> <p>normal: a miss in the first flow table of the pipeline will not cascade to any other table. Instead the packet will be sent to the switch's normal hardware forwarding.</p> <p>controller: a miss in the first flow table of the pipeline will not cascade to any other table. Instead the packet will be sent to the controller.</p>
Step 15	(Optional) statistics collection-interval <i>seconds</i> Example: Device(config-ofa-switch) # statistics collection 10	A setting of zero disables statistics collection. If collection is enabled, the interval must be a minimum of seven seconds. The interval setting can be used to reduce the CPU load from periodic statistics polling. For example, if you have 1000 flows and choose a statistics collection interval of 10 seconds, $1000\text{flows}/10\text{s} = 100\text{ flows per second poll rate.}$

	Command or Action	Purpose
		Note Each flow table has a prescribed maximum flows-per-second poll rate supported by hardware as displayed in the show openflow hardware capabilities command. If you choose a statistics collection interval that is too small, the maximum rate supported by the hardware is used, effectively throttling the statistics collection.
Step 16	end Example: Device (config-ofa-switch) # end	Exits logical switch configuration mode and enters privileged EXEC mode.
Step 17	copy running-config startup-config Example: Device# copy running-config startup-config	Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.

What to do next

Configure logical sub-switches.

Configuring Logical Sub-Switches

This task configures a logical subswitch for OpenFlow control by a controller other than the primary controller.

Before you begin

Configure an OpenFlow logical switch.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	openflow Example: Device (config) # openflow	Enters OpenFlow configuration mode.

	Command or Action	Purpose
Step 3	<p>Required: switch <i>switch-id</i> pipeline <i>pipeline-id</i></p> <p>Example:</p> <pre>Device(config-ofa) # switch 1 pipeline 201</pre>	<p>Selects the existing OpenFlow switch under which the subswitch will be created. This is the primary switch, which has the ID of 1.</p> <p>Note For the Cisco Nexus 3500 platform switches, the value of <i>pipeline-id</i> is 203.</p>
Step 4	<p>Required: sub-switch <i>sub-switch-id</i> vlan <i>vlan-range</i></p> <p>Example:</p> <pre>Device(config-ofa-switch) # sub-switch 2 vlan 301-305</pre>	<p>Creates an OpenFlow logical subswitch for the specified VLAN or VLAN range.</p> <ul style="list-style-type: none"> • The <i>sub-switch-id</i> is a unique ID for this sub-switch. It is an integer between 2 and 10. The primary switch has the ID of 1. • VLANs associated with this subswitch cannot also be associated to another subswitch, and VLAN ranges cannot overlap between subswitches. <p>To return to the configuration of this subswitch later, you must repeat the exact command, including the subswitch ID and the VLAN range.</p>
Step 5	<p>controller ipv4 <i>ip-address</i> [port <i>tcp-port</i>] [vrf <i>vrf-name</i>] security {none tls}</p> <p>Example:</p> <p>Controller in default VRF:</p> <pre>Device(config-ofa-switch-subswitch) # controller ipv4 10.1.1.2 security none</pre>	<p>Specifies the IPv4 address, port number, and VRF of a controller that can manage the logical switch, port number that is used by the controller to connect to the logical switch and the VRF of the controller.</p> <ul style="list-style-type: none"> • If unspecified, the default VRF is used. • Controllers use TCP port 6653 by default, but the port is configurable to a different port number using the CLI. • You can configure up to eight controllers. Repeat this step if you need to configure more controllers. • If TLS is not disabled in this step, configure TLS trustpoints using the tls command. • You can use the clear openflow switch 1 controller all command to clear controller connections. This command can reset a connection after Transport Layer Security (TLS) certificates and keys are updated. This is not required for TCP connections.

	Command or Action	Purpose
		A connection to a controller is initiated for the logical switch.
Step 6	Required: protocol-version <i>version-info</i> Example: Device (config-ofa-switch-subswitch) # protocol-version 1.3	This command forces a specific version of the controller connection. If you force version 1.3 and the controller supports only 1.0, no session is established (or vice versa). The default behavior is to negotiate a compatible version between the controller and device. Supported values are: <ul style="list-style-type: none"> • 1.0—Configures device to connect to 1.0 controllers only • 1.3—Configures device to connect to 1.3 controllers only • negotiate—(Default) Negotiates the protocol version with the controller. Device uses 1.3 for negotiation.
Step 7	(Optional) tls trust-point local <i>local-trust-point remote remote-trust-point</i> Example: Device (config-ofa-switch-subswitch) # tls trust-point local mylocal remote myremote	Specifies the local and remote TLS trustpoints to be used for the controller connection. <ul style="list-style-type: none"> • For information on configuring trustpoints, refer to the "Configuring PKI" chapter of the <i>Cisco Nexus 7000 Series NX-OS Security Configuration Guide</i>.
Step 8	(Optional) probe-interval <i>probe-interval</i> Example: Device (config-ofa-switch-subswitch) # probe-interval 5	Configures the interval, in seconds, at which the controller is probed with echo requests. <ul style="list-style-type: none"> • The default value is 5. • The range is 5–65535.
Step 9	(Optional) rate-limit packet_in <i>controller-packet-rate burst</i> <i>maximum-packets-to-controller</i> Example: Device (config-ofa-switch-subswitch) # rate-limit packet_in 300 burst 50	Configures the maximum packet rate of the connection to the controller and the maximum packets that are permitted in a burst of packets that are sent to the controller in a second. <ul style="list-style-type: none"> • The default value is zero, meaning that an indefinite packet rate and packet burst are permitted. • This rate limit is for Cisco OpenFlow Agent. It is not related to the rate limit of the device (data plane) configured by CoPP.

	Command or Action	Purpose
Step 10	(Optional) max-backoff <i>backoff-timer</i> Example: Device(config-ofa-switch-subswitch) # max-backoff 8	Configures the time, in seconds, for which the device must wait before attempting to retry the connection with the controller. <ul style="list-style-type: none"> • The default value is eight. • The range is 1–65535 seconds.
Step 11	(Optional) datapath-id <i>id</i> Example: Device(config-ofa-switch-subswitch) # datapath-id 0x111	The identifier of the subswitch, which allows the controller to uniquely identify the device. This command overwrites the default value, which is based on the MAC address of the switch and the ID of the subswitch. A valid <i>id</i> is a 64-bit hex value in the range [0x1-0xffffffffffff].

Configuration Examples for Cisco OpenFlow Agent

Example: Enabling Cisco OpenFlow Agent in the Nexus 3000 series device

```

Device> enable
Device# configure terminal
Device(config)# system switch-mode n9k
Device# exit
Device# write erase
Device# reload
This command will reboot the system. (y/n)? [n] y
.
.
.
[log in after reboot]
Device# configure terminal
Device(config)# feature openflow
Device(config)# show feature | inc openflow
openflow                1                enabled

```

Example: Enabling Cisco OpenFlow Agent in the Nexus 9000 series device

```

Device# configure terminal
Device(config)# feature openflow
Device(config)# show feature | inc openflow
openflow                1                enabled

```

Example: Adjusting the Number of Flow Entries

```

Device# configure terminal
Device(config)# hardware access-list tcam region racl 0

```

```

Device(config)# hardware access-list tcam region e-racl 0
Device(config)# hardware access-list tcam region l3qos 0
Device(config)# hardware access-list tcam region span 0
Device(config)# hardware access-list tcam region redirect 0
Device(config)# hardware access-list tcam region vpc-convergence 0
Device(config)# hardware access-list tcam region openflow 1024
Device(config)# exit
Device# copy running-config startup-config
Device# reload

```

Example: Configuring Global Variables for a Cisco OpenFlow Agent Logical Switch

```

Device# configure terminal
Device(config)# mac-learn disable
Device(config)# spanning-tree mode mst
Device(config)# vlan 2
Device(config-vlan)# end

```

Example: Configuring Control Plane Policing for Packets Sent to a Controller

```

Device# configure terminal
Device# setup

```

---- Basic System Configuration Dialog ----

This setup utility will guide you through the basic configuration of the system. Setup configures only enough connectivity for management of the system.

*Note: setup is mainly used for configuring the system initially, when no configuration is present. So setup always assumes system defaults and not the current system configuration values.

Press Enter at anytime to skip a dialog. Use ctrl-c at anytime to skip the remaining dialogs.

Would you like to enter the basic configuration dialog (yes/no): **yes**

Create another login account (yes/no) [n]:

Configure read-only SNMP community string (yes/no) [n]:

Configure read-write SNMP community string (yes/no) [n]:

Enter the switch name : **QI32**

Continue with Out-of-band (mgmt0) management configuration? (yes/no) [y]: **n**

Configure the default gateway? (yes/no) [y]: **n**

Enable the telnet service? (yes/no) [n]: **y**

Enable the ssh service? (yes/no) [y]: **n**

Configure the ntp server? (yes/no) [n]:

Configure default interface layer (L3/L2) [L2]:

```
Configure default switchport interface state (shut/noshut) [noshut]:
Configure CoPP System Policy Profile ( default / 12 / 13 ) [default]:
```

The following configuration will be applied:

```
switchname QI32
telnet server enable
no ssh server enable
system default switchport
no system default switchport shutdown
policy-map type control-plane copp-system-policy ( default )
```

Would you like to edit the configuration? (yes/no) [n]:

Use this configuration and save it? (yes/no) [y]:

```
[#####] 100%
Copy complete, now saving to disk (please wait)...
```

```
Device# configure terminal
Device(config)# policy-map type control-plane copp-system-policy
Device(config-pmap)# class copp-s-dpss
Device(config-pmap-c)# police pps 1000
Device(config-pmap-c)# end
Device# show run copp
```

Example: Specifying a Route to a Controller Using a Physical Interface

```
Device# configure terminal
Device(config)# interface ethernet1/1
Device(config-if)# no switchport
Device(config-if)# ip address 10.0.1.4 255.255.255.255
Device(config-if)# exit
Device(config)# ip route 0.0.0.0 0.0.0.0 10.0.1.6
Device# copy running-config startup-config
Device(config)# exit
```

Example: Specifying a Route to a Controller Using a Management Interface

```
Device# configure terminal
Device(config)# interface mgmt0
Device(config-if)# no switchport
Device(config-if)# ip address 10.0.1.4 255.255.255.255
Device(config-if)# exit
Device(config)# vrf context management
Device(config)# ip route 0.0.0.0 0.0.0.0 10.0.1.6
Device# copy running-config startup-config
Device(config)# exit
```

Example: Configuring an Interface for a Cisco OpenFlow Agent Logical Switch in L2 mode

```
Device# configure terminal

Device(config)# interface ethernet1/1
Device(config-if)# switchport mode trunk
Device(config-if)# no shutdown
Device(config-if)# exit

Device(config)# interface ethernet1/2
```

```

! Adding the interface to a port channel.
Device(config-if)# channel-group 2
Device(config-if)# switchport mode trunk
Device(config-if)# no shutdown
Device(config-if)# end
Device# copy running-config startup-config

```

Example: Configuring a Port-Channel Interface

```

Device# configure terminal
Device(config)# interface port-channel 2
Device(config-if)# switchport mode trunk
Device(config-if)# end
Device# copy running-config startup-config

```

Example: Cisco OpenFlow Agent Logical Switch Configuration (Default VRF)

```

Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1 pipeline 201
! Specifies the pipeline that enables the IP Forwarding Table.
Device(config-ofa-switch)# logging flow-mod
Device(config-ofa-switch)# max-backoff 5
Device(config-ofa-switch)# probe-interval 5
Device(config-ofa-switch)# rate-limit packet-in 300 burst 50
Device(config-ofa-switch)# controller ipv4 10.0.1.6 security none
! Adding an interface to the Cisco OpenFlow Agent logical switch.
Device(config-ofa-switch)# of-port interface ethernet1/1
Device(config-ofa-switch)# of-port interface ethernet1/2
! Adding a port channel to the Cisco OpenFlow Agent switch.
Device(config-ofa-switch)# of-port interface port-channel 2
Device(config-ofa-switch)# end
Device# copy running-config startup-config

```

Example: Configuring a Cisco OpenFlow Agent Logical Switch (Management VRF)

```

Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1 pipeline 201
! Specifying a controller that is part of a VRF.
Device(config-ofa-switch)# controller ipv4 10.0.1.6 vrf management security none
! Adding an interface to the Cisco OpenFlow Agent logical switch.

Device(config-ofa-switch)# of-port interface ethernet1/1
Device(config-ofa-switch)# of-port interface ethernet1/2
! Adding a port channel to the Cisco OpenFlow Agent switch.
Device(config-ofa-switch)# of-port interface port-channel 2
Device(config-ofa-switch)# end
Device# copy running-config startup-config

```

Example: Creating a Sub-Switch

```

Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1 pipeline 201
Device(config-ofa-switch)# controller ipv4 5.30.199.200 port 6645 vrf management security

```

```

none
Device(config-ofa-switch)# of-port interface port-channel1000
Device(config-ofa-switch)# of-port interface Ethernet1/1
Device(config-ofa-switch)# of-port interface Ethernet1/37
Device(config-ofa-switch)# of-port interface Ethernet1/39
Device(config-ofa-switch)# logging flow-mod
Device(config-ofa-switch)# sub-switch 2 vlan 100
Device(config-ofa-switch-subswitch)# controller ipv4 5.30.19.239 port 6653 vrf management
security none

```

NXOS NXAPI Migration from OpenFlow

Beginning with Cisco Nexus Release 10.3(3)F, Openflow is not supported on N3500. Upgrade from older NXOS releases with Active Openflow configuration is not supported. Users should remove any active OpenFlow configuration on the device before the upgrade. After the upgrade, users can achieve similar redirect functionality using NXAPI.

Below are the steps to Upgrade Cisco Nexus 3500 devices and configure the same functionality through NXAPI.

Before you begin

Follow the steps as mentioned in [Uninstalling Cisco Plug-in for OpenFlow](#) and disable OpenFlow feature on NXOS.

Procedure

	Command or Action	Purpose
Step 1	switch(config)# no feature openflow	Removes all openflow related configurations from the switch.
Step 2	switch(config)# hardware profile forwarding-mode normal	Sets hardware profile forwarding mode to normal.
Step 3	switch(config)# no hardware profile openflow forward-pdu	Reset openflow forward pdu flag in hardware. Ignore this step if you have not configured it. Save the configuration.

Achieving OpenFlow Functionality

Follow the steps as mentioned in **NXOS NXAPI Migration from OpenFlow** to upgrade to 10.3(3)F release. When the device is reloaded after upgrade, use the following commands to achieve OpenFlow functionality using CLIs supporting NXAPIs.

Before you begin

Follow the steps as mentioned in **NXOS NXAPI Migration from OpenFlow** to upgrade to 10.3(3)F release.

Procedure

	Command or Action	Purpose
Step 1	switch(config)# hardware profile tcam region ifacl-wide 4096/8192	Performs TCAM Carving. IFACL & IFACL-WIDE TCAM carvings are mutually exclusive, resize IFACL TCAM size to 0. This requires a box reload. Resize IFACL TCAM size to 0 first, before performing this step. Use the command hardware profile tcam region ifacl 0 to reduce the ifacl tcam size. This requires a box reload.
Step 2	switch(config)# hardware profile flow-redirect forward-pdu	Enable forward pdu.
Step 3	switch(config)# interface type number	Configures an interface and enters interface configuration mode.
Step 4	switch(config-if)# mode flow-redirect	Redirects mode. Configure this on required trunk interfaces.

What to do next

See [Configuring Wideflow IFACL Redirect on IP Port ACLs](#) to define a new access-list with wideflow options. Attach IFACL to flow redirect interfaces as IFACL using standard ACL.



Note CLI support to define a new access-list Attach IFACL to flow redirect are interim till NDB starts supporting these. NDB GUI is recommended configuration approach once these options are supported by NDB.

Verifying Cisco OpenFlow Agent

Procedure**Step 1**

show openflow switch *switch-id*

Displays information that is related to a Cisco OpenFlow Agent logical switch.

Example:

Device# **show openflow switch 1**

```
Logical Switch Context
Id: 1
Switch type: Forwarding
Pipeline id: 201
VLAN restrictions: none
Data plane: secure
```



```

Table-Miss default: controller
Configured protocol version: Negotiate
Config state: no-shutdown
Working state: enabled
Rate limit (packet per second): 300
Burst limit: 50
Max backoff (sec): 8
Probe interval (sec): 5
TLS local trustpoint name: not configured
TLS remote trustpoint name: not configured
Logging flow changes: Enabled
Stats collect interval (sec): 7
Stats collect Max flows: 3001
Minimum flow idle timeout (sec): 14
OFA Description:
  Manufacturer: Cisco Systems, Inc.
  Hardware: N9K-C9372PX 2.1
  Software: 7.0(3)I5(0.51)| of_agent 0.1
  Serial Num: SAL1944RZQN
  DP Description: switch:sw1
OF Features:
  DPID: 0x00000000000009000
  Number of tables:1
  Number of buffers:256
  Capabilities: FLOW_STATS TABLE_STATS PORT_STATS
Controllers:
  5.30.19.236:6653, Protocol: TCP, VRF: management
Interfaces:
  Ethernet1/1
  Ethernet1/2

```

Step 2 **show openflow switch *switch-id* controllers [stats]**

Displays information that is related to the connection status between a Cisco OpenFlow Agent logical switch and connected controllers.

Example:

```
Device# show openflow switch 1 controllers
```

```

Logical Switch Id: 1
Total Controllers: 1
  Controller: 1
    5.30.19.236:6653
    Protocol: tcp
    VRF: management
    Connected: Yes
    Role: Master
    Negotiated Protocol Version: OpenFlow 1.3
    Last Alive Ping: 09/27/2016 00:04:53
    last_error:Connection timed out
    state:ACTIVE
    sec_since_connect:103334
    sec_since_disconnect:103345
    Current Role Since: 09/25/2016 19:22:41

```

The above sample output is displayed when the controller is connected (state:ACTIVE).

```
Device# show openflow switch 1 controllers stats
```

```

Logical Switch Id: 1
Total Controllers: 1

```

```

Controller: 1
  address                : tcp:5.30.19.236:6653%management
  connection attempts    : 19
  successful connection attempts : 2
  flow adds               : 2
  flow mods               : 0
  flow deletes            : 0
  flow removals           : 0
  flow errors             : 0
  flow unencodable errors : 0
  total errors            : 0
  echo requests           : rx: 0, tx: 7
  echo reply              : rx: 6, tx: 0
  flow stats              : rx: 33763, tx: 33763
  barrier                 : rx: 2, tx: 2
  packet-in/packet-out    : rx: 0, tx: 23033
  Topology Monitor        : rx: 0, tx: 0
  Topology State          : rx: 0

```

Step 3 **show running-config interface ethernet** *interface-id*

In the interface configuration, verify **mode openflow**.

Example:

```

Device# show running-config interface ethernet 1/2

!Command: show running-config interface Ethernet1/2
!Time: Thu Sep 29 00:08:18 2016

version 7.0(3)I5(1)

interface Ethernet1/7
no lldp transmit
spanning-tree bpdufilter enable
mode openflow

```

Step 4 **show openflow switch** *switch-id* **ports**

Displays the mapping between physical device interfaces and ports of a Cisco OpenFlow Agent logical switch.

Example:

```

Device# show openflow switch 1 ports

Logical Switch Id: 1

```

Port	Interface Name	Config-State	Link-State	Features
2	Ethernet1/2	PORT_UP	LINK_UP	10MB-FD
3	Ethernet1/3	PORT_UP	LINK_DOWN	100MB-HD AUTO_NEG
4	Ethernet1/4	PORT_UP	LINK_UP	10MB-FD

Step 5 **show openflow switch** *switch-id* **flows** [**configured** | **controller** | **default** | **fixed** | **pending** | **pending-del**] [**brief** | **summary**]

Displays flows defined for the device by controllers.

Example:

```

Device# show openflow switch 1 flows

Logical Switch Id: 1
Total flows: 2

```

```

Flow: 1
  Match:          any
  Actions:        CONTROLLER:0
  Priority:        0
  Table:          0
  Cookie:         0x0
  Duration:       104160.376s
  Number of packets: 0
  Number of bytes: 0

Flow: 2
  Match:          in_port=2,d1_vlan=100
  Actions:        drop
  Priority:        100
  Table:          0
  Cookie:         0x0
  Duration:       103753.162s
  Number of packets: 0
  Number of bytes: 0

```

The following example show flows installed by the OpenFlow agent:

```

Device# show openflow switch 1 flows configured

Logical Switch Id: 1
Total flows: 1

Flow: 1
  Match:          any
  Actions:        CONTROLLER:0
  Priority:        0
  Table:          0
  Cookie:         0x0
  Duration:       104180.584s
  Number of packets: 0
  Number of bytes: 0

```

The following example show flows installed from the controller:

```

Device# show openflow switch 1 flows controller

Logical Switch Id: 1
Total flows: 1
Flow: 1
Match: in_port=2,d1_vlan=100
Actions: drop
Priority: 100
Table: 0
Cookie: 0x0
Duration: 103753.162s
Number of packets: 0
Number of bytes: 0

```

The following example displays the flow summary:

```

switch# show openflow switch 1 flows summary
Logical Switch Id: 1
Switch flow count: 2

```

The following example displays the brief version:

```

switch# show openflow switch 1 flows brief
Logical Switch Id: 1
Total flows: 3

Flow: 1 Match: any Actions: drop
Priority: 0, Table: 0, Cookie: 0x0, Duration: 127.349s, Packets: 7653260179, Bytes:
489808651630

Flow: 2 Match: dl_type=0x88cc Actions: CONTROLLER:65535
Priority: 50000, Table: 0, Cookie: 0x0, Duration: 127.431s, Packets: 14, Bytes: 1472

Flow: 3 Match: in_port=34,dl_type=0x800 Actions: output:20
Priority: 500, Table: 0, Cookie: 0x0, Duration: 127.432s, Packets: 63, Bytes: 4032

```

Step 6 **show openflow switch switch-id flow stats**

Displays send and receive statistics for each port that is defined for a Cisco OpenFlow Agent logical switch.

Example:

```

Device# show openflow switch 1 flow stats

Logical Switch Id: 1

Total ports: 2
  Port 1: rx pkts=96932, bytes=10911299, drop=0, errs=0,
          tx pkts=209683, bytes=19045035, drop=0, errs=0,
  Port 2: rx pkts=350485253, bytes=23834112937, drop=0, errs=0,
          tx pkts=191127, bytes=16001929, drop=0, errs=0,
Total tables: 1
  Table 0: NXOS PLCMGR IPV6 - PIPE 201
  Wildcards = 0x300033
  Max entries = 3001
  Active entries = 2
  Number of lookups = 0
  Number of matches = 0

```

Flow statistics are available for pipeline 201 and table 0. For pipeline 202, flow statistics are not available for table 1.

Step 7 **show logging last number-of-lines**

Displays logging information of flow changes, including addition, deletion, or modification of flows.

Example:

```

Device# show logging last 10

2016 Oct 5 09:52:27 switch of_agent: <{of_agent}> libpolicyshim:
policy_shim_parse_plcmgr_policy_stats 65
15 cmd_attr 352256118
2016 Oct 5 09:52:27 switch of_agent: <{of_agent}> libpolicyshim:
policy_shim_parse_plcmgr_policy_stats 65
43 ppf_id 87032089
2016 Oct 5 09:52:27 switch of_agent: <{of_agent}> libpolicyshim:
policy_shim_parse_plcmgr_policy_stats 65
15 cmd_attr 352256200
2016 Oct 5 09:52:27 switch of_agent: <{of_agent}> libpolicyshim:
policy_shim_parse_plcmgr_policy_stats 65
36 pkts 0x9d3b bytes 0x0
2016 Oct 5 09:52:27 switch of_agent: <{of_agent}>|-|00353|plif_xos_util|DBG|cstat
classified.pkts = 40251

```

```

2016 Oct  5 09:52:27 switch of_agent: <{of_agent}>|-|00354|plif_xos_util|DBG|cstat
classified.bytes = 0
2016 Oct  5 09:52:27 switch of_agent: <{of_agent}>|-|00355|plif_xos_util|DBG|cstat drop.pkts
= 0
2016 Oct  5 09:52:27 switch of_agent: <{of_agent}>|-|00356|plif_xos_util|DBG|cstat drop.bytes
= 0
2016 Oct  5 09:52:27 switch of_agent: <{of_agent}>|-|00357|plif_xos|DBG|PXOS lookup switch
by ls_id: switc
h ls_id is 1, passed in ls_id is 1
2016 Oct  5 09:52:28 switch of_agent: <{of_agent}>|-|1841673|poll_loop|DBG|wakeup due to
999-ms timeout at
../feature/sdn/openflow/cmn/ovs/cof_ovs_ofproto_plif.c:815 (0% CPU usage)

```

Step 8 **show running-config openflow**

Displays configurations that are made for Cisco OpenFlow Agent.

Example:

```

Device# show running-config openflow

!Command: show running-config openflow
!Time: Tue Sep 27 00:19:00 2016

version 7.0(3)I5(1)
feature openflow

openflow
  switch 1 pipeline 201
    rate-limit packet_in 300 burst 50
    probe-interval 5
    statistics collection-interval 7
    datapath-id 0x9000
    controller ipv4 5.30.19.236 port 6653 vrf management security none
    of-port interface Ethernet1/1
    of-port interface Ethernet1/2
    default-miss controller
    logging flow-mod

```

Step 9 **show running-config openflow**

Displays configurations that are made for Cisco OpenFlow Agent for Cisco Nexus 3500 platform switches.

Example:

```

Device# show running-config openflow

!Command: show running-config openflow
!Time: Tue Sep 27 00:19:00 2016

version 7.0(3)I7(8)
feature openflow

openflow
  switch 1 pipeline 203
    rate-limit packet_in 300 burst 50
    probe-interval 10
    max-backoff 5
    statistics collection-interval 7
    datapath-id 0x1
    controller ipv4 5.30.19.236 port 6653 vrf management security none
    of-port interface Ethernet1/17
    of-port interface Ethernet1/18
    of-port interface Ethernet1/19

```

```

of-port interface Ethernet1/33
of-port interface Ethernet1/48
default-miss controller
logging flow-mod

```

Step 10 show openflow hardware capabilities

Displays hardware capabilities for OpenFlow.

Example:

Device# **show openflow hardware capabilities**

```

Max Interfaces: 1000
Aggregated Statistics: NO

Pipeline ID: 201
  Pipeline Max Flows: 3001
  Max Flow Batch Size: 300
  Statistics Max Polling Rate (flows/sec): 1024
  Pipeline Default Statistics Collect Interval: 7

Flow table ID: 0

Max Flow Batch Size: 300
Max Flows: 3001
Bind Subintfs: FALSE
Primary Table: TRUE
Table Programmable: TRUE
Miss Programmable: TRUE
Number of goto tables: 0
goto table id:
Stats collection time for full table (sec): 3

Match Capabilities                                Match Types
-----
ethernet type                                    optional
VLAN ID                                          optional
VLAN priority code point                       optional
IP DSCP                                         optional
IP protocol                                    optional
ipv6 source addresss                           lengthmask
ipv6 destination address                      lengthmask
source port                                    optional
destination port                              optional
in port (virtual or physical)                 optional
wildcard all matches                          optional

Actions                                Count Limit    Order
-----
specified interface                    64             20
controller                            1              20
divert a copy of pkt to application    1              20

set eth source mac                     1              10
set eth destination mac                1              10
set vlan id                           1              10

pop vlan tag                           1              10

drop packet                            1              20

Miss actions                                Count Limit    Order
-----
use normal forwarding                  1              0

```

controller	1	20
drop packet	1	20

Max Interfaces: 1000
 Aggregated Statistics: NO

Pipeline ID: 202
 Pipeline Max Flows: 3001
 Max Flow Batch Size: 300
 Statistics Max Polling Rate (flows/sec): 1024
 Pipeline Default Statistics Collect Interval: 7

Flow table ID: 0

Max Flow Batch Size: 300
 Max Flows: 3001
 Bind Subintfs: FALSE
 Primary Table: TRUE
 Table Programmable: TRUE
 Miss Programmable: TRUE
 Number of goto tables: 1
 goto table id: 1
 Stats collection time for full table (sec): 3

Match Capabilities	Match Types
-----	-----
ethernet type	optional
VLAN ID	optional
VLAN priority code point	optional
IP DSCP	optional
IP protocol	optional
ipv6 source addresss	lengthmask
ipv6 destination address	lengthmask
source port	optional
destination port	optional
in port (virtual or physical)	optional
wildcard all matches	optional

Actions	Count Limit	Order
specified interface	64	20
controller	1	20
divert a copy of pkt to application	1	20
set eth source mac	1	10
set eth destination mac	1	10
set vlan id	1	10
pop vlan tag	1	10
drop packet	1	20

Miss actions	Count Limit	Order
use normal forwarding	1	0
controller	1	20
perform another lookup in the specified table	1	20
drop packet	1	20

```

Flow table ID: 1

Max Flow Batch Size: 300
Max Flows: 32001
Bind Subintfs: FALSE
Primary Table: FALSE
Table Programmable: TRUE
Miss Programmable: TRUE
Number of goto tables: 0
goto table id:
Stats collection: Not Supported

Match Capabilities          Match Types
-----
ethernet mac destination    mandatory
VLAN ID                     mandatory
wildcard all matches        mandatory

Actions                      Count Limit      Order
specified interface         64              20

drop packet                  1              20

Miss actions                 Count Limit      Order
use normal forwarding        1              0
controller                   1              20
drop packet                  1              20

```

Step 11 **show openflow switch 2**

Displays configuration of OpenFlow subswitch.

Example:

```

Device# show openflow switch 2

Logical Switch Context
Id: 2
Switch type: Forwarding
Pipeline id: 201
VLAN restrictions: 100
Data plane: secure
Table-Miss default: drop
Configured protocol version: Negotiate
Config state: no-shutdown
Working state: enabled
Rate limit (packet per second): 0
Burst limit: 0
Max backoff (sec): 8
Probe interval (sec): 180
TLS local trustpoint name: not configured
TLS remote trustpoint name: not configured
Logging flow changes: Disabled
Stats collect interval (sec): 7
Stats collect Max flows: 3001
Minimum flow idle timeout (sec): 14
OFA Description:
  Manufacturer: Cisco Systems, Inc.
  Hardware: N9K-C9372PX 2.1

```



```

Software: 7.0(3)I5(0.51)| of_agent 0.1
Serial Num: SAL1944RZQN
DP Description: switch:sw2
OF Features:
  DPID: 0x000258ac786b5457
  Number of tables:1
  Number of buffers:256
  Capabilities: FLOW_STATS TABLE_STATS PORT_STATS
Controllers:
  5.30.19.239:6653, Protocol: TCP, VRF: management
Interfaces:
  port-channel1000
  Ethernet1/1
  Ethernet1/37
  Ethernet1/39

```

Step 12 **show openflow switch 1**

Displays configuration of OpenFlow subswitch for Cisco Nexus 9500 platform switches.

Example:

```

Device# show openflow switch 1

Logical Switch Context
  Id: 1
  Switch type: Forwarding
  Pipeline id: 203
  VLAN restrictions: none
  Data plane: secure
  Table-Miss default: drop
  Configured protocol version: Negotiate
  Config state: no-shutdown
  Working state: enabled
  Rate limit (packet per second): 0
  Burst limit: 0
  Max backoff (sec): 5
  Probe interval (sec): 10
  TLS local trustpoint name: not configured
  TLS remote trustpoint name: not configured
  Logging flow changes: Enabled
  Stats collect interval (sec): 7
  Stats collect Max flows: 4095
  Minimum flow idle timeout (sec): 14
OFA Description:
  Manufacturer: Cisco Systems, Inc.
  Hardware: N9K-C3548P-10G V00
  Software: 7.0(3)I7(8)| of_agent 0.1
  Serial Num: FOC163R04W
  DP Description: OF-MTC:sw1
OF Features:
  DPID: 0x0001<>
  Number of tables:1
  Number of buffers:256
  Capabilities: FLOW_STATS TABLE_STATS PORT_STATS
  Actions: OUTPUT SET_VLAN_VID STRIP_VLAN
Controllers:
  <>:6653, Protocol: TCP, VRF: management
Interfaces:
  Ethernet1/17
  Ethernet1/18
  Ethernet1/19
  Ethernet1/33

```

Ethernet1/48

Step 13 show openflow switch 2 controllers stats

Displays information that is related to the controller statistics for a logical subswitch.

Example:

```
Device# show openflow switch 2 controllers stats

Logical Switch Id: 2
Total Controllers: 1
  Controller: 1
    address                : tcp:5.30.19.239:6653%management
    connection attempts    : 5
    successful connection attempts : 0
    flow adds               : 0
    flow mods               : 0
    flow deletes            : 0
    flow removals           : 0
    flow errors             : 0
    flow unencodable errors : 0
    total errors            : 0
    echo requests           : rx: 0, tx: 0
    echo reply              : rx: 0, tx: 0
    flow stats              : rx: 0, tx: 0
    barrier                 : rx: 0, tx: 0
    packet-in/packet-out    : rx: 0, tx: 0
    Topology Monitor        : rx: 0, tx: 0
    Topology State          : rx: 0
```

Step 14 show run openflow

Displays configurations that are made for Cisco OpenFlow Agent when a subswitch is configured.

Example:

```
Device# show run openflow

!Command: show running-config openflow
!Time: Thu Sep 29 00:09:21 2016

version 7.0(3)I5(1)
feature openflow

openflow
  switch 1 pipeline 201
    controller ipv4 5.30.199.200 port 6645 vrf management security none
    of-port interface port-channel1000
    of-port interface Ethernet1/1
    of-port interface Ethernet1/37
    of-port interface Ethernet1/39
    logging flow-mod
    sub-switch 2 vlan 100
      controller ipv4 5.30.19.239 port 6653 vrf management security none
```

Step 15 show openflow hardware capabilities

Displays configurations that are made for Cisco OpenFlow Agent when a subswitch is configured for Cisco Nexus 3500 platform switches.

Example:

Device# **show openflow hardware capabilities**

Max Interfaces: 1000
Aggregated Statistics: YES

Pipeline ID: 203
Pipeline Max Flows: 4095
Max Flow Batch Size: 100
Statistics Max Polling Rate (flows/sec): 1024
Pipeline Default Statistics Collect Interval: 7

Flow table ID: 0

Max Flow Batch Size: 0
Max Flows: 4095
Bind Subintfs: FALSE
Primary Table: TRUE
Table Programmable: TRUE
Miss Programmable: TRUE
Number of goto tables: 0
goto table id:
Stats collection time for full table (sec): 4

Match Capabilities	Match Types
-----	-----
ethernet mac destination	optional
ethernet mac source	optional
ethernet type	optional
VLAN ID	optional
IP DSCP	optional
IP protocol	optional
IPv4 source address	lengthmask
IPv4 destination address	lengthmask
source port	optional
destination port	optional
in port (virtual or physical)	optional

Actions	Count Limit	Order	
specified interface		64	20
controller		1	20
set vlan id		1	10
pop vlan tag		1	10
drop packet		1	20
Miss actions	Count Limit	Order	
specified interface		64	20
controller		1	20
drop packet		1	20

Additional Information for Cisco OpenFlow Agent

Related Documents

Related Topic	Document Title
Cisco command references	Cisco Nexus 3000 Series Switches Command References Cisco Nexus 9000 Series Switches Command References

Standards and RFCs

Standard/RFC	Title
OpenFlow 1.3	<i>OpenFlow Switch Specification Version 1.3.0 (Wire Protocol 0x04).</i>
OpenFlow 1.0	<i>OpenFlow Switch Specification Version 1.0.1 (Wire Protocol 0x01).</i>

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation and tools. Use these resources to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html

Feature Information for Cisco OpenFlow Agent

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 4: Feature Information for Cisco OpenFlow Agent

Feature Name	Releases	Feature Information
Cisco OpenFlow Agent	7.0(3)I5(1)	Cisco OpenFlow Agent is introduced, replacing the Cisco Plug-in for OpenFlow used in previous NX-OS releases.