



# CONTENTS

## **Preface** xvii

Document Revision History	xvii
Document Objectives	xix
Audience	xix
Document Organization	xix
Conventions	xxi
Safety Warnings and Cautions	xxi
Warning Definition	xxii
Related Documentation	xxvii
Obtaining Documentation and Submitting a Service Request	xxviii

---

## **CHAPTER 1**

### **Cisco ASR 1000 Series Routers Hardware Overview** 1-1

Cisco ASR 1000 Series Routers	1-2
Cisco ASR 1000 Series Router Features	1-3
Cisco ASR 1000 Series Routers Compatibility Information	1-4
Hardware Compatibility	1-5
Cisco ASR 1000 Series Router Configurations	1-6
Field-Replaceable Units	1-7
Functional Overview	1-8
Chassis Slot and Logical Interface Numbering	1-8
MAC Address Information	1-8
Online Insertion and Removal	1-9
Environmental Monitoring and Reporting Functions	1-10
Environmental Monitoring	1-10
Fan Failures	1-11
Reporting Functions	1-12
Cisco Product Identification Standard	1-17
Unique Device Identifier	1-17
Serial Number Label Location	1-18

---

## **CHAPTER 2**

### **Cisco ASR 1000 Series Routers Component Overview** 2-27

Cisco ASR 1000 Series Routers Component Software Support	2-27
Upgrading to New Software	2-27

Supported ASR 1000 Hardware Components	2-29
Supported Cisco ASR 1000 Platforms	2-29
Cisco ASR 1000 Series Hardware Configuration Combinations	2-30
Hardware Requiring a CPLD Upgrade	2-31
Incompatible Hardware Configuration Combinations	2-31
Incompatible ASR1000-ESP Error Message	2-32
Incompatible ASR1000-RP Error Message	2-32
Unsupported Hardware Configurations	2-32
Unsupported ASR1000-ESP Error Message	2-33
Unsupported ASR1000-SIP Error Message	2-34
Incompatible Cisco High Availability Hardware Configurations	2-34
Upgrading Existing Hardware Components to Support the Cisco ASR 1013 Router	2-34
Unsupported Active ASR1000-RP2 Requires Upgrade	2-35
When To Perform a CPLD Upgrade	2-36
Unsupported Standby ASR1000-RP2 or ASR1000-SIP10 Requires Upgrade	2-36
Image to Upgrade Field-Programmable Hardware Devices	2-37
Cisco ASR 1000 Series Route Processor	2-37
Cisco ASR 1000 Series Route Processor Differences	2-38
Cisco Integrated ASR1000-RP1 for Cisco ASR 1002 Router	2-43
How Cisco ASR1000-RP Alarm Monitoring Works	2-46
Cisco ASR 1000 Series Router Power Supplies	2-47
Power Supply Requirements for All Cisco ASR 1000 Series Routers	2-47
DC Power System Input Requirements for Cisco ASR 1000 Series Routers	2-47
AC and DC Power Supply Types	2-48
AC and DC System Power Ratings	2-49
Power Supplies for the Cisco ASR 1006 Router	2-49
AC Power Supply LEDs and Connector for Cisco ASR 1006	2-50
–48 VDC Power Supply LEDs and Connectors for Cisco ASR 1006	2-53
Power Supplies for the Cisco ASR 1004 Router	2-55
Cisco ASR 1004 AC Power Supply	2-56
Cisco ASR 1004 AC Power Supply LEDs and Connector	2-57
Cisco ASR Router 1004 –48 VDC Power Supply	2-59
Cisco ASR 1004 Router –48 VDC Power Supply LEDs and Connector	2-60
DC Power System Input for Cisco ASR 1004	2-61
AC/DC Power System Output for Cisco ASR 1004	2-61
Power Supplies for the Cisco ASR 1002 Router	2-62
Cisco ASR 1002 Router AC Power Supply	2-62
Cisco ASR 1002 AC Power Supply LEDs and Connector	2-63
Cisco ASR 1002 Router –48 VDC Power Supply	2-64

Cisco ASR 1002 Router –48 VDC Power Supply LEDs and Connector	2-65
–48 VDC Power System Input for Cisco ASR 1002 Router	2-66
–48 VDC Power System Output for Cisco ASR 1002 Router	2-66
Cisco ASR 1002 Router +24 VDC Power Supply	2-67
Cisco ASR 1002 Router +24 VDC Power Supply LEDs and Connector	2-67
+24 VDC Power System Input for Cisco ASR 1002 Router	2-68
+24 VDC Power System Output for Cisco ASR 1002 Router	2-69
Power Supplies for the Cisco ASR 1013 Router	2-70
AC Power Supply LEDs and Connector for Cisco ASR 1013	2-71
–48 VDC Power Supply LEDs and Connectors for Cisco ASR 1013	2-73
Power Supplies for the Cisco ASR 1001 Router	2-75
Cisco ASR 1001 Router AC Power Supply	2-77
Cisco ASR 1001 Router DC Power Supply	2-77

---

**CHAPTER 3**
**Cisco ASR 1000 Series Routers Embedded Services Processors 3-79**

Cisco ASR 1000-ESP5	3-80
Cisco ASR 1000-ESP10	3-80
Cisco ASR 1000-ESP20	3-81
Cisco ASR 1000-ESP40	3-81
Cisco ASR 1000-ESP100	3-82
Cisco ASR 1000-ESP200	3-82
Cisco ASR 1000-ESP200 and Third Generation Cisco QFP	3-83
Implications of SIP and SPA Slot Mapping	3-84
Features of the Cisco ASR 1000 Series Embedded Services Processors	3-85

---

**CHAPTER 4**
**Cisco ASR 1000 Series Router SPA Interface Processors (SIPs) 4-89**

Cisco ASR 1000 Series SPA Interface Processor	4-90
SPA Interface Processor Slot Numbering	4-92
Cisco ASR 1006 Router and Cisco ASR 1004 Router	4-92
Cisco ASR 1002 Router	4-93
Cisco ASR 1002-F Router	4-94
Cisco ASR 1013 Router	4-95
Cisco ASR 1001 Router	4-97
Cisco ASR 1002-X Router	4-97

---

**CHAPTER 5**
**Preparing Your Site for Installation 5-99**

Prerequisites and Preparation	5-99
Safety Guidelines	5-100

Safety Warnings	5-100
Safety Recommendations	5-101
Compliance Requirements	5-101
Cautions and Regulatory Compliance Statements for NEBS	5-102
Standard Warning Statements	5-103
General Safety Warnings	5-103
Site Planning	5-106
General Precautions	5-106
Site Selection Guidelines	5-107
Site Environmental Requirements	5-107
Physical Characteristics	5-108
Floor Loading Considerations	5-110
Site Power Guidelines	5-110
Electrical Circuit Requirements	5-110
Site Cabling Guidelines	5-111
Asynchronous Terminal Connections	5-112
Interference Considerations	5-112
Rack-Mounting Guidelines	5-114
Precautions for Rack-Mounting	5-114
General Rack Selection Guidelines	5-114
Guidelines for 23 in. (Telco) Racks	5-115
Equipment Rack Guidelines	5-115
Site Planning Checklist	5-116
Preventing Electrostatic Discharge Damage	5-116
Electrical Safety	5-119
Receiving the Cisco ASR 1000 Series Router	5-120
Chassis-Lifting Guidelines	5-121
Tools and Equipment	5-121
Unpacking and Verifying Shipping Contents	5-122
Checking the Shipping Container Contents	5-122
Cisco ASR 1000 Series Router Installation Checklist	5-123

## CHAPTER 6

<b>Cisco ASR 1006 Router Overview and Installation</b>	<b>6-125</b>
Cisco ASR 1006 Router Description	6-125
Front View	6-126
Rear View	6-127
Cisco ASR 1006 Router Slot Numbering	6-129
Installation Methods	6-130

General Rack Installation Guidelines	6-130
Guidelines for an Equipment Shelf or Tabletop Installation	6-131
Equipment Shelf or Tabletop Installation	6-132
Rack-Mounting the Cisco ASR 1006 Router	6-134
Verifying Rack Dimensions	6-134
Attaching the Chassis Rack-Mount Brackets	6-135
Chassis Front Rack-Mount Brackets	6-135
Chassis Rear Rack-Mount Brackets	6-136
Installing the Cisco ASR 1006 Router in a Rack	6-138
Two-Post Rack Installation	6-139
Four-Post Rack Installation	6-140
Attaching the Cable-Management Brackets	6-142
Attaching a Chassis Ground Connection	6-143
Recommended Tools and Supplies	6-144
Connecting the Shared Port Adapter Cables	6-145
Connecting the Console and Auxiliary Port Cables	6-146
Connecting the Ethernet Management Port Cable	6-146
Connecting Power to the Cisco ASR 1006 Router	6-147
Power Cords Supported by the Cisco ASR 1006 Router	6-147
Connecting AC Input Power to Cisco ASR 1006 Router	6-148
Connecting DC Input Power to Cisco ASR 1006 Router	6-151
Connecting a Terminal to the Cisco ASR 1000 Series RP Console Port	6-157
Connecting the System Cables	6-159
Auxiliary Connection	6-160

## CHAPTER 7

<b>Cisco ASR 1004 Router Overview and Installation</b>	<b>7-161</b>
Cisco ASR 1004 Router Description	7-162
Front View	7-162
Rear View	7-163
Cisco ASR 1004 Router Slot Numbering	7-165
Installation Methods	7-165
General Rack Installation Guidelines	7-166
Guidelines for an Equipment Shelf or Tabletop Installation	7-167
Equipment Shelf or Tabletop Installation	7-168
Rack-Mounting the Cisco ASR 1004 Router	7-169
Verifying Rack Dimensions	7-170
Attaching the Chassis Rack-Mount Brackets	7-170

Chassis Front Rack-Mount Brackets	7-171
Chassis Rear Rack-Mount Brackets	7-171
Installing the Cisco ASR 1004 Router in a Rack	7-173
Two-Post Rack Installation	7-174
Four-Post Rack Installation	7-175
Attaching a Chassis Ground Connection	7-177
Recommended Tools and Supplies	7-178
Attaching the Cable-Management Bracket	7-179
Connecting the Shared Port Adapter Cables	7-181
Connecting the Console and Auxiliary Port Cables	7-181
Connecting the Ethernet Management Port Cable	7-182
Connecting Power to Cisco ASR 1004 Router	7-182
Power Cords Supported by the Cisco ASR 1004 Router	7-184
Connecting AC Input Power to Cisco ASR 1004 Router	7-184
Connecting –48 VDC Input Power to Cisco ASR 1004 Router	7-185
Connecting a Terminal to the Cisco ASR Series 1000 Route Processor Console Port	7-190
Connecting the Network Management and Signal System Cables	7-191
Auxiliary Connection	7-192

---

**CHAPTER 8**
**Cisco ASR 1002 Router Overview and Installation 8-193**

Cisco ASR 1002 Router Description	8-193
Front View	8-194
Rear View	8-195
Cisco ASR 1002 Router Slot Numbering	8-196
Cisco ASR 1002 Router Components	8-197
Cisco Embedded ASR1000-RP1 for Cisco ASR 1002 Router Description	8-197
Cisco Embedded ASR1000-SIP10 and SPAs for Cisco ASR 1002 Router Description	8-197
Cisco ASR1000-ESP5 and ASR1000-ESP10 Description	8-198
Power Supplies in the Cisco ASR 1002 Router	8-199
AC Power Supply for Cisco ASR 1002 Router	8-199
–48 VDC Power Supply for Cisco ASR 1002 Router	8-200
+24 VDC Power Supply for Cisco ASR 1002 Router	8-202
+24 VDC Power System Input for Cisco ASR 1002 Router	8-204
+24 VDC Power System Output for Cisco ASR 1002 Router	8-205
Power Cords Supported by the Cisco ASR 1002 Router	8-206
Installation Methods	8-206
General Rack Installation Guidelines	8-207
Guidelines for an Equipment Shelf or Tabletop Installation	8-208

Equipment Shelf or Tabletop Installation	8-209
Rack-Mounting the Cisco ASR 1002 Router	8-210
Verifying Rack Dimensions	8-211
Attaching the Chassis Rack-Mount Brackets	8-211
Chassis Front Rack-Mount Brackets	8-212
Chassis Rear Rack-Mount Brackets	8-213
Installing the Cisco ASR 1002 Router in a Rack	8-214
Two-Post Rack Installation	8-215
Four-Post Rack Installation	8-216
Attaching the Cable-Management Bracket	8-218
Attaching a Chassis Ground Connection	8-219
Connecting the Shared Port Adapter Cables	8-222
Connecting the Console and Auxiliary Port Cables	8-222
Management Ethernet Port Cable Connection	8-223
Cisco ASR 1002 Router Power Supplies	8-224
Connecting AC Input Power to Cisco ASR 1002 Router	8-225
Connecting –48 VDC Input Power to Cisco ASR 1002 Router	8-227
Connecting Cisco +24 VDC Power Supply	8-230
Connecting a Terminal to the Cisco ASR1000-RP1 Console Port	8-237
Connecting Cables	8-239
Auxiliary Connection	8-239

## CHAPTER 9

<b>Cisco ASR 1002-F Router Overview and Installation</b>	<b>9-241</b>
Cisco ASR 1002-F Router Description	9-242
Front View	9-242
Rear View	9-243
Cisco ASR 1002-F Router Slot Numbering	9-244
Cisco ASR 1002-F Router Components	9-245
Cisco Integrated RP and Cisco ASR 1002-ESP-F Description	9-245
Cisco Integrated ASR 1002-SIP10-F and SPA for Cisco ASR 1002-F Router Description	9-248
Power Supplies in the Cisco ASR 1002-F Router	9-249
AC Power Supply for the Cisco ASR 1002-F Router	9-249
DC Power Supply for the Cisco ASR 1002-F Router	9-249
Power Cords Supported by the Cisco ASR 1002-F Router	9-251
Installation Methods	9-251
General Rack Installation Guidelines	9-252
Guidelines for an Equipment Shelf or Tabletop Installation	9-253
Equipment Shelf or Tabletop Installation	9-253

Rack-Mounting the Cisco ASR 1002-F Router	9-255
Verifying Rack Dimensions	9-256
Attaching the Chassis Rack-Mount Brackets	9-256
Chassis Front Rack-Mount Brackets	9-256
Chassis Rear Rack-Mount Brackets	9-257
Installing the Cisco ASR 1002-F Router in a Rack	9-258
Two-Post Rack Installation	9-260
Four-Post Rack Installation	9-261
Attaching the Cable-Management Bracket	9-262
Attaching a Chassis Ground Connection	9-263
Connecting the Shared Port Adapter Cables	9-266
Connecting the Console and Auxiliary Port Cables	9-266
Connecting a Cable to the Management Ethernet Port	9-267
Connecting Power to the Cisco ASR 1002-F Router	9-268
Connecting AC Input Power to the Cisco ASR 1002-F Router	9-270
Connecting DC Input Power to the Cisco ASR 1002-F Router	9-273
Connecting a Terminal to the Cisco Integrated RP Console Port and Auxiliary Port	9-275
Connecting Cables	9-276
Auxiliary Connection	9-277

## CHAPTER 10

<b>Cisco ASR 1013 Router Overview and Installation</b>	<b>10-279</b>
Cisco ASR 1013 Router Description	10-279
Front View	10-281
Rear View	10-283
Cisco ASR 1013 Router Power Zones	10-285
Cisco ASR 1013 Router Slot Numbering	10-286
Installation Methods	10-286
General Rack Installation Guidelines	10-286
Guidelines for Equipment Rack Installation	10-288
Attaching the Rear Rack-Mount Brackets	10-289
Rack-Mounting the Cisco ASR 1013 Router	10-291
Verifying Rack Dimensions	10-291
Installing the Cisco ASR 1013 Router in a Rack	10-292
Installing the Chassis Using the Forward Rack-Mount Brackets	10-292
Two-Post Rack Installation	10-296
Four-Post Rack Installation	10-297
Attaching the Cable-Management Bracket	10-299



Attaching a Chassis Ground Connection	10-302
Recommended Tools and Supplies	10-302
Connecting the Shared Port Adapter Cables	10-303
Connecting the Console and Auxiliary Port Cables	10-304
Connecting the Ethernet Management Port	10-305
Connecting Power to the Cisco ASR 1013 Router	10-305
Cisco ASR 1013 Router Power Supply Overview	10-306
Power Cords Supported by the Cisco ASR 1013 Router	10-306
Connecting AC Input Power to Cisco ASR 1013 Router	10-307
Connecting DC Input Power to Cisco ASR 1013 Router	10-309
Connecting a Terminal to the Cisco ASR 1000 Series RP Console Port	10-313
Connecting the System Cables	10-314
Auxiliary Connection	10-314

---

**CHAPTER 11**

<b>Cisco ASR 1001 Router Overview and Installation</b>	<b>11-317</b>
Cisco ASR 1001 Router Description	11-317
Cisco ASR 1001 Router Architecture	11-318
Cisco ASR 1001 Router Faceplate Common Components	11-325
Cisco ASR 1001 Chassis Front View	11-326
Cisco ASR 1001 Chassis Rear View	11-326
Cisco ASR 1001 Router Slot Numbering	11-327
Cisco ASR 1001 Router Components	11-327
Cisco Embedded ASR1000-RP1 for Cisco ASR 1001 Router Description	11-328
Cisco Embedded ASR1000-SIP10 and SPAs for the Cisco ASR 1001 Router Description	11-329
Cisco ASR 1001 Router Integrated Daughter Card Description	11-329
Cisco ASR1000-ESP for the Cisco ASR 1001 Router Description	11-329
Power Supplies in the Cisco ASR 1001 Router	11-330
AC Power Supply for Cisco ASR 1001 Router	11-331
–48 VDC Power Supply for Cisco ASR 1001 Router	11-331
Power Cords Supported by the Cisco ASR 1001 Router	11-332
Installation Methods	11-332
General Rack Installation Guidelines	11-333
Guidelines for an Equipment Shelf or Tabletop Installation	11-334
Mounting the Cisco ASR 1001 Router on an Equipment Shelf or Tabletop Installation	11-334
Rack-Mounting the Cisco ASR 1001 Router	11-336
Verifying Rack Dimensions	11-336
Attaching the Chassis Rack-Mount Brackets	11-337
Chassis Front Rack-Mount Brackets	11-337

Installing the Cisco ASR 1001 Router in a Rack	11-338
Two-Post Rack Installation	11-340
Four-Post Rack Installation	11-341
Attaching the Cable-Management Bracket	11-342
Attaching a Chassis Ground Connection	11-343
Recommended Tools and Supplies	11-344
Connecting the Shared Port Adapter Cables	11-346
Connecting the Console and Auxiliary Port Cables	11-346
Management Ethernet Port Cable Connection	11-346
Connecting a Terminal to the Cisco ASR1000-RP1 Console Port	11-347
Connecting Cables	11-347
Auxiliary Connection	11-348
Overview of AC and DC Power Supplies for the Cisco ASR 1001 Router	11-348
Cisco ASR 1001 Router Power Supply Installation	11-348
Installing AC Input Power to Cisco ASR 1001 Router	11-350
Removing AC Power Supply from the Cisco ASR 1001 Router	11-352
Installing DC Input Power on the Cisco ASR 1001 Router	11-354
Wiring the DC Input Power Source	11-355
Removing DC Input Power from the Cisco ASR 1001 Router	11-359

## CHAPTER 12

### Cisco ASR 1000 Series Routers Power Up and Initial Configuration 12-361

Checking Conditions Prior to System Startup	12-361
Verifying Power Supply Operation	12-362
Powering Up the Cisco ASR 1000 Series Routers	12-363
Verifying the Front Panel LEDs	12-367
Verifying the Hardware Configuration	12-367
Checking Hardware and Software Compatibility	12-367
Configuring the Cisco ASR 1000 Series Routers at Startup	12-367
Using the Console Interface	12-368
Configuring Global Parameters	12-368
Checking the Running Configuration Settings	12-369
Saving the Running Configuration to NVRAM	12-369
Powering Off the Cisco ASR 1000 Series Router Safely	12-370

## CHAPTER 13

### Removing and Replacing FRUs from the Cisco ASR 1000 Series Routers 13-373

Removing and Replacing Cisco ASR 1000 Series Route Processors	13-373
Removing the Cisco ASR 1000 Series Route Processor from the Cisco ASR 1006, Cisco ASR 1004, and Cisco ASR 1013 Routers	13-374

Replacing the Cisco ASR 1000 Series Route Processor in the Cisco ASR 1006, Cisco ASR 1004, and Cisco ASR 1013 Routers	13-375
Removing and Replacing Cisco ASR 1000 Series Route Processor Internal Hard Drive	13-375
Cisco ASR1000-RP1 Spare Hard Drive Accessory Kit	13-376
Removing and Replacing the Cisco ASR1000-RP1 Module Internal Hard Drive	13-376
Removing the Cisco ASR1000-RP1 Internal Hard Drive	13-376
Replacing the Cisco ASR1000-RP1 Internal Hard Drive	13-380
Removing and Replacing the Cisco ASR1000-RP2 Module Internal Hard Drive	13-381
Removing the Cisco ASR1000-RP2 Internal Hard Drive	13-381
Replacing the Cisco ASR1000-RP2 Internal Hard Drive	13-383
Removing and Replacing the Hard Drive on the Cisco ASR 1002-X Router	13-383
Removing the Hard Drive from the Cisco ASR 1002-X Router	13-384
Replacing the Hard Drive on the Cisco ASR 1002-X Router	13-386
Removing and Replacing the Hard Drive on the Cisco ASR 1001 Router	13-386
Removing the Hard Drive from the Cisco ASR 1001 Router	13-387
Replacing the Hard Drive on the Cisco ASR 1001 Router	13-389
Removing and Replacing the Cisco ASR 1000 Series DIMM Memory Modules	13-389
Removing and Replacing the DIMM Memory Modules on the Cisco ASR 1006 Router and the Cisco ASR 1013 Router	13-390
Removing and Replacing the Cisco ASR1000-RP1 DIMM Memory Modules	13-391
Removing and Replacing the Cisco ASR1000-RP2 DIMM Memory Modules	13-396
Removing the Cisco ASR1000-RP2 DIMMs	13-397
Replacing the Cisco ASR1000-RP2 DIMMs	13-398
Removing and Replacing the Cisco ASR 1001 Router DIMM Memory Modules	13-400
Removing the Cisco ASR 1001 Router DIMMs	13-402
Replacing the Cisco ASR 1001 Router DIMM	13-404
Removing and Replacing the Cisco ASR 1002-X Router DIMM Memory Modules	13-406
Removing the Cisco ASR1002-X Router DIMMs	13-407
Replacing the Cisco ASR1002-X Router DIMMs	13-408
Removing and Replacing Cisco ASR 1000 Router eUSB Devices	13-410
Remove and Replace the eUSB Device on the Cisco ASR 1006 and Cisco ASR 1004 Routers	13-410
Remove and Replace the eUSB Device on the Cisco ASR 1001 Router	13-414
Removing and Replacing Cisco ASR 1000 Series Router 1 GB USB Flash Token Memory Stick	13-417
Minimum Requirements of eUSB Devices Supported on Cisco ASR 1000 Series Routers	13-418
Removing and Replacing Cisco ASR 1000 Series Embedded Service Processors	13-420
Important Notes about Cisco ASR1000-ESP Upgrades	13-420
Removing a Cisco ASR1000-ESP	13-421
Replacing the Cisco ASR1000-ESP	13-421
Removing and Replacing Cisco ASR 1000 Series Router SPAs and SPA Interface Processors	13-423

Electrostatic Discharge Prevention	13-423
Removing the Cisco ASR 1000 SPA Interface Processor	13-425
Replacing the Cisco ASR 1000 SPA Interface Processor	13-425
Removing a Shared Port Adapter from a SIP	13-426
Replacing a Shared Port Adapter in a SIP	13-426
Removing and Replacing the Cisco ASR 1006 Router Power Supplies	13-427
Removing and Replacing a AC Power Supply in Cisco ASR 1006 Router	13-427
Removing the AC Power Supply from Cisco ASR 1006 Router	13-427
Replacing the AC Power Supply in Cisco ASR 1006 Router	13-428
Removing and Replacing a DC Power Supply in Cisco ASR 1006 Router	13-430
Removing the DC Power Supply from Cisco ASR 1006 Router	13-432
Replacing the DC Power Supply in Cisco ASR 1006 Router	13-437
Removing and Replacing the Cisco ASR 1004 Router Power Supplies	13-440
Removing and Replacing an AC Power Supply in Cisco ASR 1004 Router	13-441
Removing the AC Power Supply from Cisco ASR 1004 Router	13-441
Replacing the AC Power Supply in Cisco ASR 1004 Router	13-442
Removing and Replacing a DC Power Supply in Cisco ASR 1004 Router	13-442
Removing the DC Power Supply from the Cisco ASR 1004 Router	13-444
Replacing the DC Power Supply in Cisco ASR 1004 Router	13-446
Removing and Replacing the Cisco ASR 1002 Router Power Supplies	13-447
Removing and Replacing an AC Power Supply in Cisco ASR 1002 Router	13-448
Removing the AC Power Supply from Cisco ASR 1002 Router	13-448
Replacing the AC Power Supply in Cisco ASR 1002 Router	13-449
Removing and Replacing a –48 VDC Power Supply in Cisco ASR 1002 Router	13-451
Removing the –48 VDC Power Supply from Cisco ASR 1002 Router	13-452
Replacing the –48 VDC Power Supply in Cisco ASR 1002 Router	13-454
Removing and Replacing a +24 VDC Power Supply in Cisco ASR 1002 Router	13-456
Removing the +24 VDC Power Supply from Cisco ASR 1002 Router	13-457
Replacing the +24 VDC Power Supply in Cisco ASR 1002 Router	13-458
Removing and Replacing the Cisco ASR 1013 Router Power Supplies	13-465
Removing and Replacing an AC Power Supply in Cisco ASR 1013 Router	13-465
Removing the AC Power Supply from Cisco ASR 1013 Router	13-465
Replacing the AC Power Supply in Cisco ASR 1013 Router	13-467
Removing and Replacing a DC Power Supply in Cisco ASR 1013 Router	13-467
Removing the DC Power Supply from Cisco ASR 1013 Router	13-468
Replacing the DC Power Supply in Cisco ASR 1013 Router	13-471
Removing and Replacing the Cisco ASR 1001 Router Power Supplies	13-473
Installing the AC Power Supply into Cisco ASR 1001 Router	13-475
Removing AC Power Supply from the Cisco ASR 1001 Router	13-477

Installing DC Power Supply into Cisco ASR 1001 Router	13-479
Wiring the DC Input Power Source	13-480
Removing DC Input Power from the Cisco ASR 1001 Router	13-485
Repacking the Router	13-486

## APPENDIX A

### Cisco ASR 1000 Series Router Specifications A-487

Cisco ASR 1006 Router Specifications	A-487
Cisco ASR 1006 Router Memory and Storage Options	A-488
Cisco ASR 1006 Router Ethernet RJ-45 Port Pinouts	A-488
Cisco ASR 1006 Router MGMT Ethernet Port Pinouts	A-489
Cisco ASR 1006 Router BITS Port Signals and Pinouts	A-489
Cisco ASR 1006 Router Console Port Signals and Pinouts	A-490
Cisco ASR 1006 Router Auxiliary Port Signals and Pinouts	A-490
Cisco ASR 1006 Router DB-25 Pinout Assignments for Alarm Relays	A-490
Cisco ASR 1004 Router Specifications	A-491
Cisco ASR 1004 Router Memory and Storage Options	A-492
Cisco ASR 1004 Router Ethernet RJ-45 Port Pinouts	A-492
Cisco ASR 1004 Router MGMT Ethernet Port Signals and Pinouts	A-492
Cisco ASR 1004 Router Console Port Signals and Pinouts	A-493
Cisco ASR 1004 Router Auxiliary Port Signals and Pinouts	A-493
Cisco ASR 1004 Router BITS Port Signals and Pinouts	A-493
Cisco ASR 1004 Router DB-25 Pinout Assignments for Alarm Relays	A-494
Cisco ASR 1002 Router, Cisco ASR 1002-F Router, and Cisco ASR 1002-X Router Specifications	A-494
Cisco ASR 1002 Router Mgmt Ethernet RJ-45 Port Pinouts	A-496
Cisco ASR 1002 Router Console Port Signals and Pinouts	A-496
Cisco ASR 1002 Router Auxiliary Port Signals and Pinouts	A-497
Cisco ASR 1002 Router BITS Port Signals and Pinouts	A-497
Cisco ASR 1002-X Router BITS Port Signals and Pinouts	A-497
Cisco ASR 1002-X Router BNC GPS Ports	A-498
Cisco ASR 1002-X Router Time of Day Port Pinout	A-498
Cisco ASR 1013 Router Specifications	A-500
Cisco ASR 1013 Router Memory and Storage Options	A-501
Cisco ASR 1013 Router Ethernet RJ-45 Port Pinouts	A-501
Cisco ASR 1013 Router MGMT Ethernet Port Signals and Pinouts	A-501
Cisco ASR 1013 Router Console Port Signals and Pinouts	A-502
Cisco ASR 1013 Router Auxiliary Port Signals and Pinouts	A-502
Cisco ASR 1013 Router BITS Port Signals and Pinouts	A-502
Cisco ASR 1013 Router DB-25 Pinout Assignments for Alarm Relays	A-503
Cisco ASR 1001 Router Specifications	A-503

Cisco ASR 1001 Router Memory and Storage Options A-504

## APPENDIX B

### Cisco ASR 1000 Series Router Route Processor and Embedded Services Processor Signals and Pinouts B-505

- Cisco ASR 1000-RP1 Pinout Specifications B-505
  - MGMT Ethernet Port Signals and Pinouts B-505
  - BITS Interface Port Signals and Pinouts B-506
  - Console Port Signals and Pinouts B-506
  - Auxiliary Port Signals and Pinouts B-506
- Cisco ASR1000-RP2 Pinout Specifications B-507
  - MGMT Ethernet Port Pinouts B-507
  - BITS/DTI Interface Port Signals and Pinouts B-507
  - Console Port Signals and Pinouts B-508
  - Auxiliary Port Signals and Pinouts B-508
- Cisco ASR1000-ESP40 Console Port Pinout Specifications B-508
- Cisco ASR1000-ESP100 Console Port Pinout Specifications B-509
- Cisco ASR1000-ESP200 Console Port Pinout Specifications B-509

## APPENDIX C

### Troubleshooting Initial Startup Problems C-511

- Troubleshooting Overview C-511
- Online Troubleshooting Resources C-512
- General Troubleshooting Tips C-512
  - Troubleshooting Using a Subsystem Approach C-513
  - Normal Router Startup Sequence C-513
  - Troubleshooting the Power Subsystem C-514
  - Troubleshooting the Cooling Subsystem C-515
  - Troubleshooting the Shared Port Adapter C-516
- Troubleshooting the Upgrade C-516
- Replacing or Recovering a Lost Password C-519
  - Overview of the Password Recovery Procedure C-519
  - Details of the Password Recovery Procedure C-520
  - Recovering the Password When a Standby RP Is Included in the System C-523

## APPENDIX D

### MIBs for the Cisco ASR 1001 Router D-525