

## FCC Wants You To Know

This equipment complies with Part 68 of the FCC rules. On the bottom of the base of this equipment is a label that contains, among other information, the FCC Registration Number and Ringer Equivalence Number (REN) for this equipment.

You must, upon request, provide this information to your telephone company.

The USOC number of the registration jack for the equipment is RJ11C.

A FCC compliant telephone cord and modular plug is provided with this equipment. This equipment is designed to be connected to the telephone network or premises wiring using a compatible modular jack which is Part 68 compliant. See Installation Instructions for details.

The REN is useful to determine the quantity of devices you may connect to your telephone line and still have all of those devices ring when your telephone number is called. In most, but not all areas, the sum of the REN's of all devices connected to one line should not exceed five (5.0). To be certain of the number of devices you may connect to your line, as determined by the REN, you should contact your local telephone company to determine the maximum REN for your calling area.

If your telephone equipment causes harm to the telephone network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advance notice isn't practical, you will be notified as soon as possible. You will be informed of your right to file a complaint with the FCC.

Your telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service. If you experience trouble with this telephone equipment, disconnect from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning.

This equipment may not be used on coin service provided by the telephone company.

Connection to party lines is subject to state tariffs.

This equipment is hearing aid compatible.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Some cordless telephones operate at frequencies that may cause interference to nearby TV's and VCR's. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- \* Reorient or relocate the receiving antenna.
- \* Increase the separation between the equipment and receiver.
- \* Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \* Consult the dealer or an experienced radio TV technician for help.

## Answers to Commonly Asked Questions

**Q. The LED on my handset won't light and I can't get a dial tone. What do I do?**

A. Your phone may have lost its digital security code and needs to be reset. Refer to the "To Reset" procedure on page 25.

**Q. My answering system lights are flashing. What do I do?**

A. Refer to the "LED Indications" section on page 20.

**Q. My answering system won't work. What do I do?**

A. You may have had a power failure and need to reset your machine. Refer to the "To Reset Unit" procedure on page 25 or "To Turn System On" on page 21.

**Q. How do I erase the incoming messages to make room for more?**

A. Your unit automatically saves message unless you erase them. Refer to page 24 "To Erase Your Messages."

**Q. How often do I need to replace the 9 volt battery?**

A. You should replace the 9 volt battery once a year or after a power outage.

**Q. Can my unit be left on for a long period of time?**

A. Yes. Your unit is designed to be on 24 hours a day.

**Q. My AC Adaptor feels warm to the touch. Is this normal?**

A. Yes. It is characteristic of your AC Adaptor to feel slightly warm. There is no need to be alarmed.

**Q. Will my unit operate in a very cold or hot environment?**

A. Your unit is designed to perform most efficiently at room temperature. However, it can be used in environments ranging from 50° F to 120° F.

**Q. How do I know my system is set to answer calls?**

A. When the message display indicator shows a number that is lit solid or flashing, your unit is ready to answer calls. After most modes of operation (such as after recording your outgoing message) the unit will automatically switch to the answer mode. If the display shows "A", the unit is in the announce only mode and will NOT record messages.

**Q. How do I know that messages are saved?**

A. The FF2125 automatically saves message unless you press the "ERASE" button.

**Q. When I try to record a new outgoing greeting, the old greeting plays back. Why?**

A. Pressing and RELEASING the GREETING button will play back the current outgoing greeting.

To record a new outgoing greeting, you must press and HOLD the GREETING button while you record your greeting.

**Q. What is the maximum length of the outgoing greeting I can record on my unit?**

A. Your outgoing greeting recording time is up to 30 seconds.