# Always here to help you


Register your product and get support at www.philips.com/welcome



SCD860







ENGLISH 4
DEUTSCH 30
ESPAÑOL 57
FRANÇAIS 84
ITALIANO 112
NEDERLANDS 139
PORTUGUÊS 166

ann de icemanuals eul

Table of contents	
Introduction	4
Product overview	5
First-time setup	5
Mounting the baby monitor on the wall	5 5 7 9
Quick start guide	
Viewing, hearing and monitoring your baby	12
Viewing your baby	12
Hearing your baby	13
How to get notified that your baby cries	14
Background monitoring	14
Notification options	15
Guest viewers and accounts	16
Inviting guests and a second admin	16
Giving and removing access	17
Account management General app use Video and audio quality optimisation	18
General app use	19
Video and audio quality optimisation	19
WiFi connection to the Internet	20
Using the baby monitor away from home	20
Using the app on several devices	21 21
Resetting the baby monitor	22
Firmware upgrades WiFi status light signals	22
Security and privacy	24
Network security	24
Strong password	24
Safe use of the baby monitor app	24
Device compatibility	24
Orderir & accessories	25
Guarantee and support	25
Fires vently asked questions	25

#### Introduction

Congratulations on your purchase and welcome to Philips Avent! To benefit fully from the support that Philips Avent offers, register your product at

www.philips.com/welcome.

The uGrow Smart Baby Monitor uses new SafeConnect Technology to work across networks. It automatically adjusts to the network conditions to maintain a high-quality constant connection to your baby. It continuously seeks to reconnect if connection drops. Bandwidth usage has been optimised so that it does not drain the battery of your mobile device unnecessarily. It even works when you use your phone for other things. The uGrow Smart Baby Monitor requires Internet connection and WiFi. A good Internet connection and WiFi are essential to get the best performance of your uGrow Smart Baby Monitor. A lower quality Internet connection and WiFi can reduce the quality of the connection between the uGrow app and baby monitor. It is compatible with iOS 7 or higher, or Android 4.1 or higher. It has all the support features you expect of a baby monitor, including Iullabies, multi-colour nightlight, and humidity and temperature monitoring.

### Product overview (Fig. 1)

- 1 WiFi status light
- 2 Infrared lights
- 3 Baby monitor lens
- 4 Microphone
- 5 Viewing indicator
- 6 Nightlight
- 7 Foot
- 8 Nightlight button
- 9 Lullaby play/pause button
- 10 Light sensor
- 11 Temperature and humidity sensor unit
- 12 Appliance plug socket
- 13 Reset button
- 14 On/off button
- 15 Wall mounting bracket
- 16 Adapter
- 17 Appliance plug

### First-time setup


Before you start the set-up procedure, make sure:

- You have wireless Internet access (2.4 GHz WiFi).
- You are close enough to the WiFi router to have a good WiFi signal.
- If you use a WiFi repeater, make sure that your router and your WiFi repeater have the same SSID (the network name) and that you use the same parsword for the router and the repeater.
- You have the password of your WiFi network at hand. Always connect the baby monitor to a secure network (see chapter 'Security and privacy').
- Male, sure that your smart device runs on iOS 7 or higher, or And old 4.1 or higher (for device compatibility, see chapter 'Device compatibility').
- Download the Philips Avent uGrow Smart Baby Monitor app from the App Store or Google Play. Use keywords 'uGrow smart monitor' or 'Philips smart monitor' to find the app.
- 2 Launch the app.





#### 6 **ENGLISH**



#### 3 Follow the on-screen instructions to create a uGrow account.

- 1 Make sure that you use a working email address on which you can always be reached.
- Use a strong password (see 'Security and privacy').
- 3 When you receive the verification email, follow the instructions in this email to continue setting up your uGrow Smart Baby Monitor.

### 4 Create your user profile.

A user profile is needed to identify yourself to invited guest users.

5 Create your baby's profile.

A baby name is needed to identify your baby monitor in the app, especially when multiple baby monitor, are connected to your account.


18.81

4 Follow the on-screen instructions to connect the baby monitor to the mains.

1 Insert the appliance plug into the appliance plug socket in the temperature and humidity sensor unit and insert the adapter into a wall socket.

- The Wifi status light starts to flash orange when the baby monitor is switched on. Wait until the WiFi status stops flashing. When the WiFi status light is solid orange, the baby monitor is ready to read the WiFi QR code.
- 5 Link the baby monitor to your smart device.
- 1 Select the WiFi network you want to use. Please note that the baby monitor only works on a 2.4 GHz WiFi network.
- 2 Enter the WiFi password.






- 3 As instructed by the app, hold the WiFi QR code on the screen of your smartphone or tablet at a distance of around 20 cm in front of the baby monitor lens. Slowly move the smartphone or tablet closer or further away from the lens to ensure the WiFi QR is read properly. When the baby monitor has read the WiFi QR code, it plays a short tune and the WiFi status light starts to flash green.
- 4 Follow the on-screen instructions to complete the setup procedure.
- 5 The WiFi status light turns solid green when the baby monitor is linked to the WiFi network.

Note: If you are unable to complete the setup procedure and your baby monitor is not linked to your smart device after you have completed the steps above, check 'Frequently asked questions' in this user manual for a possible solution.

Tip: For more information on the WiFi status light, see chapter 'WiFi status light signals'.

- 6 Next you get an introductory tour through the app.
- 7 You can then choose between two options: 'Help me mount the baby monitor' and 'Let me see my baby'
- 8 If you choose the first option, you can follow the on-screen instructions to mount the baby monitor on the wall (see chapter 'Mounting the baby monitor on the wall'). At the end of the on-screen instructions you can choose 'Let me see my baby'.

### Mounting the baby monitor on the wall



1 Use a pencil to put a cross on the wall at the place where you want to mount the baby monitor.

Hold the wall mounting bracket to the wall. Make sure that one of the holes is right over the cross that you put on the wall at step 1.



Note: Make sure that the ring of the wall mounting bracket slants downward when you hold it to the wall. If the ring of the wall mounting bracket slants upward, turn the wall mounting bracket the other way around so that it is in the correct position.











3 Use a pencil to mark the other screw hole on the wall.

4 Drill 2 holes in the wall at the marks.

5 Use 2 screws to fasten the wall mounting bracket to the wall. Tighten the screws with a screwdriver.

6 Pass the humidity and temperature sensor unit through the hole in the wall mounting bracket. Then align the slots in the foot of the baby monitor with the projections on the ring. Fit the groove in the foot of the baby monitor onto the raised edge on the inside of the ring.


7 Turn the foot of the baby monitor clockwise to position the baby monitor:




Insert the appliance plug into the appliance plug socket in the temperature and humidity sensor unit and insert the adapter into a wall socket. Now your baby monitor is ready for use.

#### Quick start guide









### Main screen features

Top of screen:

- All notifications on/off
- Malseul Sound level indication ban
- Switch audio on/off

#### Bottom of screen:

- Snap shot
- 5 Talk-back
- Nightlight
- Lullabies

### Quick action buttons


- Snap shot: tap this button to take a photo of your baby.
- When you take a photo of your baby, the photo will be stored in the photo allourn on your smart device.
  - lalk-back: tap this button to talk to your baby directly. Options available:
- Talk back on or off
- Adjust talk-back volume

- Nightlight: tap this button to switch the nightlight on or off. Tap the settings icon in the bottom right-hand corner to adjust the colour of the nightlight or to set the nightlight timer. Options available:
- Nightlight on/off
- Set the nightlight timer or switch the nightlight on continuously

#### 10 ENGLISH









- Set the colour of the nightlight

Lullabies: tap this button to switch lullaby playing on or off. Tap the settings icon in the bottom right-hand corner to select the lullabies, to set a timer and to adjust the volume. Options available:

Select a lullaby from a list of lullabies

ZVICER

- Program a play list from the iuilabies available

- Set the lullaby timer or choose play continuously - Adjust the playback volume.


### **Background monitoring icons**

- Bell icon: tap to switch notifications on or off.











- Mobile phone icon: tap to switch audio on or off.

Note: For more information about background monitoring, see chapter 'Viewing, hearing and monitoring your baby'.

#### Sound level indication bar

- The lights indicate the sound level in your baby's room.

Note: For more information, see chapter Viewing, hearing and monitoring your baby'.

#### Left tray

- List of baby monitors linked to the app: tap the settings icon to set your baby monitor preferences and to invite guest users to view your baby
- My account: tap this opion to view and adjust your account information, your profile and your baby's profile, and to add or remove a baby monitor
- About: tap this cotion for more information about the app, versions, etc.
- Support: tap this option to open the support menu

Note: For more information about the left tray, see chapter 'General app use'.

### Right tray

The right tray gives information on the users connected.

Note:The options in the right tray are only available to you if you are an admin (for more information about the right tray, see chapter 'General app use').

- It shows who is currently watching
- It shows who has access or has no access

The privacy mode button prevents all users from being able to watch your baby

#### **Dashboard**

The app's dashboard is in the bottom tray.

1 Put your finger on the horizontal line on the screen just above the icons at the bottom of the screen. Pull this line towards the top of the screen. The icons at the bottom of the screen also move up.



2 When you have pulled the line up, the dashboard in the bottom tray is fully visible.

On the dashboard you have a number of notification options:

- 1 Sound
- 2 Temperature
- 3 Humidity

Note: For more information about the notification options on the dashboard, see section 'Notification options' in chapter 'Viewing, hearing and monitoring your baby' in this user manual.

### Viewing, hearing and monitoring your baby

You can watch, hear and monitor your baby on your smartphone or tablet. You can also comfort your child by talking to it.

### Viewing your baby



#### Zooming and panning

Note: This feature is only available in portrait viewing mode.

1 When in full screen mode, double tap or pinch outwards to zoom in.




2 Double ten or pinch inwards to zoom out.



3 Drag to pan through a zoomed-in image.






#### Portrait or landscape viewing

 Rotate your smartphone or tablet to view your baby in landscape mode.

### Night vision mode

When the light level in the room is low, the baby monitor switches to night vision mode.

 In this mode, you see black and white images of your baby on your smart device.





 How loud you hear the baby, depends on the set volume level of your smart device.

13.81


- The level of sound produced by the baby is also visible on the sound level indication bar. The number of lights that light up indicates the loudness of the sound in your baby's room. The indication bar works from of to right. The further to the right the lights light up, the louder the sound is.



Note:The audio on/off button must be set to 'on' for you to hear your baby at all.

Tip: Connect your smart device to mains power when you want to use it for overnight monitoring to prevent the battery from running out.

### How to get notified that your baby cries



1 Push notification: you receive a push notification when your baby starts to cry.




Note: If you want to receive a notification while you are performing other activities on your smart device (e.g. texting, phoning, browsing the Internet), make sure that you set the all notifications toggle switch to 'on '.

Tip: Switch on vibration in the 'Settings' of your smartphone if you want your smartphone to vibrate to alert you when your baby cries, for instance when you carry the smartphone in your pocket or because you are in a loud environment.



You can also specify in the dashboard when you want to receive a notification.



2 Receive a notification  $\sqrt{h}$  en the baby has been crying for a preset time.

Note: If you choose 'no notification', you don't receive any notification that your baby is crying (see section 'Notification options' in this chapter.

### Switching netifications on or off on your smart device

Notification are a setting on your smart device (outside the app). You can select if and how you want to receive notifications from the app.


1 Co to the notification centre on your device.

Select notification and click to set it on or off.

### **Background monitoring**

Background monitoring is a feature in the app that ensures that you can hear your baby and/or receive notifications about your baby while you are doing other things on your smart device. Background monitoring is on by default, but you can switch it off.

### Switching background monitoring off or on



Note: Set the all notifications toggle switch to 'on' to receive all notifications about your baby if the app is running in the background, for example when you do something else on your smart device or the device is on standby with its screen off. The all notifications toggle switch has to be set to 'on' if you want to adjust personalised notifications on temperature, sound and humidity in the dashboard.









.......

Set your listening threshold

- Tap the mobile phone icon to switch audio on or off.

Note: If you mute the sound, you will not be able to hear your baby when you switch to another function on your smart device (phoning, texting, etc.).

Note:When you make a mobile call or use a VoIP app (e.g. Skype, Viber or FaceTime) to call someone, you will not hear your baby. As soon as the baby starts to cry, however, you will receive a notification.

### Switching from background monitoring to app main screen

The app remains active in the background, also when the device is on standby. While background monitoring is active, there is a red bar at the top of the screen of your smart device.

1 To switch from background monitoring to the app main screen, tap the red bar at the top of the screen to bring the app to the foreground.

### **Notification options**

The app's notification options are in the dashboard. The dashboard is located in the tray at the bottom of the screen. Pull up the dashboard to see the option menu. The menu contains the following options.

#### Sound

- Set the slider to a sound level above which you wish to be notified

Note: If the s'ider is set to 'quiet', you will hear your baby continuously when you leave the app.


- Set the duration of the sound after which you wish to be notified

### Temperature

Set the temperature range above or below which you want to receive a temperature notification

- Switch temperature notification on or off
- Display current temperature or history






### Humidity

- Set the humidity range above or below which you want to receive a humidity notification
- Switch humidity notification on or off
- Display current humidity or history

#### **Guest viewers and accounts**

#### Inviting guests and a second admin



access, to remove their access and to disconnect them. The admin can also deactivate his or her account and thereby disassociate the guests from the baby monitor.


- 1 In the left tray, tap on the settings icon next to the baby monitor.
- anuals.et 2 Scroll down and tap 'Add new user'.

3 Add a guest's email address and his or her role (admin or guest).

my deli 4 The app sends an email to the person invited and you see a notification pop up that an email has been sent.

- 5 The guest receives an email with an invitation code that is only valid for a limited period. The email also contains a link to the App Store. The guest can click this link to install the app.
- 6 After installing the app, the guest creates an account by following the instructions in the app.















- 7 The guest selects the 'Connect to a shared baby monitor' option during the setup process. This opens the page on which the invitation is validated.
- 8 The guest enters the invitation code, his email address and confirms. The code and the email address are checked.
- The admin receives an email that confirms that the guest has been connected to the baby monitor and that the admin can now grant the guest access.
- 10 When the admin has granted the guest access, the guest can view the baby.
- When one or more people watch the baby, the red viewing indicator lights up red.

Note: Although up to ten people (eight or nine guests and one or two admins) have viewing rights to the same baby monitor, only three people can watch the baby at the same time. If guests try to a cers the baby monitor while three viewers are already watching, they will receive the message 'Too many connections'. Admins can always override the access of the guests if they want to watch the baby.

#### Giving and removing access


Users with admin rights can determine who can watch the baby.

1 To remove access for a guest viewer, go to the right tray, tap the guest whose access you want to remove and tap the eye icon next to the guest name.

Tip: If there are already three people watching your baby and you want to give someone, e.g. the babysitter, access to the baby monitor, you can remove access for one of the current viewers and give someone else access instead.

- o give a guest viewer access, go to the right tray, tap the guest you want to give access and tap the eye icon next to the guest's icon.
- If you want to remove access for all viewers simultaneously, tap the privacy mode button. This will deny everyone except yourself access to the baby monitor until you tap the privacy mode button again.





Tip:You can use the privacy mode button to have a moment of privacy with your baby, e.g. to breastfeed or bathe the baby or to change its nappy.

The guests who try to access the baby monitor receive an on-screen notification.

### **Account management**

#### Disconnecting a guest


To disconnect guest users from the app permanently, you have to remove them from the list of guests. A guest may also disconnect himself permanently from the app.


#### Deactivating your user account

If there is only one admin and this admin deactivates his or her account, all the accounts of guest users are disassociated from the baby monitor, although the accounts continue to exist. If there are two admins, both admins have to deactivate their accounts to disassociate all accounts. If only one of the two admins deactivates his or her account, the guests remain connected to the baby monitor:

If you want to transfer the baby monitor to someone else, if you lose the baby monitor or if the baby monitor is stolen, we advise you to deactivate the admin account or accounts. This is essential to protect you and your baby's privacy.

- To deactivate your account, go to the left tray and tap on 'My account'.
- 2 Tap on 'Deactivate account'









4 When you tap on 'Deactivate', a pop-up window confirms that your account has been deactivated.

#### Adding or removing baby monitors

You can add up to ten baby monitors in the app. This allows you to monitor more children or the same child in more rooms. You may, for instance, want to install a monitor over the baby's cot in the baby room and over its playpen in the living room. You have to connect the baby monitors to the app one by one.



- 1 Go to 'My account' in the left tray.
- 2 You will see the list of baby monitors connected. Tap on 'Add baby monitor'.
- 3 Follow the instructions in chapter 'First-time setup' in this user manual to connect the baby monitor to the app.

### General app use

### Video and audio quality optimisation



The quality of the video and audio on your smart device may change over time, depending on the available bandwidth of your connection to Internet. Using a WiFi connection typically gives the best results, while 4G and 3G may offer less bandwidth and deliver reduced quality. The app will automatically offer you the best possible experience, by matching the video and audio quality to the bandwidth available.

Matching takes place in steps:

- 1 Large bandwidth: good video and audio quality, with text notifications.
- 2 Reduced band vicitin (such as when using 3G): reduced video quality; good audio (ua)ny, with text notifications.



3 Small bandwidth (such as when using 2G): only an audio link will be available, with text notifications



4 Very small bandwidth: only text notifications are available



#### WiFi connection to the Internet

You get the best results if you connect your smart device to the Internet via WiFi. It will then automatically use the WiFi network to link to your baby monitor. When there is no WiFi connection to the Internet, your smart device switches to its 3G or 4G mobile data connection. Use of this data connection may involve extra charges from your provider, depending on your subscription. A video connection typically requires 0.1 to 0.25 MB of data per second. An audio connection requires 0.01 MB of data per second. If you want to prevent your smart device from connecting to the 3G or 4G network, you have to switch off the mobile data connection of your device. This will affect all other apps that may use the 3G or 4G mobile data connection, you will not be alerted that your baby is crying when you lose the WiFi connection to the Internet.

#### Using the baby monitor away from home


You can use the monitor at any place where a 2.4 GHz WiFi network is available, whether it as a friend's or relative. Home or at a hotel or holiday residence. If you have the WiFi network name and the WiFi password, you can set up and use your baby monitor away from home. Follow the setup instructions below to do so. Once you have set up connection with a WiFi network, the settings are stored in the memory of your device and you need not repeat the setup procedure as long as you use your app and baby monitor at the same blace.

Note: If the WiFi net work connection requires an extra confirmation, e.g. to agree to the terms of use, the baby monitor will not be able to connect to the WiFi network. This may happen on hotel WiFi networks and other public WiFi networks.

There are two options to connect the baby monitor to the WiFinetwork.

The first option: When you switch on the baby monitor, you get the message 'Baby monitor not found'. Wait until the app offers the option 'Reconnect the baby monitor'.

 The second option: Switch on the baby monitor. Open the left tray, select the baby monitor and choose 'Reconnect the baby monitor'.





When the app has generated a WiFi QR code, hold the screen of your smartphone or tablet at a distance of around 20 cm in front of the baby monitor lens. Slowly move the smartphone or tablet closer or further away from the lens to ensure the WiFi QR is read properly.



3 Follow the rest of the on-screen instructions to complete setup. The setup procedure is completed and the baby monitor is connected to the WiFi network and ready for use, when the WiFi status light on the front of the baby monitor turns solid green.

Note: When you return home, you have to follow the procedure above to reconnect the baby monitor to your home WiFi network.

#### Using the app on several devices

You can use the uGrow Smart Baby Monitor app on more than one device (e.g. on your iPhone and your iPad).

Note: When you log in with the same account on a device while the app is active on another device, the device on which the app was active first will automatically log you out. You cannot use the epp under the same account on two different devices simultaneously.

### Resetting the baby monitor

The baby monitor has a reset button on the back. When you press this button the baby monitor is reset to its factory default settings. This means that you disassociate all accounts from the baby monitor.

Note: Always reset the haby monitor by pressing the reset button before you transfer the baby monitor to someone else. This is necessary to protect your privacy. Also reset the baby monitor when you buy or receive it second-hand.

### How to reserve factory default settings

Note: Make sure the baby monitor is switched on before you reset it.

- 1 While the baby monitor is on, press the reset button on the back if the baby monitor with a paperclip or another pointed object. It is recommended to do this when the baby monitor is connected to your WiFi network.
- 2 Keep the reset button pressed until the baby monitor beeps, then you can release the button. When you release the button, the baby monitor plays a short tune to confirm the reset.

### What to do after a reset to factory default settings

After the baby monitor has been reset, the WiFi status light flashes orange when you switch on the baby monitor to indicate that it is rebooting after a reset. When the WiFi status light stops flashing, you can connect the baby monitor to your WiFi network again. Follow the instructions in chapter 'First-time setup' in this user manual. If you invited other people to access the baby monitor, you need to invite them again.




#### Firmware upgrades

Upgrading is essential to safeguard your privacy and the proper functioning of the baby monitor and the app.

- Essential upgrades are mandatory. Mandatory app upgrades are installed on your smart device automatically and do not require confirmation. You will only receive a notification that a forced mandatory upgrade is taking place.
- From time to time, you receive notifications that upgrades are available for your baby monitor's firmware or for the app software.
   The upgrades are installed when you confirm them.
- To look for firmware upgrades for your baby monitor, open the left tray and tap the settings icon next to the baby monitor. Scroll down to 'Firmware' and tap on it to check for firmware upgrades. If an upgrade is available, tap on it to install.

Note: When an upgrade is being installed, you are temporarily unable to view and hear your baby.




### WiFi status light signals


- Of
- 1 Off: The baby monitor is off
- Orange



1 Flashes orange fast: the baby monitor is starting up.





2 Flashes orange slowly: the baby monitor is upgrading its firmware. Do not switch the baby monitor off during the firmware upgrade.




Note: The WiFi status light might switch off shortly during the firmware upgrade.











- Solid orange: the camera of the baby monitor is ready to read the WiFi QR code generated by your smartphone or tablet.
- Green

Flashes green: the WiFl QR code has been read successfully.

Solid green: the baby monitor is connected to the WiFi network. **Red** 

1 Flashes red slowly: you entered the wrong WiFi password.

2 Solid red: the baby monitor fails to connect to the WiFi network.

### Security and privacy **Network security** WiFi hotspots in public places, such as airports and hotels, are convenient, but they are often not secure. We advise you to use the baby monitor only on a WiFi network protected with WPA2 encryption. We advise you not to use the baby monitor on a network that uses WEP encryption. Note: WiFi networks that do not require a password are not secure. Strong passwords Passwords are essential to protect your WiFi network and your account against unauthorised access. The stronger your password, the better protected your WiFi network and your account is. The rules for a strong password are: 1 A strong password has at least 8 characters. 2 A strong password does not contain your name, your baby's name, another real name or a brand name. A strong password does not contain a complete word. 4 A strong password is very different from passwords that you have used before. 5 A strong password contains characters from at least two of the following categories: Letters: A, B, C or a, b, c Numbers: 0, 1, 2, 3, 4, 5, 6, 7, 8, 9 Symbols: \_\_\_ (2)

## Safe use of the baby monitor app

### Only use the app on a secure network

Don't use the app on an unsecured WiFi network. We advise you to use the bib, monitor only on a WiFi network protected with WPA2 encryption. Ou can also use your phone's data network (often referred to as 3G or 4G).

### Always use the latest software and firmware

Always upgrade the app software and the baby monitor firmware when you receive a notification that an upgrade is available. Upgrades are made available when there are software improvements or to prevent a security issue. If you fail to upgrade, your connection to the baby monitor via the app may no longer be safe and private.

### Device compatibility

- In iPhone compatibility
- iPhone 4S and newer
- iPad compatibility
- iPad 2 and newer
- ▶ iPod Touch compatibility
  - iPod Touch 5th gen and newer
- Android compatibility
- Android 4.1 or higher

Note: For the latest information on device compatibility, please visit **www.philips.com/ugrow**.

### **Ordering accessories**

To buy accessories or spare parts, visit **www.shop.philips.com/service** or go to your Philips dealer. You can also contact the Philips Consumer Care Centre in your country (see the worldwide guarantee leaflet for contact details).

### **Guarantee and support**

If you need information or support, please visit the Philips website at **www.philips.com/support** or read the separate worldwide guarantee leaflet.

### Frequently asked questions

For more frequently asked questions about this baby monitor, see the support page of this product on **www.philips.com/support**.

#### Question Answer **Troubleshooting** You can download the app from the App Store or Google Play, by Why can't I find the searching for uGrow Smart Baby Monitor. If you do not see the app in the app in the App Store or Google Play? App Store or Google Play, your phone may not have the required iOS or Android version. This app is only compatible with iOS 7 or higher, or Android 4.1 or higher. I cannot download and Please check if any of the following factors prevent a smooth download. Is your WiFi signal stable and strong enough? Does your smart device run on install the app. What can iOS 7 or higher or Android 4.1 and higher? Do you have enough space left I do? on your smar device to save the app? Did you enter the correct password for the App Store or Google Play? I cannot setup the baby If the Viii status light is solid orange and flashed red while trying to connect, monitor. Each time I end the WiFi password entered is wrong. Restart the set up process. Re-enter the up in the connection Vir password and make sure that the password is correct. error screen. What is the matter?

If the WiFi status light is solid orange and was solid red while trying to connect, the baby monitor fails to connect to the WiFi network. First check if your phone or tablet uses the same WiFi network you want to connect the baby monitor to. Then check if you have Internet access to 2.4GHz WiFi. If this does not solve the problem, make sure the router SSID (the network name) does not contain special symbols. If it does, change the name of your router SSID accordingly.

I have problems making my baby monitor read the QR code on my smart device. What can I do? Make sure that you hold the WiFi QR code at approx. 20 cm/8 inch distance from the lens. Try moving the smart device slightly up or down or left or right to ensure the WiFi QR code is directly in front of the baby monitor. You can also try moving the smart device closer to or further away from the baby monitor lens to allow proper focussing. Make sure that there is enough light in the room, but avoid too bright light. When the baby monitor has read the WiFi QR code, you hear a confirmation sound and the WiFi status light flashes green.

### **ENGLISH**

Question	Answer
	Perhaps you did not remove the protective foil from the baby monitor lens. Remove the foil.
	Perhaps part of your hand covers the WiFi QR code. Hold your device in such a way that your hand does not cover the WiFi QR code.
	If the WiFi status light is solid orange, the baby monitor did not read the QR code successfully. Go back using the arrow in the top left-hand corner of the screen and follow the QR code instructions.
	If the WiFi status light flashes orange, the camera is still booting. Wait until the light is solid orange. Then go back using the arrow in the top left-hand corner of the screen and follow the QR code instructions.
I cannot see my baby. What is wrong?	Check if the WiFi signal is strong enough in the room where the baby monitor is placed.
	Check if the baby monitor is connected to a live power socket and switched on.
	The WiFi status light on the front of the baby monitor must be solid green (see chapter 'WiFi status light signals').
	If you use more than one baby monitor, check that the correct one is selected. Go to the left tray and tap the baby monitor to see if it is active.
	Perhaps there are already usree people watching the baby. The app only allows three people to watch simultaneously. If you have administrator rights, you can remove access for one of the guests to be able to watch yourself.
Why does the app not notify me that the baby is crying?	Check if the baby monitor is connected to the WiFi network. The WiFi status light on the front of the baby monitor must be solid green.
	The hap, monitor may be offline. To receive a notification that the baby monitor goes offline, go to the left tray and switch on this notification under 'Setungs'.
	The sound threshold for notification may have been set too high. In that case, the app will only notify you when the baby produces a lot of sound. Open the dashboard to lower the sound threshold to ensure that you will be notified sooner when the baby starts crying.
	You may have set the duration of the crying too long. Choose a shorter time so that the app notifies you sooner.
	The volume of your phone may be off. Set the volume of your phone to normal.
	Perhaps talk-back is active. Tap the talk-back icon to switch off talk-back. During talk-back you don't hear any sounds from the baby.
	Check if you have not received an email to notify that your account has been removed. If you have viewing rights as a guest, the administrator may also deny you access temporarily. Contact the administrator and ask him or her do enable you or to reinvite you as a guest.

Question	Answer
I lose connection frequently. What is the matter?	Check if the WiFi signal in the room where the baby monitor is placed is strong enough and stable. If this is not the case, you need a WiFi repeater to get a strong and stable signal. If you use a WiFi repeater, make sure that your router and your WiFi repeater have the same SSID and that you use the same password for the router and the repeater.
	If the WiFi status light on the front of the baby monitor is solid green and you keep losing connection, there may be a problem with the Internet connection of your smart device. Check the WiFi signal on your smart device or the 3G or 4G speed by trying to watch a movie, e.g. one on YouTube.
After I changed my router, I cannot see my baby anymore. What is wrong?	First make sure that your smart device has a good WiFi signal from the new router. There are two options to connect the baby monitor to the WiFi network. The first option is to switch on the baby monitor. The app will give the message 'Baby monitor not found'. Go to 'Troubleshooting' and select 'Reconnect baby monitor'. The second option is to open the left tray when the app gives the message 'Baby monitor' not found'. Select the baby monitor in the left tray and select 'Reconnect baby monitor'. When the app has generated a WiFi QR code, hold the screen of your smart device at a distance of 20cm in front of the bab' monitor's lens. Next, follow the on-screen instructions to complete selup. The setup procedure has been completed successfully when the WiFi status light on the front of the baby monitor turns solid green.
I have been invited as a guest, but why don't I see anything when I open the app?	Check if you have not received an email to notify that your account has been removed. If you have viewing rights as a guest, the administrator may also deny you access temporarily. Contact the administrator and ask him or her do enable you cano reinvite you as a guest.
	Check if your smart device is connected to the Internet.
	The baby monitor may be offline. To receive a notification that the baby monitor goes offline, go to the left tray and switch on this notification under 'Settings'.
•	The sound threshold for notification may have been set too high. In that case, the app will only notify you when the baby produces a lot of sound. Open the dashboard to lower the sound threshold to ensure that you will be notified sooner when the baby starts crying.
	You may have set the duration of the crying too long. Choose a shorter time so that the app notifies you sooner.
	The volume of your phone may be off. Set the volume of your phone to normal.

Question	Answer
Tips and tricks	
Do I have to keep the app on screen to monitor my baby?	No, the app can monitor in the background while you do other things on your smartphone or tablet. Tap the mobile phone icon. Now you hear your baby and also hear when it starts to cry. When the all notifications toggle switch is set to on, you will also receive an on-screen notification that the baby is crying, while the app runs in the background.
Why do I get black and white images instead of colour ones?	The baby monitor has switched to night vision mode. The room where the baby monitor is placed is dark.
	If there is enough light in the room, the light sensor on top of the baby monitor may be covered or dirty. Make sure that this sensor is fully exposed to the light in the room.
If my device is locked or I am using another app or making a phone call, can I still hear my baby?	Yes, you can choose to continue monitoring your body in the background. Please note that if you use your phone to male a call, you will only hear a ringtone when the baby starts crying. You will not hear your baby. Tap the mobile phone symbol to switch on background audio. When background audio is on, you hear your baby while you are engaged in other activities. You can also choose to receive a notification when your baby is crying. Tap the bell symbol on the main screen to switch all notifications on or off. When all notifications is set to on, you will receive a message on your screen when the baby is crying.
Use and learn	
Do I need an extra account if I have more baby monitors?	No, you do not need an extra account if you use more baby monitors. You can add a baby monitor to your uGrow Smart Baby Monitor app. Go to 'My account' in in eleft tray. Here you see a list of the baby monitors connected to the app. Tap on 'Add baby monitor'. Follow the instructions in chapter 'First-time setup' to connect the baby monitor to the app.
Can I use more baby monitors in the same app?	You can connect up to ten baby monitors to the app, but you can only view the video from one baby monitor at the time. You will receive notifications from the other baby monitors connected. If you receive a notification and tap on it, the app will take you directly to that baby monitor. You can also select the baby monitor you want to view in the left tray.
Why does it take a long time for the app to load?	The Internet connection of your smart device or the WiFi connection of the baby monitor may be slow. Please check the connection of your smart device and of the baby monitor. The app needs a stable network connection.
Is the baby monitor hacker-proof?	We do everything we can to prevent hacking and issue frequent updates. Please make sure that you always use the latest app software and the latest baby monitor firmware. If you lose your smart device, reset the baby monitor to remove any connections to it. You can also log in on the app from another smart device and delete your account. If you are the only administrator, all guest users will be disconnected from the baby monitor too.

Question	Answer
I have lost my smartphone. How can I prevent strangers from viewing my baby?	Log in on the app from another smart device and delete your account. If you are the only administrator, this will disconnect all guest users of the app from the baby monitor tool. You can also reset the baby monitor to disable all connections to the device you lost. You find the reset button on the back of the baby monitor.
Will I be notified of upgrades of the app or the baby monitor software?	Yes, you will receive a notification on your phone to upgrade via the App Store. This will happen periodically. Upgrade notifications for the firmware of the baby monitor will appear in the app along with instructions on how to upgrade.
My phone or tablet becomes warm when I use the app. Is this normal?	Your device needs the power to provide high-quality video. This does not harm your device. To prevent this, we advise you to update your device to the latest iOS and uGrow app version. Your device does not warm up when you run the app in the background.

.g wi

vide high-qualit
we advise you to vion. Your device does i
and.

#### www.philips.com/avent

Philips Consumer Lifestyle BV Tussendiepen 4, 9206 AD Drachten, Netherlands

Trademarks owned by the Philips Group. ©2015 Koninklijke Philips N.V.All rights reserved

www.devicemanuals.eul

