

User Manual

Ipad Active Capacitive Pen



Please read this instructions completely and keep it properly Note: The picture is for reference only, and the appearance is subject to the actual product

Product Details



Product parameter

Model NO: Active capacitive pen Material: metal Paint Anti-mis-touch function: Yes Input: 5V-0.2A Tilt pressure feeling: Yes Bluetooth: No

Pen head: Replaceable pen head

Applicable model: ipad 2018 (version6) A1893/A1954 ipad 2019 (version7) A2197/A2200/A2198 ipad 2020 (version8) A2270/A2428/A2429/A2430 ipad 2021 (version9) A2602/A2603/A2604/A2605 ipad mini (version5) A2133/A2124/A2126/A2125 ipad mini (version6) A2567/A2568/A2569 ipad Air(version3) A2152/A2123/A2153/A2154 ipad Air(version4) A2316/A2324/A2325/A2072 ipad Pro(11 inches) A1980/A2013/A1934/A1979 ipad pro11 inches(version2) A2228/A2068/A2230/A2231 ipad pro11 inches(version3) A2377/A2301/A2459/A2460 ipad Pro12.9 inches(version3) A1983/A2014/A1895/A1876 ipad pro12.9 inches(version4) A2229/A2069/A2232/A2233 ipad pro12.9 inches(version5) A2378/A2379/A2461/A2462 Please confirm that the above models are universal and

other models are invalid. Confirmable model on the back

Product Features

- 1. Stylish and minimalist style, aluminum alloy with piano baking varnish,calm and luxurious, novel and durable.
- 2.Replaceable nib design, no fear of wear and tear! New upgraded tilt and thickening function, the larger the pen tilt area, the thicker the line
- The tip of the pen is made of special conductive materials and finely ground. Artificially create a smooth pen tip to prevent damage to the screen
- Products compatible with iPad 2018 after model (specific model to see product parameters) can be written, painted, recorded
- Continuous use for up to 8-10 hours (for reference only), 5 minutes without using smart power off

Instructions for use

- 1. iPad version is not lower than 12.2;
- 2. Open Settings-Apple Pencil-Turn off only use Apple Pencil to doodle
- 3. Turn on Settings-Bluetooth and close the connection of the original Apple Pen.

(After the above settings are completed, the product can be used normally.)



How to Use

 Double-click the top of the capacitance pen to turn it on, and the indicator lights up blue to start using. Touch the top of the capacitance pen again to turn it off, and the indicator lights out.



 With magnetic adsorption function, it can be adsorbed by lightly putting it on, like Apple Pencil can be adsorbed on the tablet



 Detachable and replaceable nib design, no need to worry about wear and tear! (Lightly twist the nib for easy removal / installation)




(install)

(Disassembly)

How to Charge

of IPAD device

- Please use micro usb/Type-C charging cable to charge, and connect one end to the usb interface of stylus and the other end to the USB interface of computer or tablet. (FIG 1)
- 2. Please connect one end of the data cable to the pen and the other end to the 5V DC power adapter.(FIG 2)
- Directly plug the 5V mobile power supply with usb interface into the stylus to charge. During the charging process, the indicator light will light up, and the whole charging time is about 90 minutes. (FIG 3)



Battery reminder

jobs	A light is on	Battery level 5%-30%
	AB light is on	Battery level 30%-70%
	ABC light is on	Battery level 70%–100%
Low power	A light flashes	Battery is less than 5%
Recharge	A light flashes	Battery level 5%-30%
	A light is on, B light flashes	Battery level 30%-70%
	AB light is on,C light flashes	Battery level 70%–99%
full	ABC light is on	More than 99% battery



正面