



Cisco Nexus 3000 Series NX-OS Release Notes, Release 5.0(3)U5(1)

Release Date: October 29, 2012
Part Number: OL-28183-01 F0
Current Release: Cisco NX-OS Release 5.0(3)U5(1)

This document describes the features, caveats, and limitations for Cisco Nexus 3000 Series switches. Use this document in combination with documents listed in the [“Obtaining Documentation and Submitting a Service Request”](#) section on page 15.



Note

[Table 1-1](#) shows the online change history for this document.

Table 1-1 Online History Change

Part Number	Revision	Date	Description
OL-28183-01	A0	October 25, 2012	Created NX-OS Release 5.0(3)U5(1) release notes.
	B0	October 28, 2012	Updated Table 1-3.
	C0	October 29, 2012	Removed Footnote 5 from 40GBASE-CSR4 QSFP.
	D0	November 1, 2012	Updated Table 1-3 to show support for the Gigabit Ethernet SFP, LC connector SX transceiver (MMF), GLC-SX-MM.
	E0	February 20, 2013	Updated support information for the Cisco Nexus 3064-TQ switch.
	F0	September 18, 2013	Updated resolved caveat CSCuh79034.

Contents

This document includes the following sections:

- [Introduction, page 2](#)



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

- [System Requirements, page 3](#)
- [New and Changed Features, page 10](#)
- [Upgrade Guidelines, page 12](#)
- [Limitations, page 12](#)
- [Caveats, page 12](#)
- [Obtaining Documentation and Submitting a Service Request, page 15](#)

Introduction

The Cisco NX-OS software is a data center-class operating system built with modularity, resiliency, and serviceability at its foundation. Cisco NX-OS helps ensure continuous availability and sets the standard for mission-critical data center environments. The highly modular design of Cisco NX-OS makes zero-effect operations a reality and enables exceptional operational flexibility. Cisco NX-OS software offers the following benefits:

- Cisco NX-OS runs on all Cisco data center switch platforms: Cisco Nexus 7000, Nexus 5000, Nexus 4000, Nexus 3000, Nexus 2000, and Nexus 1000V Series switches.
- Cisco NX-OS software interoperates with Cisco products running any variant of Cisco IOS software and also with any networking operating system that conforms to common networking standards.
- Cisco NX-OS modular processes are triggered on demand, each in a separate protected memory space. Processes are started and system resources are allocated only when a feature is enabled. The modular processes are governed by a real-time preemptive scheduler that helps ensure timely processing of critical functions.
- Cisco NX-OS provides a programmatic XML interface based on the NETCONF industry standard. The Cisco NX-OS XML interface provides a consistent API for devices. Cisco NX-OS also provides support for Simple Network Management Protocol (SNMP) Versions 1, 2, and 3 MIBs.
- Cisco NX-OS enables administrators to limit access to switch operations by assigning roles to users. Administrators can customize access and restrict it to the users who require it.

Cisco Nexus 3000 Series Switches

The Cisco Nexus 3000 Series switches are high-performance, high-density, ultra-low-latency Ethernet switches that provide line-rate Layer 2 and Layer 3 switching. The Cisco Nexus 3000 Series includes the following switches:

- The Cisco Nexus 3064 switch is a 1 RU switch that supports 48 1- or 10-Gigabit downlink ports, four QSFP+ ports that can be used as a 40 Gigabit Ethernet port or 4 x10-Gigabit Ethernet ports, one 10/100/1000 management port, and one console port.
- The Cisco Nexus 3048 switch is a 1 rack unit (RU) switch that supports 48 10/100/1000 Ethernet server-facing (downlink) ports, four 10-Gigabit network-facing (uplink) ports, one 100/1000 management port, and one console port.
- The Cisco Nexus 3016 is a 1 RU, 16-port QSFP+ switch. Each QSFP+ port can be used as a 40-Gigabit Ethernet port or 4 x10-Gigabit Ethernet ports.

Each switch includes one or two power supply units and one fan tray module, and each switch can be ordered with either forward (port-side exhaust) airflow or reverse (port-side intake) airflow for cooling. All platforms support both AC and DC power-supplies. All combinations of power (AC/DC) and airflow (forward/reverse) are available. The Cisco Nexus 3000 Series switches run the industry-leading Cisco NX-OS Software operating system.

For information about the Cisco Nexus 3000 Series, see the [Cisco Nexus 3000 Series Hardware Installation Guide](#).

System Requirements

This section includes the following topics:

- [Memory Requirements, page 3](#)
- [Hardware Supported, page 3](#)
- [Twinax Cable Support on Cisco Nexus 3000 Switches, page 10](#)

Memory Requirements

The Cisco NX-OS Release 5.0(3)U5(1) software requires 135MB of flash memory.

Hardware Supported

Cisco NX-OS Release 5.0(3)U5(1) supports the Cisco Nexus 3000 Series switches. You can find detailed information about supported hardware in the [Cisco Nexus 3000 Series Hardware Installation Guide](#).

[Table 1-2](#) shows the hardware supported by Cisco NX-OS Release 5.0(3) software.

[Table 1-3](#) shows the transceivers supported by Cisco NX-OS Release 5.0(3) software.

Table 1-2 Hardware Supported by Cisco NX-OS Release 5.0(3) Software

Hardware	Part Number	Supported Cisco NX-OS Release						
		5.0(3)U5(1)	5.0(3)U4(1)	5.0(3)U3(2b), 5.0(3)U3(2a), 5.0(3)U3(2), 5.0(3)U3(1)	5.0(3)U2(2d), 5.0(3)U2(2c), 5.0(3)U2(2b)	5.0(3) U2(2a)	5.0(3)U2(2), 5.0(3)U2(1), 5.0(3)U1(2a), 5.0(3)U1(2)	5.0(3) U1(1d)
Cisco Nexus 3000 Series								
Cisco Nexus 3016 switch	N3K-C3016Q-40GE	X	X	X	X	X	—	—
Cisco Nexus 3048 switch	N3K-C3048TP-1GE	X	X	X	X	—	—	—
Cisco Nexus 3064-TQ switch	N3K-C3064TQ-10GT	X ¹	—	—	—	—	—	—
Cisco Nexus 3064-X switch	N3K-C3064PQ-10GX	X	X	X	—	—	—	—

Table 1-2 Hardware Supported by Cisco NX-OS Release 5.0(3) Software (continued)

Supported Cisco NX-OS Release								
Hardware	Part Number	5.0(3)U5(1)	5.0(3)U4(1)	5.0(3)U3(2b) 5.0(3)U3(2a), 5.0(3)U3(2), 5.0(3)U3(1)	5.0(3)U2(2d), 5.0(3)U2(2c), 5.0(3)U2(2b)	5.0(3) U2(2a)	5.0(3)U2(2), 5.0(3)U2(1), 5.0(3)U1(2a), 5.0(3)U1(2)	5.0(3) U1(1d)
Cisco Nexus 3064-E switch	N3K-C3064PQ-10GE	X	X	X	X	X	X	—
Cisco Nexus 3064 switch	N3K-C3064PQ	X	X	X	X	X	X	X
Cisco Nexus 3048 fan module, Forward airflow (port-side exhaust)	N3K-C3048-FAN	X	X	X	X	—	—	—
Cisco Nexus 3048 fan module, Reverse airflow (port-side intake)	N3K-C3048-FAN-B	X	X	X	X	—	—	—
Nexus 3064-T 500W forward airflow (port side exhaust) AC power supply	NXA-PAC-500W	X	X	—	—	—	—	—
Nexus 3064-T 500W reverse airflow (port side intake) AC power supply	NXA-PAC-500W-B	X	X	—	—	—	—	—
Nexus 3064-T 500W forward airflow (port side exhaust) DC power supply	N2200-PDC-400W	X	X	—	—	—	—	—
Nexus 3064-T 500W reverse airflow (port side intake) DC power supply	N3K-PDC-350W-B	X	X	—	—	—	—	—
Cisco Nexus 3064-X forward airflow (port-side exhaust), AC power supply	N3K-C3064-X-FA-L3	X	X	X	—	—	—	—

Table 1-2 Hardware Supported by Cisco NX-OS Release 5.0(3)Software (continued)

Supported Cisco NX-OS Release								
Hardware	Part Number	5.0(3)U5(1)	5.0(3)U4(1)	5.0(3)U3(2b) 5.0(3)U3(2a), 5.0(3)U3(2), 5.0(3)U3(1)	5.0(3)U2(2d), 5.0(3)U2(2c), 5.0(3)U2(2b)	5.0(3) U2(2a)	5.0(3)U2(2), 5.0(3)U2(1), 5.0(3)U1(2a), 5.0(3)U1(2)	5.0(3) U1(1d)
Cisco Nexus 3064-X reversed airflow (port-side intake), AC power supply	N3K-C3064-X-BA-L3	X	X	X	—	—	—	—
Cisco Nexus 3064-X forward airflow (port-side exhaust), DC power supply	N3K-C3064-X-FD-L3	X	X	X	—	—	—	—
Cisco Nexus 3064-X forward airflow (port-side intake), DC power supply	N3K-C3064-X-BD-L3	X	X	X	—	—	—	—
Cisco Nexus 3064 fan module, Forward airflow (port-side exhaust); also used in the Cisco Nexus 3016	N3K-C3064-FAN	X	X	X	X	X	X	X
Cisco Nexus 3064 fan module, Reverse airflow (port-side intake); also used in the Cisco Nexus 3016	N3K-C3064-FAN-B	X	X	X	X	X	X	X
Cisco Nexus 3000 power supply, Forward airflow (port-side exhaust)	N2200-PAC-400W	X	X	X	X	X	X	X
Cisco Nexus 3000 power supply, Reverse airflow (port-side intake)	N2200-PAC-400W-B	X	X	X	X	X	X	X

Table 1-2 Hardware Supported by Cisco NX-OS Release 5.0(3)Software (continued)

Supported Cisco NX-OS Release								
Hardware	Part Number	5.0(3)U5(1)	5.0(3)U4(1)	5.0(3)U3(2b) 5.0(3)U3(2a), 5.0(3)U3(2), 5.0(3)U3(1)	5.0(3)U2(2d), 5.0(3)U2(2c), 5.0(3)U2(2b)	5.0(3) U2(2a)	5.0(3)U2(2), 5.0(3)U2(1), 5.0(3)U1(2a), 5.0(3)U1(2)	5.0(3) U1(1d)
Cisco Nexus 2000 power supply, Forward airflow (port-side exhaust)	N2200-PDC-400W	X	X	X	X	X	X	X
Cisco Nexus 2000 DC power supply, Reverse airflow (port-side intake)	N3K-PDC-350W-B	X	X	X	X	X	X	X

1. Recommended release for the Cisco Nexus 3064-TQ switch is Cisco NX-OS Release 5.0(3)U5(1c).

Table 1-3 Transceivers Supported by Cisco NX-OS Release 5.0(3)Software

Supported Cisco NX-OS Release								
Transceivers	Part Number	5.0(3)U5(1)	5.0(3)U4(1)	5.0(3)U3(2b) 5.0(3)U3(2a), 5.0(3)U3(2), 5.0(3)U3(1)	5.0(3)U2(2c), 5.0(3)U2(2b), 5.0(3)U2(2a), 5.0(3)U2(2)	5.0(3) U2(1)	5.0(3)U1(2), 5.0(3)U1(2a)	5.0(3)U1(1a), 5.0(3)U1(1b), 5.0(3)U1(1d)
QSFP								
Active copper splitter cable 7m	QSFP-4x10G-AC7M ¹	X	—	—	—	—	—	—
Active copper splitter cable 10m	QSFP-4x10G-AC10M ¹	X	—	—	—	—	—	—
Active copper QSFP transceiver module 7m	QSFP-H40G-ACU7M ¹	X	—	—	—	—	—	—
Active copper QSFP transceiver module 10m	QSFP-H40G-ACU10M ¹	X	—	—	—	—	—	—
40GBASE-CSR4 QSFP transceiver module with mpo connector 300 m	QSFP-40G-CSR4 ¹	X	X	—	—	—	—	—
40GBASE-CSR4 QSFP transceiver module with mpo connector 300 m (using fiber splitter cables)	QSFP-40G-CSR4 ¹	X	X	—	—	—	—	—

Table 1-3 Transceivers Supported by Cisco NX-OS Release 5.0(3) Software (continued)

Supported Cisco NX-OS Release								
Transceivers	Part Number	5.0(3)U5(1)	5.0(3)U4(1)	5.0(3)U3(2b), 5.0(3)U3(2a), 5.0(3)U3(2), 5.0(3)U3(1)	5.0(3)U2(2c), 5.0(3)U2(2b), 5.0(3)U2(2a), 5.0(3)U2(2)	5.0(3)U2(1)	5.0(3)U1(2), 5.0(3)U1(2a)	5.0(3)U1(1a), 5.0(3)U1(1b), 5.0(3)U1(1d)
40GBASE-SR4 QSFP transceiver module with mpo connector 100 m	QSFP-40G-SR4 ¹	X	X	X	X	X	X	X
40GBASE-SR4 QSFP transceiver module with mpo connector 100 m (using fiber splitter cables)	QSFP-40G-SR4 ¹	X	X	X	X	X	X	X
40GBASE-CR4 passive copper cable, 1 m	QSFP-H40G-CU1 M	X	X	X	X	X	X	X
40GBASE-CR4 passive copper cable, 3 m	QSFP-H40G-CU3 M	X	X	X	X	X	X	X
40GBASE-CR4 passive copper cable, 5 m	QSFP-H40G-CU5 M	X	X	X	X	X	X	X
QSFP to 4xSFP10G passive copper splitter cable, 1 m	QSFP-4SFP10G-C U1M	X	X	X	X	X	X	X
QSFP to 4xSFP10G passive copper splitter cable, 3 m	QSFP-4SFP10G-C U3M	X	X	X	X	X	X	X
QSFP to 4xSFP10G passive copper splitter cable, 5 m	QSFP-4SFP10G-C U5M	X	X	X	X	X	X	X
Revision 2 copper splitter cables 3m	QSFP-4SFP10G-C U3 (Rev. 2)	X	—	—	—	—	—	—
Revision 2 copper splitter cables 5m	QSFP-4SFP10G-C U5 (Rev. 2)	X	—	—	—	—	—	—
10-Gigabit								
10GBASE-SR SFP+ module (multimode fiber [MMF])	SFP-10G-SR	X	X	X	X	X	X	X

Table 1-3 Transceivers Supported by Cisco NX-OS Release 5.0(3) Software (continued)

Supported Cisco NX-OS Release								
Transceivers	Part Number	5.0(3)U5(1)	5.0(3)U4(1)	5.0(3)U3(2b), 5.0(3)U3(2a), 5.0(3)U3(2), 5.0(3)U3(1)	5.0(3)U2(2c), 5.0(3)U2(2b), 5.0(3)U2(2a), 5.0(3)U2(2)	5.0(3)U2(1)	5.0(3)U1(2), 5.0(3)U1(2a)	5.0(3)U1(1a), 5.0(3)U1(1b), 5.0(3)U1(1d)
10GBASE-LR SFP+ module (single-mode fiber [SMF])	SFP-10G-LR	X	X	X	X	X	X	X
10GBASE-ER SFP+ module (single-mode fiber [SMF])	SFP-10G-ER	X	X	X	X	X	X	X
10GBASE-ZR SFP+ module (single-mode fiber [SMF]) ²	SFP-10G-ZR ²	X	X	X	—	—	—	—
10GBASE-DWD M SFP+ module (single-mode fiber [SMF]) ²	10-2767-01 ²	X	X	X	—	—	—	—
10GBASE-CU SFP+ cable 1 m (Twinax cable)	SFP-H10GB-CU1 M	X	X	X	X	X	X	X
10GBASE-CU SFP+ cable 3 m (Twinax cable)	SFP-H10GB-CU3 M	X	X	X	X	X	X	X
10GBASE-CU SFP+ cable 5 m (Twinax cable)	SFP-H10GB-CU5 M	X	X	X	X	X	X	X
10GBASE-CU SFP+ cable 2 m (Twinax cable) ³	SFP-H10GB-CU2 M ³	X	X	—	—	—	—	—
10GBASE-CU SFP+ cable 2.5 m (Twinax cable) ³	SFP-H10GB-CU2-5M ³	X	X	—	—	—	—	—
Active Optical cable 1m	SFP-10G-AOC1M ⁴	X	—	—	—	—	—	—
Active Optical cable 3m	SFP-10G-AOC3M ⁴	X	—	—	—	—	—	—
Active Optical cable 5m	SFP-10G-AOC5M ⁴	X	—	—	—	—	—	—
Active Optical cable 7m	SFP-10G-AOC7M ⁴	X	—	—	—	—	—	—

Table 1-3 Transceivers Supported by Cisco NX-OS Release 5.0(3) Software (continued)

Supported Cisco NX-OS Release								
Transceivers	Part Number	5.0(3)U5(1)	5.0(3)U4(1)	5.0(3)U3(2b), 5.0(3)U3(2a), 5.0(3)U3(2), 5.0(3)U3(1)	5.0(3)U2(2c), 5.0(3)U2(2b), 5.0(3)U2(2a), 5.0(3)U2(2)	5.0(3) U2(1)	5.0(3)U1(2), 5.0(3)U1(2a)	5.0(3)U1(1a), 5.0(3)U1(1b), 5.0(3)U1(1d)
1-Gigabit Ethernet								
1000BASE-T SFP ⁴	GLC-T ⁴	X	X	X	X	X	X	X
Gigabit Ethernet SFP, LC connector SX transceiver (MMF)	GLC-SX-MM ³	X	X	X	X	X	X	X
Gigabit Ethernet SFP, LC connector SX transceiver (MMF)	GLC-SX-MMD	X	X	—	—	—	—	—
Gigabit Ethernet SFP, LC connector LX/LH transceiver (SMF)	GLC-LH-SM ⁴	X	X	X	X	X	X	X
1000BASE-LX/LH SFP transceiver module for MMF and SMF	GLC-LH-SMD ⁴	X	—	—	—	—	—	—
1000Base BX fiber transceiver	GLC-BX-U ⁴	X	—	—	—	—	—	—
1000Base BX fiber transceiver	GLC-BX-D ⁴	X	—	—	—	—	—	—
1000BASE-T SFP transceiver module with extended operating temperature range	SFP-GE-T ⁴	X	—	—	—	—	—	—
100 Mbps Ethernet								
100BASE-FX SFP module for Gigabit Ethernet ports GLC-GE-100FX ⁵	10-2019-02 ⁵ GLC-GE-100FX	X	X	X	X	X	X	X

1. Supported on the Cisco Nexus 3016, Cisco Nexus 3064-X, Cisco Nexus 3064-T, Cisco Nexus 3064, and Cisco Nexus 3064-E switches.

2. Supported on the Cisco Nexus 3064-E and Cisco Nexus 3064-X switches.

3. Supported on the Cisco Nexus 3048, Cisco Nexus 3064-X, Cisco Nexus 3064, and Cisco Nexus 3064-E switches.

4. Supported on the Cisco Nexus 3048, Cisco Nexus 3064-E, and Cisco Nexus 3064-X switches.

5. Supported on the Cisco Nexus 3064, Cisco Nexus 3064-E, and Cisco Nexus 3064-X switches. For the GLC-GE-100FX, only part number 10-2019-02 is supported.

Twinax Cable Support on Cisco Nexus 3000 Switches

Starting with Cisco Release NX-OS 5.0(3)U1(1), the following algorithm is used to detect SFP+ twinax cables on Cisco Nexus 3000 switches:

If the attached interconnect (transceiver) is a twinax cable:

- Verify the transceiver SPROM to match Cisco magic code.
- If the check succeeds, bring up the interface; else check whether the Vendor Part Number (PN) has been certified.
- If the Vendor PN is certified, bring up the interface; else print the following warning message stating that a non-Cisco transceiver is attached and try to bring up the port.

```
2009 Oct 9 01:46:42 switch %ETHPORT-3-IF_NON-CISCO_TRANSCEIVER: Non-Cisco transceiver
on interface Ethernet1/18 is detected.
```

Starting with Cisco Release NX-OS 5.0(3)U3(1), the following algorithm is used to detect copper splitter (QSFP) cables on Cisco Nexus 3000 switches:

A Cisco Nexus 3000 switch allows any copper splitter (QSFP, connector type 0x21) cable to come up, however the following disclaimer applies to non-Cisco manufactured and non-Cisco certified QSFP copper splitter cables.

Cisco Service and Support

If a customer has a valid support contract for Cisco Nexus switches, Cisco TAC will support twinax cables that are a part of the compatibility matrix for the respective switches. However, if the twinax cables are not purchased through Cisco, a customer cannot return these cables through an RMA to Cisco for replacement.

If a twinax cable that is not part of the compatibility matrix is connected into a system, Cisco TAC will still debug the problem, provided the customer has a valid support contract on the switches. However TAC may ask the customer to replace the cables with Cisco qualified cables if there is a situation that points to the cables possibly being faulty or direct the customer to the cable provider for support. Cisco TAC cannot issue an RMA against uncertified cables for replacement.

New and Changed Features

This section describes the new features introduced in Cisco NX-OS Release 5.0(3)U5(1). This section includes the following topics:

- [New Supported Hardware, page 10](#)
- [New Software Features, page 11](#)

New Supported Hardware

Cisco NX-OS Release 5.0(3)U5(1) does not include new hardware.

New Software Features

All Cisco Nexus 3000 Series switches are supported by Cisco NX-OS Release 5.0(3)U5(1). Cisco NX-OS interoperates with any networking OS, including Cisco IOS software, that conforms to the networking standards mentioned in the product data sheet.

New Software Features in Cisco NX-OS Release 5.0(3)U5(1)

Cisco NX-OS Release 5.0(3)U5(1) is a minor release that includes bug fixes and the following new software features and enhancements:

SVI Autostate Disable

The SVI autostate disable feature allows a user to keep a SVI up, even when no interfaces are up in the corresponding VLAN.

IP Multicast MIB

This release supports the IP Multicast MIB.

Configurable Source Interface for Syslog

In Cisco NX-OS Release 5.0(3)U5(1), a user can configure a variety of interfaces as the source interface for system logging messages.

Configurable SPAN Buffer Limit

This feature allows a user to configure the maximum SPAN buffer limit on a monitor port.

ECMP Routing and Port-Channel Load-Balancing Hash

In Cisco NX-OS Release 5.0(3)U5(1), added support with a show command that provides ECMP hashing result used by hardware to forward the given traffic flow. Added support to avoid ECMP polarization by allowing configuration of a different hash offset for each tier.

BGP Disable Peer AS Check

Added support for allowing eBGP learned routes to be advertised to the peers in the same autonomous system.

POAP Enhancement

Added support for POAP enhancement that includes:

- DCHP option 60 (device type) in the DCHP messages.
- Verify MD5 Checksum before the image download.

Upgrade Guidelines

Cisco NX-OS Release 5.0(3)U3(1) does not support a software upgrade from Cisco NX-OS Release 5.0(3)U2(2c). If you want to upgrade through this path, see [CSCty75328](#) for details about how to work around this issue.



Note

This restriction does not apply to Cisco NX-OS Release 5.0(3)U3(2a) and Cisco NX-OS Release 5.0(3)U3(2).

In Cisco NX-OS Release 5.0(3)U3(1), support for IPv6 has been added in CoPP. To enable redirection of IPv6 control packets to the CPU, IPv6 CoPP must be configured on the system. Performing the write erase command on a device running Release 5.0(3)U3(1) automatically applies CoPP on the device and ensures that all IPv4 and IPv6 related CoPP configuration is setup correctly.

If you upgrade from a Cisco NX-OS release that does not support the CoPP feature to a release that does support the CoPP feature, you must run the setup utility after the upgrade to enable CoPP on the device.

If you upgrade from Cisco NX-OS Release 5.0(3)U2(2) (which supports the CoPP feature) to Cisco NX-OS Release 5.0(3)U3(1) (which adds CoPP classes for IPv6 support), you must run the setup script to enable the IPv6 CoPP feature on the device.

Limitations

There are no known limitations for Cisco NX-OS Release 5.0(3)U5(1).

Caveats

Open and resolved caveat record numbers are provided with links to the Bug Toolkit where you can find details about each caveat.

This section includes the following topics:

- [Resolved Caveats in Cisco NX-OS Release 5.0\(3\)U5\(1\), page 12](#)
- [Open Caveats in Cisco NX-OS Release 5.0\(3\)U5\(1\), page 13](#)


Resolved Caveats in Cisco NX-OS Release 5.0(3)U5(1)

[Table 1-4](#) lists descriptions of resolved caveats in Cisco NX-OS Release 5.0(3)U5(1). The record ID links to the Cisco Bug Toolkit where you can find details about the caveat.

Table 1-4 Cisco NX-OS Release 5.0(3)U5(1)—Resolved Caveats

Record Number	Resolved Caveat Headline
CSCty83151	Provide Netstack BGP authentication for prefix-based neighbors.
CSCub55490	If the source and receiver are on different switch virtual interfaces (SVIs) in the last-hop router (LHR), the (S, G) entry is not created for the link-local address aliasing group.

Table 1-4 Cisco NX-OS Release 5.0(3)U5(1)—Resolved Caveats (continued)

Record Number	Resolved Caveat Headline
CSCub66729	The Multicast Source Discovery Protocol (MSDP) Source-Active (SA) cache fails on non-default VPN routing and forwarding (VRF) instance.
CSCub80210	Python transfer() function to the http server fails in default VRF.
CSCuc73943	OSPF does not install all ECMP paths in the RIB.
CSCuh79034	High CPU utilization due to bcm_usd and syslogd causing protocol flaps.
	 Note This caveat was resolved in Cisco NX-OS Release 5.0(3)U5(1g)

Open Caveats in Cisco NX-OS Release 5.0(3)U5(1)

Table 1-5 lists descriptions of open caveats in Cisco NX-OS Release 5.0(3)U5(1). The record ID links to the Cisco Bug Toolkit where you can find details about the caveat.

Table 1-5 Cisco NX-OS Release 5.0(3)U5(1) —Open Caveats

Record Number	Open Caveat Headline
CSCtz64709	A Cisco Nexus 3000 Series switch incorrectly forwards an echo request from an unspecified (::) address.
CSCub91054	A Cisco Nexus 3000 Series switch cannot resolve a domain name from a copy command.
CSCub91090	A Cisco Nexus 3000 Series switch IPv6 route is impacted by a down interface.
CSCuc18788	The show load-balance command displays an incorrect egress interface for non-IP traffic.
CSCuc21712	A SPAN buffer does not use the complete configured buffer.
CSCuc29982	Ports become active when configured with the wrong speed and a GLC-SX-MMD or GLC-LH-SMD SFP is inserted in a Cisco Nexus 3000 Series switch.
CSCuc31412	Layer 3 routed ports are added as part of Layer 2 VLANs in hardware.
CSCuc32159	EIGRP routes that are learned through a Layer 3 port channel take approximately 20 seconds to converge on the failure of the Layer 3 port channel.
CSCuc34673	When shutting a range of all uplink ports on a Cisco Nexus 3048 switch where a GLC-BX-U SFP was inserted, the ports appear up on the peer switch.
CSCuc35912	Multicast traffic is duplicated with ECMP enabled.
CSCuc44153	A MAC address is not learned, but ARP is resolved on reload of both vPC peers.
CSCuc44353	In a Multicast Source Discovery Protocol (MSDP) configuration, different values are shown for ipMcastNextHopRouteProtocol.
CSCuc50368	SNMP CLI does not accept the AES authentication password.
CSCuc50968	A dual Protocol Independent Multicast (PIM) designated router (DR) scenario stops working in a vPC after subsequent reloads.
CSCuc56928	The initial PowerOn Auto Provisioning (POAP) discovery phase fails a few times before successful POAP iteration.

Table 1-5 Cisco NX-OS Release 5.0(3)U5(1) —Open Caveats (continued)

Record Number	Open Caveat Headline
CSCuc57875	Syslog is not using the outgoing interface address as the source interface when the logging source-interface is modified.
CSCuc58104	A FabricPath entry programming issue occurs with DHCP relay.
CSCuc59987	The interface storm control counter does not show the suppress value.
CSCuc64329	A route map is misinterpreted when used in configuring the rp-address in Protocol Independent Multicast (PIM).
CSCuc67363	The show load-balance command does not display the tunnel interface.
CSCuc70495	A change in the route-map match multicast group list is not reflected in the output of the show ip pim rp vrf command.
CSCuc71247	PVLAN vPC ports are inactive on the secondary switch with the reason “VLAN is not configured on remote vPC.”
CSCuc73455	Authentication fails on the AAA server with -while loopback interface is the global source-interface.
CSCuc77993	The SVI interface remains up with autostate enabled when all the interfaces are down.

Related Documentation

Documentation for the Cisco Nexus 3000 Series Switch is available at the following URL:

http://www.cisco.com/en/US/products/ps11541/tsd_products_support_series_home.html

The documentation set is divided into the following categories:

Release Notes

The release notes are available at the following URL:

http://www.cisco.com/en/US/products/ps11541/prod_release_notes_list.html

Installation and Upgrade Guides

The installation and upgrade guides are available at the following URL:

http://www.cisco.com/en/US/products/ps11541/prod_installation_guides_list.html

Command References

The command references are available at the following URL:

http://www.cisco.com/en/US/products/ps11541/prod_command_reference_list.html

Technical References

The technical references are available at the following URL:

http://www.cisco.com/en/US/products/ps11541/prod_technical_reference_list.html

Configuration Guides

The configuration guides are available at the following URL:

http://www.cisco.com/en/US/products/ps11541/products_installation_and_configuration_guides_list.html

Error and System Messages

The system message reference guide is available at the following URL:

http://www.cisco.com/en/US/products/ps11541/products_system_message_guides_list.html

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to nexus3k-docfeedback@cisco.com. We appreciate your feedback.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2012 Cisco Systems, Inc. All rights reserved.

