

WHEEL LIGHT INSTRUCTIONS


Note: After receiving the goods, please use 12V power supply to test the installation

Material: PVC+ LED lamp beads

Voltage: 12V

Control mode: mobile APP/ remote control

Installation: car brake disc baffle



Corresponding controller wiring




COLOR CONNECTION

- Positive pole/ACC
- The brake
- dextroversion
- Left turn
- Negative electrode



MULTICOLOR CONTROLLER

- Positive pole/ACC
- Negative electrode



FOUR ROWS OF WHITE AND YELLOW

- Positive pole/ACC
- Negative electrode
- Right turn
- Left turn
- driving mode




THREE ROWS OF FANCY COLORS


- Positive pole/ACC
- Negative electrode
- Right turn
- Left turn
- driving mode
- brake




Qr code APP




APP icon



Corresponding remote control instructions



Screw glue



- ① Remove the original wheel hub
- ② Mark the installation position of the support and drill holes
- ⑦ Clamp the light strip into the bracket
- ⑧ Fasten the lamp strip with screws



- ③ Use the appropriate drill bit according to the screw size
- ④ Glue the screws before installing the lamp stand
- ⑨ Note: Keep the installation direction light lines consistent
- ⑩ Tie the light wire into the front of the car along the slit



- ⑤ Install the light bar support
- ⑥ Use screws to lock
- ⑪ Control box avoid high temperature
- ⑫ The installation is complete and the final cable is connected

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.