

# SoundBuds Flow

## Owner's Manual

---

### Safety Instructions

- ① Avoid dropping.
- ② Do not disassemble.
- ③ Do not submerge in water.
- ④ The product shall not be exposed to dripping or splash.
- ⑤ Avoid extreme temperatures.
- ⑥ The battery shall not be exposed to excessive heat such as sunshine, fire or the like.
- ⑦ Use original or certified cables.
- ⑧ Do not use any corrosive cleaner/oil to clean.
- ⑨ Do not use the product outdoors during thunderstorms.
- ⑩ Keep out of reach of children. It contains small parts which may be a choking hazard.



### Hearing Safety

- ① To avoid hearing damage, do not listen for extended periods at high volume.
- ② Do not turn the volume so high that you're unable to hear your surroundings.
- ③ Do not use earphones while driving.
- ④ You should use caution or temporarily discontinue use in potentially hazardous situations.

### FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.


This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.





RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.









### On / Off

ON	 Press and hold for 1 second	 Flashing blue once
OFF	 Press and hold for 3 seconds	 Flashing red once






### Charging





 Flashing red	Low battery
 Steady red	Charging
 Steady blue	Fully charged

 **Pairing**







Enter pairing mode	 Press and hold for 3 seconds
Un-pair connected device and re-enter pairing mode	 Press and hold for 3 seconds






 Rapidly flashing blue	Pairing mode
 Steady blue	Connected to a device



 **Controls**




Play / Pause	 Press
Next track	 Press and hold for 1 second
Previous track	 Press and hold for 1 second
Volume up / down	 Press



Answer / End call	 Press
Reject call	 Press and hold for 1 second
Put current call on hold and answer incoming call	 Press
Switch between held call and active call	 Press and hold for 1 second
Transfer a call between headphones and mobile phone	 Press and hold for 1 second

 Steady blue	On a call
 Flashing blue	Incoming call



Activate Siri / other voice control software	 Press and hold for 1 second
--	---

---

## Specifications

Note: Specifications are subject to change without notice.

Input	5 V = 0.1 A
Charging time	1.5 hours
Play time (varies by volume level and content)	7 hours
Weight	16 g / 0.56 oz
Impedance	16 $\Omega$
Driver (full range)	6 mm x 2
Frequency response	20 Hz - 20 KHz
Bluetooth version	V4.1
Range	10 m / 33 ft

---

Product Number A3234  
Bluetooth Headphone / SoundBuds Flow

---