



Cisco DCNM Compatibility Matrix, Release 11.2(1)

[Cisco DCNM Compatibility Matrix](#) 2

[Compatibility Matrix for Cisco DCNM, Release 11.2\(1\)](#) 2

Cisco DCNM Compatibility Matrix

Compatibility Matrix for Cisco DCNM, Release 11.2(1)

The below table shows the Cisco DCNM Compatibility Matrix for Release 11.2(1).



Note Cisco [DCNM Compatibility Matrix Tool](#) provides an intuitive/interactive tool to find the NXOS version compatible with the DCNM release version.

Table 1: Compatibility Matrix for Cisco DCNM, Release 11.2(1)

Cisco MDS 9100	6.2(29), 8.4(1), 6.2(27), 8.3(2), 8.3(1), 8.2(2), 8.2(1), 8.1(1a), 8.1(1), 7.3(1)DY(1), 7.3(1)D1(1), 7.3(0)DY(1), 7.3(0)D1(1), 6.2(25), 6.2(23), 6.2.(21), 6.2(19), 6.2(17), 6.2(15), 6.2(13b), 6.2(13a), 6.2(13), 6.2(11c), 6.2(11b), 6.2(11), 6.2(9c), 6.2(9b), 6.2(9a), 6.2(9), 6.2(7), 6.2(5a), 6.2(5), 6.2(3), 6.2(1), 5.2(8i), 5.2(8h), 5.2(8c), 5.2(8d), 5.2(8e), 5.2(8f), 5.2(8g)
Cisco MDS 9200	6.2(29), 8.4(1), 6.2(27), 8.3(2), 8.3(1), 8.2(2), 8.2(1), 8.1(1a), 8.1(1), 7.3(1)DY(1), 7.3(1)D1(1), 7.3(0)DY(1), 7.3(0)D1(1), 6.2(25), 6.2(23), 6.2.(21), 6.2(19), 6.2(17), 6.2(15), 6.2(13b), 6.2(13a), 6.2(13), 6.2(11c), 6.2(11b), 6.2(11), 6.2(9c), 6.2(9b), 6.2(9a), 6.2(9), 6.2(7), 6.2(5a), 6.2(5), 6.2(3), 6.2(1), 5.2(8h), 5.2(8c), 5.2(8d), 5.2(8e), 5.2(8f), 5, 2(8g)
Cisco MDS 9300	6.2(29), 8.4(1), 6.2(27), 8.3(2), 8.3(1), 8.2(2), 8.2(1), 8.1(1a), 8.1(1), 7.3(1)DY(1), 7.3(1)D1(1), 7.3(0)DY(1), 7.3(0)D1(1), 6.2(25), 6.2(23), 6.2.(21), 6.2(19), 6.2(17), 6.2(15), 6.2(13b), 6.2(13a), 6.2(13)
Cisco MDS 9500	6.2(29), 6.2(27), 7.3(1)DY(1), 7.3(1)D1(1), 7.3(0)DY(1), 7.3(0)D1(1), 6.2(25), 6.2(23), 6.2.(21), 6.2(19), 6.2(17), 6.2(15), 6.2(13b), 6.2(13a), 6.2(13), 6.2(11c), 6.2(11b), 6.2(11), 6.2(9c), 6.2(9b), 6.2(9a), 6.2(9), 6.2(7), 6.2(5a), 6.2(5), 6.2(3), 6.2(1), 5.2(8h), 5.2(8c), 5.2(8d), 5.2(8e), 5.2(8f), 5.2(8g)
Cisco MDS 9700	6.2(29), 8.4(1), 6.2(27), 8.3(2), 8.3(1), 8.2(2), 8.2(1), 8.1(1a), 8.1(1), 7.3(1)DY(1), 7.3(1)D1(1), 7.3(0)DY(1), 7.3(0)D1(1), 6.2(25), 6.2(23), 6.2.(21), 6.2(19), 6.2(17), 6.2(15), 6.2(13b), 6.2(13a), 6.2(13), 6.2(11c), 6.2(11b), 6.2(11), 6.2(9c), 6.2(9b), 6.2(9a), 6.2(9), 6.2(7), 6.2(5a), 6.2(5), 6.2(3), 6.2(1)
Cisco Nexus 9000v	9.3(2), 9.2(4), 9.3(1), 9.2(3), 9.2(1), 7.0(3)I7(3), 7.0(3)I7(2), 7.0(3)I7(1), 7.0(3)I6(2)
Cisco Nexus 9000 Series	9.3(2), 9.2(4), 9.3(1), 9.2(3), 7.0(3)I4(9), 7.0(3)I7(6), 9.2(2), 9.2(1), 7.0(3)I7(5), 7.0(3)I7(4), 7.0(3)I7(3), 7.0(3)I7(2), 7.0(3)I7(1), 7.0(3)I4(8), 7.0(3)I4(7), 7.0(3)I4(6), 7.0(3)I4(5), 7.0(3)I4(4), 7.0(3)I4(3), 7.0(3)I4(2), 7.0(3)I4(1), 7.0(3)F3(2), 7.0(3)F3(1), 7.0(3)F1(2), 7.0(3)I6(2), 7.0(3)I6(1), 7.0(3)F2(1), 7.0(3)F1(1), 7.0(3)I2(4), 7.0(3)I2(5), 7.0(3)I5(2), 7.0(3)I5(1), 7.0(3)I3(2), 7.0(3)I3(1), 7.0(3)I2.3, 7.0.3.I2.2c, 7.0(3)I2.2a, 7.0(3)I2.1, 7.0(3)I1.3, 7.0(3)I1.2, 6.2(9), 6.1(2)I3.4, 6.1(2)I3.2, 6.1(2)I3(1), 6.1(2)I2(1), 6.1(2)I1(2), 6.1(2)I1(1)

Cisco Nexus 7000 Series	8.4(1), 8.2(4), 7.3(4)D1(1), 6.2(22), 8.3(2), 8.3(1), 8.2(3), 8.2(2), 8.2(1), 8.1(2), 8.1(1), 8.0(1), 7.3(3) D1(1), 7.3(2)D1(3), 7.3(2)D1(2), 7.3(2)D1(1), 7.3(1)D1(1), 7.3(0)DX(1), 7.3(0)D1(1), 7.2(2)D1(4), 7.2(2)D1(2), 7.2(2)D1(1), 7.2(1)D1(1), 7.2(0)D1(2), 7.2(0)D1(1), 6.2(20), 6.2(18), 6.2(16), 6.2(14), 6.2(12), 6.2(10), 6.2(8), 6.2(6a), 6.2(6), 6.2(2a), 6.2(2), 6.1, 6.0, 5.2, 5.1, 5.0, 4.2, 4.1, 4.0
Cisco Nexus 7700 Series	8.4(1), 8.2(4), 7.3(4)D1(1), 6.2(22), 8.3(2), 8.3(1), 8.2(3), 8.2(2), 8.2(1), 8.1(2), 8.1(1), 8.0(1), 7.3(3) D1(1), 7.3(2)D1(3), 7.3(2)D1(2), 7.3(2)D1(1), 7.3(1)D1(1), 7.3(0)DX(1), 7.3(0)D1(1), 7.2(2)D1(4), 7.2(2)D1(2), 7.2(2)D1(1), 7.2(1)D1(1), 7.2(0)D1(2), 7.2(0)D1(1), 6.2(20), 6.2(18), 6.2(16), 6.2(14), 6.2(10), 6.2(8), 6.2(6a), 6.2(6), 6.2(2a), 6.2.2
Cisco Nexus 6000/5600 Series	7.3(5)N1(1), 7.1(5)N1(1b), 7.3(4)N1(1), 7.3(3)N1(1), 7.3(2)N1(1e), 7.3(2)N1(1), 7.3(1)N1(1), 7.3(0)N1(1), 7.2(1)N1(1), 7.1(5)N1(1), 7.2(0)N1(1), 7.1(5)N1(1), 7.1(4)N1(1), 7.1(3)N1(2), 7.1(3)N1(1), 7.1(2)N1(1), 7.1(1)N1(1), 7.1(0)N1(1), 7.0(8)N1(1), 7.0(7)N1(1), 7.0(6)N1(1), 7.0(5)N1(1), 7.0(4)N1(1), 7.0(3)N1(1), 7.0(2)N1(1), 7.0(1)N1(1), 6.0(2)N2(7), 6.0(2)N2(2), 6.0(2)N2(1), 6.0(2)N1(2)
Cisco Nexus 5000 Series	7.3(5)N1(1), 7.1(5)N1(1b), 7.3(4)N1(1), 7.3(3)N1(1), 7.3(2)N1(1e), 7.3(2)N1(1), 7.3(1)N1(1), 7.3(0)N1(1), 7.2(1)N1(1), 7.2(0)N1(1), 7.1(5)N1(1), 7.1(4)N1(1), 7.1(3)N1(2), 7.1(3)N1(1), 7.1(2)N1(1), 7.1(1)N1(1), 7.1(0)N1(1), 7.0(8)N1(1), 7.0(7)N1(1), 7.0(6)N1(1), 7.0(5)N1(1), 7.0(4)N1(1), 7.0(3)N1(1), 7.0(2)N1(1), 7.0(1)N1(1), 6.0(2)N2(7), 6.0(2), 5.2(1)N1(9a), 5.2(1)N1(9), 5.2(1), 5.1(3), 5.0(3), 5.0(2), 4.2(1), 4.1(3)
Cisco Nexus 4000 Series	4.1(2)
Cisco Nexus 3600 Series	9.2(4), 9.3(1), 9.2(3), 9.2(2)
Cisco Nexus 3500 Series	9.2(4), 9.3(1), 9.2(3), 9.2(2), 9.2(1), 7.0(3)I7(5), 7.0(3)I7(1), 7.0(3)I2(4), 7.0(3)I2(5), 7.0(3)I4(5), 7.0(3)I4(6), 7.0(3)I4(7), 7.0(3)I4(8), 7.0(3)I5(2), 7.0(3)I5(1), 7.0(3)I4(4), 7.0(3)I4(3), 7.0(3)I4(2), 7.0(3)I4(1), 7.0(3)i3(2), 7.0(3)I3(1), 7.0(3)I2.3, 7.0(3)I2.2a, 7.0(3)I2.1, 6.0(2)U3(2), 6.0(2)A8(9), 6.0(2)A3(1), 6.0(2)A1(1d), 5.0(3)A1(2a)
Cisco Nexus 3100 Series	9.2(4), 9.3(1), 9.2(3), 7.0(3)I4(9), 7.0(3)I7(6), 9.2(2), 9.2(1), 7.0(3)I7(5), 7.0(3)I7(4), 7.0(3)I4(8), 7.0(3)I4(7), 7.0(3)I7(3), 7.0(3)I7(2), 7.0(3)I7(1), 7.0(3)I6(2), 7.0(3)I6(1), 7.0(3)I2(4), 7.0(3)I2(5), 7.0(3)I4(5), 7.0(3)I4(6), 7.0(3)I4(7), 7.0(3)I4(8), 7.0(3)I5(2), 7.0(3)I5(1), 7.0(3)I4(4), 7.0(3)I4(3), 7.0(3)I4(2), 7.0(3)I4(1), 7.0(3)I3(1), 7.0(3)I2.3, 7.0(3)I2.2a, 7.0(3)I2.1, 6.0(2)U3(2), 6.0(2)U3(1), 6.0(2)U2(1), 6.0(2)U2(1)
Cisco Nexus 3000 Series	9.2(4), 9.3(1), 9.2(3), 7.0(3)I4(9), 7.0(3)I7(6), 9.2(2), 9.2(1), 7.0(3)I7(5), 7.0(3)I7(4), 7.0(3)I4(8), 7.0(3)I4(7), 7.0(3)I7(3), 7.0(3)I7(2), 7.0(3)I7(1), 7.0(3)I6(2), 7.0(3)I6(1), 7.0(3)I2(4), 7.0(3)I2(5), 7.0(3)I4(5), 7.0(3)I4(6), 7.0(3)I4(7), 7.0(3)I4(8), 7.0(3)I5(2), 7.0(3)I5(1), 7.0(3)I4(4), 7.0(3)I4(3), 7.0(3)I4(2), 7.0(3)I3(2), 7.0(3)I3(1), 7.0(3)I2.3, 7.0(3)I2.2a, 7.0(3)I2.1, 6.0(2)U3(2), 6.0(2)U3(1), 6.0(2)U2(3), 6.0(2)U2(1), 6.0(2)U1(3), 6.0(2)A1(1b), 6.0(2)A1(1a), 6.0(2)A1(1), 6.0(2)U1(2), 6.0(2)U1(1), 5.0(3)U5(1i), 5.0(3)U4(1), 5.0(3)A1(2a), 5.0(3)U5(1e), 5.0(3)U4, 5.0(3)U3, 5.0(3)U2, 5.0(3)U1,
Cisco Nexus 1010 Series	4.2(1)SP1(6.1), 4.2(1)SP1(5.1a), 4.2(1)SP1(4a)
Cisco Nexus 1000v Series	5.2(1)SV3(1.4), 4.2(1)SV2(2.3), 4.2(1)SV2(2.2), 4.2(1)SV2(2.1), 4.2(1)SV2(1.1), 4.2(1)SV1(4), 5.2(1)SM1(5.1)
UCS Infrastructure and UCS Manager Software	4.0.4, 4.0.1, 3.2(3k), 2.2.5a



Note The Cisco NX-OS version of the Cisco Nexus 2000 Series Fabric Extenders will be same as the NX-OS version of the supported Nexus switch (that is, Cisco Nexus 5000, Cisco Nexus 7000 or Cisco Nexus 9000).

Compatibility Matrix for Each Installation Type

Table 2: Supported Switch Versions for Cisco DCNM 11.2(1)

Installation Type	Switch Versions
LAN Classic	See Table 1: Compatibility Matrix for Cisco DCNM, Release 11.2(1) .
LAN Fabric	<ul style="list-style-type: none"> • Newly provisioned VXLAN fabrics using DCNM (Easy_Fabric_11_1, Easy_Fabric_eBGP and MSD_Fabric_11_1): 9.2(3), 9.2(2), 7.0(3)I7(6)* • External Fabric N3000/3100/3500 (External_Fabric_11_1): 7.0(3)I7(6)* • External Fabric N3600 (External_Fabric_11_1): 9.2(3) • External Fabric N5000/5600/6000 (External_Fabric_11_1): 7.3(5)N1(1)* • External Fabric N7000/7700 (External_Fabric_11_1): 7.3(3)D1(1)*, 8.2(3)* • External Fabric N9000 (External_Fabric_11_1): 9.2(3), 9.2(2), 7.0(3)I7(6)* • Migrating NFM-managed VXLAN fabric to DCNM (Easy_Fabric_11_1): 7.0(3)I7(6)* • Migrating Switch Command line configured VXLAN fabrics to DCNM (Easy_Fabric_11_1): 9.2(2), 7.0(3)I7(6)*, 7.0(3)I7(5a), 7.0(3)I4(9), 7.0(3)I4(8b)
IP Fabric for Media (IPFM)	9.3(2), 9.3(1), and 9.2(3)
SAN	See the SAN supported switches in Table 1: Compatibility Matrix for Cisco DCNM, Release 11.2(1) .

*Indicates the recommended NX-OS version

Interoperability Matrix for Cisco Nexus and MDS 9000 Products

For Cisco DCNM Connect Support, see the [Interoperability Matrix for Cisco Nexus and MDS 9000 Products](#).



Americas Headquarters
Cisco Systems, Inc.
San Jose, CA 95134-1706
USA

Asia Pacific Headquarters
CiscoSystems(USA)Pte.Ltd.
Singapore

Europe Headquarters
CiscoSystemsInternationalBV
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.